



DCS400
USER'S MANUAL



THE SEEKER 400
WIRELESS
VIDEO INSPECTION SYSTEM

Please read this manual carefully and thoroughly before using this product.

CONTENTS

Welcome	1
Features	1
Packing List	1
Structure	2
Operation	5
Basic Operation	5
Other Operation and Settings for Monitor	6
Record Video	6
Take Photo	7
Play Video/Picture	7
Delete Video/Picture	8
Delete Folder	9
Language Setting	9
Video System Setting	10
Format	10
Default Setup	10
View Version Information	11
Frame Rate Setting	11
Time Stamp Setting	11
Recording Type	12
Date/Time Setting	12
Event Playback	12
Specifications	13
FCC Information	14

WELCOME

Thanks you for purchasing our data-logging wireless inspection camera scope. Please read the User's Manual carefully before using this product.


The product is designed as a remote inspection device. It can be used to look into tight spots and beam back real time video to monitor and record video/take pictures.

Typical applications may include HVAC inspection, automotive inspection, cable routing, automotive/boat/aircraft inspection, etc.



FEATURES

- 3.5" (88.9mm) TFT-LCD Wireless Color Monitor, can be detached from the unit for remote viewing up to 32.8ft (10m) away
- 3.28ft (1m) Flexible Waterproof (IP67) Obedient Probe retains configured shape
Standard Length: 3.28ft (1m)
Optional Length: up to 18ft (5.5m)
- 0.67" (17mm) diameter Camera-tipped Probe has built-in adjustable LED lighting
- Records in Still Photo (JPEG) and Video (AVI), or view it live
- Records up to 3 hours continuously
- NTSC or PAL compatible
- Choices of 10 languages in the menu: English, Spanish, French, German, Chinese, Portuguese, Italian, Japanese, Dutch, and Russian

PACKING LIST



STRUCTURE





INSTALLATION

Please install the batteries, probe and insert the SD card first before using product, and choose the accessory according to actual situation.

Please follow the installation steps listed below:

Install Batteries

1. Using a screwdriver, remove screw and cover.



2. Remove battery compartment and insert four new “AA” batteries into the proper slots in the battery compartment. Proper battery orientation is indicated on the battery compartment.



3. Reinstall battery compartment and battery cover and screw as previous.

NOTE! Dry your hands before installation or replacing batteries.


Install the Camera with Flexible Probe

Connect the camera with the probe; make sure the keyed ends are properly aligned. Once they are aligned, tighten the knurled knob to hold the connection in place.



Install Accessory

The three accessories include (mirror, hook and magnet), all are attached to the camera by the same way. Install as follows:



Make sure the stem is placed at side face from the arrow mark, and tighten to secure the accessories in place.



Install Monitor for Wired Use

The product also supports wired use by connecting the monitor to the camera.






Connect Magnetic Base Stand to the Monitor

The magnetic base stand allows user to stick the monitor on any metal surface for true hands-free and wireless viewing. Connect it to the monitor as shown in the following diagram:




Insert SD Card

After the SD card was inserted successfully into SD card socket, “” icon will appear on the screen; otherwise, “” icon will appear.



Connect USB Cable


Use the USB cable to connect the monitor to a PC. The USB online icon appears on the PC. Open **My Computer**, and find the **Mobile Disk**, the video/picture files in SD card could be copied/cut/played back.



NOTE! If the video files do not play on the PC normally, please install the plug-in the enclosed CD-ROM.

Connect Monitor Power

Connect the adapter to the monitor, the red power indicator will light or the battery capacity icon on LCD of the monitor will flicker which indicates charging, and will turn off after a full charge.



Video Output



Insert the video cable into the VIDEO OUT socket of monitor.



Insert the other end of the cable into the VIDEO IN jack of a TV or another monitor. The LCD Monitor will output a high quality video.



OPERATION

Basic Operation


1. Roll the ON/OFF switch to turn ON the camera, and the power indicator will light up. The switch then acts as a dimmer for the twin LED's that surrounds the camera on the camera head and provides lighting.





2. Press and hold on the Power ON/OFF button of the monitor for 2 seconds, and power indicator will be green, then press  button to select the CH4 (channel 4) and the picture will display on LCD of the monitor and press  button to select recording video or take pictures status:



3. Roll the ON/OFF switch of camera for a better image effect.




4. When in use, maneuver the probe into position.



TIP! The flexible probe can be bent into a certain shape. This may help you insert the probe into narrow areas.


5. The accessories can be used to retrieve small items such as dropped rings or screws.




Other Operation and Settings for Monitor

Record Video

1. In the real time monitoring status, press **▲** button to enter VIDEO status as follows:



2. Press OK button to record as follows:




3. Press OK button again to stop recording.

Notice!


- * The Video will be automatically saved as a file every 30 minutes.
- * SD card is full when the SD card icon changes to “**F**”

Take photo


1. In the real time monitoring status, press  button to switch to photo taking status as follows:




2. Press OK button to take photo.


Notice! when the SD card icon changes to "" it means the SD card is full.

Play Video/Picture



1. In the real time monitoring status, press  button to enter into the following interface:




2. Press  or  button to select folder, then press OK button to enter into it:



3. **For Video:**

Press  or  button to select video, then press the OK button to play as following interface:




Pause: press OK button in playing status to pause;
press again to resume;
Fast Forward: press ▲ button in playing status
Fast Backward: press ▼ button in playing status
Stop/Exit: press ≡ button.

For Picture:


Press ▲ or ▼ button to select picture, then press OK button to display. Press the OK button again to exit.

Delete Video/Picture


1. In the real time monitoring status, press ≡ button once to enter into the following interface:



2. Press ▲ or ▼ button to select folder, then press OK button to enter into the following interface:




3. Press ▲ or ▼ button to select file, press and hold on ≡ button for 2 seconds will enter the following interface:



4. Press ▲ or ▼ button to select YES , then press OK button will be deleted has been selected by the file; NO will be exit.


Delete Folder

Delete folder is the same as delete file, but make sure the folder is empty, otherwise it will not delete it and a warning interface will appear:




How to enter the Setting Mode

In the real time monitoring status, press and hold on ≡ button for about 1 to 2 seconds to enter into the setting interface as follows:








Language Setting



1. In the setting mode, press ▲ or ▼ button to select "SYSTEM SETTING" press OK button to enter.
2. Press ▲ or ▼ button to select "Language" press the OK button to enter into the following interface.
3. Press ▲ or ▼ button to select a suitable language.
4. Press OK button to confirm and exit.







Video System Setting


1. In the setting mode, press  or  button to select “SYSTEM SETTING” press OK button to enter
2. Press  or  button to select “Video System”, press OK button to enter into the following interface:





3. Press  or  button to select right type, press OK button to confirm and exit.

Format

1. In the setting mode, press  or  button to select “SYSTEM SETTING” press OK button to enter.
2. Press  or  button to select “Format” press OK button to enter into the following interface:




3. Press  or  button to select YES, then press OK button will erase all data; NO will be exit.

Default Setup

1. In the setting mode, press  or  button to select “SYSTEM SETTING” press OK button to enter.

2. Press ▲ or ▼ button to select “Default Setup” press OK button to enter into the following interface:




3. Press ▲ or ▼ button to select YES, then press OK button will restore default; NO will be exit.

View Version Information

1. In the setting mode, press ▲ or ▼ button to select “SYSTEM SETTING”, then press OK button to enter.
2. Press ▲ or ▼ button to select “Version”, press OK button to enter and view the version of product.

Frame Rate Setting


1. In the setting mode, press ▲ or ▼ button to select “RECORDER SETTING” press OK button to enter.
2. Press ▲ or ▼ button to select “Frame Rate” press OK button to enter into interface:



3. Press ▲ or ▼ button to select suitable frame rate.
4. Press OK button to confirm and exit.

Time Stamp Setting


1. In the setting mode, press ▲ or ▼ button to select “RECORDER SETTING” press the OK button to enter.
2. Press ▲ or ▼ button to select “Time Stamp” press OK button to enter into the following interface:



3. Press ▲ or ▼ button to select “Off” or “On” then press the OK button to confirm and exit.

Recording Type


1. In the setting mode, press ▲ or ▼ button to select “RECORDER SETTING” press OK button to enter.
2. Press ▲ or ▼ button to select “Recording Type” press the OK button to enter into the following interface:



3. Press ▲ or ▼ button to select “STILL VIDEO” then press the OK button to confirm and exit.

Date/Time Setting

1. In the setting mode, press ▲ or ▼ button to select “Date/Time” then press the OK button to enter into the following interface:
2. Press the OK button to select Date or Time; press ▲ or ▼ button to modify; press ⌂ button to confirm and exit.



Event Playback

1. In the setting mode, press ▲ or ▼ button to select “EVENT PLAYBACK” then press the OK button to enter.
2. Other operations see: “Play Video/Picture”, “Delete Video/Picture”, “Delete Folder” section.

SPECIFICATIONS

Camera	
Imaging Sensor	CMOS
Total Pixels	704 x 576 (PAL)/712 x 486 (NTSC)
Horizontal View Angle	50°
Transmission Frequency	2468MHz
Minimum Illumination	0 Lux
Modulation Type	FM
Bandwidth	18MHz
Power Source	4 "AA" batteries
Unobstructed Effective Range	32.8" (10m)
Waterproof Capacity	IP67 (only for probe head)
Dimensions (WxDxH)	7.3" x 5.7" x 1.6" (186 x 145 x 41mm) (Excluding Flexible Tube)
Weight (about)	19oz (530g)
Monitor	
LCD Screen Type	3.5" TFT-LCD
Effective Pixels	320 (R.G.B.) x 240
Video System	PAL/NTSC
Transmission Frequency	2414MHz,2432MHz, 2450MHz,2468MHz
Exterior Supply Voltage	5VDC
Consumption Current (Max.)	500mA
Charge Time	3 hours
Work Time	2 hours
Picture/Video Pixels	640 x 480
Video Size	27M byte/minute
Frame Rate	30 frame/second
Video Output Level	0.9-1.3VP-P@75ohm
Receiving Sensitivity	≤-85dBm
Dimensions (W x D x H)	4" x 2.8" x 1" (100 x 70 x 25mm)
Weight (About)	5oz (140g)
Operating Temperature	14° to 122°F (-10° to 50°C)
Operating Humidity	15%~85%RH

* Actual transmission range may vary according to the weather, location, interference and building construction.

* All the specifications are subject to minor change without prior notice.

FCC INFORMATION

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference. (2) this device must accept any interference received, including interference that may cause undesired operation. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

CAUTIONS!

- The apparatus shall not be exposed to dripping or splashing and that no objects filled with liquids, such as vases, shall be placed on the apparatus. Do not expose instrument to moisture.
- Turn off the Camera/Monitor if the system is not in use.
- The adapter is used as the disconnect device from the mains. The adapter shall remain readily operable.
- The Camera/Monitor can only be completely disconnected from the mains by unplugging the adapter.
- Do not cut the DC power cable of the apparatus to fit with another power source.
- Attention should be paid to dispose batteries in environmentally-friendly ways.
- Remove the batteries when cleaning the unit.
- Remove the batteries before storing the unit for a long time.
- When necessary, replace all four batteries in this unit with new ones.
- Use only the size and type of battery specified.
- Be sure to install the battery with the correct polarity as indicated in the battery compartment.

EU Environmental Protection

Waste electrical products should not be disposed of with household waste. Please recycle where facilities exist. Check with your Local Authority or retailer for recycling advice.



NOTES

A series of horizontal dotted lines for writing notes.



Specialty Tools & Instruments™

GENERAL TOOLS & INSTRUMENTS™

80 White Street

New York, NY 10013-3567

PHONE (212) 431-6100

FAX (212) 431-6499

TOLL FREE (800) 697-8665

e-mail: sales@generaltools.com

www.generaltools.com

DCS400 User's Manual

Specifications subject to change without notice

©2009 GENERAL TOOLS & INSTRUMENTS™

NOTICE - WE ARE NOT RESPONSIBLE
FOR TYPOGRAPHICAL ERRORS.
MAN#DCS400 7/09