


Controller



Diagnostic Use of the Controller

- To display error codes, press the ON/OFF button followed by the ▲ thermostat button to cycle through the error codes.
- To display the water flow through the water heater, press the ▲ thermostat button (hold for 2 seconds) and then press the ON/OFF button while continuing to hold the ▲ thermostat button.
- To display the outlet water temperature, press the ▼ thermostat button (hold for 2 seconds) and then press the ON/OFF button while continuing to hold the ▼ thermostat button.

To Change the Temperature Scale (°F / °C)

With the water heater turned off, press and hold the ON/OFF button until the display changes to the other temperature scale (about 5 seconds).


To Turn Off the Controller Sound (Mute)

To turn the sound off (mute), press and hold both the ▲ and ▼ thermostat buttons until a "beep" is heard (about 5 seconds).

Gas Pressure Setting

Ensure gas pressure check under Commissioning has been completed first! The regulator is electronically controlled and factory pre-set. Under normal circumstances it does not require adjustment during installation. Make adjustments only if the unit is not operating correctly and all other possible causes for incorrect operation have been eliminated.

- Turn OFF the gas supply.
- Turn OFF the 120 V power supply.
- Remove the front panel from the appliance.
- Check the gas type using the data plate on the side of the unit. If using a spare PC board, check that the gas type switches are in the correct position (switch 1 of SW2: ON for natural gas, NG, and OFF for propane, LPG). See dip switch settings section below. (ON is towards the right and OFF is towards the left) (Fig. 1).
- Attach the pressure gauge to the burner test point, located on the gas control (Fig. 2).
- Turn ON the gas supply.
- Turn ON the 120 V power supply.
- If a controller is installed, turn the unit ON with the controller. Select the maximum delivery temperature and open all available hot water taps at full.
- Set the unit to "Forced Low" combustion by setting No. 7 switch of the SW1 set to ON (Fig. 3).
- Check the burner test point pressure.
- Remove the rubber access plug and adjust the regulator screw on the modulating valve (Fig. 4) as required in Table 1. Replace the rubber access plug.
- Set the unit to "Forced High" combustion by setting both No. 7 and No. 8 switches of the SW1 set to ON (Fig. 5). Ensure maximum water flow.
- Check the burner test point pressure.
- Adjust the high pressure potentiometer (POT) on the PC board as required to the pressure shown in Table 1.
- Return the unit to normal operation by setting switches 7 and 8 of the SW1 set back to OFF (Fig. 6). Close all water taps.
- Turn OFF the gas supply and 120 V power supply.
- Remove the pressure gauge and install sealing screw.
- Turn ON the gas supply and 120 V power supply.
- Operate the unit and check for gas leaks at the burner test point.
- Install the front panel.



Gas Pressure Setting

NOTE: For additional installation and commissioning information refer to the Operation and Installation Manual.

WARNING

This appliance must be installed, serviced and removed by a trained and qualified person. During pressure testing of the consumer piping, ensure gas valve is turned off before unit is shut off. Failure to do so may result in serious injury to yourself or damage to the unit.

APPLIANCE OPERATING PRESSURES

	Water Inlet Max.	Gas Inlet Min./Max.		Forced Low		Forced High	
		NAT.G	LPG	NAT.G	LPG	NAT.G	LPG
RC80HPi	Short flue length	150 PSI	5"W.C.	8"W.C.	0.7"W.C.	1.06"W.C.	2.9"W.C.
	Long flue length		10.5"W.C.	13.5"W.C.	0.81"W.C.	1.11"W.C.	3.0"W.C.

Check whether your flue length is short or long. See Dip Switches Settings below.

Commissioning

With all gas appliances in operation at maximum gas rate, the flowing inlet pressure at the incoming test point on the Rinnai water heater should read 5" W.C. - 10.5" W.C. on natural gas and 8" W.C. - 13.5 W.C. on propane gas. If the pressure is lower, the gas supply is inadequate and the unit will not operate to specification. Check the gas meter regulator and pipework for correct operation/sizing and correct as required.

Troubleshooting

Important Safety Notes

There are a number of (live) tests that are required when fault finding this product. Extreme care should be used at all times to avoid contact with energized components inside the water heater. Only trained and qualified service technicians should attempt to repair this product. Before checking for resistance readings, disconnect the power source to the unit and isolate the item from the circuit (unplug it).

(SV1, SV2, SV3, SV4 and POV) Gas valve and Modulating solenoids: (Set meter above 2K)

Wire color	Voltage	Resistance	Connector #	Pin #s
(SV0) Pink - Black	11 - 13 VDC	37 - 43 ohms	B5	7 - 8
(SV1) Blue - Black	11 - 13 VDC	37 - 43 ohms	B6	6 - 7
(SV2) Yellow - Black	11 - 13 VDC	37 - 43 ohms	B7	5 - 7
(SV3) Red - Black	11 - 13 VDC	37 - 43 ohms	B3	4 - 7
(SV4) Orange - Black	11 - 13 VDC	37 - 43 ohms	B4	3 - 7
(POV) Orange - Orange	2 - 15 VDC	67 - 81 ohms	B2	10 - 11

(M) Water Flow Control Device Servo:

Wire color	Voltage	Resistance	Connector #	Pin #s
Red or Pink - Orange	5 - 7 VDC	N/A	G2	3 or 4 - 8
Blue or White - Orange			G2	1 or 2 - 8
Red - Pink	N/A	30 - 50 ohms	G2	3 - 4
Blue - White			G2	1 - 2
Gray - Yellow	0 - 6 VDC	N/A	G2	7 - 5
Gray - Brown			G2	7 - 6

NOTE: The grey wire listed above turns to black at G connector on the PCB.

(QS) Water Flow Sensor:

Wire color	Voltage	Resistance	Connector #	Pin #s
Black - Red	11 - 13 VDC	N/A	E5	1 - 3
Yellow - Black	4 - 7 VDC	1 - 1.4 Mega ohms	E5	2 - 3

By-pass Flow Control:

Wire color	Voltage	Resistance	Connector #	Pin #s
Brown - White	2 - 6 VDC	15 - 35 ohms	G1	1 - 5
Orange - White			G1	2 - 5
Yellow - White	(Unit in operating mode)		G1	3 - 5
Red-White - Ground			G1	4 - 5

(IG) Ignition System:

Wire color	Voltage	Resistance	Connector #	Pin #s
Grey - Grey	90 - 110 VAC	N/A	D1	1 - 2

(FM) Combustion Fan Motor:

Wire color	Voltage	Resistance	Connector #	Pin #s
Red - Black	6 - 45 VDC	N/A	L1	1 - 2
White - Black	5 - 10 VDC	9.2 - 9.4 K ohms	L1	2 - 4
Yellow - Black	11 - 13 VDC	3.5 - 3.9 K ohms	L1	2 - 3

Set your meter to the hertz scale. Reading across the white and black wires at terminals 2 and 4 you should read between 60 and 420 hertz.

Thermal Fuse / Overheat Switch:

Wire color	Voltage	Resistance	Connector #	Pin #s
Red - White	11 - 13 VDC	Below 1 ohms	B1	B13 - E9

Flame Rod:

Place one lead of your meter to the flame rod and the other to ground. With the unit running you should read between 5-150 VAC. Set your

meter to the μ amp scale and series your meter in line with the flame rod. You should read 1 μ amp or greater for proper flame circuit. In the event of low flame circuit remove the flame rod and check for carbon or damage.

Heat Exchanger and Outgoing Water Temperature Thermistors:

Check all thermistors by inserting meter leads into each end of the thermistor plug. Set your meter to the 20 K scale and read resistance. Applying heat to the thermistor bulb should decrease the resistance. Applying ice to the thermistor bulb should increase the resistance. See below for examples of typical temperatures and resistance readings.

Example:	59°F = 11.4 - 14K	140°F = 2.2 - 2.7K
	86°F = 6.4 - 7.8K	221°F = 0.6 - 0.8K
	113°F = 3.6 - 4.5K	

Outgoing Water Thermistor:

White - White	N/A	See example above	E4	E3 - E4
Blue - Blue			E4	E6 - E5

Heat Exchanger Temperature Thermistor:

Pink - Pink	N/A	See example above	E2	5 - 10
-------------	-----	-------------------	----	--------

Surge Protector:

Black - White	108 - 132 VAC	N/A	C2	1 - 3
White - White	108 - 132 VAC	N/A	C1	1 - 3

With the power off you can check the continuity through the surge protector. Place a meter lead on the top pin #1 of the surge protector and pin #3 on the bottom of the surge protector. Check across the top pin #3 and bottom pin #1. If you read continuity across these two points then the surge protector is good. If you do not get continuity then replace the surge protector.

Temperature Controller:

Terminals A1	10 - 13 VDC	1.5 - 3.0 K ohms	A	1 - 3
--------------	-------------	------------------	---	-------

Frost Protection:

This unit has frost protection heaters mounted at different points to protect the water heater from freezing. The heaters located on the hot water outlet line should have a resistance reading of 10-20 ohms through each of these heaters. The heater located on the heat exchanger piping should have a resistance reading of 35-50 ohms and the one located in the water flow sensor valve, hot water out let and drain connection should have a resistance reading 110-150 ohms. The heater located on the latent heat exchanger should have a resistance reading 90-110 ohms.

Amp Fuses:


This unit has one inline (7) amp glass fuse. Remove the fuse and check continuity through it. If you have continuity through the fuse then it is good. Otherwise the fuse is blown and must be replaced.

Dip Switches Settings

Adjust switches 2 and 3 in the bank of 8 depending on your altitude according to the table below.

The original PC boards on the water heaters do not have the bank of 6 switches. Only spare PC boards have this bank.

RC80HPi



Move switch 1 to OFF for long flue lengths. See below.

Adjustment for long flue length:
1. Determine the equivalent length using the formula:
Equivalent length = Straight lengths + [no. of 90° elbows x 6]
(Two 45° elbows = one 90° elbow)
2. If the equivalent length is greater than 21 ft then move switch no. 1 to OFF. If the equivalent length is longer than 41 ft the heater may not work properly. The installer should be called.

WARNING


DO NOT adjust the other switches unless specifically instructed to do so. Incorrect Dip Switch Settings can cause the Rinnai water heater to operate in an unsafe condition and may damage the water heater and void the warranty.

SW No.	NOTES
2	High Altitude
3	High Altitude

Error Codes


- 03 Power interruption during Bath Fill (Water will not flow when power returns).**
 - Turn off all hot water taps. Press ON/OFF twice.
- 10 Air Supply or Exhaust Blockage**
 - Ensure Rinnai approved venting materials are being used.
 - Check that nothing is blocking the flue inlet or exhaust.
 - Check all vent components for proper connections.
 - Ensure vent length is within limits.
 - Ensure condensation collar was installed correctly.
 - Verify dip switches are set properly.
 - Check fan for blockage.
 - Burner Sensor Error (see code 31)
 - Check the fins in the heat exchanger.
- 11 No Ignition**
 - Check that the gas is turned on at the water heater, gas meter, or cylinder.
 - Ensure gas type and pressure is correct.
 - Ensure gas line, meter, and/or regulator is sized properly.
 - Bleed all air from gas lines.
 - Verify dip switches are set properly.
 - Ensure appliance is properly grounded.
 - Disconnect EZConnect™ or MSA controls to isolate the problem.
 - Ensure igniter is operational.
 - Check igniter wiring harness for damage.
 - Check gas solenoid valves for open or short circuits.
 - Remove burner cover and ensure all burners are properly seated.
 - Remove burner plate and inspect burner surface for condensation or debris.
- 12 Flame Failure**
 - Check that the gas is turned on at the water heater and gas meter. Check for obstructions in the flue outlet.
 - Ensure gas line, meter, and/or regulator is sized properly.
 - Ensure gas type and pressure is correct.
 - Bleed all air from gas lines.
 - Ensure proper Rinnai venting material was installed.
 - Ensure condensation collar was installed properly.
 - Ensure vent length is within limits.
 - Verify dip switches are set properly.
 - Ensure appliance is properly grounded.
 - Disconnect EZConnect™ or MSA controls to isolate the problem.
 - Check power supply for loose connections.
 - Check power supply for proper voltage and voltage drops.
 - Ensure flame rod wire is connected.
 - Check flame rod for carbon build-up.
 - Disconnect and reconnect all wiring harnesses on unit and PC board.
 - Check for DC shorts at components.
 - Check gas solenoid valves for open or short circuits.
 - Remove burner plate and inspect burner surface for condensation or debris.
 - Check the ground wire for the PC board.
- 14 Thermal Fuse**
 - Check gas type of unit and ensure it matches gas type being used.
 - Check for restrictions in air flow around unit and vent terminal.
 - Check for low water flow in a circulating system causing short-cycling.
 - Ensure dip switches are set to the proper position.
 - Check for foreign materials in combustion chamber and/or exhaust piping.
 - Check heat exchanger for cracks and/or separations.
 - Check heat exchanger surface for hot spots which indicate blockage due to scale build-up.
 - Refer to instructions in manual for flushing heat exchanger.
 - Measure resistance of safety circuit.
 - Ensure high fire and low fire manifold pressure is correct.
 - Check for improper conversion of product.
- 16 Over Temperature Warning**
 - Check for restrictions in air flow around unit and vent terminal.
 - Check for low water flow in a circulating system causing short-cycling.
 - Check for foreign materials in combustion chamber and/or exhaust piping.
 - Check for clogged heat exchanger.
- 25 Condensate Trap Error**
 - Condensate container is full.
 - Check condensate drain for blockage.
 - Replace condensate trap.
- 31 Burner Sensor Error**
 - Measure resistance of sensor.
 - Replace sensor.
- 32 Outgoing Water Temperature Sensor Fault**
 - Check sensor wiring for damage.
 - Measure resistance of sensor.
 - Clean sensor of scale build-up.
 - Replace sensor.
- 33 Heat Exchanger Outgoing Temperature Sensor Fault**
 - Check sensor wiring for damage.
 - Measure resistance of sensor.
 - Clean sensor of scale build-up.
 - Replace sensor.
- 52 Modulating Solenoid Valve Signal Abnormal**
 - Check modulating gas solenoid valve wiring harness for loose or damaged terminals.
 - Measure resistance of valve coil.
- 61 Combustion Fan Failure**
 - Ensure fan will turn freely.
 - Check wiring harness to motor for damaged and/or loose connections.
 - Measure resistance of motor winding.
- 65 Water Flow Control Fault**
 - The water flow control valve has failed to close during the bath fill function. Immediately turn off the water and discontinue the bath fill function. Contact a state qualified or licensed contractor to service the appliance.
- 71 SV0, SV1, SV2, SV3 and SV4 Solenoid Valve Circuit Fault**
 - Replace the PC board.
- 72 Flame Sensing Device Fault**
 - Ensure flame rod is touching flame when unit fires.
 - Check all wiring to flame rod for damage.
 - Remove flame rod and check for carbon build-up; clean with sand paper.
 - Check inside burner chamber for any foreign material blocking flame at flame rod.
 - Measure micro amp output of sensor circuit with flame present.
 - Replace flame rod.
- 73 Burner Sensor Circuit Error**
 - Check sensor wiring and PC board for damage.
 - Replace sensor.
- LC Scale Build-up in Heat Exchanger (when checking maintenance code history, "00" is substituted for "LC")**
 - Flush heat exchanger. Refer to instructions in manual.
 - Replace heat exchanger.
 - NOTE: The LC code is the only error code that will allow the unit to keep running. The display will alternate between the LC code and the temperature setting. The controller will continue to beep.
 - The LC code will reset if power is turned off and then on.
- No Code** (Nothing happens when water flow is activated.)
 - Clean inlet water supply filter.
 - On new installations ensure hot and cold water lines are not reversed.
 - Check for bleed over. Isolate unit from building by turning off hot water line to building. Isolate the circulating system if present. Open your pressure relief valve; if water is flowing, there is bleed over in your plumbing.
 - Ensure you have at least the minimum flow rate required to fire unit.
 - Ensure turbine spins freely.
 - Measure the resistance of the water flow control sensor.
 - Check for DC shorts at components.

Wire Diagram




RC80HPi
(KA2530FFUD-US)
U290-761X01(00)


EXPLODED VIEW - CABINET




EXPLODED VIEW - INTERNALS



EXPLODED VIEW - INTERNALS



EXPLODED VIEW - ELECTRICAL



PARTS LIST

Item	Description	Part Number	Qty	Item	Description	Part Number	Qty	Item	Description	Part Number	Qty
001	Main Body	109000167	1	145	O-ring	108000017	1	707	High TensionCord	105000095	1
002	Wall Bracket	109000064	2	149	Gasket	109000159	1	708	Electrode Sleeve	AU206-218	1
003	Rubber Bushing	109000015	1	151	Burner fixing	109000160	1	709	Thermistor	105000114	1
004	Connection Reinforcement Panel	109000118	1	153	Burner Sensor Gasket	109000149	1	710	Thermistor Clip Large	CP-90172	1
005	Heat Protection Plate	H73-065	1	154	Burner Thermistor	105000100	1	711	Thermal Fuse Clip	109000141	6
006	Front Panel	109000144	1	160	Heat Exchanger, Secondary	107000071	1	712	Frost Sensing Switch	105000097	2
007	Gasket - Top and Bottom	109000120	2	161	Outlet pipe packing	109000161	1	713	Anti Frost Heater 120V	105000115	1
008	Gasket - Side	109000121	2	162	Outlet pipe	107000064	1	715	Valve Heater 120V Assembly	105000099	1
009	Temperature Controller	103000021	1	163	ø80 O-ring	108000018	2	717	Anti Frost Heater Clip A	105000028	1
010	Temperature Controller Bracket	109000156	1	164	Packing	109000162	2	718	Anti Frost Heater Clip C	105000027	4
011	Screw Cover	109000122	2	165	OHS cover	109000163	1	720	Power Cord	105000030	1
012	Screw Cover Lid	109000150	4	166	Reinforcement Bracket	109000129	1	721	Fuse Harness	105000101	1
014	Rubber Bushing	U245-125	1	400	Water Inlet 3/4" NPT	H73-501-2	1	722	Power Harness	105000107	1
016	Packing	109000016	1	401	Water Flow Servo and Sensor Assembly	107000055	1	724	Sensor Harness	105000116	1
017	Screw Cover Assembly	109000123	2	402	Rectifier	M8D1-15X01	1	725	Thermal Fuse Harness Assembly	105000117	1
021	Reinforcement Bracket	109000124	1	403	By-pass Flow Assembly	M6J-1-4	1	726	Ignitor Harness	105000112	1
022	Attachment Bracket	109000125	3	404	Stop Bracket	AH69-310	2	727	Flow sensor	105000041	1
024	Temperature Controller Packing	109000157	1	405	Plug Band	109000018	1	728	Ignitor Attachment Plate	U273-225	1
025	Temperature Controller Bracket	109000145	1	408	Hot Water Outlet 3/4" NPT	107000066	1	729	Temperature Controller Harness	105000042	1
100	Gas Controller Assembly	106000010	1	409	Stop Bracket	U211-322X01	1	730	Thermistor	105000108	1
101	Test port set screw	109000151	2	410	Plug Band (small)	109000019	1	731	Solenoid Connection Harness	105000118	1
102	"Gas Connection 3/4" NPT"	CU195-1866	1	411	Drain Valve	107000021	1	732	AWG#18 Harness	105000119	1
103	"Burner Unit Assembly LPG,NG"	106000040	1	412	Water Filter Assembly	H98-510-S	1	733	Connection Harness	105000120	1
104	Burner Case Cover	CH51-209X04	1	413	Cover	109000130	1	743	Secondary Heat Exchanger Heater	107000063	1
105	Burner Case Bottom Plate	106000041	1	421	Drain Connection	107000057	1	744	Heater and Harness	105000106	1
106	Burner Packing	BH51-218	1	422	Drain Plug	107000058	1	800	Screw	ZIHD0510UK	8
107	Burner	B3A7-1X05	16	423	Clip	109000131	2	801	Screw	CP-30580-3	4
108	Burner Case Back Cover	106000042	1	424	Connecting Pipe	107000067	1	802	Washer	CF83-41430	4
109	"24 Damper LPG,NG"	106000043	1	426	Packing	109000153	1	803	Screw	CP-30627-414	3
110	Manifold Assembly NG	106000044	1	431	Connecting Pipe - Inlet	107000060	1	804	Screw	U217-449	1
110	Manifold Assembly LPG	106000045	1	432	Connecting Pipe - HEX	107000068	1	805	Screw	ZAA0408UK	3
111	Manifold Packing	106000049	1	433	Clip	109000132	2	806	Screw	CP-80452	1
112	Manifold Packing	106000050	1	434	Clip	109000133	1	807	Washer	AU48-174X01	2
114	Combustion Chamber Sight Glass Plate	109000168	1	440	Condensate Trap	109000134	1	810	O-ring	M10B-2-4	2
116	Electrode	H73-120	1	441	Packing	109000154	2	814	O-ring	M10B-2-16	3
117	Flame Rod	105000093	2	442	Condensate Trap Plug	109000135	1	815	O-ring	M10B-2-14	4
118	Electrode Packing	109000126	1	443	Condensate Drain Tube	109000136	1	816	O-ring	M10B-2-7	1
119	Electrode Holder	109000127	1	444	Band	109000137	1	817	O-ring	M10B-1-24	1
120	Chamber Packing	106000046	1	445	Band	109000138	1	818	Packing	C36E1-6	2
125	Fan Motor All Assembly	108000041	1	446	Screw	109000155	2	819	Screw	ZQAA0512UK	2
126	Fan Casing	108000042	1	447	Conection Harness	105000105	1	820	Screw	ZQAA0514UK	4
127	Fan Inlet Connector	BH29-606X09	1	700	PC Board	105000113	1	821	Screw	ZQAA0508UK	2
128	Fan Inlet Packing	AU183-562	1	701	Surge Protector	105000014	1	822	Screw	ZBA0512UK	3
129	Fan Motor	108000043	1	701	Surge Protector with Terminals	BU195-1873-2X01	1	823	O-ring	M10B-2-5	1
131	ø36 Bell Mouth	109000169	1	702	PC Board Cover Side	109000164	1	824	O-ring	M10B-2-6	2
139	Air Inlet Duct	108000039	1	703	PC Board Cover Front	109000139	1	888	Tech Sheet	10000152	1
143	Heat Exchanger Assembly	107000065	1	704	Clip	109000140	1	889	Manual	10000150	1
144	Flue Connection Assembly	108000040	1	706	Ignitor	105000018	1	900	Front Panel Label	10000153	1