

This chapter contains information for interpreting data parameters on Ford vehicles.

For additional information on Ford vehicles, see the following sections:

- “Ford Operations” on page 53
- “Ford Testing” on page 71
- “Ford Communications Problems” on page 717

## Alphabetical Parameter List

### Numerics

3/2 SHIFT SOL .....	324
4/3 SHIFT SOL .....	324
4_LOW_LED .....	320
4WD_FrShftSp .....	410
4WD_RrShftSp .....	410
4WD_Switch .....	411
4WDClutch(%) .....	410
4WDClutchElec .....	410
4WDClutchPWM .....	410
4WDClutchStat .....	410
4WDCPWMOU .....	320
4WDCPWMST(%) .....	320
4WDHigh .....	410
4WDHIGLMP .....	320
4WDINP_SW .....	320
4WDINP_SW_ABS .....	393
4WDLOLED .....	410
4WDLow .....	410
4WDLOWLMP .....	320
4WDMODE_L .....	320
4WDPlate_A .....	411
4WDPlate_B .....	411
4WDPlate_C .....	411
4WDPlate_D .....	411
4WDPlatePwr .....	411
4X4_BOO .....	320
4X4_CWRLY .....	320
4X4CCWRLY .....	320
4X4Low .....	324

### A

A/C BLndoorPos .....	411
A/CClutchSw .....	324

A/CPRs(V) .....	324
A_CT(°C/F).....	324
A_CT_V(V .....	324
AAT(°C/F).....	324
ABagCHIME .....	411
ABBRGR .....	392
ABPROS.....	393
ABS PLS.....	393
ABS_ACTIVE .....	320
ABS_ACTIVE .....	418
ABS_LAMP.....	393
ABS_MSG .....	320
ABS_MSG_TCM .....	418
ABS_MTR.....	393
ABS_partbaseno .....	393
ABS_PartNoldSuffix .....	393
ABS_POWER .....	393
ABS_PWR_R .....	320
ABS_PWR_R .....	393
ABS_SoftVerNo .....	393
ABS_TCS_WIN126_SELTESTDTC .....	393
ABSLAMP.....	393
ABSLF I .....	393
ABSLF O .....	393
ABSLR I .....	393
ABSLR O .....	393
ABSPMPRLY .....	394
ABSR I .....	394
ABSR O .....	394
ABSRF I .....	393
ABSRF O .....	393
ABSRR I .....	393
ABSRR O .....	393
ABSVLVRLY .....	394
AC_RC_SW.....	325
ACC DeLaY .....	411
ACC_Pos .....	411
AccessoryDly.....	411
ACCLMTR .....	394
ACCLUTCH_TCM .....	418
ACClutchHEV .....	325
ACCR_TEMP (°C(°F .....	394
ACCR_TRAV .....	394
ACCS.....	325
ACCS=A/C .....	325
ACDS1.....	325
ACDS2.....	325
ACFD_BAT .....	324
ACFD_PAS .....	325
ACL=ACCEL .....	325
AclPedl(V).....	325
ACP .....	325
ACP .....	325

---

ACP_PSI(KPA).....	325
ACRDRV.....	326
ACRDV_F.....	326
ACT_MNT .....	326
ACTF .....	326
ACTMNT_F .....	326
ACU_CHK .....	394
AFT_ADDS.....	326
AFT2_ADDS.....	326
AIR A .....	326
AIR B.....	327
AIR D .....	327
AIR .....	326
AIR_FLT .....	326
AIRBA.....	326
AIRbypass.....	327
AIRCON_SW_STATUS.....	327
AIRD.....	327
AIRDA .....	327
AIRDivert.....	327
AIREVAL_DC_MODE1.....	327
AIRFault .....	327
AIRFLOW(g/S).....	362
AIRM .....	327
AIRMonitor .....	327
ALarm EVent1-8.....	412
ANTISCAN .....	327
AntiScan .....	405
AP(%).....	328
AP(V).....	328
AP_MODE_TCM .....	328
AP_PER_TCM .....	418
AP_PER_TCM(%).....	328
APP_F .....	328
APP_LOW(V) .....	328
APP_MODE .....	328
APP1(V) .....	328
APP1(V) .....	328
APP1_FN_TCM.....	418
APP1_TCM .....	418
APP2(V) .....	328
APP2_TCM .....	418
APP3(V) .....	328
APP3_TCM .....	418
ARCFault.....	394
ARPMDES(rpm).....	328
AST .....	328
AST2 .....	328
AUTOLMP .....	412
AutoRideCtrl .....	394
AWD_MSG .....	394
AWD_MSG_ABS_MZ.....	394
AXLE .....	329

---

**B**

BALVLV1.....	394
BALVLV2.....	395
BARO(Hz).....	329
BARO(V).....	329
BARO_TCM.....	418
BATSAV.....	412
BATT_I_REC.....	418
BATT_V_REC.....	418
BattSaver.....	412
BLD_STAT.....	395
BLoWerMoToR .....	329
BLSHORT BATT.....	329
BLSHORT GND.....	329
BOO ABS .....	395
BOO SW.....	412
BOO.....	329
BOO=BRAKE SW .....	329
BOO_GEM .....	412
BOO_TCM.....	418
BP=BARO ("HG) .....	330
BP=BARO (kPa).....	330
BP_CALST .....	395
BPA.....	330
BPA_SW.....	330
BPO .....	330
BPO_Hz.....	330
BPP_BOO .....	330
BPTSCAL .....	395
Bracket( $\Omega$ ).....	392
BRAKE_LMP .....	395
BrakeOnOff.....	330
BrakePrsApply .....	395
BRAKPRES(KPA/PSI).....	395
BRK_CHK.....	395
BRK_FLUID.....	395
BRK_MSIG(KPA/PSI).....	395
BRK_RSIG .....	395
BRK_WARN .....	396
BRKLAMP .....	396
BRKPEDSW .....	418
BSTLRNCYC.....	396
BSTR_BSWF.....	396
BSTR_LCCS .....	396
BSTR_LERN .....	396
BSTR_MECH .....	396
BSTR_SOL.....	396
BSTR_SOL1.....	396
BSTR_SW_T .....	396
BSTRBP_FSNC .....	396
BSTRBP_FSNO .....	396

---

## C

C KEYMD .....	405
CAMDC 1 .....	330
CAMDC 2 .....	330
CAMDCCR.....	330
CAMERR1.....	331
CAMERR2.....	331
CANP=PURGE.....	331
CASeGND(V) .....	331
CAT mon ready.....	331
CAT MONITOR.....	331
CATCAL1(Hz).....	331
CATCAL2(Hz).....	331
CATEVAL_DC_MODE1.....	331
CATTST1(Hz).....	331
CATTST2(Hz).....	331
CCB_LCCS .....	396
CCB_LCTF .....	396
CCC=TCC .....	332
CCL .....	332
CCLAS_ICS .....	397
CCLAS_ITF .....	397
CCLF .....	332
CCMSTAT_DC_MODE1.....	332
CCNT .....	320
CCNT_TCM.....	418
CCNT_TPMS .....	431
CCNTABS.....	397
CCS .....	332
CCS_FLT.....	332
CCSA .....	332
CCSFault.....	332
CCSWA_TPS .....	397
CCW_Shift_Mtr.....	412
CCYR_ICS .....	397
CCYR_ITF .....	397
ChimeReq .....	412
CHIMERQ .....	412
CHT SENSOR(°) .....	332
CHT(°C/F) .....	332
CHT_COLD(°C/F) .....	332
CHT_HOT(°C/F) .....	332
CHT_V(°C/F).....	332
CHTFM .....	332
CHTIL .....	333
CHTIL_FLT .....	333
CHTILFault .....	333
CKP_PROF .....	333
CLCH_SOL (%) .....	321
CLRDIST_NOMIL.....	333
CLTCHAMP_CMD.....	419
ClutchLock.....	412
CMPFM .....	333

CMPFM .....	333
CMPFM2 .....	333
CmprCompMon_rdy .....	333
CMPS_lp_Lev .....	333
CMPS_Status .....	333
COAST .....	333
CoastCISol .....	333
CoastCISol(%) .....	334
CoastCISol(mA) .....	334
CONPROV .....	397
CONTRACTOR .....	419
COOLANT .....	412
COPENPLAT .....	321
CPC_AMP .....	334
CPC_AMP .....	419
CPP .....	334
CPP/TCS .....	334
CPP_ST .....	334
CRaSHSN1( $\Omega$ ) .....	392
CRaSHSN2( $\Omega$ ) .....	392
CRSHSN1( $\Omega$ ) .....	392
CRSHSN2( $\Omega$ ) .....	392
CRUISE .....	334
CRUISE_SW .....	334
CSEGND(V) .....	334
CUTVLV1 .....	397
CUTVLV2 .....	397
CW_CCW .....	321
CW_Shift_Mtr .....	412
CylHdTemp(V) .....	334

**D**

D DR SW .....	413
D_SBELT .....	413
D_Airbag( $\Omega$ ) .....	392
D_AirBAG2( $\Omega$ ) .....	392
D_AirBAGLoop2( $\Omega$ ) .....	392
D_Preten( $\Omega$ ) .....	392
D_PRETNR( $\Omega$ ) .....	392
DCDC_ENA .....	334
DCDC_F .....	335
DECKLID .....	413
DIM DEC .....	413
DIM INC .....	413
DISTDIG_TCM .....	419
DoorAjarLamp .....	413
DoorAJR_L .....	413
DoorLocK .....	413
DoorUnlock .....	413
DPFE(V) .....	335
DPFEGR .....	335

---

Dr DR SW.....	413
Dr SBELT.....	413
DRIVE CounT.....	335
Drive_COUNT .....	335
DRIVECNT .....	335
DRIVECNT_TCM .....	419
DRIVEPOS_TCM .....	419
DSBELTR .....	392
DSBL_TOG .....	397
DSD .....	335
DTC CouNT (AIRBAG).....	392
DTC CouNT (pcm).....	335
DTC CouNT.....	413
DTC .....	335
DTC_CNT .....	335
DTC_CNT_TCM .....	419
DYNOMODE .....	397

## E

EBP(V) .....	336
ECT .....	336
ECT(°C).....	336
ECT(°F) .....	336
ECT(V) .....	336
ECT_FF (°C/°F).....	336
ECT_TCM (°C/°F) .....	419
ECT_TCM_DI (°C/°F).....	419
ECTF .....	336
EFTA.....	336
EGR mon ready.....	337
EGR MONITOR.....	337
EGR_EVAL.....	336
EGR_Fault.....	337
EGRBARO .....	337
EGRCFault .....	337
EGRCvacsol.....	337
EGRDc(%). ....	337
EGRDtCycl(%). ....	337
EGREVAL_DC_MODE1.....	337
EGRFOpen.....	337
EGRFShort .....	337
EGRMC1 .....	338
EGRMC1F .....	338
EGRMC2 .....	338
EGRMC2F .....	338
EGRMC3 .....	338
EGRMC3F .....	338
EGRMC4 .....	338
EGRMC4F .....	338
EGRMDSD .....	338
EGRTP(V) .....	338
EGRTPDC(%) .....	338
EGRVentsol .....	338

EGRVFault .....	338
EGRVP(V) .....	338
EGRVPDES.....	338
EGRVR(%) .....	338
EGRVR_FLT.....	338
ElecPrsCtrl.....	339
ENABLE_S .....	405
ENG LOAD(%) .....	359
ENG_CTO .....	419
ENG_TORQ .....	419
EngFuelTA(V) .....	339
EngFuelTB(V) .....	339
ENGINE_STAT .....	419
EngOilTemp(°) .....	339
EOT(°) .....	339
EOT(V) .....	339
EOT_DEG(°C/°F) .....	339
EOT_M(°C/°F) .....	339
EOTF .....	339
EOTM .....	339
EPC(psi) .....	339
EPC(V) .....	339
EPCV(V) .....	339
EPR(%).....	340
ETC_ACT .....	340
ETC_CTRL.....	340
ETC_DSD .....	340
EVACFILL .....	397
EVAP mon ready .....	340
EVAPC .....	340
EVAPCP .....	340
EVAPCP_FLT .....	340
EVAPCPFault .....	340
EVAPCV .....	340
EVAPCV(%).....	340
EVAPCVA .....	340
EVAPCVF1 .....	340
EVAPCVFault .....	341
EVAPCVFLT .....	341
EVAPEVAL_DC_MODE1 .....	341
EVAPPrgFlw(V) .....	341
EVAPSTA .....	341
EVAPVM(%) .....	341
EVAPVM_Fault.....	341
EVAPVMA .....	341
EVMV .....	341
EVP(V).....	341
EVR(%).....	342
ExhBackPrs .....	342
EXTCRSH .....	392
FAILSAF .....	405

**F**

---

FAN Monitor .....	342
FAN .....	342
FAN_FLT .....	342
FAN_REQ.....	342
FANM(HIGH).....	342
FANSS.....	342
FANSSM.....	342
FDSP_ESCS_GPL.....	343
FFINF(%).....	343
FFLRND .....	343
FICM_LPWR .....	343
FICM_MPWR .....	343
FICM_VPWR .....	343
FICMSYNC.....	343
FIRMSHFT .....	343
FIRMSHFT .....	419
FlexFuel(Hz).....	343
FLG_MLUUSFM .....	343
FLG_MLUUSFM .....	419
FLG_OTLK .....	343
FLG_OTLK .....	420
FLG_SS4.....	344
FLI(V) .....	344
FLI_PERCENT(%) .....	343
FLI_SG(V) .....	344
FLIFM .....	343
FLInput(%).....	344
FLInput(V) .....	344
FP .....	343
FP=FUEL PUMP .....	344
FP_FLT .....	344
FPA STATE.....	344
FPPFault .....	344
FPM .....	345
FPM(%) .....	345
FPMode.....	345
FPMonitor.....	345
FR_OUTSHA.....	321
FRP(psi) .....	345
FRP(V) .....	345
FRP_DSD .....	345
FRP_FAULT .....	345
FRP_PRESS .....	345
FRPFM .....	345
FRT1FM .....	345
FrWiperMd.....	413
FRZ_DTC .....	420
FSVFault .....	345
FSVMonitor .....	345
FTIV_F .....	346
FTIV_HEV(%).....	345
FTP(KPA) .....	346
FTP_FAULT.....	346

---

FUEL mon ready .....	346
FUEL STATUS.....	347
FUEL SYS.....	347
FUEL SYS1 .....	347
FUEL SYS2.....	347
FUEL_CUT .....	420
FUEL_RAIL_TEMP(°C/°F) .....	346
FuelPumpA.....	346
FUELFW.....	346
FUELFW(mS).....	346
FUELFW1(mS).....	346
FUELFW2(%).....	346
FUELFW2(mS).....	346
FuelRailPrs(V) .....	347
FuelSolVlv .....	345
FUELSYS .....	347
FuelTankPrs(V).....	347
FueLvlinput(%) .....	344
FueLvlinput(V .....	344

**G**

G_INPUT.....	397
G_SDN .....	347
G_SDN_A.....	420
G_SDN_B.....	420
G_SDN_C.....	420
G_SENSOR.....	398
GEAR .....	347
Gear.....	420
GEAR_MAX.....	347
GEAR_MAX.....	420
Gear_OSC.....	347
Gear_OSCIP .....	420
GEAR_RAT .....	347
GEAR_RAT .....	420
GEN_BRK_CMD .....	420
GEN_COILTEMP (°C)(°F) .....	420
GEN_CTRL .....	420
GEN_FAULT .....	348
GEN_INV_V .....	420
GEN_LAMP .....	348
GEN_MON .....	348
GEN_MON(%).....	348
GEN_SPEED.....	421
GEN_TEMPHI (°C)(°F).....	421
GEN_TORQ_CMD .....	421
GENB_F .....	348
GENB_FAULT .....	348
GENF.....	348
GENFDC(%).....	348
GENFIL.....	348
GENLMP .....	348
GENVDSD.....	348

---

GlowPlugCtrl(%)	348
GPC(%)	348
GPC_L	349
GPC_R	349
GPCoilTiMe	349
GPCTM	349
GPLampTiMe	349
GPLTM	349
GR_RATIO	349
GR_RATIO	421
GTQ_OUT	421
GTQ_OUT_ENG	349

## H

HALLPOWER	321
HallPwr	414
HatchUnlkSw	414
HCATEVAL_DC_MODE1	349
HDLMPSW	414
HeaDLaMP	414
HFC	349
HFC=HI FAN	358
HFC_FLT	349
HFCA	350
HFCFault	350
HIGH_LAMP	321
HighFanCtrl	358
HO2S mon ready	350
HO2S MONITOR	350
HO2S11(mA)	350
HO2S12(mA)	350
HO2S21(mA)	350
HO2S22(mA)	350
HORN SW	414
HORN TPM	431
HPRC_ENA	350
HPRC_F	350
HTR11	351
HTR11A	351
HTR11F	351
HTR11Fault	351
HTR12	351
HTR12A	351
HTR12F	351
HTR12Fault	351
HTR13	351
HTR21	351
HTR21A	351
HTR21F	351
HTR21F	351
HTR21Fault	351
HTR22	351
HTR22A	351

HTR22F .....	351
HTR22Fault .....	351
HTR23 .....	351
HTRCM11 .....	351
HTRCM12 .....	351
HTRCM21 .....	352
HTRCM22 .....	352
HTREVAL_DC_MODE1 .....	352
HTRX1 .....	352
HTRX2 .....	352

## I

I_SDN_1 .....	421
I_SDN_2 .....	421
IAC(%) .....	352
IAC=IDLE AIR(%) .....	352
IAC_CELL0 .....	352
IAC_CELL1 .....	352
IAC_CELL2 .....	352
IAC_CELL3 .....	353
IAC_FLT .....	353
IAC_MODE .....	353
IAC_TRIM .....	353
IACDTCY(%) .....	353
IACF .....	353
IACFault .....	353
IAT .....	353
IAT(°C) .....	353
IAT(°F) .....	353
IAT(V) .....	353
IAT=ACT(°C) .....	354
IAT=ACT(°F) .....	354
IAT=ACT(V) .....	354
IAT_C .....	353
IAT_FAULT .....	354
IAT_T .....	353
IAT_TCM (°C)(°F) .....	421
IAT2 .....	353
IAT2(V) .....	353
IAT2_TEMP .....	353
IAT2_VOLTS .....	353
IC_MSG .....	398
IC_MSG_ABS_MZ .....	398
ICP(V) .....	354
ICP_DES .....	354
ICP_PRESS .....	354
IGN ADVANCE(°) .....	378
IGN O/L .....	411
IGN Run .....	411
IGN_RUN_PCM .....	354
IGN_SW .....	321
IGNITION .....	421
IGNITION(V) .....	321

---

IGNITION(V).....	398
IINE_V .....	354
IlumEntry .....	414
IMAN_DN_TCM .....	421
IMIN_UP_TCM .....	421
IMRC .....	354
IMRC1M(V) .....	355
IMRC2M(V) .....	355
IMRCFault .....	355
IMRCFLT .....	355
IMRCM(V) .....	354
IMS_SRC .....	355
IMS_SRC .....	421
IMTV(%) .....	355
IMTV_FLT.....	355
IMTV1_PER(%).....	355
IMTV2.....	355
IMTV2_FLT.....	355
IMTV2_PER(%).....	355
IMTVF.....	355
IMTVFault.....	355
INJ PW1(mS) .....	356
INJ PW2(mS) .....	356
INJ .....	355
INJ_TIM.....	356
INJ1 .....	356
INJ10 .....	356
INJ2 .....	356
INJ3 .....	356
INJ4 .....	356
INJ5 .....	356
INJ6 .....	356
INJ7 .....	356
INJ8 .....	356
INJ9 .....	356
INJnFault .....	356
InjPrsReg(%) .....	357
InManRunCtrl .....	357
InManRunCtrl(%).....	357
IPR(%).....	357
ISS.....	421
ISS(rpm) .....	357
ISS_DIR .....	357
ISS_DIR .....	421
ISS_F .....	357
ISS_F .....	422
ISS_FAULT.....	357
ITS1 .....	357
ITS2 .....	357
ITSD .....	357
ITSR .....	357
IVD_R_IN .....	398
IVD_R_OUT .....	398

---

IVS.....	358
IWE_SOL.....	321
IWE_SOLST.....	321

**K**

KAMFUSE .....	358
KeyInIgn .....	414
KEYPOS.....	358
KNOCK_1.....	358
KNOCK_2.....	358

**L**

L_ACCEL_EPB .....	398
LAS_ICS.....	398
LAST_ID.....	431
LATACCEL.....	398
LATACCL.....	398
LATACINPT .....	398
LCF_FLT.....	358
LCP_AMP.....	422
LF_WSPD(MPH) .....	400
LF_FAIL.....	398
LF_ID.....	431
LF_IN(AMP).....	398
LF_INLET .....	398
LF_LRН .....	431
LF_MES.....	431
LF_NORM .....	431
LF_OUT(AMP).....	398
LF_OUTLET .....	399
LF_PRES.....	399
LF_PRIME .....	399
LF_PSI.....	431
LF_PwrWndw .....	414
LF_REC.....	431
LF_SWITCH .....	399
LF_TC_PRV .....	399
LF_TC_SWV .....	399
LF_UnlockSw .....	414
LF_WSPD.....	321
LF_WSPD(KPH MPH).....	399
LF_WSPD_TCM.....	422
LFAWAKE.....	431
LFBeltFstd .....	414
LFC.....	358
LFC=LO FAN.....	358
LFCFault.....	359
LFDoorAjar .....	414
LFDR_SW .....	321
LFIDPRG .....	431
LFLOBAT .....	431
LFT1(%). . . . .	359

---

LFTRIM 1(%).....	359
LFTRIM 2(%).....	359
LFWindowDn .....	415
LFWindowMotr(A) .....	415
LFWndwPeak(A).....	415
LGATESW .....	413
LOAD(%).....	359
LOAD_FF(%).....	359
LOAD_TCM.....	422
LONG_ACCL.....	399
LONGFT1(%) .....	359
LONGFT2(%) .....	359
LOOP .....	368
LOS_BRAK .....	359
LOS_ENG .....	360
LOS_EQ .....	360
LOS_ETC .....	360
LOS_GEN .....	360
LOS_HV .....	360
LOS_IPC .....	360
LOS_KEY .....	360
LOS_LV .....	360
LOS_MOT .....	360
LOS_OWC .....	360
LOS_TCM .....	360
LOSSRTT .....	360
LOW_LAMP .....	321
LowFanCA.....	360
LowFanCtrl .....	360
LowFPumpFault .....	361
LPC_AMP .....	361
LR TURN .....	415
LR WSPD(MPH.) .....	400
LR_FAIL .....	400
LR_ID .....	431
LR_IN(AMP) .....	400
LR_INLET .....	400
LR_LRН .....	431
LR_MES .....	432
LR_NORM .....	432
LR_OUT(AMP) .....	400
LR_OUTLET .....	400
LR_PRES(KPA/PSI) .....	399
LR_PRIME .....	399
LR_PRIME .....	400
LR_REC .....	432
LR_SWITCH.....	399
LR_SWITCH.....	400
LR_TC_PRV .....	400
LR_TC_SWV .....	399
LR_TC_SWV.....	400
LR_TC_VLV .....	399
LR_TC_VLV.....	400

---

LR_WSPD .....	321
LR_WSPD(KPH MPH) .....	401
LRAWAKE .....	432
LRDoor SWitch.....	413
LRDoorAjar.....	414
LRDR SW .....	413
LRDR Switch .....	413
LRIDPRG .....	432
LRLOBAT .....	432
LRO_PSI .....	432
LT TRIM B1(%).....	361
LT TRIM B2(%).....	361
LTRL_ACC .....	401

**M**

M KEY .....	405
M_DPF.E .....	361
M_IAT .....	361
M_LOAD(%) .....	361
M_PNP .....	361
M_RPM.....	361
M_RUN.....	361
M_SDN .....	365
M_SDN_A.....	422
M_SDN_B.....	422
M_SDN_C .....	422
M_SOAK.....	361
M_TP .....	362
M_TRIP .....	362
M_VSS .....	362
M_WHEEL.....	362
MAF(gm/S) .....	362
MAF(V .....	362
MAF=MASS AIR(V .....	362
MAF_Fault.....	362
MAF_RATE.....	362
MAFF .....	362
MAN LEV POS .....	363
MAN LEV POS(V) .....	363
MAN VAC .....	363
MANSW_TCM .....	422
MAP(Hz) .....	363
MAP(psi).....	363
MAP_DI2 .....	363
MAP_F.....	363
MAP_PCM.....	363
MAP_PCM.....	401
MAP_V .....	363
MAP2.....	364
MASS AIR FLOW_STATUS .....	362
MASS AIR(gm/sec) .....	362
Master KEY .....	405
MASTERKEY .....	364

---

MAT .....	364
MC_PT_1 .....	401
MC_PT_2 .....	401
MECH_TCM (°C/°F) .....	422
MECP_ENA .....	364
MECP_F .....	364
MECT_V(V) .....	364
MFC .....	364
MFC_FLT .....	364
MFDES .....	364
MGP .....	364
MIL .....	365
MIL_DIS .....	401
MIL_DIS_TCM .....	422
MIL_FLT .....	365
MILFault .....	365
MIN_KEY .....	364
MISF_EVAL .....	365
MISFEVAL_DC_MODE1 .....	365
MISFire .....	365
MN_PR_TRN .....	401
MNC_VEL_1 .....	401
MNC_VEL_2 .....	401
MODSTATE .....	401
MPLRN .....	365
MTQ_OUT .....	422
MTQ_OUT_ENG .....	365
MTR_CCW .....	321
MTR_COILTEMP (°C)(°F) .....	422
MTR_CW .....	322
MTR_INV_V .....	422
MTR_SPEED .....	422
MTR_TEMPHI (°C)(°F) .....	423
MTR_TORQ_CMD .....	423

## N

N_KEYCODE .....	365
NeuSafetySw .....	415
NeuTowFcnLmp .....	415
NEUTPOS_TCM .....	423
NeutTowFcn .....	415
NM .....	365
NSAFETYSW .....	322
NTF_4X4M .....	322
NTF_CMD .....	322
NTF_LAMP .....	322
NTRL SW .....	415
NUMKEYS .....	365
NUMKEYS .....	405

## O

O2 B1-S1(V .....	) 366
------------------	-------

O2 B1-S2(V) .....	366
O2 B2-S1(V) .....	366
O2 B2-S2(V) .....	366
O2OEVAP .....	366
O2OTEST .....	366
O2S1(mV) .....	367
O2S11(mV) .....	367
O2S11FM .....	367
O2S12(mV) .....	367
O2S12(V) .....	367
O2S13(V) .....	367
O2S2(mV) .....	367
O2S21(mV) .....	367
O2S21(V) .....	367
O2S21FM .....	367
O2S22(mV) .....	367
O2S22(V) .....	367
O2S23(V) .....	367
O2SEVAL_DC_MODE1 .....	368
OCT ADJ .....	368
OCTADJ .....	368
OCTANE ADJ .....	368
OCTANE .....	368
ODOMETER_TCM .....	423
ODS(rpm) .....	368
OFF/LOCK_Pos .....	411
OFMFLG .....	368
OFMFLG .....	423
OIL_TMP .....	322
OILPRES .....	322
OPEN/CLSD LOOP .....	368
OSFMFLG .....	368
OSS .....	423
OSS(rpm) .....	368
OSS=TSS(RPM) .....	369
OSS_DIR .....	369
OSS_DIR .....	423
OSS_F .....	369
OSS_F .....	423
OSS_FAULT .....	369
OSS_TCM .....	423
OTEMP_FMFLG .....	369
OTEMP_FMFLG .....	423
OUT_CODE .....	369
OUTCODE_BIT .....	369
OutShftSp(RPM) .....	369
OverdriveCancel .....	369
OverdriveCancel .....	423
OverSpdWarn .....	415

**P**

P DR SW .....	413
P/S PRESS(HIGH) .....	369

---

P_Airbag( $\Omega$ )	392
P_AirBAG2( $\Omega$ )	392
P_AirBAGLoop2( $\Omega$ )	392
P_Preten( $\Omega$ )	392
P_PRETNR( $\Omega$ )	392
PARK/NEU POS	370
PARK_INPT	369
ParkBrakeApply	370
ParkLmpSw	415
ParkNeuPos	370
PART#PRE_ABS	401
Pass DR SW	413
PATS_TYPE	370
PATSENABL	370
PBA	370
PCA	370
PCA	423
PCA_FAULT	370
PCA_FLT	423
PCA_FLT2	370
PCA_MES	423
PCAA	370
PCAA	424
PCAAMP_MES	424
PCB	371
PCB	424
PCBA	371
PCBA	424
PCBAMP_MES	424
PCBFILT	371
PCC	371
PCC	424
PCC_FLT	371
PCC_MES	424
PCCA	371
PCCA	424
PCCAMP_MES	424
PCD	371
PCD	424
PCD_AMP	371
PCD_AMP	424
PCD_FAULT	370
PCD_FLT	371
PCD_FLT	424
PCE	371
PCE	425
PCE_AMP	424
PCE_FAULT	370
PCE_FLT	371
PCF	371
PCF	424
PCF_FAULT	370

PCF_FLT .....	371
PCF_FLT .....	425
PCG .....	371
PCG .....	425
PCG_FAULT .....	370
PCG_FLT .....	372
PCG_FLT .....	425
PCLowOSM .....	372
PCM ID .....	405
PCM_VFY .....	405
PCM_MSG .....	322
PCM_MSG .....	401
PCM_MSG_TCM .....	425
PERDEL1(%) .....	372
PERDEL2(%) .....	372
PERDEL3(%) .....	372
PERDEL4(%) .....	372
PERDEL5(%) .....	372
PERDEL6(%) .....	372
PERDEL7(%) .....	372
PERDEL8(%) .....	372
PEVAP_TMP(°C/°F)(V) .....	372
PFE(V) .....	373
PinInputLevel .....	373
PIP .....	373
PLATE_A .....	411
PLATE_B .....	411
PLATE_C .....	411
PLATE_D .....	411
PLATE_A .....	322
PLATE_B .....	322
PLATE_C .....	322
PLATE_D .....	322
PLATE_PWR .....	322
PMP_AMP .....	322
PMP_MOTOR .....	402
PMPSTAT .....	402
PNP .....	373
PNP_ONLY .....	373
PRE_CHK .....	401
PRIM_VLV .....	401
PS1 .....	373
PSBELTR .....	392
PSP .....	373
PSP(KPA/PSI) .....	373
PSP(V) .....	373
PSR .....	374
PTO .....	374
PUMP .....	402
PUMPEFF .....	402
PVT_WDS .....	425
PWR_RLY .....	402
PwrStrPrs .....	369

## R

R_WSPD(MPH).....	400
R_DIF_SPD.....	402
R_INLET.....	402
R_OUTLET.....	402
R_PUTSHA .....	323
RCAM.....	374
RCL_F .....	374
RCL_F .....	425
RCL_FAULT .....	374
RearDefRly.....	415
RearDefSw .....	416
RearPosSense .....	416
RearWasher .....	416
RearWASHSW .....	416
RearWiper .....	416
RearWiperDn.....	416
RearWiperMd .....	413
RearWiperUp.....	416
RearWPRUN .....	416
RESET .....	432
RESPOS_TCM.....	425
RESUME .....	374
REV_SW .....	374
RevSel.....	416
RF_WSPD(MPH).....	400
RF_FAIL .....	402
RF_ID .....	432
RF_IN(AMP).....	402
RF_INLET .....	402
RF_LRН .....	432
RF_MES .....	432
RF_NORM.....	432
RF_OUT(AMP).....	402
RF_OUTLET .....	402
RF_PRES(KPA/PSI).....	403
RF_PRIME .....	403
RF_PSI .....	432
RF_REC .....	432
RF_SWITCH .....	403
RF_TC_PRV.....	403
RF_TC_SWV.....	403
RF_UnlockSw.....	414
RF_WSPD .....	323
RF_WSPD(KPH/MPH).....	403
RF_WSPD_TCM .....	425
RFAWAKE .....	433
RFDoorAjar .....	414
RFIDPRG .....	433
RFLOBAT .....	433
ROLLRAT .....	403

ROLLRATE.....	403
RPM.....	374
RPM_DSD_TCM .....	425
RPM_ENG_E4WD .....	323
RPM_FF .....	403
RPM_TCM.....	425
RPM_TCM_HEV .....	425
RPMDES.....	374
RR_TURN .....	415
RR_WSPD(MPH .....	400
RR_SlidDr_Ajar .....	414
RR_FAIL .....	403
RR_ID .....	433
RR_IN(AMP).....	403
RR_INLET .....	403
RR_LRN .....	433
RR_MES.....	433
RR_NORM .....	433
RR_OUT(AMP).....	403
RR_OUTLET .....	403
RR_PRES(KPA/PSI) .....	404
RR_PRIME .....	403
RR_REC .....	433
RR_SWITCH .....	404
RR_TC_VLV .....	404
RR_WSPD.....	323
RR_WSPD(KPH MPH .....	) 406
RRAWAKE.....	433
RRDoor SWitch .....	413
RRIDPRG .....	433
RRLOBAT .....	433
RRO_PSI .....	433
RUN_Pos .....	411

**S**

SAS_CAL .....	406
SBB_SS2.....	374
SC_VAC_SW.....	375
SC_VENT_SW.....	375
SC_OFF .....	374
SC_ON .....	375
SCBC.....	375
SCBCF .....	375
SCC_AMP .....	379
SCCS.....	375
SCCS(V.....)	375
SCCS_CANCEL.....	375
SCCS_NULL .....	375
SCCS_OFF_PID .....	376
SCCS_ON_PID .....	376
SCCS_RESUME .....	376
SCCS_TAP_DN.....	376
SCCS_TAP_UP .....	376

---

SCIICP .....	376
SCIICPF .....	376
SCP_PARK_BRAKE .....	376
SeatBeltLamp .....	416
SEC_ACCES.....	376
SecAIR mon rdy.....	376
SECND_VLV .....	406
SECPR_TRN.....	406
SELTESTDTC .....	323
SELTESTDTC .....	406
SEN_CAL.....	406
SENVBAT(V .....	406
SERV_MOD .....	376
SET_ACL .....	376
SFT1.....	376
SFT2.....	376
SFTRIM 1(%) .....	377
SFTRIM 2(%) .....	377
SHFT_TYP .....	377
SHFT_TYP .....	425
SHIFT_POS .....	425
ShiftSol1 .....	377
ShiftSol1A.....	377
ShiftSol1Fault .....	377
ShiftSol2 .....	377
ShiftSol2A.....	377
ShiftSol2Fault .....	377
ShiftSol3 .....	377
ShiftSol3A.....	377
ShiftSol3Fault .....	377
SHMOTCCLO .....	323
SHMOTCLOC .....	323
SHRTFT1(%).....	377
SHRTFT2(%).....	377
SLIP_DES_SCP .....	378
SLIP_DES_SCP .....	426
SP_LRN .....	433
SP_MES .....	433
SP_NORM.....	434
SP_REC .....	434
SPAREKEY_PCM .....	378
SPAREKY.....	406
SPARK ADV(°) .....	378
SPARK_ACT .....	378
SPARKADV(°) .....	378
SPARKDUR1.....	378
SPARKDUR2.....	378
SPARKDUR3.....	378
SPARKDUR4.....	378
SPARKDUR5.....	378
SPARKDUR6.....	378
SPARKDUR7.....	378
SPARKDUR8.....	378

SPA WAKE .....	434
SpdSensWipr .....	416
SPIDPRG .....	434
SPLOBAT .....	434
SPR_ID .....	434
SPR_PSI .....	434
SPRKADV(°) .....	378
SRC_CAN .....	378
SSA_AMP .....	378
SSA_AMP .....	426
SSA_SS1 .....	378
SSA_SS1_FLT .....	378
SSAFM .....	426
SSB_AMP .....	378
SSB_AMP .....	426
SSB_SS1 .....	426
SSB_SS2 .....	426
SSB_SS2_FLT .....	379
SSBFM .....	426
SSC(%) .....	379
SSC_AMP .....	426
SSC_SS3 .....	379
SSC_SS3_FLT .....	379
SSD(%) .....	379
SSD_SS4 .....	379
SSE .....	426
SSE(%) .....	379
SSPCA .....	379
SSPCA .....	426
SSPCA_FLT .....	379
SSPCA_FLT .....	426
SSPCB .....	379
SSPCB .....	426
SSPCB_FLT .....	379
SSPCB_FLT .....	426
SSPCC .....	379
SSPCC .....	426
SSPCC_FLT .....	379
SSPCC_FLT .....	427
ST TRIM B1(%) .....	380
ST TRIM B2(%) .....	380
ST_WH_ANGL .....	406
START_Pos .....	411
STATUS B1 .....	380
STE=EVP(V) .....	341
STEER_ANGL .....	406
SW_TEST .....	406
SWA_CCW .....	406
SWA_CW .....	406
SWA_LPS .....	407
SWA_POS(°) .....	407
SWA1_CIR .....	407
SWA1_INPT .....	407

---

SWA2_CIR .....	407
SWA2_INPT .....	407
SYNC_DI.....	380

## T

TA_LVAL.....	407
TA_RVAL.....	407
TC_RVAL.....	407
TC_SLIP.....	380
TC_SLIP.....	427
TCC SOL.....	381
TCC SOL(%) .....	381
TCC .....	380
TCC .....	427
TCC(%) .....	380
TCC_FLT.....	380
TCC_FLT.....	427
TCC_OSC .....	381
TCC_OSC .....	427
TCC_SLIP_DSD .....	427
TCCA.....	381
TCCA(V).....	381
TCCAMP_MES .....	427
TCCF.....	381
TCCFault.....	381
tccmact (RPM).....	381
TCCMACT(RPM).....	381
TCIL.....	381
TCIL.....	427
TCIL_FAULT.....	381
TCIL_FLT.....	381
TCIL_FLT.....	427
TCILFault.....	381
TCM_CAUTION .....	427
TCM_HAZ .....	427
TCS .....	382
TCS .....	427
TCSLAMP .....	386
TCYC_FS .....	323
TCYC_FS .....	407
TCYC_SW .....	407
TDPT_COMP .....	407
TDPT_PASS.....	407
TFT (°C/°F).....	427
TFT(V)(°C/°F) .....	382
TFT=TOT(V).....	382
THEFT_LMP .....	382
ThrPosMODE .....	383
THTRC(%).....	382
THTRCF .....	382
TIP_MIN_TCM .....	427
TIP_PL_TCM.....	428
TIRESIZE .....	382

TORQ_DSD.....	428
TorqConvCl.....	382
TORQUE .....	382
TORQUE .....	428
TORQUE(lb·ft).....	382
TORQUE_DSD.....	428
TORQUE_TCM .....	428
TOT_ENG (°C/°F).....	428
TOTF .....	382
TOTF .....	428
TOW_LAMP .....	322
TOWHAUL.....	383
TOWHAUL.....	428
TP MODE .....	383
TP MODE .....	383
TP(V) .....	383
TP=TPS(%) .....	383
TP=TPS(V) .....	383
TP_FAULT .....	383
TP_PER.....	428
TP_REL_TCM .....	428
TP1 .....	383
TP2 .....	383
TPCT(V) .....	384
TPF .....	384
TPI.....	323
TPREL(V) .....	384
TQ_CNTL .....	384
TQ_CNTL .....	429
TR .....	384
TR .....	428
TR=GEAR .....	387
TR_DC(%) .....	384
TR_FAULT .....	384
TR_FREQ(Hz) .....	384
TR_FREQ(Hz) .....	428
TR_V .....	386
TR_V .....	428
TR1 .....	384
TR2 .....	384
TR3 .....	384
TR3_MODE .....	384
TR4 .....	384
TRAC SW .....	407
TRAC_ACT .....	384
TRACtionassist.....	408
TRAN_OT_FAULT .....	384
TRAN_TEMP (°C/°F).....	428
TRANSMIT .....	384
TransRange_D .....	385
TRCASEGND .....	323
TRFM.....	385
TRFM.....	428

---

TRIM_B1-S1(%) .....	385
TRIM_B2-S1(%) .....	385
TRIP_CounT .....	386
TRIP .....	385
TRIP_CNT .....	386
TrnCtrlIndLamp .....	386
TrnCtrlSw .....	386
TrnFluidTmp(V) .....	386
TrnRange .....	387
TRO_N_F .....	387
TRO_N_F .....	428
TRO_N_FAULT .....	387
TRO_P_F .....	387
TRO_P_F .....	429
TRS1(V) .....	386
TRS2(V) .....	386
TRS3(V) .....	386
Trunk/Htch_Ajar .....	414
TSES_TCM .....	429
TSFMFGLG .....	387
TSFMFGLG .....	429
TSFMFGLG_TCM .....	429
TSLIPRAT .....	387
TSLIPRAT .....	429
TSS .....	429
TSS(rpm) .....	387
TSS_F .....	387
TSS_F .....	429
TSS_FAULT .....	387
TSS_TCM .....	429
TTR_DC .....	428
TurbSpdS(RPM) .....	388

## U

UNLIMITED_KEY .....	388
---------------------	-----

## V

V_ENABLE .....	406
V_4X4L .....	388
V_OCTADJ .....	388
V_TCASE .....	388
VALVCAL .....	408
VALVE_CAL .....	408
VAR_CMD .....	429
VAR_MES .....	429
VBAT(V) .....	388
VBATT .....	323
VBatt(V) .....	416
VBATT(V) .....	392
VBatt_GEM(V) .....	417
VBATT_PCM(V) .....	388
VBatt_Rem(V) .....	417

VCT_1_FAULT .....	388
VCT_2_FAULT .....	388
VCT1 .....	388
VCT1F .....	388
VCT2 .....	388
VCT2F .....	388
VCTA .....	388
VCTADV .....	388
VCTADV2 .....	388
VCTADVERR .....	389
VCTADVERR2 .....	389
VCTDC(%) .....	389
VCTDC2(%) .....	389
VCTSYS .....	389
VEH_CTRL .....	429
VehSpdSensr .....	389
VFC(%) .....	389
VFCDC(%) .....	389
VFCF .....	389
VFDES .....	389
VGT_F .....	389
VGT_FAULT .....	389
VGTDC(%) .....	389
VLV_AMP .....	323
VLVCHAR .....	323
VOLT_SENSR .....	429
VPoWeR .....	390
VPoWeR(V) .....	390
VPWR .....	429
VPWR(V) .....	390
VPWR=BATT(V) .....	390
VPWR_TCM .....	429
VREF(V) .....	390
VS_SET .....	390
VS_SRC .....	390
VS_SRC .....	429
VSMFLG .....	390
VSMFLG .....	430
VSS(KPH) .....	390
VSS(KPH MPH) .....	323
VSS(MPH) .....	390
VSS_F .....	430
VSS_FAULT .....	390
VSS_FF .....	408
VSS_GEM .....	417
VSS_PCM .....	408
VSS_TCM .....	430
VSS_TCM_HEV .....	430
VSS_TCM_HR .....	430
VSS TPM .....	434

**W**

WAC .....	391
-----------	-----

---

WAC=WOT A/C.....	391
WAC_FLT .....	391
WACA.....	391
WACFault .....	391
WAKESIG.....	408
WARM_NOMIL.....	391
WARMUPDTC_TCM.....	430
WARN_1.....	434
WARN_2.....	434
WARN_3.....	434
WARN_4.....	434
WARN_5.....	434
WasherPumpRly.....	417
WasherPumpSw.....	417
WASHRLY .....	417
WASTEGATE .....	391
WEAR OK .....	417
WFLUID.....	417
WFS .....	391
Wiper2SpdRly.....	417
WiperPk-Pk(mS).....	417
WiperRunRly .....	417
WotA/Ccutoff .....	391

## X

XDCR_ACCR(KPA/PSI).....	408
XDCR_LFW(KPA/PSI).....	408
XDCR_LRW(KPA/PSI) .....	408
XDCR_RFW(KPA/PSI).....	408
XDCR_RRW(KPA/PSI).....	408
XDCR_TMC(KPA/PSI) .....	408
XDUCERCAL .....	408

## Y

YAW_INPUT.....	409
YAW_RATE(°).....	409
YAWRATE .....	409
YAWRTSEN(°).....	409
YR_ICS .....	409

## 4x4 Parameters

**4\_LOW\_LED**Range: \_\_\_\_\_ **ON/OFF**

The 4x4 low status.

**4WDCPWMOU****4WDCPWMST(%)**Range: \_\_\_\_\_ **not available**

4WD clutch PWM status.

**4WDHIGHLMP**Range: \_\_\_\_\_ **not available**

4WD HIGH indicator lamp status.

**4WDINP\_SW**Range: \_\_\_\_\_ **2-W DRIVE, GND, OPEN, 4-W LOW, NEUTRAL, A4WD, 4W AUTO/HI**

4WD switch status.

**4WDLOWLMP**Range: \_\_\_\_\_ **not available**

4WD LOW warning indicator.

**4WDMODE\_L**Range: \_\_\_\_\_ **ON/OFF**

4WD mode lamp status.

**4X4\_BOO**Range: \_\_\_\_\_ **ON/OFF**

Brake ON/OFF status.

**4X4CCWRLY**Range: \_\_\_\_\_ **ON/OFF**

Transfer case shift relay (L2H counterclockwise status).

**4X4\_CWRLY**Range: \_\_\_\_\_ **ON/OFF**

4WD HIGH indicator LED.

**ABS\_ACTIVE**Range: \_\_\_\_\_ **ON/OFF**

Clockwise relay control.

**ABS\_MSG**Range: \_\_\_\_\_ **PRESENT/NOT PRESENT**

CAN message is missing from the ABS.

**ABS\_PWR\_R**Range: \_\_\_\_\_ **ON/OFF**

Antilock braking system power relay output status.

**CCNT**Range: \_\_\_\_\_ **not available**

Number of continuous codes present.

---

<b>CLCH_SOL (%)</b>	<b>Range:</b> _____	<b>not available</b>
PWM Output control command #1 status.		
<b>COPENPLAT</b>	<b>Range:</b> _____	<b>not available</b>
Currently open contact plates status.		
<b>CW_CCW</b>	<b>Range:</b> _____	<b>not available</b>
Clockwise relay control status.		
<b>FR_OUTSHA</b>	<b>Range:</b> _____	<b>not available</b>
Front shaft speed status.		
<b>HALLPOWER</b>	<b>Range:</b> _____	<b>not available</b>
Hall effect sensor power status.		
<b>HIGH_LAMP</b>	<b>Range:</b> _____	<b>ON/OFF</b>
4WD HIGH indicator LED.		
<b>IGN_SW</b>	<b>Range:</b> _____	<b>START/RUN</b>
Ignition switch status.		
<b>IGNITION(V)</b>	<b>Range:</b> _____	<b>not available</b>
Ignition status.		
<b>IWE_SOL</b>	<b>Range:</b> _____	
<b>IWE_SOLST</b>	<b>Range:</b> _____	<b>ON/OFF</b>
Integrated wheel ends solenoid status.		
<b>LF_WSPD</b>	<b>Range:</b> _____	<b>not available</b>
Left front wheel speed sensor.		
<b>LR_WSPD</b>	<b>Range:</b> _____	<b>not available</b>
Left rear wheel speed sensor.		
<b>LFDR_SW</b>	<b>Range:</b> _____	<b>AJAR/CLOSED</b>
Left front door ajar switch status.		
<b>LOW_LAMP</b>	<b>Range:</b> _____	<b>ON/OFF</b>
4WD Low indicator status.		
<b>MTR_CCW</b>	<b>Range:</b> _____	<b>ON/OFF</b>
Counterclockwise shift motor driver output state.		

---

<b>MTR_CW</b>	<b>Range:</b> _____	<b>ON/OFF</b>
Clockwise shift motor driver output state.		
<b>NSAFETYSW</b>	<b>Range:</b> _____	<b>NEUTRAL/OFF</b>
Neutral safety switch state.		
<b>NTF_4X4M</b>	<b>Range:</b> _____	
<b>NTF_CMD</b>	<b>Range:</b> _____	<b>ON/OFF</b>
Neutral tow function state.		
<b>NTF_LAMP</b>	<b>Range:</b> _____	
<b>TOW_LAMP</b>	<b>Range:</b> _____	<b>ON/OFF</b>
Neutral tow light state.		
<b>OILPRES</b>	<b>Range:</b> _____	<b>not available</b>
All wheel drive oil pressure before any FMEM substitution.		
<b>OIL_TMP</b>	<b>Range:</b> _____	<b>not available</b>
All wheel drive oil temperature before any FMEM substitution.		
<b>PCM_MSG</b>	<b>Range:</b> _____	<b>PRESENT/NOT PRESENT</b>
Indicates if CAN message is missing from the PCM.		
<b>PLATE_A</b>	<b>Range:</b> _____	<b>OPEN/CLOSED</b>
Transfer case contact plate switch A state.		
<b>PLATE_B</b>	<b>Range:</b> _____	<b>OPEN/CLOSED</b>
Transfer case contact plate switch B state.		
<b>PLATE_C</b>	<b>Range:</b> _____	<b>OPEN/CLOSED</b>
Transfer case contact plate switch C state.		
<b>PLATE_D</b>	<b>Range:</b> _____	<b>OPEN/CLOSED</b>
Transfer case contact plate switch D state.		
<b>PLATE_PWR</b>	<b>Range:</b> _____	<b>ON/OFF</b>
Contact plate power state.		
<b>PMP_AMP</b>	<b>Range:</b> _____	<b>not available</b>
Pump current - Actual.		

---

<b>R_PUTSHA</b>	<b>Range:</b> _____	<b>not available</b>
Rear shaft speed.		
<b>RF_WSPD</b>	<b>Range:</b> _____	<b>not available</b>
Right front wheel speed sensor.		
<b>RR_WSPD</b>	<b>Range:</b> _____	<b>not available</b>
Right rear wheel speed sensor.		
<b>RPM_ENG_E4WD</b>	<b>Range:</b> _____	<b>not available</b>
Engine speed state.		
<b>SELTESTDTC</b>	<b>Range:</b> _____	<b>not available</b>
Diagnostic trouble codes state.		
<b>SHMOTCCLO</b>	<b>Range:</b> _____	<b>ON/OFF</b>
Counterclockwise shift motor driver short to ground.		
<b>SHMOTCLOC</b>	<b>Range:</b> _____	<b>not available</b>
Clockwise shift motor driver short to ground.		
<b>TCYC_FS</b>	<b>Range:</b> _____	<b>ACTIVE/PASSIVE</b>
Traction control system state.		
<b>TPI</b>	<b>Range:</b> _____	<b>not available</b>
Throttle position state.		
<b>TRCASEGND</b>	<b>Range:</b> _____	<b>not available</b>
Transfer case contact plate ground return.		
<b>VBATT</b>	<b>Range:</b> _____	<b>not available</b>
Battery positive voltage.		
<b>VLV_AMP</b>	<b>Range:</b> _____	<b>not available</b>
Valve current - Actual.		
<b>VLVCHAR</b>	<b>Range:</b> _____	<b>not available</b>
Valve characteristic signal.		
<b>VSS(KPH MPH)</b>	<b>Range:</b> _____	<b>not available</b>
Vehicle speed.		

---

## Powertrain Control Module (PCM) Parameters

This section defines data parameters available from the engine control module or the powertrain control module (PCM) on Ford vehicles.

**3/2 SHIFT SOL**

**4/3 SHIFT SOL**

**Range:** \_\_\_\_\_ **ON/OFF**

State of the two solenoids used to activate the 3-2 and 4-3 downshift valves during deceleration and read ON when energized.

**4X4Low**

**Range:** \_\_\_\_\_ **ON/OFF**

State of 4-wheel drive low switch on the instrument panel. The switch sends a ground signal to the PCM when 4x4 low is ON, which is used to adjust the transmission shift schedule.

4x4Low reads as follows:

- ON when the switch circuit is closed
- OFF when the switch is open

**A\_CT(°C/°F)**

**Range:** \_\_\_\_\_ **not available**

Evaporator temperature state.

**A\_CT\_V(V)**

**Range:** \_\_\_\_\_ **not available**

Evaporator temperature signal voltage.

**A/CClutchSw**

**Range:** \_\_\_\_\_ **ON/OFF**

State of the A/C cycling switch. The PCM uses this parameter to adjust engine speed for added load.

A/CClutchSw reads as follows:

- ON when the switch is closed
- OFF when the switch is open

**A/CPrs(V)**

**Range:** \_\_\_\_\_ **0.0 to 5.0 V**

Condition of the air conditioning pressure (ACP) switch and reads as follows:

- 0 V when the switch is closed
- 4.0–5.0 V when the switch is open

On some models, the PCM turns on the high-speed cooling fan if ACP readings indicate A/C compressor head pressure is over 325 psi. The PCM may also use the signal to control idle speed and the A/C clutch.

**AAT(°C/°F)**

**Range:** \_\_\_\_\_ **not available**

Ambient air temperature.

**ACFD\_BAT**

**Range:** \_\_\_\_\_ **ON/OFF**

A/C full demand switch for the battery area.

---

<b>ACFD_PAS</b>	<b>Range:</b> _____	<b>ON/OFF</b>
A/C full demand switch for the passenger area.		
<b>AC_RC_SW</b>	<b>Range:</b> _____	<b>ON/OFF</b>
A/C recirculation switch.		
<b>ACCS</b>	<b>Range:</b> _____	<b>ON/OFF</b>
Air conditioning compressor cycling switch.		
<b>ACCS=A/C</b>	<b>Range:</b> _____	<b>ON/OFF</b>
Position of the air conditioning cycle switch (ACCS. It reads ON if the A/C switch on the instrument panel is on, or the PCM is commanding A/C on.		
In some cases, the A/C compressor may not turn on even though the switch is closed. Several other switch or sensor signals may prevent the PCM from engaging the A/C compressor clutch.		
<b>ACClutchHEV</b>	<b>Range:</b> _____	<b>ON/OFF</b>
Air conditioning clutch.		
<b>ACDS1</b>	<b>Range:</b> _____	<b>ENABLE/DISABLE</b>
Air conditioning diagnostic switch 1.		
<b>ACDS2</b>	<b>Range:</b> _____	<b>ENABLE/DISABLE</b>
Air conditioning diagnostic switch 2.		
<b>ACL=ACCEL</b>	<b>Range:</b> _____	<b>ON/OFF</b>
Accelerometer status.		
<b>AclPedl(V)</b>	<b>Range:</b> _____	<b>0.0 to 5.0 V</b>
Accelerator pedal (AP) sensor signal voltage to the PCM on diesel control systems. The AP sensor is similar to the throttle position sensor on a gasoline engine.		
The AP sensor signal is used to calculate the fuel injection quantity and to control the exhaust backpressure regulator. The MIL lights if the AP sensor signal does not match the IVS signal at idle. A faulty AP sensor allows the engine to run at low idle speed only.		
<b>ACP</b>	<b>Range:</b> _____	<b>not available</b>
Air conditioning pressure switch.		
<b>ACP</b>	<b>Range:</b> _____	<b>OPEN/CLOSED</b>
Air conditioning pressure switch.		
<b>ACP_PSI(KPA)</b>	<b>Range:</b> _____	<b>not available</b>
A/C pressure sensor.		

<b>ACRDV</b>	<b>Range:</b> _____	<b>ON/OFF</b>
A/C refrigerant distribution valve commanded.		
<b>ACRDV_F</b>	<b>Range:</b> _____	<b>YES FAULT/NO FAULT</b>
A/C refrigerant distribution valve status.		
<b>ACT_MNT</b>	<b>Range:</b> _____	<b>ON/OFF</b>
Active mount control commanded.		
<b>ACTF</b>	<b>Range:</b> _____	<b>YES/NO</b>
Inlet air temperature status.		
<b>ACTMNT_F</b>	<b>Range:</b> _____	<b>YES FAULT/NO FAULT</b>
Active mount control status.		
<b>AFT_ADDS</b>	<b>Range:</b> _____	<b>not available</b>
Passenger side power sliding door module.		
<b>AFT2_ADDS</b>	<b>Range:</b> _____	<b>not available</b>
Adaptive fuel table 2.		
<b>AIR</b>	<b>Range:</b> _____	<b>ON/OFF</b>
PCM command to the electric air pump and reads ON when the PCM has commanded the air pump on. The parameter also indicates the secondary air injector. The AIR and AIRMonitor parameters should read the same.		
<b>AIR A</b>	<b>Range:</b> _____	<b>ON/OFF</b>
PCM command to the secondary air relay and reads ON when the PCM is energizing the relay solenoid to close the relay contacts and run the air pump.		
<b>AIR_FLT</b>	<b>Range:</b> _____	<b>YES FAULT/NO FAULT</b>
Secondary air injection status.		
<b>AIRBA</b>	<b>Range:</b> _____	<b>ON/OFF</b>
Secondary air bypass actual.		

---

<b>AIRBypass</b>	
<b>Range:</b>	_____
<b>AIR B</b>	
<b>Range:</b>	_____ <b>ON/OFF</b>
Air bypass solenoid, which controls vacuum to the air bypass valve. If bypass is activated, air is directed to either the catalyst or an upstream-downstream valve. When the system is deactivated, air is blocked from the catalyst or routed to atmosphere.	
These parameters read as follows:	
<ul style="list-style-type: none"> <li>• ON when the air bypass solenoid is on and air bypass voltage is low</li> <li>• OFF if the solenoid is off and air bypass voltage is high</li> </ul>	
<b>AIRCON_SW_STATUS</b>	
<b>Range:</b>	_____ <b>ON/OFF</b>
Air conditioning switch status.	
<b>AIRD</b>	
<b>Range:</b>	_____ <b>ON/OFF</b>
Secondary air injection divert.	
<b>AIRDA</b>	
<b>Range:</b>	_____ <b>ON/OFF</b>
Secondary air divert actual.	
<b>AIRDivert</b>	
<b>AIR D</b>	
<b>Range:</b>	_____ <b>ON/OFF</b>
State of the air diverter solenoid, which controls vacuum to the air diverter valve. When the air diverter system is activated, air is routed upstream on many systems.	
These parameters read as follows:	
<ul style="list-style-type: none"> <li>• ON when the air diverter solenoid is on and air bypass voltage is low</li> <li>• OFF when the solenoid is off and voltage is high</li> </ul>	
<b>AIREVAL_DC_MODE1</b>	
<b>Range:</b>	_____ <b>YES/NO</b>
Secondary air system is evaluated.	
<b>AIRFault</b>	
<b>Range:</b>	_____ <b>YES/NO</b>
Secondary air injection system and reads YES when a fault is present.	
<b>AIRM</b>	
<b>Range:</b>	_____ <b>ON/OFF</b>
Status of the secondary air monitor.	
<b>AIRMonitor</b>	
<b>Range:</b>	_____ <b>ON/OFF</b>
Status for the electric air pump based on a PCM feedback signal and reads ON if the PCM detects a voltage change when the pump is commanded on. The AIR and AIRMonitor parameters should read the same.	
<b>ANTISCAN</b>	
<b>Range:</b>	_____ <b>ACTIVE/OFF</b>
Anti-scan function status.	

---

**AP(%)**

Range: \_\_\_\_\_ not available

Accelerator pedal position.

**AP(V)****APP1(V)****APP2(V)****APP3(V)**

Range: \_\_\_\_\_ 0 to 5.00 V

Voltage signal of the accelerator pedal position on a diesel engine control system. The accelerator position (AP) sensor is a three-wire potentiometer.

**Table 13-1 Normal AP sensor voltage readings**

SENSOR	CLOSED THROTTLE	WIDE OPEN THROTTLE
APP1	3.9–4.2 V	0.7–1.2 V
APP2	1.4–1.6 V	3.6–4.1 V
APP3	0.8–1.1 V	3.1–3.5 V

**AP\_MODE\_TCM**

Range: \_\_\_\_\_ PT/WOT/CT

**AP\_PER\_TCM(%)**

Range: \_\_\_\_\_ not available

Accelerator pedal position.

**APP\_MODE**

Range: \_\_\_\_\_ CT/PT/WOT

Indicates whether the APP sensor mode is closed throttle (CT), partial throttle (PT), or wide open throttle (WOT).

**APP\_F**

Range: \_\_\_\_\_ NO FAULT/FAULT

Accelerator pedal position status.

**APP1(V)**

Range: \_\_\_\_\_ not available

Accelerator pedal position sensor 1.

**APP\_LOW(V)**

Range: \_\_\_\_\_ not available

Closed throttle status.

**ARPMDES(rpm)**

Range: \_\_\_\_\_ not available

Ancillary RPM desired, which is the engine speed required to maintain the vehicle speed being commanded by the speed control system.

**AST**

Range: \_\_\_\_\_

**AST2**

Range: \_\_\_\_\_ not available

Time since start in seconds.

---

**AXLE**  
Range: \_\_\_\_\_ **not available**

This parameter indicates the axle ratio.

**BARO(Hz)**  
Range: \_\_\_\_\_ **125 to 160 Hz**

Barometric pressure in cycles per second, or Hertz (Hz) and should read as follows:

- 160 Hz at sea level
- 125 Hz at an elevation of 10,000 feet

**BARO(V)**  
Range: \_\_\_\_\_ **2.6 to 4.6 V**

Barometric pressure as voltage and should read as follows:

- 4.6 V at sea level
- 2.6 V at an elevation of 10,000 feet

**BLoWerMoToR**  
Range: \_\_\_\_\_ **ON/OFF**

Blower motor status.

**BLSHORT BATT**  
Range: \_\_\_\_\_ **YES/NO**

Presence of a short to battery positive in the blower motor circuit. YES means that a short exists.

**BLSHORT GND**  
Range: \_\_\_\_\_ **YES/NO**

Presence of a short to ground in the blower motor circuit. YES means that a short exists.

**BOO**  
Range: \_\_\_\_\_ **ON/OFF**

Brake ON/OFF status.

**BOO=BRAKE SW**  
Range: \_\_\_\_\_ **ON/OFF**

Brake pedal switch. Whenever the brake pedal is pressed, the brake ON/OFF (BOO) switch sends a battery voltage signal to the PCM.

BOO=BRAKE SW should read as follows:

- ON when the brake pedal is pressed
- OFF at all other times

Depending on the vehicle, the PCM may adjust engine idle speed with the brakes applied and the A/C turned on, or may turn the A/C off after a preset time. On vehicles with locking torque converters, the PCM may unlock the torque converter when the brakes are applied.

**BP=BARO (kPa)****BP=BARO ("HG)****Range:** \_\_\_\_\_ **see description**

Barometric pressure, which is calculated by the PCM based on the frequency of the barometric pressure (BP) sensor signal.

This parameter reads as follows:

- 102 kPa (30.1 inHG at sea level)
- 78 kPa (23 inHG at 7,000 feet)

Actual readings vary with weather conditions that cause barometric pressure to change.

**BPA****Range:** \_\_\_\_\_ **ON/OFF**

Brake pressure applied switch status.

**BPA\_SW****Range:** \_\_\_\_\_ **ON/OFF**

Brake pedal position status.

**BPO****Range:** \_\_\_\_\_ **YES/NO**

Battery power off request.

**BPO\_Hz****Range:** \_\_\_\_\_ **not available**

Battery power off signal.

**BPP\_BOO****Range:** \_\_\_\_\_ **ON/OFF**

Brake pedal position.

**BrakeOnOff****Range:** \_\_\_\_\_ **ON/OFF**

Brake pedal switch and reads as follows:

- ON when the brakes are applied
- OFF when the brakes are not applied

This parameter should read the same as the BOO=BRAKE SW parameter.

**CAMDC 1****CAMDC 2****Range:** \_\_\_\_\_ **not available**

Duty cycle of the variable cam timing solenoids.

- CAMDC 1 = bank 1
- CAMDC 2 = bank 2

**CAMDRCR****Range:** \_\_\_\_\_ **0 to 99%**

“On” time of the variable camshaft timing (VCT solenoid as requested by the PCM).

CAMDRCR should read as follows:

- Near 0% with the engine running at a warm idle, camshaft fully advanced with no EGR
- Near 50% with a warm engine and the vehicle operating at a steady cruise speed

---

**CAMERR1**  
**CAMERR2**  
**Range:** \_\_\_\_\_ **not available**

Variable cam timing error in crankshaft degrees.

- CAMERR 1 = bank 1
- CAMERR 2 = bank 2

**CANP=PURGE**  
**Range:** \_\_\_\_\_ **ON/OFF**

Canister purge solenoid, which opens canister purge (CANP) valve to regulate the flow of fuel vapors from the EVAP canister to the intake manifold.

- When the engine is at operating temperature, the solenoid turns ON. This opens the canister purge valve and purging occurs.
- When the engine is at idle or below operating temperature, the solenoid turns OFF. The valve closes and purge stops.

**CASEGND(V)**  
**Range:** \_\_\_\_\_ **-16.0 to 16.0 V**

Voltage difference between the PCM case ground and the hardwired Fuel Level Input from the fuel pump driver module.

- Above 0.050 V indicates high resistance
- 0.027 V is a typical reading

**CAT MONITOR**  
**CAT mon ready**  
**Range:** \_\_\_\_\_ **YES/NO**

Indicate whether the Catalyst Efficiency Monitor has successfully completed and read as follows:

- YES if the monitor completed
- NO if it did not

**CATCAL1(Hz)**  
**CATCAL2(Hz)**  
**Range:** \_\_\_\_\_ **1 to 4 Hz**

Catalyst calibrated frequency for each cylinder bank, which is determined by the PCM based on engine load and RPM. See CATTST for further information.

**CATEVAL\_DC\_MODE1**  
**Range:** \_\_\_\_\_ **YES/NO**

Catalyst monitor evaluated.

**CATTST1(Hz)**  
**CATTST2(Hz)**  
**Range:** \_\_\_\_\_ **1 to 4 Hz**

Steady State CAT monitor measured frequency for banks 1 and 2 and are only used in 1996 OBD-II vehicles. The reading is the frequency of the rear O2S during a catalyst efficiency monitor test. This number is compared to a calibrated frequency number determined by the PCM (CATCAS based on engine load and RPM).

If the CATTST value is greater than CATCAL, a Diagnostic Trouble Code (DTC is stored. The DTCs associated with this test are DTCs P0420 and P0430. The MIL is activated after a fault is detected on two consecutive drive cycles.

If the CATTST value is less than CATCAL the catalyst monitor will indicate YES or passed.

**CCC=TCC**  
**Range:** \_\_\_\_\_ **LOCKED/OFF**

PCM command to the torque converter clutch control (TCC solenoid and reads as follows:

- LOCKED when the TCC is engaged
- OFF when the TCC is disengaged

**CCL**  
**Range:** \_\_\_\_\_ **ON/OFF**

Fuel cap off indicator lamp state.

**CCLF**  
**Range:** \_\_\_\_\_ **YES FAULT/NO FAULT**

Fuel cap off indicator lamp fault state.

**CCMSTAT\_DC\_MODE1**  
**Range:** \_\_\_\_\_ **YES/NO**

Comprehensive components monitor evaluated state.

**CCS**  
**Range:** \_\_\_\_\_ **ON/OFF**

Coast clutch solenoid state.

**CCS\_FLT**  
**Range:** \_\_\_\_\_ **YES FAULT/NO FAULT**

**CCSFault**  
**Range:** \_\_\_\_\_ **YES/NO**

Presence of a fault in the coast clutch solenoid circuit. Reads YES or YES FAULT when a circuit fault is present.

**CCSA**  
**Range:** \_\_\_\_\_ **ON/OFF**

PCM feedback signal indicating the actual state of the coast clutch solenoid. When activated, fourth gear is disabled to allow engine braking in third gear. CCSA and the CoastCISol readings should simultaneously display ON or OFF.

**CHT(°C/°F)**  
**CHT SENSOR(°)**  
**Range:** \_\_\_\_\_ **ON/OFF**

Cylinder head temperature.

**CHT\_COLD(°C/°F)**  
**Range:** \_\_\_\_\_ **not available**

Cylinder head temperature cold value.

**CHT\_HOT(°C/°F)**  
**Range:** \_\_\_\_\_ **not available**

Cylinder head hot value.

**CHT\_V(°C/°F)**  
**Range:** \_\_\_\_\_ **not available**

Cylinder head temperature.

**CHTFM**  
**Range:** \_\_\_\_\_ **YES FAULT/NO FAULT**

Cylinder head temperature status.

---

**CHTIL**  
Range: \_\_\_\_\_ **ON/OFF**  
**CHTILFault**  
Range: \_\_\_\_\_ **YES/NO**  
**CHTIL\_FLT**  
Range: \_\_\_\_\_ **FAULT/NO FAULT**

Operating status of the Cylinder Head Temperature Indicator Lamp (CHTIS).

- CHTIL reads ON when the lamp is on.
- CHTILFault reads YES if a fault was detected.

**CKP\_PROF**  
Range: \_\_\_\_\_ **YES/NO**

Learned misfire correction profile state.

**CLRDIST\_NOMIL**  
Range: \_\_\_\_\_ **not available**

Distance since the last time diagnostic trouble codes were cleared.

**CMPFM**  
Range: \_\_\_\_\_ **YES/NO**

**CMPFM**  
Range: \_\_\_\_\_ **YES FAULT/NO FAULT**

Camshaft position (CMP) failure mode, which indicates if a fault was detected in the camshaft position (CMP) sensor circuits and reads YES if a fault occurred.

When the engine is cranking, or if operating in CMPFM mode, two spark plugs fire simultaneously until the CMP is determined by the PCM. This allows the engine to run even though the PCM is unable to determine if cylinder number 1 is on compression.

**CMPFM2**  
Range: \_\_\_\_\_ **YES FAULT/NO FAULT**

Camshaft position sensor 2 status.

**CmprCompMon rdy**  
Range: \_\_\_\_\_ **YES/NO**

Indicates whether the Component monitor has successfully completed and reads as follows:

- YES if the monitor completed
- NO if it did not

**CMPS\_Ip\_Lev**  
Range: \_\_\_\_\_ **HIGH/LOW**

Camshaft position sensor level state.

**CMPS\_Status**  
Range: \_\_\_\_\_ **OK/FAULT**

Camshaft position sensor state.

**COAST**  
Range: \_\_\_\_\_ **ON/OFF**

Speed control actuator coast switch state.

**CoastCISol**  
Range: \_\_\_\_\_ **ON/OFF**

PCM command to the coast clutch solenoid, which allows engine braking in third gear when fourth gear is disabled by the transmission control switch. Reads ON when the coast clutch solenoid is activated.

**CoastCISol(mA)**Range: \_\_\_\_\_ **0 to 1000 mA****CoastCISol(%)**Range: \_\_\_\_\_ **0 to 100%**

PCM command to the coast clutch solenoid. When activated, coast clutch solenoid allows engine braking in third gear when fourth gear is disabled by the transmission control switch.

The milliamp parameter displays the coast clutch solenoid current, and the percent parameter displays the duty cycle of the pulse width modulated solenoid signal.

**CPC\_AMP**Range: \_\_\_\_\_ **not available**

Converter pressure control state.

**CPP**Range: \_\_\_\_\_ **ON/OFF**

Clutch pedal position switch state.

**CPP\_ST**Range: \_\_\_\_\_ **NOT DEPRESSED/DEPRESSED**

Clutch pedal position switch state.

**CPP/TCS**Range: \_\_\_\_\_ **ON/OFF**

Indicates the following:

- Manual transmission vehicles—the status of the clutch pedal position switch (CPP)
- Automatic transmission vehicles—the status of the transmission control switch (TCS)

CCP/TCS reads as follows:

- ON when the switch is closed
- OFF when the clutch pedal or TCS is pressed and the switch opens

**CRUISE**Range: \_\_\_\_\_ **ON/OFF**

Reads ON if the driver selectable cruise control switch is on.

**CRUISE\_SW**Range: \_\_\_\_\_ **ON/OFF**

Speed control command switch state.

**CSEGND(V)**Range: \_\_\_\_\_ **-16.0 to 16.0 V**

Voltage difference between the PCM case ground and signal return.

- Above 0.050 V indicates high resistance
- 0.027 V is a typical reading

**CylHdTemp(V)**Range: \_\_\_\_\_ **(range 0.25 to 4.75 V**

Cylinder head temperature as voltage. The higher the voltage, the lower the temperature.

**DCDC\_ENA**Range: \_\_\_\_\_ **ON/OFF**

DC to DC converter enabled status.

---

**DCDC\_F**  
Range: \_\_\_\_\_ YES FAULT/NO FAULT

DC to DC converter status.

**DPFE(V)**  
Range: \_\_\_\_\_ 0.45 to 4.60 V

Differential pressure feedback EGR (DPFE sensor signal, which displays exhaust pressure to the PCM. The PCM uses DPFE to compute optimum EGR flow.

Pressure feedback EGR systems control EGR flow rate by monitoring pressure drop across a remotely located sharp-edged orifice. There are several sensor designs, some have an aluminum housing and use a 0.55 V offset, others have aluminum or plastic housings and use a 1.0 V offset. Typically, sensor output should be as shown in Table 13-2.

**Table 13-2 Outputs for DPFE sensors with 0.55 V and 1.0 V offsets**

0.55 V OFFSET			1.0 V OFFSET		
inHg	kPa	Volts	inHg	kPa	Volts
8.83	29.81	4.66	8.56	28.9	4.95
6.62	22.36	3.64	4.3	14.4	2.97
4.41	14.90	2.61	0	0	1.0
2.21	7.46	1.58			
0	0	0.55			

**DPFEGR**  
Range: \_\_\_\_\_ not available

Delta feedback pressure exhaust gas recirculation state.

**DRIVE Count**  
Range: \_\_\_\_\_ 0 to 255

The number of times the engine has been started since the last DTC P1000 (monitor readiness set).

**DRIVECNT**  
**Drive\_COUNT**  
Range: \_\_\_\_\_ not available

Valid drive counters.

**DSD**  
Range: \_\_\_\_\_ not available

Desired idle speed (rpm).

**DTC**  
Range: \_\_\_\_\_ not available

Diagnostic trouble codes.

**DTC\_CNT**  
Range: \_\_\_\_\_ not available

DTC count and includes DTCs needing no action.

**DTC\_CouNT (pcm)**  
Range: \_\_\_\_\_ see description

The number of continuous or pending codes that have set. The number changes each time a new code sets.

**EBP(V)**  
**Range:** \_\_\_\_\_ **0 to 5 V**

Voltage signal from the exhaust backpressure sensor, which is used by the PCM to control the exhaust backpressure regulator (EPR). As voltage increases, so does pressure:

**Table 13-3 Outputs for exhaust backpressure sensor**

VOLTS	psi	kPa
0.00	0.00	0.00
0.25	8.00	55.1
1.45	20.0	137
4.45	50.0	344
4.75	53.0	365
5.00	60.0	413

**ECT(°C)**  
**Range:** \_\_\_\_\_ **-40 to 199**

**ECT(°F)**  
**Range:** \_\_\_\_\_ **-40 to 389**

**ECT(V)**  
**Range:** \_\_\_\_\_ **0.0 to 5.0**

**ECT**  
**Range:** \_\_\_\_\_ **NORM/COLD/HOT**

Engine coolant temperature (ECT sensor signal as temperature or voltage. The ECT is a thermistor installed in the engine coolant passages. A 5 V reference signal is applied to the ECT. As temperature increases, sensor resistance decreases to provide a variable voltage signal to the PCM. The PCM converts ECT sensor voltage to temperature.

These parameters read as follows:

- The temperature parameter reads 185° to 220°F (85° to 105°C on a warm engine at idle).
- A temperature reading of -40°C or -40°F may indicate an open sensor or circuit.
- A temperature reading above 185°C or 366°F may indicate a short in the sensor or circuit.
- The voltage parameter reads 0.70 to 0.40 V on a warm engine at idle.

**ECT\_FF (°C/°F)**  
**Range:** \_\_\_\_\_ **not available**

Engine coolant temperature.

**ECTF**  
**Range:** \_\_\_\_\_ **YES FAULT/NO FAULT**

Engine coolant temperature state.

**EFTA**  
**Range:** \_\_\_\_\_ **not available**

Fuel rail pressure state.

**EGR\_EVAL**  
**Range:** \_\_\_\_\_ **YES/NO**

Exhaust gas recirculation system has been evaluated.

---

<b>EGR_Fault</b>	<b>Range:</b> _____	<b>YES FAULT/NO FAULT</b>
Exhaust gas recirculation state.		
<b>EGR MONITOR</b>		
<b>EGR mon ready</b>	<b>Range:</b> _____	<b>YES/NO</b>
EGR system monitor has successfully completed and read as follows:		
	<ul style="list-style-type: none"> <li>• YES if the monitor completed</li> <li>• No if it did not.</li> </ul>	
<b>EGRBARO</b>	<b>Range:</b> _____	<b>0 to 5 V</b>
EGR Baro sensor voltage signal. The signal is used by the PCM to control EGR flow. The greater the EGR flow, the lower the voltage.		
<b>EGRCFault</b>	<b>Range:</b> _____	<b>YES/NO</b>
PCM has detected a fault in the EGR control solenoid circuit and reads YES when a fault is present.		
<b>EGRCvacsol</b>	<b>Range:</b> _____	<b>ON/OFF</b>
State of a normally closed solenoid that regulates vacuum to the EGR valve with a variable duty cycle and reads as follows:		
	<ul style="list-style-type: none"> <li>• ON when the solenoid is enabled</li> <li>• OFF when it is disabled</li> </ul>	
<b>EGRDC(%)</b>	<b>Range:</b> _____	<b>not available</b>
Exhaust gas recirculation valve duty cycle.		
<b>EGRDtyCycl(%)</b>	<b>Range:</b> _____	<b>0 to 100%</b>
Duty cycle of the EGR vacuum regulator valve or EVR. The EVR controls the amount of EGR flow.		
EGRDtyCycl reads as follows:		
	<ul style="list-style-type: none"> <li>• 0% when the EVR is fully open and allowing vacuum to vent to atmosphere</li> <li>• 100% when the EVR is fully closed allowing vacuum to open the EGR valve</li> </ul>	
<b>EGREVAL_DC_MODE1</b>	<b>Range:</b> _____	<b>YES/NO</b>
Indicates if the exhaust gas recirculation system has been evaluated.		
<b>EGRFOpen</b>	<b>Range:</b> _____	<b>YES/NO</b>
Indicates whether the PCM has detected an open circuit in the EGR vacuum regulator valve or EVR circuit and reads YES when a fault is present.		
<b>EGRFShort</b>	<b>Range:</b> _____	<b>YES/NO</b>
Indicates whether the PCM has detected a short circuit in the EGR vacuum regulator valve or EVR circuit and reads YES when a fault is present.		

**EGRMC1****EGRMC2****EGRMC3****EGRMC4****Range:****ON/OFF**

EGR motor control state for the indicated EGR motor control number.

**EGRMC1F****EGRMC2F****EGRMC3F****EGRMC4F****Range:****YES FAULT/NO FAULT**

EGR motor control fault state for the indicated EGR motor control number.

**EGRMDSD****Range:****not available**

EGR motor position desired.

**EGRTPDC(%)****Range:****not available**

EGR throttle position.

**EGRVP(V)****EGRTP(V)****Range:****0.30 to 4.50 V**

Voltage signal sent to the PCM by the EGR valve position sensor, which indicates the position of the EGR valve pintle.

- A low reading indicates low EGR flow
- A high reading indicates high EGR flow

**EGRVPDES****Range:****0 to 14%**

Desired EGR.

**EGRVR(%)****Range:****0 to 90%**

Signal sent to the PCM by the EGR valve position sensor as a percentage.

A low reading indicates low EGR flow, while a high reading indicates high EGR flow.

**EGRVR\_FLT****Range:****No fault/Short/Open/Yes Fault/Invalid**

Exhaust gas recirculation vacuum regulator fault.

**EGRVentsol****Range:****ON/OFF**

PCM command to the EGR vent solenoid and reads ON when the solenoid is energized to bleed vacuum from the EGR valve and closing it.

**EGRVFault****Range:****ON/OFF**

PCM has detected a fault in the EGR vent solenoid circuit and reads YES when a fault is present.

---

**ElecPrsCtrl**  
Range: \_\_\_\_\_ **0 to 100 psi**

PCM commanded transmission electronic control pressure. This is a calculated parameter based on PCM-controlled pulse-width output.

**EngFuelTA(V)**  
**EngFuelTB(V)**  
Range: \_\_\_\_\_ **0 to 5.00 V**

Engine fuel temperature sensor voltage on diesel, flexible-fuel, and natural-gas powered vehicles.

- EngFuelTA = bank 1
- EngFuelTB = bank 2

**EOT(V)**  
Range: \_\_\_\_\_ **0 to 5 V**

**EOT(°)**

**EngOilTemp(°)**

**EOT\_DEG(°C/°F)**

Range: \_\_\_\_\_ **0 to 212°F or -17.8 to 100°C**

Engine oil temperature (EOT in volts and degrees).

**EOT\_M(°C/°F)**  
Range: \_\_\_\_\_ **not available**

Engine oil temperature.

**EOTF**  
Range: \_\_\_\_\_ **YES FAULT/NO FAULT**

Engine oil temperature state.

**EOTM**  
Range: \_\_\_\_\_ **HOT/COLD/NORM/DEF**

General state, or mode, of the engine oil temperature (EOT on diesel powertrain control systems).

Possible states are HOT, COLD, NORM (normal), and DEF (deFAULT). If the engine oil temperature is out of range, EOTM reads DEF.

**EPC(psi)**  
Range: \_\_\_\_\_ **0 to 100 psi**

PCM commanded transmission electronic control pressure (EPC). This is a calculated parameter base on PCM-controlled Pulse-Width output.

**EPC(V)**  
Range: \_\_\_\_\_ **2 V to battery voltage**

Average operating voltage of the pulse-width-modulated electronic pressure control solenoid.

A low average voltage reading indicates a higher EPC pressure; a higher reading indicates a lower EPC pressure.

**EPCV(V)**  
Range: \_\_\_\_\_ **not available**

Electronic pressure control voltage.

**EPR(%)**  
Range: \_\_\_\_\_ **0 to 100%**

Position of the exhaust pressure regulator (EPR). No further definition available at this time.

**ETC\_ACT**  
Range: \_\_\_\_\_ **Actual degrees**

**ETC\_DSD**  
Range: \_\_\_\_\_ **Desired degrees**

Actual (ACT and desired (DSD) electronic throttle control.

**ETC\_CTRL**  
Range: \_\_\_\_\_ **not available**

Throttle control for drive shaft balance.

**EVAP mon ready**  
Range: \_\_\_\_\_ **YES/NO**

Evaporative monitor has successfully completed and reads as follows:

- YES if the monitor completed.
- NO if it did not complete.

**EVAPC**  
**EVAPCV(%)**  
Range: \_\_\_\_\_ **0 to 100%**

PCM-commanded canister purge valve duty cycle and reads 100% when the canister purge valve is closed and not allowing fuel vapors from the evaporative canister.

**EVAPCPFault**  
Range: \_\_\_\_\_ **YES/NO**

Indicates whether the PCM detects a fault in the canister purge solenoid circuit and reads YES when a fault is present.

**EVAPCP**  
Range: \_\_\_\_\_ **ON/OFF**

Indicates whether the canister purge solenoid is on (ON or off (OFF).

**EVAPCP\_FLT**  
Range: \_\_\_\_\_ **YES FAULT/NO FAULT**

Evaporative emission canister purge fault.

**EVAPCV**  
Range: \_\_\_\_\_ **0 to 100%**

Duty cycle of the EVAP canister vent solenoid, which controls the amount of air entering the EVAP system.

EVAPCV reads as follows:

- 0% when the solenoid is fully open
- 100% when the solenoid is fully closed

**EVAPCVA**  
Range: \_\_\_\_\_ **ON/OFF**

Evaporative emission canister vent valve.

**EVAPCVF1**  
Range: \_\_\_\_\_ **YES FAULT/NO FAULT**

Evaporative emission canister vent valve status.

---

<b>EVAPCVFault</b>	<b>Range:</b> _____	<b>YES/NO</b>
<b>EVAPCVFLT</b>	<b>Range:</b> _____	<b>YES FAULT/NO FAULT</b>
PCM detects a fault in the canister vent solenoid circuit and reads YES when a fault is present.		
<b>EVAPEVAL_DC_MODE1</b>		
<b>Range:</b> _____	<b>YES/NO</b>	
Evaporative system monitor evaluated.		
<b>EVAPPrgFlw(V)</b>		
<b>Range:</b> _____	<b>0 to 5 V</b>	
Presence of purge flow from the canister to the engine. Voltage should increase as purge flow increases.		
EVAPPrgFlw reads as follows:		
<ul style="list-style-type: none"> <li>• 0.4 to 1.3 V at idle</li> <li>• 0.4 to 4.0 V at steady cruise</li> </ul>		
<b>EVAPSTA</b>	<b>Range:</b> _____	<b>not available</b>
Evaporative emissions monitor status.		
<b>EVAPVM(%)</b>		
<b>Range:</b> _____	<b>not available</b>	
Evaporative emission vapor management valve status command.		
<b>EVAPVM_Fault</b>	<b>Range:</b> _____	<b>YES FAULT/NO FAULT</b>
Evaporative emission vapor management fault.		
<b>EVAPVMA</b>	<b>Range:</b> _____	<b>ON/OFF</b>
Commanded state of the EVAPVM.		
<b>EVMV</b>	<b>Range:</b> _____	<b>OFF/ON/VARYING</b>
Evaporative emission vapor management valve status.		
<b>EVP(V)</b>	<b>Range:</b> _____	<b>0.30 to 4.50 V</b>
<b>STE=EVP(V)</b>	<b>Range:</b> _____	
EGR valve position (EVP) sensor signal, which reflects EGR valve pintle position. The EVP sensor is mounted on the EGR valve.		
The spring-loaded EGR valve is operated by a vacuum signal from the EGR vacuum regulator solenoid. As supply vacuum overcomes spring force, the diaphragm moves. This lifts the pintle off of its seat and allows exhaust gas to recirculate. The amount of flow is proportional to the pintle position. Specifications are model dependant.		

**EVR(%)**  
**Range:** \_\_\_\_\_ **0 to 100%**

Duty-cycle output by the PCM to operate the EGR vacuum regulator (EVR) solenoid.

The EVR solenoid is a pulse-width-modulated (PWM) device that controls manifold vacuum to the EGR valve. The PCM outputs to the EVR regulates the vacuum output to the EGR valve. As the duty-cycle is increased, so is the vacuum output to the EGR valve.

EVR(%) reads as described in Table 13-4.

**Table 13-4 EVR(%) readings**

EVR(%)	inHg RANGE	kPa RANGE
0%	0 to 0.75	0 to 2.53
33%	0.55 to 2.05	1.86 to 6.9
90%	5.69 to 6.95	19.2 to 23.47

**ExhBackPrs**  
**Range:** \_\_\_\_\_ **0 to 2368 psi**

Exhaust back pressure sensor as determined by a variable-capacitor type sensor in the right exhaust manifold on diesel powertrain control systems.

**FAN**  
**Range:** \_\_\_\_\_ **LOW/HIGH/OFF**

Operational status of the engine cooling fan.

**FAN\_FLT**  
**Range:** \_\_\_\_\_ **No Fault/LFC Fault/HFC FAULT**

Engine cooling fan operation.

**FAN Monitor**  
**Range:** \_\_\_\_\_ **ON/OFF**

Feedback signal that determines if the fan has been successfully commanded on or off by the PCM. The PCM monitors the fan side of the CCRM (or IRCM).

- ON indicates high input voltage
- OFF indicates low input voltage

**FAN\_REQ**  
**Range:** \_\_\_\_\_ **ON/OFF**

Cooling fan state requested.

**FANM(HIGH)**  
**Range:** \_\_\_\_\_ **ON/OFF**

Indicates whether the PCM is commanding the fan to run at high speed and reads ON when the fan is running at high speed.

**FANSSM**  
**Range:** \_\_\_\_\_ **HIGH/LOW**

Fan speed sensor monitor.

**FANSS**  
**Range:** \_\_\_\_\_ **not available**

Electronic cooling fan speed sensor.

---

<b>FDSP_ESCS_GPL</b>	<b>Range:</b> _____	<b>ON/OFF</b>
Glow plug lamp state.		
<b>FFINF(%)</b>	<b>Range:</b> _____	<b>not available</b>
Inferred flex fuel.		
<b>FFLRND</b>	<b>Range:</b> _____	<b>YES/NO</b>
Flex fuel learned status.		
<b>FICM_LPWR</b>		
<b>FICM_VPWR</b>		
<b>Range:</b> _____	<b>10.5 to 15.5 V</b>	
<b>FICM_MPWR</b>		
<b>Range:</b> _____	<b>40 to 52 V</b>	
Voltage readings from the fuel injector control module (FICM).		
• LPWR = Logic power		
• MPWR = Main power		
• VPWR = Vehicle power		
<b>FICMSYNC</b>	<b>Range:</b> _____	<b>YES/NO</b>
Synchronization from the FICM (Fuel Injector Control Module).		
<b>FIRMSHFT</b>	<b>Range:</b> _____	<b>ON/OFF</b>
Firm shift status.		
<b>FLIFM</b>		
<b>Range:</b> _____	<b>YES/NO</b>	
Fuel level input FMEM flag.		
<b>FLI_PERCENT(%)</b>	<b>Range:</b> _____	<b>not available</b>
Fuel level state.		
<b>FP</b>	<b>Range:</b> _____	<b>ON/OFF</b>
Fuel pump status.		
<b>FlexFuel(Hz)</b>	<b>Range:</b> _____	<b>-32,512 to 32,768</b>
Flexible fuel output frequency.		
<b>FLG_MLUSFM</b>	<b>Range:</b> _____	<b>YES FAULT/NO FAULT</b>
Torque converter unlocking due to slipping.		
<b>FLG_OTLK</b>	<b>Range:</b> _____	<b>YES FAULT/NO FAULT</b>
Transmission over temperature lock up mode.		

**FLG\_SS4**Range: \_\_\_\_\_ **ON/OFF**

Shift solenoid 4 state.

**FLI(V)**Range: \_\_\_\_\_ **not available**

Fuel level input voltage.

**FLInput(V)****FuelLvlInput(V)**Range: \_\_\_\_\_ **0 to 32.0 V****FLInput(%)****FuelLvlInput(%)**Range: \_\_\_\_\_ **0 to 100%**

Fuel level in the fuel tank as a voltage. A voltage or percentage at the high end of the sensor range indicates a high fuel level.

The PCM must receive a signal of 25–75% before beginning the evaporative emission monitor test.

**FLI\_SG(V)**Range: \_\_\_\_\_ **not available**

Fuel level input voltage.

**FPA STATE**Range: \_\_\_\_\_ **ON/OFF**

Actual state of the fuel pump power circuit and reads as follows:

- ON when the pump is running
- OFF when it is not

**FP=FUEL PUMP**Range: \_\_\_\_\_ **ON/OFF**

ON/OFF status of the fuel pump relay.

- The fuel pump turns ON when the ignition switch is turned on and the fuel pump relay is energized.
- The fuel pump shuts OFF if the ignition switch is not turned to the start position and the PCM de-energizes the fuel pump relay after approximately one second.

The PCM operates the fuel pump when the ignition is in the start position to provide fuel while the engine is cranking. Once the engine starts the PCM continues operating the fuel pump unless the engine speed drops below 120 RPM or the inertia fuel switch (IFS) is activated.

**FP\_FLT**Range: \_\_\_\_\_ **YES FAULT/NO FAULT**

Fuel pump fault status.

**FPFault**Range: \_\_\_\_\_ **YES/NO**

Indicates whether the PCM has detected a fault in the fuel pump circuit and reads YES when a fault is present.

---

<b>FPM</b>		ON/OFF
<b>Range:</b>	_____	
<b>FPM(%)</b>		
<b>Range:</b>	_____	not available
Fuel pump monitor.		
<b>FPMode</b>		
<b>Range:</b>	_____	
<b>FPMonitor</b>		
<b>Range:</b>	_____	ON/OFF
Indicate whether the fuel pump has turned on or off in response to a command from the PCM.		
<b>FRP(psi)</b>		
<b>Range:</b>	_____	37 to 150 psi
Fuel rail pressure (FRP) in psi on natural gas powered vehicles.		
<b>FRP(V)</b>		
<b>Range:</b>	_____	not available
Fuel rail pressure voltage.		
<b>FRP_DSD</b>		
<b>Range:</b>	_____	not available
Fuel pressure desired.		
<b>FRP_FAULT</b>		
<b>Range:</b>	_____	YES FAULT/NO FAULT
Fuel rail pressure status.		
<b>FRP_PRESS</b>		
<b>Range:</b>	_____	not available
Fuel rail pressure.		
<b>FRPFM</b>		
<b>Range:</b>	_____	YES FAULT/NO FAULT
Fuel rail pressure transducer status.		
<b>FRT1FM</b>		
<b>Range:</b>	_____	YES FAULT/NO FAULT
Fuel rail temp sensor #1 status.		
<b>FSVFault</b>		
<b>FuelSolVlv</b>		
<b>Range:</b>	_____	YES/NO
Indicates whether the PCM detects a fault in the fuel solenoid valve circuit on flexible-fuel vehicles and reads YES when a fault is present.		
<b>FSVMonitor</b>		
<b>Range:</b>	_____	ON/OFF
Fuel solenoid valve (FSV circuit on flexible-fuel vehicles state and reads ON when the PCM has turned on the fuel solenoid valve.		
<b>FTIV_HEV(%)</b>		
<b>Range:</b>	_____	not available
Fuel tank isolation valve.		

---

<b>FTIV_F</b>		
Range:	_____	YES FAULT/NO FAULT
Fuel tank isolation valve status.		
<b>FTP(KPA)</b>		
Range:	_____	not available
Fuel tank pressure transducer.		
<b>FTP_FAULT</b>		
Range:	_____	YES FAULT/NO FAULT
Fuel tank pressure transducer status.		
<b>FUEL_mon ready</b>		
Range:	_____	YES/NO
Indicates whether the Fuel monitor has successfully completed and reads as follows:		
• YES if the monitor completed		
• NO if it did not		
<b>FUEL_RAIL_TEMP(°C/°F)</b>		
Range:	_____	not available
Fuel rail temperature.		
<b>FuelPumpA</b>		
Range:	_____	ON/OFF
Actual state of the commanded fuel pump output and should read the same as the fuel pump monitor and fuel pump command output displays. All three should be ON or OFF at the same time.		
<b>FUELPW(mS)</b>		
Range:	_____	0 to 99.9
Time in milliseconds (mS) that the PCM commands the fuel injectors to turn on for diesel powertrain control systems.		
• A high reading indicates more on-time.		
• A low reading indicates less on-time.		
<b>FUELPW</b>		
Range:	_____	not available
Fuel pulse width.		
<b>FUELPW1(mS)</b>		
<b>FUELPW2(mS)</b>		
Range:	_____	0 to 99.9
Current commanded pulse width of the injectors affected by O2S1 and O2S2. The displayed value is the pulse width that was commanded at the time of the last update.		
On some vehicles, updating may occur only when a PIP signal is being received, and the last updated value is retained after the PIP signal stops. In these cases, a value greater than zero may display during KOEO.		
<b>FUELPW2(%)</b>		
Range:	_____	not available
Fuel pulse width #2 percentage.		

---

**FuelRailPrs(V)****Range:** \_\_\_\_\_ **0 to 4.5 V**

Fuel rail pressure in volts on natural gas powered vehicles. As voltage increases, so does pressure.

- 0 V = 37.6 psi (260 kPa)
- 4.5 V = 150 psi (1034 kPa)

**FUEL STATUS****FUEL SYS****FUEL SYS1****FUEL SYS2****FUELSYS****Range:** \_\_\_\_\_ **see description**

Indicate whether the vehicle is operating in open or closed loop. It is similar to the OPEN/CLSD LOOP but provides more information about the cause of the open- or closed-loop condition. FUEL SYS1 and FUEL SYS2 refer to bank 1 and 2.

These parameters read as follows:

- CL = normal closed loop
- CL FLT = One O2S is not switching and the PCM is using the other one for feedback
- OL = normal open loop
- OL DRV = Open loop because of driver action or other special circumstances
- OL FLT = Open loop with O2S problem or primary side coil failure

**FuelTankPrs(V)****Range:** \_\_\_\_\_ **0 to 5.0 V**

Signal voltage from the fuel tank pressure sensor. The Evaporative Emissions Monitor requires input from this sensor.

With the gas cap removed, signal voltage should be between 2.4 and 2.8 V. During the evaporative emissions test, expect voltage to decrease while the PCM applies vacuum to the fuel tank.

**G\_SDN****Range:** \_\_\_\_\_ **YES/NO**

Generator shutdown request.

**GEAR****Range:** \_\_\_\_\_ **1st/2nd/3rd/4th/5th/6th/REV**

Processor commanded gear position on vehicles with electronic transmissions.

**GEAR\_MAX****Range:** \_\_\_\_\_ **not available**

Highest gear allowed.

**Gear\_OSC****Range:** \_\_\_\_\_ **not available**

Gear command by output state control.

**GEAR\_RAT****Range:** \_\_\_\_\_ **not available**

Gear ratio.

**GENLMP****GEN\_LAMP****Range:** \_\_\_\_\_ )ON/OFF

Generator lamp circuit.

**GEN\_FAULT****Range:** \_\_\_\_\_ YES/NO

Reads YES when the PCM detects a generator output fault.

**GEN\_MON****Range:** \_\_\_\_\_ LOW/HIGH**GEN\_MON(%)****Range:** \_\_\_\_\_ not available

Generator monitor status.

**GENB\_F****Range:** \_\_\_\_\_ YES FAULT/NO FAULT

Generator B fault.

**GENB\_FAULT****Range:** \_\_\_\_\_ YES/NO

Reads YES when the PCM detects a fault in the generator B+ circuit.

**GENF****Range:** \_\_\_\_\_ YES FAULT/NO FAULT

Generator output fault.

**GENFDC(%)****Range:** \_\_\_\_\_ not available

Generator field duty cycle.

**GENFIL****Range:** \_\_\_\_\_ YES/NO

Reads YES when the PCM detects a fault in the generator lamp circuit.

**GENVDSD****Range:** \_\_\_\_\_ not available

Generator voltage desired.

**GlowPlugCtrl(%)****Range:** \_\_\_\_\_ 0 to 100%

Glow plug control (GPC duty cycle on diesel truck powertrain control systems, this. At high battery voltage, the PCM cycles the glow plug current on and off to prevent damage to the glow plugs.

GlowPlugCtrl reads as follows:

- 0% = the glow plug circuit is off
- 100% = the circuit is on continuously

Related parameters that may display are GPCTM and GPLTM.

**GPC(%)****Range:** \_\_\_\_\_ not available

Glow plug control percentage.

---

<b>GPC_L</b>	<b>Range:</b> _____	<b>not available</b>
	Glow plug current, left bank.	
<b>GPC_R</b>	<b>Range:</b> _____	<b>not available</b>
	Glow plug current, right bank.	
<b>GPCoilTiMe</b>	<b>Range:</b> _____	<b>10 to 120 seconds</b>
	Glow plug control time on diesel powertrain control systems, which shows the actual time the glow plugs would be switched on for if the engine were started under current conditions.	
	The time interval is based on engine oil temperature and reads as follows:	
	<ul style="list-style-type: none"> <li>• About 10 seconds on a warm engine</li> <li>• 120 seconds on a cold engine</li> </ul>	
<b>GPCTM</b>	<b>Range:</b> _____	<b>not available</b>
	Glow plug coil on time.	
<b>GPLTM</b>	<b>Range:</b> _____	<b>not available</b>
	Glow plug lamp time if active.	
<b>GPLampTiMe</b>	<b>Range:</b> _____	<b>2 to 10 seconds</b>
	Glow plug lamp time on diesel powertrain control systems, which shows the length of time that the "wait to start" would be illuminated if the ignition was switched on under current conditions.	
	The lamp comes on every time a key reset occurs, and it remains on from 2 to 10 seconds depending upon engine temperature.	
<b>GR_RATIO</b>	<b>Range:</b> _____	<b>not available</b>
	Transmission gear ratio.	
<b>GTQ_OUT_ENG</b>	<b>Range:</b> _____	<b>not available</b>
	Measured generator torque.	
<b>HCATEVAL_DC_MODE1</b>	<b>Range:</b> _____	<b>YES/NO</b>
	Heated catalyst monitor is evaluated.	
<b>HFC</b>	<b>Range:</b> _____	<b>ON/OFF</b>
	Fan control high speed.	
<b>HFC_FLT</b>	<b>Range:</b> _____	<b>YES FAULT/NO FAULT</b>
	Fan control high fault.	

---

**HFCA**  
Range: \_\_\_\_\_ **ON/OFF**

Actual state of the commanded output to the fan. It should be the same as the fan monitor and fan command output displays; that is, all three should display ON or OFF at the same time.

**HFCFault**  
Range: \_\_\_\_\_ **YES/NO**

Indicates whether the PCM detects a fault with the high speed cooling fan circuit and reads YES if a fault is present.

**HO2S11(mA)**

**HO2S12(mA)**

**HO2S21(mA)**

**HO2S22(mA)**

Range: \_\_\_\_\_ **0 to 1000 mA**

Actual current in the heated oxygen sensor (HO2S heater circuit in milli-amps).

The two-digit numbers after HTR in the parameter refer to the HO2S position:

- 11—Bank 1, Upstream
- 12—Bank 1, Downstream
- 21—Bank 2, Upstream
- 22—Bank 2, Downstream

**HO2S MONITOR**

**HO2S mon ready**

Range: \_\_\_\_\_ **YES/NO**

Indicate whether the heated oxygen sensor (HO2S monitor has successfully completed and reads as follows:

- YES if the monitor completed
- NO if it did not

**HPRC\_ENA**

Range: \_\_\_\_\_ **ON/OFF**

Heater pump command.

**HPRC\_F**

Range: \_\_\_\_\_ **YES FAULT/NO FAULT**

Heater pump status.

---

**HTR11Fault**  
**HTR11F**  
**HTR12Fault**  
**HTR12F**  
**HTR21Fault**  
**HTR21F**  
**HTR22Fault**  
**HTR22F**  
**Range:** \_\_\_\_\_ **YES/NO**

PCM detects a fault in the oxygen sensor (O2S) heater circuit. Reads YES when a fault is present. The two-digit numbers after HTR in the parameter refer to the O2S position:

- 11—Bank 1, Upstream
- 12—Bank 1, Downstream
- 21—Bank 2, Upstream
- 22—Bank 2, Downstream

**HTR11A**  
**HTR11**  
**HTR12A**  
**HTR12**  
**HTR21A**  
**HTR21**  
**HTR22A**  
**HTR22**  
**Range:** \_\_\_\_\_ **ON/OFF**

O2S heaters state. The state should be the same as for the corresponding HTRX data parameter; both should read ON or OFF at the same time.

- HTR11/HTR11A = bank 1 upstream O2S, should read the same as HTRX1
- HTR12/HTR12A = bank 1 downstream O2S, should read the same as HTRX2
- HTR21/HTR21A = bank 2 upstream O2S, should read the same as HTRX1
- HTR22/HTR22A = bank 2 downstream O2S, should read the same as HTRX2

**HTR13**  
**Range:** \_\_\_\_\_ **ON/OFF**

Heated exhaust gas oxygen sensor heater (bank 1, sensor 3).

**HTR21F**  
**Range:** \_\_\_\_\_ **YES FAULT/NO FAULT**

Heater control for O2S21 fault.

**HTR23**  
**Range:** \_\_\_\_\_ **ON/OFF**

Heated exhaust gas oxygen sensor heater (bank 2, sensor 3).

**HTRCM11**  
**Range:** \_\_\_\_\_ **not available**

Heater current monitor for heated exhaust oxygen sensor 11.

**HTRCM12**  
**Range:** \_\_\_\_\_ **not available**

Heater current monitor for heated exhaust oxygen sensor 12.

**HTRCM21****Range:** \_\_\_\_\_ **not available**

Heater current monitor for heated exhaust oxygen sensor 21.

**HTRCM22****Range:** \_\_\_\_\_ **not available**

Heater current monitor for heated exhaust oxygen sensor 22.

**HTREVAL\_DC\_MODE1****Range:** \_\_\_\_\_ **YES/NO**

Heated exhaust oxygen sensor heater system evaluated.

**HTRX1****HTRX2****Range:** \_\_\_\_\_ **ON/OFF**

PCM-command status for the upstream (HTRX1) or downstream (HTRX2) O2S heater. ON means the heater is on.

**IAC(%)****Range:** \_\_\_\_\_**IAC=IDLE AIR(%)****Range:** \_\_\_\_\_ **0 to 100%**

PCM output command to the idle air bypass solenoid. The reading displays as a percentage value and corresponds to the IAC valve amperage (current and voltages in Table 13-5).

**Table 13-5 IAC(%) and IAC=IDLE AIR(%) readings**

PERCENTAGE READING	IAC VALVE VOLTAGE	IAC VALVE AMPERAGE
10%	1 V	0.1 A
50%	5 V	0.5 A
80%	8 V	0.8 A
100%	10–12 V	1.0 A

The idle air control (IAC) solenoid is used to regulate the amount of air that bypasses the throttle at idle, and thus the idle speed. A lower number indicates the valve is open for a shorter period, providing less idle air. A higher number indicates that the valve is open longer, providing more idle air.

An adaptive IAC strategy is used by the PCM to compensate for wear, vacuum leaks, and throttle plate coking. When engine conditions meet IAC adaptive strategy learning requirements, the PCM monitors and determines the values for ideal idle calibration. These values are stored in PCM memory as a correction factor for controlling idle speed.

**IAC\_CELL0****Range:** \_\_\_\_\_ **not available**

Airflow time learned (Drive, A/C, OFF).

**IAC\_CELL1****Range:** \_\_\_\_\_ **not available**

Airflow time learned (Drive, A/C, ON).

**IAC\_CELL2****Range:** \_\_\_\_\_ **not available**

Airflow time learned (Neutral, A/C, On.).

---

<b>IAC_CELL3</b>	<b>Range:</b> _____	<b>not available</b>
Airflow time learned (Neutral, A/C, OFF.)		
<b>IAC_MODE</b>	<b>Range:</b> _____	<b>not available</b>
Idle air control.		
<b>IAC_TRIM</b>	<b>Range:</b> _____	<b>not available</b>
Short term airflow trim before KAM learned.		
<b>IACDTCY(%)</b>	<b>Range:</b> _____	<b>not available</b>
Idle air control valve duty cycle.		
<b>IACF</b>	<b>Range:</b> _____	<b>not available</b>
Idle air control fault.		
<b>IACFault</b>	<b>Range:</b> _____	<b>YES/NO</b>
<b>IACFLT</b>	<b>Range:</b> _____	<b>YES FAULT/NO FAULT</b>
Indicate whether the PCM detects a fault in the idle air control (IAC system and reads YES if a fault is present.		
<b>IAT</b>		
<b>IAT(°C)</b>		
<b>IAT(°F)</b>		
<b>IAT_C</b>		
<b>IAT2</b>		
<b>IAT2_TEMP</b>		
<b>IAT_T</b>		
<b>IAT2_VOLTS</b>	<b>Range:</b> _____	<b>0 to 255°C or °F</b>
Intake air temperature. The IAT2 sensor provides a manifold air temperature signal to the PCM and is located in the intake manifold.		
<b>IAT(V)</b>		
<b>IAT2(V)</b>	<b>Range:</b> _____	<b>0.0 to 5.0 V</b>
Voltage signal from the intake air temperature sensor. A 5 V reference signal is applied to the IAT. As temperature increases, the sensor resistance decreases, which provides a variable intake air voltage signal to the PCM.		

<b>IAT=ACT(°C)</b>		
Range:	_____	-40 to 199°C
<b>IAT=ACT(°F)</b>		
Range:	_____	-40 to 389°F

**IAT=ACT(V)**  
Range: \_\_\_\_\_ **0.0 to 5.0 V**

Intake air temperature (IAT) sensor signal as temperature or voltage. The IAT is a thermistor that is typically installed in the air cleaner. A 5 V reference signal is applied to the IAT. As temperature increases, the sensor resistance decreases, which provides a variable intake air voltage signal to the PCM. The PCM converts IAT voltage signals to temperature readings.

IAT readings, along with MAF or MAP, are primary parameters used by the PCM to calculate the amount of air entering the engine, which is critical for determining the amount of fuel required. The IAT reading should be close to the ambient air temperature on a cold engine and should rise steadily as the engine warms up. Readings on a warm engine differ greatly between vehicles because of under-hood temperature variations and hot-soak conditions.

**IAT\_FAULT**  
Range: \_\_\_\_\_ **YES FAULT/NO FAULT**

Indicates the inlet air temperature status.

**ICP(V)**  
Range: \_\_\_\_\_ **0.0 to 5.0 V**

Injector control pressure (ICP) sensor signal, which indicates absolute pressure for the fuel injection on a diesel engine. The ICP sensor is mounted on the left cylinder bank.

The display may be the unconverted voltage signal, or it may be the PCM converted equivalent pressure in psi or megapascal (MPa). On any of these scales, a low reading indicates low injection pressure and a high reading indicates higher injection pressure.

**ICP\_DES**  
Range: \_\_\_\_\_ **not available**

Injector control pressure desired.

**ICP\_PRESS**  
Range: \_\_\_\_\_ **not available**

Injector control pressure.

**IGN\_RUN\_PCM**  
Range: \_\_\_\_\_ **not available**

Ignition key status.

**ILINE\_V**  
Range: \_\_\_\_\_ **not available**

Generator command.

**IMRC**  
Range: \_\_\_\_\_ **ON/OFF**

Intake manifold runner control.

**IMRCM(V)**  
Range: \_\_\_\_\_ **not available**

Intake manifold runner control monitor.

**IMRC1M(V)**

Range: \_\_\_\_\_

**IMRC2M(V)**Range: \_\_\_\_\_ **not available**

Position of the intake manifold runner control valves on cylinder Bank 1 (IMRC1M) and Bank 2 (IMRC2M). Depending on the vehicle, a high voltage may mean that the valve is open or that the value is shut.

**IMRCFault**Range: \_\_\_\_\_ **YES/NO****IMRCFLT**Range: \_\_\_\_\_ **YES FAULT/NO FAULT**

Indicate whether the PCM detected a fault in the intake manifold runner control system and reads YES when a fault is present.

**IMS\_SRC**Range: \_\_\_\_\_ **not available**

Intermediate shaft speed.

**IMTV(%)**Range: \_\_\_\_\_ **0 to 100%**

PCM-command status for the intake manifold tuning valve. At 100% the valve should be fully open.

**IMTV\_FLT**Range: \_\_\_\_\_ **YES FAULT/NO FAULT****IMTVF**Range: \_\_\_\_\_ **YES FAULT/NO FAULT**

Intake manifold tuning valve fault status.

**IMTV1\_PER(%)**Range: \_\_\_\_\_ **not available**

Intake manifold tuning valve bank 1.

**IMTV2**Range: \_\_\_\_\_ **ON/OFF**

Intake manifold tuning valve bank 2.

**IMTV2\_FLT**Range: \_\_\_\_\_ **YES FAULT/NO FAULT**

IMTV 2 status.

**IMTV2\_PER(%)**Range: \_\_\_\_\_ **not available**

Intake manifold tuning valve bank 2.

**IMTVFault**Range: \_\_\_\_\_ **YES/NO**

Indicates whether the PCM has set an intake manifold tuning valve DTC and reads YES when the PCM set a DTC.

**INJ**Range: \_\_\_\_\_ **YES FAULT/NO FAULT**

Indicates the injector fault status.

**INJ PW1(mS)****INJ PW2(mS)****Range:** \_\_\_\_\_ **0 to 99.9**

Length of time in milliseconds (mS) that the PCM commands the fuel injectors to energize. These parameters are used on multiport fuel injection systems.

On Electronic Fuel Injection (EFI) systems, the PCM simultaneously pulses half of the fuel injectors at a time. INJ PW1(mS) refers to those injectors installed in bank #1, and INJ PW2(mS) refers to the injectors in bank #2. Depending on the engine, banks #1 and #2 may be staggered.

These parameters read as follows:

- A high pulse width indicates more on-time and a richer mixture.
- A low pulse width indicates less on-time and a leaner mixture.

There are no definite specifications for injector pulse width, but the reading should change as engine speed and load change.

On EFI systems, these parameters read as follows:

- 1 to 5 mS at idle
- About 18 mS at wide open throttle (a little higher for some engines)

Since the PCM on SEFI systems pulses each injector individually, the readings represent, at best, the "average" injector pulse width for each bank. Ford SEFI systems use these parameters to allow the PCM to conduct rationality tests on the fuel delivery, the mass airflow (MAF) sensor, and the throttle position (TP) sensor.

**INJ\_TIM****Range:** \_\_\_\_\_ **not available**

Injector timing before top dead center.

**INJ1****INJ2****INJ3****INJ4****INJ5****INJ6****INJ7****INJ8****INJ9****INJ10****Range:** \_\_\_\_\_ **YES FAULT/NO FAULT**

Injector fault according to injector number.

**INJnFault****Range:** \_\_\_\_\_ **YES/NO**

Reads YES when the PCM has detected a fault, such as an open or short, in the injector circuit.

The "n" in INJnFault is a variable from 1 to 10, depending on the indicated cylinder.

---

**InjPrsReg(%)**  
Range: \_\_\_\_\_ **0 to 100%**

On-time of the pulse-width-modulated injector pressure regulator on a diesel engine as a percentage. The PCM controls the fuel volume by varying the injection oil pressure with the injector pressure regulator. The injector pressure regulator is a ground-side controlled 12 V regulator.

**InManRunCtrl(%)**  
Range: \_\_\_\_\_ **0 to 100%**

PCM-command status for the intake manifold runner control valve. At 100% the pulse-width-modulated valve should be fully open.

**InManRunCtrl**  
Range: \_\_\_\_\_ **ON/OFF**

Intake manifold runner control valve status. Reads as follows:

- ON = the valve is open
- OFF = the valve is close

Normally this valve is closed when the engine speed is below 3000 RPM.

**IPR(%)**  
Range: \_\_\_\_\_ **not available**

Injector control pressure regulator.

**ISS(rpm)**  
Range: \_\_\_\_\_ **not available**

Input shaft speed.

**ISS\_DIR**  
Range: \_\_\_\_\_ **FORWARD/REVERSE**

Immediate shaft direction.

**ISS\_F**  
Range: \_\_\_\_\_ **YES FAULT/NO FAULT**

Intermediate shaft speed reliable.

**ISS\_FAULT**  
Range: \_\_\_\_\_ **YES/NO**

Reads YES when a fault is detected in the input shaft speed (ISS circuit).

**ITS1**  
Range: \_\_\_\_\_ **GEAR1/NOT GEAR1**

1st gear indicator.

**ITS2**  
Range: \_\_\_\_\_ **NOT GEAR/GEAR**

2nd gear indicator.

**ITSD**  
Range: \_\_\_\_\_ **DRIVE/NOT DRIVE**

Drive status.

**ITSR**  
Range: \_\_\_\_\_ **REVERSED/NOT REVERSED**

Reverse indicator.

**IVS**  
Range: \_\_\_\_\_ YES/NO

Idle validation switch (IVS state, which verifies that the accelerator pedal (AP) is in the idle position on diesel powertrain control systems.

The IVS provides a check on the AP sensor. The MIL lights if the IVS signal does not match the AP sensor signal. A faulty IVS or AP sensor allows the engine to run at low idle speed only.

**KAMFUSE**  
Range: \_\_\_\_\_ ON/FAULT

Keep alive memory power.

**KEYPOS**  
Range: \_\_\_\_\_ not available

Ignition key status.

**KNOCK\_1**  
Range: \_\_\_\_\_ not available

Sensor 1 status.

**KNOCK\_2**  
Range: \_\_\_\_\_ not available

Sensor 2 status.

**LCF\_FLT**  
Range: \_\_\_\_\_ YES FAULT/NO FAULT

Fan control low fault.

**LFC**  
Range: \_\_\_\_\_ ON/OFF

Fan control low speed.

**LFC=LO FAN**  
**HFC=HI FAN**  
**HighFanCtrl**  
Range: \_\_\_\_\_ ON/OFF

Fan relays. Some engines have a two-speed electric fan, which the PCM controls through LFC and HFC outputs to the fan relays.

The high speed relay is a normally open for all models. However, the low speed fan relay is normally closed for Escort and Tracer, and normally open for Probe.

When the fan is off:

- HFC should read OFF.
- LFC should read OFF for Probe and ON for Escort and Tracer.

With the low speed fan on:

- HFC should read OFF.
- LFC should read ON for Probe and OFF for Escort or Tracer.

When the high speed fan is on:

- HFC should read ON.
- LFC should read OFF for all models.

---

**LFCFault**  
Range: \_\_\_\_\_ **YES/NO**

Reads YES when the PCM has detected a low speed fan control module fault.

**LFT1(%)**  
Range: \_\_\_\_\_ **not available**

Long term fuel trim 1.

**LFTRIM 1(%)**  
**LFTRIM 2(%)**  
Range: \_\_\_\_\_ **-35% to +35%**

The long-term fuel trim (LFTRIM) numbers represent the operation and long-term correction of fuel-metering on a fuel-injected engine. The value shows if the PCM is commanding a rich or a lean mixture.

Similar to short-term fuel trim (SFTRIM), the LF TRIM number can range from -35% to +35%, with 000% as the midpoint. A number above zero percent indicates the PCM has commanded a long-term rich mixture correction. A number below zero percent indicates the PCM is commanding a lean mixture.

The LF TRIM number follows the short-term fuel (ST FUES) number and makes long-term corrections to the fuel-metering in response to a pattern or trend of short-term fuel changes.

Compare LF TRIM numbers to injector on-time. Numbers above zero percent indicate increased on-time. Numbers below zero percent indicate decreased on-time. LF TRIM corrections operate only in closed loop. In open loop, the number goes to a fixed value.

**LOAD(%)**  
**ENG LOAD(%)**  
Range: \_\_\_\_\_ **see description**

Engine load as calculated by the PCM based on engine speed (RPM), number of cylinders, airflow, and cylinder air charge compared to the theoretical air charge that occurs at standard PCM temperature and pressure (volumetric efficiency). The resulting ratio—called engine load—is expressed as a percentage.

The engine load parameters read as follows:

- 20–40% = a normal load at idle
- Less than 80% = normal driving
- More than 100% = under hard acceleration in cold temperatures or high barometric pressure, or on supercharged vehicles

**LOAD\_FF(%)**  
Range: \_\_\_\_\_ **not available**

Engine load.

**LONGFT1(%)**  
Range: \_\_\_\_\_ **not available**

Long term fuel trim 1.

**LONGFT2(%)**  
Range: \_\_\_\_\_ **not available**

Long term fuel trim 2.

**LOS\_BRAK**  
Range: \_\_\_\_\_ **YES/NO**

Limited operating mode due to the regenerative braking system.

<b>LOS_ENG</b>	<b>Range:</b> _____	<b>YES/NO</b>
Limited operating mode due to the engine.		
<b>LOS_ETC</b>	<b>Range:</b> _____	<b>YES/NO</b>
Limited operating mode due to the electronic throttle control.		
<b>LOS_EQ</b>	<b>Range:</b> _____	<b>YES/NO</b>
Limited operating mode due to the E-quizzzer.		
<b>LOS_GEN</b>	<b>Range:</b> _____	<b>YES/NO</b>
Limited operating mode due to the generator.		
<b>LOS_HV</b>	<b>Range:</b> _____	<b>YES/NO</b>
Limited operating mode due to the high voltage battery.		
<b>LOS_IPC</b>	<b>Range:</b> _____	<b>YES/NO</b>
Limited operating mode due to the independent plausibility checker.		
<b>LOS_KEY</b>	<b>Range:</b> _____	<b>YES/NO</b>
This parameter indicates the limited operating mode due to the key position.		
<b>LOS_LV</b>	<b>Range:</b> _____	<b>YES/NO</b>
Limited operating mode due to the 12-Volt battery.		
<b>LOS_MOT</b>	<b>Range:</b> _____	<b>YES/NO</b>
Limited operating mode due to the electric motor.		
<b>LOS_OWC</b>	<b>Range:</b> _____	<b>YES/NO</b>
Limited operating mode due to the one way clutch.		
<b>LOS_TCM</b>	<b>Range:</b> _____	<b>YES/NO</b>
Limited operating mode due to the transmission control module.		
<b>LOSSRTT</b>	<b>Range:</b> _____	<b>YES/NO</b>
Limited operating mode due to the engine no start.		
<b>LowFanCA</b>	<b>Range:</b> _____	<b>ON/OFF</b>
Actual state of the commanded output to the fan. It should read the same as the fan monitor and fan command output; that is, all three should be ON or OFF at the same time.		
<b>LowFanCtrl</b>	<b>Range:</b> _____	<b>ON/OFF</b>
State of the low-speed fan control on vehicles with multiple fan speed control.		

---

<b>LowFPumpFault</b>	<b>Range:</b> _____	<b>YES/NO</b>
Reads YES when the PCM has detected a fault in the low speed fuel pump circuit.		
<b>LPC_AMP</b>	<b>Range:</b> _____	<b>not available</b>
Line pressure.		
<b>LT TRIM B1(%)</b>		
<b>LT TRIM B2(%)</b>		
<b>Range:</b> _____		<b>-20 to +20%</b>
Long-term fuel trim (LT TRIM B1 or B2 = BANK 1, or BANK 2) numbers represent the operation and long-term correction of fuel-metering on a fuel-injected engine. The value shows if the PCM is commanding a rich or a lean mixture.		
Similar to short-term fuel trim ("ST TRIM B1(%)" on page 380), the LT TRIM parameter ranges from -20% to +20% with 00% as the midpoint:		
<ul style="list-style-type: none"> <li>• A number above zero percent indicates the PCM has commanded a long-term rich mixture correction.</li> <li>• A number below zero percent indicates the PCM is commanding a lean mixture.</li> </ul>		
LT TRIM follows the short-term fuel (ST FUES number and makes long-term corrections to the fuel-metering in response to a pattern or trend of short-term fuel changes.		
Compare LT TRIM numbers to injector on-time. Numbers above zero percent indicate increased on-time. Numbers below zero percent indicate decreased on-time. LT TRIM corrections operate only in closed loop. In open loop, the number goes to a fixed value.		
<b>M_DPFE</b>		
<b>Range:</b> _____		<b>not available</b>
EGR sensor input at the time of a misfire.		
<b>M_IAT</b>		
<b>Range:</b> _____		<b>not available</b>
Intake air temperature (IAT at the time of a misfire).		
<b>M_LOAD(%)</b>		
<b>Range:</b> _____		<b>not available</b>
Engine load at the time of a misfire.		
<b>M_PNP</b>		
<b>Range:</b> _____		<b>not available</b>
Park/Neutral Position (PNP) at the time of a misfire.		
<b>M_RPM</b>		
<b>Range:</b> _____		<b>not available</b>
Engine speed at the time of a misfire.		
<b>M_RUN</b>		
<b>Range:</b> _____		<b>not available</b>
Engine running time at the time of a misfire.		
<b>M_SOAK</b>		
<b>Range:</b> _____		<b>not available</b>
Engine-off soak time in minutes prior to a misfire.		

**M\_TP**  
**Range:** \_\_\_\_\_ **not available**

Throttle position at the time of a misfire.

**M\_TRIP**  
**Range:** \_\_\_\_\_ **not available**

Number of trips since the time of a misfire.

**M\_VSS**  
**Range:** \_\_\_\_\_ **not available**

Vehicle speed at the time of a misfire.

**M\_WHEEL**  
**Range:** \_\_\_\_\_ **not available**

Learned misfire correction profile at the time of a misfire.

**MAF(gm/S)**  
**AIRFLOW(g/S)**  
**Range:** \_\_\_\_\_ **0 to 255**

Amount of air flowing into the engine in grams per second. It is the same as the MAF=MASS AIR(gm/sec) parameter. Reading should be low at idle and higher at high RPM.

**MAF(V**  
**Range:** \_\_\_\_\_ **0 to 5.0 V**

Voltage signal from the mass airflow (MAF sensor to the PCM).

It is the same as the MAF=MASS AIR(V parameter. The reading should be low at idle and higher at high RPM.

**MAF\_Fault**  
**MASS AIR FLOW\_STATUS**  
**Range:** \_\_\_\_\_ **YES/NO**

Indicate whether a fault has occurred in the MAF circuit.

**MAF\_RATE**  
**Range:** \_\_\_\_\_ **not available**

Indicates the mass air flow.

**MAF=MASS AIR(V**  
**Range:** \_\_\_\_\_ **0.5 to 5.0 V**  
**MASS AIR(gm/sec)**  
**Range:** \_\_\_\_\_ **0 to 255**

Display the MAF sensor output in volts on EEC-IV systems with DCL. They display a value in grams per second calculated by the PCM based on the MAF sensor signal on EEC-V (OBD-II) systems.

The MAF sensor, which is located between the air cleaner and the throttle body, measures the mass of air flowing to the engine. The PCM uses this value to calculate the injector pulse width needed to obtain an optimal air-fuel ratio.

MAF sensor readings should be low at idle and should increase as the throttle opens.

**MAFF**  
**Range:** \_\_\_\_\_ **YES FAULT/NO FAULT**

Mass air flow status.

---

**MAN LEV POS**

Range: \_\_\_\_\_ see description

Position of the gear selector lever: PARK, REV, NEUT, O/D, DRIVE, MAN1, and MAN2.

**MAN LEV POS(V)**

Range: \_\_\_\_\_ see description

Status of the manual lever position (MLP) sensor, which is a ratiometric sensor with six resistors in series. The PCM looks at the voltage for each shift lever position.

Typical readings are:

- Park = 4.41 V
- Reverse = 3.60 V
- Neutral = 2.83 V
- Drive = 2.09 V
- 2nd = 1.37 V
- 1st = 0.68 V

**MAN VAC**

Range: \_\_\_\_\_ 0 to 35 "HG

Internally calculated PCM value that indicates engine manifold vacuum as determined by inputs from various system sensors. Values should equal actual vacuum gauge readings.

**MAP(Hz)**

Range: \_\_\_\_\_ see description

Manifold absolute pressure (MAP) sensor outputs frequency signal, which is relative to intake manifold vacuum. The MAP sensor frequency increases as vacuum decreases.

MAP(Hz) reads as follows:

- 80 Hz at 101.6 kPa (30 inHG of manifold vacuum)
- 159 Hz at zero manifold vacuum

The PCM uses the MAP signal to determine engine load and regulate the air-fuel ratio, ignition timing, and EGR flow, and to compensate for altitude.

**MAP(psi)**

Range: \_\_\_\_\_ 0 to 2368 psi

Manifold absolute pressure on turbocharged diesel powertrain systems in pounds per square inch (psi). The PCM uses the MAP sensor signal to decrease fuel during acceleration until reaching a specified boost pressure. This decreases tailpipe smoke.

**MAP\_DI2**

Range: \_\_\_\_\_ not available

Manifold absolute pressure sensor status.

**MAP\_F**

Range: \_\_\_\_\_ YES FAULT/NO FAULT

Manifold absolute pressure sensor status.

**MAP\_PCM**

Range: \_\_\_\_\_ not available

Manifold absolute pressure sensor.

**MAP\_V**

Range: \_\_\_\_\_ not available

Manifold absolute pressure sensor.

**MAP2**

**Range:** \_\_\_\_\_ **not available**

Manifold absolute pressure sensor.

**MASTERKEY**

**Range:** \_\_\_\_\_ **PRESENT/NOT PRESENT**

Master key present status.

**MAT**

**Range:** \_\_\_\_\_ **not available**

Input signal from the manifold air temperature sensor to the PCM on diesel powertrain systems. The PCM uses this signal and other sensor signals to determine fuel injection rate.

**MECP\_ENA**

**Range:** \_\_\_\_\_ **ON/OFF**

Motor electronics coolant pump.

**MECP\_F**

**Range:** \_\_\_\_\_ **YES FAULT/NO FAULT**

Motor electronics coolant pump status.

**MECT\_V(V)**

**Range:** \_\_\_\_\_ **not available**

Motor electronics coolant temperature.

**MIN\_KEY**

**Range:** \_\_\_\_\_ **not available**

Minimum number of keys required.

**MFC**

**Range:** \_\_\_\_\_ **ON/OFF**

Medium fan control

**MFC\_FLT**

**Range:** \_\_\_\_\_ **YES FAULT/NO FAULT**

Medium fan control status.

**MFDES**

**Range:** \_\_\_\_\_ **0 to 255 mG**

Internal PCM calculation of the mass fuel desired (MFDES per stroke of the injection pump to operate the engine under the current speed, load, and temperature conditions on diesel powertrain systems.

The readings are in milligrams (mG):

- 8 to 10 mg at idle
- About 60 mg at full throttle

**MGP**

**Range:** \_\_\_\_\_ **-10 to 30 psi**

Manifold gauge pressure (MGP).

---

<b>MIL</b>	<b>Range:</b> _____	<b>ON/OFF</b>
<b>MILFault</b>	<b>Range:</b> _____	<b>YES/NO</b>
Indicate whether a fault has occurred in the MIL circuit:		
<ul style="list-style-type: none"> <li>• ON = the MIL is lit</li> <li>• OFF = the MIL is off</li> </ul>		
<b>MIL_FLT</b>	<b>Range:</b> _____	<b>YES FAULT/NO FAULT</b>
MIL driver fault.		
<b>MISF_EVAL</b>	<b>Range:</b> _____	<b>YES/NO</b>
Misfire monitor evaluated.		
<b>MISFEVAL_DC_MODE1</b>	<b>Range:</b> _____	<b>YES/NO</b>
Misfire monitor evaluation is complete.		
<b>MISFire</b>	<b>Range:</b> _____	<b>YES/NO</b>
Indicates whether a misfire has occurred. Crankshaft acceleration is measured for each cylinder firing event. Should the acceleration drop below a specified threshold, a misfire is deemed to have occurred.		
<b>MPLRN</b>	<b>Range:</b> _____	<b>YES/NO</b>
Learned status of the misfire wheel. Reads as follows:		
<ul style="list-style-type: none"> <li>• YES if the PCM has learned and stored the misfire wheel profile</li> <li>• NO if the profile has not been learned</li> </ul>		
<b>M_SDN</b>	<b>Range:</b> _____	<b>YES/NO</b>
Electronic motor shutdown request.		
<b>MTQ_OUT_ENG</b>	<b>Range:</b> _____	<b>not available</b>
Total number of misfires.		
<b>N_KEYCODE</b>	<b>Range:</b> _____	<b>not available</b>
Number of keys stored.		
<b>NM</b>	<b>Range:</b> _____	<b>not available</b>
Total number of misfires.		
<b>NUMKEYS</b>	<b>Range:</b> _____	<b>not available</b>
Number of keys stored in the module.		

---

**O2 B1-S1(V)****O2 B1-S2(V)****O2 B2-S1(V)****O2 B2-S2(V)****Range:****0 to 1.800 V**

Oxygen sensors (O2SS) are the primary sensors used to determine if the engine is running rich or lean. The O2S generate a voltage signal ranging from 0 to a little over 1 V:

- 0.800 V or higher signal indicates a rich exhaust
- 0.200 V or lower signal indicates a lean exhaust

An O2S must be hot (above 500°F/260°C), and the PCM must be operating in closed loop before the PCM responds to the sensor signal. EEC-IV V-type engines have separate sensors for the left and right banks, while EEC-IV transverse-mounted engines have separate sensors for front and rear.

EEC-V systems have additional oxygen sensors after each catalyst. Ford calls these downstream sensors catalyst monitor sensors (CMS). This means EEC-V vehicles with dual exhaust have four sensors:

- B1-S1—The upstream sensor for bank 1
- B1-S2—The downstream sensor for bank 1
- B2-S1—The upstream sensor for bank 2
- B2-S2—The downstream sensor for bank 2

**O2OEVAP****Range:****YES/NO**

Indicates whether the EVAP purge leak check monitor has completed.

- YES indicates the leak check was performed and the PCM can run a purge monitor idle test.
- NO indicates that the purge monitor is being prevented because the leak check failed.

**O2OTEST****Range:****YES/NO**

Indicates whether the minimum soak time has elapsed to enable an EVAP monitor test.

- YES indicates the purge monitor test is enabled.
- NO indicates the purge monitor is being prevented due to insufficient soak time.

---

**O2S1(mV)**

**O2S2(mV)**

**O2S11(mV)**

**O2S12(mV)**

**O2S21(mV)**

**O2S22(mV)**

**Range:** \_\_\_\_\_ **0 to 1800**

The oxygen sensors (O2SS) are the primary sensors used to determine if the engine is running rich or lean. The O2S generate a voltage signal ranging from 0 to a little over 1 V (0 to 1000 mV).

- A high millivolt signal indicates a rich exhaust.
- A low signal indicates a lean exhaust.

An O2S must be hot (above 500°F/260°C), and the PCM must be operating in closed loop before the PCM responds to the sensor signal. EEC-IV V-type engines have separate sensors for the left and right banks, EEC-IV transverse-mounted engines have separate sensors for front and rear.

EEC-V systems have an additional O2S after each catalyst. Ford calls these downstream sensors catalyst monitor sensors (CMS). This means EEC-V vehicles with dual exhaust have four sensors:

- O2S11 — The upstream sensor for bank 1
- O2S12 — The downstream sensor for bank 1
- O2S21 — The upstream sensor for bank 2
- O2S22 — The downstream sensor for bank 2.

**O2S11FM**

**Range:** \_\_\_\_\_ **YES FAULT/NO FAULT**

Heated exhaust oxygen sensor (bank1, sensor 1 status).

**O2S12(V)**

**Range:** \_\_\_\_\_ **not available**

Heated exhaust oxygen sensor (bank 1, sensor 2).

**O2S13(V)**

**Range:** \_\_\_\_\_ **not available**

Heated exhaust oxygen sensor (bank 1, sensor 3).

**O2S21(V)**

**Range:** \_\_\_\_\_ **LEAN/RICH**

Heated exhaust oxygen sensor (bank 2, sensor 1).

**O2S21FM**

**Range:** \_\_\_\_\_ **YES FAULT/NO FAULT**

Heated exhaust oxygen sensor (bank 2, sensor 1).

**O2S22(V)**

**Range:** \_\_\_\_\_ **LEAN/RICH**

Heated exhaust gas oxygen sensor (bank 2, sensor 2).

**O2S23(V)**

**Range:** \_\_\_\_\_ **not available**

Heated exhaust gas oxygen sensor (bank 2, sensor 3).

**O2SEVAL\_DC\_MODE1**

Range: \_\_\_\_\_ YES/NO

Oxygen sensor monitor evaluated.

**OCTANE**

Range: \_\_\_\_\_ not available

Octane of the fuel.

**OCTANE ADJ**

Range: \_\_\_\_\_ ON/OFF

**OCT ADJ****OCTADJ**

Range: \_\_\_\_\_ YES/NO

Status of the octane adjust shorting bar, which is used to retard spark, and read as follows:

- ON when the shorting bar is removed
- OFF at all other times

---

**NOTE:**Removing the shorting bar retards spark about 3 degrees.

---

**ODS(rpm)**

Range: \_\_\_\_\_ not available

Overdrive drum speed sensor.

**OFMFLG**

Range: \_\_\_\_\_ YES FAULT/NO FAULT

Pressure control failure mode.

**OPEN/CLSD LOOP****LOOP**

Range: \_\_\_\_\_ OPEN/CLSD)

Indicate whether the PCM is operating the engine in open or closed loop and read as follows:

- OPEN during warm-up
- CLSD when the engine reaches normal operating temperature and the PCM responds to O2S voltage

Some failure conditions (many associated with trouble codes) will cause the PCM to return to open-loop operation. Additionally, some vehicles normally return to open-loop operation at idle. This occurs because the O2S cools off at idle, and the PCM returns to open loop because the signal is no longer reliable.

To restore closed-loop operation, accelerate and hold engine speed at a high idle to warm the sensor.

**OSFMFLG**

Range: \_\_\_\_\_ YES FAULT/NO FAULT

Output-shaft speed failure mode.

**OSS(rpm)**

Range: \_\_\_\_\_ not available

Output shaft speed.

---

<b>OSS_DIR</b>	<b>Range:</b> _____	<b>FORWARD/REVERSE</b>
Output shaft direction.		
<b>OSS_F</b>	<b>Range:</b> _____	<b>YES FAULT/NO FAULT</b>
EGR motor position desired.		
<b>OSS_FAULT</b>	<b>Range:</b> _____	<b>YES/NO</b>
Reads YES when a fault is detected in the output shaft speed (OSS circuit).		
<b>OSS=TSS(RPM)</b>	<b>Range:</b> _____	<b>0 to vehicle max</b>
PCM calculated RPM value for the transmission turbine shaft. The turbine speed sensor (TSS is a voltage-generating magnetic pickup. The processor converts the voltage signal of the TSS to an RPM value.		
<b>OTEMP_FMFLG</b>	<b>Range:</b> _____	<b>YES FAULT/NO FAULT</b>
Transmission over temperature.		
<b>OUT_CODE</b>		
<b>OUTCODE_BIT</b>		
<b>Range:</b> _____		<b>not available</b>
Indicate the outcode status.		
<b>OutShftSp(RPM)</b>	<b>Range:</b> _____	
PCM calculated RPM value for the transmission output shaft. The output shaft speed sensor (OSS is a voltage-generating magnetic pickup. The processor converts the voltage signal of the OSS to an RPM value.		
<b>OverdriveCancel</b>	<b>Range:</b> _____	<b>NOT DEPRESSED/DEPRESSED</b>
Overdrive cancel switch/Hold switch.		
<b>P/S PRESS(HIGH)</b>		
<b>PwrStrPrs</b>		
<b>Range:</b> _____		<b>YES/NO</b>
Status of the power steering pressure (PSP) switch, which closes under high pressure and read as follows:		
<ul style="list-style-type: none"> <li>• YES when the steering wheel is turned right or left to full lock</li> <li>• NO at all other times</li> </ul>		
If it does not change between NO and YES as the wheel turns through its full range, there may be a problem with the switch or other component in the power steering system.		
<b>PARK_INPT</b>	<b>Range:</b> _____	<b>PARK/NOT PARK</b>
Park position input.		

**ParkBrakeApply**

Range: \_\_\_\_\_ YES/NO

State of the parking brake applied switch on diesel powertrain control systems. The parking brake applied switch is located under the instrument panel.

ParkBrakeApply reads as follows:

- YES with the brake applied
- NO with the brake not applied

This switch disables speed control when it is applied and it also prevents operation of the power take off (PTO) when it is not applied.

**ParkNeuPos****PARK/NEU POS**

Range: \_\_\_\_\_ P-N—/-R-DS

Indicate whether an automatic transmission is in park or neutral or in one of the drive ranges.

These parameters read as follows:

- P-N— if the transmission is in either park or neutral
- -R-DL if the transmission is in any forward gear or reverse

The park/neutral switch is a grounding switch that is closed in park or neutral and open in any forward gear or reverse.

**PATS\_TYPE**

Range: \_\_\_\_\_ TIMED/CODED

Security access type.

**PATSENABL**

Range: \_\_\_\_\_ ENABLE/DISABLE

Vehicle enable status.

**PBA**

Range: \_\_\_\_\_ ON/OFF

Parking brake switch status.

**PCA**

Range: \_\_\_\_\_ not available

Pressure control solenoid A.

**PCA\_FAULT****PCD\_FAULT****PCE\_FAULT****PCF\_FAULT****PCG\_FAULT**

Range: \_\_\_\_\_ YES/NO

Read YES when a fault is detected in pressure control (PC solenoids A, D, E, F, and G, respectively).

**PCA\_FLT2**

Range: \_\_\_\_\_ NO FAULT/FAULT

Pressure control solenoid A.

**PCAA**

Range: \_\_\_\_\_ not available

Pressure control solenoid A.

---

<b>PCB</b>	<b>Range:</b> _____	<b>not available</b>
Pressure control solenoid B.		
<b>PCBA</b>	<b>Range:</b> _____	<b>not available</b>
Pressure control solenoid B.		
<b>PCBFLT</b>	<b>Range:</b> _____	<b>NO FAULT/FAULT</b>
Pressure control solenoid B fault state.		
<b>PCC</b>	<b>Range:</b> _____	<b>not available</b>
Pressure control solenoid C.		
<b>PCCA</b>	<b>Range:</b> _____	<b>not available</b>
Pressure control solenoid C.		
<b>PCC_FLT</b>	<b>Range:</b> _____	<b>NO FAULT/FAULT</b>
Shift solenoid pressure control C.		
<b>PCD</b>	<b>Range:</b> _____	<b>not available</b>
Shift solenoid pressure control D.		
<b>PCD_AMP</b>	<b>Range:</b> _____	<b>not available</b>
Shift solenoid pressure control D.		
<b>PCD_FLT</b>	<b>Range:</b> _____	<b>NO FAULT/FAULT</b>
SSPCD status.		
<b>PCE</b>	<b>Range:</b> _____	<b>not available</b>
Shift solenoid pressure control E.		
<b>PCE_FLT</b>	<b>Range:</b> _____	<b>NO FAULT/FAULT</b>
Shift solenoid pressure control E.		
<b>PCF</b>	<b>Range:</b> _____	<b>not available</b>
Line pressure control.		
<b>PCF_FLT</b>	<b>Range:</b> _____	<b>NO FAULT/FAULT</b>
LPC status.		
<b>PCG</b>	<b>Range:</b> _____	<b>not available</b>
Converter pressure control.		

---

<b>PCG_FLT</b>	<b>Range:</b> _____	<b>NO FAULT/FAULT</b>
Torque converter clutch status.		
<b>PCLowOSM</b>	<b>Range:</b> _____	<b>ON/OFF</b>
Low speed engine cooling fan monitor.		
<b>PERDEL1(%)</b>	<b>Range:</b> _____	<b>not available</b>
Percent delta for cylinder 1.		
<b>PERDEL2(%)</b>	<b>Range:</b> _____	<b>not available</b>
Percent delta for cylinder 2.		
<b>PERDEL3(%)</b>	<b>Range:</b> _____	<b>not available</b>
Percent delta for cylinder 3.		
<b>PERDEL4(%)</b>	<b>Range:</b> _____	<b>not available</b>
Percent delta for cylinder 4.		
<b>PERDEL5(%)</b>	<b>Range:</b> _____	<b>not available</b>
Percent delta for cylinder 5.		
<b>PERDEL6(%)</b>	<b>Range:</b> _____	<b>not available</b>
Percent delta for cylinder 6.		
<b>PERDEL7(%)</b>	<b>Range:</b> _____	<b>not available</b>
Percent delta for cylinder 7.		
<b>PERDEL8(%)</b>	<b>Range:</b> _____	<b>not available</b>
Percent delta for cylinder 8.		
<b>PEVAP_TMP(°C/°F)(V)</b>	<b>Range:</b> _____	<b>not available</b>
Post evaporator temperature sensor input.		

---

**PFE(V)**  
Range: \_\_\_\_\_ **0.25 to 4.75 V**

Pressure feedback EGR (PFE sensor signal voltage, which determines exhaust system pressure. The PCM uses this signal to compute optimum EGR flow.

PFE systems control EGR flow rate by monitoring pressure drop across a remotely located sharp-edged orifice. Typically, sensor output should be as described in Table 13-6.

**Table 13-6 PFE sensor outputs**

inHg	kPa	VOLTS
3.70	12.5	4.75
2.79	9.42	4.38
1.85	6.25	4.0
0.94	3.17	3.82
0	0	3.25
-5.03	-17.0	1.22
-7.40	-25.0	0.25

The PFE pressure transducer is a feedback device. Pressure is varied by valve modulation. The vacuum output of the EGR vacuum regulator (EVR) solenoid modulates the valve. With PFE, the EGR valve serves as a pressure regulator, rather than a metering device.

**PinInputLevel**  
Range: \_\_\_\_\_ **ON/OFF**

Profile ignition pick-up.

**PIP**  
Range: \_\_\_\_\_ **YES/NO**

Status of the profile ignition pickup (PIP) and reads as follows:

- YES when the PIP is switching between low and high voltage
- NO when there are no PIP signal transitions

**PNP**  
Range: \_\_\_\_\_ **NEUTRAL/DRIVE**

Neutral switch circuit.

**PNP\_ONLY**  
Range: \_\_\_\_\_ **NEUTRAL/DRIVE**

Park/neutral position switch.

**PS1**  
Range: \_\_\_\_\_ **OPEN/CLOSED**

Pressure switch 1.

**PSP**  
Range: \_\_\_\_\_ **HIGH/LOW**

**PSP(V)**

**PSP(KPA/PSI)**

Range: \_\_\_\_\_ **not available**

Power steering pressure switch status.

<b>PSR</b>	<b>Range:</b> _____	<b>ON/OFF</b>
	Power sustained relay commanded.	
<b>PTO</b>	<b>Range:</b> _____	<b>ON/OFF</b>
	Power take off status.	
<b>PwTakeOff</b>	<b>Range:</b> _____	<b>ON/OFF</b>
	Status of the driver-operated power take off (PTO) switch on diesel powertrain control systems.	
<b>RCAM</b>	<b>Range:</b> _____	<b>-15° to +45°</b>
	Actual position of the camshaft in relation to the crankshaft in degrees of rotation and reads as follows:	
	• Near -15° with the engine running at a warm idle, camshaft fully advanced with no EGR	
	• Near 40° with a warm engine and the vehicle operating at a steady cruise speed	
<b>RCL_F</b>	<b>Range:</b> _____	<b>YES FAULT/NO FAULT</b>
	Cooling fan state.	
<b>RCL_FAULT</b>	<b>Range:</b> _____	<b>YES/NO</b>
	Reads YES when a fault is detected in the reverse control lamp (RCS circuit).	
<b>RESUME</b>	<b>Range:</b> _____	<b>ON/OFF</b>
	Speed control actuator switch RESUME.	
<b>REV_SW</b>	<b>Range:</b> _____	<b>ON/OFF</b>
	Reverse switch.	
<b>RPM</b>	<b>Range:</b> _____	<b>0 to engine max</b>
	Engine speed and is always shown at the left of the top line on the display. RPM is internally computed by the PCM based on ignition reference pulses or a crankshaft sensor.	
<b>RPMDES</b>	<b>Range:</b> _____	<b>0 to engine max</b>
	Desired engine speed as calculated by the PCM for base idle. This reading should always be close to actual idle RPM.	
<b>SBB_SS2</b>	<b>Range:</b> _____	<b>ON/OFF</b>
	Shift solenoid 2.	
<b>SC_OFF</b>	<b>Range:</b> _____	<b>ON/OFF</b>
	Speed control actuator switch off status.	

---

**SC\_ON**  
Range: \_\_\_\_\_ **ON/OFF**

Speed control actuator switch on status

**SCBC**  
Range: \_\_\_\_\_ **ON/OFF**

Super charger bypass control.

**SCBCF**  
Range: \_\_\_\_\_ **YES FAULT/NO FAULT**

Super charger bypass control fault.

**SC VAC SW**  
**SC VENT SW**  
Range: \_\_\_\_\_ **ON/OFF**

PCM output commands to the speed control (SC vacuum and vent solenoids, which control the speed control servo. The SC VAC SW and SC VENT SW readings have the following relationships with throttle position control:

**Table 13-7 S/C VAC SW and S/C VENT SW readings and throttle position**

SC VAC SW	SC VENT SW	THROTTLE
ON	OFF	Accelerate
OFF	ON	Decelerate
OFF	OFF	Steady

**SCCS**  
Range: \_\_\_\_\_ **see description**

Position of the driver-operated speed control command switch (SCCS on the steering wheel. The SCCS parameter displays several range states according to which SCCS button is pressed:

- OFF
- COAST
- ACCEL
- RESUME
- ON

Two hyphens (—), the default range state, indicates that none of the speed control switch buttons are pressed.

**SCCS(V)**  
Range: \_\_\_\_\_ **0 to 10.00**

Speed control command switch (SCCS voltage).

**SCCS\_CANCEL**  
Range: \_\_\_\_\_ **ON/OFF**

Speed control cancel switch status.

**SCCS\_NULL**  
Range: \_\_\_\_\_ **ON/OFF**

Speed control no switch input status.

**SCCS\_OFF\_PID**

Range: \_\_\_\_\_ ON/OFF

Speed control actuator switch off status.

**SCCS\_ON\_PID**

Range: \_\_\_\_\_ ON/OFF

Speed control actuator switch on status.

**SCCS\_RESUME**

Range: \_\_\_\_\_ ON/OFF

Speed control actuator switch RESUME status.

**SCCS\_TAP\_DN**

Range: \_\_\_\_\_ ON/OFF

Speed control actuator switch coast status.

**SCCS\_TAP\_UP**

Range: \_\_\_\_\_ ON/OFF

Speed pressure actuator switch SET/ACCEL status.

**SCICP**

Range: \_\_\_\_\_ ON/OFF

Super charger intercooler pump.

**SCICPF**

Range: \_\_\_\_\_ YES FAULT/NO FAULT

Supercharger intercooler pump fault.

**SCP\_PARK\_BRAKE**

Range: \_\_\_\_\_ ON/OFF

Parking brake applied status.

**SEC\_ACCEs**

Range: \_\_\_\_\_ Denied/In Progress/GrantED

Vehicle security access status.

**SecAIR mon rdy**

Range: \_\_\_\_\_ YES/NO

Secondary air monitor status and reads YES when the monitor successfully completed.

**SERV\_MOD**

Range: \_\_\_\_\_ YES/NO

PATS service module status.

**SET\_ACL**

Range: \_\_\_\_\_ ON/OFF

Speed control actuator switch SET/ACCEL.

**SFT1**

Range: \_\_\_\_\_ not available

Short term fuel trim 1.

**SFT2**

Range: \_\_\_\_\_ not available

Short term fuel trim 2.

---

**SFTRIM 1(%)**  
**SFTRIM 2(%)**  
**Range:** \_\_\_\_\_ **-25% to +35%**

The short-term fuel (ST FUES numbers are short-term fuel-metering corrections on a fuel-injected engine. It indicates whether the PCM is commanding a rich or a lean mixture.

The SFTRIM parameter ranges from -25% to +35% with 000% as the midpoint:

- A number above zero percent indicates the PCM has commanded a short-term rich mixture correction.
- A number below zero percent indicates the PCM is commanding a short-term lean mixture correction.

The ST FUEL number leads the long-term fuel (LT FUES number. When a pattern or trend of short-term corrections to fuel-metering occur, long-term fuel (LT FUES responds with a similar correction.

Compare ST FUEL numbers to injector on-time. Numbers above zero indicate increased on-time, below zero indicates decreased on-time. The ST FUEL corrections operate only in closed loop. In open loop, it goes to a fixed value.

**ShiftSol1**  
**ShiftSol2**  
**ShiftSol3**  
**Range:** \_\_\_\_\_ **ON/OFF**

PCM commands for the 1, 2, and 3 shift solenoids and read ON when the PCM has commanded the shift solenoid to energize.

**ShiftSol1A**  
**ShiftSol2A**  
**ShiftSol3A**  
**Range:** \_\_\_\_\_ **ON/OFF**

Shift solenoid 1, 2, and 3 feedback status to the PCM.

When the solenoid circuits and PCM function properly, the command parameter, such as ShiftSol1, and the feedback parameter, such as ShiftSol1A, should both display ON or OFF.

**ShiftSol1Fault**  
**ShiftSol2Fault**  
**ShiftSol3Fault**  
**Range:** \_\_\_\_\_ **YES/NO**

Read YES when a shift solenoid circuit fault is present.

**SHFT\_TYP**  
**Range:** \_\_\_\_\_ **not available**

Indicates the shift type.

**SHRTFT1(%)**  
**Range:** \_\_\_\_\_ **not available**

Short term fuel trim 1.

**SHRTFT2(%)**  
**Range:** \_\_\_\_\_ **not available**

Short term fuel trim 2.

**SLIP\_DES\_SCP**

Range: \_\_\_\_\_ not available

Torque converter slip desired in rpm.

**SPAREKEY\_PCM**

Range: \_\_\_\_\_ ENABLED/DISABLED

Spare key programming status.

**SPARK\_ACT**

Range: \_\_\_\_\_ not available

Spark advance actual.

**SPARKADV(°)**

Range: \_\_\_\_\_ -54 to +54 degrees

Amount of spark advance in degrees. An advance of more than 54 degrees shows as a negative value; this is normal.

**SPARK ADV(°)****SPRKADV(°)****IGN ADVANCE(°)**

Range: \_\_\_\_\_ -90° to +90°

Total spark advance or retard, including the base timing, that the PCM is commanding.

**SPARKDUR1****SPARKDUR2****SPARKDUR3****SPARKDUR4****SPARKDUR5****SPARKDUR6****SPARKDUR7****SPARKDUR8**

Range: \_\_\_\_\_ not available

Spark duration of the indicated cylinder.

**SRC\_CAN**

Range: \_\_\_\_\_ ENABLE/DISABLE

Starter motor relay enable status.

**SSA\_AMP**

Range: \_\_\_\_\_ not available

Shift solenoid pressure control A.

**SSA\_SS1**

Range: \_\_\_\_\_ ON/OFF

Shift solenoid 1.

**SSA\_SS1\_FLT**

Range: \_\_\_\_\_ YES FAULT/NO FAULT

Shift solenoid 1 status.

**SSB\_AMP**

Range: \_\_\_\_\_ not available

Soft solenoid pressure control B.

---

<b>SSB_SS2_FLT</b>	<b>Range:</b> _____	<b>YES FAULT/NO FAULT</b>
Shift solenoid 2 status.		
<b>SSC_SS3</b>	<b>Range:</b> _____	<b>ON/OFF</b>
Shift solenoid 3.		
<b>SSC_SS3_FLT</b>	<b>Range:</b> _____	<b>YES FAULT/NO FAULT</b>
Shift solenoid 3 status.		
<b>SSC(%)</b>	<b>Range:</b> _____	<b>not available</b>
Shift solenoid pressure control C.		
<b>SCC_AMP</b>	<b>Range:</b> _____	<b>not available</b>
Shift solenoid pressure control C.		
<b>SSD(%)</b>	<b>Range:</b> _____	<b>not available</b>
Shift solenoid pressure control D.		
<b>SSD_SS4</b>	<b>Range:</b> _____	<b>ON/OFF</b>
Shift solenoid 4.		
<b>SSE(%)</b>	<b>Range:</b> _____	<b>not available</b>
Shift solenoid pressure control E.		
<b>SSPCA</b>	<b>Range:</b> _____	<b>not available</b>
Shift solenoid pressure control A.		
<b>SSPCA_FLT</b>	<b>Range:</b> _____	<b>NO FAULT/FAULT</b>
SSPCA status.		
<b>SSPCB</b>	<b>Range:</b> _____	<b>not available</b>
Shift solenoid pressure control B.		
<b>SSPCB_FLT</b>	<b>Range:</b> _____	<b>YES FAULT/NO FAULT</b>
SSPCB status.		
<b>SSPCC</b>	<b>Range:</b> _____	<b>not available</b>
Shift solenoid pressure control C in KPA/PSI.		
<b>SSPCC_FLT</b>	<b>Range:</b> _____	<b>YES FAULT/NO FAULT</b>
SSPCC status.		

**STATUS B1****Range:** \_\_\_\_\_ **see description**

Operating status of fuel bank 1 and reads as follows:

- CL (closed-loop)
- OL (open-loop)
- OL DRIVE
- OL FAULT
- CL FAULT

**ST TRIM B1(%)****ST TRIM B2(%)****Range:** \_\_\_\_\_ **-100% to +100%**

The short-term fuel (ST TRIM) numbers are short-term fuel-metering corrections for a fuel-injected engine. It indicates whether the PCM is commanding a rich or a lean mixture.

Similar to long-term fuel trim ("LT TRIM B1(%)" on page 361), the ST TRIM parameter ranges from -100% to +100% with 000% as the midpoint:

- A number above zero percent indicates the PCM has commanded a short-term rich mixture correction.
- A number below zero percent indicates the PCM is commanding a short-term lean mixture correction.

The ST TRIM number leads the long-term fuel (LT TRIM) number. When a pattern or trend of short-term corrections to fuel-metering occur, long-term fuel (LT TRIM) responds with a similar correction.

Compare ST TRIM numbers to injector on-time. Numbers above zero indicate increased on-time, below zero indicates decreased on-time. The ST TRIM corrections operate only in closed loop. In open loop, it goes to a fixed value.

**SYNC\_DI****Range:** \_\_\_\_\_ **YES/NO**

Indicates if the CMP and CKP are synchronized.

**TC\_SLIP****Range:** \_\_\_\_\_ **not available**

Torque converter slip actual.

**TCC****Range:** \_\_\_\_\_ **Engaged/Modulated/OFF**

Torque converter clutch (modulatED).

**TCC(%)****Range:** \_\_\_\_\_ **0 to 100%**

Pulse-width-modulated (PWM) signal to the torque converter clutch (TCC) solenoid and reads as follows:

- 0% with exhaust solenoid (TCC solenoid) closed, TCC not applied
- 100% with exhaust solenoid fully open, TCC applied

**TCC\_FLT****Range:** \_\_\_\_\_ **YES FAULT/NO FAULT**

Torque converter clutch fault.

<b>TCC_OSC</b>	<b>Range:</b> _____	<b>not available</b>
Output state control of the torque converter.		
<b>TCCA</b>	<b>Range:</b> _____	<b>ON/OFF</b>
Torque converter clutch actual (TCCA) feedback signal to the PCM indicating the status of the torque converter clutch.		
Normally, the TCC SOL and TCCA parameters should both read ON or OFF simultaneously.		
<b>TCCA(V)</b>	<b>Range:</b> _____	<b>not available</b>
Voltage signal to the torque converter clutch (TCC) solenoid. Information on this parameter is not available at this time.		
<b>TCCF</b>	<b>Range:</b> _____	<b>YES FAULT/NO FAULT</b>
Torque converter clutch fault status.		
<b>TCCFault</b>	<b>Range:</b> _____	<b>YES/NO</b>
Presence of a PCM detected fault in the torque converter clutch circuit and reads YES when a fault is present.		
<b>tccmact (RPM)</b>	<b>Range:</b> _____	<b>0 to vehicle max</b>
<b>TCCMACT(RPM)</b>		
PCM calculated value of torque converter slippage. The value is derived by subtracting the turbine speed from the engine RPM.		
TCCMACT(RPM) reads less than 50 RPM when TCC(%), TCC SOL(%) reads 95% or greater or when TCC SOL reads ON.		
<b>TCC SOL</b>	<b>Range:</b> _____	<b>ON/OFF</b>
PCM command status for the torque converter clutch. When the system functions properly, ON means the torque converter clutch solenoid is energized to lock the converter.		
<b>TCC SOL(%)</b>	<b>Range:</b> _____	<b>0 to 100%</b>
Pulse-width-modulated (PWM) signal to the torque converter clutch (TCC) solenoid and reads as follows:		
<ul style="list-style-type: none"> <li>• 0% with exhaust solenoid (TCC solenoid) closed, TCC not applied</li> <li>• 100% with exhaust solenoid fully open, TCC applied</li> </ul>		
<b>TCIL</b>	<b>Range:</b> _____	<b>ON/OFF</b>
Transmission Control Indicator Lamp (TCIS) command status. TCIL reads ON when the TCIL in the dash or shifter should be on.		
<b>TCILFault</b>	<b>Range:</b> _____	<b>YES/NO</b>
<b>TCIL_FAULT</b>		
<b>TCIL_FLT</b>		
Indicate if a fault has occurred in the Transmission Control Indicator Lamp circuit.		

<b>TCS</b>	<b>Range:</b> _____	<b>DEPRESSED/NOT DEPRESSED</b>
		Overdrive cancel switch/hold switch.
<b>THEFT_LMP</b>	<b>Range:</b> _____	<b>YES FAULT/NO FAULT</b>
		Antitheft indicator lamp control.
<b>TIRESIZE</b>	<b>Range:</b> _____	<b>not available</b>
		Tire size.
<b>TFT(V)(°C/°F)</b>	<b>Range:</b> _____	<b>not available</b>
		Transmission fluid temperature.
<b>TFT=TOT(V)</b>	<b>Range:</b> _____	<b>0 to 5.10 V</b>
		Transmission fluid temperature (TFT), which is also referred to by Ford as the transmission oil temperature (TOT, as voltage).
		The TFT sensor is a thermistor that changes resistance in response to temperature changes. Resistance decreases as temperature increases to provide a variable voltage signal to the PCM.
		TFT=TOT(V) typically reads as follows:
	<ul style="list-style-type: none"> <li>• 0.60 V at 194°F (90°C)</li> <li>• 3.88 V at 32°F (0°C)</li> </ul>	
<b>THTRC(%)</b>	<b>Range:</b> _____	<b>not available</b>
		Thermostat heater control.
<b>THTRCF</b>	<b>Range:</b> _____	<b>YES FAULT/NO FAULT</b>
		Thermostat heater control fault.
<b>TORQUE(lb·fT)</b>	<b>Range:</b> _____	<b>0 to 999</b>
		Engine torque as calculated by the PCM.
<b>TORQUE</b>	<b>Range:</b> _____	<b>not available</b>
		PCM calculated engine torque in Nm or ft-lb on diesel powertrain control systems. The torque reading indicates how much load is placed on the engine.
<b>TorqConvCl</b>	<b>Range:</b> _____	<b>ON/OFF</b>
		Output used by the PCM to control the converter clutch by way of a solenoid. ON or OFF displays as the PCM commands the solenoid on or off.
<b>TOTF</b>	<b>Range:</b> _____	<b>YES FAULT/NO FAULT</b>
		Transmission fluid temperature status.

---

<b>TOWHAUL</b>	<b>Range:</b> _____	<b>ON/OFF</b>
Tow haul switch.		
<b>TP(V)</b>	<b>Range:</b> _____	<b>0.0 to 5.0 V</b>
Voltage signal from the throttle position (TP) sensor to the PCM.		
<b>TP FAULT</b>	<b>Range:</b> _____	<b>YES FAULT/NO FAULT</b>
Throttle position sensor status.		
<b>TP MODE</b>	<b>Range:</b> _____	<b>PT/WOT/CT</b>
Position of the accelerator pedal based on accelerator position sensor readings on diesel powertrain systems.		
<b>TP=TPS(V)</b>	<b>Range:</b> _____	<b>0 to 5.1 V</b>
Throttle position (TP) sensor voltage signal, which is in proportion to the throttle position. The TP signal allows the PCM to determine throttle opening: low voltage at closed throttle and high voltage at wide open throttle.		
TP=TPS(V) reads as follows:		
• About 0.5 V at idle		
• 4.5 V at WOT		
<b>TP=TPS(%)</b>	<b>Range:</b> _____	<b>(range 0 to 100%)</b>
Throttle position (TP) as calculated by the PCM based on TP sensor voltage on models with an autoranging TP sensor. The PCM resets the 0 to 100% range in relation to TP sensor voltage as it senses new minimum and maximum voltages.		
<b>TP1</b>	<b>Range:</b> _____	<b>not available</b>
Throttle position sensor 1.		
<b>TP2</b>	<b>Range:</b> _____	<b>not available</b>
Throttle position sensor 2.		
<b>TP MODE</b>		
<b>ThrPosMODE</b>		
<b>Range:</b> _____		<b>see description</b>
Throttle position (TP) as calculated by the PCM based on the TP sensor signal and read as follows:		
• C/T - closed throttle at idle and during deceleration		
• P/T - part throttle at cruise or during moderate acceleration		
• WOT - wide open throttle at de-choke on crank, A/C cutout, or during maximum acceleration		

**TPCT(V)****TPREL(V)****Range:** \_\_\_\_\_ **not available**

Throttle position closed throttle (TPCT indicates the most recent throttle position (TP) sensor voltage reading at closed throttle. This parameter updates each time the throttle is fully closed.

**TPF****Range:** \_\_\_\_\_ **YES/NO**

Throttle position sensor status.

**TQ\_CNTL****Range:** \_\_\_\_\_ **not available**

Torque fuel/spark limiting status.

**TR****Range:** \_\_\_\_\_ **Man1/Man2/D/OD/N/R/P**

Transmission range.

**TR\_DC(%)****Range:** \_\_\_\_\_ **not available**

Transmission range.

**TR\_FAULT****Range:** \_\_\_\_\_ **YES/NO**

Reads YES when a fault is detected in the Transmission Range (TR) circuit.

**TR\_FREQ(Hz)****Range:** \_\_\_\_\_ **not available**

Transmission range.

**TR1****TR2****TR3****TR4****Range:** \_\_\_\_\_ **OPEN/CLOSED**

Digital transmission range switch numbered.

**TR3\_MODE****Range:** \_\_\_\_\_ **OPEN/CLOSED**

Digital transmission range switch 3.

**TRAC\_ACT****Range:** \_\_\_\_\_ **ON/OFF**

Traction control system modulating status.

**TRAN\_OT\_FAULT****Range:** \_\_\_\_\_ **YES/NO**

Reads YES when a fault is detected in the trans over temp circuit.

**TRANSMIT****Range:** \_\_\_\_\_ **ON/OFF**

Anti-theft RF enabled and transmit command status.

---

**TransRange\_D****Range:** \_\_\_\_\_ **see description**

Four possible switch states of the transmission range switches TR1 through TR4 and reads as follows:

- 0 indicates the switch is closed
- 1 indicates the switch is open

Typical readings are as follows

- PARK POSITION = 0000
- Between P & R = 0100
- REVERSE POSITION = 1100
- Between R & N = 0100
- NEUTRAL POSITION = 0110
- Between N & O/D = 1100
- O/D POSITION = 1111
- Between O/D & 2 = 1011
- MANUAL 2 POSITION = 1001
- Between 1 & 2 = 1011
- MANUAL 1 POSITION = 0011

**TRFM****Range:** \_\_\_\_\_ **YES FAULT/NO FAULT**

Transmission range status.

**TRIM B1-S1(%)****TRIM B2-S1(%)****Range:** \_\_\_\_\_ **-55% to +55%**

The trim bank x – sensor x (TRIM Bx-Sx numbers are short-term fuel-metering corrections for a fuel-injected engine. It indicates whether the PCM is commanding a rich or a lean mixture.

The TRIM parameters range from -45% to +35% with 000% as the midpoint:

- A number above zero percent indicates the PCM has commanded a short-term rich mixture correction.
- A number below zero percent indicates the PCM is commanding a short-term lean mixture correction.

The TRIM Bx-Sx number leads the long-term fuel (LT TRIM) number. When a pattern or trend of short-term corrections to fuel-metering occur, long-term fuel (LT TRIM) responds with a similar correction.

Compare ST TRIM numbers to injector on-time. Numbers above zero indicate increased on-time, below zero indicates decreased on-time. The ST TRIM corrections operate only in closed loop. In open loop, it goes to a fixed value.

TRIM B1-S1 should read the same as ST TRIM B1. TRIM B2-S1 should read the same as ST TRIM B2.

**TRIP****Range:** \_\_\_\_\_ **YES/NO**

Indicates whether an On-Board diagnostic trip has occurred. A trip is a complete ignition on, engine run, ignition off cycle that tests all components and systems on an OBD-II vehicle.

**TRIP\_CNT****Range:** \_\_\_\_\_ **not available**

Number of on board diagnostic trips completed.

**TRIP\_CountT****Range:** \_\_\_\_\_ **0 to 255**

Number of completed OBD-II drive cycles completed since the last DTC P1000 monitor readiness set.

**TRS1(V)****Range:** \_\_\_\_\_ **not available**

Transmission range selector 1.

**TRS2(V)****Range:** \_\_\_\_\_ **not available**

Transmission range selector 2.

**TRS3(V)****Range:** \_\_\_\_\_ **not available**

Transmission range selector 3.

**TR\_V****Range:** \_\_\_\_\_ **see description**Voltage at processor pin 64 (signal return). Voltage for a digital transmission range (DTR) should match the examples in Table 13-8 below  $\pm 0.3$  V.**Table 13-8 Sample TR\_V readings**

<b>TR_V READING</b>	<b>GEAR</b>
0.0 V	PARK
1.5 V	REVERSE
1.5 V	NEUTRAL
1.5 V	ODRIVE
0.0 V	MAN2
0.0 V	MAN1

**TrnCtrlIndLamp****Range:** \_\_\_\_\_ **ON/OFF**

Displays ON and an indicator lamp is lit when "Overdrive Cancel" is requested.

**TrnCtrlSw****TCSLAMP** **Range:** \_\_\_\_\_ **ON/OFF**

Condition of the transmission control switch (TCS) and read as follows:

- OFF = the switch is open
- ON = the driver requests overdrive cancellation and the switch closes

**TrnFluidTmp(V)****Range:** \_\_\_\_\_ **0.0 to 5.0 V**

Voltage signal from the transmission fluid temperature (TFT) sensor to the PCM.

A low voltage reading indicates a high fluid temperature, while a high voltage reading indicates a low fluid temperature.

---

**TrnRange**  
Range: \_\_\_\_\_ **0.0 to 5.0 V**

Voltage at PCM pin 64 to signal return, or ground. This voltage indicates the position of the gear selector lever.

Each position has a typical range, as follows:

- L = 0.29 to 0.79 V
- D2 = 1.29 to 1.53 V
- OD = 1.88 to 2.29 V
- N = 2.53 to 3.04 V
- R = 3.43 to 3.78 V
- P = 4.30 to 4.73 V

**TRO\_NFAULT**

Range: \_\_\_\_\_ **YES/NO**

**TRO\_N\_F**

Range: \_\_\_\_\_ **YES/NO**

Reads YES when a fault is detected in the Neutral Output circuit.

**TRO\_P\_F**

Range: \_\_\_\_\_ **YES/NO**

Reads YES when a fault is detected in the Park Output circuit.

**TR=GEAR**

Range: \_\_\_\_\_ **see description**

Displays the driver demanded gear selection from the transmission range sensor and reads as follows:

- MAN1
- MAN2
- DRIVE
- ODRIVE
- REVERSE
- PARK/NEUTRAL

**TSFMFLG**

Range: \_\_\_\_\_ **YES FAULT/NO FAULT**

Turbine speed sensor failure mode.

**TSLIPRAT**

Range: \_\_\_\_\_ **not available**

Transmission slip ratio.

**TSS(rpm)**

Range: \_\_\_\_\_ **not available**

Turbine shaft speed.

**TSS\_F**

Range: \_\_\_\_\_ **YES FAULT/NO FAULT**

Turbine shaft speed reliable.

**TSS\_FAULT**

Range: \_\_\_\_\_ **YES/NO**

Reads YES when a fault is detected in the Turbine Shaft Speed (TSS circuit).

<b>TurbSpdS(RPM)</b>	<b>Range:</b> _____	<b>0 to 8192</b>
Speed of the transmission turbine shaft.		
<b>UNLIMITED_KEY</b>	<b>Range:</b> _____	<b>ENABLED/DISABLED</b>
Unlimited key mode status.		
<b>V_4X4L</b>	<b>Range:</b> _____	<b>PRESENT/NOT PRESENT</b>
The 4x4 low range input.		
<b>V_OCTADJ</b>	<b>Range:</b> _____	<b>ACTIVE/INACTIVE</b>
The Octane Adjust/Spark Retard.		
<b>V_TCASE</b>	<b>Range:</b> _____	<b>PRESENT/NOT PRESENT</b>
Manual shift on the fly.		
<b>VBAT(V)</b>		
<b>VBATT_PCM(V)</b>	<b>Range:</b> _____	<b>not available</b>
This parameter indicates the battery positive voltage.		
<b>VCT 1_FAULT</b>		
<b>VCT 2_FAULT</b>	<b>Range:</b> _____	<b>YES/NO</b>
Read YES if a fault has occurred in the VCT circuit.		
<b>VCT1</b>		
<b>VCT2</b>	<b>Range:</b> _____	<b>7.5 to B+</b>
Variable valve timing.		
<b>VCT1F</b>	<b>Range:</b> _____	<b>YES FAULT/NO FAULT</b>
Variable cam timing status.		
<b>VCT2F</b>	<b>Range:</b> _____	<b>YES FAULT/NO FAULT</b>
Variable cam timing 2 status.		
<b>VCTA</b>	<b>Range:</b> _____	<b>ON/OFF</b>
Variable cam timing solenoid actual state.		
<b>VCTADV</b>	<b>Range:</b> _____	<b>not available</b>
Variable cam timing actual advance status.		
<b>VCTADV2</b>	<b>Range:</b> _____	<b>not available</b>
Variable cam timing 2 actual advance.		

---

<b>VCTADVERR</b>	<b>Range:</b> _____	<b>not available</b>
VCT advance error status.		
<b>VCTADVERR2</b>	<b>Range:</b> _____	<b>not available</b>
Variable cam timing 2 advance error.		
<b>VCTDC(%)</b>	<b>Range:</b> _____	<b>not available</b>
Variable camshaft timing duty cycle.		
<b>VCTDC2(%)</b>	<b>Range:</b> _____	<b>not available</b>
Variable cam timing 2 duty cycle.		
<b>VCTSYS</b>	<b>Range:</b> _____	<b>OPEN/CLOSED LOOP</b>
VCT system status.		
<b>VehSpdSensr</b>	<b>Range:</b> _____	<b>0 to 255</b>
Vehicle speed in miles per hour or kilometers per hour.		
<b>VFC(%)</b>	<b>Range:</b> _____	<b>not available</b>
Fan speed monitor.		
<b>VFCDC(%)</b>	<b>Range:</b> _____	<b>not available</b>
Variable fan duty cycle.		
<b>VFCF</b>	<b>Range:</b> _____	<b>YES FAULT/NO FAULT</b>
Cooling fan driver fault.		
<b>VFDES</b>	<b>Range:</b> _____	<b>0 to 255 mm<sup>3</sup></b>
Internal PCM calculation of the volume of fuel desired (VFDES per stroke from the injection pump to operate the engine for current speed, load, and temperature conditions on diesel powertrain systems.		
Readings are in cubic millimeters (mm <sup>3</sup> ) and 10–15 mm <sup>3</sup> at idle.		
<b>VGTDC(%)</b>	<b>Range:</b> _____	<b>not available</b>
Variable geometry turbocharger.		
<b>VGT_F</b>	<b>Range:</b> _____	<b>YES FAULT/NOFAULT</b>
EGR motor position desired.		
<b>VGT_FAULT</b>	<b>Range:</b> _____	<b>YES/NO</b>
reads YES if a fault is detected in the variable geometry turbo (VGT circuit.		

**VPoWeR**  
**Range:** \_\_\_\_\_ **0.0 to 24.0 V**

Vehicle battery voltage.

Some vehicles may normally read lower (8 V or higher (16 V than expected. Verify system voltage with a DVOM.

**VPWR(V)**  
**Range:** \_\_\_\_\_ **not available**

Module supply voltage.

**VPWR=BATT(V)**  
**VPoWeR(V)**  
**Range:** \_\_\_\_\_ **0 to 25.5 V**

Vehicle battery voltage. The powertrain control system has no specific sensor to measure battery voltage, but some PCMs calculate this parameter from a sensing circuit on the supply voltage circuit.

The reading should be close to normal charging system regulated voltage, or about 13.5 to 14.5 V, at idle. Check against actual voltage measured at the battery or alternator.

This parameter is principally for PCM self-diagnostics. Some PCM functions are modified if voltage is out of range. For example, if voltage drops below a minimum, the PCM may try to recharge the battery by running the engine at a higher idle. This may affect the idle control, fuel metering, and ignition timing parameters.

**VREF(V)**  
**Range:** \_\_\_\_\_ **0 to 5.12 V**

Reference voltage that system sensors operate on for some vehicles. The PCM monitors this voltage and provides the parameter.

Nominal reference voltage is 5.0 V. Depending on system calibration and charging system voltage, readings may vary a few tenths of a volt. Some models normally read about 6.5 V. Verify voltage with a DVOM.

**VS\_SET**  
**Range:** \_\_\_\_\_ **see description**

Set speed of the speed control system.

**VS\_SRC**  
**Range:** \_\_\_\_\_ **not available**

Transfer case speed sensor.

**VSS(MPH)**  
**VSS(KPH)**  
**Range:** \_\_\_\_\_ **0 to vehicle max**

VSS is the measurement provided by the vehicle speed sensor (VSS) pulses to the PCM. The PCM calculates the actual speed. The PCM uses vehicle speed to control fuel injection, ignition timing, and transmission and trans-axle shift timing.

**VSS\_FAULT**  
**Range:** \_\_\_\_\_ **YES FAULT/NO FAULT**

Vehicle speed sensor reliable.

**VSFMFLG**  
**Range:** \_\_\_\_\_ **YES FAULT/NO FAULT**

Vehicle speed sensor signal status.

---

<b>WAC</b>	<b>Range:</b> _____	<b>ON/OFF</b>
Air conditioning clutch at wide open throttle.		
<b>WAC_FLT</b>	<b>Range:</b> _____	<b>YES FAULT/NO FAULT</b>
Wide open throttle A/C cutoff fault.		
<b>WACA</b>	<b>Range:</b> _____	<b>ON/OFF</b>
Wide open throttle air conditioning cutoff fault.		
<b>WAC=WOT A/C</b>	<b>Range:</b> _____	<b>ON/OFF</b>
Indicates whether the PCM is preventing the A/C system from operating due to undesirable engine conditions. These include operation during engine cranking and wide open throttle.		
On almost all vehicles, WAC=WOT A/C reads as follows:		
<ul style="list-style-type: none"> <li>• OFF when the PCM senses undesirable conditions and is currently preventing the A/C clutch from energizing</li> <li>• ON when the PCM is allowing the A/C clutch to energize</li> </ul>		
<b>WACFault</b>	<b>Range:</b> _____	<b>YES/NO</b>
Reads YES when the PCM has set a wide open throttle A/C cutout fault.		
<b>WARM_NOMIL</b>	<b>Range:</b> _____	<b>0 to vehicle max</b>
Number of warm-ups since the DTCs were cleared.		
<b>WASTEGATE</b>	<b>Range:</b> _____	<b>0 to 100%</b>
PCM input that indicates the position of the wastegate as a percentage on diesel powertrain control systems.		
<b>WFS</b>	<b>Range:</b> _____	<b>YES/NO</b>
Indicates the water in fuel.		
<b>WotA/Ccutoff</b>	<b>Range:</b> _____	<b>ON/OFF</b>
Reads ON when the wide open throttle (WOT A/C cutoff has been activated and the A/C has been switched off.		

## Airbag Parameters

**ABBRGR****Bracket( $\Omega$ )****Range:** \_\_\_\_\_ **0 to 25.5  $\Omega$** 

Resistance of the airbag mounting bracket to chassis ground.

**CRaSHSN1( $\Omega$ )****CRSHSN1( $\Omega$ )****CRaSHSN2( $\Omega$ )****CRSHSN2( $\Omega$ )****Range:** \_\_\_\_\_ **0 to 25.5  $\Omega$** 

Resistance of the crash sensors.

- CRaSHSN1 = the resistance of sensor number 1

- CRaSHSN2 = the resistance of sensor number 2

**D\_Airbag( $\Omega$ )****D\_AirBAG2( $\Omega$ )****D\_AirBAGLoop2( $\Omega$ )****P\_Airbag( $\Omega$ )****P\_AirBAG2( $\Omega$ )****P\_AirBAGLoop2( $\Omega$ )****Range:** \_\_\_\_\_ **0 to 25.5  $\Omega$** 

Resistance between the two contacts of the airbag.

- “D” = driver side airbag
- “P” = passenger side airbag

**D\_Preten( $\Omega$ )****D\_PRETNR( $\Omega$ )****P\_Preten( $\Omega$ )****P\_PRETNR( $\Omega$ )****Range:** \_\_\_\_\_ **0 to 25.5  $\Omega$** 

Resistance in the shoulder belt pre-tensioner circuit.

- D\_Preten refers to the driver side pre-tensioner.
- P\_Preten refers to the passenger side pre-tensioner.

**DSBELTR****PSBELTR****Range:** \_\_\_\_\_ **0 to 25.5  $\Omega$** 

Driver side seat belt buckle switch resistance.

**DTC CouNT (AIRBAG)****Range:** \_\_\_\_\_ **0 to 20**

Number of diagnostic trouble codes (DTCS in the airbag module memory).

**EXTCRSH****Range:** \_\_\_\_\_ **not available**

Information on this External Crash Sensor Test Voltage parameter is not available at this time.

**VBATT(V)****Range:** \_\_\_\_\_ **0 to 25 V**

This parameter displays the battery voltage being supplied to the airbag electronic control module (ECM).

## Antilock Brake Parameters

**4WDINP\_SW\_ABS**  
Range: \_\_\_\_\_ **2WD/4WD)**

Status of the 4WD switch status.

**ABPROS**  
Range: \_\_\_\_\_ **ON/OFF**

Antilock braking system power relay output status.

**ABS\_MTR**  
Range: \_\_\_\_\_ **ACTIVE/INACTIVE**

Status of the ABS pump motor.

**ABS\_PLS**  
Range: \_\_\_\_\_ **ON/OFF**

Information on this "ABS MODULATE" parameter is not available at this time.

**ABS\_POWER**  
Range: \_\_\_\_\_ **ON/OFF**

Status of the ABS power relay.

**ABS\_PWR\_R**  
Range: \_\_\_\_\_ **ON/OFF**

Antilock braking system power relay output status.

**ABS\_partbaseno**  
Range: \_\_\_\_\_ **not available**

Module part base number.

**ABS\_PartNoldSuffix**  
Range: \_\_\_\_\_ **not available**

Part version suffix.

**ABS\_SoftVerNo**  
Range: \_\_\_\_\_ **not available**

Software version number.

**ABS\_TCS\_WIN126\_SELTESTDTC**  
Range: \_\_\_\_\_ **not available**

DTC count. The count includes those needing no action.

**ABSLAMP**  
**ABS\_LAMP**  
Range: \_\_\_\_\_ **ON/OFF**

PCM command status to the ABS indicator lamp and reads ON when the Lamp is lit.

**ABSLF I**  
**ABSLF O**  
**ABSLR I**  
**ABSLR O**  
**ABSRF I**  
**ABSRF O**  
**ABSRR I**  
**ABSRR O**  
Range: \_\_\_\_\_ **ON/OFF**

State of the PCM commands to the ABS inlet (I) and outlet (O) valves.

- LF = left front
- LR = left rear
- RF = right front
- RR = right rear

**ABSR I****ABSR O****Range:** \_\_\_\_\_ **ON/OFF**

PCM commanded status to the rear ABS inlet (I) or outlet (O) valves. This parameter is only used in 4WABS systems that use a rear differential speed sensor instead of a sensor at both rear wheels. In an ABS stop this system controls both rear wheels at the same time.

**ABSPMPRLY****Range:** \_\_\_\_\_ **ON/OFF**

ABS pump motor relay.

**ABSVLVRLY****Range:** \_\_\_\_\_ **ON/OFF**

Status of the ABS valve control relay.

**ACCLMTR****Range:** \_\_\_\_\_ **not available**

Indicates the accelerometer.

**ACCR\_TEMP (°C(°F)****Range:** \_\_\_\_\_ **not available**

Brake accumulator temperature.

**ACCR\_TRAV****Range:** \_\_\_\_\_ **ON/OFF**

Brake accumulator travel signal.

**ACU\_CHK****Range:** \_\_\_\_\_ **not available**

ACU Bleed Check.

**ARCFault****Range:** \_\_\_\_\_ **YES/NO**

Indicates whether an automatic ride control DTC has set.

**AutoRideCtrl****Range:** \_\_\_\_\_ **ON/OFF**

PCM command status to the automatic ride control system.

**AWD\_MSG\_ABS\_MZ****AWD\_MSG****Range:** \_\_\_\_\_ **PRESENT/NOT PRESENT**

Indicate if there is CAN communication with the 4x4 module. NOT PRESENT indicates no communication.

**BALVLV1****Range:** \_\_\_\_\_ **ON/OFF**

Indicates the status of balance valve 1.

---

<b>BALVLV2</b>	<b>Range:</b> _____	<b>ON/OFF</b>
Indicates the status of balance valve 2.		
<b>BLD_STAT</b>	<b>Range:</b> _____	<b>DONE/NOT DONE</b>
Indicates the status of the brake air bleed check.		
<b>BOO ABS</b>	<b>Range:</b> _____	<b>ON/OFF</b>
Brake pedal switch status and reads as follows:		
<ul style="list-style-type: none"> <li>• OFF when the brakes are not applied</li> <li>• ON when the brakes are applied</li> </ul>		
This parameter should read the same as "BOO=BRAKE SW" on page 329.		
<b>BP_CALST</b>	<b>Range:</b> _____	<b>DONE/NOT DONE</b>
Indicates the status of the brake pedal travel sensor calibration.		
<b>BPTSCAL</b>	<b>Range:</b> _____	<b>not available</b>
Indicates the offset calibration.		
<b>BRAKPRES(KPA/PSI)</b>	<b>Range:</b> _____	<b>not available</b>
ABS main brake pressure.		
<b>BRAKE_LMP</b>	<b>Range:</b> _____	<b>ON/OFF</b>
Brake warning lamp.		
<b>BrakePrsApply</b>	<b>Range:</b> _____	<b>0 or 12 V</b>
PCM command status to the brake pressure applied switch and reads as follows:		
<ul style="list-style-type: none"> <li>• 0 V when the switch is on</li> <li>• 12 V when the switch is off</li> </ul>		
<b>BRK_CHK</b>	<b>Range:</b> _____	<b>not available</b>
Brake bleed check.		
<b>BRK_FLUID</b>	<b>Range:</b> _____	<b>LOW/OK</b>
Brake fluid level.		
<b>BRK_MSIG(KPA/PSI)</b>	<b>Range:</b> _____	<b>not available</b>
ABS main brake pressure.		
<b>BRK_RSIG</b>	<b>Range:</b> _____	<b>PRESSURE</b>
ABS redundant brake pressure.		

**BRK\_WARN**

Range: \_\_\_\_\_ ON/OFF

State of the brake warning lamp.

**BRKLAMP**

Range: \_\_\_\_\_ ON/OFF

PCM command status to the brake warning indicator lamp on the instrument panel and reads ON when the Lamp is lit.

**BSTLRNCYC**

Range: \_\_\_\_\_ ON/OFF

Status of the booster learn cycle.

**BSTR\_BSWF**

Range: \_\_\_\_\_ YES/NO

Booster solenoid brake switch failure.

**BSTR\_MECH**

Range: \_\_\_\_\_ PASS/FAIS

Booster mechanical failure status.

**BSTR\_LCCS**

Range: \_\_\_\_\_ YES/NO

Booster learn cycle is complete. YES indicates complete.

**BSTR\_LERN**

Range: \_\_\_\_\_ PASS/FAIS

Booster self check/calibration status.

**BSTR\_SOL**

Range: \_\_\_\_\_ ON/OFF

Interactive vehicle dynamics booster solenoid status.

**BSTR\_SOL1**

Range: \_\_\_\_\_ not available

Booster solenoid output state.

**BSTR\_SW\_T**

Range: \_\_\_\_\_ ON/OFF

Booster switch test signal output state.

**BSTRBP\_FSNC**

Range: \_\_\_\_\_ OPEN/CLOSED

Booster brake pedal force switch. The switch is normally closed.

**BSTRBP\_FSNO**

Range: \_\_\_\_\_ OPEN/CLOSED

Booster brake pedal force switch. The switch is normally open.

**CCB\_LCCS**

Range: \_\_\_\_\_ YES/NO

Indicates if the current cycle booster learn cycle is complete. YES indicates complete.

**CCB\_LCTF**

Range: \_\_\_\_\_ YES/NO

Indicates if the current cycle booster learn cycle test has failed. Yes indicated failed.

---

<b>CCLAS_ICS</b>	<b>Range:</b> _____	<b>YES/NO</b>
Indicates the if the current cycle lateral acceleration sensor initialization test is complete. YES indicates complete.		
<b>CCLAS_ITF</b>	<b>Range:</b> _____	<b>YES/NO</b>
Indicates if the current cycle lateral acceleration sensor initialization test has failed. YES indicates failed.		
<b>CCNTABS</b>	<b>Range:</b> _____	<b>not available</b>
Indicates the total number of continuous (soft) DTCs stored in the ABS control module.		
<b>CCSWA_TPS</b>	<b>Range:</b> _____	<b>YES/NO</b>
Indicates if the current cycle steering wheel angle lock to lock test passed. YES indicates passed.		
<b>CCYR_ICS</b>	<b>Range:</b> _____	<b>YES/NO</b>
Indicates if current cycle yaw rate initialization is complete.		
<b>CCYR_ITF</b>	<b>Range:</b> _____	<b>YES/NO</b>
Indicates if the current cycle yaw rate initialization test is complete. YES indicates complete.		
<b>CONPROV</b>	<b>Range:</b> _____	<b>not available</b>
Indicates the configuration and programming version.		
<b>CUTVLV1</b>	<b>Range:</b> _____	<b>ON/OFF</b>
Indicates the status of cut valve 1.		
<b>CUTVLV2</b>	<b>Range:</b> _____	<b>ON/OFF</b>
Indicates cut valve 2.		
<b>DSBL_TOG</b>	<b>Range:</b> _____	<b>ON/OFF</b>
Indicates the state disable valve toggle.		
<b>DYNOMODE</b>	<b>Range:</b> _____	<b>YES/NO</b>
Indicates the state of the brake two-wheel dynomode.		
<b>EVACFILL</b>	<b>Range:</b> _____	<b>DONE/NOT DONE</b>
Indicates the fill status of the Electro-Hydraulic EVAC.		
<b>G_INPUT</b>	<b>Range:</b> _____	<b>not available</b>
Indicates the accelerometer.		

**G\_SENSOR**Range: \_\_\_\_\_ **ON/OFF**

Indicates the longitudinal acceleration sensor initialization start.

**IC\_MSG\_ABS\_MZ**

Range: \_\_\_\_\_

**IC\_MSG**Range: \_\_\_\_\_ **PRESENT/NOT PRESENT**

Indicate if the CAN message is missing from the IC. NOT PRESENT indicates missing.

**IGNITION(V)**Range: \_\_\_\_\_ **VOLTS**

Indicates the status of the ignition.

**IVD\_R\_IN**Range: \_\_\_\_\_ **ON/OFF**

Status of the rear-only dump valve.

**IVD\_R\_OUT**Range: \_\_\_\_\_ **ON/OFF**

Status of the rear-only isolation valve.

**L\_ACCEL\_EPB**Range: \_\_\_\_\_ **Acceleration/G**

Longitudinal acceleration sensor.

**LAS\_ICS**Range: \_\_\_\_\_ **YES/NO**

Status of the EEPROM - lateral acceleration sensor initialization. YES indicates complete.

**LATACCEL**Range: \_\_\_\_\_ **TRUE/FALSE**

State of the lateral accel sensor initialization start.

**LATACCL**Range: \_\_\_\_\_ **not available**

ABS lateral acceleration rate.

**LATACINPT**Range: \_\_\_\_\_ **not available**

Status of the lateral accelerometer input.

**LF\_FAIL**Range: \_\_\_\_\_ **TRUE/FALSE**

Left front failure test.

**LF\_IN(AMP)**Range: \_\_\_\_\_ **not available**

Current of the left front current inlet valve.

**LF\_INLET**Range: \_\_\_\_\_ **ON/OFF**

Status of the left front inlet valve.

**LF\_OUT(AMP)**Range: \_\_\_\_\_ **not available**

Current of the front left current outlet valve.

---

<b>LF_OUTLET</b>	<b>Range:</b> _____	<b>ON/OFF</b>
Left front outlet valve.		
<b>LF_PRES</b>	<b>Range:</b> _____	<b>not available</b>
Left front brake pressure applied.		
<b>LF_PRIME</b>	<b>Range:</b> _____	<b>ON/OFF</b>
Traction assist left front priming valve output state.		
<b>LF_SWITCH</b>	<b>Range:</b> _____	<b>ON/OFF</b>
Traction assist left front switching valve output state.		
<b>LF_TC_PRV</b>	<b>Range:</b> _____	<b>ON/OFF</b>
Status of the left front traction control priming valve.		
<b>LF_TC_SWV</b>	<b>Range:</b> _____	<b>ON/OFF</b>
State of the traction assist left priming valve output.		
<b>LF_WSPD(KPH MPH)</b>	<b>Range:</b> _____	<b>not available</b>
Status of the left front wheel speed sensor.		
<b>LONG_ACCL</b>	<b>Range:</b> _____	<b>not available</b>
Status of the longitudinal accelerometer signal.		
<b>LR_PRES(KPA PSI)</b>	<b>Range:</b> _____	<b>not available</b>
Left rear brake pressure applied.		
<b>LR_PRIME</b>	<b>Range:</b> _____	<b>ON/OFF</b>
Status of the traction assist left rear priming valve output.		
<b>LR_SWITCH</b>	<b>Range:</b> _____	<b>ON/OFF</b>
Status of the traction assist left rear switching valve output state.		
<b>LR_TC_SWV</b>	<b>Range:</b> _____	<b>ON/OFF</b>
Status of the left rear traction control switching valve.		
<b>LR_TC_VLV</b>	<b>Range:</b> _____	<b>ON/OFF</b>
Status of the left rear traction control valve.		

---

**LF\_WSPD(MPH)****LR\_WSPD(MPH)****R\_WSPD(MPH)****RF\_WSPD(MPH)****RR\_WSPD(MPH)****Range:** \_\_\_\_\_ **0 to 100+ MPH/KPH**

Display the speed signals being sent by each front wheel speed sensor (LF/RF, each rear wheel speed sensors (LR or RR), or the single rear wheel speed sensor (R) to the electronic control module (ECM).

Wheel speeds should be equal to each other and to vehicle speed as the vehicle is driven in a straight line without braking. Wheel speeds vary when turning a corner and during braking without antilock operation. During antilock braking, wheel speeds should remain close to equal.

Some 4WABS systems use a rear differential speed sensor (R) instead of a sensor at both rear wheels. In an ABS stop this system controls both rear wheels at the same time.

**LR\_FAIL****Range:** \_\_\_\_\_ **TRUE/FALSE**

Left rear failure test.

**LR\_IN(AMP)****Range:** \_\_\_\_\_ **not available**

Current of the left rear current inlet valve.

**LR\_INLET****Range:** \_\_\_\_\_ **ON/OFF**

Status of the left rear inlet valve.

**LR\_OUT(AMP)****Range:** \_\_\_\_\_ **not available**

Current of the left rear current outlet valve.

**LR\_OUTLET****Range:** \_\_\_\_\_ **ON/OFF**

Status of the left rear outlet valve.

**LR\_PRIME****Range:** \_\_\_\_\_ **ON/OFF**

State of the traction assist left rear priming valve output.

**LR\_SWITCH****Range:** \_\_\_\_\_ **ON/OFF**

Status of the traction assist left rear switching valve output.

**LR\_TC\_PRV****Range:** \_\_\_\_\_ **ON/OFF**

Status of the left rear traction control priming valve.

**LR\_TC\_SWV****Range:** \_\_\_\_\_ **ON/OFF**

Status of the left rear traction control switching valve.

**LR\_TC\_VLV****Range:** \_\_\_\_\_ **ON/OFF**

Status of the left rear traction control valve.

---

<b>LR_WSPD(KPH MPH)</b>	<b>Range:</b> _____	<b>not available</b>
Status of the left rear wheel speed sensor.		
<b>LTRL_ACC</b>	<b>Range:</b> _____	<b>not available</b>
ABS lateral acceleration rate.		
<b>MAP_PCM</b>	<b>Range:</b> _____	<b>not available</b>
Manifold absolute pressure sensor.		
<b>MC_PT_1</b>	<b>Range:</b> _____	<b>not available</b>
Master cylinder travel signal 1.		
<b>MC_PT_2</b>	<b>Range:</b> _____	<b>not available</b>
Master cylinder travel signal 2.		
<b>MIL_DIS</b>	<b>Range:</b> _____	<b>not available</b>
Distance travelled since the MIL was activated.		
<b>MNC_VEL_1</b>	<b>Range:</b> _____	<b>not available</b>
Brake tandem main cylinder velocity signal 1.		
<b>MNC_VEL_2</b>	<b>Range:</b> _____	<b>not available</b>
Brake tandem main cylinder velocity signal 2.		
<b>MN_PR_TRN</b>	<b>Range:</b> _____	<b>PASS/FAIS</b>
Booster main pressure transducer status.		
<b>MODSTATE</b>	<b>Range:</b> _____	<b>not available</b>
Indicates the module state.		
<b>PART#PRE_ABS</b>	<b>Range:</b> _____	<b>not available</b>
Indicates the part version prefix.		
<b>PCM_MSG</b>	<b>Range:</b> _____	<b>PRESENT/NOT PRESENT</b>
Indicates if there is CAN communication with the PCM. NOT PRESENT indicates no communication.		
<b>PRE_CHK</b>	<b>Range:</b> _____	<b>ON/OFF</b>
Indicates the pre-drive check.		
<b>PRIM_VLV</b>	<b>Range:</b> _____	<b>ON/OFF</b>
Indicates the status of the primary low pressure supply valve.		

---

**PMP\_MOTOR****Range:** \_\_\_\_\_ **ON/OFF**

Indicates the status of the hydraulic pump motor.

**PMPSTAT****Range:** \_\_\_\_\_ **ON/OFF**

Indicates the status of the ABS pump motor.

**PUMP****Range:** \_\_\_\_\_ **ON/OFF**

Indicates the status of the pump.

**PUMPEFF****Range:** \_\_\_\_\_ **not available**

Indicates the status of the pump efficiency test.

**PWR RLY****Range:** \_\_\_\_\_ **ON/OFF**

Indicates whether the relay for the ABS System has been commanded on by the ABS module.

PWR RLY reads ON when the relay contacts are closed, which directs current to the ABS pump motor.

**R\_DIF\_SPD****Range:** \_\_\_\_\_ **not available**

Indicates the rear differential wheel speed.

**R\_INLET****Range:** \_\_\_\_\_ **ON/OFF**

Indicates the status of the rear only isolation valve.

**R\_OUTLET****Range:** \_\_\_\_\_ **ON/OFF**

Indicates the status of the right outlet.

**RF\_FAIL****Range:** \_\_\_\_\_ **TRUE/FALSE**

Indicates right front failure test.

**RF\_IN(AMP)****Range:** \_\_\_\_\_ **not available**

Indicates the current of the right front current inlet valve.

**RF\_INLET****Range:** \_\_\_\_\_ **ON/OFF**

Indicates the status of the right front inlet valve.

**RF\_OUT(AMP)****Range:** \_\_\_\_\_ **not available**

Indicates the current of the right front current outlet valve.

**RF\_OUTLET****Range:** \_\_\_\_\_ **ON/OFF**

Indicates the status of the right front outlet valve.

---

<b>RF_PRES(KPA/PSI)</b>	<b>Range:</b> _____	<b>not available</b>
Indicates right front brake pressure applied.		
<b>RF_PRIME</b>	<b>Range:</b> _____	<b>ON/OFF</b>
Indicates the state of the right front priming valve output.		
<b>RF_SWITCH</b>	<b>Range:</b> _____	<b>ON/OFF</b>
Indicates the state of the traction assist right front switching valve output.		
<b>RF_TC_PRV</b>	<b>Range:</b> _____	<b>ON/OFF</b>
Indicates the status of the front right traction control priming valve.		
<b>RF_TC_SWV</b>	<b>Range:</b> _____	<b>ON/OFF</b>
Indicates the status of the front right traction control switching valve.		
<b>RF_WSPD(KPH MPH)</b>	<b>Range:</b> _____	<b>not available</b>
Indicates the status of the right front wheel speed sensor.		
<b>ROLLRAT</b>		
<b>ROLLRATE</b>	<b>Range:</b> _____	<b>not available</b>
Indicate the roll rate value.		
<b>RPM_FF</b>	<b>Range:</b> _____	<b>not available</b>
Indicates the engine speed.		
<b>RR_FAIL</b>	<b>Range:</b> _____	<b>TRUE/FALSE</b>
Indicates the status of the right rear failure test.		
<b>RR_IN(AMP)</b>	<b>Range:</b> _____	<b>not available</b>
Indicates the current of the right rear current inlet valve.		
<b>RR_INLET</b>	<b>Range:</b> _____	<b>ON/OFF</b>
Indicates the status of the right rear inlet valve.		
<b>RR_OUT(AMP)</b>	<b>Range:</b> _____	<b>not available</b>
Indicates the current of the right rear current outlet valve.		
<b>RR_OUTLET</b>	<b>Range:</b> _____	<b>ON/OFF</b>
Indicates the status of the right rear outlet valve.		
<b>RR_PRIME</b>	<b>Range:</b> _____	<b>ON/OFF</b>
Indicates the state of the right rear priming valve output.		

---

**RR\_PRES(KPA/PSI)**

**Range:** \_\_\_\_\_ **not available**

Indicates the right rear brake pressure applied.

**RR\_SWITCH**

**Range:** \_\_\_\_\_ **ON/OFF**

Indicates the state of the traction assist right rear switching valve output.

**RR\_TC\_VLV**

**Range:** \_\_\_\_\_ **ON/OFF**

Indicates the status of the right rear traction assist valve.

# Passive Antitheft System (PATS) Parameters

PATS parameters may be located in any of the following locations:

- HEC
- ICM
- PATS
- PCM
- SCIL
- VIC

Refer to your service manual for a correct PATS location.

**AntiScan**  
Range: \_\_\_\_\_

ON/OFF

Indicates if PATS has activated the Antiscan function. The PATS enables Antiscan after an unprogrammed PATS key is used to attempt to start the engine. Antiscan then temporarily locks out all keys from starting the vehicle and flashes a dash-mounted LED or the Theft Lamp indicator.

**C KEYMD**  
Range: \_\_\_\_\_

ACTIVE/NOTACTIVE

This parameter should read ACTIVE when PATS has been requested to clear all keys.

**ENABLE S**  
Range: \_\_\_\_\_

DISABLE/ENABLE

Information on this "VEHICLE ENABLE STATUS" parameter is not available at this time. It appears to be an output from PATS indicating that the engine will start or is ENABLED.

**FAILSAF**  
Range: \_\_\_\_\_

ON/OFF

Information on this "Failsafe Mode" parameter is not available at this time.

**M KEY**  
**Master KEY**  
Range: \_\_\_\_\_

NOTPRE/PRESENT

Indicate whether a Master Key is present in the ignition. Master keys are required to program in new spare keys. Depending upon the type of PATS system, one or two Master keys may be needed to program extra spare keys.

**NUMKEYS**  
Range: \_\_\_\_\_

0 to 255

Number of Master and Spare keys that are programmed into the PATS control module.

**PCM ID**  
Range: \_\_\_\_\_

STORED/NOTSTORED

Indicates whether the PATS has learned and stored the unique identification (ID) of the powertrain control module (PCM).

**PCM VFY**  
Range: \_\_\_\_\_

YES/NO

Indicates whether PATS has verified that the PCM ID matches the ID stored from module initialization.

**SPAREKY**  
Range: \_\_\_\_\_ **DISABLE/ENABLE**

Indicates whether spare key programming is enabled in the PATS module. Spare key programming may not be desired and therefore can be disabled or enabled on certain models.

**V ENABLE**  
Range: \_\_\_\_\_ **DISABLE/ENABLE**

Information on this "VEH ENABLE" parameter is not available at this time.

**RR\_WSPD(KPH MPH)**  
Range: \_\_\_\_\_ **not available**

This parameter indicates the speed of the right rear wheel.

**SAS\_CAL**  
Range: \_\_\_\_\_ **TRUE/FALSE**

Indicates the status of the steering angle sensor initialization start.

**SECND\_VLV**  
Range: \_\_\_\_\_ **ON/OFF**

Indicates the secondary low pressure feed valve.

**SECPR\_TRN**  
Range: \_\_\_\_\_ **PASS/FAIS**

Indicates the status of the booster secondary transducer.

**SELTESTDTC**  
Range: \_\_\_\_\_ **not available**

Indicates the DTC count. Count includes those that needing no action.

**SEN\_CAL**  
Range: \_\_\_\_\_ **not available**

Indicates the status of the pressure sensor calibration.

**SENVBAT(V**  
Range: \_\_\_\_\_ **not available**

Indicates the IVD/DSC sensors supply voltage.

**STEER\_ANGL**  
Range: \_\_\_\_\_ **not available**

Indicates the steering wheel angle sensor.

**ST\_WH\_ANG**  
Range: \_\_\_\_\_ **not available**

Indicates the ABS steering wheel angle.

**SW\_TEST**  
Range: \_\_\_\_\_ **ON/OFF**

Indicates the switch test signal.

**SWA\_CW**  
**SWA\_CCW**  
Range: \_\_\_\_\_ **not available**

Indicate an angle in degrees clockwise from start.

---

<b>SWA_LPS</b>	<b>Range:</b> _____	<b>YES/NO</b>
Shows if the SWA Lock to Lock test is passed. YES indicates passed.		
<b>SWA_POS(°)</b>	<b>Range:</b> _____	<b>not available</b>
This parameter indicates the steering wheel angle in degrees.		
<b>SWA1_CIR</b>	<b>Range:</b> _____	<b>Open/Sht-B+/Sht-Gnd/Normal</b>
Indicates the steering wheel angle 1 circuit state.		
<b>SWA1_INPT</b>	<b>Range:</b> _____	<b>HIGH/LOW</b>
Indicates the steering wheel angle 1 input state.		
<b>SWA2_CIR</b>	<b>Range:</b> _____	<b>Open/Sht-B+/Sht-Gnd/Normal</b>
Indicates the steering wheel angle 2 circuit state.		
<b>SWA2_INPT</b>	<b>Range:</b> _____	<b>HIGH/LOW</b>
Indicates the steering wheel angle 2 input state.		
<b>TA_LVAL</b>	<b>Range:</b> _____	<b>ON/OFF</b>
Indicates the status of the traction assist left control valve.		
<b>TA_RVAL</b>	<b>Range:</b> _____	<b>ON/OFF</b>
Indicates the status of the traction assist right control valve.		
<b>TC_RVAL</b>	<b>Range:</b> _____	<b>ON/OFF</b>
Indicates the status of the traction assist right control valve		
<b>TCYC_FS</b>	<b>Range:</b> _____	<b>ACTIVE/PASSIVE or ON/OFF</b>
Indicates the status of the traction control system.		
<b>TCYC_SW</b>	<b>Range:</b> _____	<b>NOT DEPRESSED/DEPRESSED or ACTIVATED/NOT ACTIVATED</b>
Indicates the status of the traction control switch.		
<b>TDPT_COMP</b>	<b>Range:</b> _____	<b>YES/NO</b>
States if the travel direction plausibility test is complete. YES indicates complete.		
<b>TDPT_PASS</b>	<b>Range:</b> _____	<b>YES/NO</b>
Indicates if the travel direction plausibility test is complete. YES indicates complete.		
<b>TRAC SW</b>	<b>Range:</b> _____	<b>ON/OFF</b>
Indicates the status of the driver-operated Traction Switch. When ON, TRACtionassist should also display ON.		

**TRACtionassist****Range:** \_\_\_\_\_ **ON/OFF**

Reads ON when the PCM has activated the Traction Assist system.

**VALVCAL****Range:** \_\_\_\_\_ **not available**

Indicates the status of the valve calibration.

**VALVE\_CAL****Range:** \_\_\_\_\_ **DONE/NOT DONE**

Indicates the calibration status of the Electro-Hydraulic valve.

**VSS\_FF****Range:** \_\_\_\_\_ **not available**

Vehicle speed input to overhead trip computer.

**VSS\_PCM****Range:** \_\_\_\_\_ **not available**

Vehicle speed.

**WAKESIG****Range:** \_\_\_\_\_ **not available**

Wake-up signal.

**XDCR\_ACCR(KPA/PSI)****Range:** \_\_\_\_\_ **not available**

Brake pressure transducer accumulator signal.

**XDCR\_LFW(KPA/PSI)****Range:** \_\_\_\_\_ **not available**

Brake pressure transducer left front wheel signal.

**XDCR\_LRW(KPA/PSI)****Range:** \_\_\_\_\_ **not available**

Brake pressure transducer left rear wheel signal.

**XDCR\_RFW(KPA/PSI)****Range:** \_\_\_\_\_ **not available**

Brake pressure transducer right front wheel signal.

**XDCR\_RRW(KPA/PSI)****Range:** \_\_\_\_\_ **not available**

Brake pressure transducer right rear wheel signal.

**XDCR\_TMC(KPA/PSI)****Range:** \_\_\_\_\_ **not available**

Brake pressure transducer tandem main cylinder signal.

**XDUCERCAL****Range:** \_\_\_\_\_ **ENERGIZED/DE-ENERGIZED**

Status of the pressure transducer.

---

<b>YAW_INPUT</b>		
Range:	_____	<b>not available</b>
		Status of the yaw rate sensor input circuit.
<b>YAW_RATE(°)</b>		
Range:	_____	<b>not available</b>
		ABS yaw rate value in degrees.
<b>YAWRATE</b>		
Range:	_____	<b>ON/OFF</b>
		Yaw rate sensor initialization start.
<b>YAWRTSEN(°)</b>		
Range:	_____	<b>not available</b>
		ABS yaw rate value.
<b>YR_ICS</b>		
Range:	_____	<b>YES/NO</b>
		Complete status of yaw rate initialization. YES indicates complete.

## Generic Electronic Module (GEM) Parameters

**4WDClutch(%)**Range: \_\_\_\_\_ **0 to 100%**

Amount of transfer case clutch lockup that is commanded by the module. When both front and rear axles rotate at the same speed, 4WDClutch(%) should display 0 to 2%.

**4WDClutchElec**Range: \_\_\_\_\_ **ON/OFF**

Power available to the 4WD magnetic clutch and should read ON for about 1 second after shifting from 4WD to 2WD.

**4WDClutchPWM**Range: \_\_\_\_\_ **ON/OFF**

Reads ON when the GEM is controlling the transfer case clutch using pulse-width modulation (PWM).

**4WDClutchStat**Range: \_\_\_\_\_ **ON/OFF**

4WD clutch output status. The module determines actual status of the A4WD magnetic clutch by monitoring the Torque ON Demand Relay output.

4WDClutchStat reads ON when commanded by the GEM/4X4 module.

**4WDHigh**Range: \_\_\_\_\_ **ON/OFF**

Reads ON when the GEM has commanded the transfer case to run in 4WD high mode.

**4WDLOLED**Range: \_\_\_\_\_ **ON/OFF**

Command status of the 4X4 Low indicator LED and reads ON when the 4WD low lamp is illuminated.

**4WDLow**Range: \_\_\_\_\_ **ON/OFF**

GEM command status to run the transfer case in 4WD low mode. Reads ON when the transfer case is running in 4WD low mode.

**4WD\_FrShftSp****4WD\_RrShftSp**Range: \_\_\_\_\_ **0 to 255 MPH**

Speeds in MPH for the front and rear transfer case drive shafts. Using the speeds of these two shafts, the GEM module calculates wheel slippage between the front and rear axles. The amount of wheel slippage is used to determine how much the GEM module applies the 4WD clutch.

---

**4WDPlate\_A**  
PLATE A  
**4WDPlate\_B**  
PLATE B  
**4WDPlate\_C**  
PLATE C  
**4WDPlate\_D**  
PLATE D  
Range: \_\_\_\_\_ OPEN/CLOSED

Status of various transfer case contact plates. Refer to the Ford factory manual for a chart identifying plate positions with shift lever positions.

**4WDPlatePwr**  
Range: \_\_\_\_\_ ON/OFF

Power available to the transfer case shift motor contact plates that limit transfer case shift linkage travel and should read ON when shifting the transfer case between ranges.

**4WD\_Switch**  
Range: \_\_\_\_\_ AUTO/4HI/4LOW

GEM module input from the driver-operated 4WD switch. The switch controls transfer case operation.

**ABagCHIME**  
Range: \_\_\_\_\_ ON/OFF

Commanded status of the Air Bag Chime from the restraint module.

ABagCHIME normally reads OFF and reads ON only if a short or open is detected in the Air Bag lamp circuit by the Restraint module.

**A/C BLndoerPos**  
Range: \_\_\_\_\_ OPEN/CLOSE

Commanded position of the A/C blend door.

**ACC\_Pos**  
**RUN\_Pos**  
**IGN\_Run**  
**START\_Pos**  
**OFF/LOCK\_Pos**  
**IGN\_O/L**  
Range: \_\_\_\_\_ YES/NO

Current position of the ignition switch and read as follows:

- ACC\_Pos reads YES with the switch in accessory position.
- START\_Pos reads YES with the switch in cranking position.
- RUN\_Pos or IGN\_Run reads YES with the switch in run position.
- OFF/LOCK\_Pos or IGN\_O/L reads YES with the switch in lock position and reads NO when the ignition switch is in the off position or accessory position.

**AccessoryDly**  
**ACC DeLaY**  
Range: \_\_\_\_\_ ON/OFF

Actual status of the accessory power relay and read ON when the relay contacts are closed, allowing some accessories to be turned on after the ignition key has been switched off.

**ALarm EVent1-8****Range:** \_\_\_\_\_ **see description**

Trigger source for the last 8 perimeter alarm activations. Event # 1 is the oldest and # 8 is the newest. They continue to rotate from 8 to 1 as more events accumulate.

The following descriptions may appear depending upon model and available options:  
DOOR, BATTERY, DECKLID, DRIVDOOR, DOODAJR, HOOD/TRNK, IGNITION,  
LRDOOR, NO EVNT, PANIC, PASS DOOR, RADIO, RR/SLI.

**AUTOLMP****Range:** \_\_\_\_\_ **ON/OFF**

Status of the Automatic Headlamp switch.

**BATSAV****BattSaver****Range:** \_\_\_\_\_ **ON/OFF**

Actual status of the battery saver relay and read ON when the relay contacts are closed, allowing some accessories to be turned on after the ignition key has been turned to the OFF position.

When the battery saver relay contacts are closed, all the accessories operate. If an accessory is left on with the ignition key off, after approximately one hour the battery saver relay contacts open to shut off the accessories.

**BOO\_GEM****BOO SW****Range:** \_\_\_\_\_ **ON/OFF**

Brake ON/OFF (BOO) pedal switch signal to the GEM module and read ON when the switch contacts are closed.

**CCW\_Shift\_Mtr****CW\_Shift\_Mtr****Range:** \_\_\_\_\_ **ON/OFF**

GEM commands to the counterclockwise (CCW and clockwise (CW shift motor relays on 4WD systems. The relays control the directional rotation of the shift motor inside the transfer case.

These parameters read ON when the solenoid for the relay is energized, which closes the relay contacts.

**ChimeReq****CHIMERQ****Range:** \_\_\_\_\_ **ON/OFF**

Command status for the warning chime and read ON when the chimes sound.

The module relies on inputs from the door switches, door key cylinder, headlight switch, and seatbelt buckle to determine when to activate the chime.

**ClutchLock****Range:** \_\_\_\_\_ **ACTIVE/INACTV**

Status of the driver-operated clutch pedal switch on 4WD systems and reads ACTIVE when the switch contacts are closed.

**COOLANT****Range:** \_\_\_\_\_ **notOK/OK**

Displays the coolant level.

---

<b>D DR SW</b>	
<b>DECKLID</b>	
<b>Dr DR SW</b>	
<b>LGATESW</b>	
<b>LRDR Switch</b>	
<b>LRDoor SWitch</b>	
<b>LRDR SW</b>	
<b>P DR SW</b>	
<b>Pass DR SW</b>	
<b>RRDoor SWitch</b>	
<b>Range:</b> _____	<b>CLOSED/OPEN</b>
Indicate whether the indicated door and trunk switches are open or closed and read OPEN when the door is open and switch contacts are closed.	
<b>DIM DEC</b>	
<b>Range:</b> _____	<b>NotAct/ActivE</b>
Status of the instrument cluster illumination control switch and should read ACTIVE when the OFF button is pressed.	
<b>DIM INC</b>	
<b>Range:</b> _____	<b>NotAct/ActivE</b>
Status of the instrument cluster illumination control switch and should read ACTIVE when the MAX button is pressed.	
<b>DoorAjarLamp</b>	
<b>DoorAJR L</b>	
<b>Range:</b> _____	<b>ON/OFF</b>
Read ON when the door ajar lamp should be lit.	
<b>DoorLock</b>	
<b>DoorUnlock</b>	
<b>Range:</b> _____	<b>LOCK/UNLOCKN</b>
Command status for the door lock solenoids and reads LOCK when the module has commanded the solenoids to energize towards the lock position.	
<b>Dr SBELT</b>	
<b>Range:</b> _____	<b>IN/OUT</b>
Reads IN when the passenger side seat belt buckle switch is engaged and the belt is buckled.	
<b>D SBELT</b>	
<b>Range:</b> _____	<b>IN/OUT</b>
Reads IN when the driver side seat belt buckle switch is engaged and the belt is buckled.	
<b>DTC CouNT</b>	
<b>Range:</b> _____	<b>0 to 20</b>
Displays the number of diagnostic trouble codes stored in GEM module memory.	
<b>FrWiperMd</b>	
<b>RearWiperMd</b>	
<b>Range:</b> _____	<b>see description</b>
Display the position of the driver-operated front or rear windshield wiper switch. The GEM module uses this information to control the wiper and washer relays. Readings vary by model. The screen may display the selected switch range position or the switch operating status.	

The possible range positions include POS1, POS2, POS3, POS4, POS5, POS6, POS7, WASH.

The possible operating states include INT, LOW, HIGH, OPEN, CKT.

**HallPwr**

**Range:** \_\_\_\_\_ **ON/OFF**

Indicates whether the module is supplying a reference voltage to the transfer case Hall-effect switches on 4WD systems.

**HatchUnlkSw****LF\_UnlockSw****RF\_UnlockSw**

**Range:** \_\_\_\_\_ **ON/OFF**

Status of the driver-operated door unlock switches and read ON when the switch contacts are closed.

**HeaDLaMP****HDLMPSW**

**Range:** \_\_\_\_\_ **ON/OFF**

Actual status of the headlamp switch and read ON when the switch contacts are closed and the headlamps are on.

**HORN SW**

**Range:** \_\_\_\_\_ **ON/OFF**

Actual status of the horn switch and reads ON when the switch contacts are closed and the horn should be on.

**IllumEntry**

**Range:** \_\_\_\_\_ **ON/OFF**

Indicates the presence of a request to turn on the illuminated entry lamps. A request to light the entry lamps may come from any one of the door ajar switches, and a special driver door handle switch whose contacts close when the handle is lifted.

**KeyInIgn**

**Range:** \_\_\_\_\_ **ON/OFF**

Indicates if the key is in the ignition switch.

**LFBeltFstnd**

**Range:** \_\_\_\_\_ **ON/OFF**

Indicates if the left front seat belt buckle is latched.

**LFDoorAjar****LRDoorAjar****RFDoorAjar****RR/SlidDr\_Ajar****Trunk/Hitch\_Ajar**

**Range:** \_\_\_\_\_ **ON/OFF**

Indicate whether door and trunk switches are open or closed. NO means the door is shut and switch contacts are closed.

**LF\_PwrWndw**

**Range:** \_\_\_\_\_ **ENABLE/DISABLE**

Status of the left front window one-touch down feature and reads ENABLE when this feature should be currently rolling the window down.

---

<b>LFWindowDn</b>	<b>Range:</b> _____	<b>YES/NO</b>
GEM command status for the left front window to roll down and reads YES when the window is rolling down.		
<b>LFWindowMotr(A)</b>	<b>Range:</b> _____	<b>0 to 64</b>
Amount of current through the left front window motor during use.		
<b>LFWndwPeak(A)</b>	<b>Range:</b> _____	<b>0 to 64</b>
Maximum amount of current drawn by the left front window motor after use.		
<b>LR TURN</b>		
<b>RR TURN</b>		
<b>Range:</b> _____		<b>ON/OFF</b>
Commanded status of the left rear and right rear turn signal lamps.		
<b>NeuSafetySw</b>		
<b>Range:</b> _____		<b>ACTIVE/INACTV</b>
Status of the neutral safety switch on 4WD systems and reads ACTIVE when the switch contacts are closed.		
<b>NeuTowFcnLmp</b>		
<b>Range:</b> _____		<b>ON/OFF</b>
Command status for the neutral tow indicator lamp on 4WD systems and reads ON when the lamp is lit and the Neutral Tow function is enabled.		
<b>NeutTowFcn</b>		
<b>Range:</b> _____		<b>ENABLE/DISABLE</b>
Indicates if the transfer case is in neutral tow mode on 4WD systems and reads ENABLE when tow mode is in effect.		
Neutral tow prevents drive train damage when the vehicle is being towed.		
<b>NTRL SW</b>		
<b>Range:</b> _____		<b>NotAct/ActivE</b>
Status of the neutral safety switch and reads ACTIVE when the switch contacts are closed.		
<b>OverSpdWarn</b>		
<b>Range:</b> _____		<b>ENABLE/DISABLE</b>
Presence of a higher-than-normal wheel speed sensor signal and reads ENABLE only when one or more wheels exceeded maximum vehicle speed or a speed sensor circuit has shorted.		
<b>ParkLmpSw</b>		
<b>Range:</b> _____		<b>ON/OFF</b>
Status of the driver-operated park lamp switch and reads ON when the park lamp switch contacts are closed.		
<b>RearDefRly</b>		
<b>Range:</b> _____		<b>ON/OFF</b>
Command status to the rear window defroster relay and reads ON when the module is commanding the relay solenoid to energize and close the relay contacts.		

**RearDefSw**  
Range: \_\_\_\_\_ **ON/OFF**

Status of the driver-operated rear window defroster switch and reads ON when the defroster switch contacts are closed.

**RearPosSense**  
Range: \_\_\_\_\_ **YES/NO**

Reads YES when the rear windshield wiper is in the PARK position.

**RearWasher**  
Range: \_\_\_\_\_ **ON/OFF**

Reads ON when the GEM is commanding the rear window washer to apply fluid to the rear window.

**RearWASHSW**  
Range: \_\_\_\_\_ **ON/OFF**

Actual status for the rear window washer switch and reads ON when the washer switch contacts are closed.

**RearWiper**  
Range: \_\_\_\_\_ **ON/OFF**

Command status for the rear window wiper and reads ON when the rear wiper is operating.

**RearWiperDn**  
**RearWiperUp**  
Range: \_\_\_\_\_ **ON/OFF**

Module status for the rear wiper arm down or up command.

- RearWiperDn = ON means the wiper should be moving down to home position.
- RearWiperUp = ON means the wiper should be moving up.

**RearWPRUN**  
Range: \_\_\_\_\_ **ON/OFF**

Status for the rear window wiper switch and reads ON when the rear wiper switch is in the on position.

**RevSel**  
Range: \_\_\_\_\_ **ON/OFF**

Indicates whether the gear selector is in reverse on 4WD systems and reads ON when the gear selector is in reverse.

**SeatBeltLamp**  
Range: \_\_\_\_\_ **ON/OFF**

GEM command status to the seat belt lamp indicator on the instrument panel and reads ON if the GEM has commanded the lamp to light.

**SpdSensWipr**  
Range: \_\_\_\_\_ **ENABLE/DISABLE**

Status of the windshield wiper mode that makes wiper motion vehicle speed sensitive and reads ENABLE when the wiping motion speed increases and decreases with vehicle speed.

**VBatt(V**  
Range: \_\_\_\_\_ **0 to 25 V**

Battery voltage.

---

<b>VBatt_GEM(V</b>	<b>Range:</b> _____	<b>0 to 25 V</b>
Battery voltage supplied to the GEM module.		
<b>VBatt_Rem(V)</b>	<b>Range:</b> _____	<b>0 to 25 V</b>
Battery voltage supplied to the REM module.		
<b>VSS_GEM</b>	<b>Range:</b> _____	<b>0 to 120 MPH</b>
Vehicle speed sensor (VSS signal being supplied to the GEM module in MPH).		
<b>WasherPumpRly</b>	<b>Range:</b> _____	<b>ON/OFF</b>
Command status to the washer pump relay and read ON when the module has energized the relay solenoid to close the relay contacts.		
<b>WasherPumpSw</b>	<b>Range:</b> _____	<b>ON/OFF</b>
Status of the driver-operated washer pump switch and reads ON when the switch contacts are closed.		
<b>WEAR OK</b>	<b>Range:</b> _____	<b>YES/NO</b>
Status of the brake pad wear switch and reads as follows:		
<ul style="list-style-type: none"> <li>• YES when the switch contacts are closed</li> <li>• NO when the switch contacts are open</li> </ul>		
The dash brake warning indicator illuminates when the switch contacts open.		
<b>WFLUID</b>	<b>Range:</b> _____	<b>LOW/OK</b>
Indicates whether the washer fluid level is LOW or OK.		
<b>Wiper2SpdRly</b>	<b>Range:</b> _____	<b>ON/OFF</b>
Status of the two-speed (high wiper relay and reads ON when the relay contacts are closed, allowing the wipers to operate at high speed.		
<b>WiperPk-Pk(mS)</b>	<b>Range:</b> _____	<b>0 to 255 mS</b>
Windshield intermittent delay time.		
<b>WiperRunRly</b>	<b>Range:</b> _____	<b>ON/OFF</b>
Command status to the wiper run relay and reads ON when the module has energized the relay solenoid to close the relay contacts.		

# Transmission Control Module Parameters

**ABS\_ACTIVE**

Range: \_\_\_\_\_ NORMAL/ACTIVE

Antilock braking system.

**ABS\_MSG\_TCM**

Range: \_\_\_\_\_ PRESENT/NOT PRESENT

CAN message is missing from the ABS.

**ACCLUTCH\_TCM**

Range: \_\_\_\_\_ ON/OFF

Status of the air conditioning clutch.

**AP\_PER\_TCM**

Range: \_\_\_\_\_ not available

Accelerator pedal position 1 in percentage.

**APP1\_FN\_TCM**

Range: \_\_\_\_\_ not available

Accelerator pedal position sensor 1.

**APP1\_TCM**

Range: \_\_\_\_\_ not available

Accelerator pedal position sensor 1.

**APP2\_TCM**

Range: \_\_\_\_\_ not available

Accelerator pedal position sensor 2.

**APP3\_TCM**

Range: \_\_\_\_\_ not available

Accelerator pedal position sensor 3.

**BARO\_TCM**

Range: \_\_\_\_\_ not available

Barometric pressure.

**BATT\_I\_REC**

Range: \_\_\_\_\_ not available

Battery current received.

**BATT\_V\_REC**

Range: \_\_\_\_\_ not available

Battery voltage received from the transmission control module.

**BOO\_TCM**

Range: \_\_\_\_\_ ON/OFF

Brake switch input status.

**BRKPEDSW**

Range: \_\_\_\_\_ ACTIVE/INACTIVE

Status of the brake pedal switch.

**CCNT\_TCM**

Range: \_\_\_\_\_ not available

Indicates continuous codes.

---

<b>CLTCHAMP_CMD</b>	Range: _____	not available
Commanded current for the clutch actuator.		
<b>CONTRACTOR</b>	Range: _____	OPEN/CLOSED
Contractor status.		
<b>CPC_AMP</b>	Range: _____	not available
Converter pressure control.		
<b>DISTDIG_TCM</b>	Range: _____	not available
Distance since the last time diagnostic trouble codes were cleared.		
<b>DRIVECNT_TCM</b>	Range: _____	not available
Valid drive counter.		
<b>DRIVEPOS_TCM</b>	Range: _____	YES/NO
Gear level position - drive.		
<b>DTC_CNT_TCM</b>	Range: _____	not available
DTC count (includes those needing no action		
<b>ECT_TCM (°C/°F)</b>	Range: _____	not available
(ECT transmission control module temperature.		
<b>ECT_TCM_DI (°C/°F)</b>	Range: _____	not available
Engine coolant temperature.		
<b>ENG_CTO</b>	Range: _____	not available
Engine speed clean tachometer output.		
<b>ENG_TORQ</b>	Range: _____	not available
Engine torque.		
<b>ENGINE_STAT</b>	Range: _____	YES/NO
Engine running status.		
<b>FIRMSHFT</b>	Range: _____	ON/OFF
Firm shift status.		
<b>FLG_MLUSFM</b>	Range: _____	YES FAULT/NO FAULT
Torque converter had unlocked due to slipping.		

**FLG\_OTLK**

Range: \_\_\_\_\_ YES FAULT/NO FAULT

Transmission over temperature lockup mode.

**FRZ\_DTC**

Range: \_\_\_\_\_ not available

Freeze frame diagnostic trouble code.

**FUEL\_CUT**

Range: \_\_\_\_\_ not available

Fuel cut-off signal.

**G\_SDN\_A**

Range: \_\_\_\_\_ not available

Generator shutdown from e-quizzer.

**G\_SDN\_B**

Range: \_\_\_\_\_ not available

Generator shutdown for vehicle system control.

**G\_SDN\_C**

Range: \_\_\_\_\_ not available

Generator shutdown from the powertrain control module.

**Gear**

Range: \_\_\_\_\_ not available

Commanded by module.

**GEAR\_MAX**

Range: \_\_\_\_\_ not available

Highest gear allowed.

**Gear\_OSCIP**

Range: \_\_\_\_\_ not available

Gear command by output state control.

**GEAR\_RAT**

Range: \_\_\_\_\_ not available

Gear ratio.

**GEN\_BRK\_CMD**

Range: \_\_\_\_\_ ON/OFF

Generator brake command.

**GEN\_CTRL**

Range: \_\_\_\_\_ not available

Generator control mode.

**GEN\_COILTEMP (°C)(°F)**

Range: \_\_\_\_\_ not available

Generator coil temperature.

**GEN\_INV\_V**

Range: \_\_\_\_\_ not available

Voltage of the generator inverter.

---

<b>GEN_SPEED</b>	<b>Range:</b> _____	<b>not available</b>
Generator speed.		
<b>GEN_TEMPHI (°C)(°F)</b>	<b>Range:</b> _____	<b>not available</b>
Generator inverter phase temperature.		
<b>GEN_TORQ_CMD</b>	<b>Range:</b> _____	<b>not available</b>
Generator torque command.		
<b>GR_RATIO</b>	<b>Range:</b> _____	<b>not available</b>
Transmission gear ratio.		
<b>GTQ_OUT</b>	<b>Range:</b> _____	<b>not available</b>
Generator torque from AC Source.		
<b>I_SDN_1</b>	<b>Range:</b> _____	<b>not available</b>
Rapid discharge signal 1.		
<b>I_SDN_2</b>	<b>Range:</b> _____	<b>not available</b>
Rapid discharge signal 2.		
<b>IAT_TCM (°C)(°F)</b>	<b>Range:</b> _____	<b>not available</b>
Intake air temperature.		
<b>IGNITION</b>	<b>Range:</b> _____	<b>not available</b>
Indicates the ignition.		
<b>IMAN_DN_TCM</b>	<b>Range:</b> _____	<b>OPEN/CLOSED</b>
Gear lever position - Tip Minus.		
<b>IMIN_UP_TCM</b>	<b>Range:</b> _____	<b>OPEN/CLOSED</b>
Position of the gear level - Tip Plus.		
<b>IMS_SRC</b>	<b>Range:</b> _____	<b>not available</b>
Immediate shaft speed.		
<b>ISS</b>	<b>Range:</b> _____	<b>not available</b>
Input shaft speed.		
<b>ISS_DIR</b>	<b>Range:</b> _____	<b>FORWARD/REVERSE</b>
Intermediate shaft direction.		

---

<b>ISS_F</b>	<b>Range:</b> _____	<b>YES FAULT/NO FAULT</b>
		Intermediate shaft speed reliability.
<b>LF_WSPD_TCM</b>	<b>Range:</b> _____	<b>not available</b>
		Left front wheel speed sensor.
<b>LOAD_TCM</b>	<b>Range:</b> _____	<b>not available</b>
		Percentage engine load.
<b>LCP_AMP</b>	<b>Range:</b> _____	<b>not available</b>
		Line pressure control.
<b>M_SDN_A</b>	<b>Range:</b> _____	<b>not available</b>
		Motor shutdown from E-quizzer.
<b>M_SDN_B</b>	<b>Range:</b> _____	<b>not available</b>
		Motor shutdown from vehicle system control.
<b>M_SDN_C</b>	<b>Range:</b> _____	<b>not available</b>
		Motor shutdown from powertrain control module.
<b>MANSW_TCM</b>	<b>Range:</b> _____	<b>OPEN/CLOSED</b>
		Gear level position - manual.
<b>MECH_TCM (°C/°F)</b>	<b>Range:</b> _____	<b>not available</b>
		Motor electronics coolant temperature.
<b>MIL_DIS_TCM</b>	<b>Range:</b> _____	<b>not available</b>
		Distance traveled since the MIL was activated.
<b>MTQ_OUT</b>	<b>Range:</b> _____	<b>not available</b>
		Motor torque from AC source.
<b>MTR_COILTEMP (°C)(°F)</b>	<b>Range:</b> _____	<b>not available</b>
		Motor coil temperature.
<b>MTR_INV_V</b>	<b>Range:</b> _____	<b>not available</b>
		Motor inverter voltage.
<b>MTR_SPEED</b>	<b>Range:</b> _____	<b>not available</b>
		Motor speed in RPM (Rotations Per Minute).

---

<b>MTR_TEMPHI (°C)(°F)</b>	<b>Range:</b> _____	<b>not available</b>
This parameter indicates the motor inverse phase temperature.		
<b>MTR_TORQ_CMD</b>	<b>Range:</b> _____	<b>not available</b>
This parameter indicates the motor torque command.		
<b>NEUTPOS_TCM</b>	<b>Range:</b> _____	<b>YES/NO</b>
Gear level position is neutral.		
<b>ODOMETER_TCM</b>	<b>Range:</b> _____	<b>not available</b>
Indicates the total distance.		
<b>OFMFLG</b>	<b>Range:</b> _____	<b>YES FAULT/NO FAULT</b>
Indicates the pressure control failure mode		
<b>OSS</b>	<b>Range:</b> _____	<b>not available</b>
Output shaft speed.		
<b>OSS_F</b>	<b>Range:</b> _____	<b>YES FAULT/NO FAULT</b>
Reliability of the output shaft speed.		
<b>OSS_DIR</b>	<b>Range:</b> _____	<b>FORWARD/REVERSE</b>
Output shaft direction.		
<b>OSS_TCM</b>	<b>Range:</b> _____	<b>not available</b>
Output shaft speed in RPM.		
<b>OTEMP_FMFLG</b>	<b>Range:</b> _____	<b>YES FAULT/NO FAULT</b>
Transmission over temperature.		
<b>OverdriveCancel</b>	<b>Range:</b> _____	<b>NOT DEPRESSED/DEPRESSED</b>
State of the overdrive cancel switch/hold switch.		
<b>PCA</b>	<b>Range:</b> _____	<b>not available</b>
Pressure control solenoid A.		
<b>PCA_FLT</b>	<b>Range:</b> _____	<b>NO FAULT/FAULT</b>
Pressure control solenoid A.		
<b>PCA_MES</b>	<b>Range:</b> _____	<b>not available</b>
Measured pressure of the transmission PCA.		

<b>PCAA</b>		
Range:	_____	not available
Pressure control solenoid A.		
<b>PCAAMP_MES</b>		
Range:	_____	not available
Measured current PCA.		
<b>PCB</b>		
Range:	_____	not available
Pressure control solenoid B.		
<b>PCBA</b>		
Range:	_____	not available
Pressure control solenoid B.		
<b>PCBAMP_MES</b>		
Range:	_____	not available
Measured current for the transmission PCB.		
<b>PCCAMP_MES</b>		
Range:	_____	not available
Measured current for the PCC.		
<b>PCC</b>		
Range:	_____	not available
Pressure control solenoid C.		
<b>PCC_MES</b>		
Range:	_____	not available
Measured pressure of the PCC.		
<b>PCCA</b>		
Range:	_____	not available
Pressure control solenoid C.		
<b>PCD</b>		
Range:	_____	not available
Shift solenoid pressure control D.		
<b>PCD_FLT</b>		YES FAULT/NO FAULT
Range:	_____	
Indicates the SSPCD status.		
<b>PCD_AMP</b>		
Range:	_____	not available
Shift solenoid pressure control D.		
<b>PCE_AMP</b>		
Range:	_____	not available
Shift solenoid pressure control E.		
<b>PCF</b>		
Range:	_____	not available
Line pressure control		

---

<b>PCF_FLT</b>	<b>Range:</b> _____	<b>YES FAULT/NO FAULT</b>
LPC status.		
<b>PCG</b>	<b>Range:</b> _____	<b>not available</b>
Converter pressure control.		
<b>PCG_FLT</b>	<b>Range:</b> _____	<b>YES FAULT/NO FAULT</b>
Torque converter clutch status.		
<b>PCE</b>	<b>Range:</b> _____	<b>not available</b>
Shift solenoid pressure control E.		
<b>RCL_F</b>	<b>Range:</b> _____	<b>YES FAULT/NO FAULT</b>
Reverse control lamp status.		
<b>PCM_MSG_TCM</b>	<b>Range:</b> _____	<b>PRESENT/NOT PRESENT</b>
CAN message is missing from the PCM.		
<b>PVT_WDS</b>	<b>Range:</b> _____	<b>not available</b>
Pressure vacuum transducer.		
<b>RESPOS_TCM</b>	<b>Range:</b> _____	<b>YES/NO</b>
Gear level position - Reverse.		
<b>RF_WSPD_TCM</b>	<b>Range:</b> _____	<b>not available</b>
Right front wheel speed sensor.		
<b>RPM_DSD_TCM</b>	<b>Range:</b> _____	<b>not available</b>
Desired idle speed (RPM).		
<b>RPM_TCM</b>	<b>Range:</b> _____	<b>not available</b>
Engine rpm (revolutions per minute).		
<b>RPM_TCM_HEV</b>	<b>Range:</b> _____	<b>not available</b>
Shift position.		
<b>SHIFT_POS</b>	<b>Range:</b> _____	<b>not available</b>
Status of the transmission control indicator light.		
<b>SHFT_TYP</b>	<b>Range:</b> _____	<b>not available</b>
Shift type.		

---

**SLIP\_DES\_SCP**

Range: \_\_\_\_\_ not available

Desired torque converter slip.

**SSA\_AMP**

Range: \_\_\_\_\_ not available

Shift solenoid pressure control A.

**SSAFM**

Range: \_\_\_\_\_ YES/NO

Shift solenoid 1 status.

**SSB\_AMP**

Range: \_\_\_\_\_ not available

Shift solenoid pressure control B.

**SSB\_SS1**

Range: \_\_\_\_\_ ON/OFF

Shift solenoid 1.

**SSB\_SS2**

Range: \_\_\_\_\_ ON/OFF

Shift solenoid 2.

**SSBFM**

Range: \_\_\_\_\_ YES/NO

Shift solenoid 2 status.

**SSC\_AMP**

Range: \_\_\_\_\_ not available

Shift solenoid pressure control C.

**SSE**

Range: \_\_\_\_\_ not available

Shift solenoid pressure control E.

**SSPCA**

Range: \_\_\_\_\_ not available

Shift solenoid pressure control A.

**SSPCA\_FLT**

Range: \_\_\_\_\_ NO FAULT/FAULT

SSPCA status.

**SSPCB**

Range: \_\_\_\_\_ not available

Shift solenoid pressure control B.

**SSPCB\_FLT**

Range: \_\_\_\_\_ NO FAULT/FAULT

SSPCB status.

**SSPCC**

Range: \_\_\_\_\_ not available

Shift solenoid pressure control C.

---

<b>SSPCC_FLT</b>	<b>Range:</b> _____	<b>NO FAULT/FAULT</b>
SSPCC status.		
<b>TC_SLIP</b>	<b>Range:</b> _____	<b>not available</b>
Rpm of the torque converter slip actual.		
<b>TCC</b>	<b>Range:</b> _____	<b>not available</b>
Torque converter clutch (modulatED).		
<b>TCCAMP_MES</b>	<b>Range:</b> _____	<b>not available</b>
Measured current for the TCC pressure control.		
<b>TCC_FLT</b>	<b>Range:</b> _____	<b>YES FAULT/NO FAULT</b>
Status of the torque converter clutch fault.		
<b>TCC_OSC</b>	<b>Range:</b> _____	<b>not available</b>
Output state control of the torque converter.		
<b>TCC_SLIP_DSD</b>	<b>Range:</b> _____	<b>not available</b>
Desired torque converter slip.		
<b>TCIL</b>	<b>Range:</b> _____	<b>ON/OFF</b>
Status of the transmission control indicator light.		
<b>TCIL_FLT</b>	<b>Range:</b> _____	<b>YES FAULT/NO FAULT</b>
Transmission control indicator light.		
<b>TCM_CAUTION</b>	<b>Range:</b> _____	<b>ON/OFF</b>
Status of the transmission control module caution.		
<b>TCM_HAZ</b>	<b>Range:</b> _____	<b>ON/OFF</b>
Transmission control module hazard warning.		
<b>TCS</b>	<b>Range:</b> _____	<b>NOT DEPRESSED/DEPRESSED</b>
Status of the overdrive cancel switch/hold switch.		
<b>TFT (°C/°F)</b>	<b>Range:</b> _____	<b>not available</b>
Transmission fluid temperature.		
<b>TIP_MIN_TCM</b>	<b>Range:</b> _____	<b>OPEN/CLOSED</b>
Gear level position - Tip Minus.		

---

**TIP\_PL\_TCM**

Range: \_\_\_\_\_ OPEN/CLOSED

Gear level position - Tip Plus.

**TORQUE**

Range: \_\_\_\_\_ not available

Net engine torque.

**TORQUE\_DSD****TORQ\_DSD**

Range: \_\_\_\_\_ not available

Desired total torque.

**TORQUE\_TCM**

Range: \_\_\_\_\_ not available

Net engine torque.

**TOT\_ENG (°C/F)**

Range: \_\_\_\_\_ not available

Transmission fluid temperature.

**TOTF**

Range: \_\_\_\_\_ YES FAULT/NO FAULT

Transmission fluid temperature status.

**TOWHAUL**

Range: \_\_\_\_\_ ON/OFF

Tow haul switch.

**TP\_PER**

Range: \_\_\_\_\_ not available

Throttle position in percentage.

**TP\_REL\_TCM**

Range: \_\_\_\_\_ not available

Relative throttle position.

**TR****TR\_FREQ(Hz)****TTR\_DC****TR\_V**

Range: \_\_\_\_\_ not available

Indicate the transmission range.

**TRAN\_TEMP (°C/F)**

Range: \_\_\_\_\_ not available

Indicates the transmission oil temperature.

**TRFM**

Range: \_\_\_\_\_ YES FAULT/NO FAULT

Indicates the transmission range status.

**TRO\_N\_F**

Range: \_\_\_\_\_ YES FAULT/NO FAULT

Neutral output status.

---

<b>TRO_P_F</b>	<b>Range:</b> _____	<b>YES FAULT/NO FAULT</b>
Park output status.		
<b>TSES_TCM</b>	<b>Range:</b> _____	<b>CLOCKTIME</b>
Time since start in seconds.		
<b>TSLIPRAT</b>	<b>Range:</b> _____	<b>not available</b>
Transmission slip ratio.		
<b>TSFMFLG_TCM</b>	<b>Range:</b> _____	<b>YES FAULT/NO FAULT</b>
Status of the turbine speed sensor failure mode.		
<b>TSS</b>	<b>Range:</b> _____	<b>not available</b>
Turbine shaft speed.		
<b>TSS_F</b>	<b>Range:</b> _____	<b>YES FAULT/NO FAULT</b>
Turbine shaft speed reliability.		
<b>TSS_TCM</b>	<b>Range:</b> _____	<b>not available</b>
Turbine shaft speed.		
<b>TQ_CNTL</b>	<b>Range:</b> _____	<b>not available</b>
Torque fuel/spark limiting status.		
<b>VAR_CMD</b>	<b>Range:</b> _____	<b>not available</b>
Commanded variator ratio (input speed/output speed).		
<b>VAR_MES</b>	<b>Range:</b> _____	<b>not available</b>
Measured variator ratio (input speed/output speed).		
<b>VEH_CTRL</b>	<b>Range:</b> _____	<b>not available</b>
Vehicle control mode.		
<b>VOLT_SENSR</b>	<b>Range:</b> _____	<b>not available</b>
Sensor supply voltage.		
<b>VPWR_TCM</b>	<b>Range:</b> _____	<b>not available</b>
Module supply voltage.		
<b>VS_SRC</b>	<b>Range:</b> _____	<b>not available</b>
Transfer case sensor.		

---

<b>VSFMFLG</b>		
Range:	_____	<b>YES FAULT/NO FAULT</b>
Vehicle speed sensor signal status.		
<b>VSS_F</b>		
Range:	_____	<b>YES FAULT/NO FAULT</b>
Vehicle speed sensor reliability.		
<b>VSS_TCM</b>		
Range:	_____	<b>not available</b>
Vehicle speed.		
<b>VSS_TCM_HEV</b>		
Range:	_____	<b>not available</b>
Vehicle speed.		
<b>VSS_TCM_HR</b>		
Range:	_____	<b>not available</b>
Vehicle speed - high resolution.		
<b>WARMUPDTC_TCM</b>		
Range:	_____	<b>not available</b>
Number of warm-ups since the DTCs were cleared.		

---

## Tire Pressure Monitor (TPM) Parameters

<b>CCNT_TPMS</b>	<b>Range:</b> _____	<b>not available</b>
Indicates continuous codes.		
<b>HORN TPM</b>	<b>Range:</b> _____	<b>ACTIVE/INACTIVE</b>
Indicates horn output.		
<b>LAST_ID</b>	<b>Range:</b> _____	<b>not available</b>
Indicates the last received tire transmitter ID code value.		
<b>LF_ID</b>	<b>Range:</b> _____	<b>not available</b>
Indicates the left front tire transmitter identifier.		
<b>LF_LRN</b>	<b>Range:</b> _____	<b>ACTIVE/INACTIVE</b>
Indicates the left front learn status.		
<b>LF_MES</b>	<b>Range:</b> _____	<b>ACTIVE/INACTIVE</b>
Left front re-measure status.		
<b>LF_NORM</b>	<b>Range:</b> _____	<b>ACTIVE/INACTIVE</b>
Left front normal status.		
<b>LF_PSI</b>	<b>Range:</b> _____	<b>not available</b>
Left front tire pressure.		
<b>LF_REC</b>	<b>Range:</b> _____	<b>YES/NO</b>
Left front transmit has been received after learn.		
<b>LFAWAKE</b>	<b>Range:</b> _____	<b>not available</b>
Left front awake status.		
<b>LFIDPRG</b>	<b>Range:</b> _____	<b>YES/NO</b>
Left front sensor programmed.		
<b>LFLOBAT</b>	<b>Range:</b> _____	<b>LOW/OK</b>
Left front low battery.		
<b>LR_ID</b>	<b>Range:</b> _____	<b>not available</b>
Left rear tire transmitter identifier.		
<b>LR_LRN</b>	<b>Range:</b> _____	<b>ACTIVE/INACTIVE</b>
Left rear learn status.		

<b>LR_MES</b>		
Range:	_____	ACTIVE/INACTIVE
	Right rear re-measure status.	
<b>LR_NORM</b>		
Range:	_____	ACTIVE/INACTIVE
	Left rear normal status.	
<b>LR_REC</b>		
Range:	_____	YES/NO
	Left rear transmit has been received after learn.	
<b>LRAWAKE</b>		
Range:	_____	not available
	Left rear awake status.	
<b>LRIDPRG</b>		
Range:	_____	YES/NO
	Left rear sensor programmed.	
<b>LRLOBAT</b>		
Range:	_____	LOW/OK
	Left rear low battery.	
<b>LRO_PSI</b>		
Range:	_____	not available
	Left rear outer tire pressure.	
<b>RESET</b>		
Range:	_____	ACTIVE/INACTIVE
	Parameter reset command.	
<b>RF_ID</b>		
Range:	_____	not available
	Right front tire transmitter identifier.	
<b>RF_REC</b>		
Range:	_____	YES/NO
	Right front transmit bas been received after learn.	
<b>RF_LRN</b>		
Range:	_____	ACTIVE/INACTIVE
	Right front learn status.	
<b>RF_MES</b>		
Range:	_____	ACTIVE/INACTIVE
	Right front re-measure status.	
<b>RF_NORM</b>		
Range:	_____	ACTIVE/INACTIVE
	Right front normal status.	
<b>RF_PSI</b>		
Range:	_____	not available
	Right front tire pressure.	

---

<b>RFAWAKE</b>	<b>Range:</b> _____	<b>not available</b>
Right front awake status.		
<b>RFIDPRG</b>	<b>Range:</b> _____	<b>YES/NO</b>
Right front sensor programmed.		
<b>RFLOBAT</b>	<b>Range:</b> _____	<b>LOW/OK</b>
Right front low battery.		
<b>RR_ID</b>	<b>Range:</b> _____	<b>not available</b>
Right rear tire transmitter identifier.		
<b>RR_LRN</b>	<b>Range:</b> _____	<b>ACTIVE/INACTIVE</b>
Right rear learn status.		
<b>RR_MES</b>	<b>Range:</b> _____	<b>ACTIVE/INACTIVE</b>
Right rear re-measure status.		
<b>RR_NORM</b>	<b>Range:</b> _____	<b>ACTIVE/INACTIVE</b>
Right rear normal status.		
<b>RR_REC</b>	<b>Range:</b> _____	<b>YES/NO</b>
Right rear transmit has been received after learn.		
<b>RRAWAKE</b>	<b>Range:</b> _____	<b>not available</b>
Right rear awake status.		
<b>RRIDPRG</b>	<b>Range:</b> _____	<b>YES/NO</b>
Right rear sensor programmed.		
<b>RRLOBAT</b>	<b>Range:</b> _____	<b>LOW/OK</b>
Right rear low battery.		
<b>RRO_PSI</b>	<b>Range:</b> _____	<b>not available</b>
Right rear outer tire pressure.		
<b>SP_LRN</b>	<b>Range:</b> _____	<b>ACTIVE/INACTIVE</b>
Spare learn status.		
<b>SP_MES</b>	<b>Range:</b> _____	<b>ACTIVE/INACTIVE</b>
Spare re-measure status.		

---

**SP\_NORM**

Range: \_\_\_\_\_ ACTIVE/INACTIVE

Spare normal status.

**SP\_REC**

Range: \_\_\_\_\_ YES/NO

Spare transmit has been received after learn.

**SPAWAKE**

Range: \_\_\_\_\_ not available

Spare awake status.

**SPIDPRG**

Range: \_\_\_\_\_ YES/NO

Spare sensor programmed.

**SPLOBAT**

Range: \_\_\_\_\_ ACTIVE/INACTIVE

Spare low battery.

**SPR\_ID**

Range: \_\_\_\_\_ not available

Spare tire transmitter identifier.

**SPR\_PSI**

Range: \_\_\_\_\_ not available

Spare tire pressure.

**VSS TPM**

Range: \_\_\_\_\_ not available

Vehicle speed.

**WARN\_1**

Range: \_\_\_\_\_ not available

Transmitter identifier with warning value 1.

**WARN\_2**

Range: \_\_\_\_\_ not available

Transmitter identifier with warning value 2.

**WARN\_3**

Range: \_\_\_\_\_ not available

Transmitter identifier with warning value 3.

**WARN\_4**

Range: \_\_\_\_\_ not available

Transmitter identifier with warning value 4.

**WARN\_5**

Range: \_\_\_\_\_ not available

Transmitter identifier with warning value 5.