


JSDAP series



Driving & Connecting Globally



■ Warning and Caution:



Warning

- Do not proceed to the assembly of the line while electrifying.
- Circuit & change components between entering shutting down the power supply and stopping showing CHARGE LED light of the Servo driver.
- The output of Servo drive [U, V, W] must NOT touch the AC power.
- Motor over temperature protection is not provided.



Caution

- Install the fan if the temperature around is too high while the Servo driver is installed in the Control Board.
- Do not proceed to the Anti-Pressure-Test to the Servo driver.
- Confirm the quick stop function is available before operate servo drive.
- Matching up machine to change the user parameter setting before machine performs. If there is no according correct setting number, it could lead to out of control or breakdown.

Safety proceeding:

Check the covering letter detail before installing, running, maintaining and examining. Furthermore, only the profession-qualified people can proceed to the line-assembly.

Safety proceeding in the covering letter discriminate between "Warning" & "Alert".



Warning

Indicate the possibility dangerous situation. It could cause the death or serious damage if being ignored.



Caution

Indicate the possibility dangerous situation. It could cause smaller or lighter human injured and damage of equipment.

Read this covering letter detail before using Servo driver.

First of all, thank you for using TECO Servo Driver JSDAP Series (“JSDAP” for short) and Servo Motors. JSDAP can be controlled by digital board or PC, and provide excellent performance for a wide range of applications and different requirement from customers.

Read this covering letter before using JSDAP. Contents of the letter comprise:

- **Servo System checking, installing and procedure of assembly line.**
- **Controller procedure for digital board, status displaying, unusual alarm and strategy explanation.**
- **Servo System control function, running testing and procedures adjusted.**
- **Explanation for all parameter of Servo Driver.**
- **Standard specification of JSDAP Series.**

In order to daily examine, maintain and understand the reason of unusual situation and handle strategy, please put this covering letter in safe place to read it anytime.

P.S: The end user should own this covering letter, in order to make the Servo Driver bring the best performance.

Table of Contents

Chapter 1 Checking and Installing

1-1 Checking Products.....	1-1
1-1-1 Confirming with Servo Drives.....	1-1
1-1-2 Confirming with Servo motors.....	1-2
1-1-3 Servo motor Model Code display.....	1-3
1-2 Surface and Panel Board.....	1-11
1-3 A Brief Introduction of Operation for Drives.....	1-15
1-4 Conditions for Installation of Drives.....	1-16
1-4-1 Environmental Conditions.....	1-16
1-4-2 Direction and Distance.....	1-17
1-5 Conditions for Installation of Servomotors.....	1-18
1-5-1 Environmental Conditions.....	1-18
1-5-2 Method of Installation.....	1-18
1-5-3 Notice for install motor.....	1-19

Chapter 2 Wiring

2-1 Basic Wiring for Servo System.....	2-1
2-1-1 Wiring for Main Circuit and Peripheral Devices.....	2-1
2-1-2 Wiring for Servo Drives.....	2-3
2-1-3 Specifications of Wiring.....	2-4
2-1-4 Motor Terminal Layout.....	2-6
2-1-5 TB Terminal.....	2-9
2-1-6 Wiring for Mechanical Brake.....	2-10
2-1-7 MCCB/Fuse/Filter Recommended Specification.....	2-10
2-2 I/O Terminal.....	2-11
2-2-1 Output Signals from the Servo pack.....	2-12
2-2-2 Encoder Connector (CN2) Terminal Layout.....	2-24
2-2-3 CN3/CN4 Communication Terminal Layout.....	2-26
2-3 Typical Circuit Wiring Examples.....	2-27
2-3-1 Position Control Mode (Pe Mode) (Line Driver).....	2-27
2-3-2 Position Control Mode (Pe Mode) (Open Collector).....	2-28
2-3-3 Position Control Mode (Pi Mode)	2-29
2-3-4 Speed Control Mode (S Mode).....	2-30
2-3-5 Torque Control Mode (T Mode).....	2-31
2-3-6 Turret Mode (Pt Mode).....	2-32

Chapter 3 Panel Operator / Digital Operator

3-1 Panel Operator on the Drives.....	3-1
3-2 Signal Display.....	3-8
3-2-1 Status Display.....	3-8
3-2-2 Diagnostic function.....	3-10

Chapter 4 Trial Operation

4-1 Trial Operation for Servomotor without Load.....	4-2
4-2 Trial Operation for Servomotor without Load from Host Reference.....	4-5
4-3 Trial Operation with the Servomotor Connected to the Machine.....	4-9

Chapter 5 Control Functions

5-1 Control Mode Selection.....	5-1
5-2 Torque Mode.....	5-2
5-2-1 Analog Torque command Ratio.....	5-2
5-2-2 Analog Speed Limit Proportion.....	5-3
5-2-3 Adjusting the Analog Torque Command Offset.....	5-3
5-2-4 Torque Command Linear Acceleration and Deceleration.....	5-4
5-2-5 Definition of Torque Direction.....	5-5
5-2-6 Internal Torque Limit.....	5-6
5-2-7 Limiting Servomotor Speed during Torque Control.....	5-7
5-2-8 Additional Torque Control Functions.....	5-8
5-3 Speed Mode.....	5-9
5-3-1 Selection for Speed Command.....	5-10
5-3-2 Analog Speed Command Ratio.....	5-11
5-3-3 Adjusting the Analog Reference Offset.....	5-11
5-3-4 Analog Reference for Speed Command Limit.....	5-12
5-3-5 Encoder Signal Output.....	5-12
5-3-6 Smoothing the Speed Command.....	5-14
5-3-7 Setting Rotation Direction.....	5-17
5-3-8 Speed Loop Gain.....	5-18
5-3-9 Notch Filter.....	5-19
5-3-10 Torque Limit of Speed Control Mode.....	5-20
5-3-11 Gain Switched.....	5-21
5-3-12 Other Functions.....	5-28
5-4 Position Mode.....	5-30
5-4-1 External Pulse Command.....	5-31
5-4-2 Internal Position Command.....	5-33
5-4-3 Electronic Gear.....	5-37
5-4-4 Smoothing Acceleration.....	5-41
5-4-5 Definition of Direction.....	5-44
5-4-6 Gain Adjustment.....	5-44
5-4-7 Clear the Pulse Offset.....	5-45
5-4-8 Homing Function.....	5-46
5-4-9 Other Position Functions.....	5-55
5-5 Gain Adjustment.....	5-56
5-5-1 Automatic Gain Adjustment.....	5-59
5-5-2 Manual Gain Adjustment.....	5-67
5-5-3 Improving Resonance.....	5-68
5-6 Other Functions.....	5-69

5-6-1 Programmable I/O Functions.....	5-69
5-6-2 Switch for the Control Mode.....	5-72
5-6-3 Auxiliary Functions.....	5-72
5-6-4 Brake Mode.....	5-73
5-6-5 Timing Diagram of Mechanical Brake.....	5-73
5-6-6 CW/CCW Drive Inhibit Function.....	5-75
5-6-7 Selecting for External Regeneration Resistor.....	5-76
5-6-8 Fan Setting.....	5-80
5-6-9 Low Voltage Protection Auto-reset.....	5-80
5-6-10 Absolute Encoder Battery Fault.....	5-80
5-6-11 Analog Monitor.....	5-81
5-6-12 Factory Setting Parameter.....	5-82
5-7 Tool Turret Modes.....	5-83
5-7-1 Parameter Setting.....	5-83
5-7-2 Rigidity Setting.....	5-86
5-7-3 Tool Turret Mode Setting Flow Chart.....	5-87
5-7-4 Timing Diagram of Tool Turret Homing.....	5-88
5-7-5 Timing Diagram of Auto-selection Mode.....	5-89
5-7-6 Timing Diagram of JOG Mode.....	5-90

Chapter 6 Parameters

6-1 Explanation of Parameter Groups.....	6-1
6-2 Parameter Display Table.....	6-2

Chapter 7 Communications Function

7-1 Communications Function (RS232 & RS485).....	7-1
7-1-1 Communication Wiring.....	7-1
7-1-2 RS232 Communication Protocol and Format.....	7-5
7-1-3 Modbus Communication Protocol for RS485.....	7-7

Chapter 8 Troubleshooting

8-1 Alarm Functions.....	8-1
8-2 Troubleshooting of Alarm and Warning.....	8-3
8-3 Alarm Status Description.....	8-6

Chapter 9 Specifications

9-1 Specifications and Dimension for Servo Drives.....	9-1
9-2 Specifications and Dimension for Servomotors.....	9-6

Appendix A Accessories.....	A-1
------------------------------------	------------

Appendix B Battery Module.....	B-1
---------------------------------------	------------

Chapter 1 Checking and Installing


1-1 Checking Products

Our Servo Pack have already completely been functionally examined before leaving the factory. In order to protect the products from the damage during transportation, please check the items below before sealing off the pack:

- Check if the models of servo driver and motor are the same with the models of ordering.
(About the model explanation, please check the chapters below)
- Check if there are damage or scrape out side of the servo driver and motor.
(If there is any damage during transportation, do not power ON)
- Check if there are any bad assembly or slipped component in the Servo Drive and Motor
- Check if the Motor's rotor and shaft can be rotated smoothly by hand
(The Servo Motor with Mechanical-Brake can not be rotated directly)
- There must be the "QC"-seal in each servo drive, if not, please do not proceed Power ON.

If there is any bug or irregular under the situation above, please contact TECO's Local sales representative or distributor instantly.


1-1-1 Confirming with Servo Drives



Notes: Maximum output power

200V class		400V class
10A(1) : 100 W	75A3 : 3.0 KW	25B : 2.0 KW
15A(1) : 400 W	100A3 : 4.4 KW	35B : 3.0 KW
20A : 750 W	150A3 : 5.5 KW	50B : 4.4 KW
30A : 1.0 KW	200A3 : 7.5 KW	75B : 5.5 KW
50A3 : 2.0 KW	300A3 : 15 KW	100B : 7.5 KW

1-1-2 Confirming with Servo Motors



1-1-3 Servo motor Model Code display

dn-08 (Servo motor Model Code display)

Use dn-08 to display servo motor code and check the servo drive and motor compatibility according to the table below. If the collocation is discordant with that dn08 presented, reset parameter Cn030 or contact your supplier. The motor model code is stored in parameter Cn030.

200V Class

dn-08 Display Cn030 Setting	Drive Model JSDAP	Motor Model	Motor Standards		Encoder Specification
			Watt(KW)	Speed(rpm)	
H1011	10A(1)	JSMA-(P)SCP5AB	0.05	3000	2500
H1015		JSMA-PSCP5A5			15 bit(ABS)
H1017		JSMA-PSCP5A7			17 bit
H101A		JSMA-PSCP5AA			17 bit(ABS)
H1021		JSMA- (P)SC01AB	0.1	3000	2500
H1025		JSMA-PSC01A5			15 bit(ABS)
H1027		JSMA-PSC01A7			17 bit
H102A		JSMA-PSC01AA			17 bit(ABS)
H1101	15A(1)	JSMA-PSC02AB	0.2	3000	2500
H1102		JSMA-PSC02AH			8192
H1105		JSMA-PSC02A5			15 bit(ABS)
H1107		JSMA-PSC02A7			17 bit
H110A		JSMA-PSC02AA			17 bit(ABS)
H1111		JSMA- (P)SC01AB	0.1	3000	2500
H1115		JSMA-PSC01A5			15 bit(ABS)
H1117		JSMA-PSC01A7			17 bit
H111A		JSMA-PSC01AA			17 bit(ABS)

dn-08 Display Cn030 Setting	Drive Model JSDAP	Motor Model	Motor Standards		Encoder Specification
			Watt(KW)	Speed(rpm)	
H1121	15A(1)	JSMA-PLC03AB	0.3	3000	2500
H1122		JSMA-PLC03AH			8192
H1125		JSMA-PLC03A5			15 bit(ABS)
H1127		JSMA-PLC03A7			17 bit
H112A		JSMA-PLC03AA			17 bit(ABS)
H1141	15A(1)	JSMA-SC04AB	0.4 (rated 3.5A)	3000	2500
H1142		JSMA-SC04AH			8192
H1145		JSMA-SC04A5			15 bit(ABS)
H1147		JSMA-SC04A7			17 bit
H114A		JSMA-SC04AA			17 bit(ABS)
H1151		JSMA- (P)SC04AB	0.4 (rated 2.5A)	3000	2500
H1152		JSMA- (P)SC04AH			8192
H1155		JSMA-PSC04A5			15 bit(ABS)
H1157		JSMA-PSC04A7			17 bit
H115A		JSMA-PSC04AA			17 bit(ABS)
H1211	20A	JSMA-PLC08AB	0.75	3000	2500
H1212		JSMA-PLC08AH			8192
H1215		JSMA-PLC08A5			15 bit(ABS)
H1217		JSMA-PLC08A7			17 bit
H121A		JSMA-PLC08AA			17 bit(ABS)
H1221		JSMA-SC04AB	0.4 (rated 3.5A)	3000	2500
H1222		JSMA-SC04AH			8192
H1225		JSMA-SC04A5			15 bit(ABS)
H1227		JSMA-SC04A7			17 bit
H122A		JSMA-SC04AA			17 bit(ABS)

dn-08 Display Cn030 Setting	Drive Model JSDAP	Motor Model	Motor Standards		Encoder Specification
			Watt(KW)	Speed(rpm)	
H1231	20A	JSMA- (P)SC08AB	0.75	3000	2500
H1232		JSMA-PSC08AH			8192
H1235		JSMA-PSC08A5			15 bit(ABS)
H1237		JSMA-PSC08A7			17 bit
H123A		JSMA-PSC08AA			17 bit(ABS)
H1241		JSMA-PMA05AB	0.55	1000	2500
H1252		JSMA-PMH05AH		1500	8192
H1255		JSMA-PMH05A5			15 bit(ABS)
H1257		JSMA-PMH05A7			17 bit
H125A		JSMA-PMH05AA			17 bit(ABS)
H1261	30A	JSMA- (P)SC04AB	0.4 (rated2.5A)	3000	2500
H1262		JSMA- (P)SC04AH			8192
H1265		JSMA-PSC04A5			15 bit(ABS)
H1267		JSMA-PSC04A7			17 bit
H126A		JSMA-PSC04AA			17 bit(ABS)
H1311	30A	JSMA- (P)SC08AB	0.75	3000	2500
H1312		JSMA-PSC08AH			8192
H1315		JSMA-PSC08A5			15 bit(ABS)
H1317		JSMA-PSC08A7			17 bit
H131A		JSMA-PSC08AA			17 bit(ABS)
H1321	30A	JSMA-PMA10AB	1.0	1000	2500
H1322		JSMA-PMA10AH			8192
H1325		JSMA-PMA10A5			15 bit(ABS)
H1327		JSMA-PMA10A7			17 bit

dn-08 Display Cn030 Setting	Drive Model JSDAP	Motor Model	Motor Standards		Encoder Specification
			Watt(KW)	Speed(rpm)	
H132A	30A	JSMA-PMA10AA	1.0	1000	17 bit(ABS)
H1331		JSMA-PMB10AB		2500	
H1332		JSMA-PMB10AH		8192	
H1335		JSMA-PMB10A5		2000	15 bit(ABS)
H1337		JSMA-PMB10A7		17 bit	
H133A		JSMA-PMB10AA			17 bit(ABS)
H1341		JSMA-PMH10AB		2500	
H1342		JSMA-PMH10AH	1500	8192	
H1345		JSMA-PMH10A5		15 bit(ABS)	
H1347		JSMA-PMH10A7		17 bit	
H134A		JSMA-PMH10AA		17 bit(ABS)	
H1351		JSMA-PMC10AB	1.0	2500	
H1352		JSMA-PMC10AH		8192	
H1355		JSMA-PMC10A5		3000	15 bit(ABS)
H1357		JSMA-PMC10A7		17 bit	
H135A		JSMA-PMC10AA		17 bit(ABS)	

dn-08 Display Cn030 Setting	Drive Model JSDAP	Motor Model	Motor Standards		Encoder Specification
			Watt(KW)	Speed(rpm)	
H1511	50A3	JSMA-PMA15AB	1000	2500 8192 15 bit(ABS) 17 bit	2500
H1512		JSMA-PMA15AH			8192
H1515		JSMA-PMA15A5			15 bit(ABS)
H1517		JSMA-PMA15A7			17 bit
H151A		JSMA-PMA15AA			17 bit(ABS)
H1521		JSMA-PMB15AB			2500
H1522		JSMA-PMB15AH			8192
H1525		JSMA-PMB15A5	2000	15 bit(ABS) 17 bit	15 bit(ABS)
H1527		JSMA-PMB15A7			17 bit
H152A		JSMA-PMB15AA			17 bit(ABS)
H1531		JSMA-PMC15AB			2500
H1532	50A3	JSMA-PMC15A5H	3000	15 bit(ABS) 17 bit	8192
H1535		JSMA-PMC15A5			15 bit(ABS)
H1537		JSMA-PMC15A7			17 bit
H153A		JSMA-PMC15AA			17 bit(ABS)
H1541		JSMA-PMB20AB	2000	2500 8192 15 bit(ABS) 17 bit	2500
H1542		JSMA-PMB20AH			8192
H1545		JSMA-PMB20A5			15 bit(ABS)
H1547		JSMA-PMB20A7			17 bit
H154A		JSMA-PMB20AA			17 bit(ABS)
H1551	50A3	JSMA-PMC20AB	3000	2500 8192 15 bit(ABS) 17 bit	2500
H1552		JSMA-PMC20AH			8192
H1555		JSMA-PMC20A5			15 bit(ABS)
H1557		JSMA-PMC20A7			17 bit
H155A		JSMA-PMC20AA			17 bit(ABS)

dn-08 Display Cn030 Setting	Drive Model JSDAP	Motor Model	Motor Standards		Encoder Specification
			Watt(KW)	Speed(rpm)	
H1711	75A3	JSMA-PMB30AB	3.0	2000	2500
H1712		JSMA-PMB30AH			8192
H1715		JSMA-PMB30A5			15 bit(ABS)
H1717		JSMA-PMB30A7	2000	2000	17 bit
H171A		JSMA-PMB30AA			17 bit(ABS)
H1721		JSMA-PMC30AB			2500
H1722		JSMA-PMC30AH			8192
H1725		JSMA-PMC30A5	3.0	3000	15 bit(ABS)
H1727		JSMA-PMC30A7			17 bit
H172A		JSMA-PMC30AA			17 bit(ABS)
H1732		JSMA-PMH30AH	1500	1500	8192
H1735		JSMA-PMH30A5			15 bit(ABS)
H1737		JSMA-PMH30A7			17 bit
H173A		JSMA-PMH30AA			17 bit(ABS)
H1822	100A3	JSMA-PMH44AH	4.4	1500	8192
H1825		JSMA-PMH44A5			15 bit(ABS)
H1827		JSMA-PMH44A7			17 bit
H182A		JSMA-PMH44AA			17 bit(ABS)
H1832		JSMA-PHH30AH	3.0	1500	8192
H1835		JSMA-PHH30A5			15 bit(ABS)
H1837		JSMA-PHH30A7			17 bit
H183A		JSMA-PHH30AA			17 bit(ABS)
H1922	150A3	JSMA-PMH55AH	5.5	1500	8192
H1925		JSMA-PMH55A5			15 bit(ABS)
H1927		JSMA-PMH55A7	3.0	1500	17 bit
H192A		JSMA-PMH55AA			17 bit(ABS)

dn-08 Display Cn030 Setting	Drive Model JSDAP	Motor Model	Motor Standards		Encoder Specification	
			Watt(KW)	Speed(rpm)		
H1932	150A3	JSMA-PHH44AH	4.4	2000	8192	
H1935		JSMA-PHH44A5			15 bit(ABS)	
H1937		JSMA-PHH44A7			17 bit	
H193A		JSMA-PHH44AA			17 bit(ABS)	
H1A12	200A3	JSMA-PMH75AH	7.5	Watt(KW)	Speed(rpm)	
H1A15		JSMA-PMH75A5			15 bit(ABS)	
H1A17		JSMA-PMH75A7			17 bit	
H1A1A		JSMA-PMH75AA	7.5		17 bit(ABS)	
H1A22		JSMA-PHH55AH	5.5		8192	
H1A25		JSMA-PHH55A5			15 bit(ABS)	
H1A27		JSMA-PHH55A7			17 bit	
H1A2A		JSMA-PHH55AA			17 bit(ABS)	
H1B12	300A3	JSMA-PMH110AH	11.0	1500	8192	
H1B15		JSMA-PMH110A5			15 bit(ABS)	
H1B17		JSMA-PMH110A7			17 bit	
H1B1A		JSMA-PMH110AA			17 bit(ABS)	
H1B22		JSMA-PMH150AH	15.0		8192	
H1B25		JSMA-PMH150A5			15 bit(ABS)	
H1B27		JSMA-PMH150A7			17 bit	
H1B2A		JSMA-PMH150AA			17 bit(ABS)	
H1B32		JSMA-PHH75AH	7.5		8192	
H1B35		JSMA-PHH75A5			15 bit(ABS)	
H1B37		JSMA-PHH75A7			17 bit	
H1B3A		JSMA-PHH75AA			17 bit(ABS)	

400V


dn-08 Display Cn030 Setting	Drive Model JSDAP	Motor Model	Motor Standards		Encoder Specification
			Watt(KW)	Speed(rpm)	
H1211	25B	JSMA-PMB10BB	1.0	2000	2500
H1212		JSMA-PMB10BH			8192
H1215		JSMA-PMB10B5			15 bit(ABS)
H1217		JSMA-PMB10B7			17 bit
H121A		JSMA-PMB10BA			17 bit(ABS)
H1231		JSMA-PMB15BB	1.5	2000	2500
H1232		JSMA-PMB15BH			8192
H1235		JSMA-PMB15B5			15 bit(ABS)
H1237		JSMA-PMB15B7			17 bit
H123A		JSMA-PMB15BA			17 bit(ABS)
H1251	35B	JSMA-PMB20BB	2.0	2000	2500
H1252		JSMA-PMB20BH			8192
H1255		JSMA-PMB20B5			15 bit(ABS)
H1257		JSMA-PMB20B7			17 bit
H125A		JSMA-PMB20BA			17 bit(ABS)
H1311	35B	JSMA-PMB20BB	2.0	2000	2500
H1312		JSMA-PMB20BH			8192
H1315		JSMA-PMB20B5			15 bit(ABS)
H1317		JSMA-PMB20B7			17 bit
H131A		JSMA-PMB20BA			17 bit(ABS)
H1331	3.0	JSMA-PMB30BB	3.0	2000	2500
H1332		JSMA-PMB30BH			8192
H1335		JSMA-PMB30B5			15 bit(ABS)
H1337		JSMA-PMB30B7			17 bit
H133A		JSMA-PMB30BA			17 bit(ABS)

dn-08 Display Cn030 Setting	Drive Model JSDAP	Motor Model	Motor Standards		Encoder Specification
			Watt(KW)	Speed(rpm)	
H1341	35B	JSMA-PMH30BB	3.0	1500	2500
H1342		JSMA-PMH30BH			8192
H1345		JSMA-PMH30B5			15 bit(ABS)
H1347		JSMA-PMH30B7			17 bit
H134A		JSMA-PMH30BA			17 bit(ABS)
H1401	50B	JSMA-PMB30BB	3.0	2000	2500
H1402		JSMA-PMB30BH			8192
H1405		JSMA-PMB30B5			15 bit(ABS)
H1407		JSMA-PMB30B7			17 bit
H140A		JSMA-PMB30BA			17 bit(ABS)
H1411	50B	JSMA-PMH30BB	3.0	1500	2500
H1412		JSMA-PMH30BH			8192
H1415		JSMA-PMH30B5			15 bit(ABS)
H1417		JSMA-PMH30B7			17 bit
H141A		JSMA-PMH30BA			17 bit(ABS)
H1421	75B	JSMA-PMH44BB	4.4	1500	2500
H1422		JSMA-PMH44BH			8192
H1425		JSMA-PMH44B5			15 bit(ABS)
H1427		JSMA-PMH44B7			17 bit
H142A		JSMA-PMH44BA			17 bit(ABS)
H1501	75B	JSMA-PMH44BB	4.4	1500	2500
H1502		JSMA-PMH44BH			8192
H1505		JSMA-PMH44B5			15 bit(ABS)
H1507		JSMA-PMH44B7			17 bit


dn-08 Display Cn030 Setting	Drive Model JSDAP	Motor Model	Motor Standards		Encoder Specification
			Watt(KW)	Speed(rpm)	
H150A	75B	JSMA-PMH44BA	4.4	1500	17 bit(ABS)
H1511		JSMA-PMH55BB	5.5	1500	2500
H1512		JSMA-PMH55BH			8192
H1515		JSMA-PMH55B5			15 bit(ABS)
H1517		JSMA-PMH55B7			17 bit
H151A		JSMA-PMH55BA			17 bit(ABS)
H1611	100B	JSMA-PMH75BB	7.5	1500	2500
H1612		JSMA-PMH75BH			8192
H1615		JSMA-PMH75B5			15 bit(ABS)
H1617		JSMA-PMH75B7			17 bit
H161A		JSMA-PMH75BA			17 bit(ABS)

1-2 Surface and Panel Board


JSDAP-10A / 15A / 20A / 30A




JSDAP-50A3 / 75A3 / 100A3 / 25B / 35B / 50B




JSDAP-150A3 / 75B / 100B



JSDAP-200A3 / 300A3



Key Board



1-3 A Brief Introduction of Operation for Drives

There are many kinds of control-mode. The detail modes display as fellow:

	Name	Mode	Explanation
Single Mode	Position Mode (External Pulse Command)	Pe	Position control for the servo motor is achieved via an external pulse command. Position command is input from CN1.
	Position Mode (Internal Position Command)	Pi	Position control for the servo motor is achieved via by 16 commands stored within the servo controller. Execution of the 16 positions is via Digital Input signals.
	Speed Mode	S	Speed control for the servo motor can be achieved via parameters set within the controller or from an external analog -10 ~ +10 Vdc command. Control of the internal speed parameters is via the Digital Inputs. A maximum of three steps speed can be stored internally.
	Torque Mode	T	Torque control for the servo motor can be achieved via parameters set or from an external analog -10 ~ +10 Vdc command.
	Tool turret Mode	Pt	The tool turret Mode use internal position command to do the DI/DO switch to change the tool turret.
Multiple Mode	Pe-S	Pe and S can be switched by digital-input-contact-point.	
	Pe-T	Pe and T can be switched by digital-input-contact-point.	
	Pi-S	Pi and S can be switched by digital-input-contact-point.	
	Pi-T	Pi and T can be switched by digital-input-contact-point.	
	S-T	S and T can be switched by digital-input-contact-point.	
	Pe-Pi	Pe and Pi can be switched by digital-input-contact-point.	


1-4 Conditions for Installation of Drives

1-4-1 Environmental Conditions

The product should be kept in the shipping carton before installation. In order to retain the warranty coverage, the AC drive should be stored properly when it is not to be used for an extended period of time. Some storage suggestions are:

- Ambient Temperature: 0 ~ + 55 °C; Ambient Humidity: Under 90% RH (Under the condition of no moisture).
- Stored Temperature: - 20 ~ + 65 °C; Stored Humidity: Under 90%RH (Under the condition of no moisture).
- Vibrating: Under 0.5 G.
- Do not mount the servo drive or motor in a location where temperatures and humidity will exceed specification.
- To avoid the isolation.
- To avoid the erosion of grease and salt.
- To avoid the corrosive gases and liquids.
- To avoid the invading of airborne dust or metallic particles.
- When over 1 Drives are installed in control panel, enough space have to be kept to get enough air to prevent the heat; the fan also must be installed, to keep the ambient temperature under 55 °C.
- Please Install the drive in a vertical position, face to the front, in order to prevent the heat.
- To avoid the metal parts or other unnecessary things falling into the drive when installing.
- The drive must be stable by M5 screws.
- When there were the vibrating items nearby, please using vibration-absorber or installing anti-vibration-rubber, if the vibration can not be avoided.
- When there is any big-size magnetic switch, welding machines or other source of interference. Please install the filter. When the filter is installed, we must install the insulation transformer.

1-4-2 Direction and Distance




1-5 Conditions for Installation of Servo Motors

1-5-1 Environmental Conditions

- Ambient Temperature: 0 ~ + 40 °C; Ambient humidity: Under 90% RH (No Moisture).
- Storage Temperature: - 20 ~ + 60 °C; Storage temperature: Under 90%RH (No Moisture).
- Vibration: Under 2.5 G.
- In a well-ventilated and low humidity and dust location.
- Do not store in a place subjected to corrosive gases, liquids, or airborne dust or metallic particles.
- Do not mount the servo motor in a location where temperatures and humidity will exceed specification.
- Do not mount the motor in a location where it will be subjected to high levels of electromagnetic radiation.

1-5-2 Method of Installation


1. Horizontal Install: Please let the cable-cavity downside to prevent the water or oil or other liquid flow into the servo motor.




2. Vertical Install: If the motor shaft is side-up installed and mounted to a gear box, please pay attention to and avoid the oil leakage from the gear box.

1-5-3 Notice for install motor

1. Please using oil-seal-motor to avoid the oil from reduction gear flowing into the motor through the motor shaft.
2. The cable need to be kept dry.
3. Please fixing the wiring cable certainly, to avoid the cable ablating or breaking.
4. The extending length of the shaft shall be enough, otherwise there will be the vibration from motor operating.



5. Please do not beat the motor when installing or taking it apart. Otherwise the shaft and the encoder of backside will be damaged.




Chapter 2 Wiring


2-1 Basic Wiring for Servo System

2-1-1 Wiring for Main Circuit and Peripheral Devices

200V Class



400V Class



2-1-2 Wiring for Servo Drives

- The wire material must go by “Wiring Specifications.”
- Wiring Length: Command Input Wire: Less than 3m.
Encoder Input Wire: Less than 20m.
The Wiring goes by the shortest length.
- Please wire according to the standard wiring schema. Don’t connect if no using.
- Please use the NFB to meet IEC (or UL Certification) between power supplier and servo drive.
- In the addition of supplying max. voltage, the capability of short circuit current must below 5000Arms, If there is possibility.
- Drive output terminals (U,V,W) must be connected to motor correctly. Otherwise the servo motor will abnormally function.
- Shielded cable must be connected to FG terminal.
- Don’t install the capacitor or Noise Filter at the output terminal of servo drive.
- At the control-output-signal relay, the direction of surge absorb diode must be correctly connected, otherwise it can not output signal, and cause the protect loop of emergency-stop abnormal.
- Please do these below to avoid the wrong operation from noise:
 - Please install devices such as the insulated transformer and noise filter at the input power.
 - Keep more than 30 cm between Power wire (power cable or motor cable...etc.) and signal cable, do not install them in the same conduit.
 - Please set “emergency-stop switch” to prevent abnormal operation.
 - After wiring, check the connection-situation of each joint (ex: loose soldering, soldering point short, terminal order incorrect...etc.). Tighten the joints to confirm if surely connected to the servo drive, if the screw is tight.

There can not be the situations such as cable break, cable pulled and dragged, or be heavily pressed.

* Especially pay attention to the polarity between servo motor wiring and encoder.

- There is no necessary to add extra regeneration resistance under general situation. If there is any need or problem, please connect to distributor or manufacturer.

2-1-3 Specifications of Wiring

Connection Terminal			Servo Drives and Wire Specifications mm ² (AWG)														
Connection Terminal	Mark (Sign)	Name of Connect Terminal	10	15	20	30	50	75	100	150	200	300	25B	35B	50B	75B	100B
Terminal	R、S、T	Main Power Terminal	1.25 (16)	2.0 (14)	3.5 (12)	5.5 (10)	8.0 (8)	22.0 (4)	2.0 (14)	2.0 (14)	3.5 (12)	3.5 (12)	3.5 (12)	3.5 (12)	3.5 (12)	3.5 (12)	
	U、V、W	Motor Terminal	1.25 (16)	2.0 (14)	3.5 (12)	5.5 (10)	8.0 (8)	14.0 (6)	22.0 (4)	2.0 (14)	2.0 (14)	3.5 (12)	3.5 (12)	3.5 (12)	3.5 (12)	5.5 (10)	
	r、s	Power-Control Terminal			1.25 (16)								0.2 (24)				
	P、Pc	External regeneration resistance terminal	1.25 (16)	2.0 (14)	3.5 (12)	5.5 (10)	8.0 (8)	22.0 (4)			1.25 (16)			14.0 (6)			
	FG 	Ground						Over 2.0(14)									

Connection Terminal			Servo Drives and Wire Specifications												
Connection Terminal	Position Number	Position Name	10	15	20	30	50	75	100	150	200	300			
CN1 Joint Control Signal	26,27	Speed Command / Limit ; Torque Command / Limit (SIC/ TIC)											0.2mm ² or 0.3mm ² -> Twisted-pair-cable connecting to the Analog Grounding wire (including shield cable)		
	30,31	Analog Monitor Output (MON 1 & MON 2)													
	33,34	Power Output +15V & -15V													
	28,29,32	Analog Ground Terminal (AG)													
	1~12	General Analog Input (DI)													
	18~25	General Analog Output (DO)											0.2mm ² or 0.3mm ² -> Twisted-pair-cable connecting to the I/O Grounding wire (including shield cable)		
	43	Home Signal Output (ZO)													
	47,44	DI PW Command Point / DO Common (DICOM / DOCOM)													
	45,46, 48	24V Power & I/O Ground (IP24 / IG24)													
	49	Absolute Encoder Power Supply (BAT+)													

Connection Terminal			Servo Drives and Wire Specifications									
Connection Terminal	Position Number	Position Name	10	15	20	30	50	75	100	150	200	300
	14~17	Position Command Input (Pulse、Sing、/Pulse、/Sing)										
	35~40	Encoder Signal Output (PA、/PA、PB、/PB、PZ、/PZ)										
	41,42	24V Open Collector Sign Input (EXT1、EXT2)										
CN2 Joint of motor encoder	1,2	PW Output Terminal 5V (+5E)										
	3,4	PW Grounding Terminal (GND)										0.2mm ² or 0.3mm ² -> Twisted-pair-cable (including shield cable)
	5~10	Encoder Signal Input (A、/A、B、/B、Z、/Z)										
CN3 CN4 Communication connector	1,4,5,7	Data transfer & receive										0.2mm ² or 0.3mm ² -> Twisted-pair-cable (including shield cable)
	3	Communication grounding wire										
	2,6,8	Floating										—


- P.S.:**
1. Please pay attention to the NFB and the capacity of noise filter when using multi Servo Drives.
 2. CN1 ->50 Pins (3M Co.)
 3. CN2 ->20 Pins (3M Co.)
 4. CN3/CN4-> 8 Pins Mini-Din type

2-1-4 Motor Terminal Layout

- Table of Motor-Terminal Wiring


(1) General Joint:

Terminal Symbol	Color	Signal
1	Red	U
2	White	V
3	Black	W
4	Yellow / Green	FG
Brake control wire	Fine White 1	0V
	Fine White 2	DC +24V




(2) Military Specifications Joint (No Brake):

Terminal	Color	Signal
A	Red	U
B	White	V
C	Black	W
D	Green	FG



(3) Military Specifications Joint (Brake):

Terminal	Color	Signal
B	Red	U
G	White	V
E	Black	W
C	Green	FG
A	Fine White 1	BK control wire
F	Fine White 2	0V
		DC +24V




P.S.: The military joint with BK of servo motor has 9 Pins; and the encoder joint has also 9 Pins. Please confirm before wiring.

- **Table of Motor-Encoder Wiring**

➤ **For 15 bits / 17 bits Encoders**


(1) General Joint:

Terminal Symbol	Color		Signal	
	15bits	17bits	15bits	17bits
1	Red	White	+5V	VCC
2	Black		0V	GND
3	Brown	--	VB+	--
4	Brown/ Black	--	VB-	--
5	Blue		SD	
6	Blue/ Black	Purple	/SD	
7	--		--	
8	--		--	
9	Shield		FG	



(2) Military Specifications Joint


Terminal Symbol	Color		Signal	
	15bits	17bits	15bits	17bits
B	Red	White	+5V	
I	Black		0V	
A	Brown	--	VB+	--
C	Brown/ Black	--	VB-	--
H	Blue		SD	
D	Blue/ Black	Purple	/SD	
G	--		--	
E	--		--	
F	Shield		FG	



➤ For 2500 / 8192 ppr Encoders


(1) General Joint:

Terminal Symbol	Color	Signal
1	Red	+5V
2	Black	0V
3	Blue	A
4	Blue/ Black	/A
5	Green	B
6	Green/ Black	/B
7	Yellow	Z
8	Yellow/ Black	/Z
9	Shield	FG



(2) Military Specifications Joint

Terminal Symbol	Color	Signal
B	Red	+5V
I	Black	0V
A	Blue	A
C	Blue / Black	/A
H	Green	B
D	Green / Black	/B
G	Yellow	Z
E	Yellow / Black	/Z
F	Shield	FG



2-1-5 TB Terminal

Name	Terminal Sign	Detail
Control circuit power input terminal	r	200V ➤ Connecting to external AC Power.
	s	➤ Single Phase 200~230VAC +10 ~ -15% 50/60Hz ±5%
	24V	400V
	0V	➤ Connecting to external DC Power. ➤ Single Phase 24VDC ±10%.
Main circuit power input terminal	R	200V ➤ Connecting to external AC Power.
	S	➤ Single / 3 Phase 200~230VAC +10 ~ -15% 50/60Hz ±5%
	T	400V ➤ Connecting to external AC Power. ➤ Three Phase 380~480VAC ±10% 50/60Hz ±5%
External regeneration resistance terminal	P	Please refer to Cn012 to see resistance value, when using external regeneration resistance. After installing regeneration resistance, set the resistance power in Cn012 .
Regeneration terminal common point	PC	*If no using external regeneration resistance, PC-P1 need be close, P doesn't be connected.
Internal regeneration resistance terminal	P1	*When using external regeneration, equip regeneration resistance between PC-P, do not connect P1 terminal.
Motor-power output terminal	U	Motor terminal wire is red
	V	Motor terminal wire is white
	W	Motor terminal wire is black
Motor-case grounding terminal	FG	Motor terminal wire is green or yellow-green .


TB Terminal Tightening Torque

Servo Pack Model	Max. Tightening Torque (kgf-cm / in-lbs)	
	Control circuit terminal(r , s)	Main circuit terminal(R, S, T)
JSDAP-10A	10 / 8.7	
JSDAP-15A	10 / 8.7	
JSDAP-20A	10 / 8.7	
JSDAP-30A	10 / 8.7	
JSDAP-50A3	16 / 13.9	
JSDAP-75A3	16 / 13.9	
JSDAP-100A3	16 / 13.9	
JSDAP-150A3	18 / 15.6	30 / 26
JSDAP-200A3	15 / 13	30 / 26
JSDAP-300A3	15 / 13	30 / 26
JSDAP-25B	16 / 13.9	
JSDAP-35B	16 / 13.9	
JSDAP-50B	16 / 13.9	
JSDAP-75B	18 / 15.6	30 / 26
JSDAP-100B	18 / 15.6	30 / 26

2-1-6 Wiring for Mechanical Brake

Uninstall BRAKE:

- JSMA-S/L/T series: Use Red wire and yellow wire connecting to DC +24V voltage(**No polarity**)
- JSMA-M/H series: BK outputs from A & F of **Motor Power Joint**, servo motor can operate normally after uninstalling.



2-1-7 MCCB/Fuse/Filter Recommended Specification


- Please use the MCCB and Fuse to meet IEC (or UL Certification) between power supplier and servo drive.
- Any noise issue which occurred during servo drive operation could be avoided by using filter.

Recommended Specification

Servo pack Model	MCCB	Fuse		Filter
		Rating	Suggestion	Suggestion
JSDAP-15A	10A	20A	Bussmann 20CT	Schaffner FN3258-7-45
JSDAP-20A	15A	20A	Bussmann 20CT	Schaffner FN3258-7-45
JSDAP-30A	15A	20A	Bussmann 20CT	Schaffner FN3258-16-45
JSDAP-50A3	30A	40A	Bussmann 40FE	Schaffner FN3258-16-45
JSDAP-75A3	30A	40A	Bussmann 40FE	Schaffner FN3258-16-45
JSDAP-100A3	50A	63A	Bussmann 63FE	Schaffner FN3258-30-47
JSDAP-150A3	50A	63A	Bussmann 63FE	Schaffner FN3258-42-47
JSDAP-200A3	75A	100A	Ferraz Shawmut A50QS100-4	Schaffner FN3258-42-47
JSDAP-300A3	125A	100A	Ferraz Shawmut A50QS100-4	Schaffner FN3258-75-47
JSDAP-25B	10A	20A	Bussmann 20CT	Schaffner FN3258-16-45
JSDAP-35B	15A	20A	Bussmann 20CT	Schaffner FN3258-16-45
JSDAP-50B	20A	20A	Bussmann 20CT	Schaffner FN3258-16-45
JSDAP-75B	30A	40A	Bussmann 40FE	Schaffner FN3258-16-45
JSDAP-100B	30A	40A	Bussmann 40FE	Schaffner FN3258-16-45

2-2 I/O Terminal

There are 4 group terminal, which control signal terminal (CN1), encoder terminal(CN2) and communication connector(CN3/CN4). The diagram below displays all positions for the terminal.



2-2-1 Output Signals from the Servo pack

(1) Diagram of CN1 Terminal:

Position Number	Name	Function	1	DI-1	SON ON	27	TIC	Speed Control Torque Limit /Torque control Torque Command	26	SIC	Speed Control Speed Command /Torque Control Speed Limit
2	DI-2	ALRS	3	DI-3	PCNT PI/P Switch	29	AG	Analog Signal Ground Terminal	28	AG	Analog Signal Ground Terminal
4	DI-4	CCWL	5	DI-5	CWL	31	MON2	Analog Monitor Output 2	30	MON1	Analog Monitor Output 1
6	DI-6	TLMT	7	DI-7	CLR	33	+15V	+15V PW output	32	AG	Analog Signal Ground Terminal
8	DI-8	LOK	9	DI-9	EMC	35	PA	Encoder output A Phase	34	-15V	-15V PW Output
10	DI-10	SPD1	11	DI-11	SPD2	37	PB	Encoder output B Phase	36	/PA	Encoder Output / A Phase
12	DI-12	MDC	13	--	-----	39	PZ	Encoder output Z Phase	38	/PB	Encoder Output / B Phase
14	Pulse	Position Pulse Command Input(+)	15	/Pulse	Position Pulse Command Input(-)	41	EXT1	24V Open Collector Pulse command input	40	/PZ	Encoder Output / Z Phase
16	Sign	Position Symbol Command Input(+)	17	/Sign	Position Symbol Command Input(-)	43	ZO	Home Signal Output	42	EXT2	24V Open Collector Sign input
18	DO-1	RDY Servo Ready	19	DO-2	ALM	45	IP24	+24V PW Output	44	DOCOM	DO Common
20	DO-3	Zero Speed	21	DO-4	INP	47	DICOM	DI PW Command Point	46	IG24	+24V PW Ground Terminal
22	DO-5	Torque Limit(LM)/ ALRS Code0(A0)	23	DO-6	PC / (A1)	49	BAT+	Absolute Encoder Power Supply	48	IG24	+24V PW Ground Terminal
24	DO-7	Drive Limit(ST)/ ALRS Code2(A2)	25	DO-8	BASE BLOCK/ (A3)	50	--	-----			

P.S.:

1. If there is unused terminal, please do not connect it or let it be the relay terminal.
2. The Shielded Wire of I/O cable should connect to the ground.

(2) CN1 Signal Name and Explanation:

(a) General I/O Signal:

Explanation of General I/O Signal Function

Signal	Function Symbol	Pin No.	Wired Mode	Signal	Function Symbol	Pin No.	Wired Mode	
Position Pulse Command Input	Pulse	14	IO3	Encoder Output A-Phase	PA	35	IO4	
	/Pulse	15		Encoder Output / A Phase	/PA	36		
Position Symbol Command Input	Sign	16		Encoder Output B-Phase	PB	37		
	/Sign	17		Encoder Output /B-Phase	/PB	38		
Open Collector Position Command Power Input.	EXT1	41	IO3	Encoder Output Z-Phase	PZ	39	IO4	
				/Z-Phase	/PZ	40		
Speed Control Speed Command/ Torque Control Speed Limit	SIC	26	IO5	Analog Signal Ground Terminal	AG	28,29,32	IO4	
				+15Vdc Output Terminal	+15V	33		
Speed Control Torque Limit / Torque control Torque Command	TIC	27		-15Vdc Output Terminal	-15V	34		
				Digital input Com Terminal	DOCOM	47		
Analog Monitor Output 1	MON1	30	IO6	+24Vdc Output	IP24	45	IO4	
Analog Monitor Output 2	MON2	31		+24Vdc Com Terminal	IG24	46,48		
Home Signal Output	ZO	43	IO2	Power supply for absolute encoder	BAT+	49		

Explanation of General I/O Signal Function

Signal Name	Function Symbol	Mode	I/O Operation and Function
Position Pulse Command Input	Pulse /Pulse	Pe	The Driver can receive 3 kinds of Command below: . (Pulse)+ (Sign) . (CCW)/ (CW)Pulse . AB Phase pulse
Position Sign Command Input	Sign /Sign		
Open Collect Position Command PW Input	OPC	Pe	When open collect input in position command, OPC and IP24 can be close, and using internal 24V power and resistor.
Speed Analog command Input	SIC	S	In Speed Mode, when external speed command is operated at SPD1=0, SPD2=0, input the voltage range: -10V~+10V , Sn216 can be set input voltage: $\pm 10V$'s Motor output speed.
Torque Analog Command Input		T	In Torque Mode, input the voltage range -10~+10V , Tn103 can be set input voltage $\pm 10V$'s motor output torque.
Torque Control Speed Limit Command	TIC	T	In Torque Mode, when external speed limit is operated at input connect point SPD1=0 & SDP2=0(P.S.) , input voltage range: 0~+10V , 10V's speed limit stands for motor's ratio speed.
CCW Torque Limit Command		S	In Speed Mode, when external torque limit is be used at input connect point TLMT=1(P.S.) , input voltage range: 0~+10V , to input 10V will limit the motor CCW torque having 300% of ratio torque.
Analog Monitor Output 1	MON1	ALL	Operating the motor to control the current speed to transform the voltage output in accordance with the rate ($\pm 10V/1.5$ times ratio speed) CCW stands for positive voltage, CW negative voltage.
Analog Monitor Output 2	MON2	ALL	Operating the motor to control the current torque to transform the voltage output in accordance with the rate ($\pm 10V/3.5$ times ratio torque) CCW torque stands for positive voltage, CW negative voltage.
Encoder Output A Phase	PA	ALL	Outputting the Motor Encoder Signal through pulse per rotation handle. The pulse quantity of every rotating can be set in Cn005 . When "1" is set in Cn004 , it is CCW rotation from the motor load terminal direction, and A Phase gets 90 degree ahead B Phase. Signal Output is Line Driver.
Encoder Output / A Phase	/PA		
Encoder Output B Phase	PB		
Encoder Output / B Phase	/PB		
Encoder Output Z Phase	PZ		
Encoder Output / Z Phase	/PZ		
Home Signal Output	ZO		
Analog Signal Ground Terminal	AG	ALL	Analog signal grounding: CN1 -> Pin 28, 29, 32 .
+15V PW Output Terminal	+15V	ALL	To provide $\pm 15V$ output power (Max. 10mA), which can be used in servo drive – external voltage command. Suggestion: Using the variable resistance which is more than 3kΩ.
-15V PW Output Terminal	-15V	ALL	
DI PW Common Terminal	DICOM	ALL	Digital input power supply common terminal.
DO PW Common Terminal	DOCUM	ALL	Digital output power supply common terminal.
+24V PW Output	IP24	ALL	+24V power output terminal (Max. 0.2A).
+24V PW Ground Terminal	IG24	ALL	+24V power grounding terminal
Power supply for absolute encoder	BAT+	ALL	Power supply for absolute encoder. If user had not battery module, user can use this pin to supply power to absolute encoder. The range of power supply is 3.3V~3.65V.

P.S.: "1" stands for "close loop with **IG24**"; "0" stands for "open loop with **IG24**".

PW is abbreviation of Power

(b) Digital I/O Signal:

For many kinds of application, the digital input/output terminal layout of all operation mode are accordingly different. In order to provide more functions, our drives can provide multi terminal layout settings. Users can set these functions for application.

Digital input terminal layout provides 13 (**Pin1~13**) programmable terminal; digital output terminal provides 4 (**Pin18~21**) programmable terminals. The diagram below shows the default digital input/output terminal placement and functions. Please refer to 5-6-1 to check related parameters setting.

Default Digital Input Terminal placement Functions and Wired Mode

Signal	terminal	Function Sign	Pin No.	Wired Mode	Signal	terminal	Function Sign	Pin No.	Wired Mode
Servo ON	DI-1	SON	1	IO1	Servo Lock	DI-8	LOK	8	IO1
Alarm reset	DI-2	ALRS	2		Emergency Stop	DI-9	EMC	9	
PI/P Switch	DI-3	PCNT	3		Internal speed command / Limit select 1	DI-10	SPD1	10	
CCW Operation Limit	DI-4	CCWL	4		Internal speed command / Limit select 2	DI-11	SPD2	11	
CW Operation Limit	DI-5	CWL	5		Control Mode Switch	DI-12	MDC	12	
External Torque Limit	DI-6	TLMT	6		Reverse Direction Speed Command	DI-13	SPDINV	13	
Pulse error amount delete	DI-7	CLR	7		—	—	—	—	

Default Digital Input Terminal Layout Functions and Wired Mode

Signal	terminal	Function Sign	Pin No.	Wired Mode	Signal	terminal	Function Sign	Pin No.	Wired Mode
Servo ready	DO-1	RDY	18	IO2	Torque limit/ Alarm code A0	DO-5	LM/A0	22	IO2
Alarm	DO-2	ALM	19		P action / Alarm code A1	DO-6	PC/A1	23	
Zero speed	DO-3	ZS	20		Operation limit/ Alarm code A2	DO-7	ST/A2	24	
Fix position	DO-4	INP	21		Base Block/ Alarm code A3	DO-8	BB/A3	25	

Digital Input Function

(Except CCWL and CWL are high electric potential, other terminal layout are low electric potential. Please refer to 5-6-1 to see related parameters)

Signal Name	Function Sign	Mode	I/O Function																				
Servo On	SON	ALL	SON and IG24 close loop: Servo ON ; SON and IG24 open loop: Servo OFF. Attention: Before power on, the input connect point SON (servo on) can not be operated to avoid danger.																				
Abnormal Reset	ALRS	ALL	ALRS and IG24 close loop: Relieving the stop-situation from of abnormality. But the abnormality of encoder or memory will cause the same alarm again. Please reset power after the abnormality is eliminated.																				
PI/P switch	PCNT	Pi/Pe/S	PCNT and IG24 close loop will cause the speed loop control transforming to ratio control from ratio integration control.																				
CCW Operation limit	CCWL	ALL	Connect to CCW over travel detector: CCWL and IG24 close loop; open loop with IG24 -> CCW over travel operates.																				
CW Operation limit	CWL	ALL	Connect to CW over travel detector: CWL and IG24 close loop; open loop with IG24 -> CW over travel operates.																				
External torque limit	TLMT	Pi/Pe/S	TLMT and IG24 close loop will cause the motor-output-torque-limit to stay in the command-voltage range of torque-limit-terminal-layout (PIC 、 NIC).																				
Pulse error amount delete	CLR	Pi/Pe	When CLR and IG24 close loop, delete the pulse amount in the Position Error Counter.																				
Servo lock	LOK	S	When LOK and IG24 close loop will transform speed control mode into position control mode in order to lock the motor at the last position.																				
Emergency stop	EMC	ALL	When EMC and IG24 close loop: Emergency stop -> Servo Off and exit the rotating statue, and Cn008 will decide if the dynamic Brake operates.																				
Internal speed command / limit select 1 Internal speed command / limit select 2	SPD1 SPD2	S/T	<table border="1"> <thead> <tr> <th>SPD2</th><th>SPD1</th><th>Speed Command (Speed Mode)</th><th>Speed Limit Command (Torque Mode)</th></tr> </thead> <tbody> <tr> <td>0</td><td>0</td><td>External command(SIN)</td><td>External limit(PIC)</td></tr> <tr> <td>0</td><td>1</td><td>Sn201</td><td>Tn105</td></tr> <tr> <td>1</td><td>0</td><td>Sn202</td><td>Tn106</td></tr> <tr> <td>1</td><td>1</td><td>Sn203</td><td>Tn107</td></tr> </tbody> </table> <p>Internal speed setting and limit: "1": Close loop with IG24 "0": Open loop with IG24</p>	SPD2	SPD1	Speed Command (Speed Mode)	Speed Limit Command (Torque Mode)	0	0	External command(SIN)	External limit(PIC)	0	1	Sn201	Tn105	1	0	Sn202	Tn106	1	1	Sn203	Tn107
SPD2	SPD1	Speed Command (Speed Mode)	Speed Limit Command (Torque Mode)																				
0	0	External command(SIN)	External limit(PIC)																				
0	1	Sn201	Tn105																				
1	0	Sn202	Tn106																				
1	1	Sn203	Tn107																				

Digital Input Function Explanation

(Except CCWL and CWL are the high electric potential, other terminal layout are the low electric potential, please refer to 5-6-1 to check related parameters setting)

Signal Name	Function Symbol	Mode	I/O Function															
Control Mode Switch	MDC	Pe/S/T	When MDC and IG24 close loop, current control mode will transform into default control mode, please refer to Cn001 .															
Position Command Limit	INH	Pe	When INH and IG24 close loop, position command input does not operate (do not accept external pulse command).															
Speed Command Counter Wise	SPDINV	S	When SPDINV and IG24 close loop in speed mode, setting rotating speed will become counter-wise rotating speed.															
Gain Select	G-SEL	Pi/Pe/S	When G-SEL and IG24 close loop, first stage control gain switch to the second control gain.															
Electric Gear ratio Numerator 1~2	GN1 GN2	Pi/Pe	<p>Electric gear ratio: select explanation:</p> <table border="1"> <thead> <tr> <th>GN2</th> <th>GN1</th> <th>Electric Gear ratio Numerator</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>0</td> <td>Pn302</td> </tr> <tr> <td>0</td> <td>1</td> <td>Pn303</td> </tr> <tr> <td>1</td> <td>0</td> <td>Pn304</td> </tr> <tr> <td>1</td> <td>1</td> <td>Pn305</td> </tr> </tbody> </table> <p>“1”: Close loop with IG24 “0”: Open loop with IG24</p>	GN2	GN1	Electric Gear ratio Numerator	0	0	Pn302	0	1	Pn303	1	0	Pn304	1	1	Pn305
GN2	GN1	Electric Gear ratio Numerator																
0	0	Pn302																
0	1	Pn303																
1	0	Pn304																
1	1	Pn305																
Internal Position Command Trigger	PTRG	Pi	When PTRG and IG24 close loop (positively-triggered), the motor will select related position command to operate in accordance with the terminal layout POS1~POS4 .															
Internal Position Command Hold	PHOLD	Pi	When PHOLD and IG24 close loop(positively-triggered), the motor will stay holding.															
Home	SHOME	Pi/Pe	When SHOME and IG24 close loop(positively-triggered), HOME function operates															
External Origin	ORG	Pi	When ORG and IG24 close loop(positively-triggered), server will use this as external reference point for home position returning.															

Digital Input Function Explanation

(Except CCWL and CWL are the high electric potential, other terminal layout are the low electric potential, please refer to 5-6-1 to check related parameters setting)

Signal Name	Function Symbol	Mode	I/O Function					
Internal Position Command select 1~5	POS1 POS2 POS3 POS4 POS5	Pi	Internal position command select :					
			POS1	POS2	POS3	POS4	POS5	Internal Position Command select
			0	0	0	0	0	Pn317, Pn318
			0	0	0	1	0	Pn320, Pn321
			0	0	1	0	0	Pn323, Pn324
			0	0	1	1	0	Pn326, Pn327
			0	1	0	0	0	Pn329, Pn330
			0	1	0	1	0	Pn332, Pn333
			0	1	1	0	0	Pn335, Pn336
			0	1	1	1	0	Pn338, Pn339
			1	0	0	0	0	Pn341, Pn342
			1	0	0	1	0	Pn344, Pn345
			1	0	1	0	0	Pn347, Pn348
			1	0	1	1	0	Pn350, Pn351
			1	1	0	0	0	Pn353, Pn354
			1	1	0	1	0	Pn356, Pn357
			1	1	1	0	0	Pn359, Pn360
			1	1	1	1	0	Pn362, Pn363
			Internal position command select explanation: “1”: close loop with IG24 “0”: open loop with IG24					
Torque Command Counter Clock Wise	TRQINV	T	When TRQINV and IG24 close loop in torque mode, setting torque command output wise becomes counter wise output.					
External torque command direction select	RS1 RS2	T	External torque command direction select :					
			RS2	RS1	Statement			
			0	0	No torque command input			
			0	1	According to torque command			
			1	0	Opposite direction for currently torque command			
			1	1	No torque command input			
			“1” means short with IG24 . “0” means open with IG24 .					

Digital Output Function Explanation

(The terminal layout here from this explanation are all the low electric potential, please refer to 5-6-1 to check parameter settings)


Signal Name	Function Symbol	Mode	I/O Function
Servo Ready	RDY	ALL	Main power and control power input are normal. Under the situation of no alarm, terminal layouts RDY and IG24 close loop.
Alarm	ALM	ALL	If normally operates, the terminal layouts ALM and IG24 open loop. When alarm occurs, protection-function operates, the terminal and IG24 close loop.
Zero Speed	ZS	S	When the motor speed is less than the speed from Sn215 , the terminal layout ZS and IG24 close loop.
BK Signal	BI	ALL	When Cn008 is set "1" or "3" and the servo on, the terminal layout BI and IG24 close loop; when servo off, terminal layout and IG24 open loop. (When this terminal layout is generally applied, it is the Brake relay, which is connected to control motor).
In Speed	INS	S	When the motor speed has achieved the setting speed from Cn007 , INS and IG24 close loop.
In Position	INP	Pi/Pe	When the amount of position error counter is less than the amount range which is set in Pn307 , INP and IG24 close loop.
Home	HOME	Pi/Pe	When HOME is accomplished, HOME and IG24 close.
Torque Reach signal	INT	ALL	When the output torque reached the setting value of Tn108, INT and IG24 close.
Limiting Torque/ Alarm No. 0	LM/A0	ALL	When motor output torque is limited by internal torque limit amount (Cn010&Cn011) or external torque limit command (PIC&NIC). LM/A0 and IG24 close loop. When alarm occurs, this terminal layout is alarm code output A0 .
P in Action / Alarm No.1	PC/A1	Pe/Pi/S	When speed loop is ratio(P)-control, PC/A1 and IG24 close loop. When alarm occurs, this terminal layout is alarm code output A1 .
Server in Limiting/ Alarm No.2	ST/A2	ALL	When CCW or CW operation-limit occurs, ST/A2 and IG24 close loop. When alarm occurs, this terminal layout is alarm code output A2 .
Base Block/ Alarm No.3	BB/A3	ALL	When servo motor has not been operated, BB/A3 and IG24 close loop. When alarm occurs, this terminal layout is alarm code output A3 .

(3) CN1 Interface Circuit and Wire Mode:

The diagram below introduces all interface circuit of CN1 and wire-method of host controller.

(a) Digital input interface circuit (IO1):


Digital input interface circuit can be operated by relay or collector transistor circuit. The relay should be the low electric current, in order to avoid the faulty contacting. External voltage: 24V.



(b) Digital Output Interface Circuit (IO2):




When using external power, please attention to the power polarity. Adverse polarity will case circuit damage.

Digital output is “Open Collector”. The maximum of external voltage is 24V; and the maximum electric current is 10mA.




(c) Pulse Command Input Interface Circuit(IO3):

Suggesting to use the input method of Line Driver to send the pulse command. The maximum input command frequency is 500kpps. Using the input method of Open Collector will cause the decrease of input command frequency, the maximum input command frequency is 200kpps. The servo provides only 24V power, and other power should be prepared. Adverse polarity of power will cause the servo damage. The maximum of External power (Vcc) is 24V limited. Input current is about 8~15mA. Please refer to the examples below to select resistance. Please refer to 5-4-1 to check pulse input command timing.

Line Driver pulse command input	Open Collector pulse command input			
 <p>The max. frequency of line driver type pulse command is 500kpps</p>	 <p>Maximum input command frequency of open collector is 200kpps</p>			
Open Collector (Internal 24V)	Open Collector – Selection of input Resistance			
 <p>The maximum input command frequency of open collector is 200kpps</p>	<table border="1"> <tr> <td>External Power Vcc=24V R=2KΩ</td><td>External Power Vcc=12V R=750Ω</td><td>External Power Vcc=5V R=100Ω</td></tr> </table>	External Power Vcc=24V R=2KΩ	External Power Vcc=12V R=750Ω	External Power Vcc=5V R=100Ω
External Power Vcc=24V R=2KΩ	External Power Vcc=12V R=750Ω	External Power Vcc=5V R=100Ω		

(d) Encoder Output Interface Circuit (IO4):

Encoder output interface circuit is the output method of Line Driver, please let end terminal resistance($R=200\sim 330\Omega$) connect to Line Receiver input terminal.




(e) Analog Input Interface Circuit (IO5):

There is sometimes ripple inside the servo internal power. Adverse external power polarity will cause severe damage. Maximum external power voltage (V_c) should be less than 12V; terminal input voltage should not more than 10V. Over voltage will cause damage. When using internal power of server, user need to choose the resistance (suggestion: more than $3K\Omega$), which maximum current is less than 10mA.

SIC Input impedance: $15K\Omega$


PIC Input impedance: $40K\Omega$

NIC Input impedance: $20K\Omega$



(f) Analog Output Interface Circuit (IO6):

The maximum current of analog output is 5mA, so user needs to choose the device, which Impedance is larger.



2-2-2 Encoder Connector (CN2) Terminal Layout

(1) Diagram of CN2 Terminal:

(a) Diagram of Fewer Wiring Type Encoder:

Pin No.	Terminal Layout	Function	1	+5V	PW Output Terminal	11	—	—
2	+5V	PW Output Terminal	3	0V	PW Grounding Terminal	12	—	—
4	0V	PW Grounding Terminal	5	A	Encoder / A Phase Input	13	—	—
6	/A	Encoder / A Phase Input	7	B	Encoder / B Phase Input	14	—	—
8	/B	Encoder / B Phase Input	9	Z	Encoder / Z Phase Input	15	—	—
10	/Z	Encoder / Z Phase Input	20	FG	Shielded Wire Grounding	16	—	—
			17	—	—	18	—	—
			19	—	—			

(b) Diagram of 15 bits / 17 bits Encoder:

Pin No.	Terminal Layout	Function	1	Vcc	Power Supply Output	11	VB+	Battery(+)
2	—	—	3	GND	Ground	12	VB-	Battery(-)
4	—	—	5	—	—	13	SD	Serial Data output(+)
6	—	—	7	—	—	14	/SD	Serial Data output(-)
8	—	—	9	—	—	15	—	—
10	—	—	20	—	—	16	—	—
			17	—	—	18	—	—
			19	—	—			


P.S.: Do not wire to the terminal, which is un-operated.

(2) Name and Explanation of I/O Signal:

Pin No.	Signal Name	Code	Encoder Output No. and Color			Terminal Layout Function
			General Joint		Plug-in Joint	
			9 wires (fewer wiring)	15 wires (non-fewer wiring)	Output No.	
1 2	Power output + Terminal	+5V	white	Red	B	5V Power for encoder (provided from driver). When the cable is more than 20m, user should separately use 2 cables to avoid decreasing voltage of encoder. When the cable is more than 30m, please contact to the distributorship.
3 4	Power output - Terminal	0V	Black	Black	I	
5	A Phase encoder input A	A	Green	Green	A	Encoder A Phase: From motor terminal to the driver.
6		/A	Blue	Green White	C	
7	B Phase encoder input	B	Red	Gray	H	Encoder B Phase: From motor terminal to the driver.
8		/B	Pink	Gray white	D	
9	Z Phase encoder input	Z	Yellow	Yellow	G	Encoder Z Phase: From motor terminal to the driver.
10		/Z	Orange	Yellow white	E	
11	U Phase encoder input	U		Brown		When using fewer-wiring-type motor, do not wire.
12		/U		Brown white		
13	V Phase encoder input	V		Blue		When using fewer-wiring-type motor, do not wire.
14		/V		Blue white		
15	W Phase encoder input	W		Orange		When using fewer-wiring-type motor, do not wire.
16		/W		Orange white		
17 18 19	No operated	--	--			Please do not wire.

2-2-3 CN3/CN4 Communication Terminal Layout

Diagram of CN3/CN4 terminal :



CN3 for RS-485

PIN NO.	Terminal Layout	Function
1	—	—
2	—	—
3	—	—
4	—	—
5	Data +	Serial Data(+)
6	—	—
7	Data -	Serial Data(-)
8	—	—


CN4 for RS-232/RS485

PIN NO.	Terminal Layout	Function
1	RxD	Serial Data Received
2	—	—
3	GND	Ground
4	TxD	Serial Data Transmission
5	Data +	Serial Data(+)
6	—	—
7	Data -	Serial Data(-)
8	—	—

Notes: Do not wire to the terminal, which is un-operated.

2-3 Typical Circuit Wiring Examples

2-3-1 Position Control Mode (Pe Mode) (Line Driver)




Notes: 1. Pe mode =External pulse positioning command

2. DOCOM means common port of digital input

(DOCOM must connect to IG24 when using internal power supply)

2-3-2 Position Control Mode (Pe Mode) (Open Collector)




Notes: 1. Pe mode =External pulse positioning command

2. DOCOM means common port of digital input

(DOCOM must connect to IG24 when using internal power supply)


2-3-3 Position Control Mode (Pi Mode)



Notes:

1. Pe mode =External pulse positioning command
2. DOCOM means common port of digital input
(DOCOM must connect to IG24 when using internal power supply)


2-3-4 Speed Control Mode (S Mode)



Notes:

1. Pe mode =External pulse positioning command
2. DOCOM means common port of digital input
(DOCOM must connect to IG24 when using internal power supply)


2-3-5 Torque Control Mode (T Mode)



Notes:

1. Pe mode =External pulse positioning command
2. DOCOM means common port of digital input
(DOCOM must connect to IG24 when using internal power supply)

2-3-6 Turret Mode (Pt Mode)



Notes: 1. DCOM means common port of digital input

(DCOM must connect to IG24 when using internal power supply)

Chapter 3 Panel Operator / Digital Operator


3-1 Panel Operator on the Drives

The operator keypad & display contains a 5 digit 7 segment display, 4 control keys and two status LED displays.

Power status LED (Green) is lit when the power is applied to the unit.

Charge LED (Red) Indicate the capacitor 's charge status of main circuit. power on to light up Charge LED and gradual dark when internal power capacitors are discharged complete.

Do NOT wire or assemble to the servo drive before Charge LED is off.



Key	Name	Function Keys Description
	MODE/SET	1. To select a basic mode, such as the status display mode, utility function mode, parameter setting mode, or monitor mode. 2. Returning back to parameter selection from data-setting screen.
	INCREMENT	1. Parameter Selection. 2. To increase the set value.
	DECREMENT	3. Press and at the same time to clear ALARM.
	DATA SETTING & DATA ENTER	1. To confirm data and parameter item. 2. To shift to the next digit on the left. 3. To enter the data setting (press 2 sec.)

After power on, MODE button can be used to select 9 groups of parameter.

By pressing the Mode key repeatedly once at a time you can scroll through the displays below.

Step	Key	LED Display after Operation	Description
1	Power on		Drive status parameters.
2			Diagnostic parameters.
3			Alarm parameters.
4			System Control parameters.
5			Torque Control parameters.
6			Speed Control parameters.
7			Position Control parameters.
8			Quick set up parameters.
9			Multi function I/O (programmable Inputs/Outputs) Parameters.
10			Return to Drive status parameters.

Once the first parameter in a parameter group is displayed use **Increment** or **Decrement** keys to select the required parameter then use **Enter** key in order to view and alter the parameter setting, once this is done then press **Enter** key again to save the change.

Notes: On each parameter display the first digit will be flashing, the enter key can be used to move between digits.

Example procedures are shown below: -

Ex: Setting Speed Parameter Sn203 to 100rpm.

Step	Key	LED Display after Operation	Description
1	Power On		Display status of servo drive
2			Press MODE-Key 6 times to select Sn 201
3			Press INCREMENT- Key twice Sn203 is displayed.
4			To view the Sn203 preset value by press ENTER-Key for 2 seconds
5			Shift to the second digit by press ENTER- Key once
6			Shift to next Digit by press ENTER-Key once again
7			Change the digit preset value by press the DECREMET-Key twice
8		 	To save the altered preset value, Press the ENTER- Key for 2 seconds until “SET”is displayed briefly and then display is returned to parameter Sn203

Following example shows the sequence where a parameter preset value is displayed.

When no change is made and it is skip back to the original parameter by pressing the Mode-Key.


Step	Key	LED Display after Operation	Description
1	Power ON		When power on drive status parameter will display
2			Pressing MODE-Key 6 times, Sn 201 will be displayed.
3			Pressing INCREMENT- Key twice Sn203 is displayed.
4			To view the Sn203 preset press ENTER-Key for 2 seconds.
5			No change is made and LED display return to last select parameter Sn203, press MODE-Key once skip

Some of the data entry in this drive are in the format shown below, for these data the Most significant digit will be shown by the Capital letter "H" as shown below.

Ex: Home search function in position mode **Pn317 = 0212**. Each digit of this preset for Pn317 parameter defines a selection for a specific function.

Bit0 corresponds to a selection for parameter Pn 317.0 and bit1 setting for Pn 317.1 ... etc.

Parameter Pn 365 Format for the 5 digits data value is shown below:



Display of Positive and Negative values:

Description of Positive/Negative Display	Display of Positive	Display of Negative
For negative numbers with 4 digits or less, the negative sign is displayed in the most significant digit as shown. Ex: Sn201 (Internal Speed Command 1).	3000	-3000
For negative numbers with 5 digits the negative sign is indicated by displaying all the 5 decimal points on the display. Ex: Pn317 (Internal Position Command 1- Rotation number)	30000	-30000

Setting a negative value.

(1) If the negative value has 4 digits or less follow the steps in the example below:

Ex: Sn201(Internal speed command 1)= preset speed of 100 to -100 rpm.

Step	Key	LED Display after Operation	Description
1	Power ON		On" power on “ Drive Status parameter is displayed.
2			Pressing MODE-Key 5 times, Sn 201 will be displayed.
3			To view the Sn201 preset press ENTER-Key for 2 seconds.
4			To move to the most significant digit press the ENTER-Key 4 times.
5			Use INCREMENT Or DECREMENT key until the minus sign (-) is displayed. You can toggle between – and + by this key.
6		 	To save the altered preset value, Press the ENTER- Key for 2 seconds until “SET”is displayed briefly and then display is returned to parameter Sn201.

If the negative value has 5 digits follow the steps in the example below:

Ex: Pn317 (internal position preset command 1) set to a negative value -10000 revolutions.

Step	Control Keys	LED Display after Operation	Description
1	Power On		On" power on “ Drive Status parameter is displayed.
2			Pressing MODE-Key 8 times, position parameter Pn 301 will be displayed.
3			Use INCREMENT- Key to display Pn317.
4			To view the Pn317 preset press ENTER-Key for 2 seconds.
5			To move to the most significant digit press the ENTER-Key 4 times.
6			Press DECREMENT-Key once to set the most significant digit To 1. And press the DECREMENT-Key once again. All 5 decimal points will light up to indicate a negative number.
7			To save the altered preset value, Press the ENTER- Key for 2 seconds until “ SET ”is displayed briefly and then display is returned to parameter Pn 317.

Alarm Reset from the Keypad.


All alarm displays can be cleared from the keypad without a need for an external Alarm clear (Reset) signal.

Ex. Under voltage Alarm AL-01.

Step	Control Key	LED Display after Operation	Description
1	Alarm		Under voltage Alarm AL-01 is displayed.
2			To clear Alarm:- Remove input contact SON (Servo On). Then press INCREMENT-Key and DECREMENT-Key at the same time. The display will show RESET briefly and then returns back to parameter display.

The LED display contains status code and the digit of LED, the LED shows different meaning in Torque/Speed control mode and Position control mode, the statement is below.

(1) Speed and Torque control mode :




The following table describes the digit and status code.

Digit	Description	
	Digit Lighting	Digit Off
BASE BLOCK	Servo OFF	Servo ON
Speed Reached (INS)	Motor speed was greater than Cn007 (Speed reached preset)	Motor speed was less than Cn007 (Speed reached preset)
Speed Command Reached	Speed command was greater than Cn007 (Speed reached preset)	Speed command less than Cn007 (Speed reached preset)
Torque Command Reached	Torque command was greater than 0% of rated torque.	Torque command was less than 0% of rated torque.

Status Code	Description
	BASE BLOCK Servo OFF (Motor hasn't established the magnetic flux)
	Servo drive running Servo ON (Motor is establishing the magnetic flux)
	CCW direction banned Input contact(CCWL) operation.
	CW direction banned Input contact(CWL) operation.

(2) Position control mode :



The following table describes the digit and status code.

Digit	Description	
	Digit Lighting	Digit Off
BASE BLOCK	Servo OFF	Servo ON
Position Complete (INP)	Position error was less than Pn307 (Position complete value)	Position error was greater than Pn307 (Position complete value)
Speed Reached (INS)	Motor speed was greater than Cn007 (Speed reached preset)	Motor speed was less than Cn007 (Speed reached preset)
External Pulse Train Command	External Pulse Train Command	Internal Pulse Command
Pulse Error Clear Mode	Input Contact CLR (Pulse error clear) operation	Input Contact CLR (Pulse error clear) Disable

Status Code	Description
	BASE BLOCK Servo OFF(Motor hasn't established the magnetic flux)
	Servo drive running Servo ON(Motor is establishing the magnetic flux)
	CCW direction banned Input contact(CCWL) operation.
	CW direction banned Input contact(CWL) operation.

3-2 Signal Display

The following parameters can be used to display drive and motor status.

Parameter Signal	Display	Unit	Explanation	Communication Address	
				RS232	RS485
Un-01	Actual Motor Speed	rpm	Motor Speed is displayed in rpm.	6C4H	0601H
Un-02	Actual Motor Torque	%	It displays the torque as a percentage of the rated torque. Ex: 20 are displayed. It means that the motor torque output is 20% of rated torque.	9B6H	0602H
Un-03	Regenerative load rate	%	Value for the processable regenerative power as 100%. Displays regenerative power consumption in 10-s cycle.	6F4H	0603H
Un-04	Accumulated load rate	%	Value for the rated torque as 100%. Displays effective torque in 10-s cycle.	693H	0604H
Un-05	Max load rate	%	Max value of accumulated load rate	694H	0605H
Un-06	Speed Command	rpm	Speed command is displayed in rpm.	678H	0606H
Un-07	Position Error Value	pulse	Error between position command value and the actual position feedback.	65CH	0607H
Un-08	Position Feed-back Value	pulse	The accumulated number of pulses from the encoder.	688H	0608H
Un-09	ExternalVoltage Command	V	External analog voltage command value in volts.	B93H	0609H
Un-10	(Vdc Bus)Main Loop Voltage	V	DC Bus voltage in Volts.	6B7H	060AH
Un-11	External analog voltage limit value	V	EX : The value is 5.25 means external analog voltage limit value is 5.25V.	B9BH	060BH
Un-12	External CCW Torque Limit Command Value	%	Ex: Display 100. Means current external CCW torque limit command is set to 100 %.	6C0H	060CH
Un-13	External CW Torque LimitCommand Value	%	Ex: Display 100. Means current external CW torque limit command is set to 100%.	6C1H	060DH
Un-14	Motor feed back – Less than 1 rotation pulse value(Low Byte)	pulse	After power on, it displays the number of pulses for an incomplete revolution of the motor as a Low Byte value.	8FDH	060EH
Un-15	Motor feed back – Less than 1 rotation pulse value(High Byte)	pulse	After power on, it displays the number of pulses for an incomplete revolution of the motor as a High Byte value.	8FCH	060FH
Un-16	Motor feed back – Rotation value (Low Byte)	rev	After power on, it displays motor rotation number as a Low Byte value.	8FFH	0610H
Un-17	Motor feed back – Rotation value (absolute value)	rev	After power on, it displays motor rotation number as a High Byte value.	8FEH	0611H
Un-18	Pulse command – Less than 1 rotation pulse value(Low Byte)	pulse	After power on, it displays pulse command input for an incomplete rotation. pulse value is a Low Byte value.	8F9H	0612H
Un-19	Pulse command – Less than 1 rotation pulse value(absolute value)	pulse	After power on, it displays pulse command input for an incomplete rotation. pulse value is a High Byte value.	8F8H	0613H
Un-20	Pulse command – rotation value(Low Byte)	rev	After power on, it displays pulse command input rotation number in Low Byte value.	8FBH	0614H

Parameter Signal	Display	Unit	Explanation	Communication Adress	
				RS232	RS485
Un-21	Pulse command – rotation value(absolute value)	rev	After power on, it displays pulse command input rotation number in High Byte value.	8FAH	0615H
Un-22	Position feedback	pulse	2500/8192 ppr Encoder feedback.	6B0H	0616H
Un-23	15 bits encoder position feedback Less than 1 rotation	pulse	it displays absolute position for an incomplete rotation.	9E7H	0617H
Un-24	Communication encoder position feedback of multi-rotations	rev	It displays absolute position for multi-rotations.	9D9H	0618H
Un-25	17 bits encoder position feedback Less than 1 rotation(Low Byte)	pulse	it displays absolute position for an incomplete rotation as Low Byte value.	9E7H	0619H
Un-26	17 bits encoder position feedback Less than 1 rotation(High Byte)	pulse	it displays absolute position for an incomplete rotation as High Byte value.	9E6H	061AH
Un-27	15bits/17bits encoder status	—	15 bits/17bits encoder status feedback.	9DAH	061BH
Un-28	Torque command	%	It displays the torque command as a percentage of the rated torque. Ex: Display. 50.Means current motor torque command is 50% of rated torque.	67EH	061CH
Un-29	Load inertia	x0.1	When Cn002.2=0(Auto gain adjust disabled), it displays the current preset load inertia ratio from parameter Cn025. When Cn002.2=1(Auto gain adjust enabled), it displays the current estimated load inertia ratio.	844H	061DH
Un-30	Digital Output status(Do)	—	The status of digital output contact (Do) represented in hexadecimal. Ex : H00XX (0000 0000 Do-8/7/6/5 Do-4/3/2/1)	6AFH	061EH
Un-31	Digital Input status(Di)	—	The status of digital input contact (Di) represented in hexadecimal. Ex : HXXXX (000Di-13 Di-12/11/10/9 Di-8/7/6/5 Di-4/3/2/1)	6CBH	061FH
Un-39	The offset voltage of TLA	mV	EX : The value is 25 means The offset voltage of TLA is 25mV.	97CH	0627H
Un-40	The offset voltage of VIC	mV	EX : The value is 25 means The offset voltage of VIC is 25mV.	97FH	0628H
Un-41	The offset voltage of TC	mV	EX : The value is 25 means The offset voltage of TC is 25mV.	97DH	0629H
Un-42	The offset voltage of VC	mV	EX : The value is 25 means The offset voltage of VC is 25mV.	97EH	062AH
Un-43	Electric motor angle	degree	Display the moment of electric motor angle.	6BAH	062BH
Un-44	Read the model of motor with communication type encoder	—	EX : When it display H1267 means motor's Cn030 number is H1267	72FH	062CH
Un-45	Inertia Estimation for OnLine_AutoTuning	X0.1	EX : The value is 100 means the inertia ratio is ten times.	B34H	062DH
Un-46	Status for OFFLine_Tuning	—	The status of OFFLine_Tuning	90AH	062EH
Un-47	The error code for OFFLine_Tuning	—	The error code for OFFLine_Tuning	CA5H	062FH

3-2-2 Diagnostic function

The following diagnostics parameters are available:

Parameter Signal	Name and Function
dn-01	Control mode display
dn-02	Output terminal status
dn-03	Input terminal status
dn-04	Software version (CPU version)
dn-05	JOG mode operation
dn-06	Reserve function
dn-07	Auto offset adjustment of external analog command voltage
dn-08	Servo model code
dn-09	ASIC software version display
dn-10	Absolute Encoder Rotation Value Reset
dn-10.1	Absolute Encoder Battery Alarm (AL-16) clear
dn-11	Automatic alignment function

dn-01 (Control Mode Display)

Access **dn-01** to display the selected control mode.


Control mode display description is listed in the table below:

Control Mode	dn-01 (Control mode display)
Torque control - T	<input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> T
Speed control - S	<input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> S
Position control (External pulse command) - Pe	<input type="checkbox"/> <input type="checkbox"/> P E
Position/Speed control switch - Pe/S	<input type="checkbox"/> P E - S
Speed/Torque control switch - S/T	<input type="checkbox"/> S - T
Position/Torque control switch - Pe/T	<input type="checkbox"/> P E - T
Position control (Internal position command) - Pi	<input type="checkbox"/> P I
Internal Position / Speed control switch - Pi/S	<input type="checkbox"/> P I - S
Internal Position / Speed control switch - Pi/T	<input type="checkbox"/> P I - T

dn-02 (Output terminal status)

Use dn-02 to check the status of output terminals.

Output status display is described below:



When output terminal signal has a low logic level (**close** loop with **IG24**),
the corresponding LED will be on.

When output terminal signal has a high logic level (**open** loop with **IG24**),
the corresponding LED will be off.

Table below shows the functions of the digital outputs.

DO-1~DO-4 are programmable outputs. Default settings are shown below.

DO-5~DO-8 are fix function outputs. (non-programmable)

For programmable output list see section 5-6-1.

LED No.	Output terminal number	Default function
1	DO-1	RDY
2	DO-2	ALM
3	DO-3	ZS
4	DO-4	INP
5	DO-5	LM/A0
6	DO-6	PC/A1
7	DO-7	ST/A2
8	DO-8	BB/A3


Note: To set the logic state (High or Low) of for programmable digital outputs refer to section 5-6-1.

For the DO-5~DO-8 (non-programmable) terminals are active when logic is low.

dn-03 (Input terminals status)

Use dn-03 to check the status of Input terminals.

Digital Input status display is described below:



When Input terminal signal has a low logic level (close loop with **IG24**), the corresponding LED will be on.

When Input terminal signal has a high logic level (open loop with **IG24**), the corresponding LED will be off.

Table below shows the functions of the digital input.

DI-1 ~ DI -10 are programmable Inputs. Default settings are shown below.

For programmable function list see section 5-6-1.

LED Number	Input terminal number	Default function
1	DI-1	SON
2	DI -2	ALRS
3	DI -3	PCNT
4	DI -4	CCWL
5	DI -5	CWL
6	DI -6	TLMT
7	DI -7	CLR
8	DI -8	LOK
9	DI -9	EMC
10	DI -10	SPD1

dn-04 (Version of Software)

Use **dn-04** to view the current software version of the Servo drive.

Software version can be checked as below:

Step	Keys	LED Display	Description
1	Power On		On" power on Drive Status is displayed.
2			Press MODE-Key twice to view diagnostics parameter dn-01.
3			Press INCREMENT-Key 3 times to display dn-04.
4			Press ENTER-Key for 2 seconds to view the software version. (Software version: 2.00)
5			Press MODE-Key once to return to dn-04 and parameter selection.

dn-05 (JOG Operation)

Use dn-05 to JOG the motor. Jog is activated by following the steps below:

Note: JOG speed is in accordance with setting of Sn201(internal speed command 1).

Ensure that the required speed is set in Sn201 before executing this function.

Warning: Motor will be agitated run as soon as JOG command is activated.

without the need for SON input (Servo On signal).


Step	Key	LED display	Description
1	Power on		On" power on Drive Status is displayed.
2			Press MODE-Key once to view diagnostics parameter dn-01.
3			Press INCREMENT-Key 4 times to display dn-05.
4			Press ENTER-Key for 2 seconds to enter JOG MODE . Motor will power on immediately.
5			Press INCREMENT-Key , motor will run in the pre-defined positive direction.
6			Press DECREMENT-Key , motor will run in the pre-defined negative direction.
7			Press MODE-Key once to return to dn-05 and parameter selection. Motor stoped the excitation immediately.

dn-07 (Auto offset adjustment of external analog command voltage)


If the external torque or speed analog command is set to 0V and the motor is rotating slowly, this is due to analog input zero offset, use **dn-07** to auto adjust this offset and stop the motor rotating. Follow the steps below:

Step	Key	LED Display	Description
1	Insert a link between analog command terminal SIN(CN1-26) and Analog Ground terminal AG(CN1-29) before proceeding.		
2	Power on		On" power on " Drive Status is displayed.
3			Press MODE-Key twice into diagnostics parameter dn-01.
4			Press INCREMENT-Key 6 times to display dn-7.
5			Press ENTER-Key for 2 seconds to enter dn-07
6			Press INCREMENT-Key once to set to 1 (Enable auto offset adjustment).
7			To save the altered preset value and activate auto offset adjust, Press the ENTER- Key for 2 seconds until "SET" is displayed briefly and then display is returned to parameter dn-07. To save this offset value, please select parameters Tn104 or Sn217 as required and press the ENTER-Key. Tn107 for analog torque command. Sn217 for analog speed command.

Before bias adjusting



After bias adjusting



dn-08 (Servo motor Model Code display)

Use **dn-08** to display servo motor code and check the servo drive and motor compatibility according to the table below.

If the dn08 preset is not according to the list below then contact your supplier.

The motor model code is stored in parameter Cn30.

200V Class

dn-08 Display Cn030 Setting	Drive Model JSDAP	Motor Model	Motor Standards		Encoder Specification
			Watt(KW)	Speed(rpm)	
H1011	10A(1)	JSMA-(P)SCP5AB	0.05	3000	2500
H1015		JSMA-PSCP5A5			15 bit(ABS)
H1017		JSMA-PSCP5A7			17 bit
H101A		JSMA-PSCP5AA			17 bit(ABS)
H1021		JSMA- (P)SC01AB	0.1	3000	2500
H1025		JSMA-PSC01A5			15 bit(ABS)
H1027		JSMA-PSC01A7			17 bit
H102A		JSMA-PSC01AA			17 bit(ABS)
H1101	15A(1)	JSMA-PSC02AB	0.2	3000	2500
H1102		JSMA-PSC02AH			8192
H1105		JSMA-PSC02A5			15 bit(ABS)
H1107		JSMA-PSC02A7			17 bit
H110A		JSMA-PSC02AA			17 bit(ABS)
H1111	15A(1)	JSMA- (P)SC01AB	0.1	3000	2500
H1115		JSMA-PSC01A5			15 bit(ABS)
H1117		JSMA-PSC01A7			17 bit
H111A		JSMA-PSC01AA			17 bit(ABS)

dn-08 Display Cn030 Setting	Drive Model JSDAP	Motor Model	Motor Standards		Encoder Specification
			Watt(KW)	Speed(rpm)	
H1121	15A(1)	JSMA-PLC03AB	0.3	3000	2500
H1122		JSMA-PLC03AH			8192
H1125		JSMA-PLC03A5			15 bit(ABS)
H1127		JSMA-PLC03A7			17 bit
H112A		JSMA-PLC03AA			17 bit(ABS)
H1141	15A(1)	JSMA-SC04AB	0.4 (rated 3.5A)	3000	2500
H1142		JSMA-SC04AH			8192
H1145		JSMA-SC04A5			15 bit(ABS)
H1147		JSMA-SC04A7			17 bit
H114A		JSMA-SC04AA			17 bit(ABS)
H1151		JSMA-(P)SC04AB	0.4 (rated 2.5A)	3000	2500
H1152		JSMA-(P)SC04AH			8192
H1155		JSMA-PSC04A5			15 bit(ABS)
H1157		JSMA-PSC04A7			17 bit
H115A		JSMA-PSC04AA			17 bit(ABS)
H1211	20A	JSMA-PLC08AB	0.75	3000	2500
H1212		JSMA-PLC08AH			8192
H1215		JSMA-PLC08A5			15 bit(ABS)
H1217		JSMA-PLC08A7			17 bit
H121A		JSMA-PLC08AA			17 bit(ABS)
H1221		JSMA-SC04AB	0.4 (rated 3.5A)	3000	2500
H1222		JSMA-SC04AH			8192
H1225		JSMA-SC04A5			15 bit(ABS)
H1227		JSMA-SC04A7			17 bit
H122A		JSMA-SC04AA			17 bit(ABS)

dn-08 Display Cn030 Setting	Drive Model JSDAP	Motor Model	Motor Standards		Encoder Specification
			Watt(KW)	Speed(rpm)	
H1231	20A	JSMA- (P)SC08AB	0.75	3000	2500
H1232		JSMA-PSC08AH			8192
H1235		JSMA-PSC08A5			15 bit(ABS)
H1237		JSMA-PSC08A7			17 bit
H123A		JSMA-PSC08AA			17 bit(ABS)
H1241		JSMA-PMA05AB	0.55	1000	2500
H1252		JSMA-PMH05AH		1500	8192
H1255		JSMA-PMH05A5			15 bit(ABS)
H1257		JSMA-PMH05A7			17 bit
H125A		JSMA-PMH05AA			17 bit(ABS)
H1261	20A	JSMA- (P)SC04AB	0.4 (rated2.5A)	3000	2500
H1262		JSMA- (P)SC04AH			8192
H1265		JSMA-PSC04A5			15 bit(ABS)
H1267		JSMA-PSC04A7			17 bit
H126A		JSMA-PSC04AA			17 bit(ABS)
H1311	30A	JSMA- (P)SC08AB	0.75	3000	2500
H1312		JSMA-PSC08AH			8192
H1315		JSMA-PSC08A5			15 bit(ABS)
H1317		JSMA-PSC08A7			17 bit
H131A		JSMA-PSC08AA			17 bit(ABS)
H1321	30A	JSMA-PMA10AB	1.0	1000	2500
H1322		JSMA-PMA10AH			8192
H1325		JSMA-PMA10A5			15 bit(ABS)
H1327		JSMA-PMA10A7			17 bit

dn-08 Display Cn030 Setting	Drive Model JSDAP	Motor Model	Motor Standards		Encoder Specification
			Watt(KW)	Speed(rpm)	
H132A	30A	JSMA-PMA10AA	1.0	1000	17 bit(ABS)
H1331		JSMA-PMB10AB		2500	
H1332		JSMA-PMB10AH		8192	
H1335		JSMA-PMB10A5		2000	15 bit(ABS)
H1337		JSMA-PMB10A7			17 bit
H133A		JSMA-PMB10AA			17 bit(ABS)
H1341		JSMA-PMH10AB			2500
H1342		JSMA-PMH10AH	1.0	1500	8192
H1345		JSMA-PMH10A5			15 bit(ABS)
H1347		JSMA-PMH10A7			17 bit
H134A		JSMA-PMH10AA			17 bit(ABS)
H1351		JSMA-PMC10AB			2500
H1352		JSMA-PMC10AH			8192
H1355		JSMA-PMC10A5			15 bit(ABS)
H1357		JSMA-PMC10A7			17 bit
H135A		JSMA-PMC10AA			17 bit(ABS)

dn-08 Display Cn030 Setting	Drive Model JSDAP	Motor Model	Motor Standards		Encoder Specification
			Watt(KW)	Speed(rpm)	
H1511	50A3	JSMA-PMA15AB	1.5	1000	2500
H1512		JSMA-PMA15AH			8192
H1515		JSMA-PMA15A5			15 bit(ABS)
H1517		JSMA-PMA15A7			17 bit
H151A		JSMA-PMA15AA			17 bit(ABS)
H1521		JSMA-PMB15AB		2000	2500
H1522		JSMA-PMB15AH			8192
H1525		JSMA-PMB15A5			15 bit(ABS)
H1527		JSMA-PMB15A7			17 bit
H152A		JSMA-PMB15AA			17 bit(ABS)
H1531		JSMA-PMC15AB	3000	15 bit(ABS)	2500
H1532		JSMA-PMC15A5H			8192
H1535		JSMA-PMC15A5			17 bit
H1537		JSMA-PMC15A7			17 bit(ABS)
H153A		JSMA-PMC15AA			2500
H1541		JSMA-PMB20AB			8192
H1542	2.0	JSMA-PMB20AH	2000	15 bit(ABS)	15 bit(ABS)
H1545		JSMA-PMB20A5			17 bit
H1547		JSMA-PMB20A7			17 bit(ABS)
H154A		JSMA-PMB20AA			2500
H1551		JSMA-PMC20AB	3000	15 bit(ABS)	8192
H1552		JSMA-PMC20AH			17 bit
H1555		JSMA-PMC20A5			17 bit(ABS)
H1557	2.0	JSMA-PMC20A7	3000	17 bit	2500
H155A		JSMA-PMC20AA			17 bit(ABS)

dn-08 Display Cn030 Setting	Drive Model JSDAP	Motor Model	Motor Standards		Encoder Specification
			Watt(KW)	Speed(rpm)	
H1711	75A3	JSMA-PMB30AB	3.0	2000	2500
H1712		JSMA-PMB30AH			8192
H1715		JSMA-PMB30A5			15 bit(ABS)
H1717		JSMA-PMB30A7	2000	17 bit	17 bit
H171A		JSMA-PMB30AA			17 bit(ABS)
H1721		JSMA-PMC30AB	3000	2500	2500
H1722		JSMA-PMC30AH			8192
H1725		JSMA-PMC30A5			15 bit(ABS)
H1727		JSMA-PMC30A7	3.0	17 bit	17 bit
H172A		JSMA-PMC30AA			17 bit(ABS)
H1732		JSMA-PMH30AH			8192
H1735		JSMA-PMH30A5	1500	15 bit(ABS)	15 bit(ABS)
H1737		JSMA-PMH30A7			17 bit
H173A		JSMA-PMH30AA			17 bit(ABS)
H1822	100A3	JSMA-PMH44AH	4.4	1500	8192
H1825		JSMA-PMH44A5			15 bit(ABS)
H1827		JSMA-PMH44A7			17 bit
H182A		JSMA-PMH44AA			17 bit(ABS)
H1832		JSMA-PHH30AH	3.0	1500	8192
H1835		JSMA-PHH30A5			15 bit(ABS)
H1837		JSMA-PHH30A7			17 bit
H183A		JSMA-PHH30AA			17 bit(ABS)
H1922	150A3	JSMA-PMH55AH	5.5	1500	8192
H1925		JSMA-PMH55A5			15 bit(ABS)
H1927		JSMA-PMH55A7	3.0	1500	17 bit
H192A		JSMA-PMH55AA			17 bit(ABS)

dn-08 Display Cn030 Setting	Drive Model JSDAP	Motor Model	Motor Standards		Encoder Specification	
			Watt(KW)	Speed(rpm)		
H1932	150A3	JSMA-PHH44AH	4.4	2000	8192	
H1935		JSMA-PHH44A5			15 bit(ABS)	
H1937		JSMA-PHH44A7			17 bit	
H193A		JSMA-PHH44AA			17 bit(ABS)	
H1A12	200A3	JSMA-PMH75AH	7.5	Watt(KW)	Speed(rpm)	
H1A15		JSMA-PMH75A5			15 bit(ABS)	
H1A17		JSMA-PMH75A7			17 bit	
H1A1A		JSMA-PMH75AA			17 bit(ABS)	
H1A22		JSMA-PHH55AH	5.5		8192	
H1A25		JSMA-PHH55A5			15 bit(ABS)	
H1A27		JSMA-PHH55A7			17 bit	
H1A2A		JSMA-PHH55AA			17 bit(ABS)	
H1B12	300A3	JSMA-PMH110AH	11.0	1500	8192	
H1B15		JSMA-PMH110A5			15 bit(ABS)	
H1B17		JSMA-PMH110A7			17 bit	
H1B1A		JSMA-PMH110AA			17 bit(ABS)	
H1B22		JSMA-PMH150AH	15.0		8192	
H1B25		JSMA-PMH150A5			15 bit(ABS)	
H1B27		JSMA-PMH150A7			17 bit	
H1B2A		JSMA-PMH150AA			17 bit(ABS)	
H1B32		JSMA-PHH75AH	7.5		8192	
H1B35		JSMA-PHH75A5			15 bit(ABS)	
H1B37		JSMA-PHH75A7			17 bit	
H1B3A		JSMA-PHH75AA			17 bit(ABS)	

400V

dn-08 Display Cn030 Setting	Drive Model JSDAP	Motor Model	Motor Standards		Encoder Specification
			Watt(KW)	Speed(rpm)	
H1211	25B	JSMA-PMB10BB	1.0	2000	2500
H1212		JSMA-PMB10BH			8192
H1215		JSMA-PMB10B5			15 bit(ABS)
H1217		JSMA-PMB10B7			17 bit
H121A		JSMA-PMB10BA			17 bit(ABS)
H1231		JSMA-PMB15BB	1.5	2000	2500
H1232		JSMA-PMB15BH			8192
H1235		JSMA-PMB15B5			15 bit(ABS)
H1237		JSMA-PMB15B7			17 bit
H123A		JSMA-PMB15BA			17 bit(ABS)
H1251	35B	JSMA-PMB20BB	2.0	2000	2500
H1252		JSMA-PMB20BH			8192
H1255		JSMA-PMB20B5			15 bit(ABS)
H1257		JSMA-PMB20B7			17 bit
H125A		JSMA-PMB20BA			17 bit(ABS)
H1311	35B	JSMA-PMB20BB	2.0	2000	2500
H1312		JSMA-PMB20BH			8192
H1315		JSMA-PMB20B5			15 bit(ABS)
H1317		JSMA-PMB20B7			17 bit
H131A		JSMA-PMB20BA			17 bit(ABS)
H1331	3.0	JSMA-PMB30BB	3.0	2000	2500
H1332		JSMA-PMB30BH			8192
H1335		JSMA-PMB30B5			15 bit(ABS)
H1337		JSMA-PMB30B7			17 bit
H133A		JSMA-PMB30BA			17 bit(ABS)




dn-08 Display Cn030 Setting	Drive Model JSDAP	Motor Model	Motor Standards		Encoder Specification
			Watt(KW)	Speed(rpm)	
H1341	35B	JSMA-PMH30BB	3.0	1500	2500
H1342		JSMA-PMH30BH			8192
H1345		JSMA-PMH30B5			15 bit(ABS)
H1347		JSMA-PMH30B7			17 bit
H134A		JSMA-PMH30BA			17 bit(ABS)
H1401	50B	JSMA-PMB30BB	3.0	2000	2500
H1402		JSMA-PMB30BH			8192
H1405		JSMA-PMB30B5			15 bit(ABS)
H1407		JSMA-PMB30B7			17 bit
H140A		JSMA-PMB30BA			17 bit(ABS)
H1411	50B	JSMA-PMH30BB	3.0	1500	2500
H1412		JSMA-PMH30BH			8192
H1415		JSMA-PMH30B5			15 bit(ABS)
H1417		JSMA-PMH30B7			17 bit
H141A		JSMA-PMH30BA			17 bit(ABS)
H1421	75B	JSMA-PMH44BB	4.4	1500	2500
H1422		JSMA-PMH44BH			8192
H1425		JSMA-PMH44B5			15 bit(ABS)
H1427		JSMA-PMH44B7			17 bit
H142A		JSMA-PMH44BA			17 bit(ABS)
H1501	75B	JSMA-PMH44BB	4.4	1500	2500
H1502		JSMA-PMH44BH			8192
H1505		JSMA-PMH44B5			15 bit(ABS)
H1507		JSMA-PMH44B7			17 bit

dn-08 Display Cn030 Setting	Drive Model JSDAP	Motor Model	Motor Standards		Encoder Specification
			Watt(KW)	Speed(rpm)	
H150A	75B	JSMA-PMH44BA	4.4	1500	17 bit(ABS)
H1511		JSMA-PMH55BB	5.5	1500	2500
H1512		JSMA-PMH55BH			8192
H1515		JSMA-PMH55B5			15 bit(ABS)
H1517		JSMA-PMH55B7			17 bit
H151A		JSMA-PMH55BA			17 bit(ABS)
H1611	100B	JSMA-PMH75BB	7.5	1500	2500
H1612		JSMA-PMH75BH			8192
H1615		JSMA-PMH75B5			15 bit(ABS)
H1617		JSMA-PMH75B7			17 bit
H161A		JSMA-PMH75BA			17 bit(ABS)

Chapter 4 Trial Operation

Before proceeding with trial run, please ensure that all the wiring is correct.

Trial run description below covers the operation from keypad and also from an external controller such as a PLC. Trial run with external controller speed control loop (analog voltage command) and position

(1) No-load servo motor. Trial run (Reference:4-1)	
A. Servo Drive wiring and motor installation	B. Purpose of trial run
	<p>Confirm if the items below are correct:</p> <ul style="list-style-type: none"> . Drives power cable wiring . Servo Motor wiring . Encoder wiring . Setting servo motor rotation direction and speed
(2) No-load servo motor with a host controller. Trial run (Reference:4-2)	
	<p>Confirm if the items below are correct:</p> <ul style="list-style-type: none"> . Control signal wiring between host controller and servo drive. . Servo motor rotation direction, speed and rotating number . . Brake function, operation limit function and protection function.
(3) Servo motor connected to load and controlled by a host controller. Trial run (Reference:4-3)	
	<p>Confirm if the items below are correct:</p> <ul style="list-style-type: none"> . Servo motor rotation direction, speed and mechanical operation range. . Set related control parameters.

control loop (external pulse command).

4-1 Trial Operation for Servomotor without Load

To carry out a successful trial run follow the steps below and ensure that drive wiring is correct and as specified.

Warning

In order to prevent potential damage,prior to trial run ensure that the driven mechanism, couplings and belts etc are disconnected from the motor.

1. Installation of servo motor.

Ensure that the motor is installed securely so that there is no movement and vibration during trial run.


2. Wiring.

Check servo drive , motor power connections and motor encoder connection.

No control signal wiring is required of this stage thus remove connector (CN1) from the servo drive.

3. Servo drive power.

Apply power to servo drive. If the display showed any Alarm message as below, please refer to chapter 8 to identify the cause.



The above is caused by Input terminals **CCWL (Counter clockwise Limit)** and **CWL (Clockwise Limit)** being activated at the same time. See (the default setting of high or low input logic state according to the description in section 5-6-1). Because of the alarm, the servo can not operate normally.

Set the parameter **Cn002.1=1** to disable the drive limit function temporarily during trial run period.

Steps for setting parameter Cn002.1 (CCWL &CWL Rotation limit selection).

Setup	Keys	LED Display	Description
1	Power on		On" power on " Drive Status is displayed.
2			Press MODE-Key 4 times to display Cn001.
3			Press INCREMENT-Key once to display Cn002.
4			Press ENTER-Key for 2 secs to display the preset value of Cn002. Note: Cn 002 includes 4 digits corresponding to Cn002.0,Cn002.1,Cn002.2 & Cn002.3.
5			Press ENTER-Key once to move to the 2 nd digit for (Cn 002.1).
6			Press INCREMENT- Key once to adjust the 2 nd digit to 1. Disable the function of external limits CCWL and CWL.
7		 	To save the setting value by Press the ENTER- Key for 2 seconds until "SET" is displayed briefly and then display is returned to parameter Cn-002.

After accomplish these steps, reset the power. If there are any other alarms then refer to section **8-2 (Clearing Alarms)**. Once there is no alarms then operate the drive again. If any of the alarms can not be cleared, please contact your local supplier for assistance.

4. Mechanical Brake Release.

When a brake type servo motor is used then must release the brake before starting trial run by applying 24vdc voltage to brake terminals.

5. Keypad Trial run (JOG function).

Jog function can be used to check if motor speed and rotation direction is correct.

Parameters Sn 201(internal speed command 1) and Cn004 (motor rotation direction selection)

Can be used to set the required speed and direction.

Warning!

Set the required JOG speed before the trial run otherwise the motor will run at the default speed set in parameter Sn201(internal speed command 1).

Warning!

Regardless of external SON (servo on) is active or not, Servo motor will get excitation as soon as JOG is activated.

Steps for setting JOG function:

Step	Keys	LED Display	Description
1	Power on		On" power on " Drive Status is displayed.
2			Press MODE-Key twice to view diagnostics parameter dn-01.
3			Press INCREMENT-Key 4 times to display dn-5.
4			Press ENTER-Key for 2 seconds to enter JOG MODE . Motor will power on immediately.
5			Press INCREMENT-Key , motor will run in the pre-defined positive direction.
6			Press DECREMENT-Key , motor will run in the pre-defined negative direction.
7			Press MODE-Key once to return to dn-05 and parameter selection. Motor power will be turned off immediately.

4-2 Trial Operation for Servo motor without Load from Host Reference

Check and ensure that all power connections to the drive and motor and control signal connection between the host controller and the drive are correct. Motor must be mechanically disconnected from the load.


Following section describes the trial run when using a host controller such as a PLC.

Two trial runs have been discussed. Speed control mode (Section B) and Position control mode (Section C).

Section A shows the connections and SON signal (servo on) requirements for both trial runs.

A. Launching Servo motor

Example wiring diagram:



a. **Disable Analog Input command terminals.**

Speed control mode: Link analog input terminal SIN to 0V terminal (AG).

Position control mode: Link external pulse command terminals "Pulse" to "/Pulse" and "Sign" to "/Sign".

b. **Enable Servo ON Signal**

Connect **SON** terminal to IG 24 (0V) terminal (Digital Ground).

On drive power up servo will be turned on. Now check for any Alarms. If any alarms then refer to Chapter 8-2 for how to reset the Alarms.

Warning


- **To control the motor operating and stop, please input Torque/Speed/Position command after Servo ON.**
- **When input Torque/Speed/Position command, Please do not control the motor operating and stop by using servo on signal.**

B. Trial run in Speed control mode(Cn001=1).

1. Wiring check:

Check and ensure that all power cable and control signal connections are correct as shown below.

To be able to adjust the speed for test connect a potentiometer between terminals SIN (analog input voltage) and AG (Analog Ground). Set the analog input voltage to 0V. (No speed reference).



2. Apply Servo on.

Apply power to the drive and activate (**SON**) signal by switching SON terminal to IG24 (input digital Ground).

If the motor rotates slowly, while the speed analog input voltage is 0 volts

then use **dn-07** function to auto offset adjustment for the analog input value. (refer to **section 3-2-2**).

3. Check the relationship between motor speed and the analog input speed command.

Increase the analog speed input voltage gradually (by potentiometer) and monitor the actual motor speed by parameter **Un0-01**.


Check if motor rotation direction is correct and if necessary set it by parameter **Cn004**.

Check for correctness of analog speed command ratio in relation to the preset in parameter (**Sn216**) and analog speed command limit as set in parameter (**Sn218**).

Finally, switch off **SON signal** (turn off the servo motor).

4. Connection with a host controller.

Check and ensure that the wiring for the servo drive and host controller, speed analog signal input (**SIN**), and encoder output (**PA**, **/PA**, **PB**, **/PB**, **PZ**, **/PZ**) are all correct and according to the diagram below:



5. Confirm the rotation number and encoder output of Servo Motor.

Use parameter Un-14 to check if the Motor feed back (number of revolutions) per minute is correct and the same as number of revolutions sent by the host controller.


If there is any difference then check and make sure that parameter Cn005 (Encoder ppr) is set correctly.

Once this is complete remove SON signal to switch off power to the motor.

C. Position control mode trial run (Cn001=2).

1. Wiring:

Check and ensure that all power connections to the drive and motor and control signal connections are correct as diagram below.



2. Setting electronic gear ratio.

Set electronic gear ratio parameters Pn302~Pn306 as required for the positioning application.
(refer to section 5-4-3).

Note: Electronic gear ratio parameter can be used to scale the command output pulse.

This would be useful in transmission applications where move distance per move command pulse has to be scaled due to mechanical requirements.

3. Apply Servo on.

Apply power to the drive and activate (**SON**) signal by switching SON terminal to IG24 (input digital Ground).

4. Confirm motor speed, direction and number of revolutions.

Apply a low-speed pulse command from the host controller to the servo drive so that the servo motor operates at low-speed.

- Compare the number of pulses per revolution from parameters **Un-15** (motor feed back pulse ppr) and **Un-17** (Input command ppr) these should be the same.
- Compare the number of revolutions using parameters Un-14 (motor feed back rotation number) and Un-16 (pulse command rotation number) these should be the same.

If there are differences then adjust electronic gear ratio parameters **Pn302~Pn306** as required and test again until the result is satisfactory.

If the direction of motor rotation is incorrect then check and if necessary set parameter Pn 301.0 (position pulse command types).

Also check and if necessary set parameter **Pn314** (Position command direction selection).

Once the test result is correct then remove SON signal. (Power to the motor is switched off).

4-3 Trial Operation with the Servo motor Connected to the Machine


Warning

Servo drive parameters must be set correctly otherwise damage to machinery and potential injury may result.

Do not close to the machine after temporary power loss, the machine may restart unexpected.

Please take the measures highlighted in the section below before trial run with load.

- Consider the Mechanical system requirements and set the parameters appropriate for control by the host controller.
- Ensure that the rotation direction and speed are suitable for the Mechanical system.



Steps required for Trial run.

1. Ensure that the ServoDrive Power is off.

2. Connect the servo motor to the load shaft.

Refer to Chapter 1-5 to check the installation guidelines for the servo motor.

3. Gain adjustment for the servo control loop.

Refer to Chapter 5-5 for details.

4. Trial run with a host controller.

Run command is to be signaled by the host controller.

Refer to Chapter 4-2 to choose the required trial run mode (Speed control or position control modes) according to the application and set and adjust the parameters if necessary for the application.

5. Repeat adjusting and record the set parameter values.

Repeat steps 3 and 4 until the mechanical system is operating satisfactorily then record the Gain value and the parameters changes for the future use.

Chapter 5 Control Functions

5-1 Control Mode Selection

There are three control modes in the servo drive, torque, speed and position modes can be selected individually or as a combination according to the selection table below:


Parameter	Name	Setting	Description	Default Value	Control Mode
★● Cn001	Control mode selection	0	Torque control To use one analog voltage command signal to control torque. Please refer to 5-2 .	2	ALL
		1	Speed control Input contacts SPD1 and SPD2 can be used to select 4 -steps of speed. Please refer to section 5-3-1 .		
		2	Position control (External pulse command) Four separate selectable pulse command types are possible to control position. Please refer to section 5-4-1 .		
		3	Position / Speed control switch Input contact MDC can be used to switch between position & speed control. Please refer to section 5-6-2 .		
		4	Speed / Torque control switch Input contact MDC can be used to switch between speed & torque control. Please refer to section 5-6-2 .		
		5	Position / Torque control switch Input contact MDC can be used to switch between position & torque control. Please refer to section 5-6-2 .		
		6	Position control (internal position command) Input contacts POS 1~POS 4 can be used to select 16 programmable preset position commands to control position. Please refer to 5-4-2 .		
		7	Internal Position / Speed control switch Input contact MDC can be used to switch control mode between position and speed, please refer to chapter 5-6-2 .		
		8	Internal Position / Torque control switch Input contact MDC can be used to switch control mode between position and torque, please refer to chapter 5-6-2 .		
		9	Tool Turret mode Please refer to 5-7 .		
		A	Internal/External Position switching Input contactor MDC can be switch between internal and external position. Please refer to 5-7 .		

New setting will become effective after re-cycling the power.


5-2 Torque Mode

Torque mode is used in applications such as printing machines, coil wiring machines, injection molding machines and specific application that requiring torque control.

Diagram below shows the torque control process diagram.



Analog voltage torque command is applied to the drive input terminals as shown below:



Caution!

Care should be taken in selection of required torque direction CW/CCW.

Please refer to Chapter 5-2-4.


5-2-1 Analog Torque Command Ratio

Analog torque command ratio can be used to adjust the relationship between Input voltage torque command and actual torque command.

Parameter	Name	Default	Unit	Setting range	Control Mode
Tn103	Analog torque command ratio	300	%/10V	0~600	T

Setting example: refer to the following diagram.

- With Tn103 set to 300, a torque command input voltage of 10V, corresponds to 300% of rated torque.
For input voltage of 5V, actual torque command will be 150% of rated torque.
- With Tn103 set to 200, a torque command input voltage of 10V, corresponds to 200% of rated torque. For input voltage of 5V, actual torque command will be 100%.




5-2-2 Analog Speed Limit Proportion

Parameter	Name	Default	Unit	Setting range	Control Mode
Tn109	Analog Speed Limited Proportion	3000	rpm	100 4500	T

Setting example:

- (1) If **Tn109** is set to 3000, the corresponding speed limited to the input voltage of 10V is 3000 rpm; if the input voltage is 5V, the corresponding speed should be limited to 1500 rpm.
- (2) If **Tn109** is set to 2000, the corresponding speed limited to the input voltage of 10V is 2000 rpm; if the input voltage is 5V, the corresponding speed should be limited to 1000 rpm.




5-2-3 Adjusting the Analog Torque Command Offset

For a torque command of 0V, motor could possibly be rotating slowly.

To rectify this effect by adjust offset value in parameter **Tn104** or use auto offset adjust feature. (Please refer to section 3-2-2).

Note: To check and set the offset to zero, insert a link between analog torque command contact SIN (CN1-26) and analog ground contact AG (CN1-29).

Parameter	Name	Default	Unit	Setting range	Control mode
Tn104	Analog torque command offset	0	mV	-10000~10000	T



5-2-4 Torque Command Linear Acceleration and Deceleration

A smooth torque command can be achieved by enabling acceleration/Deceleration parameter **Tn101**.


Parameter	Name	Setting	Description	Setting range	Control mode
★ Tn101	Linear acceleration/ deceleration method	0	Disable	0 2	T
		1	Enable		
		2	Enable Torque command smooth accel/decel time Constant.		

Torque command acceleration/deceleration time is the time taken for the torque to rise from zero to the required level by **Tn102**.

As per diagram below:-

Parameter	Name	Default	Unit	Setting Range	Control mode
★ Tn102	Linear acceleration /deceleration time period	1	msec	1~50000	T

New setting will become effective after re-cycling the power.



Setting examples:

- (1) To achieve 50% of rated torque output in 10msec:

$$Tn102 = 10(\text{msec}) \times \frac{100\%}{50\%} = 20(\text{msec})$$

- (2) To achieve 75% of rated torque output in 10msec:

$$Tn102 = 10(\text{msec}) \times \frac{100\%}{75\%} = 13(\text{msec})$$

5-2-5 Definition of Torque Direction

In torque mode, torque direction can be defined by one of the following three methods.

- (1) Input contacts **RS1, RS2**. (Torque command CW/CCW selectable by programmable input)
- (2) Parameter **Cn004**. (Motor rotation direction)
- (3) Input contact **TRQINV**. (reverse torque command)

Caution!


All 3 methods can be active at the same time.

User must ensure that correct selections are made for these three selections.

Input Contact		Description	Control mode
RS2	RS1		
0	0	Zero torque	T
0	1	Rotation in the current torque command direction	
1	0	Reverse the current torque command direction	
1	1	Zero torque	

Note: RS2 and RS1 contact status “1” (ON) and “0” (OFF).

Please check 5-6-1 to set the required high /Low signal levels (PNP/NPN) .

Parameter Signal	Name	Setting	Description			Control mode	
Cn004	Motor rotation direction (load end) 	No.	Torque Control	Speed Control		S/T	
		0	Counter Clockwise(CCW)	Counter Clockwise (CCW)			
		1	Clockwise(CW)	Counter Clockwise (CCW)			
		2	Counter Clockwise (CCW)	Clockwise (CW)			
		3	Clockwise (CW)	Clockwise (CW)			

Input contact TRQINV	Description	Control mode
0	Rotation in current torque command direction	T
1	Reverse torque command direction	

Note: Input contacts status “1” (ON) and “0” (OFF).

Please refer to 5-6-1 to set the required high /Low signal levels (PNP/NPN) selection.

5-2-6 Internal Torque Limit

In torque Control mode, user can set internal torque limit values as required.

Set as below:-

Parameter	Name	Default	Unit	Setting range	Control mode
Cn010	CCW Torque command limit	300	% %	0~300 -300~0	ALL
		260			
		250			
		240			
		220			
		200			
Cn011	CW Torque command limit	-300	% %	-300~0	ALL
		-260			
		-250			
		-240			
		-220			
		-200			

5-2-7 Limiting Servomotor Speed during Torque Control

In torque control, input contacts SPD1 and SPD2 can be used for selecting one of the two methods below for setting speed limits.

- (1) External Analog command (Default) Signal is applied to terminals PIC & AG (pins 27& 29 on CN1)
- (2) Selection of Three presentable Limits (Tn105~Tn107) according to the table below.


Caution! For achieving smooth speed response please refer to section 5-3-6.

Input contact SPD2	Input contact SPD1	Speed limit command	Control mode
0	0	External analog command SIC(CN1-26)	T
0	1	Internal speed limit1 Tn105	
1	0	Internal speed limit2 Tn106	
1	1	Internal speed limit3 Tn107	

Note: Input contacts status "1" (ON) and "0" (OFF).

Please check 5-6-1 to set the required high /Low signal levels (PNP/NPN) selection.

Below is the external analog speed limit command wiring diagram:



Internal presentable speed limit parameters for torque control mode are listed below:

These preset limits apply to both CW & CCW directions.

Parameter	Name	Default	Unit	Setting range	Control mode
Tn105	Internal speed limit 1	100	rpm	0~1.5*rated speed	T
Tn106	Internal speed limit 2	200	rpm	0~1.5*rated speed	T
Tn107	Internal speed limit 3	300	rpm	0~1.5*rated speed	T


P.S also refer to page 6-11 for detail.

5-2-8 Additional Torque Control Functions

Torque Output Monitor

When the torque level in CW or CCW directions becomes greater than the value set in **Tn108** (torque level monitor value), the output contact **INT** is active.

Parameter	Name	Default	Unit	Setting range	Control mode
Tn108	Torque output monitor level	0	%	0~300	ALL



Note: Input contacts status "1" (ON) and "0" (OFF).

Please check 5-6-1 to set the required high /Low signal levels (PNP/NPN) selection.

Torque Smoothing Filter

Torque vibration can be diminution by setting an appropriate value in Cn034 (Torque command smoothing filter). In the other hand, this will cause a delay in the response time of the torque loop.



Parameter	Name	Default	Unit	Setting range	Control mode
Cn034	Torque smoothing filter	500	Hz	0~5000	ALL

5-3 Speed Mode

Speed Mode is necessary for applications that require precisely speed control, such as weaving, drilling and CNC type machines. Diagrams below shows the speed control system in two parts.

First stage shows **Speed processing and conditioning** and the second stage shows the **Speed controller**

With PI/P control modes, and controller1&2 selection and interface with torque control stage.



5-3-1 Selection for Speed Command

In Speed control, input contacts SPD1 and SPD2 can be used for selecting one of the two methods below for setting speed limits.


- (1) External Analog command (Default) : Analog signal is input from terminals SIC & AG (pins 26& 29 on CN1)
- (2) Internal speed command: Selection of Three presentable Limits according to the table below.

Input Contact SPD2	Input Contact SPD1	Speed Command	Control Mode
0	0	External analog command SIC(CN1-26)	S
0	1	Internal speed command 1 Sn201	
1	0	Internal speed command 2 Sn202	
1	1	Internal speed command 3 Sn203	

Note: Input contacts status "1" (ON) and "0" (OFF).

Please check 5-6-1 to set the required high /Low signal levels (PNP/NPN) selection.

Diagram below shows the external analog speed command wiring:



Internal presettable speed limit parameters for speed command mode are listed below:

These preset limits apply to both CW & CCW directions.

Parameter	Name	Default	Unit	Setting range	Control mode
Sn201	Internal speed command 1	100	rpm	0~1.5*rated speed	S
Sn202	Internal speed command 2	200			
Sn203	Internal speed command 3	300			


5-3-2 Analog Speed Command Ratio

Analog speed command ratio can be used to adjust the relationship between Input voltage speed command and actual speed command.

Parameter	Name	Default	Unit	Setting range	Control mode
Sn216	Analog speed command ratio	Rated Speed	rpm/10V	100~6000	S

Setting Example:

- (1) With **Sn216 set to 3000**, a speed command input voltage of 10V, corresponds to 3000rpm; for an input voltage of 5V speed command will be 1500rpm.
- (2) With **Sn216 set to 2000**, a speed command input voltage of 10V, corresponds to 2000rpm, for an input voltage of 5 volts speed command will be 1000rpm.



5-3-3 Adjusting the Analog Reference Offset


For a speed command of 0V, motor could possibly be rotating slowly.

To rectify this effect by adjust offset value manually in parameter **Sn217** or use auto offset adjust feature. (Please refer to section 3-2-2).

Note: To check and set the offset to zero, insert a link between analog torque command contact SIC (CN1-26) and analog ground contact AG (CN1-29).

Parameter	Name	Default	Unit	Setting range	Control mode
Sn217	Analog speed command offset adjust	0	mV	-10000~10000	S

Refer to the following diagrams:




5-3-4 Analog Reference for Speed Command Limit

A maximum limit for analog speed can be set by Sn218.

Parameter	Name	Default	Unit	Setting range	Control mode
Sn218	Analog speed command limit	Rated rpm x 1.02	rpm	100~4500	S

5-3-5 Encoder Signal Output

Servo motor encoder pulse signal can be output to a host controller to establish an external control loop.



Set the required encoder Pulse Per Revolution (PPR) in parameter Cn005.





Default output value is the actual encoder PPR.

Parameter	Name	Default	Unit	Setting range	Control mode
★ Cn005	Encoder pulse output scale	2500	pulse	1~Encoder PPR	ALL
		8192			
		32768			

New setting will become effective after re-cycling the power.

Encoder pulse output terminal description:

Pin	Name	Pin NO. of CN1	Control mode
PA	Encoder pulse output A Phase signal	CN1-35	ALL
/PA	Encoder pulse output /A Phase signal	CN1-36	
PB	Encoder pulse output B Phase signal	CN1-37	
/PB	Encoder pulse output /B Phase signal	CN1-38	
PZ	Encoder pulse output Z Phase signal	CN1-39	
/PZ	Encoder pulse output /Z Phase signal	CN1-40	



5-3-6 Smoothing the Speed Command

Sn205 can be used to eliminate speed overshoot and motor vibration by selecting one of the acceleration /deceleration methods which is suitable for the application from the table below.

Parameter	Name	Setting	Description	Control mode
Sn205	Speed command accel/decel smooth method	0	Disable accel/decel smooth function	S
		1	Smooth accel/decel according to parameter Sn206	
		2	Linear accel/decel according to parameter Sn207	
		3	S-curve accel /decel according to parameter Sn208	


Above three methods of Acceleration/deceleration are described below.

(1)Speed command smooth ac/deceleration:

Set **Sn205=1** to enable the use of speed command smooth acceleration/deceleration function.

Parameter	Name	Default	Unit	Setting range	Control mode
Sn206	Speed command smooth accel/decel time Constant	1	msec	1~10000	S

Smooth acceleration/deceleration time corresponds to the time in which the speed command increases from 0 to 63.2% as shown in diagram below.



Setting example:

(1) To achieve 95% of speed command output in 30msec:

$$\text{Set } Sn206 = \frac{30(\text{msec})}{-\ln(1-95\%)} = 10(\text{msec})$$

(2) To achieve 75% of speed command output in 30msec:

$$\text{Set } Sn206 = \frac{30(\text{msec})}{-\ln(1-75\%)} = 22(\text{msec})$$


In= Natural log

(2) Speed command linear acceleration/deceleration function:

Set **Sn205=2** to enable the use of speed command linear acceleration/deceleration function.

Parameter	Name	Default	Unit	Setting range	Control mode
Sn207	Speed command linear accel/decel time constant	1	msec	1~50000	S

Linear acceleration/deceleration time corresponds to the time in which the speed increases (linearly) from zero to the rated speed. As shown in the diagram below.



Setting examples:

(1) To achieve 50% of rated speed output in 10msec:

$$\text{Set } Sn207 = 10(\text{msec}) \times \frac{100\%}{50\%} = 20(\text{msec})$$

(2) To achieve 75% of rated speed output in 10msec:


$$\text{Set } Sn207 = 10(\text{msec}) \times \frac{100\%}{75\%} = 13(\text{msec})$$

S-Curve Speed Command Acceleration/Deceleration:

Set Sn205=3 to enable the use of S-Curve speed command ac/deceleration function.

Parameter	Name	Default	Unit	Setting range	Control mode
Sn208	S-Curve speed command accel/decel time setting	1	msec	1~1000	S
Sn209	S-Curve speed command acceleration time setting	200	msec	0~5000	S
Sn210	S-Curve speed command deceleration time setting	200	msec	0~5000	S

In applications where normal acceleration/deceleration on ramp up or ramp down bring in vibration of the mechanical system. S- curve acceleration/deceleration parameters could help to reduce vibration as diagram below:



Caution! Setting Rule: $\frac{t_a}{2} > t_s$, $\frac{t_d}{2} > t_s$


5-3-7 Setting Rotation Direction

Motor rotation direction in speed mode can be set by parameter **Cn004 (Motor rotation direction)** and input contact **SPDINV** according to the tables below.

Caution!

Both methods can be operated at the same time.

Ensure that these parameters are set correctly for the required direction.

Parameter	Name	Setting	Description		Control mode
Cn004	Motor rotation direction (observation from load side). 	No.	Torque control	Speed control	S/T
		0	Counter Colckwise (CCW)	Counter Colckwise (CCW)	
		1	Colckwise (CW)	Counter Colckwise (CCW)	
		2	Counter Colckwise (CCW)	Colckwise (CW)	
		3	Colckwise (CW)	Colckwise (CW)	

Input contact SPDINV	Description	Control mode
0	Rotation by speed command direction.	S
1	Rotation by reverse speed command direction.	

Note: Input contacts status “1” (ON) and “0” (OFF).

Please check 5-6-1 to set the required high /Low signal levels (PNP/NPN) selection.

5-3-8 Speed Loop Gain

In speed mode there are two speed controller loops, with separate Gain (P) and Integral (I) functions. Speed controllers 1 or 2 can be selected by setting one of the multi-function input terminals, to selection G-SEL or by setting one of the parameters Cn20-Cn24 as required.


Please refer to section 5-3-11 section B for more details.

Parameter	Name	Default	Unit	Setting range	Control mode
Sn211	Speed loop gain 1	40	Hz	10~1500	Pe/Pi/S
Sn212	Speed loop integral time constant 1	100	x0.2 ms	1~5000	Pe/Pi/S
Sn213	Speed loop gain 2	40	Hz	10~1500	Pe/Pi/S
Sn214	Speed loop integral time constant 2	100	x0.2 ms	1~5000	Pe/Pi/S

Diagram below shows the speed controller.

Setting a high speed loop gain or a lower speed loop integral time provides a faster speed control response time.

For more details refer to section 5-5.



5-3-9 Notch Filter

The function of the Notch filter is to suppress mechanical system resonance.

Resonance occurs due to low mechanical system rigidity (high springiness) of transmission systems used with servo motors such as couplings, bearings, lead screws, etc.


Enter the mechanical system vibration (resonance frequency) in parameter Cn013 (Notch Filter frequency) and adjust Cn014 to set the filter bandwidth scaling factor.

Lower the setting of Cn014 value, wider is the notch filter frequency bandwidth. The adjustment required depends on the application.

Caution!

If Cn013 is set to “0” the Notch filter is disabled.

Parameter	Name	Default	Unit	Setting range	Control mode
Cn013	Notch Filter frequency	0	Hz	0~1000	Pi/Pe/S
Cn014	Notch Filter Band Width Scaling factor	7	X	1~100	Pi/Pe/S



5-3-10 Torque Limit of Speed Control Mode

In speed mode, the motor torque limit input contact **TLMT** could be used to select one of the two methods below:

- (1) Internal torque limit: Using default **Cn010** (CCW Torque command limit) and **Cn011** (CW Torque command limit).
- (2) External analog command: Using two separate analog voltage command signals at input terminals **TIC (CN1-27)** to limit CCW torque and CW torque.

As shown in the table below:

Input contact TLMT	CCW torque command limit source	CW torque command limit source	Control mode
0	Cn010	Cn011	ALL
1	External analog command TIC(CN1-27)	External analog command TIC(CN1-27)	Pi/Pe/S

Note: Input contacts status "1" (ON) and "0" (OFF).

Please check 5-6-1 to set the required high /Low signal levels (PNP/NPN) selection.


Caution!

To use external analog torque command limit, if analog torque command limit is greater than internal torque command limit, the internal torque command limit has the priority over external analog torque command limit.

Internal Torque command limit is set as below.

Parameter	Name	Default	Unit	Setting range	Control mode
Cn010	CCW Torque command limit	300	%	0~300	ALL
		260			
		250			
		240			
		220			
		200			
		-300			
Cn011	CW Torque command limit	-260	%	-300~0	ALL
		-250			
		-240			
		-220			
		-200			

The diagram below shows the external analog torque limit command wiring:



5-3-11 Gain Switched

PI/P control mode selection (Section A)

Automatic gain 1& 2 switch (Section B)

The selection of **PI/P control mode switch** and **Automatic gain 1& 2 switch** by parameters or from input terminals can be used in following conditions.

- (1) In speed control, to restrain acceleration/deceleration overshooting.
- (2) In position control, to restrain oscillations and decrease the adjusting time.
- (3) To decrease the possible noise caused by using Servo Lock function.

(A) Switching between PI/P Control modes

Switch over from PI to P mode is determined by setting of parameter Cn015.0 and according to the selection options below:

Parameter Signal	Name	Setting	Description	Control mode
Cn015.0 	PI/P control mode switch	0	Switch from PI to P if the torque command is greater than Cn016	Pi/Pe/S
		1	Switch from PI to P if the speed command is greater than Cn017	
		2	Switch from PI to P if the acceleration command is greater than Cn018	
		3	Switch from PI to P if the position error is greater than Cn019	
		4	Switch from PI to P by the input contact PCNT . Set one of the multi function terminals to option 03.	


Parameter	Name	Default	Unit	Setting range	Control mode
Cn016	PI/P control mode switch by (torque command)	200	%	0~399	Pi/Pe/S
Cn017	PI/P control mode switch by (speed command)	0	rpm	0~4500	Pi/Pe/S
Cn018	PI/P control mode switch by (acceleration)	0	rps/s	0~18750	Pi/Pe/S
Cn019	PI/P control mode switch by (position error value)	0	pulse	0~50000	Pi/Pe/S

(1) PI to P mode switch over by comparing *Torque command*.

When the *Torque command* is less than Cn016 PI control is selected.

When the *Torque command* is greater than Cn016 P control is selected..

As shown in diagram below:




(2) PI to P mode switch over by comparing *Speed command*.

When the *Speed command* is less than Cn017 PI control is selected.

When the *Speed command* is greater than Cn017 P control is selected.

As shown in diagram below:




(3) PI to P mode switch over by comparing *Acceleration command*.

When the *Acceleration command* is less than Cn018 PI control is selected.

When the *Acceleration command* is greater than Cn018 P control is selected.

As shown in diagram below:




(4) PI to P mode switch over by comparing *Position Error value*.

When the *Position Error value* is less than Cn019 PI control is selected.

When the *Position Error value* is greater than Cn019 P control is selected.

As shown in diagram below:




(5) PI to P mode switch over by PCNT input contact.

When the **PCNT input contact is open** PI control is selected.

When the **PCNT input contact is closed** P control is selected.

Note: Input contacts status “1” (ON) and “0” (OFF).

Please check 5-6-1 to set the required high /Low signal levels (PNP/NPN) selection.




(B) Automatic gain 1& 2 switching

Selection of **Automatic gain 1& 2 switch** with different **P&I Gains** is possible by setting

Parameter Cn 015.1 to one of the selections listed in the table below.

Parameter Cn 020 can be used for setting a switch delay time between different gains. (Gain 1 and 2)

Parameter	Name	Setting	Description	Control Mode
Cn015.1 	Automatic gain 1& 2 switch	0	Switch from gain 1 to 2 if torque command is greater than Cn021 .	Pi/Pe/S
		1	Switch from gain 1 to 2 if speed command is greater than Cn022 .	
		2	Switch from gain 1 to 2 if acceleration command is greater than Cn023 .	
		3	Switch from gain 1 to 2 if position error value is greater than Cn024 .	
		4	Switch from gain 1 to 2 by input contact G-SEL . Set one of the multi function terminals to option 15 of Hn501.	
Cn015.3	Automatic gain proportion switch	0	JSDAP new automatic gain proportion	ALL
		1	JSDAP old automatic gain proportion	

Parameter	Name	Default	Unit	Setting Range	Control Mode
Cn020	Automatic gain 1& 2 switch delay time.	0	x0.2 msec	0~10000	Pi/Pe/S
Cn021	Automatic gain 1& 2 switch condition (torque command)	200	%	0~399	Pi/Pe/S
Cn022	Automatic gain 1& 2 switch condition (speed command)	0	rpm	0~4500	Pi/Pe/S
Cn023	Automatic gain 1& 2 switch condition (acceleration command)	0	rps/s	0~18750	Pi/Pe/S
Cn024	Automatic gain 1& 2 switch condition (position error value)	0	pulse	0~50000	Pi/Pe/S

Note: Gain 1: is consisted of **Pn 310** (position loop gain 1), **Sn211**(speed loop gain 1) and

Sn212 (Speed loop integral time 1).

Gain 2: is consisted of **Pn 311** (position loop gain 2), **Sn213**(speed loop gain 2) and

Sn214 (Speed loop integral time 2).


- **Automatic gain 1&2 switch condition (by torque command).**

When torque command is less than **Cn021**, Gain 1 is selected.

When torque command is greater than **Cn021**, Gain 2 is selected

When **Gain 2** is active and torque command becomes less than **Cn021** system will automatically switch back to **Gain 1** the switch time delay can be set by Cn020.

As show in the diagram below:




- **Automatic gain 1&2 switch condition (by Speed command).**

When speed command is less than Cn022 Gain 1 is selected.

When speed command is greater than Cn022 Gain 2 is selected.

When **Gain 2** is active and speed command becomes less than **Cn022** system will automatically switch back to **Gain 1** the switch time delay can be set by Cn020.

As show in the diagram below:




- **Automatic gain 1&2 switch condition (by Acceleration command).**

When acceleration command is less than Cn023 Gain 1 is selected.

When acceleration command is greater than Cn023 Gain 2 is selected.

When **Gain 2** is active and acceleration command becomes less than **Cn023** system will automatically switch back to **Gain 1** the switch time delay can be set by Cn020.

As show in the diagram below :




- **Automatic gain 1&2 switch condition (by Position error value).**

When position error value is less than Cn024 Gain 1 is selected.

When position error value is greater than Cn024 Gain 2 is selected.

When **Gain 2** is active and position error value becomes less than **Cn024** system will automatically switch back to **Gain 1** and the switch time delay can be set by Cn020.

As show in the diagram below :




(5) Automatic gain 1&2 switch condition by G-SEL input contact.

When the G-SEL input contact is open Gain 1 is selected.

When G-SEL input contact is closed Gain 2 is selected.

When G-SEL input contact opens again then Gain 1 is selected and switch delay time can be set by Cn20.

As show in the diagram below:



Note: Input contacts status "1" (ON) and "0" (OFF).


Please refer to 5-6-1 for setting required high /Low signal levels (PNP/NPN) selection.

5-3-12 Other Functions

When the speed level in CW or CCW directions becomes greater than the value set in **Cn007** (Speed reached preset), the output contact **INS** operates.

Speed reached preset

Parameter Signal	Name	Default	Unit	Setting Range	Control Mode
Cn007	Speed reached preset	Rated rpm x 1/3	rpm	0~4500	S/T




Note: Input contacts status “1” (ON) and “0” (OFF).

Please check section 5-6-1 to set the required high /Low signal levels (PNP/NPN) selection.

Zero Speed preset

When the speed is less than the speed set in Sn215 (Value of ZS), the output contact **ZS** operates.

Parameter Signal	Name	Default	Unit	Setting Range	Control Mode
Sn215	Value of zero speed	50	rpm	0~4500	S




Note: Input contacts status “1” (ON) and “0” (OFF)

Please check section 5-6-1 to set the required high /Low signal levels (PNP/NPN) selection.

To Zero the speed command according to preset level in Sn215 set Sn204 to selection 1.

Parameter Signal	Name	Setting	Description	Control Mode
Sn204	Zero Speed selection	0	No action	S
		1	Regard Speed command as Zero. (According to Sn215 setting).	



Servo Lock

In speed mode: the Servo Lock is used to lock servo motor when input voltage command is not at 0V.

When input contact **LOK** operates: The control mode changes to internal position control mode, it temporarily stop motor rotation. Please refer to section **5-6-1** for setting input contact **LOK** function.

Speed Feedback Smooth Filter

When there is system abnormal vibration or noise, Set **Cn032** (speed feed back smoothing filter) to restrain vibration or noise. Addition of this filter will delay the speed response of servo system.

Parameter Signal	Name	Default	Unit	Setting Range	Control Mode
Cn032	Speed feed back smoothing filter	500	Hz	0~2500	Pe/Pi/S

5-4 Position Mode

Position control mode is used for high-precision applications on machinery such as machine tools.

The Position control mode offers ***two methods*** of control.

- External pulse input position command
- Internal position command.

In external pulse command input mode, the positioning command is signaled to the drive by a host Controller to achieve a fixed position.


In internal position command mode, 32 preset position commands can be set by parameters (**Pn401~Pn496**), and can be activated by use of input contacts **POS1 ~ POS5**.

Set parameter **Cn001** (control mode selection) as required according to the table below.

Parameter Signal	Name	Setting	Description	Control Mode
★● Cn001	Control mode selection	2	Position control (External pulse command) Using one pulse command signal to control position. Please refer to 5-4-3.	ALL
		6	Position control (Internal pulse command) Use input contacts to select 16 programmable preset position commands. Please refer to 5-4-2.	

New setting will become effective after re-cycling the power.

The diagram below shows the position loop control. Detailed functions are described in the following chapters.





5-4-1 External Pulse Command





Four types of external position pulse command signals can be interfaced,

These can be selected from the list below.

Position pulse signal logic can be selected Positive or negative as required.

Parameter Signal	Name	Setting	Description	Control Mode
★ Pn301.0 	Position pulse command selection	0	(Pulse)+(Sign)	Pe
		1	(CCW)and (CW) pulse	
		2	AB-Phase Pulsex2	
		3	AB-Phase Pulsex4	
★ Pn301.1 	Position pulse command logic selection	0	Positive Logic	Pe
		1	Negative Logic	
Pn329	Pulse command smoothing filter timing	0 2500 ms	Pulse command smoothing filter. Timing of filter can be set by this parameter.	Pe
Pn330	Pulse command moving filter timing	0 250 ms	Pulse command moving filter Timing of filter can be set by this parameter.	

New setting will become effective after re-cycling the power.

Position pulse command types	Positive Logic		Negative Logic	
	CCW Command	CW Command	CCW Command	CW Command
(Pulse)+(Sign)	 	 		
(CCW)/(CW) Pulse	 	 		
AB-Phase Pulse	 	 		

Two types of pulse command can be connected, (Open collector) and (Line driver).

Please refer to **section 2-2-1** for the pulse wiring method.

Pulse command timing should be in accordance with the time sequence standard below.

Pulse Command Types	Time Sequence Diagram of Pulse Command	Time Standard
(Pulse)+ (Sign)		Line Driver: $t_1, t_2 \leq 0.1\mu s$ $t_3 > 3\mu s$ $T \geq 1.0\mu s$ $(T/T) \leq 50\%$ OpenCollector: $t_1, t_2 \leq 0.2\mu s$ $t_3 > 3\mu s$ $T \geq 2.0\mu s$ $(T/T) \leq 50\%$
(CCW)/ (CW) Pulse		LineDrive: $t_1, t_2 \leq 0.1\mu s$ $t_3 > 3\mu s$ $T \geq 1.0\mu s$ $(T/T) \leq 50\%$ OpenCollector: $t_1, t_2 \leq 0.2\mu s$ $t_3 > 3\mu s$ $T \geq 2.0\mu s$ $(T/T) \leq 50\%$
AB-Phase Pulse		LineDrive: $t_1, t_2 \leq 0.1\mu s$ $T \geq 1.0\mu s$ $(T/T) \leq 50\%$ OpenCollector: $t_1, t_2 \leq 0.2\mu s$ $T \geq 2.0\mu s$ $(T/T) \leq 50\%$

Position command can be disabled (Inhibited) by external input contact **INH**.

Input Contact INH	Description	Control Mode
0	Position Pulse command enabled	Pe
1	Position Pulse command disabled	

Note: Input contacts status "1" (ON) and "0" (OFF)

Please check section 5-6-1 to set the required high /Low signal levels (PNP/NPN) selection.

5-4-2 Internal Position Command

In internal position command mode, 32 preset position commands can be set by parameters (**Pn401~Pn496**), and can be activated by use of input contacts **POS1 ~ POS5**.

Preset positions are programmable and can be selected according to the table below:

Position Command	POS5	POS4	POS3	POS2	POS1	Position Command Parameter		Position Speed Parameter
P1	0	0	0	0	0	Rotation Number	Pn401	Pn403
						Pulse Number	Pn402	
P2	0	0	0	0	1	Rotation Number	Pn404	Pn406
						Pulse Number	Pn405	
P3	0	0	0	1	0	Rotation Number	Pn407	Pn409
						Pulse Number	Pn408	
P4	0	0	0	1	1	Rotation Number	Pn410	Pn412
						Pulse Number	Pn411	
P5	0	0	1	0	0	Rotation Number	Pn413	Pn415
						Pulse Number	Pn414	
P6	0	0	1	0	1	Rotation Number	Pn416	Pn418
						Pulse Number	Pn417	
P7	0	0	1	1	0	Rotation Number	Pn419	Pn421
						Pulse Number	Pn420	
P8	0	0	1	1	1	Rotation Number	Pn422	Pn424
						Pulse Number	Pn423	
P9	0	1	0	0	0	Rotation Number	Pn425	Pn427
						Pulse Number	Pn426	
P10	0	1	0	0	1	Rotation Number	Pn428	Pn430
						Pulse Number	Pn429	
P11	0	1	0	1	0	Rotation Number	Pn431	Pn433
						Pulse Number	Pn432	
P12	0	1	0	1	1	Rotation Number	Pn434	Pn436
						Pulse Number	Pn435	
P13	0	1	1	0	0	Rotation Number	Pn437	Pn439
						Pulse Number	Pn438	
P14	0	1	1	0	1	Rotation Number	Pn440	Pn442
						Pulse Number	Pn441	
P15	0	1	1	1	0	Rotation Number	Pn443	Pn445
						Pulse Number	Pn444	
P16	0	1	1	1	1	Rotation Number	Pn446	Pn448
						Pulse Number	Pn447	
P17	1	0	0	0	0	Rotation Number	Pn449	Pn451
						Pulse Number	Pn450	
P18	1	0	0	0	1	Rotation Number	Pn452	Pn454
						Pulse Number	Pn453	
P19	1	0	0	1	0	Rotation Number	Pn455	Pn457
						Pulse Number	Pn456	
P20	1	0	0	1	1	Rotation Number	Pn458	Pn460
						Pulse Number	Pn459	
P21	1	0	1	0	0	Rotation Number	Pn461	Pn463
						Pulse Number	Pn462	
P22	1	0	1	0	1	Rotation Number	Pn464	Pn466
						Pulse Number	Pn465	

Position Command	POS5	POS4	POS3	POS2	POS1	Position Command Parameter		Position Speed Parameter
P23	1	0	1	1	0	Rotation Number	Pn467	Pn469
						Pulse Number	Pn468	
P24	1	0	1	1	1	Rotation Number	Pn470	Pn472
						Pulse Number	Pn471	
P25	1	1	0	0	0	Rotation Number	Pn473	Pn475
						Pulse Number	Pn474	
P26	1	1	0	0	1	Rotation Number	Pn476	Pn478
						Pulse Number	Pn477	
P27	1	1	0	1	0	Rotation Number	Pn479	Pn481
						Pulse Number	Pn480	
P28	1	1	0	1	1	Rotation Number	Pn482	Pn484
						Pulse Number	Pn483	
P29	1	1	1	0	0	Rotation Number	Pn485	Pn487
						Pulse Number	Pn486	
P30	1	1	1	0	1	Rotation Number	Pn488	Pn490
						Pulse Number	Pn489	
P31	1	1	1	1	0	Rotation Number	Pn491	Pn493
						Pulse Number	Pn492	
P32	1	1	1	1	1	Rotation Number	Pn494	Pn496
						Pulse Number	Pn495	


For **internal positioning** mode there are two types of moves **incremental** move or **absolute** move, selectable by parameter **Pn316** as below.

Parameter Signal	Name	Setting	Description	Control Mode
★ Pn316	Internal position command mode selection	0	Absolute mode	Pi
		1	Incremental mode	

New setting will become effective after re-cycling the power.

Example below shows the difference between absolute and incremental moves.

For two pulse commands of 10 pulse position pulse command and followed with another 20 pulse, the traveled positions will be different.




PTRG. (Position Trigger).

Once any preset position is selected by input contacts **POS1~POS5** then require a trigger signal (**PTRG**) from the input contact, enable **PTRG** to start operation.

Diagram below shows an example for 4 different absolute encoders.

Absolute moves



Note: Input contacts status "1" (ON) and "0" (OFF)

Please check section 5-6-1 to set the required high /Low signal levels (PNP/NPN) selection.


PHOLD. (Position Hold)

The Position command can be inhibited (Held) at any time by input contact signal **PHOLD**.

Once PHOLD is initiated the motor will decelerate and stop.

As soon as the input contact **PTRG** is triggered again the original position command will be Completed.


Diagram below shows PHOLD function with incremental encoder.



CLR (Clear position command).

If the CLR input is activated when a position command is in process then the motor will stop immediately and the remaining positioning pulses will be cleared. Parameter Pn315 must be set to 1 or 2 as required (refer to section 5-4-7).

Once the PTRG input contact is activated again then a new position command will be started according to the selection of input contacts POS1~POS5.



Note: Input contacts status "1" (ON) and "0" (OFF)

Please check section 5-6-1 to set the required high /Low signal levels (PNP/NPN) selection.


5-4-3 Electronic Gear

Electronic gear ratio parameter can be used to scale the command output pulse.

This would be useful in transmission applications where move distance per move command pulse has to be scaled due to mechanical requirements.

Diagram and notes below describe the electronic gear ratio effect.

Example of a transmission device and calculations that show the required number of pulses from a host controller to move the table by 10mm.



Calculations without Electronic Gear Ratio	Calculations with Electronic Gear Ratio
<ol style="list-style-type: none"> One rotation of ball screw = Table move distance of 5mm. If the table is required to move 10mm, then Ball screw needs to rotate by $(10\text{mm} \div 5 \text{ mm/rev}) = 2 \text{ Revs}$ Command pulses required to cause one revolution: = Encoder ppr \times (Internal multiplication factor). = 2000 ppr \times 4 = 8000 pulses. So the Command pulses required to move 10mm (2 revs):- = 8000 pulses \times 2 (revs) = 16000 Pulses. <p>Number of command pulses for an specific move distance can be calculated according to the formula below: = Number of Ball Screw Revs \times (Encoder ppr \times 4).</p>	<p>For Calculating the number of pulses command required, Setting of Electronic gear ratio see next chapter. Electronic gear ratio can be set according to the required move distance per move command pulse.</p> <p>For example:</p> <ol style="list-style-type: none"> One Pulse command = Move distance of 1μm. If the Motion Table needs to move 10mm, Then the required command pulses from a Host Controller is = $10\text{mm} \div 1\mu\text{m} / \text{Pulse} = 10000 \text{ Pulses}$. <p>Once the move distance per pulse and the Electronic gear ratio is known then the required number of pulse command can be calculated.</p>

Electronic Gear Ratio Calculation

Follow the Steps below:

1. Define the requirements of the positioning system

Establish the following:

- Move distance per one revolution of load shaft.
- Servo motor Encoder ppr (Pulse Per Revolution). (please refer to section 1-1-2 Servo Motor Standards).
- Motor / load Shaft deceleration ratio.

2. Move distance per one move command pulse.

Define the move distance caused by the transmission system as a result of, one move command pulse from the host controller.

Ex: When 1 Pulse Command move = 1μm

If the Host Controller gives a move command of 2000 pulses, the transmission device will move by:-

$$2000\text{pulse} \times 1\mu\text{m/pulse} = 2\text{mm}$$
 (The Electronic Gear Ratio must be set correctly).

3. Calculate the Electronic Gear Ratio

Calculate the Electronic Gear Ratio according to the formula below:-

Encoder ppr (Pulse Per Revolution)

Electronic Gear Ratio = $\frac{\text{Encoder ppr (Pulse Per Revolution)}}{\text{Move distance per load shaft revolution} \div \text{Move distance per command Pulse}}$

If the deceleration ratio between motor and load shaft is $\frac{n}{m}$

(m = Motor Rotating number, n= Load Shaft Rotating Value), Then the formula for Electronic Gear Ratio is:

Encoder ppr (Pulse Per Revolution)

Electronic Gear Ratio = $\frac{\text{Encoder ppr (Pulse Per Revolution)}}{\text{Move distance per load shaft revolution} \div \text{Move distance per command Pulse}} \times \frac{m}{n}$

Warning!

The calculated Electronic Gear Ratio must be according to the conditions below, otherwise the servo drive and motor will not function correctly.

$$\frac{1}{400} \leq \text{ElectroniceGearRatio} \leq 400$$

(*P.S. : 2500/8192 ppr encoder, Pulse Per Revolution should times 4.)

4. Parameter Setting for Electronic Gear Ratio

Setting gear ratio Numerator and denominator parameters:

Numerator and denominator values of the calculated electronic gear ratio must be entered in the required parameters.

These two values have to be integer and with a value within the specified range in the table below.

Parameter Signal	Name	Default	Unit	Setting Range	Control Mode
Pn302	Numerator of Electronic Gear Ratio 1	1	X	1~50000	Pi/Pe
Pn303	Numerator of Electronic Gear Ratio 2	1	X	1~50000	Pi/Pe
Pn304	Numerator of Electronic Gear Ratio 3	1	X	1~50000	Pi/Pe
Pn305	Numerator of Electronic Gear Ratio 4	1	X	1~50000	Pi/Pe
★ Pn306	Denominator of Electronic Gear Ratio	1	X	1~50000	Pi/Pe

★ New setting will become effective after re-cycling the power.

This device provides 4 selections of Numerator for Electronic Gear Ratio.

Input contacts **GN1** and **GN2** can be used to select the required Numerator for the Electronic Gear Ratio

According to the following table.

Input Contact GN2	Input Contact GN1	Numerator of Electronic Gear Ratio	Control Mode
0	0	Numerator of Electronic Gear Ratio 1 Pn302	Pi/Pe
0	1	Numerator of Electronic Gear Ratio 2 Pn303	
1	0	Numerator of Electronic Gear Ratio 3 Pn304	
1	1	Numerator of Electronic Gear Ratio 4 Pn305	

Note: Input contacts status "1" (ON) and "0" (OFF)

Please check 5-6-1 to set the required high /Low signal levels (PNP/NPN) selection.

Electronic Gear Ratio setting examples

Transmission System	Setting Process
<p style="text-align: center;">Ball Screw</p> <p>Pulse Value of 1 Rotating for Encoder = 2000pulse/rev</p>	<p>1. Main positioning specifications:</p> <ul style="list-style-type: none"> a) Load Shaft(Ball Screw) pitch move distance per revolution= 5mm b) Motor Encoder ppr (Pulse per revolution) = 2000pulses <p>2. Move distance per one pulse of move Command. Moving Distance of 1 Pulse Command = $1\mu\text{m}$</p> <p>3. Calculation of the Electronic Gear Ratio: $\text{Electronic Gear Ratio} = \frac{2000\text{pulse/rev} \times 4}{5\text{mm/rev} \div 1\mu\text{m/pulse}} = \frac{8000}{5000} = 1.6$</p> <p>4. Set the parameter of Electronic Gear Ratio: Numerator of Electronic Gear Ratio = 8000 Denominator of Electronic Gear Ratio = 5000</p>
<p style="text-align: center;">Mechanical Disc</p> <p>Deceleration Ratio-1/5</p> <p>Pulse Value of Rotating for Encoder = 2500pulse/rev</p>	<p>1. Main positioning specifications:</p> <ul style="list-style-type: none"> a) Deceleration Ratio=1/5 b) Load Shaft(Mechanical Disc)Move Value per one revolution=360° <p>Motor Encoder ppr (Pulse per revolution)= 2500 pulses</p> <p>2. Move distance per one pulse of move Command. Distance for 1Pulse Command = 0.1°</p> <p>3. Calculation of the Electronic Gear Ratio: $\text{Electronic Gear Ratio} = \frac{2500\text{pulse/rev} \times 4}{360^\circ \div 0.1^\circ/\text{pulse}} \times \frac{5}{1} = \frac{50000}{3600} = 13.89$</p> <p>4. Set the parameter of Electronic Gear Ratio: Numerator of Electronic Gear Ratio = 50000 Denominator of Electronic Gear Ratio = 3600</p>
<p style="text-align: center;">Transmission Belt</p> <p>Deceleration Ratio=1/8</p> <p>Diameter of Idler=100mm</p> <p>Pulse Value of 1 Rotating for Encoder = 8192pulse/rev</p>	<p>1. Main positioning specifications:</p> <ul style="list-style-type: none"> a) Deceleration Ratio=1/8 b) Load Shaft (Idler) Move Value per revolution. $= 3.14 \times 100\text{mm} = 314\text{mm}$ c) Motor encoder ppr (Pulse Per Revolution) = 8192pulse <p>2. Move distance per pulse of move Command. Distance for 1Pulse Command = $10\mu\text{m}$</p> <p>3. Calculation the Electronic Gear Ratio: $\text{Electronic Gear Ratio} = \frac{8192\text{pulse/rev} \times 4}{314\text{mm} \div 10\mu\text{m/pulse}} \times \frac{8}{1} = \frac{262144}{31400} = 8.37$</p> <p>4. Set the parameter of Electronic Gear Ratio: Reduction of the fraction to make the Numerator and Denominator less than 50000. Numerator of Electronic Gear Ratio 32768 Denominator of Electronic Gear Ratio 3925</p>

5-4-4 Smooth Acceleration

Using the **One Time Smooth Acceleration/Deceleration of Position Command**"


It smoothes the position pulse command frequency.

Parameter Signal	Name	Default	Unit	Setting Range	Control Mode
★ Pn313	External Position command Accel/Decel Time Constant	0	msec	0~10000	Pi/Pe

★ New setting will become effective after re-cycling the power.

Time Constant of Smooth Acceleration/Deceleration of Position Command defined for a cycle as below:

The require time of the Position Pulse Frequency started from 0 to 63.2%.



Setting Examples:

(1) To achieve 95% of Position Pulse Command Frequency Output in 30msec:

$$Pn313 = \frac{30(\text{msec})}{-\ln(1 - 95\%)} = 10(\text{msec})$$

(2) To achieve 75% of Position Pulse Command Frequency Output in 30msec:

$$Pn313 = \frac{30(\text{msec})}{-\ln(1 - 75\%)} = 22(\text{msec})$$

Note: Above curve is a logarithmic

In = Natural log.

S-curve time constant of the Internal Position Command


S-curve time constant generator can smoothen the command, it provides continuous speed and acceleration which not only better the motor characteristic of acc/dec but also helps the motor to operate more smoothly in machinery structure. S-curve time constant generator is only applicable to the mode of internal position command input. When position command input switch to external position pulse, the speed and acceleration are already constant, so it doesn't use the S-curve time constant generator.

Parameter Signal	Name	Default	Unit	Setting range	Control mode
Pn322	S-Curve Time Constant for Internal Position command(TSL) S-curve time constant generator can smoothen the command, it provides continuous speed and acceleration which not only better the motor characteristic of acc/dec but also helps the motor to operate more smoothly in machinery structure. S-curve time constant generator is only applicable to the mode of internal position command input. When position command input switch to external position pulse, the speed and acceleration are already constant, so it doesn't use the S-curve time constant generator. Notice ! 1. Setting rule : Pn323(TACC) \geq Pn322(TSL). 2. When Pn322 = 0, S-Curve time constant disabled.	0	x0.4ms	0 5000	Pi
Pn323	S-Curve Time Constant for Internal Position command(TACC) Please refer to Pn322 statement	1	x0.4ms	1 5000	Pi
Pn333	S-Curve Time Constant Deceleration for Internal Position Command(TDEC) We define the input time parameter are TSL and TDEC. It judges the dec trip by the setted time parameter. Figure (a) shows that when TDEC > TSL, it will generate a constant deceleration region, and the time of deceleration is TDEC – TSL. Refered to figure (b), there is no constant deceleration region when TDEC = TSL, and it can not be define on TDEC<TSL.	1	x0.4ms	1 ~ 5000	Pi


We define the input time parameter are TSL and TACC. It judges the acc/dec trip by the setted time parameter.

Figure (a) shows that when TACC > TSL, it will generate a constant acceleration region, and the time of acceleration is TACC – TSL.


Refered to figure (b), there is no constant acceleration region when TACC = TSL, and it can not be define on TACC<TSL.



S-Curve trip definition




S-Curve trip definition



5-4-5 Definition of Direction

In position mode, user can use Pn314 (Position Command Direction Definition) to define motor rotation direction. The setting is showed as follow:

Parameter Signal	Name	Setting	Description	Control Mode
★ Pn314	Definition of position command direction (from motor load end) 	0	Clockwise (CW)	Pi Pe
		1	Counter Clockwise (CCW)	

New setting will become effective after re-cycling the power.

5-4-6 Gain Adjustment

The table below shows the parameters for adjusting the position loop.

Two position loop gains can be selected from input contact terminals according to table below.


For selection methods refer to section. 5-3-11.

Parameter Signal	Name	Default	Unit	Setting Range	Control Mode
Pn310	Position Loop Gain1	40	1/s	1~1000	Pe/Pi
Pn311	Position Loop Gain 2	40	1/s	1~1000	Pe/Pi
Pn312	Position Feed-Forward Gain	0	%	0~100	Pe/Pi
Cn033	Speed Feed-Forward Smooth Filter	500	Hz	0~1000	Pe/Pi

Diagram below shows the position controller. Adjust a higher gain value can reduce response time.

Position Feed-Forward Gain can also be used to shorten the positioning time.

Refer to section 5-5 for Position Loop Gain Adjustment methods.



5-4-7 Clear the Pulse Offset

In position control mode, **parameter Pn315** (Pulse Error clear mode) has three modes can be select. **CLR** input contact is used to clear the pulse error as required according to the list below.

Parameter	Name	Setting	Description	Control Mode
Pn315	Pulse Error Clear Mode	0	When Input CLR contact, clears the pulse error value.	Pe
		1	When Input CLR contact to cancels the position command, Stops the motor rotating, the pulse error value is cleared and mechanical Home signal is reset.	Pi Pe
		2	When Input CLR contact to cancels the position command, stops the motor rotating and the pulse error value is cleared.	Pi

Note: Input contacts status “1” (ON) and “0” (OFF)


Please check 5-6-1 to set the required high /Low signal levels (PNP/NPN) selection.

5-4-8 Homing Function

Homing function is used to find and set a reference point for correct positioning.

To set a HOME reference position, one of input contacts ORG (external sensor input), CCWL, or CWL can be used.

An encoder Z phase (marker pulse) can also be used as home reference and can be search by CW or CCW direction. Following Home routine selections are available for setting parameter Pn 365.0.

Parameter	Name	Setting	Description	Control Mode
Pn317.0 	On activation of Home input contact, It sets the search direction and Home reference. (Setting for home routine)	0	<p>Once the home routine is activated, motor will search for Home Position switch in 1st preset speed in CCW direction. Input contacts CCWL or CWL can be used as the Home Reference Switch.</p> <p>Once Home reference switch is detected and complete, input contacts CCWL and CWL will act as limits input contact again.</p> <p>Note: When using this function, 1 or 2 setting of Pn317.1 is not allowable. Cn002.1 (CCWL & CWL Input terminal function) must to set as 0.</p>	
		1	<p>Once the home routine is activated, motor will search for Home Position switch in 1st preset speed in CW direction. Input contacts CCWL or CWL can be used as the Home Reference Switch.</p> <p>Once Home reference switch is detected and complete, input contacts CCWL and CWL will act as limits input contact again.</p> <p>Note: When using this function, 1 or 2 setting of Pn317.1 is not allowable. Cn002.1 (CCWL & CWL Input terminal function) must to set as 0.</p>	
		2	<p>Once the home routine is activated , motor will search for Home Position switch in 1st preset speed in CCW direction and sets the input contact ORG (external sensor input) as a Home reference when ORG contact is activated.</p> <p>If Pn317.1=2, it will directly find the closest Rising-Edge of ORG to be the Home position (without a need for Home reference),then it stops in accordance with Pn317.3 setting.</p>	Pi/Pe
		3	<p>Once the home routine is activated , motor will search for Home Position switch in 1st preset speed in CW direction and sets the input contact ORG (external sensor input) as a Home reference when ORG contact is activated.</p> <p>If Pn317.1=2, it will directly find the closest Rising-Edge of ORG to be the Home position (without a need for Home reference),then it stops in accordance with Pn317.3 setting.</p>	
		4	<p>Once the home routine is activated , motor will search for Home position in 1st preset speed in CCW direction and sets the Home reference Servo drive start to find the Home position of the nearest Z phase. (No need for Home reference) When using this function, set Pn317.1=2 . After finished setting of Z Phase to the Home position, for the stop method refer to the setting of Pn317.3.</p>	
		5	<p>Once the home routine is activated , motor will search for Home position in 1st preset speed in CW direction and sets the Home reference Servo drive start to find the Home position of the nearest Z phase. (No need for Home reference) When using this function, set Pn317.1=2 . After finished setting of Z Phase to the Home position, for the stop method refer to the setting of Pn317.3.</p>	

Parameter	Name	Setting	Description	Control Mode
Pn317.1 	Once Reference Home switch or Signal, is found set search method for the Home position.	0	Once the Home Reference switch or signal is detected, motor reverses direction in 2 nd speed to find the nearest Z Phase pulse and sets this as the Home position, then stops in accordance with Pn317.3 setting method.	Pi/Pe
		1	Once the Home Reference switch or signal is detected, motor Continues in its direction in 2 nd speed to find the nearest Z Phase pulse and sets this as the Home position, then stops in accordance with Pn317.3 setting method.	
		2	When Pn317.0=2 or 3 , it finds the rising edge of ORG to be the Home position, then stops in accordance with Pn317.3 ; When Pn317.0=4 or 5 , it finds Z Phase pulse to be the Home, then stops in accordance with Pn317.3 .	
Pn317.2 	Setting of Home Routine Start method	0	Homing routine is Disabled .	Pi/Pe
		1	On power up and activation of Servo on the home routine is started automatically. This method is useful for applications that do not require repeated home routines. No external home reference switch is required.	
		2	Use SHOME input contact to start a home routine. In position mode, SHOME can be used to start a home routine at any moment.	
Pn317.3 	Stopping mode after finding Home signal.	0	After detecting the Home signal, it sets this position to be the Home reference (Un-14 encoder feed back rotating number and Un-15 encoder feed back pulse number are all 0), motor decelerates and stops. Then it reverses direction in 2 nd speed to detect the Home Position again then it decelerates and stops..	Pi/Pe
		1	After detecting the Home signal, it sets this position to be the Home reference (Un-14 encoder feed back rotating number and Un-15 encoder feed back pulse number are all 0), motor decelerates and stops.	

Home Mode selection table

Pn317.0 and Pn 317.1 selections can be made for each application as required according to the table below:-

Pn317.0 Pn317.1	0	1	2	3	4	5
0	●	●	●	●	✗	✗
1	✗	✗	●	●	✗	✗
2	✗	✗	●	●	●	●

● HOME routine available ✗ HOME routine not available.

Additional Home routine parameters

Home search speed parameters 1st (Fast) and 2nd (Slow) speeds are set according to table below:

Parameter Signal	Name	Default	Unit	Setting Range	Control Mode
Pn318	1 st preset high speed of HOME	100	rpm	0~2000	Pi/Pe
Pn319	2 nd preset low speed of HOME	50	rpm	0~500	Pi/Pe

Parameters Pn320 and Pn 321 provide Home position offset feature for applications where the machine mechanical home position is a different position to the detected home position.



This offset can be achieved by setting the two parameters below.

Once the detected home position is found in accordance with **Pn317** (Home routine mode), and then it will search by number of revolutions and pulses set in Pn320 and Pn 321 to find the new off set Home position.

Parameter Signal	Name	Default	Unit	Setting Range	Control Mode
Pn320	HOME Position Offset. (No of Revolutions)	0	rev	-30000~30000	Pi/Pe
Pn321	HOME position Bias Pulse value (No of pulses)	0	pulse	-32767~32767	Pi/Pe

Home routine Timing Chart

During the Home routine if the SON (Servo On) is not activated or any alarm happens, Home routine is stopped and Home Complete output contact is reset (Cleared).



Note: Input contacts status “1” (ON) and “0” (OFF)

Please check 5-6-1 to set the required high /Low signal levels (PNP/NPN) selection.

Home Routine Speed /Position Timing Charts


Following Sections Show the Speed/Position Timing charts according to Pn 317.0 and Pn317.1 selections.

Pn317.0 Pn317.1	0	1	2	3	4	5
0	(1)	(2)	(1)	(2)	X	X
1	X	X	(3)	(4)	X	X
2	X	X	(5)	(6)	(7)	(8)

X No Home routine


(1)

- **Pn317.0=0 or 2** (After starting HOME routine, run **CCW** in 1st preset high speed for HOME Reference (**CCWL, CWL or ORG**)).
- **Pn317.1=0** (After finding HOME Reference, **reverse direction** in 2nd preset low speed to search for the nearest Z Phase pulse to be set as the HOME position).
- **Pn317.2=2** (Input Contact SHOME to Start Home routine).
- **Pn317.3=0** (**Reverse search for HOME position**).




(2)

- **Pn317.0=1 or 3.** After starting the HOME routine, run **CW** in 1st preset high speed to search for HOME Reference (**CWL, CCWL or ORG**).
- **Pn317.1=0 .** After finding HOME Reference, **reverse direction** in 2nd preset low speed to search for the nearest Z Phase pulse to be set as the HOME position.
- **Pn317.2=2.** Input Contact SHOME Starts the Home routine.
- **Pn317.3=0.** **Reverse search for** HOME position.




(3)

- **Pn317.0=2.** After starting HOME routine, **run CCW** in 1st preset high speed to search for HOME Reference (**ORG**).
- **Pn317.1=1.** After finding HOME Reference, **continues in the same direction** in 2nd preset low speed to find the nearest Z Phase to be set as the HOME position.
- **Pn317.2=2** Input Contact **SHOME** Starts the HOME routine.
- **Pn317.3=0 Reverse search for** HOME position




(4)

- **Pn317.0=3** (After Starting HOME routine, run **CW** in 1st preset high speed to search for HOME Reference. **(ORG)**)
- **Pn317.1=1**. After finding HOME Reference, **continues in the same direction** in 2nd preset low speed to find the nearest Z Phase to be set as the HOME position.
- **Pn317.2=2** Input Contact **SHOME** Starts the HOME routine.
- **Pn317.3=0 Reverse search for HOME position**




(5)

- **Pn317.0=2**. After Starting HOME routine, run **CCW** in 1st preset high speed to search for HOME Reference. **(ORG)**.
- **Pn317.1=2**. After Finding the HOME Reference, the Rising Edge of **ORG sets the HOME Position**.
- **Pn317.2=2** Input Contact **SHOME** Starts the HOME routine.
- **Pn317.3=0 Reverse search for HOME position**




(6)

- **Pn317.0=3.** After Starting HOME routine, run **CW** in 1st preset high speed to search for HOME Reference. (**ORG**).
- **Pn317.1=2.** After Finding the HOME Reference, the Rising Edge of **ORG** sets the HOME Position.
- **Pn317.2=2** Input Contact **SHOME** Starts the HOME routine.
- **Pn317.3=0 Reverse search for HOME position**



(7)

- **Pn317.0=4.** After Starting HOME routine, run **CCW** in 1st preset high speed to search for the nearest Z phase pulse.
- **Pn317.1=2.** After Finding the Z phase pulse, set this position as the HOME position.
- **Pn317.2=2** Input Contact **SHOME** Starts the HOME routine.
- **Pn317.3=0 Reverse search for HOME position**




(8)

Pn317.0=5. After Starting HOME routine, run **CW** in 1st preset high speed to search for the nearest Z phase pulse.

Pn317.1=2. After Finding the Z phase pulse, set this position as the HOME position.

Pn317.2=2 Input Contact **SHOME** Starts the HOME routine.

Pn317.3=0 Reverse search for HOME position




5-4-9 Other Position Functions

In position (Position Complete)

As long as the position **error value** (counts) is less than the pulse counts set in **Pn307** (Position Complete value) then **INP output contact** will be activated.

Parameter	Name	Default	Unit	Setting Range	Control Mode
Pn307	Position Complete value	10/40	pulse	0~50000	Pi/Pe



Note: Input contacts status “1” (ON) and “0” (OFF)

Please check 5-6-1 to set the required high /Low signal levels (PNP/NPN) selection.

Position error alarm

When the Position error value is greater than the preset pulse value of **Pn308** (Positive position error level) or **Pn309** (Negative position error level) this will generate **AL-11 (Position error)** signal.

Parameter	Name	Default	Unit	Setting Range	Control Mode
Pn308	Positive position error level	50000	x10 pulse x131pulse	0~50000	Pi/Pe
Pn309	Negative position error level	50000	x10 pulse x131pulse	0~50000	Pi/Pe

P.S. Use 2500/8192/15bits encoder the unit is 10 pulse. Use 17bits encoder the unit is 131pulse

5-5 Gain Adjustment

The Servo controller provides 3 control loops as diagram shown below:

Control methods are: **Current Control**, **Speed Control** and **Position Control**.




Diagram above shows the three control loops.

Current (Inner loop), Speed (middle loop) and position (outer loop).

Theoretically, the bandwidth of inner control loop must be higher than the bandwidth of the outer control loop, otherwise, the whole control system will become unstable, and cause vibration or abnormal response.

The relationship between the **band width** for these three control loops is as follows:

Current Loop (Inner) > Speed Loop (Middle) > Position Loop (outer).

The **default current control bandwidth** has already been set for optimum response, So **Only speed and position control loop gains** may be adjusted.

Table below shows the Gain adjustment parameters for the three control loops.

Parameter	Name	Default	Unit	Setting Range	Control Mode
Sn211	Speed Loop Gain 1	40	Hz	10~1500	Pe/Pi/S
Sn212	Speed Loop Integration Time Constant 1	100	x0.2 msec	1~5000	Pe/Pi/S
Sn213	Speed Loop Gain 2	40	Hz	10~1500	Pe/Pi/S
Sn214	Speed Loop Integration Time Constant 2	100	x0.2 msec	1~5000	Pe/Pi/S
Pn310	Position Loop Gain 1	40	1/s	1~1000	Pe/Pi
Pn311	Position Loop Gain 2	40	1/s	1~1000	Pe/Pi
Pn312	Position Loop Feed-Forward Gain	0	%	0~100	Pe/Pi
Cn025	Load Inertia Ratio	10	x0.1	0~1000	Pe/Pi/S

Speed Loop Gain

Speed Loop Gain has a direct effect on the response Bandwidth of Speed Control Loop. Under the condition of no vibration or noise, when higher is the Speed Loop Gain Value is setting speed response is becoming faster.

If **Cn025** (Load Inertia Ratio) is correctly set then,

Speed Loop Bandwidth = Sn211 (Speed Loop Gain1) or **Sn213** (Speed Loop Gain2).

Load Inertia Ratio Formula is as below:

$$\text{Load inertia rating} = \frac{\text{Load inertia transforming to motor axis } (J_L)}{\text{Inertia of servo motor rotor } (J_M)} \times 100\%$$

Speed Loop Integration Time Constant

Integral element in Speed Control Loop eliminates the steady state error.

Under the condition of no vibration or noise, reducing the speed loop Integral Time Constant can enhance system rigidity. If the Load Inertia Ratio is very high or the system has vibration factors, ensure that the Speed Loop Integral Time Constant is also high enough, otherwise the mechanical system would produce resonance easily.

Integral Time Constant for Speed Loop can be set using the formula below:

$$\text{Sn212}(\text{Integral Time constant 1 of Speed Loop}) \geq 5 \times \frac{1}{2\pi \times \text{Sn211}(\text{Speed Loop Gain 1})}$$

Setting Example:

Assume: **Cn025** (Load Inertia Ratio) is correctly set, If target Speed Loop Bandwidth 100Hz, set **Sn211** (Speed Loop Gain 1) =100(Hz) then

$$\text{Sn212}(\text{Integral Time Constant 1 of Speed Loop}) \geq 5 \times \frac{1}{2\pi \times 100} = 40 (\times 0.2\text{msec})$$

Position Loop Gain

Position Loop Gain has a direct effect on the response speed of Position Loop.

Under the condition that there is no vibration or noise from servo motor, increasing the Position Loop Gain Value can enhance the response speed and hence reduce the positioning time.

Position Loop Feed-Forward Gain

Using Position Loop Feed-Forward Gain can enhance the response speed.

If the Feed-Forward Gain value is setting too high, overshooting could occur and cause the **INP** (In Position) output contact to switch ON and OFF repeatedly.

SO monitor Speed Curve and **INP** (In Position Signal) at the same time then increase Feed-Forward Value slowly.

If Position Loop Gain is too high, Feed-Forward function will be insignificant.

Quick Parameters for Gain adjustment

Quick Gain adjust parameters are available for setting manually.

The related Gain Adjust parameters are listed in the Quick-Parameter leaflet for convenient reference. Quick adjust parameters once altered are saved and become effective **immediately**, without pressing the Enter-Key. The table below shows the Gain Adjust Quick-Parameters.


Parameter	Name	Default	Unit	Setting Range	Control Mode
◆ qn501	Speed Loop Gain 1	40	Hz	10~1500	Pe/Pi/S
◆ qn502	Integral Time Constant 1 of Speed Loop	100	x0.2 msec	1~5000	Pe/Pi/S
◆ qn503	Speed Loop Gain 2	40	Hz	10~1500	Pe/Pi/S
◆ qn504	Integral Time Constant 2 of Speed Loop	100	x0.2 msec	1~5000	Pe/Pi/S
◆ qn505	Position Loop Gain 1	40	rad/s	1~1000	Pe/Pi
◆ qn506	Position Loop Gain 2	40	rad/s	1~1000	Pe/Pi
◆ qn507	Position Loop Feed-Forward Gain	0	%	0~100	Pe/Pi

- ◆ Become effective immediately without pressing Enter-Key

5-5-1 Automatic Gain Adjustment

This device provides OFF-LINE and ON-LINE Auto tuning, which can quickly and precisely measure Load Inertia and adjust the Gain automatically. Setting is according to the table below:

ON-LINE Auto tuning

Parameter	Name	Setting	Description	Control Mode
★ Cn002.2 	Auto tuning	0	Auto tuning Disabled	Pe/Pi/S
		1	Enable Auto tuning	

When **Cn002.2 is set to 0** (Auto tuning Disabled), following Gain adjust parameters must be set.

Parameter Signal	Name
Cn025	Load Inertia Ratio
Sn211	Speed Loop Gain 1
Sn212	Speed-loop Integral time constant 1
Sn213	Speed loop Gain 2
Sn214	Speed loop Integral time constant 2
Pn310	Position Loop Gain 1
Pn311	Position Loop Gain 2
Pn312	Position Loop Feed-Forward Gain

When **Cn002.2 is set to 1** auto tuning is enabled and the Servo controller will adjust the Servo Gain in accordance with **Cn026** (Rigidity Setting) and the measured Load Inertia Ratio by monitor parameter **Un-19** (Load Inertia Ratio), when the Load Inertia Ratio is becomes stable,

Then set **0** in **Cn002.2** to cancel Auto tuning. At this moment, servo controller will record the measured Load Inertia Ratio into **Cn025** (Load Inertia Ratio).

If servo drive is used in a applications where there is no significant load variations, then monitor **Un-19** (Load Inertia Ratio) if this is stable then it is recommended that Auto tuning is not used.

Applying conditions of Auto tuning

The Servo drive provides Auto tuning and uses an advanced control technique “ON-LINE” to measure the Load Inertia Ratio to control the system to achieve default speed or Position Response Bandwidth. System must comply with the conditions below, so that the Auto tuning can operate normally.

- (1) The timing from stop to 2000rpm needs be less than 1 second.
- (2) Motor speed is larger than 200rpm.
- (3) Load Inertia needs be **20** times less than the inertia of the motor.
- (4) External force or the variation of inertia ratio can not be excessive.


Rigidity Setting

When Auto tuning is used, set the Rigidity Level depending on the various Gain settings for applications such as those listed below:

Rigidity Setting Cn026	Position Loop Gain Pn310 [1/s]	Speed Loop Gain Sn211 [Hz]	Speed-loop Integral time constant 1 Sn212 [x0.2msec]	Mechanical Rigidity	Application
1	2	2	1400	Low	Machines driven by timing Belt, Chain or Gear: Large Moving Table, Conveyor Belt.
2	3	3	950		
3	6	6	450		
4	9	9	300		
5	12	12	300		
6	15	15	300		
7	20	20	225		
8	30	30	150		
9	40	40	100		
10	50	50	60		
11	60	60	75	Middle	The machines driven by Ballscrew through decelerator: Ordinary machines, Mechanics arms, robot arms, conveyor.
12	70	70	50		
13	85	85	50		
14	100	100	40		
15	120	120	40		
16	140	140	30		
17	160	160	30		
18	180	180	25		
19	200	200	25		
20	225	225	20		
21	250	250	20	High	The machines driven by Ballscrew: High precision Machines, Metal engraving Machine, Insertion Machine and IC inspection Machine.

Process for ON-LINE Auto tuning

The following diagram shows the process for Auto tuning.



Note: After Auto tuning is complete Set 0 in Cn002.2, otherwise it will not record the present measured Load Inertia Ratio.

If the power is cut off during Auto tuning then when the power is established, Servo controller will use the previously recorded setting of Load Inertia Ratio which is stored in parameter Cn025.

OFF-LINE Auto tuning

OFF-Line Auto tuning could automatic measuring the load characteristics and adjusts the appropriate control gain in a fixed-action stroke. Gain adjustment method based on the vibration detection, and the rigid table as a basis for the adjustment. In order to find the system gain limit, the machine would increase the gain until the system start to vibration, and then reduced the gain to be stable.

OFF-Line automatic gain adjustment limitation:

- (1) The turns need to more than 3 runs.
- (2) the torque need to higher than the rated torque
- (3) The inertia ratio and the external force could not change too intense.
- (4) The function of tuning only can use in position mode(cn01 = 2)


The parameters of automatic gain adjustment for OFF-LINE Tuning

Parameter	Name	Default	Unit	Setting Range	Control Mode
Cn059	AutoTuning function choice	0	—	0 ~ 3	Pe Pi
	Setting Explanation				
	0 Disable AutoTuning				
	1 Enable OFFLine-AutoTuning				
Cn060	The turns command of OFFLine-tuning EX: When you set 10 means the tuning command would finished in 10 turns.	3	rev	3 ~ 1024	Pe Pi
Cn061	The Maximum speed OFFLine-tuning The Maximum speed OFFLine-tuning	Rated speed x2/3	rpm	1/3~ 2/3 x Rated speed	Pe Pi
Cn062	OFFLine-tuning operation overtravel distance protection settings When Cn60 is 3 and Cn62 is 50 means the distance protection is 3.5 runs (Cn60+Cn62*0.01). When over 3.5 runs it would stop in emergency.	50	0.01rev	50 ~ 300	ALL
Un45	Inertia Estimation for OnLine_AutoTuning	—	X0.1	—	—
Un46	Status for OFFLine_Tuning	—	—	—	—
Un47	The error code for OFFLine_Tuning	—	—	—	—

OFF-Line adjustment will change the parameters as follows:

Parameter	Name	Default	Unit	Setting Range	Control Mode	Communication Adress	
						RS232	RS485
Cn025	Load-Inertia ratio $LoadInertiaRatio = \frac{LoadInertiaToMotor(J_L)}{MotorRotorInertia(J_M)} \times 100\%$	10	x0.1	0 1000	Pi Pe S	5FBH	0019H
Sn211	Speed loop Gain 1 <p>Speed loop gain has a direct effect on the frequency response bandwidth of the Speed-control loop. Without causing vibration or noise Speed-loop-gain can be increased to obtain a faster speed response.</p> <p>If Cn025 (load Inertia ratio) is set correctly, the speed-loop-bandwidth will equal to speed-loop-gain.</p>	40	Hz	10 1500	Pi Pe S	530H	020BH
Sn212	Speed-loop Integral time 1 <p>Speed loop integral element can eliminate the steady speed error and react to even slight speed variations. Decreasing Integral time can improve system rigidity. The formula below shows the relationship between Integral time and Speed loop Gain.</p> $SpeedLoopIntegrationTimeConstant \geq 5 \times \frac{1}{2\pi \times SpeedLoopGain}$	100	x0.2 ms	1 5000	Pi Pe S	531H	020CH
Pn310	Position Loop Gain 1 <p>Without causing vibration or noise on the mechanical system the position loop gain value can be increased to speed up response and shorten the positioning time. Generally, the position loop bandwidth should not be higher than speed loop bandwidth. The relationship is according to the formula below:</p> $PositionLoopGain \leq 2\pi \times \frac{SpeedLoopGain}{5}$	40	1/s	1 1000	Pi Pe	55AH	030AH

Process for OFF-LINE Auto tuning



OFF-Line Autotuning abnormal action Table

There are three reasons could cause AL09, including lack of runway, the system clock or long

Error code	Reason	Solution
0101	lack of runway	1. Confirm if there is CW/CCW drive direction inhibit be triggered. 2. Increase parameter Cn064
0201	System Oscillation	1. Mechanical properties analyze Characteristic frequency 2. Decrease parameter Cn026
0301	long setting time The difference of inertia ratio between preset value and the actual value	1. Increase parameter Cn025
0102	lack of runway	1. Confirm if there is CW/CCW drive direction inhibit be triggered. 2. Increase parameter Cn064
0302	long setting time	1. Mechanical properties analyze Characteristic frequency 2. Decrease parameter Cn026

setting time. You could check by Un-47, and the description as follow.

OFF-Line Autotuning abnormal action Table

OFF-Line Autotuning Status Display

OFF-Line Autotuning has three steps, including inertia estimation, gain adjustment and the adjustment completion. Users can use the parameters currently observed Un46 to know the condition of autotuning.

Un46	description
1	inertia estimation
2	gain adjustment
3	adjustment completion

Rigidity Table:

Rigidity Setting Cn026	Position Loop Gain Pn310 [1/s]	Speed Loop Gain Sn211 [Hz]	Speed-loop Integral time constant 1 Sn212 [x0.2msec]	Mechanical Rigidity	Application
1	2	2	1400	Low	Machines driven by timing Belt, Chain or Gear: Large Moving Table, Conveyor Belt.
2	3	3	950		
3	6	6	450		
4	9	9	300		
5	12	12	300		
6	15	15	300		
7	20	20	225		
8	30	30	150		
9	40	40	100		
10	50	50	60		
11	60	60	75		
12	70	70	50		
13	85	85	50		
14	100	100	40		
15	120	120	40		
16	140	140	30		
17	160	160	30		
18	180	180	25		
19	200	200	25		
20	225	225	20		
21	250	250	20	High	The machines driven by Ballscrew through decelerator: Ordinary machines, Mechanics arms, robot arms, conveyor.

5-5-2 Manual Gain Adjustment

Manual Gain adjustment is made available for applications when auto tune is not providing a good and stable system response, or a system where there is no significant load variations and the auto tune is not used.

Manual Gain Adjustment in Speed control Mode

Step 1: Set Rigidity level in parameter Cn 26 (See section 5-5-1 for the selection table) and Cn25.

Step 2: If the Servo system includes a host controller which is used for positioning control, then it's **position loop Gain** should be set lower, relative to the servo drive Gain.

Step 3: Adjusting Speed Loop Gain 1 (Sn211):

- a) Increase Sn212 (Integral Time Constant 1of Speed Loop). Set a higher value than default or the set value when auto tune was unsuccessful.
- b) Increase the Speed Loop Gain (Sn211) until there is no vibration or noise.
- c) Then decrease the Speed Loop Gain (Sn211) slowly and increase Position Loop Gain of Host Controller until there is no vibration or noise.

Step 4: Adjusting Speed Loop Integral Time Constant 1 (Sn212):

Set the Integral Time Constant of Speed Loop for minimum time setting that without causing mechanical vibration.

Step 5: Finally, Slowly adjust the Speed Loop Gain, Position Loop Gain of Host Controller and Integral Time Constant of Speed Loop until the servo system provides the best response.

Manual Gain Adjustment in Position Control mode

Step 1: Set Rigidity level in parameter Cn 26 (See section 5-5-1 for the selection table) for the correct Load Inertia Ratio.

Step 2: Decrease Position Loop Gain 1 (Pn 310).

Set a lower value than default or the set value when auto tune was unsuccessful.

Set a relatively higher value in Sn212 (Integral Time Constant 1 of Speed Loop).

Step 3: Adjust Speed Loop Gain 1(Sn211).

Increase the Speed Loop Gain until there is no vibration or noise.

Step 4: Adjusting Position Loop Gain 1 (Pn310).

Slowly decrease the Speed Loop Gain again, then increase the Position Loop Gain until there is no vibration or noise.

Step 5: Adjusting Speed Loop Integral Time Constant 1 (Sn212).

Set the Integral Time Constant of Speed Loop for a minimum time without causing mechanical vibration.

Step 6: Finally, slowly adjusting the Speed Loop Gain, Position Loop Gain and the Integral Time Constant of Speed Loop until the servo system provides the best response.

5-5-3 Improving Resonance

The Servo drive provides the function of Gain Switching and Position Loop Feed-Forward Gain to improve system response.

Note: Both of these features must be used correctly to improve system response, otherwise the response will become worse. Refer to the description below:

Gain Switch

Following Gain Switching features are provided:-

- a) Speed Loop Gain PI/P Switching
- b) 2-stage Gain Switching.

Purposes list:

- (1) To restrict overshoot during acceleration/deceleration in speed control.
- (2) Reducing the in position oscillations and providing shorter settling time in position control.
- (3) Decrease the noise caused when using Servo Lock.

For further details refer to section **5-3-11**.

Position Loop Feed-Forward Gain

Position Loop Feed-Forward Gain can be used to reduce the error result from position control and improve the response speed.

Position loop Feed forward gain and position loop gain should be matched with. If adjusting to higher position loop gain, the feed forward gain can be ignored. Oppositely, if the loop gain value is setting for a relatively low level, adjust position loop feed forward gain will improve system response time obviously.

The adjustment steps are as follows:

Step 1: Refer to the procedures in sections **5-5-1~5-5-2** to adjust Speed and Position Gain.

Step 2: Increase **Pn312** (Position Feed-Forward Gain) slowly, and observe the **INP** (Output Signal of In Position) at the same time and INP output should be activated faster.

Note: The Position Loop Feed-Forward Gain can not be set too high, otherwise it will cause speed overshooting and **INP** (In Position output signal) will be switching On/Off repeatedly.


5-6 Other Functions

5-6-1 Programmable I/O Functions

Digital Inputs

There are 12 DI (Digital Inputs) contacts and 4 DO (Digital Outputs) contacts which are programmable as listed below:-

Parameter	Name & Function		Default	Unit	Setting Range	Control Mode	Communication Address				
							RS232	RS485			
★ Hn601.0 Hn601.1 	DI-1 Function		Change by mode	X	01 — 20 — HEX.	ALL	C23H	0501H			
	Setting	Explanation									
	Signal	Functions									
	00 NON	Unused									
	01 SON	Servo On									
	02 ALRS	Alarm Reset									
	03 PCNT	PI/P Switching									
	04 CCWL	CCW Limit									
	05 CWL	CW Limit									
	06 TLMT	External Torque Limit									
	07 CLR	Clear Pulse Error Value									
	08 LOK	Servo Lock									
	09 EMC	Emergency Stop									
	0A SPD1	Speed 1									
	0B SPD2	Speed 2									
	0C MDC	Control Mode Switch									
	0D INH	Position Command Inhibit									
	0E SPDINV	Speed Inverse									
	0F G-SEL	Gain Select									
	10 GN1	Electronic Gear Ratio Numerator 1									
	11 GN2	Electronic Gear Ratio Numerator 2									
	12 PTRG	Position Trigger									
	13 PHOLD	Position Hold									
	14 SHOME	Start Home									
	15 ORG	Home Position Reference (Origin)									
	16 POS1	Internal Position select 1									
	17 POS2	Internal Position select 2									
	18 POS3	Internal Position select 3									
	19 POS4	Internal Position select 4									
	1A TRQINV	Torque Inverse									
	1B RS1	Torque CW Selecting									
	1C RS2	Torque CCW Selecting									
	1D MDC2	Control mode selection for tool turret									
	1E POS5	Internal position command selection 5 (Tool NO. selection 5)									
	1F POS6	Tool NO. selection 6									
	20 VDI	Virtual digital input									
★ New setting will become effective after re-cycling the power.				DI_Jog_1	DI_Jog_2	Function					
				0	0	No JOG					
				1	0	JOG Excitation Forward					
				0	1	JOG Excitation Reverse					
				1	1	JOG Excitation zero-run					
P.S. : DI_Jog function only work in Position mode (Cn01 = 2、6、A)											

Parameter Signal	Name	Setting	Description	Control Mode
★ Hn601.2 	DI-1 Logic State NO/NC Selection	0	Input contact state. NO (Normally Open). Connecting (IG24) to inputs, enables the selected function.	ALL
		1	Input contact state. NC (Normally Closed). Disconnecting (IG24) from inputs, enables the selected function.	

New setting will become effective after re-cycling the power.



Digital Inputs 2 to 12 (Hn 602 to Hn 612). Are programmable and the logic state NO/NC can also be selected same as that shown for digital input 1. See Hn501.

Parameter	Name	Description	Control Mode
★ Hn602	DI-2 Programmable	Refer to Hn601 for programmable options.	ALL
★ Hn603	DI-3 Programmable		
★ Hn604	DI-4 Programmable		
★ Hn605	DI-5 Programmable		
★ Hn606	DI-6 Programmable		
★ Hn607	DI-7 Programmable		
★ Hn608	DI-8 Programmable		
★ Hn609	DI-9 Programmable		
★ Hn610	DI-10 Programmable		
★ Hn611	DI-11 Programmable		
★ Hn612	DI-12 Programmable		

Warning! If any of programmable Inputs of DI-1 ~ DI-12 are set for the same type of function then the logic state selection (NO or NC selection) for these inputs must be the same type. Otherwise an Alarm will be displayed. AL-07 (**Multi-function contact setting error**).

Digital Outputs.

There are 4 programmable Digital Outputs according to the table below:

Parameter	Name	Setting	Description		Control Mode	
 Hn613.0 Hn613.1 	DO-1 terminal functions		Signal	Contactor functions	ALL	
		01	RDY	Servo Ready		
		02	ALM	Alarm		
		03	ZS	Zero Speed		
		04	BI	Brake Signal		
		05	INS	In Speed		
		06	INP	In Position		
		07	HOME	HOME		
		08	INT	In Torque		
	DO-1	0	Close, when the output is activated.			
		1	Open, when the output is activated..			

Parameter	Name	Description	Control Mode
Hn614	DO-2 Programmable	Refer to Hn613 for programmable options.	ALL
Hn615	DO-3 Programmable		
Hn616	DO-4 Programmable		

New setting will become effective after re-cycling the power.

Warning!

When programmable DO-1 ~ DO-4 are set for the same type of function alarm will be displayed.

AL-07 (**Multi-function contact setting error**).

Hn-601~Hn616 default settings for different control mode

Parameter \ Cn001 Setting	0	1	2	3	4	5	6	7	8	9	A
Hn601	0001										
Hn602	0002										
Hn603	0003	0003	0003	0003	0003	0003	0016	0016	0016	0016	0003
Hn604	0104	0104	0104	0104	0104	0104	0017	0017	0017	0017	0104
Hn605	0105	0105	0105	0105	0105	0105	0018	0018	0018	0018	0105
Hn606	001B	0006	0006	0006	001B	001B	0019	0019	0019	0019	0006
Hn607	001C	000E	0007	000E	001C	001C	001E	001E	001E	001E	0007
Hn608	001A	0008	000D	0008	001A	001A	0012	0012	0012	001F	000D
Hn609	0009										
Hn610	000A	000A	0014	000A	000A	000A	0014	000A	001B	0012	0014
Hn611	000B	000B	0015	000B	000B	000B	0015	000B	001C	001D	0015
Hn612	000C	000C	000C	000C	000C	000C	0013	000C	000C	000C	000C
Hn613	0001	0006	0001								
Hn614	0002										
Hn615	0008	0003	0007	0003	0008	0008	0007	0003	0008	000E	0007
Hn616	0005	0005	0006	0006	0005	0006	0006	0006	0006	000D	0006

5-6-2 Switch for the Control Mode

Set one of the programmable input terminals to MDC (Control mode) selection.

The input then will select the preset control mode, which is set by Parameter Cn001.

Selections are listed below:

Parameter	Name	Setting	Description		Control Mode
★● Cn001	Control Mode Selection		MDC Input off	MDC Input On	ALL
		3	Position Control (External Pulse Command)	Speed Control	
		4	Speed Control	Torque Control	
		5	Position Control (External Pulse Command)	Torque Control	
		7	Position Control (Internal Pulse Command)	Speed Control	
		8	Position Control (Internal Pulse Command)	Torque Control	
		A	Position Control (Internal Pulse Command)	Position Control (External Pulse Command)	

New setting will become effective after re-cycling the power.

Please check 5-6-1 to setting the input contact required high /Low signal levels (PNP/NPN selection).

5-6-3 Auxiliary Functions

Function of Input Contacts SON, CCWL and CWL can be set according to the list below:-

Parameter	Name	Setting	Description	Control Mode
★ Cn002.0 	SON (Servo ON)	0	Use input contact SON to switch Servo On.	ALL
		1	Servo on with Power on. SON input contact not required.	
Cn002.1 	CCWL and CWL (Counter Clockwise & Clockwise Limits)	0	CCWL and CWL(external limits) are effective. CCW and CW rotation is inhibited by CCWL&CWL.	ALL
		1	CCWL and CWL(external limits) are ineffective. CCW&CW rotation is not limited by CCWL&CWL.	

New setting will become effective after re-cycling the power.

5-6-4 Brake Mode

Brake function for servo motor and the external mechanical brake if it is used can be set according to the table below. Set the brake mode as required for Servo off, Emergency Stop and CCW/CW rotation inhibit functions.

Parameter	Name	Setting	Description		Control Mode
Cn008	Brake Modes		Dynamic Brake	Mechanical Brake	ALL
		0	Disable	Disable	
		1	Disable	Enable	
		2	Enable	Disable	
		3	Enable	Enable	
		4	Disable(Under 100rpm)	Disable	
		5	Disable(Under 100rpm)	Enable	

Note!

When the CCW/CW Drive Inhibit occur, the Cn009 has the higher priority than Cn008.

Example:

If Cn008 is set to 0 or 1 which means (no Dynamic Brake).

BUT Cn009= 1 (with Dynamic Brake), then the dynamic brake will be effective(enabled).


5-6-5 Timing Diagram of Mechanical Brake

In applications with vertical loading, if the power is turned off, to prevent the load from falling due to gravity, a servo motor with electro-mechanical brake can be used.

This servo drive provides a brake output (BI) which can be used for controlling the external brake.

Timing of brake output signal can be set by parameter **Cn003** (Output Time for electro-mechanical Brake).

Typical Circuit Diagram



Timing for Brake output signal

Set the required time for the operation of brake output signal (BI) according to the following.
BI output can be used to control the function of an external electro-mechanical brake.

Parameter	Name	Default	Default	Setting Range	Control Mode
Cn003	Output time setting for Mechanical Brake Signal	0	msec	-2000~2000	ALL

Note!

To use brake output signal set Cn008 (Brake mode) to selections 1 or 3 as required.

When the servo system has vertical loading, please set Cn003 to a **Positive Number**.

For definition of a time value with a positive or a negative sign refer to the following notes and timing diagrams.

(1) Cn003 set to a time value with a Positive sign.

AS soon as the input contact SON is switched on, Servo on is activated at the same time, then after a time delay set by parameter Cn003, Output Contact BI is switched on. (Signal to release the brake).

When SON input contact is switched off, BI output contact is also switched off (Signal to operate the brake).


Then after a time delay set by parameter Cn003, Servo ON is de-activated.

(2) Cn003 set to a time value with a Negative sign.

AS soon as the input contact SON is switched on, Output Contact BI is switched on at the same time. (Signal to release the brake). then after a time delay set by parameter Cn003, Servo on is activated.

When SON input contact is switched off, Servo ON is de-activated at the same time.

then after a time delay set by parameter Cn003, Output Contact BI is switched off. (Signal to operate the brake).



Note: Input contacts status of above time sequence diagram “1” (ON) and “0” (OFF).

Please check 5-6-1 to set the required high /Low signal levels (PNP/NPN) selection.

5-6-6 CW/CCW Drive Inhibit Function

Stopping method of the servo motor as a result of **CW/CCW Inhibit** function can be selected according to the list below:

Parameter	Name	Setting	Description	Control Mode
★ Cn009	CW/CCW drive inhibit	0	When torque limit reached the setting value of (Cn010,Cn011), servo motor deceleration to stop in the zero clamp status.	ALL
		1	Deceleration by using dynamic brake to stop then hold in dynamic brake status. Cn009 setting has priority over Cn008 setting, it require re-cycling power to take effect after setting changed.	
		2	Once max torque limit ($\pm 300\%$) is detected then deceleration to stop with zero clamp.	

New setting will become effective after re-cycling the power.


Note!

When the Drive Inhibit occurs in CCW/CW, the Cn009 has the higher priority than Cn008.

Example:

If Cn008 is set to 0 or 1 which means (without Dynamic Brake).

BUT Cn009= 1 (with Dynamic Brake), then the dynamic brake will be effective (enabled).



5-6-7 Selecting for External Regeneration Resistor

In applications where a high inertia load is stopped rapidly, motor will generate an energy, which is regenerate power back to the servo drive (Regeneration energy)

- (1) Short deceleration time with heavy loads.
- (2) In vertical load applications.
- (3) High inertia rotary load applied to the motor shaft.

Part of the regeneration power will be absorbed by the drive main smoothing capacitors

If there is too much regeneration power which can not be totally absorbed by the capacitor then regeneration resistors can be used to absorb the excess power.

Built-in Regeneration Resistor specification is as below table.

Drive Model	Built-in Regeneration Resistor Specifications		The Regeneration Power(W) absorbed by the built in Resistor (Average Power)	Minimum allowed Resistance Value (Ω)
	Resistance(Ω)	Power(W)		
JSDAP-15	25	60	24	25
JSDAP-20	25	60	24	25
JSDAP-30	25	60	24	25
JSDAP-50	20	150	60	15
JSDAP-75	12.5	150	60	10
JSDAP-100	12.5	150	60	10
JSDAP-150	8	200	80	6
JSDAP-200	—	—	—	3
JSDAP-300	—	—	—	3

Built-in Regeneration Resistor

The Regeneration Resistor which is built-in this device can absorb the Regeneration Power from acceleration and deceleration running or Vertical Loading.

But for applications that the large load inertia causes the motor shaft to rotate, an external regeneration Resistor must be installed to protect the servo drive otherwise the servo drive can not function correctly. Select the resistor according to the specified values and if installing regeneration resistors in a parallel way to have more power absorb capability.

Ensure that the total resistance value does not smaller than the minimum resistance listed in the table above.

Setting for the Power of External Regeneration Resistor

When using external regeneration resistor, the power value (Watts) must be set in parameter **Cn012**.

Parameter	Name	Default	Unit	Setting Range	Control Mode
Cn012	Watts setting for External Regeneration Resistor	60/150	W	0~10000	ALL

P.S.)This default value will change depend on servo model ,different series of servo has different default

Wiring for External Regeneration Resistor


When external Regeneration Resistor is used, must remove the link between **PC** and **P1** on **TB1** Terminal.

Then the resistor should be installed between terminals **P** and **PC**.

For safety, use of resistors with thermal protection is recommended.

The thermal switch contact can then be interlocked to disable drive or remove power if necessary.

Refer to connection diagram below:



When installing Regeneration Resistors care must be taken as the resistor absorbs the regeneration power, and it is possible to generate the high temperatures above 100°C.

Provide the necessary cooling and use appropriate high temperature wires and ensure there has enough space between regeneration resistor and other materials.

Assess for an external resistor and calculate for the power consumption:

Use the table below to determine, if an external regeneration Resistor is necessary.

The table below shows the permitted number of no load operation cycles per minute for various servo motors in regeneration condition.

Defination of “No load operation cycles”:

The servo motor, accerlate from 0 speed to rated speed and deceleration from the rated speed to 0 speed. (No load)

The regeneration energy capacity (in Joules) which can be absorbed by the built-in resistor during no load acceleration/deceleration period, refer to the table list below.

Drive Model	Motor Model	Permitted number of no load operation cycles/min	Main Capacitor energy absorption capacity in Joules. E_C (J).
JSDAP-15	JSMA-LC03	433	6
	JSMA-SC02	1775	
	JSMA-SC04	1004	
JSDAP-20	JSMA-LC08	118	9
	JSMA-SC04	1004	
	JSMA-SC08	321	
	JSMA-MA05	411	
	JSMA-MH05	186	
JSDAP-30	JSMA-SC08	321	13
	JSMA-MA10	213	
	JSMA-MB10	102	
	JSMA-MH10	95	
	JSMA-MA15	145	
	JSMA-MB15	73	
	JSMA-MC15	45	
JSDAP-50	JSMA-MA15	484	13
	JSMA-MB15	245	
	JSMA-MC15	152	
	JSMA-MB20	178	
JSDAP-75	JSMA-MB30	121	18
	JSMA-MC30	79	

Calculation for the allowable operation cycles per minute by motor speed and inertia.

The formula below should be used to calculate the permitted number of cycles/min in **regenerative mode** in accordance with the actual **loading** and the **running speed** of the motor.

$$\text{Allowable operation cycle/min.} = \frac{\text{No load operation cycles}}{(1+\alpha)} \times \left(\frac{\text{Rated Speed}}{\text{MaxRunningSpeed}} \right)^2$$


$\alpha = \text{Load Inertia / Motor Inertia}$

If the required number of cycles /min is higher than the calculated value then an external regeneration resistor must be installed.

Calculation of the external regeneration resistor power (Watts).

Calculate the resistor watts according to the information and formulas below:

(Energy consumed by the motor internally is ignored).



Step	Item	Formula	Description
1	Calculate the working Energy of the servo system.	$E_M = J_T \omega_{rm}^2 / 182$	E_M : Working Energy of Servo system (J) J_T : Inertia applied to the motor shaft ($kg \cdot m^2$) ω_{rm} : Motor running Speed(rpm)
2	Calculate the Energy consumption by the load during deceleration.	$E_L = (\pi / 60) \omega_{rm} T_L t_D$	E_L : The Energy during deceleration (J) T_L : Loading Torque(Nm) t_D : The Time from deceleration to stopping(s)
3	Calculate the Energy absorbed by internal main capacitor.	E_C Check the diagram above	E_C : The Energy absorbed by the main capacitor (J)
4	Calculate the Energy which regeneration resistor consumes	$E_R = E_M - (E_L + E_C)$	E_R : The Energy which Regeneration Resistor consumes (J)
5	Calculate the Power for regeneration resistor	$P_R = (E_R/T)/0.4$	P_R : Regeneration Resistor Power(W) T : Operating cycle for servo system(s)

Note 1: 0.4 in the formula for P_R corresponds to 40% regeneration duty cycle.

Note 2: If the E_L can not be calculated, then let $E_L = 0$, then calculate ER .

In applications with regenerative loads, which cause reverse torque, a large amount of energy will flow back to the driver.

In such applications, calculate ER and hence regeneration resistor power according to the formula below.

Item	Formula	Description for Symbols
Calculate the working Energy during the continuous regenerative period.	$E_G = (\pi / 60) \omega_{rm,G} T_G t_G$	E_G : Working Energy during the regenerative period. (J) $\omega_{rm,G}$: Motor running speed during the regenerative period . (rpm) T_G : Loading Torque during the regenerative period (Nm) t_G : Regenerative Time. (s)

The formula for step 4 in the previous table will be: $E_R = E_M - (E_L + E_C) + E_G$

5-6-8 Fan Setting

Available models that equipped with the fan.

Parameter	Name	Setting	Description	Control Mode
Cn031.0	Cooling fan running mode	0	Auto-run by internal temperature sensor.	ALL
		1	Run when Servo ON	
		2	Always Running.	
		3	Disabled.	

5-6-9 Low Voltage Protection Auto-reset



Parameter	Name	Setting	Description	Control Mode
Cn031.1	Low Voltage Protection(AL-01) auto-reset selection	0	As servo on, it shows AL-01 low voltage alarm immediately when it detect low voltage, and after eliminating the situation, to reset it, servo off is a must.	ALL
		1	It shows BB (baseblock) immediately when it detect low voltage, and after eliminating the situation, drive would be auto-reset and displayed Run.	

5-6-10 Absolute Encoder Battery Fault


Parameter	Name	Setting	Description	Control Mode
Cn031.2	Absolute Encoder Battery Fault	0	When battery fault occurs, driver can not be memory absolute position, AL-16 displayed and motor operates continuous.	ALL
		1	When battery fault occurs, driver can not be memory absolute position, AL-16 do not display and motor stopped.	

5-6-11 Analog Monitor

There are two analog output signals which can be used to monitor running Speed, Torque, Current and Position as follows:


Parameters	Name & Function		Default	Unit	Setting Range	Control Mode
Cn006.0 	Analog monitor output selection (MON1)		2	X	0 B	ALL
	Setting	Explanation				
	0	Speed command (±10V/1.5 times of the rated speed)				
	1	Speed feedback detection (±10V/1.5 times of the rated speed)				
	2	Torque command (±10V/1.5 times of the rated torque)				
	3	Torque feedback detection (±10V/1.5 times of the rated torque)				
	4	Pulse command input				
	5	Position deviation value				
	6	Electrical angle				
	7	Main circuit (Vdc Bus) voltage				
	8	Speed command (+10V/3.5 times of the rated torque)				
	9	Speed feedback detection (+10V/1.5 times of the rated speed)				
	A	Torque command (+10V/3.5 times of the rated torque)				
	B	Torque feedback detection (±10V/3.5 times of the rated torque)				
Cn006.1 	Analog monitor output selection MON2		0			
	Refer to Cn006.0 for setting this parameter					
Cn043	Analog monitor output ratio (MON1)		100	%	1 1000	ALL
	For example, the Analog monitor output ratio is 10V/1.5 times speed when we set 100%, if we want 10V/0.75 times speed, please set 200%					
Cn044	Analog monitor output ratio (MON2)		100	%	1 1000	ALL
	Please refer to Cn043.					

Circuit diagram for analog monitor shows below:



Analog monitor output zero offset can be adjusted by parameters **Cn027&Cn028** as below.

Parameter	Name	Default	Unit	Setting Range	Control Mode
Cn027	Analog Monitor 1 Offset adjustment	4	x40mV	-250~250	ALL
Cn028	Analog Monitor 2 Offset adjustment	4	x40mV	-250~250	ALL



5-6-12 Factory Setting Parameter

This parameter can reset all parameter settings to default value (factory reset).


Parameter	Name	Setting	Description	Control Mode
★ Cn029	Reset parameters	0	Disabled	ALL
		1	All parameters are reset to default values.	

New setting will become effective after re-cycling the power.


5-7 Tool Turret Modes

JSDAP series provided tool turret control mode, the related functions and procedures are set as following described.

5-7-1 Parameter Setting

Parameter	Name	Setting	Description
★ ● Cn001	Control Mode selection	9	Tool Turret mode
★ Cn002.0 	SON (Servo On) Input contact function	0	Input Contact, Enables SON (Servo On).
		1	Input Contact has no function. (SON is enabled when Power on).
★ Cn002.1	CCWL & CWL Input contact function	0	CCWL and CWL input contacts are able to control the drive inhibit of CCW and CW.
		1	CCWL & CWL input contacts are not able to control CCW and CW drive inhibit. CCW and CW drive inhibit is disable.
★ Cn002.3	EMC reset mode selection	0	Reset EMC signal is only available in Servo Off condition (SON contact is open) and reset AL-09 by ALRS signal. P.S.) It is NOT allow to reset when SON is applied.
		1	When EMC status is released, AL-09 can be reset on both Servo ON and Servo OFF conditions. Attention! Ensure that the speed command are removed before the alarm is reset to avoid motor unexpected start.
Cn010	CCW Torque command Limit.	0 300	Ex: For a torque limit in CCW direction which is twice the rated torque, set Cn10=200.
Cn011	CW Torque command Limit.	-300 0	Ex: For a torque limit in CW direction which is twice the rated torque, set Cn11=-200.
Cn025	Load-Inertia ratio	0 1000	$\text{LoadInertiaRatio} = \frac{\text{LoadInertiaToMotor}(J_L)}{\text{MotorRotorInertia}(J_M)} \times 100\%$


Parameter	Name & Function				Default	Unit	Setting Range	Control Mode	Communication Address							
									RS232	RS485						
Cn026 	Rigidity Setting When Auto tuning is used, set the Rigidity Level depending on the various Gain settings for applications such as those listed below:				9	X	1 21	Pi Pe S	C32H	001AH						
	Explanation															
	Setting	Position Loop Gain Pn310 [1/s]	Speed Loop Gain Sn211 [Hz]	Speed Loop Integral-Time Constant Sn212 [x0.2msec]												
	1	2	2	1400												
	2	3	3	950												
	3	6	6	450												
	4	9	9	300												
	5	12	12	300												
	6	15	15	300												
	7	20	20	225												
	8	30	30	150												
	9	40	40	100												
	10	50	50	60												
	11	60	60	75												
	12	70	70	50												
	13	85	85	50												
	14	100	100	40												
	15	120	120	40												
	16	140	140	30												
	17	160	160	30												
	18	180	180	25												
	19	200	200	25												
	20	225	225	20												
	21	250	250	20												

Parameter	Name	Setting	Description
★ Cn029	Reset parameters	0	Disabled
		1	Reset all Parameters to default (Factory setting)
★ Cn030 	Servo motor model code	Default	<p>Servo model code can be display and checked with parameter dn-08, refer 3-2-2 dn-08 table for more information.</p> <p>Attention : Before operate your servo motor, check this parameter setting is compatible for servo drive and motor. If there has any incompatible problem contact supplier for more information.</p>
Pn307	Position complete value	0 50000 pulse	<p>Set a value for In position output signal. When the Position pulse error value is less then Pn307 output-contact INP (In position output signal) will be activated.</p>
★ Pn313	Position command smooth Acceleration/Deceleration Time Constant	0 10000 ms	<p>Set the time period for the Position command pulse frequency to rise from 0 to 63.2%.</p> <p>Position Pulse Command Frequency (%)</p>  <p>Position Pulse Command Frequency</p> <p>Time (ms)</p>
Pn324	Total Number Setting	1 64	Sets total number of tool turret
Pn325	The Location of Zero CNC Tool Turret	0 131071 pulse	Sets the location of zero tool
Pn326	Reduction Gear Rate for CNC Tools Turret	0 16383 rev	Sets reduction rate for turret.
Pn327	Rotation Speed of tool turret switching	0 3000 rpm	Sets the rotation speed of tool terret swithing


5-7-2 Rigidity Setting

Parameter	Name	Setting	Description
◆ qn501	Speed Loop Gain 1	10 1500	Speed loop gain has a direct effect on the frequency response bandwidth of the Speed-control loop. Without causing vibration or noise Speed-loop-gain can be increased to obtain a faster speed response. If Cn025 (load Inertia ratio) is correctly set, the speed-loop-bandwidth will equal to speed-loop-gain.
◆ qn502	Speed-loop Integral time 1	1 5000	Speed loop integral element can eliminate the steady speed error and react to even slight speed variations. Decreasing Integral time can improve system rigidity. The formula below shows the relationship between Integral time and Speed loop Gain. $\text{SpeedLoopIntegrationTimeConstant} \geq 5 \times \frac{1}{2\pi \times \text{SpeedLoopGain}}$
◆ qn505	Position Loop Gain 1	1 1000	Without causing vibration or noise on the mechanical system the position loop gain value can be increased to speed up response and shorten the positioning time. Generally, the position loop bandwidth should not be higher than speed loop bandwidth. The relationship is according to the formula below: $\text{PositionLoopGain} \leq 2\pi \times \frac{\text{SpeedLoopGain}}{5}$
◆ qn507	Position Loop Feed Forward Gain	0 100	It can be used to reduce the follow up error of position control and speed up the response. If the feed forward gain is too large, it might cause speed overshoot and in position oscillations which result in the repeated ON/OFF operation of the output contact INP("In Position" output signal)


5-7-3 Tool Turret Mode Setting Flow Chart




5-7-4 Timing Diagram of Tool Turret Homing



5-7-5 Timing Diagram of Auto-selection Mode



5-7-6 Timing Diagram of JOG Mode



Chapter 6 Parameters

6-1 Explanation of Parameter groups.

There are 10 groups of parameters as listed below.

Symbol	Description
Un-xx	Status Display Parameters.
dn-xx	Diagnostics Parameters.
AL-xx	Alarm Parameters
Cn-xx	System Parameters
Tn1xx	Torque Control Parameters
Sn2xx	Speed Control Parameters
Pn3xx	Position Control Parameters
Pn4xx	Point to Point Control Parameter
qn5xx	Quick Set-up Parameters
Hn6xx	Multi-function I/O parameters

Control Mode Code



Signal	Control Mode
ALL	All Control Mode
Pi	Position Control Mode(Internal Positional Command)
Pe	Position Control Mode(External Pulse Command)
Pt	Tool Turret Control Mode
S	Speed Control Mode
T	Torque Control Mode

Definition of Symbols.




Symbol	Explanation
★	Parameter becomes effective after recycling the power.
●	Parameter is not effected by Cn029.
◆	Parameter is Effective without pressing the Enter key.

6-2 Parameter Display Table




System Parameters

Parameter	Name & Function	Default	Unit	Setting Range	Control Mode	Communication Address				
						RS232	RS485			
★● Cn001 	Control Mode selection	2	X	0 A	ALL	510H	0001H			
	Setting Explanation									
	0 Torque Control									
	1 Speed Control									
	2 External Position Control (external pulse Command)									
	3 External Position/Speed Control Switching									
	4 Speed/Torque Control Switching									
	5 External Position/Torque Control Switching									
	6 Internal Position Control (internal position Command)									
	7 Internal Position/Speed mode switching									
★ Cn002.0 	SON (Servo On) Input contact function	0	X	0 1	ALL	51DH	0002H			
	Setting Explanation									
★ Cn002.1 	CCWL & CWL Input contact function.	0	X	0 1						
	Setting Explanation									
★ Cn002.2 	Auto Tuning	0	X	0 1	Pi Pe S	51DH	0002H			
	Setting Explanation									
★ Cn002.3 	EMC reset mode selection	0	X	0 1	ALL					
	Setting Explanation									
	0 Reset EMC signal is only available in Servo Off condition (SON contact is open) and reset AL-09 by ALRS signal. P.S.) It is NOT allow to reset when SON is applied.									
	1 When EMC status is released, AL-09 can be reset on both Servo ON and Servo OFF conditions. Attention! Ensure that the speed command are removed before the alarm is reset to avoid motor unexpected start.									


Parameter	Name & Function	Default	Unit	Setting Range	Control Mode	Communication Address																		
						RS232	RS485																	
Cn003	<p>Output time setting for Mechanical Brake Signal</p> <p>Brake Signal Timing Sequence :</p> <p>Cn003 (machinery brake signal output time) is positive</p> <p>Cn003 (machinery brake signal output time) is negative</p> <p>Implementation a pin for dynamic brake signal(BI) as a output signal before to perform this function. Refer to sequence diagram above.</p> <p>Note: Signal logic level status: 1 = ON. 0 = OFF.</p> <p>Refer to section5-6-1 for setting contact the high & Low logic levels.</p>	0	msec	-2000 2000	ALL	511H	0003H																	
Cn004	<p>Motor rotate direction.(Inspect from the load side)</p> <p>When Torque or Speed Command value is Positive, the setting of Motor rotation direction are:</p> <table border="1"> <thead> <tr> <th rowspan="2">Setting</th> <th colspan="2">Explanation</th> </tr> <tr> <th>Torque Control</th> <th>Speed Control</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Counter ClockWise(CCW)</td> <td>Counter ClockWise (CCW)</td> </tr> <tr> <td>1</td> <td>ClockWise (CW)</td> <td>Counter ClockWise (CCW)</td> </tr> <tr> <td>2</td> <td>Counter ClockWise (CCW)</td> <td>ClockWise(CW)</td> </tr> <tr> <td>3</td> <td>ClockWise (CW)</td> <td>ClockWise (CW)</td> </tr> </tbody> </table>	Setting	Explanation		Torque Control	Speed Control	0	Counter ClockWise(CCW)	Counter ClockWise (CCW)	1	ClockWise (CW)	Counter ClockWise (CCW)	2	Counter ClockWise (CCW)	ClockWise(CW)	3	ClockWise (CW)	ClockWise (CW)	0	X	0 3	S T	512H	0004H
Setting	Explanation																							
	Torque Control	Speed Control																						
0	Counter ClockWise(CCW)	Counter ClockWise (CCW)																						
1	ClockWise (CW)	Counter ClockWise (CCW)																						
2	Counter ClockWise (CCW)	ClockWise(CW)																						
3	ClockWise (CW)	ClockWise (CW)																						





Parameter	Name & Function		Default	Unit	Setting Range	Control Mode	Communication Address							
							RS232	RS485						
★ Cn005 	Encoder pulse output scale.		2500 8192 32768	pulse	1 Encoder pulse per rotation	ALL	513H	0005H						
	For default set to the rated encoder number of pulses per revolution, such as 2500ppr. Encoder ppr can be scaled by setting a ppr in the range of 1 to the rated ppr of the encoder for scaling purpose. Ex:encoder rated precision is 2000 ppr, If you setting Cn005 =1000, the output is 1000ppr.													
	P.S.the default depends on encoder rated precision 2500PPR:2500 ;8192PPR: 8192; 32768PPR : 15bit, 17bit													
Cn006.0 	Analog monitor output selection MON1		2	X	0 B	ALL	514H	0006H						
	Setting	Explanation												
	0	Speed command (±10V/1.5 times of the rated speed)												
	1	Speed feedback detection (±10V/1.5 times of the rated speed)												
	2	Torque command (±10V/1.5 times of the rated torque)												
	3	Torque feedback detection (±10V/1.5 times of the rated torque)												
	4	Pulse command input												
	5	Position deviation value												
	6	Electrical angle												
	7	Main circuit (Vdc Bus) voltage												
	8	Speed command (+10V/3.5 times of the rated torque)												
	9	Speed feedback detection (+10V/1.5 times of the rated speed)												
	A	Torque command (+10V/3.5 times of the rated torque)												
	B	Torque feedback detection (±10V/3.5 times of the rated torque)												
Cn006.1 	Analog monitor output selection MON2		0		0 4500	S T	515H	0007H						
	Refer to Cn006.0 for setting this parameter													
Cn007 	Speed reached preset.		Rated rpm × 1/3	rpm	0 4500	S T	515H	0007H						
	Speed preset level for ClockWise or Counter ClockWise rotation. When the speed is greater than preset level in Cn007 the Speed reached output signal INS will be activated..													
Cn008 	Brake Mode		2	X	0 5	ALL	516H	0008H						
	Selectable Brake modes for Servo off, EMC and CCW/CW drive inhibit.													
	Setting	Explanation												
		Dynamic brakes	Mechanical brakes											
	0	No	No											
	1	No	Yes											
	2	Yes	No											
	3	Yes	Yes											
	4*	No (Under 100rpm)	No											
	5*	No (Under 100rpm)	Yes											




Parameter	Name & Function		Default	Unit	Setting Range	Control Mode	Communication Address	
							RS232	RS485
★ Cn009	CW/CCW drive inhibit mode		0	X	0 2	ALL	517H	0009H
	Setting	Explanation						
	0	When torque limit reached the setting value of (Cn010, Cn011), servo motor deceleration to stop in the zero clamp condition.						
	1	Deceleration by using dynamic brake to stop then hold in dynamic brake status. Cn009 setting has priority over Cn008 setting, it require re-cycling power to take effect after setting changed.						
	2	Once max torque limit ($\pm 300\%$) is detected then deceleration to stop, zero clamp is applied when stop.						
Cn010	CCW Torque command Limit.	300	%	%	0 300	ALL	518H	000AH
		260						
		250						
		240						
		220						
		200						
		-300						
Cn011	CW Torque command Limit.	-260	%	%	-300 0	ALL	519H	000BH
		-250						
		-240						
		-220						
		-200						
	Power setting for External Regeneration Resistor	0						
	Refer to section 5-6-7 to choose external Regen resister and set its power specification in Watts of Cn012. P.S.)This default value will change depend on servo model P.S.)Different series of servo has different default	/60 /150						
Cn012	Frequency of resonance Filter (Notch Filter).	0	Hz	0 1000	Pi Pe S	C40H	000DH	
	Enter the vibration frequency in Cn013, to eliminate system mechanical vibration.							
Cn013	Band Width of the Resonance Filter.	7	X	1 100	Pi Pe S	C41H	000EH	
	Adjusting the band width of the frequency, lower the band width value in Cn014 , restrain frequency Band width will be wider.							
Cn015.0 	PI/P control switch mode.	4	X	0 4	Pi Pe S	C07H	000FH	
	Setting							
	0							
	1							
	2							
	3							
	4							
	Switch from PI to P if the torque command is larger than Cn016 .							
	Switch from PI to P if the speed command is larger than Cn017 .							
	Switch from PI to P if the acceleration rate is larger than Cn018 .							
	Switch from PI to P if the position error is larger than Cn019 .							
	Switch from PI to P be the input contact PCNT . Set one of the multi function terminals to option 03.							


Parameter	Name & Function	Default	Unit	Setting Range	Control Mode	Communication Address	
						RS232	RS485
 Cn015.1	Automatic gain 1& 2 switch	4	X	0 4	Pi Pe S	C07H	000FH
	Setting Explanation						
	0 Switch from gain 1 to 2 if torque command is greater than Cn021 .						
	1 Switch from gain 1 to 2 if speed command is greater than Cn022 .						
	2 Switch from gain 1 to 2 if acceleration command is greater than Cn023 .						
	3 Switch from gain 1 to 2 if position error value is greater than Cn024 .						
 Cn015.3	4 Switch from gain 1 to 2 by input contact G-SEL . Set one of the multi function terminals to option 15.						
	Automatic gain proportion switch	0	X	1 0	ALL		
	Setting Explanation						
	0 JSDAP new automatic gain proportion						
 Cn016	1 JSDAP old automatic gain proportion						
	PI/P control mode switch by Torque Command	200	%	0 399	Pi Pe S	C4BH	0010H
	Set the Cn015.0=0 first.						
	If Torque Command is less than Cn016 PI control is selected.						
 Cn017	If Torque Command is greater than Cn016 P control is selected.						
	PI/P control mode switch by Speed Command	0	rpm	0 4500	Pi Pe S	C4CH	0011H
	Set the Cn015.0=1 first.						
 Cn018	If Speed Command is less than Cn017 PI control is selected.						
	If Speed Command is greater than Cn017 P control is selected.						
	PI/P control mode switch by accelerate Command						
 Cn019	Set the Cn015.0=2 first.	0	rps/s	0 18750	Pi Pe S	C4DH	0012H
	If Acceleration is less than Cn018 PI control is selected.						
	If Acceleration is greater than Cn018 P control is selected.						
 Cn020	PI/P control mode switch by position error number	0	pulse	0 50000	Pi Pe S	C4EH	0013H
	Set the Cn015.0=3 first.						
	If Position error value is less than Cn019 PI control is selected.						
 Cn021	If Position error value is greater than Cn019 P control is selected.						
	Automatic gain 1& 2 switch delay time.	0	x02 msec	0 10000	Pi Pe S	53CH	0014H
	Speed loop 2 to speed loop 1, Change over delay, when two control speed loops (P&I gains 1 & 2) are used.						
	Automatic gain 1& 2 switch condition (Torque command)						
	Set Cn015.1=0 first.						
	When torque command is less than Cn021 , Gain 1 is selected.						
	When torque command is greater than Cn021 , Gain 2 is selected.	200	%	0 399	Pi Pe S	53DH	0015H
	When Gain 2 is active and torque command becomes less than Cn021 setting value, system will automatically switch back to Gain 1 switch time delay can be set by Cn020.						

Parameter	Name & Function	Default	Unit	Setting Range	Control Mode	Communication Address	
						RS232	RS485
Cn022	<p>Automatic gain 1& 2 switch condition (Speed Command)</p> <p>Set the Cn015.1=1 first.</p> <p>When speed command is less than Cn022 Gain 1 is selected.</p> <p>When speed command is greater than Cn022 Gain 2 is selected.</p> <p>When Gain 2 is active and speed command becomes less than Cn022 setting value, system will automatically switch back to Gain 1 the switch time delay can be set by Cn020.</p>	0	rpm	0 4500	Pi Pe S	53EH	0016H
Cn023	<p>Automatic gain 1& 2 switch condition (Acceleration Command)</p> <p>Set Cn015.1=2 first.</p> <p>When accel. command is less than Cn023 Gain 1 is selected.</p> <p>When accel. command is greater than Cn023 Gain 2 is selected.</p> <p>When Gain 2 is active and acceleration command becomes less than Cn023 system will automatically switch back to Gain 1 the switch time delay can be set by Cn020.</p> <p>* accel. is acceleration</p>	0	rps/s	0 18750	Pi Pe S	53FH	0017H
Cn024	<p>Automatic gain 1& 2 switch condition (Position error value)</p> <p>Set Cn015.1=3 first.</p> <p>When position error value is less than Cn024 Gain 1 is selected.</p> <p>When position error value is greater than Cn024 Gain 2 is selected.</p> <p>When Gain 2 is active and position error value becomes less than Cn024 system will automatically switch back to Gain 1 and the switch time delay can be set by Cn020.</p>	0	pulse	0 50000	Pi Pe S	540H	0018H
Cn025	<p>Load-Inertia ratio</p> <p>$LoadInertiaRatio = \frac{LoadInertiaToMotor(J_L)}{MotorRotorInertia(J_M)} \times 100\%$</p>	40	x0.1	0 1000	Pi Pe S	5FBH	0019H

Parameter	Name & Function				Default	Unit	Setting Range	Control Mode	Communication Address							
									RS232	RS485						
Cn026 	Rigidity Setting				9	X	1 21	Pi Pe S	C32H	001AH						
	When Auto tuning is used, set the Rigidity Level depending on the various Gain settings for applications such as those listed below:															
	Setting	Explanation														
		Position Loop Gain Pn310 [1/s]	Speed Loop Gain Sn211 [Hz]	Speed Loop Integral-Time Constant Sn212 [x0.2msec]												
	1	2	2	1400												
	2	3	3	950												
	3	6	6	450												
	4	9	9	300												
	5	12	12	300												
	6	15	15	300												
	7	20	20	225												
	8	30	30	150												
	9	40	40	100												
	10	50	50	60												
	11	60	60	75												
	12	70	70	50												
	13	85	85	50												
	14	100	100	40												
	15	120	120	40												
	16	140	140	30												
	17	160	160	30												
	18	180	180	25												
	19	200	200	25												
	20	225	225	20												
	21	250	250	20												

Parameter	Name & Function	Default	Unit	Setting Range	Control Mode	Communication Address										
						RS232 RS485										
Cn027	Analog monitor output 1, Offset adjustment Analog monitor output zero offset can be adjusted by parameter. Cn027 as below. 	0	x40 mV	-250 250	ALL	C03H 001BH										
Cn028	Analog monitor output 2, offset adjustment Analog monitor output 2, zero offset can be adjusted by parameter. Cn028 . See diagram for Monitor 1 above.	0	x40 mV	-250 250	ALL	C04H 001CH										
Cn029	Reset parameters. <table border="1"> <tr> <th>Setting</th> <th>Explanation</th> </tr> <tr> <td>0</td> <td>Disabled</td> </tr> <tr> <td>1</td> <td>Reset all Parameters to default (Factory setting)</td> </tr> </table>	Setting	Explanation	0	Disabled	1	Reset all Parameters to default (Factory setting)	0	X	0 1	ALL	5FDH 001DH				
Setting	Explanation															
0	Disabled															
1	Reset all Parameters to default (Factory setting)															
★ Cn030	Servo motor model code  Servo model code can be display and checked with parameter dn-08, refer 3-2-2 dn-08 table for more information. Attention : Before operate your servo motor., check this parameter setting is compatible for servo drive and motor. If there has any incompatible problem contact supplier for more information.	Default	X	X	ALL	50BH 001EH										
Cn031.0	Cooling fan running modes (Available for JSDAP-50A3/75A3/100A3/200A3/300A3) <table border="1"> <tr> <th>Setting</th> <th>Explanation</th> </tr> <tr> <td>0</td> <td>Auto-run by internal temperature sensor.</td> </tr> <tr> <td>1</td> <td>Run when Servo ON</td> </tr> <tr> <td>2</td> <td>Always Running.</td> </tr> <tr> <td>3</td> <td>Disabled.</td> </tr> </table>	Setting	Explanation	0	Auto-run by internal temperature sensor.	1	Run when Servo ON	2	Always Running.	3	Disabled.	0	X	0 3	ALL	
Setting	Explanation															
0	Auto-run by internal temperature sensor.															
1	Run when Servo ON															
2	Always Running.															
3	Disabled.															
Cn031.1	Low Voltage Protection(AL-01) auto-reset selection  This parameter(AL-01) could be set the method of Low Voltage Protection. <table border="1"> <tr> <th>Setting</th> <th>Explanation</th> </tr> <tr> <td>0</td> <td>As servo on, it shows AL-01 low voltage alarm immediately when it detect low voltage, and after eliminating the situation, to reset it, servo off is a must.</td> </tr> <tr> <td>1</td> <td>It shows BB(baseblock) immediately when it detect low voltage, and after eliminating the situation, drive would be auto-reset and displayed Run.</td> </tr> </table>	Setting	Explanation	0	As servo on, it shows AL-01 low voltage alarm immediately when it detect low voltage, and after eliminating the situation, to reset it, servo off is a must.	1	It shows BB(baseblock) immediately when it detect low voltage, and after eliminating the situation, drive would be auto-reset and displayed Run .	0	X	0 1	ALL	50EH 001FH				
Setting	Explanation															
0	As servo on, it shows AL-01 low voltage alarm immediately when it detect low voltage, and after eliminating the situation, to reset it, servo off is a must.															
1	It shows BB(baseblock) immediately when it detect low voltage, and after eliminating the situation, drive would be auto-reset and displayed Run .															
● Cn031.2	Absolute Encoder Battery Fault  <table border="1"> <tr> <th>Setting</th> <th>Explanation</th> </tr> <tr> <td>0</td> <td>When battery fault occurs, driver can not be memory absolute position, AL-16 displayed and motor operates continuous.</td> </tr> <tr> <td>1</td> <td>When battery fault occurs, driver can not be memory absolute position, AL-16 do not display and motor stopped.</td> </tr> </table>	Setting	Explanation	0	When battery fault occurs, driver can not be memory absolute position, AL-16 displayed and motor operates continuous.	1	When battery fault occurs, driver can not be memory absolute position, AL-16 do not display and motor stopped.	ABS encoder = 0 others = 1	X	0 1	ALL					
Setting	Explanation															
0	When battery fault occurs, driver can not be memory absolute position, AL-16 displayed and motor operates continuous.															
1	When battery fault occurs, driver can not be memory absolute position, AL-16 do not display and motor stopped.															



Parameter	Name & Function		Default	Unit	Setting Range	Control Mode	Communication Address	
							RS232	RS485
 Cn031.3	Motor Series Selection	Setting 0 1	0	X	0 1	ALL	50EH	001FH
	Setting							
	Explanation							
Cn032	Speed feedback smoothing filter	500	Hz	0 2500	Pe Pi S	546H	0020H	
	Restrain sharp vibration noise by the setting and this filter also delay the time of servo response.							
Cn033	Speed Feed-forward smoothing filter	500	Hz	0 1000	Pe Pi	51EH	0021H	
	Smooth the speed feed-forward command.							
Cn034	Torque command smoothing filter	500	Hz	0 5000	ALL	C17H	0022H	
	Restrain sharp vibration noise by the setting and this filter delay the time of servo response.							
 Cn035	Panel display content selection	Setting 0 1 31	0	X	0 31	ALL	541H	0023H
	Select display content for LED panel for power on status.							
	Setting							
	Explanation							
	0 Display data set and drive status parameter. Refer 3-1							
 Cn036	Servo ID number	1	X	0 254	ALL	51BH	0024H	
	When using Modbus for communication, each servo units has to setting a ID number. repeated ID number will lead to communication fail.							
 Cn037.0	Modbus RS-485 braud rate setting	Setting 0 1 2 3 4 5	1	bps	0 5	ALL	544H	0025H
	Setting							
	Explanation							
	0 4800							
	1 9600							
	2 19200							
	3 38400							
 Cn037.1	PC Software RS-232 braud rate setting	Setting 0 1 2 3	1	bps	0 3	ALL	544H	0025H
	Setting							
	Explanation							
	0 4800							
	1 9600							
 Cn037.2	Communication RS-485 selection	Setting 0 1	0	X	0 1	ALL		
	This parameter can be set to RS-485 communication written to the EEPROM or SRAM.							
	Setting							
	Explanation							
	0 Write to EEPROM							
	1 Write to SRAM							


Parameter	Name & Function		Default	Unit	Setting Range	Control Mode	Communication Address	
							RS232	RS485
 ★ Cn037.3	Communication RS232 is read and written to the selection of EEPROM.		0	X	0 1	ALL	544H	0025H
	Setting	Explanation						
	0	JSDAP Command address (E8~EC)						
★ Cn038	Communication protocol		0	X	0 8	ALL	545H	0026H
	Setting	Explanation						
	0	7 , N , 2 (Modbus , ASCII)						
	1	7 , E , 1 (Modbus , ASCII)						
	2	7 , O , 1 (Modbus , ASCII)						
	3	8 , N , 2 (Modbus , ASCII)						
	4	8 , E , 1 (Modbus , ASCII)						
	5	8 , O , 1 (Modbus , ASCII)						
	6	8 , N , 2 (Modbus , RTU)						
	7	8 , E , 1 (Modbus , RTU)						
★ Cn039	Communication time-out detection		0	sec	0 20	ALL	567H	0027H
	Setting non-zero value to enable this function, communication Time should be in the setting period otherwise alarm message of communication time-out will show. Setting a zero value to disable this function.							
★ Cn040	Communication response delay time		0	0.5 msec	0 255	ALL	5EDH	0028H
Cn041	Absolute encoder rotation value reset							
	Setting	Explanation	0	X	0 1	ALL	524H	0029H
	0	Disable						
	1	Reset absolute encoder rotation value						
Cn041.1	Absolute encoder battery Alarm Reset(AL-16)		0	X	0 ~ 1	ALL	524H	0029H
	Setting	Explanation						
	0	Disable						
Cn043	Analog monitor output ratio (MON1)		100	%	1 1000	ALL	C72H	002BH
	For example, the Analog monitor output ratio is 10V/1.5 times speed when we set 100%, if we want 10V/0.75 times speed, please set 200%							
Cn044	Analog monitor output ratio (MON2)		100	%	1 1000	ALL	C73H	002CH
	Please refer to Cn043.							
Cn045 ~ Cn047	Reserved		--	--	--	--	--	--
Cn048	Automatic gain 1&2 switch delay time		0	x02 msec	0 10000	Pi Pe S	C7AH	0030H
	Set the delay time from speed loop 1 to speed loop 2, when two control speed loops are used.							
Cn049	Automatic gain 1&2 switch time		0	x02 msec	0 10000	Pi Pe S	C7BH	0031H
	Set the switch time from speed loop 1 to speed loop 2, when two control speed loops are used.							
Cn050	Automatic gain 1&2 switch time		0	x02 msec	0 10000	Pi Pe S	C7CH	0032H
	Set the switch time from speed loop 2 to speed loop 1, when two control speed loops are used.							



Parameter	Name & Function	Default	Unit	Setting Range	Control Mode	Communication Address	
						RS232	RS485
Cn051	Low voltage protection level Set the delay time of Cn052, which triggers low voltage protection alarm, when voltage of drive input power is lower than Cn051.	190	Volt	170 190	ALL	5F0H	0033H
Cn052	Low voltage protection alarm delay time Set the delay time of Cn052, which triggers low voltage protection alarm, when voltage of drive input power is lower than Cn051.	0	x250 msec	0 100	ALL	C8BH	0034H
Cn053	Current offset automatic adjust (only used in servo off) Setting Explanation 1 Drive executes current offset adjust and then clears setting to 0 automatically when the adjustment is finished.	0	x	0 1	ALL	B91H	0035H
Cn054	Drive warning setting Parameter Cn054 set by hex code, and each bit represents for each alarm. Setting the corresponding bit to 1 for the alarm is an warn mode. Drive warns and then trigger alarm after continuously executing the setting time of Cn055 when alarm occurs. Ex: Set Cn054 to 0801H, and then set Cn055 to 100 when low voltage or overspeed alarm is a warn, which triggers alarm one second later. 0000100000000001 is the setting status, presenting in binary.	0000	x	0000 FFFF	ALL	C8DH	0036H
Cn055	Drive warning delays the time of triggering alarm Parameter Cn054 set by hex code, and each bit represents for each alarm. Setting the corresponding bit to 1 for the alarm is an warn mode. Drive warns and then trigger alarm after continuously executing the setting time of Cn055 when alarm occurs. Ex: Set Cn054 to 0801H, and then set Cn055 to 100 when low voltage or overspeed alarm is a warn, which triggers alarm one second later. 0000100000000001 is the setting status, presenting in binary.	0	x10 msec	0 300	ALL	C8EH	0037H

Parameter	Name & Function	Default	Unit	Setting Range	Control Mode	Communication Address			
						RS232	RS485		
Cn056	The Sencond toreq command restriction for CCW direction	300	% 0~300	Pt	C05H 0038H				
	The same description as Cn010 P.S.)The default would depends on Cn030	260							
		250							
		240							
		220							
		200							
Cn057	The Sencond toreq command restriction for CW direction	-300	% 0~300	Pt	C06H 0039H				
	The same description as Cn011 P.S.)The default would depends on Cn030	-260							
		-250							
		-240							
		-220							
		-200							
Cn058	The delay time for the first session of torque restriction to the second session of torque restriction	0	x4 msec	0 ~ 32767	Pt	C13H 003AH			
	After INP signal output, it would switch the torque restriction from (Cn010、Cn011) to (Cn056, Cn057) according to the delay time(setting by Cn058). After PTRG action, the torque restriction switch from (Cn056, Cn057) to (Cn010、Cn011).								
Cn059	AutoTuning function choice	0	—	0 ~ 2	Pe Pi	C94H 003BH			
	Setting								
	0								
	1				P S				
	2								
Cn060	The turns command of OFFLine-tuning	3	rev	3 ~ 1024	Pe Pi	C96H 003CH			
	EX: When you set10 means the tuning command would finished in 10 turns.								
Cn061	The Maximum speed OFFLine-tuning	Rated speed x2/3	rpm	1/3~2/3 x Rated speed	Pe Pi	C9CH 003DH			
	The Maximum speed OFFLine-tuning								
Cn062	OFFLine-tuning operation overtravel distance protection settings	50	0.01rev	50 ~ 300	Pe Pi	CA4H 003EH			
	When Cn62 is 3 and Cn64 is 50 means the distance protection is 3.5 runs (Cn62+Cn64*0.01). When over 3.5 runs it would stop in emergency.								

Torque-Control Parameter




Parameter	Name & Function	Default	Unit	Setting Range	Control Mode	Communication Address	
						RS232	RS485
★ Tn101	Linear acceleration/deceleration method	0	X	0 2	T	C8CH	0101H
	Setting Explanation						
	0 Disabled.						
	1 Enabled.						
	2 Enable Torque command smooth accel/decel time Constant.						
★ Tn102	Linear accel/decel time period.	1	msec	1 50000	T	523H	0102H
	Time taken for the torque-command to linearly accelerate to the rated torque level or Decelerate to zero torque . 						
Tn103	Analog Torque Command Ratio	300	%	0 600	T	521H	0103H
	Slope of voltage command / Torque command can be adjusted. 						

Parameter	Name & Function	Default	Unit	Setting Range	Control Mode	Communication Address					
						RS232	RS485				
Tn104	Torque Command, analog input voltage offset The offset amount can be adjusted by this parameter. 	0	mV	-10000 10000	T	522H	0104H				
Tn105	Preset Speed Limit 1. (Torque control mode) In Torque control, input contacts SPD1 and SPD2 can be used to select Preset speed limit 1. As follows: <table border="1" style="margin-left: auto; margin-right: auto;"> <tr> <th>Input Contact SPD2</th> <th>Input Contact SPD1</th> </tr> <tr> <td>0</td> <td>1</td> </tr> </table> <p>Note: Input contacts status "1" (ON) and "0" (OFF). Refer to 5-6-1 to set high or low input logic levels.</p>	Input Contact SPD2	Input Contact SPD1	0	1	100	rpm	0 ~ rated speedx1.5	T	526H	0105H
Input Contact SPD2	Input Contact SPD1										
0	1										
Tn106	Preset Speed Limit 2. (Torque control mode) In Torque control, input contacts SPD1 and SPD2 can be used to select Preset speed limit 2. As follows: <table border="1" style="margin-left: auto; margin-right: auto;"> <tr> <th>Input Contact SPD2</th> <th>Input Contact SPD1</th> </tr> <tr> <td>1</td> <td>0</td> </tr> </table> <p>Note: Input contacts status "1" (ON) and "0" (OFF) Refer to 5-6-1 to set high or low input logic levels.</p>	Input Contact SPD2	Input Contact SPD1	1	0	200	rpm	0 ~ rated speedx1.5	T	527H	0106H
Input Contact SPD2	Input Contact SPD1										
1	0										
Tn107	Preset Speed Limit 3. (Torque control mode) In Torque control, input contacts SPD1 and SPD2 can be used to select Preset speed limit 3. As follows:- <table border="1" style="margin-left: auto; margin-right: auto;"> <tr> <th>Input Contact SPD2</th> <th>Input Contact SPD1</th> </tr> <tr> <td>1</td> <td>1</td> </tr> </table> <p>Note: Input contacts status "1" (ON) and "0" (OFF) Refer to 5-6-1 to set high or low input logic levels.</p>	Input Contact SPD2	Input Contact SPD1	1	1	300	rpm	0 ~ rated speedx1.5	T	528H	0107H
Input Contact SPD2	Input Contact SPD1										
1	1										
Tn108	Torque output monitor value When the torque level in CW or CCW direction become greater than this value setting, the output contact INT operate.	0	%	0 300	ALL	C30H	0108H				


Parameter	Name & Function	Default	Unit	Setting Range	Control Mode	Communication Address	
						RS232	RS485
Tn109	Analog Speed Limited Proportion Controller This function used for adjusted analog voltage command compared with the slope of speed limit command. 	3000	rpm	100 4500	T	533H	0109H
Tn110	Torque command smooth accel/decel time Constant Set Tn101=2 to enable this function. Set the time period to rise to 63.2% of the full torque. 	0	msec	0 10000	T	520H	010AH

Speed-Control Parameter



Parameter	Name & Function	Default	Unit	Setting Range	Control Mode	Communication Address											
						RS232	RS485										
Sn201	<p>Internal Speed Command 1</p> <p>In Speed control, input contacts SPD1 and SPD2 can be used to select 3 sets of internal speed command, select for speed command 1 contact status shows below:</p> <table border="1"> <tr> <td>Input Contact SPD2</td> <td>Input Contact SPD1</td> </tr> <tr> <td>0</td> <td>1</td> </tr> </table> <p>Note: Input contacts status "1" (ON) and "0" (OFF) Refer to 5-6-1 to set high or low input logic levels.</p>	Input Contact SPD2	Input Contact SPD1	0	1	100	rpm	-1.5~ 1.5 x rated speed	S	536H	0201H						
Input Contact SPD2	Input Contact SPD1																
0	1																
Sn202	<p>Internal Speed Command 2</p> <p>In Speed control, input contacts SPD1 and SPD2 can be used to select 3 sets of internal speed command, select for speed command 2 contact status shows below:</p> <table border="1"> <tr> <td>Input Contact SPD2</td> <td>Input Contact SPD1</td> </tr> <tr> <td>1</td> <td>0</td> </tr> </table> <p>Note: Input contacts status "1" (ON) and "0" (OFF) Refer to 5-6-1 to set high or low input logic levels.</p>	Input Contact SPD2	Input Contact SPD1	1	0	200	rpm	-1.5~ 1.5 x rated speed	S	537H	0202H						
Input Contact SPD2	Input Contact SPD1																
1	0																
Sn203	<p>Internal Speed Command 3</p> <p>In Speed control, input contacts SPD1 and SPD2 can be used to select 3 sets of internal speed command, select for speed command 3 contact status shows below:</p> <table border="1"> <tr> <td>Input Contact SPD2</td> <td>Input Contact SPD1</td> </tr> <tr> <td>1</td> <td>1</td> </tr> </table> <p>Note: Input contacts status "1" (ON) and "0" (OFF). Refer to 5-6-1 to set high or low input logic levels.</p>	Input Contact SPD2	Input Contact SPD1	1	1	300	rpm	-1.5~ 1.5 x rated speed	S	538H	0203H						
Input Contact SPD2	Input Contact SPD1																
1	1																
Sn204	<p>Zero Speed selection Enable or Disable the zero speed preset parameter Sn215.</p> <table border="1"> <tr> <th>Setting</th> <th>Explanation</th> </tr> <tr> <td>0</td> <td>No Action. (Sn215 zero preset is not effective).</td> </tr> <tr> <td>1</td> <td>Set the preset value in Sn215 as zero speed.</td> </tr> </table>	Setting	Explanation	0	No Action. (Sn215 zero preset is not effective).	1	Set the preset value in Sn215 as zero speed.	0	X	0 1	ALL	529H	0204H				
Setting	Explanation																
0	No Action. (Sn215 zero preset is not effective).																
1	Set the preset value in Sn215 as zero speed.																
Sn205	<p>Speed command accel/decel smooth method.</p> <table border="1"> <tr> <th>Setting</th> <th>Explanation</th> </tr> <tr> <td>0</td> <td>By Step response</td> </tr> <tr> <td>1</td> <td>Smooth Acceleration/deceleration according to the curve defined by Sn206.</td> </tr> <tr> <td>2</td> <td>Linear accel/decel time constant .Defined by Sn207</td> </tr> <tr> <td>3</td> <td>S curve for Acceleration/deceleration. Defined by Sn208.</td> </tr> </table>	Setting	Explanation	0	By Step response	1	Smooth Acceleration/deceleration according to the curve defined by Sn206.	2	Linear accel/decel time constant .Defined by Sn207	3	S curve for Acceleration/deceleration. Defined by Sn208.	0	X	0 3	S	52AH	0205H
Setting	Explanation																
0	By Step response																
1	Smooth Acceleration/deceleration according to the curve defined by Sn206.																
2	Linear accel/decel time constant .Defined by Sn207																
3	S curve for Acceleration/deceleration. Defined by Sn208.																

Parameter	Name & Function	Default	Unit	Setting Range	Control Mode	Communication Address
						RS232 RS485
Sn206	Speed command smooth accel/decel time Constant. Set Sn205=1 to enable this function then set the time period for the speed to rise to 63.2% of the full speed. 	1	msec	1 10000	S	52BH 0206H
Sn207	Speed command linear accel/decel time constant. Set Sn205=2 to enable this function then set the time period for the speed to rise linearly to full speed. 	1	msec	1 50000	S	52CH 0207H
Sn208	S curve speed command acceleration and deceleration time setting. Set Sn205=3 to enable this function. In the period of Acc/Dec , drastic speed changing might cause vibration of machine. S curve speed command acc/decel time setting has the effect to smooth acc/decel curve.  Rule for the setting : $\frac{t_a}{2} > t_s$, $\frac{t_d}{2} > t_s$	1	msec	1 1000	S	C44H 0208H



Parameter	Name & Function	Default	Unit	Setting Range	Control Mode	Communication Address	
						RS232	RS485
Sn209	S curve speed command acceleration time setting.	200	msec	0 5000	S	C45H	0209H
	Refer Sn208						
Sn210	S curve speed command deceleration time setting.	200	msec	0 5000	S	C46H	020AH
	Refer Sn208						
Sn211	Speed loop Gain 1 Speed loop gain has a direct effect on the frequency response bandwidth of the Speed-control loop. Without causing vibration or noise Speed-loop-gain can be increased to obtain a faster speed response. If Cn025 (load Inertia ratio) is set correctly, the speed-loop-bandwidth will equal to speed-loop-gain.	40	Hz	10 1500	Pi Pe S	530H	020BH
Sn212	Speed-loop Integral time 1 Speed loop integral element can eliminate the steady speed error and react to even slight speed variations. Decreasing Integral time can improve system rigidity. The formula below shows the relationship between Integral time and Speed loop Gain. $SpeedLoopIntegrationTimeConst \tan t \geq 5 \times \frac{1}{2\pi \times SpeedLoopGain}$	100	x0.2 ms	1 5000	Pi Pe S	531H	020CH
Sn213	Speed loop Gain 2	40	Hz	10 1500	Pi Pe S	53AH	020DH
	Refer to Sn211						
Sn214	Speed loop Integral time 2	100	x0.2 msec	1 5000	Pi Pe S	53BH	020EH
	Refer to Sn212						
Sn215	Value of zero speed Set the zero speed range in Sn215 When the actual speed is lower than Sn215 value, Output contact ZS is activated.	50	rpm	0 4500	S	532H	020FH
Sn216	Analog Speed Command Ratio Slope of voltage command / Speed command can be adjusted.	Rate rpm	rpm /10V	100 6000	S	533H	0210H
	<p>Speed Command (rpm)</p> <p>Input Voltage (V)</p> <p>Slope set by Sn216</p>						

Parameter	Name & Functions	Default	Unit	Setting Range	Control Mode	Communication Address	
						RS232	RS485
Sn217	Analog Speed Command offset adjust The offset amount can be adjusted by this parameter. 	0	mV	-10000 10000	S	534H	0211H
Sn218	Analog speed command limited Setting Sn218 for limit the highest speed command of analog input.	Rate rpm x 1.02	rpm	100 4500	S	C11H	0212H

Position Control Parameter

Parameter	Name & Function				Default	Unit	Setting Range	Control Mode	Communication Address									
									RS232	RS485								
Pn301.0 	Position pulse command selection				0	X	0 — 3	Pe	550H	0301H								
	Setting	Explanation																
	0	(Pulse)+(Sign)																
	1	(CCW)/(CW) Pulse																
	2	AB-Phase pulse x 2																
Pn301.1 	Position- Pulse Command Logic				0	X	0 — 1	Pe										
	Setting	Explanation																
	0	Positive Logic																
	1	Negative Logic																
Pn301.2 	Selection for command receive of drive inhibit mode				0	X	0 — 1	Pi Pe										
	Setting	Explanation																
	0	When drive inhibit occurs, record value of position command input coherently.																
	1	When drive inhibit occurs, ignore the value of position command.																
Pn301.3 	Pulse command filter band width selection				1	X	0 — 7	Pe										
	Setting	Explanation	Setting	Explanation														
	0	4500KHz	4	370KHz														
	1	2500KHz	5	180KHz														
Pn302	Electronic Gear Ratio Numerator 1				1	X	1 — 50000	Pi Pe	560H	0302H								
	Use input contacts GN1 & GN2 to select one of four electronic Gear Ratio Numerators. To select Numerator 1, the statue of the input-contacts GN1 & GN2 should be as follows:																	
	<table border="1"> <tr> <td>Input Contact GN2</td> <td>Input Contact GN1</td> </tr> <tr> <td>0</td> <td>0</td> </tr> </table>										Input Contact GN2	Input Contact GN1	0	0				
Input Contact GN2	Input Contact GN1																	
0	0																	
Note: Input contacts status "1" (ON) and "0" (OFF). Refer to 5-6-1 to set high or low input logic levels.																		
Pn303	Electronic Gear Ratio Numerator 2				1	X	1 — 50000	Pi Pe	561H	0303H								
	Use input contacts GN1 & GN2 to select one of four electronic Gear Ratio Numerators. To select Numerator 2, the statue of the input-contacts GN1 & GN2 should be as follows:																	
	<table border="1"> <tr> <td>Input Contact GN2</td> <td>Input Contact GN1</td> </tr> <tr> <td>0</td> <td>1</td> </tr> </table>										Input Contact GN2	Input Contact GN1	0	1				
Input Contact GN2	Input Contact GN1																	
0	1																	
Note: Input contacts status "1" (ON) and "0" (OFF). Refer to 5-6-1 to set high or low input logic levels.																		

Parameter	Name & Function	Default	Unit	Setting Range	Control Mode	Communication Address					
						RS232	RS485				
Pn304	<p>Electronic Gear Ratio Numerator 3</p> <p>Use input contacts GN1 & GN2 to select one of four electronic Gear Ratio Numerators.</p> <p>To select Numerator 3, the status of the input-contacts</p> <p>GN1 & GN2 should be as follows:</p> <table border="1"> <tr> <td>Input Contact GN2</td> <td>Input Contact GN1</td> </tr> <tr> <td>1</td> <td>0</td> </tr> </table> <p>Note: Input contacts status "1" (ON) and "0" (OFF).</p> <p>Refer to 5-6-1 to set high or low input logic levels.</p>	Input Contact GN2	Input Contact GN1	1	0	1	X	<div style="text-align: center;"> <input type="checkbox"/> 1 <input type="checkbox"/> 50000 </div>	Pi Pe	562H	0304H
Input Contact GN2	Input Contact GN1										
1	0										
Pn305	<p>Electronic Gear Ratio Numerator 4</p> <p>Use input contacts GN1 & GN2 to select one of four electronic Gear Ratio Numerators.</p> <p>To select Numerator 4, the status of the input-contacts</p> <p>GN1 & GN2 should be as follows:</p> <table border="1"> <tr> <td>Input Contact GN2</td> <td>Input Contact GN1</td> </tr> <tr> <td>1</td> <td>1</td> </tr> </table> <p>Note: Input contacts status "1" (ON) and "0" (OFF).</p> <p>Refer to 5-6-1 to set high or low input logic levels.</p>	Input Contact GN2	Input Contact GN1	1	1	1	X	<div style="text-align: center;"> <input type="checkbox"/> 1 <input type="checkbox"/> 50000 </div>	Pi Pe	563H	0305H
Input Contact GN2	Input Contact GN1										
1	1										
★ Pn306	<p>Electronic Gear Ratio Denominator</p> <p>Set the calculated Electronic Gear Ratio Denominator in Pn 306. (Refer to section 5-4-3).</p> <p>Final Electronic Gear Ratio should comply with the formula below.</p> $\frac{1}{200} \leq \text{ElectronicGearRatio} \leq 200$	1	X	<div style="text-align: center;"> <input type="checkbox"/> 1 <input type="checkbox"/> 50000 </div>	Pi Pe	554H	0306H				
Pn307	<p>Position complete value</p> <p>Set a value for In position output signal.</p> <p>When the Position pulse error value is less then Pn307 output-contact INP (In position output signal) will be activated.</p> <p>P.S. Use 2500/8192/15bits encoder the default is 10. Use 17bits encoder the default is 40</p>	10 / 40	pulse	<div style="text-align: center;"> <input type="checkbox"/> 0 <input type="checkbox"/> 50000 </div>	Pi Pe	552H 553H	0307H				
Pn308	<p>"Incorrect position" Error band Upper limit.</p> <p>When the Position error value is higher then number of pulses set in Pn308, an Alarm message AL-11(Position error value alarm) will be displayed.</p> <p>P.S. Use 2500/8192/15bits encoder the unit is 10 pulse. Use 17bits encoder the unit is 131pulse</p>	50000	x10 pulse x131pulse	<div style="text-align: center;"> <input type="checkbox"/> 0 <input type="checkbox"/> 50000 </div>	Pi Pe	556H 557H	0308H				
Pn309	<p>"Incorrect position" Error band lower limit.</p> <p>When the Position error value is lower then number of pulses set in Pn309, an Alarm message AL-11(Position error value alarm) will be displayed.</p> <p>P.S. Use 2500/8192/15bits encoder the unit is 10 pulse. Use 17bits encoder the unit is 131pulse</p>	50000	x10 pulse x131pulse	<div style="text-align: center;"> <input type="checkbox"/> 0 <input type="checkbox"/> 50000 </div>	Pi Pe	558H 559H	0309H				

Parameter	Name & Function	Default	Unit	Setting Range	Control Mode	Communication Address							
						RS232	RS485						
Pn310	Position Loop Gain 1 Without causing vibration or noise on the mechanical system the position loop gain value can be increased to speed up response and shorten the positioning time. Generally, the position loop bandwidth should not be higher than speed loop bandwidth. The relationship is according to the formula below: $\text{PositionLoopGain} \leq 2\pi \times \frac{\text{SpeedLoopGain}}{5}$	40	rad/s	1 1000	Pi Pe	55AH	030AH						
Pn311	Position Loop Gain 2 Refer to Pn310	40	rad/s	1 1000	Pi Pe	551H	030BH						
Pn312	Position Loop Feed Forward Gain It can be used to reduce the track error of position control and speed up the response. If the feed forward gain is too large, it might cause speed overshoot and in position oscillations which result in the repeated ON/OFF operation of the output contact INP("In Position" output signal).	0	%	0 100	Pi Pe	55BH	030CH						
★ Pn313	Position command smooth Acceleration/Deceleration Time Constant Set the time period for the Position command pulse frequency to rise from 0 to 63.2%. Position Pulse Command Frequency (%) 	0	msec	0 10000	Pi Pe	55CH	030DH						
★ Pn314	Positioning Command Direction Definition  <table border="1"> <thead> <tr> <th>Setting</th> <th>Explanation</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>(CW) .Clockwise</td> </tr> <tr> <td>1</td> <td>(CCW). Counter Clockwise</td> </tr> </tbody> </table>	Setting	Explanation	0	(CW) .Clockwise	1	(CCW). Counter Clockwise	1	X	0 1	Pi Pe	55DH	030EH
Setting	Explanation												
0	(CW) .Clockwise												
1	(CCW). Counter Clockwise												


Parameter	Name & Function		Default	Unit	Setting Range	Control Mode	Communication Address	
							RS232	RS485
Pn315	Pulse Error Clear Modes.		0	X	0 — 2	Pe	51FH	030FH
	Setting	Explanation						
	0	Once CLR signal is activated, it eliminates, the Pulse error amount.				Pi Pe		
	1	Once CLR signal is activated, following takes place: <ul style="list-style-type: none">• The position command is cancelled.• Motor rotation is interrupted• Pulse error amount is cleared.• Machine home reference is reset				Pi		
	2	Once CLR signal is activated, following takes place:- <ul style="list-style-type: none">• The position command is cancelled..• Motor rotation is interrupted• Pulse error amount is cleared.						

Parameter	Name & Function	Default	Unit	Setting Range	Control Mode	Communication Address	
						RS232	RS485
Pn316 	Internal Position Command Mode	0	X	0 1	Pi	50DH	0310H
	Setting Explanation						
	0 Absolute Position						
	1 Incremental Position						
Pn316.1 	Internal Position Command Hold (PHOLD) program select	0	X	0 1	Pi	50DH	0310H
	Setting Explanation						
	0 When PHOLD is active then received PTRG signal. servomotor will be proceed internal position command from PHOLD position.						
	1 When PHOLD is active then received PTRG signal. Servomotor will operate internal position command of current selection.						
Pn316.2 	Encoder Feedback Dividing Phase Leading Selection	0	X	0 1	Pi	50DH	0310H
	Setting Explanation						
	0 Encoder feedback phase A leading phase B						
	1 Encoder feedback phase B leading phase A.						
Pn316.3 	Encoder Feedback Dividing	0	X	0 1	ALL	50DH	0310H
	Setting Explanation						
	0 According to Cn005						
	1 According to Cn005/4						
Pn317.0 	Setting for HOME routine	0	X	0 5	Pi Pe	54AH	0311H
	Setting Explanation						
	0 Once the home routine is activated, motor will search for Home Position switch in 1 st speed in CCW direction . Input contacts CCWL or CWL can be used as the Home Reference Switch . Once Home reference switch is detected, then input contacts CCWL and CWL will act as normal max. limits again . Note: When using this function, Pn365.1 can not be set to 1 or 2 . Cn002.1 (selection for CCWL and CWL) must be set to set to 0 .						
	1 Once the home routine is activated, motor will search for Home Position switch in 1 st speed in CW direction . Input contacts CCWL or CWL can be used as the Home Reference Switch . Once Home position is detected, then input contacts CCWL and CWL will act as normal max. limits again . Note: When using this function, Pn365.1 can not be set to 1 or 2 . Cn002.1 (selection for CCWL and CWL) must be set to 0 .						

Parameter	Name & Function		Default	Unit	Setting Range	Control Mode	Communication Address	
	Setting	Explanation					RS232	RS485
Pn317.0 	Setting for HOME routine		0	X	0 5	Pi Pe	54AH	0311H
	Setting	Explanation						
	2	Once the home routine is activated , motor will search for Home position switch in 1 st speed in CCW direction and sets the Home reference position as soon as the input contact ORG is activated . If Pn365.1=2, it will directly find the closest Rising-Edge of ORG to be the Home position (without a need for Home Reference), then it stops in accordance with Pn365.3 setting						
	3	Once the home routine is activated , motor will search for Home Position switch in 1 st speed in CW direction and sets the reference Home position as soon as the input contact ORG is activated . If Pn365.1=2, it will directly find the closest rising -Edge of ORG to be the Home position (without a need for Home reference), then it stops in accordance with Pn365.3 setting.						
	4	Once the home routine is activated , motor will search for Home position in 1 st speed in CCW direction and sets the Home reference position as soon as the nearest Z (marker pulse) is detected. When using this function, set Pn365.1=2. After setting the Z Phase to be the Home, it stops in accordance with the setting of Pn365.3.						
Pn317.1 	Once Reference Home switch or Signal, is found it sets the search method for the Home position.		0	X	0 2	Pi Pe	54AH	0311H
	Setting	Explanation						
	0	Once the Home Reference switch or signal is detected, motor reverses direction in 2 nd speed to find the nearest Z. Phase pulse and sets this as the Home position, then stops in accordance with Pn317.3 setting method.						
	1	Once the Home Reference switch or signal is detected, motor Continues in its direction in 2 nd speed to find the nearest Z Phase pulse and sets this as the Home position, then stops in accordance with Pn317.3 setting method.						
	2	When Pn317.0=2 or 3, it finds the rising edge of ORG to be the Home position, then stops in accordance with Pn317.3. When Pn317.0=4 or 5, it finds Z Phase pulse to be the Home, then stops in accordance with Pn317.3.						

Parameter	Name & Function	Default	Unit	Setting Range	Control Mode	Communication Address	
						RS232	RS485
Pn317.2 	Setting of Home Routine Start method	0	X	0 — 2		54AH	0311H
	Setting Explanation						
	0 Homing routine is Disabled .						
Pn317.3 	On power up and activation of Servo on the home routine is started automatically. This method is useful for applications that do not require repeated home routines. No external home reference switch is required.	1				54AH	0311H
	Use SHOME input contactor to start a home routine. In position mode, SHOME can be used to start a home routine at any moment.						
Pn318	Setting of stopping mode after finding Home signal.	0	X	0 — 1		54AH	0311H
	Setting Explanation						
	After detecting the Home signal, it sets this position to be the Home reference (Un-14 encoder feed back rotating number and Un-15 encoder feed back pulse number are all 0), motor decelerates and stops. Then it reverses direction in 2 nd speed to detect the Home Position again then it decelerates and stops..						
Pn319	Machine Home reference search speed. 1st speed (Fast)	100	rpm	0 — 2000		54BH	0312H
	HOME Reference search speed. Speed 1.						
Pn320	Machine Home position search speed. 2nd Speed (Slow)	50	rpm	0 — 500		54CH	0313H
	Home position search speed. Speed 2.						
Pn321	Home position offset. Number of revolutions.	0	rev	-30000 — 30000		54DH	0314H
	Once the searched home position is found in accordance with Pn317 (Home routine mode), then it will search by a number of revolutions and pulses set in parameters Pn320 and Pn 321 to find the new (off set) Home position.						
	Home position offset. Number of Pulses.	0	pulse	-32767 — 32767		54EH	0315H
	Home Offset position = Pn320(Rotate Number) x Number of Encoder Pulse per Rotation x 4 + Pn321(Pulse Number)						

Parameter	Name & Function	Default	Unit	Setting Range	Control Mode	Communication Address	
						RS232	RS485
Pn322	<p>S-Curve Time Constant for Internal Position command(TSL)</p> <p>S-curve time constant generator can smoothen the command, it provides continuous speed and acceleration which not only better the motor characteristic of acc/dec but also helps the motor to operate more smoothly in machinery structure. S-curve time constant generator is only applicable to the mode of internal position command input. When position command input switch to external position pulse, the speed and acceleration are already constant, so it doesn't use the S-curve time constant generator.</p> <p>Notes :</p> <p>1. Rule of setting: Pn323(TACC)≥Pn322(TSL) and Pn333(TDEC)≥Pn322(TSL). If Pn323、Pn333 less than Pn322, ignore all the trigger signal, no action and send the alarm 11.</p> <p>2. When Pn322 sets as 0, the S-curve time constant will be disabled.</p>	0	x0.4ms	0 5000	Pi	52DH	0316H
Pn323	S-Curve Time Constant for Internal Position command(TACC)	1	x0.4ms	1 5000	Pi	52EH	0317H
Pn324	<p>Total Number Setting</p> <p>Sets total number of tool turret.</p>	12	--	1 64	Pt	C56H	0318H
Pn325	<p>The Location of Zero CNC Tool Turret</p> <p>Sets the location of zero tool.</p>	0	pulse	0 131071	Pt	C7EH C7FH	0319H 031AH
Pn326	<p>Reduction Gear Rate for CNC Tools Turret</p> <p>Sets reduction rate for turret.</p>	1	rev	0 16383	Pt	C57H	031AH
Pn327	<p>Rotation Speed of tool turret switching</p> <p>Sets the rotation speed of tool terret swithing.</p>	100	rpm	0 5000	Pt	C59H	031BH
Pn328	Reserved	--	--	--	--	--	--
★ Pn329	<p>Pulse command smoothing filter</p> <p>The smoothing filter is settable.</p>	0	x 2mesc	0 2500	Pe	C78H	031EH
★ Pn330	<p>Pulse command moving filter</p> <p>The moving filter is settable.</p>	0	x 0.4mesc	0 250	Pe	C79H	031FH
Pn331	<p>Turret backlash compensation parameter</p> <p>Set backlash compensation value</p>	0	pulse	-32768 32767	Pt	C86H	0320H
★ Pn332	Accel/dece methods for Internal Position command	0	x	0 2	Pi	C69H	0321H
	Setting						
	0						
	1						
	2						

Parameter	Name & Function	Default	Unit	Setting Range	Control Mode	Communication Address	
						RS232	RS485
Pn333	<p>S-Curve Time Constant Deceleration for Internal Position Command(TDEC)</p> <p>We define the input time parameter are TSL and TDEC. It judges the dec trip by the setted time parameter. Figure (a) shows that when TDEC > TSL, it will generate a constant deceleration region, and the time of deceleration is TDEC – TSL. Refered to figure (b), there is no constant deceleration region when TDEC = TSL, and it can not be define on TDEC<TSL.</p>  <p>(a)</p> <p>(b)</p>	1	x0.4ms	1 ~ 5000	Pi	C15H	0322H
Pn334	<p>The Delay time Constant of PTRG Trigger</p> <p>When PTRG triggered, motor would start to run after the delay time.</p>	0	4ms	0~ 2500	Pi Pe	CAEH	0323H
Pn335	<p>Second Session of Rotation Speed of tool turret switching</p> <p>Second Session of Rotation Speed of tool turret switching</p>	100	rpm	0 ~ 5000	Pi Pe	C93H	0323H

Internal Position Control Parameter

Parameter	Name & Function	Default	Unit	Setting Range	Control Mode	Communication Address	
						RS232	RS485
Pn401	Internal Position Command 1 – Rotation Number	0	rev	-16000 16000	Pi	568H	0701H
	Set the Rotation number of the internal Position Command 1 Use input contacts POS1~POS5 to select Refer to 5-4-2.						
Pn402	Internal Position Command 1 - Pulse Number	0	pulse	-131072 131072	Pi	56AH 56BH	0702H 0703H
	Set the rotation pulse number of internal position Command 1 Internal Position Command 1 =Pn401(Rotation Number) x Pulse number of One Rotate x 4 + Pn402(Pulse number)						
Pn403	Internal Position Command 1 - Move Speed	0	rpm	0 6000	Pi	569H	0704H
	Setting the Move Speed of internal Position Command 1						
Pn404	Internal Position Command 2-Rotation Number	0	rev	-16000 16000	Pi	56CH	0705H
	Please refer to Pn401						
Pn405	Internal Position Command 2-Pulse Number	0	pulse	-131072 131072	Pi	56EH 56FH	0706H 0707H
	Please refer to Pn402						
Pn406	Internal Position Command 2-Move Speed	0	rpm	0 6000	Pi	56DH	0708H
	Please refer to Pn403						
Pn407	Internal Position Command 3-Rotation Number	0	rev	-16000 16000	Pi	570H	0709H
	Please refer to Pn401						
Pn408	Internal Position Command 3-Pulse Number	0	pulse	-131072 131072	Pi	572H 573H	070AH 070BH
	Please refer to Pn402						
Pn409	Internal Position Command 3-Move Speed	0	rpm	0 6000	Pi	571H	070CH
	Please refer to Pn403						
Pn410	Internal Position Command 4 -Rotation Number	0	rev	-16000 16000	Pi	574H	070DH
	Please refer to Pn401						
Pn411	Internal Position Command 4-Pulse Number	0	pulse	-131072 131072	Pi	576H 577H	070EH 070FH
	Please refer to Pn402						
Pn412	Internal Position Command 4-Move Speed	0	rpm	0 6000	Pi	575H	0710H
	Please refer to Pn403						
Pn413	Internal Position Command 5 -Rotation Number	0	rev	-16000 16000	Pi	578H	0711H
	Please refer to Pn401						
Pn414	Internal Position Command 5-Pulse Number	0	pulse	-131072 131072	Pi	57AH 57BH	0712H 0713H
	Please refer to Pn402						
Pn415	Internal Position Command 5-Move Speed	0	rpm	0 6000	Pi	579H	0714H
	Please refer to Pn403						

Parameter	Name & Function	Default	Unit	Setting Range	Control Mode	Communication Address	
						RS232	RS485
Pn416	Internal Position Command 6 -Rotation Number Please refer to Pn401	0	rev	-16000 16000	Pi	57CH	0715H
Pn417	Internal Position Command 6-Pulse Number Please refer to Pn402	0	pulse	-131072 131072	Pi	57EH 57FH	0716H 0717H
Pn418	Internal Position Command 6-Move Speed Please refer to Pn403	0	rpm	0 6000	Pi	57DH	0718H
Pn419	Internal Position Command 7 -Rotation Number Please refer to Pn401	0	rev	-16000 16000	Pi	580H	0719H
Pn420	Internal Position Command 7-Pulse Number Please refer to Pn402	0	pulse	-131072 131072	Pi	582H 583H	071AH 071BH
Pn421	Internal Position Command 7-Move Speed Please refer to Pn403	0	rpm	0 6000	Pi	581H	071CH
Pn422	Internal Position Command 8 -Rotation Number Please refer to Pn401	0	rev	-16000 16000	Pi	584H	071DH
Pn423	Internal Position Command 8-Pulse Number Please refer to Pn402	0	pulse	-131072 131072	Pi	586H 587H	071EH 071FH
Pn424	Internal Position Command 8-Move Speed Please refer to Pn403	0	rpm	0 6000	Pi	585H	0720H
Pn425	Internal Position Command 9 -Rotation Number Please refer to Pn401	0	rev	-16000 16000	Pi	588H	0721H
Pn426	Internal Position Command 9-Pulse Number Please refer to Pn402	0	pulse	-131072 131072	Pi	58AH 58BH	0722H 0723H
Pn427	Internal Position Command 9-Move Speed Please refer to Pn403	0	rpm	0 6000	Pi	589H	0724H
Pn428	Internal Position Command 10 -Rotation Number Please refer to Pn401	0	rev	-16000 16000	Pi	58CH	0725H
Pn429	Internal Position Command 10-Pulse Number Please refer to Pn402	0	pulse	-131072 131072	Pi	58EH 58FH	0726H 0727H
Pn430	Internal Position Command 10-Move Speed Please refer to Pn403	0	rpm	0 6000	Pi	58DH	0728H
Pn431	Internal Position Command 11 -Rotation Number Please refer to Pn401	0	rev	-16000 16000	Pi	590H	0729H
Pn432	Internal Position Command 11-Pulse Number Please refer to Pn402	0	pulse	-131072 131072	Pi	592H 593H	072AH 072BH
Pn433	Internal Position Command 11-Move Speed Please refer to Pn403	0	rpm	0 6000	Pi	591H	072CH

Parameter	Name & Function	Default	Unit	Setting Range	Control Mode	Communication Address	
						RS232	RS485
Pn434	Internal Position Command 12-Rotation Number	0	rev	-16000 16000	Pi	594H	072DH
	Please refer to Pn401						
Pn435	Internal Position Command 12-Pulse Number	0	pulse	-131072 131072	Pi	596H 597H	072EH 072FH
	Please refer to Pn402						
Pn436	Internal Position Command 12-Move Speed	0	rpm	0 6000	Pi	595H	0730H
	Please refer to Pn403						
Pn437	Internal Position Command 13 -Rotation Number	0	rev	-16000 16000	Pi	598H	0731H
	Please refer to Pn401						
Pn438	Internal Position Command 13-Pulse Number	0	pulse	-131072 131072	Pi	59AH 59BH	0732H 0733H
	Please refer to Pn402						
Pn439	Internal Position Command 13-Move Speed	0	rpm	0 6000	Pi	599H	0734H
	Please refer to Pn403						
Pn440	Internal Position Command 14 -Rotation Number	0	rev	-16000 16000	Pi	59CH	0735H
	Please refer to Pn401						
Pn441	Internal Position Command 14-Pulse Number	0	pulse	-131072 131072	Pi	59EH 59FH	0736H 0737H
	Please refer to Pn402						
Pn442	Internal Position Command 14-Move Speed	0	rpm	0 6000	Pi	59DH	0738H
	Please refer to Pn403						
Pn443	Internal Position Command 15 -Rotation Number	0	rev	-16000 16000	Pi	5A0H	0739H
	Please refer to Pn401						
Pn444	Internal Position Command 15-Pulse Number	0	pulse	-131072 131072	Pi	5A2H 5A3H	073AH 073BH
	Please refer to Pn402						
Pn445	Internal Position Command 15-Move Speed	0	rpm	0 6000	Pi	5A1H	073CH
	Please refer to Pn403						
Pn446	Internal Position Command 16 -Rotation Number	0	rev	-16000 16000	Pi	5A4H	073DH
	Please refer to Pn401						
Pn447	Internal Position Command 16-Pulse Number	0	pulse	-131072 131072	Pi	5A6H 5A7H	073EH 073FH
	Please refer to Pn402						
Pn448	Internal Position Command 16-Move Speed	0	rpm	0 6000	Pi	5A5H	0740H
	Please refer to Pn403						
Pn449	Internal Position Command 17 -Rotation Number	0	rev	-16000 16000	Pi	5A8H	0741H
	Please refer to Pn401						
Pn450	Internal Position Command 17 - Pulse Number	0	pulse	-131072 131072	Pi	5AAH 5ABH	0742H 0743H
	Please refer to Pn402						
Pn451	Internal Position Command 17 - Move Speed	0	pulse	0 6000	Pi	5A9H	0744H
	Please refer to Pn403						
Pn452	Internal Position Command 18 -Rotation Number	0	rev	-16000 16000	Pi	5ACH	0745H
	Please refer to Pn401						

Parameter	Name & Function	Default	Unit	Setting Range	Control Mode	Communication Address	
						RS232	RS485
Pn453	Internal Position Command 18 - Pulse Number	0	pulse	-131072 131072	Pi	5AEH 5AFH	0746H 0747H
	Please refer to Pn402						
Pn454	Internal Position Command 18 - Move Speed	0	rpm	0 6000	Pi	5ADH	0748H
	Please refer to Pn403						
Pn455	Internal Position Command 19 -Rotation Number	0	rev	-16000 16000	Pi	5B0H	0749H
	Please refer to Pn401						
Pn456	Internal Position Command 19 - Pulse Number	0	pulse	-131072 131072	Pi	5B2H 5B3H	074AH 074BH
	Please refer to Pn402						
Pn457	Internal Position Command 19 - Move Speed	0	rpm	0 6000	Pi	5B1H	074CH
	Please refer to Pn403						
Pn458	Internal Position Command 20 -Rotation Number	0	rev	-16000 16000	Pi	5B4H	074DH
	Please refer to Pn401						
Pn459	Internal Position Command 20 - Pulse Number	0	pulse	-131072 131072	Pi	5B6H 5B7H	074EH 074FH
	Please refer to Pn402						
Pn460	Internal Position Command 20 - Move Speed	0	rpm	0 6000	Pi	5B5H	0750H
	Please refer to Pn403						
Pn461	Internal Position Command 21 -Rotation Number	0	rev	-16000 16000	Pi	5B8H	0751H
	Please refer to Pn401						
Pn462	Internal Position Command 21 - Pulse Number	0	pulse	-131072 131072	Pi	5BAH 5BBH	0752H 0753H
	Please refer to Pn402						
Pn463	Internal Position Command 21 - Move Speed	0	rpm	0 6000	Pi	5B9H	0754H
	Please refer to Pn403						
Pn464	Internal Position Command 22 -Rotation Number	0	rev	-16000 16000	Pi	5BCH	0755H
	Please refer to Pn401						
Pn465	Internal Position Command 22 - Pulse Number	0	pulse	-131072 131072	Pi	5BEH 5BFH	0756H 0757H
	Please refer to Pn402						
Pn466	Internal Position Command 22 - Move Speed	0	rpm	0 6000	Pi	5BDH	0758H
	Please refer to Pn403						
Pn467	Internal Position Command 23 -Rotation Number	0	rev	-16000 16000	Pi	5C0H	0759H
	Please refer to Pn401						
Pn468	Internal Position Command 23 - Pulse Number	0	pulse	-131072 131072	Pi	5C2H 5C3H	075AH 075BH
	Please refer to Pn402						
Pn469	Internal Position Command 23 - Move Speed	0	rpm	0 6000	Pi	5C1H	075CH
	Please refer to Pn403						
Pn470	Internal Position Command 24 -Rotation Number	0	rev	-16000 16000	Pi	5C4H	075DH
	Please refer to Pn401						
Pn471	Internal Position Command 24 - Pulse Number	0	pulse	-131072 131072	Pi	5C6H 5C7H	075EH 075FH
	Please refer to Pn402						

Parameter	Name & Function	Default	Unit	Setting Range	Control Mode	Communication Address	
						RS232	RS485
Pn472	Internal Position Command 24 - Move Speed	0	rpm	0 6000	Pi	5C5H	0760H
	Please refer to Pn403						
Pn473	Internal Position Command 25 -Rotation Number	0	rev	-16000 16000	Pi	5C8H	0761H
	Please refer to Pn401						
Pn474	Internal Position Command 25 - Pulse Number	0	pulse	-131072 131072	Pi	5CAH 5CBH	0762H 0763H
	Please refer to Pn402						
Pn475	Internal Position Command 25 - Move Speed	0	rpm	0 6000	Pi	5C9H	0764H
	Please refer to Pn403						
Pn476	Internal Position Command 26 -Rotation Number	0	rev	-16000 16000	Pi	5CCH	0765H
	Please refer to Pn401						
Pn477	Internal Position Command 26 - Pulse Number	0	pulse	-131072 131072	Pi	5CEH 5CFH	0766H 0767H
	Please refer to Pn402						
Pn478	Internal Position Command 26 - Move Speed	0	rpm	0 6000	Pi	5CDH	0768H
	Please refer to Pn403						
Pn479	Internal Position Command 27 -Rotation Number	0	rev	-16000 16000	Pi	5D0H	0769H
	Please refer to Pn401						
Pn480	Internal Position Command 27 - Pulse Number	0	pulse	-131072 131072	Pi	5D2H 5D3H	076AH 076BH
	Please refer to Pn402						
Pn481	Internal Position Command 27 - Move Speed	0	rpm	0 6000	Pi	5D1H	076CH
	Please refer to Pn403						
Pn482	Internal Position Command 28 -Rotation Number	0	rev	-16000 16000	Pi	5D4H	076DH
	Please refer to Pn401						
Pn483	Internal Position Command 28 - Pulse Number	0	pulse	-131072 131072	Pi	5D6H 5D7H	076EH 076FH
	Please refer to Pn402						
Pn484	Internal Position Command 28 - Move Speed	0	rpm	0 6000	Pi	5D5H	0770H
	Please refer to Pn403						
Pn485	Internal Position Command 29 -Rotation Number	0	rev	-16000 16000	Pi	5D8H	0771H
	Please refer to Pn401						
Pn486	Internal Position Command 29 - Pulse Number	0	pulse	-131072 131072	Pi	5DAH 5DBH	0772H 0773H
	Please refer to Pn402						
Pn487	Internal Position Command 29 - Move Speed	0	rpm	0 6000	Pi	5D9H	0774H
	Please refer to Pn403						
Pn488	Internal Position Command 30 -Rotation Number	0	rev	-16000 16000	Pi	5DCH	0775H
	Please refer to Pn401						
Pn489	Internal Position Command 30 - Pulse Number	0	pulse	-131072 131072	Pi	5DEH 5DFH	0776H 0777H
	Please refer to Pn402						
Pn490	Internal Position Command 30 - Move Speed	0	rpm	0 6000	Pi	5DDH	0778H
	Please refer to Pn403						

Parameter	Name & Function	Default	Unit	Setting Range	Control Mode	Communication Address	
						RS232	RS485
Pn491	Internal Position Command 31 -Rotation Number	0	rev	-16000 16000	Pi	5E0H	0779H
	Please refer to Pn401						
Pn492	Internal Position Command 31 - Pulse Number	0	pulse	-131072 131072	Pi	5E2H 5E3H	077AH 077BH
	Please refer to Pn402						
Pn493	Internal Position Command 31 - Move Speed	0	rpm	0 6000	Pi	5E1H	077CH
	Please refer to Pn403						
Pn494	Internal Position Command 32 -Rotation Number	0	rev	-16000 16000	Pi	5E4H	077DH
	Please refer to Pn401						
Pn495	Internal Position Command 32 - Pulse Number	0	pulse	-131072 131072	Pi	5E6H 5E7H	077EH 077FH
	Please refer to Pn402						
Pn496	Internal Position Command 32 - Move Speed	0	rpm	0 6000	Pi	5E5H	0780H
	Please refer to Pn403						

Quick Set-up Parameters

Parameter	Name & Function	Default	Unit	Setting Range	Control Mode	Communication Address	
						RS232	RS485
◆ qn501	Speed Loop Gain 1. (Same function as Sn211) Speed loop gain has a direct effect on the frequency response bandwidth of the Speed-control loop. Without causing vibration or noise Speed-loop-gain can be increased to obtain a faster speed response. If Cn025 (load Inertia ratio) is correctly set, the speed-loop-bandwidth will equal to speed-loop-gain.	40	Hz	10 1500	Pi Pe S	530H	0401H
◆ qn502	Speed-loop Integral time 1. (Same function as Sn212) Speed loop integral element can eliminate the steady speed error and react to even slight speed variations. Decreasing Integral time can improve system rigidity. The formula below shows the relationship between Integral time and Speed loop Gain. $SpeedLoopIntegrationTimeConst \geq 5 \times \frac{1}{2\pi \times SpeedLoopGain}$ $SpeedLoopIntegrationTimeConst \geq 5 \times \frac{1}{2\pi \times SpeedLoopGain}$	100	x0.2 ms	1 5000	Pi Pe S	531H	0402H
◆ qn503	Speed Loop Gain 2. (Same function as Sn213) Refer to qn401	40	Hz	10 1500	Pi Pe S	53AH	0403H
◆ qn504	Speed Loop Integration Time Constant 2. (Same function as Sn214) Refer to qn402	100	x0.2 ms	1 5000	Pi Pe S	53BH	0404H
◆ qn505	Position Loop Gain 1. (Same function as Pn310) Without causing vibration or noise on the mechanical system the position loop gain value can be increased to speed up response and shorten the positioning time. Generally, the position loop bandwidth should not be higher than speed loop bandwidth. The relationship is according to the formula below: $PositionLoopGain \leq 2\pi \times \frac{SpeedLoopGain}{5}$	40	rad/s	1 1000	Pi Pe	55AH	0405H
◆ qn506	Position Loop Gain 2 (Same function as Pn311) Please refer to qn405	40	rad/s	1 1000	Pi Pe	551H	0406H
◆ qn507	Position Loop Feed Forward Gain It can be used to reduce the follow up error of position control and speed up the response. If the feed forward gain is too large, it might cause speed overshoot and in position oscillations which result in the repeated ON/OFF operation of the output contact INP("In Position" output signal).	0	%	0 100	Pi Pe	55BH	0407H

Multi-Function Input Parameters

All digital inputs D1 to D12 are programmable and can be set to one of the functions listed below.

Hn 601 which includes Hn 601.0 ,Hn601.1, Hn601.2 is used for digital input 1 (D1-1).




Hn602 to Hn612 are used for setting digital inputs 2 to 12.(D1-2 to D1-12).

Parameter	Name & Function		Default	Unit	Setting Range	Control Mode	Communication Address					
							RS232	RS485				
★ Hn601.0 Hn601.1 	DI-1 Function		Changed by mode	X	01 — 20 — (HEX.)	ALL	C23H	0501H				
	Setting	Explanation										
	Signal	Functions										
	00 NON	Unused										
	01 SON	Servo On										
	02 ALRS	Alarm Reset										
	03 PCNT	PI/P Switching										
	04 CCWL	CCW Limit										
	05 CWL	CW Limit										
	06 TLMT	External Torque Limit										
	07 CLR	Clear Pulse Error Value										
	08 LOK	Servo Lock										
	09 EMC	Emergency Stop										
	0A SPD1	Speed 1										
	0B SPD2	Speed 2										
	0C MDC	Control Mode Switch										
	0D INH	Position Command Inhibit										
	0E SPDINV	Speed Inverse										
	0F G-SEL	Gain Select										
	10 GN1	Electronic Gear Ratio Numerator 1										
	11 GN2	Electronic Gear Ratio Numerator 2										
	12 PTRG	Position Trigger										
	13 PHOLD	Position Hold										
	14 SHOME	Start Home										
	15 ORG	Home Position Reference (Origin)										
	16 POS1	Internal Position select 1										
	17 POS2	Internal Position select 2										
	18 POS3	Internal Position select 3										
	19 POS4	Internal Position select 4										
	1A TRQINV	Torque Inverse										
	1B RS1	Torque CW Selecting										
	1C RS2	Torque CCW Selecting										
	1D MDC2	Control mode selection for tool turret										
	1E POS5	Internal position command selection 5 (Tool NO. selection 5)										
	1F POS6	Tool NO. selection 6										
	20 VDI	Virtual digital input										
★ New setting will become effective after re-cycling the power.						Function						
		DI_Jog_1		DI_Jog_2		Function						
		0		0		No JOG						
		1		0		JOG Excitation Forward						
		0		1		JOG Excitation Reverse						
		1		1		JOG Excitation zero-run						

Parameter	Name & Function		Default	Unit	Setting Range	Control Mode	Communication Address	
							RS232	RS485
Hn601.2 	DI-1 Active Level	Setting Explanation 0 Low Active (short with IG24) 1 High Active	0	X	0 1	ALL	C23H	0501H
	DI-2							
	Please refer to Hn601							
	DI-3							
Hn603	Please refer to Hn601	The default change by mode	X	000~ 120	ALL	C25H	0503H	
	DI-4							
Hn604	Please refer to Hn601							
	DI-5							
Hn605	Please refer to Hn601							
	DI-6							
Hn606	Please refer to Hn601							
	DI-7							
Hn607	Please refer to Hn601							
	DI-8							
Hn608	Please refer to Hn601							
	DI-9							
Hn609	Please refer to Hn601							
	DI-10							
Hn610	Please refer to Hn601							
	DI-11							
Hn611	Please refer to Hn601							
	DI-12							
Hn612	Please refer to Hn601							

★New setting will become effective after re-cycling the power.

Warning! If any of programmable Inputs of DI-1 ~ DI-12 are set for the same type of function then the logic state selection (NO or NC selection) for these inputs must be the same type. Otherwise an Alarm will be displayed. AL-07 (Abnormal DI/DO programming).

Parameter	Name & Function			Default	Unit	Setting Range	Control Mode	Communication Address							
	RS232	RS485													
	DO-1 Functions			Changed by mode	X	00 12	ALL	C47H	050DH						
	Setting	Explanation													
	00	NON	Unused												
	01	RDY	Servo Ready												
	02	ALM	Alarm												
	03	ZS	Zero Speed												
	04	BI	Brake Signal												
	05	INS	In Speed												
	06	INP	In Position												
	07	HOME	HOME												
	08	INT	In Torque												
	09	P1	Position Display 1 for Tool Turret mode												
	0A	P2	Position Display 2 for Tool Turret mode												
	0B	P3	Position Display 3 for Tool Turret mode												
	0C	P4	Position Display 4 for Tool Turret mode												
	0D	P5	Position Display 5 for Tool Turret mode												
	0E	P6	Position Display 6 for Tool Turret mode												
	0F	OL	Motor Over-load Signal												
	10	BAT	Absolute Encoder Battery Module Fault Signal												
	11	LIM	CWL/CCWL Drive Disable Signal												
	12	VDO	Virtual digital output												
	DO-1 Active Level			0	X	0 1	ALL	C48H	050EH						
	Setting	Explanation													
	0	Close, when the output is activated.													
	1	Open, when the output is activated.													
	DO-2			Changed by mode	X	000~ 112	ALL	C48H	050EH						
	Please refer to Hn614														
	DO-3			Changed by mode	X	000~ 112	ALL	C49H	050FH						
	Please refer to Hn614														
	DO-4			Changed by mode	X	000~ 112	ALL	C4AH	0510H						
	Please refer to Hn614														

New setting will become effective after re-cycling the power.

Warning! If any of programmable Outputs of DO-1 ~ DO-4 are set for the same type of function; then the logic state selection (NO or NC selection) for these outputs can not be the same type. Otherwise an Alarm will be displayed. AL-07 (Abnormal DI/DO programming).

Parameter	Name & Function	Default	Unit	Setting Range	Control Mode	Communication Address									
						RS232	RS485								
Hn617	<p>Digital input control method selection.</p> <p>Select digital input (12 pins) control method by external terminal or communication. Convert Binary code to Hex code for setting this parameter. DI and binary bits table as below.</p> <p>Ex. DI-1 is bit 0 and DI-12 is bit 12.</p> <table border="1"> <tr> <td>DI-[]</td> <td>DI-12</td> <td>.....</td> <td>DI-1</td> </tr> <tr> <td>bit</td> <td>11</td> <td>.....</td> <td>0</td> </tr> </table> <p>Binary code representation :</p> <p>→ "0 " Digital input control by external terminal. → "1 " Digital input control by communication.</p> <p>Set H0000 for Hn617 represent DI-1 ~ DI-12 are controlled by external terminal and set H0FFF represent all terminal is controlled by communication. Ex. Set DI (1, 3, 6, 10, 12) for communication control other pins by external terminal; The corresponding binary code is : [0 1010 0010 0101] convert to Hex code is : [H 0A25]for entering parameter. For the setting Bit0 (DI-1) is control by communication and Bit1 (DI-2) is control by external terminaletc .</p>	DI-[]	DI-12	DI-1	bit	11	0	H0000	X	H0000 H0FFF (HEX)	ALL	C31H	0511H
DI-[]	DI-12	DI-1												
bit	11	0												
Hn618	<p>Setting digital input status in communication mode</p> <p>Change Hn618 Hex code for setting digital input status of communication control mode; Setting method refer Hn617.</p> <p>Binary code representation: "0" : digital input contact OFF "1" : digital input contact ON</p> <p>Set H0000 for Hn617 represent DI-1 ~ DI-12 are controlled by external terminal and set H0FFF represent all terminal is controlled by communication.</p> <p>P.S.)This parameter should co-operate with Hn617.</p>	H0000	X	H0000 H0FFF (HEX)	ALL	5FFH	0512H								

Display Parameter

Parameter Signal	Display	Unit	Explanation	Communication Address	
				RS232	RS485
Un-01	Actual Motor Speed	rpm	Motor Speed is displayed in rpm.	6C4H	0601H
Un-02	Actual Motor Torque	%	It displays the torque as a percentage of the rated torque. Ex: 20 are displayed. It means that the motor torque output is 20% of rated torque.	9B6H	0602H
Un-03	Regenerative load rate	%	Value for the processable regenerative power as 100%. Displays regenerative power consumption in 10-s cycle.	6F4H	0603H
Un-04	Accumulated load rate	%	Value for the rated torque as 100%. Displays effective torque in 10-s cycle.	693H	0604H
Un-05	Max load rate	%	Max value of accumulated load rate	694H	0605H
Un-06	Speed Command	rpm	Speed command is displayed in rpm.	678H	0606H
Un-07	Position Error Value	pulse	Error between position command value and the actual position feedback.	65CH	0607H
Un-08	Position Feed-back Value	pulse	The accumulated number of pulses from the encoder.	688H	0608H
Un-09	ExternalVoltage Command	V	External analog voltage command value in volts.	B93H	0609H
Un-10	(Vdc Bus)Main Loop Voltage	V	DC Bus voltage in Volts.	6B7H	060AH
Un-11	External analog voltage limit value	V	EX: The value is 5.25 means external analog voltage limit value is 5.25V.	B9BH	060BH
Un-12	External CCW Torque Limit Command Value	%	Ex: Display 100. Means current external CCW torque limit command is set to 100 %.	6C0H	060CH
Un-13	External CW Torque LimitCommand Value	%	Ex: Display 100. Means current external CW torque limit command is set to 100%.	6C1H	060DH
Un-14	Motor feed back – Less than 1 rotation pulse value(Low Byte)	pulse	After power on, it displays the number of pulses for an incomplete revolution of the motor as a Low Byte value.	8FDH	060EH
Un-15	Motor feed back – Less than 1 rotation pulse value(High Byte)	pulse	After power on, it displays the number of pulses for an incomplete revolution of the motor as a High Byte value.	8FCH	060FH
Un-16	Motor feed back – Rotation value (Low Byte)	rev	After power on, it displays motor rotation number as a Low Byte value.	8FFH	0610H
Un-17	Motor feed back – Rotation value (absolute value)	rev	After power on, it displays motor rotation number as a High Byte value.	8FEH	0611H
Un-18	Pulse command – Less than 1 rotation pulse value(Low Byte)	pulse	After power on, it displays pulse command input for an incomplete rotation. pulse value is a Low Byte value.	8F9H	0612H
Un-19	Pulse command – Less than 1 rotation pulse value(absolute value)	pulse	After power on, it displays pulse command input for an incomplete rotation. pulse value is a High Byte value.	8F8H	0613H
Un-20	Pulse command – rotation value(Low Byte)	rev	After power on, it displays pulse command input rotation number in Low Byte value.	8FBH	0614H

Parameter Signal	Display	Unit	Explanation	Communication Adress	
				RS232	RS485
Un-21	Pulse command – rotation value (absolute value)	rev	After power on, it displays pulse command input rotation number in High Byte value.	8FAH	0615H
Un-22	Position feedback	pulse	2500/8192 ppr Encoder feedback.	6B0H	0616H
Un-23	15 bits encoder position feedback Less than 1 rotation	pulse	it displays absolute position for an incomplete rotation.	9E7H	0617H
Un-24	Communication encoder position feedback of multi-rotations	rev	It displays absolute position for multi-rotations.	9D9H	0618H
Un-25	17 bits encoder position feedback Less than 1 rotation (Low Byte)	pulse	it displays absolute position for an incomplete rotation as Low Byte value.	9E7H	0619H
Un-26	17 bits encoder position feedback Less than 1 rotation (High Byte)	pulse	it displays absolute position for an incomplete rotation as High Byte value.	9E6H	061AH
Un-27	15bits/17bits encoder status	—	15 bits/17bits encoder status feedback.	9DAH	061BH
Un-28	Torque command	%	It displays the torque command as a percentage of the rated torque. Ex: Display. 50. Means current motor torque command is 50% of rated torque.	67EH	061CH
Un-29	Load inertia	x0.1	When Cn002.2=0(Auto gain adjust disabled), it displays the current preset load inertia ratio from parameter Cn025. When Cn002.2=1(Auto gain adjust enabled), it displays the current estimated load inertia ratio.	844H	061DH
Un-30	Digital Output status (Do)	—	The status of digital output contact (Do) represented in hexadecimal. Ex : H00XX (0000 0000 Do-8/7/6/5 Do-4/3/2/1)	6AFH	061EH
Un-31	Digital Input status (Di)	—	The status of digital input contact (Di) represented in hexadecimal. Ex : HXXXX (0000Di-13 Di-12/11/10/9 Di-8/7/6/5 Di-4/3/2/1)	6CBH	061FH
Un-39	The offset voltage of TLA	mV	EX : The value is 25 means The offset voltage of TLA is 25mV.	97CH	0627H
Un-40	The offset voltage of VIC	mV	EX : The value is 25 means The offset voltage of VIC is 25mV.	97FH	0628H
Un-41	The offset voltage of TC	mV	EX : The value is 25 means The offset voltage of TC is 25mV.	97DH	0629H
Un-42	The offset voltage of VC	mV	EX : The value is 25 means The offset voltage of VC is 25mV.	97EH	062AH
Un-43	Electric motor angle	degree	Display the moment of electric motor angle.	6BAH	062BH
Un-44	Read the model of motor with communication type encoder	—	EX : When it display H1267 means motor's Cn030 number is H1267	72FH	062CH
Un-45	Inertia Estimation for OnLine_AutoTuning	X0.1	EX : The value is 100 means the inertia ratio is ten times.	B34H	062DH
Un-46	Status for OFFLine_Tuning	—	The status of OFFLine_Tuning	90AH	062EH
Un-47	The error code for OFFLine_Tuning	—	The error code for OFFLine_Tuning	CA5H	062FH

Diagnosis Parameter

Parameter	Name & Function	Communication Address	
		RS232	RS485
dn-01	Selected control mode	N/A	N/A
dn-02	Output terminal signal status.	6AFH	N/A
dn-03	Input terminal signal status.	6CBH	N/A
dn-04	Software version	C42H	N/A
dn-05	JOG mode operation	N/A	N/A
dn-06	Reserved.	C43H	N/A
dn-07	Auto offset adjustment of external command voltage.	5FCH	N/A
dn-08	Servo model code.	50CH	N/A
dn-09	ASIC software version display	98CH	N/A
dn-10	Absolute Encoder Rotation Value Reset	524H	N/A
dn-10.1	Absolute Encoder Battery Alarm (AL-16) clear	524H	N/A
dn-11	Automatic alignment function	6FAH	N/A


Chapter 7 Communications Function

7-1 Communications Function (RS-232 & RS-485)

The Servo drive provides RS232 communication. The description below shows the communication wiring and communication protocol.

7-1-1 Communication Wiring

RS-232 Wiring



Driver terminal MD-Type 8Pins

Pin	Description	Name
1	Receive Data	RxD
2	_____	_____
3	Ground	GND
4	Transmit Data	TxD
5	Serial transmission +	Data+
6	_____	_____
7	Serial transmission -	Data-
8	_____	_____


PC terminal D-Type 9Pins(female)

Pin	Description	Name
1	Protective Ground	PG
2	Receive Data	RxD
3	Transmit Data	TxD
4	Data Terminal Ready	DTR
5	Ground	GND
6	Data Set Ready	DSR
7	Request to Send	RTS
8	Clear to Send	CTS
9	Ring indicator	RI

※ Pin 4 and Pin 6 is short circuits.

※ Pin 7 and Pin 8 is short circuits.


RS-485 Wiring





Driver terminal MD-Type 8Pins

Pin	Description	Name
1	Receive Data	RxD
2	—	—
3	Ground	GND
4	Transmit Data	TxD
5	Serial transmission +	Data+
6	—	—
7	Serial transmission -	Data-
8	—	—

RS-232 / RS-485 Converter



RS-232/RS-485 communication parameter

Parameter	Name & Function		Default	Unit	Setting Range	Control Mode
★ Cn036	Servo ID number When using Modbus for communication, each servo units has to setting a ID number. repeated ID number will lead to communication fail.		1	X	0 — 254	ALL
★ Cn037.0	Modbus RS-485 baud rate setting 		1	bps	0 — 5	ALL
★ Cn037.1	PC Software RS-232 baud rate setting 		1	bps	0 — 3	ALL
★ Cn037.2	RS-485 communication selection This parameter can be set to RS-485 communication written to the EEPROM or SRAM. 		0	X	0 — 1	ALL
★ Cn037.3	Communication RS232 is read and written to the selection of EEPROM. 		0	X	0 — 1	ALL
★ Cn038	Communication protocol 		0	X	0 — 8	ALL
★ Cn039	Communication time-out detection Setting non-zero value to enable this function, communication Time should be in the setting period otherwise alarm message of communication time-out will show. Setting a zero value to disable this function.		0	sec	0 — 20	ALL
★ Cn040	Communication response delay time Delay Servo response time to master control unit.		0	0.5 msec	0 — 255	ALL

Parameter Signal	Name & Function	Default	Unit	Setting Range	Control Mode								
Hn617	<p>Digital input control method selection.</p> <p>Select digital input (12 pins) control method by external terminal or communication. Convert Binary code to Hex code for setting this parameter. DI and binary bits table as below.</p> <p>Ex. DI-1 is bit 0 and DI-12 is bit 12.</p> <table border="1" style="margin-left: auto; margin-right: auto;"> <tr> <td>DI-[]</td> <td>DI-12</td> <td>..... ...</td> <td>DI-1</td> </tr> <tr> <td>bit</td> <td>11</td> <td>..... ...</td> <td>0</td> </tr> </table> <p>Binary code representation :</p> <p>→ "0" Digital input control by external terminal.</p> <p>→ "1" Digital input control by communication.</p> <p>Set H0000 for Hn617 represent DI-1 ~ DI-12 are controlled by external terminal and set H0FFF represent all terminal is controlled by communication.</p> <p>Ex. Set DI (1, 3, 6, 10, 12) for communication control other pins by external terminal;</p> <p>The corresponding binary code is :[0 1010 0010 0101] convert to Hex code is : [H 0A25]for entering parameter.</p> <p>For the setting Bit0 (DI-1) is control by communication and Bit1 (DI-2) is control by external terminaletc</p>	DI-[]	DI-12	DI-1	bit	11	0	H0000	X	H0000 H0FFF (HEX)	ALL
DI-[]	DI-12	DI-1										
bit	11	0										
Hn618	<p>Setting digital input status in communication mode</p> <p>Change Hn618 Hex code for setting digital input status of communication control mode; Setting method refer Hn617.</p> <p>Binary code representation :</p> <p>"0" : digital input contact OFF</p> <p>"1" : digital input contact ON</p> <p>Set H0000 for Hn617 represent DI-1 ~ DI-12 are controlled by external terminal and set H0FFF represent all terminal is controlled by communication.</p> <p>P.S.)This parameter should co-operate with Hn617.</p>	H0000	X	H0000 H0FFF (HEX)	ALL								

7-1-2 RS-232 Communication Protocol and Format

Baud rate	9600bps (Selection by Cn037.1)
Parity	No
Data bit	8
Stop bit	1

* Symbol H in following sentence is for Hex representation.

(1) Read a word from servo drive ► Function code format: R5XxSs

Xx : A request to read register " Xx " from slave device(Unit :Byte, Hex representation)

Ss : Check Sum Ss ='R'+'5'+X'+x' (Unit :Byte, Hex representation)

Ex1: Read register address 30H and

(Convert 『R530』 into ASCII codes)

Check Sum=52H+35H+33H+30H=EA H

→ R 5 3 0

Obtain Function code for read register address 30H: 『R530EA』

Servo drive response : %XxYySs

Ss is Check Sum, Ss=%'+X'+x'+Y'+y'

Response message of example 1:

0008H is the data store in register address 30H:

Check Sum=25H+30H+30H+30H+38H=EDH

% 0 0 0 8

Drive response message: 『%0008ED』

* When function code incorrect , drive response : 『!』 (ASCII code: 21H)

(2) Read consecutive 2 words from drive ► Function code format: L5NnSs

Nn : A request to read register " Nn " from slave device (Unit :Byte, Hex representation)

Ss : Check Sum Ss =L'+5'+N'+n' (Unit : Byte, Hex representation)

Ex2: Read data from register address 60H and

(Convert 『L560』 into ASCII codes)

Check Sum=4CH+35H+36H+30H=E7

L 5 6 0

Obtain Function code for read register address 60H: 『L560E7』

Servo drive response: %XxYyAaBbSs

Ss is Check Sum Ss=%'+X'+x'+Y'+y'+A'+a'+B'+b'

XxYy is the data store in register address Nn+1,

AaBb is the data store in register address Nn

Response message of example 2:

0001 000AH is the data store in register 60H

Check Sum=25H+30H+30H+30H+31H+30H+30H+30H+41H=1B7H

% 0 0 0 1 0 0 0 A

Drive response message: 『%0001000AB7』

* When function code incorrect , drive response : 『!』 (ASCII code: 21H)

(3) Write a word to drive ► Function code format: **W5XxYyZzSs**

Xx : Address for write data (Unit :Byte 、 Hex representation)

YyZz : Writes the data contents (Unit :word, Hex representation)

Ss : Check Sum , Ss ='W'+'5'+'X'+'x'+'Y'+'y'+'Z'+'z' (Unit :Byte, Hex representation)

Ex3 : Write data 0008H to register 30H

(Convert 『W5300008』 into ASCII codes)

Check Sum=57H+35H+33H+30H+30H+30H+30H+38H=1B7H

W 5 3 0 0 0 0 8

Obtain Function code for write data 0008H to register 30H : 『**W5300008B7**』

Drive response message : 『%』 (ASCII code :25H)

* When function code incorrect , drive response : 『!』 (ASCII code: 21H)

(4) Write consecutive 2 words to drive ► Function code format: **M5NnXxYyAaBbSs**

Nn : Address for write data(Unit :Byte 、 Hex representation)

XxYy : Writes the data contents of address Nn+1 (Unit :Word 、 Hex representation)

AaBb : Writes the data contents of address Nn (Unit :Word 、 Hex representation)

Ss : Check Sum , Ss ='M'+'5'+'N'+'n'+'X'+'x'+'Y'+'y'+'A'+'a'+'B'+'b' (Unit :Byte 、 Hex representation)

Ex4: Write data 0002 000BH to register 60H

(Convert 『M5600002000B』 into ASCII codes)

Check Sum=4DH+35H+36H+30H+30H+30H+30H+32H+30H+30H+30H+42H =27CH

M 5 6 0 0 0 0 2 0 0 0 B

Obtain Function code for write data 0002000BH to register 60H : 『**M5600002000B7C**』

Drive response message: 『%』 (ASCII code :25H)

* When function code incorrect , drive response : 『!』 (ASCII code: 21H)

7-1-3 Modbus Communication Protocol for RS-485

The MODBUS protocol allows an easy communication within types of network architectures, before start to communication with slave device, set the ID number (**Cn036**) for Servo drive respectively, server distinguish ID number for controlling specific client station.

Standard Modbus networks combine two transmission modes: ASCII or RTU: ASCII(American Standard Code for information interchange) Mode and RTU (Remote Terminal Unit) Mode, Use **Cn038** to select ASCII or RTU mode.

Coding method

ASCII Mode

8-bits Data consist of two ASCII code.

Ex: Data 26H 1-byte , the '26' convert to ASCII code is include character '2' → <32H> and '6' → <36H>

ASCII Chart (0 ~ 9 and A ~ F):

Character	'0'	'1'	'2'	'3'	'4'	'5'	'6'	'7'
ASCII code(Hex)	30H	31H	32H	33H	34H	35H	36H	37H
Character	'8'	'9'	'A'	'B'	'C'	'D'	'E'	'F'
ASCII code(Hex)	38H	39H	41H	42H	43H	44H	45H	46H


RTU Mode

Each 8bits is consist of 2 Hex number (4-bits per Hex number).


Ex.: Data 26H, the data length is 1-byte.

ASCII Mode Framing

10 bits Frame (7-bits Data)



11 bits Frame (8-bits Data)



ASCII Mode Framing

Symbol	Name	Description
STX	Comm. start	3AH, Char ':'
ADR	Slave address	Include 2 ASCII code within 1-byte Comm. add : 1 ~ 254 convert to Hex representation ; Ex. Servo drive ADR is No.20 convert to 14H ; ADR = '1' , '4' → '1' = 31H , '4' = 34H
Function Code	Function code	Include 2 ASCII code within 1-byte Function codes : 03H : Read the register contents, 06H : Write Single Register , 08H : Diagnostic function, 10H : Write Multipile Registers
DATA(n-1) DATA(0)	Data	n-word = 2n-byte (ASCII numbers : 4n), n≤30 The format of data is depend on Function code
LRC	Check code	Include 2 ASCII code within 1-byte
END 1	END 1 (CR)	0DH ; Char '\r'
END 0	END 0 (LF)	0AH ; Char '\n'

RTU Mode

Symbol	Name	Description
STX	Comm. start	Excess comm. loss time setting 10ms
ADR	Slave address	1-byte Comm. address : 1 ~ 254 , convert to Hex representation ; Ex. Comm. address = 20 convert representation to 14 Hex, ADR = '14H'
Function Code	Function code	1-byte Function codes : 03H : Read the register contents, 06H : Write Single Register , 08H : Diagnostic function, 10H : Write Multipile Registers
DATA(n-1) DATA(0)	Data	n-word = 2n-byte ; n≤30 The format of data is depend on Function code
CRC-Low	Checking code-LO	1-byte
CRC-High	Checking code-HI	1-byte
END 0	End 0	Excess comm. loss time setting 10ms

Common function codes

03H : Read the register contents

Continuous read N words. * Largest number of N is 29 (1DH)

Ex.: Read two words (register 0200H and 0201H) from Slave address 01H.

ASCII Mode

Query PC → Servo

STX		‘:’	
ADR	(Hi)	‘0’	
		‘1’	
Function Code	(Lo)	‘0’	
		‘3’	
Register ADD.	(Hi)	‘0’	
		‘2’	
Data length (word)	(Lo)	‘0’	
		‘0’	
LRC	(Hi)	‘0’	
		‘2’	
END1 (CR)		(0DH)	
END0 (LF)		(0AH)	

Response Servo → PC OK)

STX		‘:’	
ADR	(Hi)	‘0’	
		‘1’	
Function Code	(Lo)	‘0’	
		‘3’	
Data length (byte)		‘0’	
Data of 0200H	(Hi)	‘4’	
		‘0’	
Data of 0201H	(Hi)	‘0’	
		‘0’	
Data of 0201H	(Lo)	‘B’	
		‘1’	
LRC	(Hi)	‘F’	
		‘4’	
LRC	(Lo)	‘E’	
		‘0’	
END1 (CR)		‘8’	
END0 (LF)		(0DH)	
END0 (LF)		(0AH)	

Servo → PC (ERROR)

STX	‘:’
ADR	‘0’
	‘1’
Function Code	‘8’
	‘3’
Exception code	‘0’
	‘2’
LRC	‘7’
	‘A’
END1 (CR)	(0DH)
END0 (LF)	(0AH)

RTU Mode

Query PC → Servo

ADR		01H
Function Code		03H
Register ADD	(Hi)	02H
	(Lo)	00H
Data length (word)		00H
		02H
CRC(Lo)		04H
CRC(Hi)		07H

Response Servo → PC (OK)

ADR		01H	
Function Code		03H	
Data (Byte)	(Hi)	04H	
		00H	
Data of 0200H	(Lo)	BAH	
		1FH	
Data of 0201H	(Hi)	40H	
		40H	
CRC(Lo)		A3H	
CRC(Hi)		D4H	

Servo → PC (ERROR)

ADR	01H
Function Code	83H
Exception	02H
CRC(Lo)	C0H
CRC(Hi)	F1H

06H : Write Single Register

Write a word into register.

Ex : Write data (0064H) into register address 0200H and slave ADR= 01

ASCII Mode

Query PC → Servo

STX		‘ : ’	
ADR		‘ 0 ’	
		‘ 1 ’	
Function Code		‘ 0 ’	
		‘ 6 ’	
Register	(Hi)	‘ 0 ’	
		‘ 2 ’	
ADD		‘ 0 ’	
		‘ 0 ’	
Write data (word)		‘ 0 ’	
‘ 0 ’		‘ 6 ’	
‘ 6 ’		‘ 4 ’	
LRC		‘ 9 ’	
‘ 3 ’			
END1 (CR)		(0DH)	
END0 (LF)		(0AH)	

Response Servo→PC (OK)

STX		‘ : ’	
ADR		‘ 0 ’	
		‘ 1 ’	
Function Code		‘ 0 ’	
		‘ 6 ’	
Register	(Hi)	‘ 0 ’	
		‘ 2 ’	
ADD.		‘ 0 ’	
		‘ 0 ’	
Write data (word)		‘ 0 ’	
‘ 0 ’		‘ 6 ’	
‘ 6 ’		‘ 4 ’	
LRC		‘ 9 ’	
‘ 3 ’			
END1 (CR)		(0DH)	
END0 (LF)		(0AH)	

Servo → PC (ERROR)

STX	‘ : ’
ADR	‘ 0 ’
	‘ 1 ’
Function Code	‘ 8 ’
	‘ 6 ’
Exception code	‘ 0 ’
	‘ 3 ’
LRC	‘ 7 ’
	‘ 6 ’
END1 (CR)	(0DH)
END0 (LF)	(0AH)

RTU Mode

Query PC → Servo

ADR		01H	
Function Code		06H	
Register	(Hi)	02H	
	(Lo)	00H	
Write data (word)		00H	
		64H	
CRC(Lo)		89H	
CRC(Hi)		99H	

Response Servo → PC (OK)

ADR		01H	
Function Code		03H	
Register	(Hi)	02H	
	(Lo)	00H	
Write data (word)		00H	
		64H	
CRC(Lo)		89H	
CRC(Hi)		99H	

Servo → PC (ERROR)

ADR	01H
Function Code	86H
Exception code	03H
CRC(Lo)	02H
CRC(Hi)	61H

08H : Diagnostic function

The sub-function code 0000H is able to check communication signal between Master and Slaver. Data content is random value.

Ex: Use the diagnostic function for ID=01H

ASCII Mode

Query PC → Servo

STX		‘:’	
ADR		‘0’	
ADR		‘1’	
Function Code		‘0’	
Function Code		‘8’	
Sub- Function	(HI)	‘0’	
		‘0’	
	(Lo)	‘0’	
		‘0’	
Data (word)		‘A’	
Data (word)		‘5’	
Data (word)		‘3’	
Data (word)		‘7’	
LRC		‘1’	
LRC		‘B’	
END1 (CR)		(0DH)	
END0 (LF)		(0AH)	

Response Servo → PC (OK)

STX		‘:’	
ADR		‘0’	
ADR		‘1’	
Function Code		‘0’	
Function Code		‘8’	
Sub- Function	(HI)	‘0’	
		‘0’	
	(Lo)	‘0’	
		‘0’	
Data (word)		‘A’	
Data (word)		‘5’	
Data (word)		‘3’	
Data (word)		‘7’	
LRC		‘1’	
LRC		‘B’	
END1 (CR)		(0DH)	
END0 (LF)		(0AH)	

Servo → PC (ERROR)

STX	‘:’
ADR	‘0’
ADR	‘1’
Function Code	‘8’
Function Code	‘8’
Exception code	‘0’
Exception code	‘3’
LRC	‘7’
LRC	‘4’
END1 (CR)	(0DH)
END0 (LF)	(0AH)

RTU Mode

Query PC → Servo

ADR		01H
Function Code		08H
Sub- Function	(HI)	00H
	(Lo)	00H
Data (word)		A5H
Data (word)		37H
CRC(Lo)		DAH
CRC(Hi)		8DH

Response Servo → PC (OK)

ADR		01H
Function Code		08H
Sub- Function	(HI)	00H
	(Lo)	00H
Data (word)		A5H
Data (word)		37H
CRC(Lo)		DAH
CRC(Hi)		8DH

Servo → PC (ERROR)

ADR	01H
Function Code	88H
Exception code	03H
CRC(Lo)	06H
CRC(Hi)	01H

10H : Write Multiple Registers

Continuously write N words to register. * Largest number of N is 27 (1BH)

Ex.: Write data (0064H) and (012CH) into register address 100H and 101H respectively.

ASCII Mode

Query PC → Servo

STX		‘ : ’	
ADR	(HI)	‘ 0 ’	
		‘ 1 ’	
Function Code	(Lo)	‘ 1 ’	
		‘ 0 ’	
Register	(HI)	‘ 0 ’	
		‘ 1 ’	
ADD	(Lo)	‘ 0 ’	
		‘ 0 ’	
Data length (word)		‘ 0 ’	
‘ 0 ’		‘ 0 ’	
‘ 0 ’		‘ 0 ’	
‘ 2 ’		‘ 2 ’	
Byte counters (byte)		‘ 0 ’	
‘ 4 ’		‘ E ’	
ADD.	(HI)	‘ 0 ’	
		‘ 0 ’	
0100H	(Lo)	‘ 6 ’	
		‘ 4 ’	
ADD.	(HI)	‘ 0 ’	
		‘ 1 ’	
0101H	(Lo)	‘ C ’	
		‘ 2 ’	
LRC		‘ 5 ’	
‘ 7 ’		‘ C ’	
END1 (CR)		(0DH)	
END0 (LF)		(0AH)	

Response Servo → PC (OK)

STX		‘ : ’	
ADR	(HI)	‘ 0 ’	
		‘ 1 ’	
Function Code	(Lo)	‘ 1 ’	
		‘ 0 ’	
Register	(HI)	‘ 0 ’	
		‘ 1 ’	
ADD	(Lo)	‘ 0 ’	
		‘ 0 ’	
Data length (word)		‘ 0 ’	
‘ 0 ’		‘ 0 ’	
‘ 0 ’		‘ 0 ’	
‘ 2 ’		‘ 2 ’	
LRC		‘ E ’	
‘ C ’		‘ C ’	
END1 (CR)		(0DH)	
END0 (LF)		(0AH)	

Servo → PC (ERROR)

STX	‘ : ’
ADR	‘ 0 ’
	‘ 1 ’
Function Code	‘ 9 ’
	‘ 0 ’
Exception code	‘ 0 ’
	‘ 2 ’
LRC	‘ 6 ’
	‘ D ’
END1 (CR)	(0DH)
END0 (LF)	(0AH)

RTU Mode

Query PC → Servo		Response Servo → PC (OK)		Servo → PC (ERROR)	
ADR	01H	ADR	01H	ADR	01H
Function Code	10H	Function Code	10H	Function Code	90H
Register ADD	(HI)	01H	Register ADD	(HI)	02H
	(Lo)	00H		(Lo)	00H
Data length (word)	00H	Data length (word)	00H	CRC(Lo)	CDH
	02H		02H	CRC(Hi)	C1H
Byte counters	04H	CRC(Lo)	40H		
Data (HI)	00H	CRC(Hi)	34H		
0100H	(Lo)	64H			
Data (HI)	01H				
0101H	(Lo)	2CH			
CRC(Lo)	BFH				
CRC(Hi)	ADH				

LRC (ASCII Mode) and CRC (RTU Mode) Check methods

LRC Checking:

ASCII Mode LRC (Longitudinal Redundancy Check) checking method

The LRC is calculated by adding together successive 8-bit bytes of the message, discarding any carries.

Ex. add ADR, Function code, register address and data contents together, if it get the sum 19DH then discard carrier "1" and find two's complement for 9DH to obtain LRC code.

Ex: Execute diagnostic function for Servo drive ID =01H

STX	' :	Data (word)	' A '
ADR	' 0 '		' 5 '
	' 1 '		' 3 '
Function code	' 0 '		' 7 '
	' 8 '	LRC	' 1 '
Sub-function	(HI)		' B '
	' 0 '	END1 (CR)	(0DH)
	' 0 '	END0 (LF)	(0AH)
	' 0 '		

01H+08H+00H+00H+A5H+37H = E5H

Two's complement for E5H is 1BH ; derive LRC code: ' 1 ', ' B '

CRC Checking:

CRC check code is from Slave Address to end of the data. The calculation method is illustrated as follow:

- (1) Load a 16-bit register with FFFF hex (all1's). Call this the CRC register.
- (2) Exclusive OR the first 8-bit byte of the message with the low-order byte of the 16-bit CRC register, putting the result in the CRC register.
- (3) Shift the CRC register one bit to the right (toward the LSB), Zero-filling the MSB, Extract and examines the LSB.
- (4) (If the LSB was 0): Repeat Steps (3) (another shift) (If the LSB was 1): Exclusive OR the CRC register with the polynomial value A001 hex (1010 0000 0000 0001).
- (5) Repeat Steps (3) and (4) until 8 shifts been performed. When this is done, a complete 8-bit byte will be processed.
- (6) Repeat Steps (2) through (5) for next 8-bit byte of the message, Continue doing this until all bytes have been processed. The final content of the CRC register is the CRC value.

Placing the CRC into the message:

When the 16-bit CRC (2 8-bit bytes) is transmitted in the message, the low-order byte will be transmitted first, followed by the high-order byte, For example, if the CRC value is 1241 hex, the CRC-16 (Low) put the 41h, the CRC-16 (Hi) put the 12h.

Example :

An example of a C language function performing CRC generation is shown on the following pages. All of the possible CRC values are preloaded into two arrays, which are simply indexed as the function increments through the message buffer. One array contains all of the 256 possible CRC values for the high byte of the 16-bit CRC field, and the other array contains all of the values for the low byte.

Indexing the CRC in this way provides faster execution than would be achieved by calculating a new CRC value with each new character from the message buffer.

Note

This function performs the swapping of the high/low CRC bytes internally. The bytes are already swapped in the CRC value that is returned from the function.

Therefore the CRC value returned from the function can be directly placed into the message for transmission.

The function takes two arguments:

unsigned char *puchMsg ;	A pointer to the message buffer containing binary data to be used for generating the CRC
unsigned short usDataLen ;	The quantity of bytes in the message buffer.

The function returns the CRC as a type unsigned short.

CRC Generation Function

```
unsigned short CRC16(puchMsg, usDataLen)
unsigned char *puchMsg ;                                /* message to calculate CRC upon*/
unsigned short usDataLen ;                             /* quantity of bytes in message*/
{
    unsigned char uchCRCHi = 0xFF ;                      /* high byte of CRC initialized*/
    unsigned char uchCRCLo = 0xFF ;                      /* low byte of CRC initialized*/
    unsigned ulIndex ;                                 /* will index into CRC lookup table*/

    while (usDataLen--)                                /* pass through message buffer
    {
        ulIndex = uchCRCHi ^ *puchMsg++;                /* calculate the CRC*/
        uchCRCHi = uchCRCLo ^ auchCRCHi[ulIndex];
        uchCRCLo = auchCRCLo[ulIndex];
    }
    return (uchCRCHi << 8 | uchCRCLo);
}
```

High-Order Byte Table

```
/* Table of CRC values for high-order byte */
```

```
static unsigned char auchCRCHi[] = {
0x00, 0xC1, 0x81, 0x40, 0x01, 0xC0, 0x80, 0x41, 0x01, 0xC0, 0x80, 0x41, 0x00, 0xC1, 0x81,
0x40, 0x01, 0xC0, 0x80, 0x41, 0x00, 0xC1, 0x81, 0x40, 0x00, 0xC1, 0x81, 0x40, 0x01, 0xC0,
0x80, 0x41, 0x01, 0xC0, 0x80, 0x41, 0x00, 0xC1, 0x81, 0x40, 0x00, 0xC1, 0x81, 0x40, 0x01,
0xC0, 0x80, 0x41, 0x00, 0xC1, 0x81, 0x40, 0x01, 0xC0, 0x80, 0x41, 0x01, 0xC0, 0x80, 0x41,
0x00, 0xC1, 0x81, 0x40, 0x01, 0xC0, 0x80, 0x41, 0x00, 0xC1, 0x81, 0x40, 0x00, 0xC1, 0x81,
0x40, 0x01, 0xC0, 0x80, 0x41, 0x00, 0xC1, 0x81, 0x40, 0x01, 0xC0, 0x80, 0x41, 0x01, 0xC0,
0x80, 0x41, 0x00, 0xC1, 0x81, 0x40, 0x00, 0xC1, 0x81, 0x40, 0x01, 0xC0, 0x80, 0x41, 0x01,
0xC0, 0x80, 0x41, 0x00, 0xC1, 0x81, 0x40, 0x01, 0xC0, 0x80, 0x41, 0x00, 0xC1, 0x81, 0x40,
0x00, 0xC1, 0x81, 0x40, 0x01, 0xC0, 0x80, 0x41, 0x01, 0xC0, 0x80, 0x41, 0x00, 0xC1, 0x81,
0x40, 0x00, 0xC1, 0x81, 0x40, 0x01, 0xC0, 0x80, 0x41, 0x00, 0xC1, 0x81, 0x40, 0x01, 0xC0,
0x80, 0x41, 0x01, 0xC0, 0x80, 0x41, 0x00, 0xC1, 0x81, 0x40, 0x00, 0xC1, 0x81, 0x40, 0x01,
0xC0, 0x80, 0x41, 0x00, 0xC1, 0x81, 0x40, 0x01, 0xC0, 0x80, 0x41, 0x00, 0xC1, 0x81, 0x40,
0x00, 0xC1, 0x81, 0x40, 0x01, 0xC0, 0x80, 0x41, 0x01, 0xC0, 0x80, 0x41, 0x00, 0xC1, 0x81,
0x40, 0x01, 0xC0, 0x80, 0x41, 0x00, 0xC1, 0x81, 0x40, 0x00, 0xC1, 0x80, 0x41, 0x01, 0xC0,
0x80, 0x41, 0x00, 0xC1, 0x81, 0x40, 0x00, 0xC1, 0x81, 0x40, 0x01, 0xC0, 0x80, 0x41, 0x01,
0xC0, 0x80, 0x41, 0x00, 0xC1, 0x81, 0x40, 0x00, 0xC1, 0x81, 0x40, 0x01, 0xC0, 0x80, 0x41,
0x00, 0xC1, 0x81, 0x40, 0x01, 0xC0, 0x80, 0x41, 0x00, 0xC1, 0x80, 0x41, 0x01, 0xC0, 0x80,
0x40
};
```

Low-Order Byte Table

/* Table of CRC values for low-order byte */

```
static char auchCRCLo[] = {  
0x00, 0xC0, 0xC1, 0x01, 0xC3, 0x03, 0x02, 0xC2, 0xC6, 0x06, 0x07, 0xC7, 0x05, 0xC5, 0xC4,  
0x04, 0xCC, 0x0C, 0x0D, 0xCD, 0x0F, 0xCF, 0xCE, 0x0E, 0x0A, 0xCA, 0xCB, 0x0B, 0xC9, 0x09,  
0x08, 0xC8, 0xD8, 0x18, 0x19, 0xD9, 0x1B, 0xDB, 0xDA, 0x1A, 0x1E, 0xDE, 0xDF, 0x1F, 0xDD,  
0x1D, 0x1C, 0xDC, 0x14, 0xD4, 0xD5, 0x15, 0xD7, 0x17, 0x16, 0xD6, 0xD2, 0x12, 0x13, 0xD3,  
0x11, 0xD1, 0xD0, 0x10, 0xF0, 0x30, 0x31, 0xF1, 0x33, 0xF3, 0xF2, 0x32, 0x36, 0xF6, 0xF7,  
0x37, 0xF5, 0x35, 0x34, 0xF4, 0x3C, 0xFC, 0xFD, 0x3D, 0xFF, 0x3F, 0x3E, 0xFE, 0xFA, 0x3A,  
0x3B, 0xFB, 0x39, 0xF9, 0xF8, 0x38, 0x28, 0xE8, 0xE9, 0x29, 0xEB, 0x2B, 0x2A, 0xEA, 0xEE,  
0x2E, 0x2F, 0xEF, 0x2D, 0xED, 0xEC, 0x2C, 0xE4, 0x24, 0x25, 0xE5, 0x27, 0xE7, 0xE6, 0x26,  
0x22, 0xE2, 0xE3, 0x23, 0xE1, 0x21, 0x20, 0xE0, 0xA0, 0x60, 0x61, 0xA1, 0x63, 0xA3, 0xA2,  
0x62, 0x66, 0xA6, 0xA7, 0x67, 0xA5, 0x65, 0x64, 0xA4, 0x6C, 0xAC, 0xAD, 0x6D, 0xAF, 0x6F,  
0x6E, 0xAE, 0xAA, 0x6A, 0x6B, 0xAB, 0x69, 0xA9, 0xA8, 0x68, 0x78, 0xB8, 0xB9, 0x79, 0xBB,  
0x7B, 0x7A, 0xBA, 0xBE, 0x7E, 0x7F, 0xBF, 0x7D, 0xBD, 0xBC, 0x7C, 0xB4, 0x74, 0x75, 0xB5,  
0x77, 0xB7, 0xB6, 0x76, 0x72, 0xB2, 0xB3, 0x73, 0xB1, 0x71, 0x70, 0xB0, 0x50, 0x90, 0x91,  
0x51, 0x93, 0x53, 0x52, 0x92, 0x96, 0x56, 0x57, 0x97, 0x55, 0x95, 0x94, 0x54, 0x9C, 0x5C,  
0x5D, 0x9D, 0x5F, 0x9F, 0x9E, 0x5E, 0x5A, 0x9A, 0x9B, 0x5B, 0x99, 0x59, 0x58, 0x98, 0x88,  
0x48, 0x49, 0x89, 0x4B, 0x8B, 0x8A, 0x4A, 0x4E, 0x8E, 0x8F, 0x4F, 0x8D, 0x4D, 0x4C, 0x8C,  
0x44, 0x84, 0x85, 0x45, 0x87, 0x47, 0x46, 0x86, 0x82, 0x42, 0x43, 0x83, 0x41, 0x81, 0x80,  
0x40  
};
```

Exception Codes

When communication error occur , servo drive is returned with an error code and Function code+80H return to the ModBus host controller.

Code	Name	Description
01	ILLEGAL FUNCTION	The function code received in the query is not an allowable action for the server (or slave).
02	ILLEGAL DATA ADD.	The data address received in the query is not an allowable address for the server (or slave).
03	ILLEGAL DATA VALUE	A value contained in the query data field is not an allowable value for server (or slave).
04	SLAVE DEVICE FAILURE	An unrecoverable error occurred while the server (or slave) was attempting to perform the requested action.
05	RTU CHECK FAILURE	RTU mode: CRC check error
06	ASCII CHECK FAILURE	ASCII mode: LRC check error or no end code(CRLF)


Chapter 8 Troubleshooting

8-1 Alarm functions

The Alarm codes are displayed in a format such as that shown below. For any Alarm messages , refer to this section for identify the cause and dispel the error. to reset the Alarm message by following pages description.

If this is not possible for any reason then contact your local supplier for assistance.

Alarm Status Display :



For Alarm List refer to the section 8-2. In the example above AL-01 indicate (Under Voltage)

There is also an Alarm history which can record ten entry of alarm record.

History record is listed as alarm history record table shows.

Alarm History Record

Display	Explanation	
AL - 00	The Latest Alarm.	Latest record ↑ ↓ Earliest record
A1 - 00	Previous First Alarm.	
A2 - 00	Previous Second. Alarm.	
A3 - 00	Previous Third Alarm.	
A4 - 00	Previous Fourth Alarm.	
A5 - 00	Previous Fifth Alarm.	
A6 - 00	Previous Sixth Alarm.	
A7 - 00	Previous Seventh Alarm.	
A8 - 00	Previous Eighth Alarm.	
A9 - 00	Previous Ninth Alarm.	

Note : 00 is denotation of the Alarm Codes.

Example:

Following table are procedures to access the alarm history record parameter.

Steps	Key	LED Display	Procedures
1	Turn On the Power		On" power on “ Drive Status parameter is displayed.
2			Press MODE key to enter the Alarm History record.
3			Press Key to view the Alarm 1 message that previously happened and the alarm code is “03” (Overload)
4			Press Key again to view Alarm 2 message and repeat this to see entire alarm history list. In this example Alarm code is 01. (Under voltage)
5			Press MODE key once to view System Parameters. Repeat this to select all other available parameters.

8-2 Troubleshooting of Alarm and Warning

Alarm Code	Alarm Name and Description	Corrective Actions	Reset Method
00	Normal	—	—
01	Under-voltage External power voltage is lower than the rated power voltage .	Use multi-meter to check whether the input voltage is within the specified limit. If it can not be solved, there may be failure inside the Drive.	Turn ALRS (DI) ON
02	Over-voltage (Regeneration error) 1. External power voltage is higher than the rated power voltage. 2. Regeneration voltage is too high.	1. Use multi-meter to check whether the input voltage is within the specified limit. 2. Check the Parameter Cn012 if it is setting correctly. 3. If this alarm appears during operation. Extend ac/deceleration time or reduce load ratio in the permitted range. Otherwise, an external regeneration resistor is needed. (Please contact your supplier for assistance.)	Turn ALRS (DI) ON
03	Motor Over-load The drive has exceeded its rated load during continuous operation. When the loading is equal to 2 times of rated loading, alarm occurs within 10sec.	1. Check connection for Motor terminal s (U,V,W) and Encoder. 2. Adjust the Drive gain, If gain is not correctly adjusted, it would cause motor vibration and large current will lead to motor over load. 3. Extend acc/deceleration time or reduce load ratio in the permitted range.	Turn ALRS (DI) ON
04	Drive Over-current Drive main circuit Over current or Transistor error.	1. Check connection of the motor cable (U,V,W) and encoder. Check power cable connection. Refer to the diagram in Chapter 2. 2. Turn off the power, and turn on again after 30 min. If the alarm still exists, there may be power module malfunction or noise consider the drive for test and repair.	Reset Power Supply
05	Encoder ABZ phase signal error Motor's encoder failure or encoder connection problem.	1. Check the motor's encoder connections. 2. Check the encoder if short circuit, poor solder joints or break. 3. Check the encoder signal terminals CN2-1 and CN2-2. (power cable 5v)	Reset Power Supply
06	Encoder UVW phase signal error Motor's encoder failure or encoder connection problem.		Reset Power Supply
07	Multi-function contact setting error Input/output contacts function setting error.	1. Check parameters Hn601~Hn612, trigger level selected by 2 nd digit of Hn601 to 612 should be the same for all inputs DI-1~DI-12 . 2. Check parameters setting of Hn613 ~ Hn616 should NOT be the same for outputs contact DO-1~DO-4 .	Reset Power Supply
08	Memory Error Parameter write-in error	Disconnect all command cable then re-cycle the power. If alarm still occurs, it means the Drive was failure.	Reset Power Supply

Alarm Code	Alarm Name and Description	Corrective Actions	Reset Method
09	Emergency Stop When the input contact point EMC is activated. Alarm 09 appears.	1. Disable Emergency stop signal input. 2. Internal mal-function. Ensure that all connection are correct, refer to Chapter 2 Power and motor circuit diagrams connection. Control wiring diagrams.	Turn ALRS (DI) ON
10	Motor over-current Motor current is 4 times greater than rated current.	1. Check if the motor wiring U,V,W)and encoder wiring correct or not. 2 .Internal interference and mal-function. Ensure that all connection are correct refer to Chapter 2 Power and motor circuit diagrams.	Turn ALRS (DI) ON
11	Position error The deviation between Pulse command and encoder feed back (position error) is greater than the setting of Pn308 or Pn309 .	1. Increase the position loop gain (Pn310 and Pn311) setting value. 2. Increase in position tolerance value by (Pn307) for a better motor response. 3. Extend the time of ac/deceleration or reduce load inertia in the permitted range. 4. Check if the motor wiring (U,V,W) is correct.	Turn ALRS (DI) ON
12	Motor over speed Motor's speed is 1.5 times more then motor's rated speed.	1. Reduce the speed command. 2. Electronic gear ratio is incorrect check and set correctly. 3. Adjust speed loop gains (Sn211 & Sn213) for a better motor response.	Turn ALRS (DI) ON
13	CPU Error Control system Mal-function.	Turn off the power. Turn on again after 30min. If error alarm still exists, this may be due to external interference. Refer to the chapter 2 Motor 、 power cable and control signals connections.	Reset Power Supply
14	Drive disable When input contacts CCWL & CWL are operated at the same time this alarm occurs.	1. Remove input contact signal CCWL or CWL . 2. Check all input wiring for correct connections. 3. For the selected High /Low logic potential settings refer to Section 5-6-1.	Turn ALRS (DI) ON
15	Drive overheat Power transistor temperature exceeds 90°C.	Over-load for a long duration will cause driver overheat, check and reset operation system.	Turn ALRS (DI) ON
16	Absolute Encoder Battery error Battery module remove or battery voltage is lower than 3.2V	Make sure if battery module is removed, power supply is losing, or battery is power shortage and requires replacing. If the battery has reset, the number of turns required to remove the encoder through Cn041,	Turn ALRS (DI) ON

Alarm Reset Methods

1. carry out the suggestions below to reset Alarm.

(a) **Reset by input signal** : Once the cause of Alarm is rectified,

disable **SON** signal (Switch off Servo ON), then activate input signal **ALRS**.

Alarm condition should be cleared and the drive will be ready for operation.

Reference 5-6-1 for setting SON and Alarm signal.

(b) **Reset from Keypad** : Once the cause of Alarm is rectified,

disable **SON** signal (Switch off Servo ON), then press the buttons  and  at the same time to reset Alarm and the drive will be ready for operation.

2. Power reset: Once the cause of Alarm is rectified, disable **SON** signal (Switch off Servo ON) and re-cycling power.

Alarm condition can be reset and the drive will be ready for operation.

Warning!

- 1) **Before applying power rest , ensure that SON is off (SON signal is removed first) to prevent danger.**
- 2) **Ensure that the speed commands are removed before the alarm is reset, otherwise the motor may run abruptly once the alarm signal is reset.**

8-3 Alarm Status Description

Alarm Code	Alarm Name and Description	Reset Method	Alarm Status Digital Output			
			CN1-25 BB/A3	CN1-24 ST/A2	CN1-23 PC/A1	CN1-22 LM/A0
00	Normal	—	If there is no Alarm, CN1-22~CN1-25 operates in accordance with default function. Please refer to 2-2-1.			
01	Under-voltage	Turn ALRS(DI) ON	1	1	1	0
02	Over-voltage (Regeneration error)	Turn ALRS(DI) ON	1	1	0	1
03	Motor Over-load	Turn ALRS(DI) ON	1	1	0	0
04	Drive Over-current	Reset Power Supply	1	0	1	1
05	Encoder ABZ phase signal error	Reset Power Supply	1	0	1	0
06	Encoder UVW phase signal error	Reset Power Supply	1	0	0	1
07	Multi-function contact setting error	Reset Power Supply	1	0	0	0
08	Memory Error	Reset Power Supply	0	1	1	1
09	Emergency Stop	Turn ALRS(DI) ON	0	1	1	0
10	Motor over-current	Turn ALRS(DI) ON	0	1	0	1
11	Position error	Turn ALRS (DI) ON	0	1	0	0
12	Motor over speed	Turn ALRS (DI) ON	0	0	1	1
13	CPU Error	Reset Power Supply	0	0	1	0
14	Drive disable	Turn ALRS (DI) ON	0	0	0	1
15	Drive overheat	Turn ALRS (DI) ON	0	0	0	0
16	Battery Module Fault	Turn ALRS (DI) ON	1	1	1	1

Chapter 9 Specifications

9-1 Specifications and Dimension for Servo Drives


Servo Drives for JSDAP-□□□□		200V Class										400V Class																										
		10A	15A	20A	30A	50A3	75A3	100A3	150A3	200A3	300A3	25B	35B	50B	75B	100B																						
Available Servo Motor (Applicable Motor Models) JSMA-□□□□		SCP5	—	SC04	SC08	MA15	MB30	MH44	MH55	MH75	MH110	MB10	MB20	MB30	MH44	MH75																						
		SC01		SC08* ¹	MA10	MB15	MC30	HH30	HH44	HH55	MH150	MB15	MB30	MH30	MH55																							
		SC02		LC08	MB10	MC15	MH30	—	—	—	HH75	MB20	MH30	MH44																								
		SC04* ¹		MA05	MC10	MB20	—	—	—	—	—																											
		LC03		MH05	MH10	MC20	—	—	—	—	—																											
		—		—	—	—	—	—	—	—	—																											
Basic Specifications	Servo motor Capacity [KW] Max.	0.1	0.4	0.75	1.0	2.0	3.0	4.4	5.5	7.5	15.0	2.0	3.0	4.4	5.5	7.5																						
	Continuous Output Current [A rms]	0.94	2.5	4.4	5.16	9.5	15.0	23.0	33.2	42.1	78.0	6.0	8.0	11.5	16.0	22.0																						
	Max. Output Current [A rms]	2.82	7.5	13.2	15.5	28.5	42.0	59.8	86.3	109.5	170.0	15.6	20.8	29.9	41.6	57.2																						
	Input Power Supply	Main Circuit R/S/T	Single/Three Phase AC 200 ~ 230V, -15~+10%			Three Phase AC 200 ~ 230V, -15~+10%						Three Phase AC 380~480V, ±10%																										
	Control Circuit r/s	Single Phase AC 200 ~ 230V, -15~+10%										DC 24V, ±10%																										
	Cooling System	Natural Air Cooling		Fan Cooling																																		
	Control of Main Circuit	Three-phase full-wave rectification IGBT- SVPWM Control(Sine-wave current drive way)																																				
	Feedback (Encoder Resolution)	Incremental type : 2500ppr / 8192ppr / 15-bit (ABS) / 17-bit																																				
	Panel and Operation Key	Main/ control circuit power indicator; 5 digital seven-segment display ; four function key.																																				
Internal Functions	Control Mode	Position (External pulse command), Position (Internal position command), Speed, Torque and Dual mode switching (Position/Speed, Speed/Torque, Position/ Torque)																																				
	Regeneration Brake	Built-in braking transistor and resistor / External braking resistor						Built-in braking transistor / External braking resistor		Built-in braking transistor and resistor / External braking resistor																												
	Dynamic Brake	Built-in dynamic braking; Power-off, Servo-off, Drive disable and Alarm occurred																																				
	Protection Function	16 Types of Alarm Functions																																				
	Communication Interface	RS-232 / RS-485 (Modbus protocol)																																				

*1 the max. torque is up to 240% while the motor horse power is the same as the servo drive.


Servo Drives for JSDAP-□□□□		200V Class										400V Class																		
		10A	15A	20A	30A	50A3	75A3	100A3	150A3	200A3	300A3	25B	35B	50B	75B	100B														
Position Control Mode	Command Source	External command/ Pulse command / 32-Stage internal register command																												
	External Command/ Pulse Input	Type	Positive/Negative Edge Trigger Type : Direction + Pulse, CW/CCW Pulse , Phase difference pulse (A Phase + B Phase)																											
		Waveform	Line Driver (+5V), Open Collector (+5 ~ +24V)																											
		Max. Frequency	4Mpps(Line Driver) / 200Kpps(Open Collector)																											
	Electronice Gear	$1/400 \leq A/B \leq 400$ (A=1 ~ 50000 : B=1 ~ 50000)																												
	Command Smoothing Constant	Ripple Time Constant : 0 ~ 10sec																												
	Final Position Tolerance (In Position)	0 ~ 50000 Pulse																												
Speed Control Mode	Forward Feedback on Gain Compensation	0 ~ 100 %																												
	Homing Function	Set by internal parameters																												
	Command Source	External analog Command / 3-Stage internal speed command																												
	External analog Command	Voltage Input Range	0 ~ ±10Vdc / 0 ~ 6000rpm (set by internal parameters)																											
		Input Impedance	10KΩ																											
	Speed Control Range	1 : 5000 (internal speed command) / 1 : 2000 (external analog command)																												
	Speed fluctuation Rate	±0.03% or less at Load fluctuation 0 to 100% (at Rated Speed) ±0.2% or less at power fluctuation ±10% (at Rated Speed) ±0.5% or less at ambient temperature fluctuation 0 °C to 50 °C (at Rated Speed)																												
Torque Control Mode	Command Smoothing Constant	Linear : 0 ~ 50sec ; S-curve : 0 ~ 5sec ; Ripple : 0 ~ 10sec																												
	Frequency Characteristics	800Hz (J _L =J _M)																												
	Torque Limit	External analog command / Set by internal parameters																												
	Zero Speed / Speed Reach Range	0 ~ 4500rpm (Set by internal parameters)																												
	Command Source	External analog command																												
	External analog command	Voltage Input Range	0 ~ ±10Vdc / 0 ~ ±600%																											
		Input Impedance	10KΩ																											
	Command Smoothing Constant	Linear : 0 ~ 50sec; Ripple : 0 ~ 10sec																												
	Speed Limit	External analog command / Set by internal parameters																												
	Torque Reach Range	0 ~ 300% (Set by internal parameters)																												

Servo Drives for JSDAP-□□□□			200V Class										400V Class				
			10A	15A	20A	30A	50A3	75A3	100A3	150A3	200A3	300A3	25B	35B	50B	75B	100B
Input/ Output Signal	Position Output	Output Type	Phase A, B, Z Line Drive /Phase Z Open Collector														
		Encoder Ratio	Pulse Output: 1 ~ encoder—pulse numbers (any arbitrary values set by Internal parameters)														
	Digital Input [NPN/ PNP]	Optional Input To 12 Ports	31 Types of Optional Functions														
	Digital Output [Photocoupler]	Fix Output to 4 Ports	Fix Output Alarm Code														
		Optional Output to 4 ports	17 Types of Optional Functions														
	Analog Monitor Output	Optional Output to 2 ports	12 Types of Optional Functions (0~±10Vdc)														
Environment	Installing Location		Indoor (avoiding direct sunshine)														
			no erosion air (avoiding oil gases, inflammable gas and dust)														
	Altitude		Sea level 1000m below														
	Temperature		Operating Temperature 0~ 50°C, storage Temperature: -20 ~ +65°C														
	Humidity		Operating, storage below 90% RH														
Certifications		CE Declaration	In compliance with EN61800-3 and EN61800-5-1														
		UL Certification	UL508C														


※ Dimensions for JSDAP-10A/15A/20A/30A




※ Dimensions for JSDAP-50A3 / 75A3 / 100A3 / 25B / 35B / 50B



※ Dimensions for JSDAP-150A3 / 75B / 100B




※ Dimensions for JSDAP-200A3 / 300A3



9-2 Specifications and Dimension for Servomotors

Description for Servo Motor Type Number



※ Standard Specifications for JSMA-PSC/PLC (200V Class)

Motor Mode	Symbol	Unit	JSMA-P□□□□□						
			SCP5A	SC01A	SC02A	SC04A	SC08A	LC03A	LC08A
Drive Model			10A	10A/15A	10A/15A	15A/20A	20A/30A	15A	20A
Rated Output	P _R	KW	0.05	0.1	0.2	0.4	0.75	0.3	0.75
Rated Torque	T _R	N · m	0.16	0.32	0.637	1.274	2.387	0.95	2.391
Max. Torque	T _{max}	N · m	0.48	0.95	1.911	3.82	7.161	2.861	7.164
Rated Speed	N _R	rpm	3000					3000	
Max. Speed	N _{max}	rpm	4500				3750	4500	3800
Rated Current	I _R	A	0.65	0.94	1.80	2.50	4.30	2.00	3.75
Max. Armature Current	I _{max}	A	1.95	2.82	5.40	7.50	12.90	6.00	11.25
Torque Constant	K _T	N · m/A	0.36	0.38	0.39	0.51	0.61	0.52	0.77
Rotor Moment of Inertia	J _M	Kg · cm ²	0.03	0.04	0.17	0.28	0.94	0.68	2.46
Armature Resistor	R _a	Ω	78.00	25.00	7.50	5.60	2.10	5.58	2.18
Armature Inductance	L _a	mH	78.0	35.0	16.2	14.5	8.6	11.6	7.7
Mechanical Time Constant	T _m	ms	2.70	0.94	0.90	0.69	0.81	1.98	1.67
Electrical Time Constant	T _e	ms	0.34	1.40	2.37	2.59	4.11	2.05	3.53
Weight(Standard)	W	kgw	0.48	0.70	1.03	1.37	2.47	1.59	3.05
Insulation Grade	—	—	Class B (130°C)		Class F (155°C)				
Operating Ambient Temp.	T	°C	0 ~ 40						
Operating Ambient Humidity	RH	%	<80					<90	<80
Storage Temp.	T	°C	-20 ~ 60						
Storage Humidity	RH	%	<80					<90	<80

1(kgf · cm)=0.0980665(N · m) ; 1(gf · cm · s²)=0.980665(kg · cm²)

※ Standard Specifications for JSMA-PM (200V Class)

Motor Mode	Symbol	Unit	JSMA-P□□□□						
			MA05A	MA10A	MA15A	MB10A	MB15A	MB20A	MB30A
Drive Model			20A	30A	50A3	20A	30A	30A	75A3
Rated Output	P _R	KW	0.55	1.00	1.50	1.00	1.50	2.00	3.00
Rated Torque	T _R	N · m	5.25	9.55	14.32	4.78	7.16	9.55	14.33
Max. Torque	T _{max}	N · m	15.76	28.65	42.96	14.33	21.49	28.65	42.69
Rated Speed	N _R	rpm	1000			2000			
Max. Speed	N _{max}	rpm	1500	1350	1250	2800		2500	
Rated Current	I _R	A	3.43	5.16	7.45	5.16	7.57	9.18	14.00
Max. Armature Current	I _{max}	A	10.30	15.50	22.35	15.50	22.71	27.50	42.00
Torque Constant	K _T	N · m/A	1.68	2.04	2.11	1.02	1.04	1.14	1.13
Rotor Moment of Inertia	J _M	Kg · cm ²	6.26	12.14	17.92	6.26	8.88	12.14	17.92
Armature Resistor	R _a	Ω	3.58	1.85	1.19	1.22	0.79	0.58	0.33
Armature Inductance	L _a	mH	18.3	12.1	8.4	6.7	4.7	3.8	2.1
Mechanical Time Constant	T _m	ms	1.19	0.81	0.72	1.09	0.98	0.80	0.70
Electrical Time Constant	T _e	ms	5.12	6.55	7.09	5.52	6.00	6.59	6.38
Weight (Standard)	W	kgw	6.49	10.16	13.87	6.47	8.08	10.16	13.87
Insulation Grade	—	—	Class B (130°C)						
Operating Ambient Temp.	T	°C	0 ~ 40						
Operating Ambient Humidity	RH	%	<90						
Storage Temp.	T	°C	-20 ~ 60						
Storage Humidity	RH	%	<90						

1(kgf · cm)=0.0980665(N · m) ; 1(gf · cm · s²)=0.980665(kg · cm²)

※ Standard Specifications for JSMA-PM (200V Class)

Motor Mode	Symbol	Unit	JSMA-P□□□□					
			MC10A	MC15A	MC20A	MC30A	MH05A	MH10A
Drive Model			30A	50A3	30A	75A3	20A	30A
Rated Output	P _R	KW	1.00	1.50	2.00	3.00	0.55	1.00
Rated Torque	T _R	N · m	3.20	4.78	6.37	9.55	3.50	6.40
Max. Torque	T _{max}	N · m	9.60	14.33	19.11	28.65	10.51	19.21
Rated Speed	N _R	rpm	3000			1500		
Max. Speed	N _{max}	rpm	3700		3850		2000	
Rated Current	I _R	A	4.96	7.06	9.50	14.00	2.98	5.00
Max. Armature Current	I _{max}	A	14.88	21.20	28.50	42.00	8.94	15.00
Torque Constant	K _T	N · m/A	0.72	0.74	0.74	0.75	1.29	1.41
Rotor Moment of Inertia	J _M	Kg · cm ²	4.60	6.26	8.88	12.54	6.26	12.14
Armature Resistor	R _a	Ω	1.02	0.65	0.40	0.25	2.31	0.95
Armature Inductance	L _a	mH	5.06	3.58	2.40	1.62	10.80	8.78
Mechanical Time Constant	T _m	ms	1.39	1.12	0.97	0.81	1.33	0.89
Electrical Time Constant	T _e	ms	4.96	5.48	6.00	6.57	4.68	9.28
Weight(Standard)	W	kgw	5.29	6.47	8.08	10.16	6.47	10.16
Insulation Grade	—	—	Class B (130°C)					
Operating Ambient Temp.	T	°C	0 ~ 40					
Operating Ambient Humidity	RH	%	<90					
Storage Temp.	T	°C	-20 ~ 60					
Storage Humidity	RH	%	<90					

1(kgf · cm)=0.0980665(N · m) ; 1(gf · cm · s²)=0.980665(kg · cm²)

※Standard Specifications for JSMA-PMH (200V Class)

Motor Mode	Symbol	Unit	JSMA-P□□□□					
			MH30A	MH44A	MH55A	MH75A	MH110A	MH150A
Drive Model			75A3	100A3	150A3	200A3	300A3	300A3
Rated Output	P _R	KW	3.00	4.40	5.50	7.50	11.00	15.00
Rated Torque	T _R	N · m	19.10	28.00	35.10	47.80	70.10	95.50
Max. Torque	T _{max}	N · m	49.50	71.50	89.60	122.60	179.00	204.00
Rated Speed	N _R	rpm	1500					
Max. Speed	N _{max}	rpm	2000					
Rated Current	I _R	A	15.00	22.50	28.50	38.00	58.00	78.00
Max. Armature Current	I _{max}	A	39.00	58.50	74.10	98.80	152.00	170.00
Torque Constant	K _T	N · m/A	1.27	1.24	1.23	1.26	1.21	1.22
Rotor Moment of Inertia	J _M	Kg · cm ²	39.99	51.44	63.52	93.94	160.94	222.20
Armature Resistor	R _a	Ω	0.18	0.12	0.09	0.05	0.03	0.02
Armature Inductance	L _a	mH	2.89	1.98	1.52	1.02	0.80	0.50
Mechanical Time Constant	T _m	ms	0.69	0.60	0.56	0.49	0.48	0.37
Electrical Time Constant	T _e	ms	16.12	16.81	17.24	18.96	26.77	29.12
Weight(Standard)	W	kgw	19.50	26.20	30.00	42.00	52.50	70.50
Insulation Grade	—	—	Class F (155°C)					
Operating Ambient Temp.	T	°C	0 ~ 40					
Operating Ambient Humidity	RH	%	<90					
Storage Temp.	T	°C	-20 ~ 60					
Storage Humidity	RH	%	<90					

1(kgf · cm)=0.0980665(N · m) ; 1(gf · cm · s²)=0.980665(kg · cm²)

※Standard Specifications for JSMA-PHH (200V Class)

Motor Mode	Symbol	Unit	JSMA-P□□□□			
			HH30A	HH44A	HH55A	HH75A
Drive Model			100A3	150A3	200A3	300A3
Rated Output	P _R	KW	3.00	4.40	5.50	7.50
Rated Torque	T _R	N · m	19.10	28.00	35.10	47.80
Max. Torque	T _{max}	N · m	49.50	71.40	89.60	122.60
Rated Speed	N _R	rpm	1500			
Max. Speed	N _{max}	rpm	3000			
Rated Current	I _R	A	23.00	33.20	42.10	58.00
Max. Armature Current	I _{max}	A	59.80	86.30	109.50	151.00
Torque Constant	K _T	N · m/A	0.83	0.84	0.83	0.82
Rotor Moment of Inertia	J _M	Kg · cm ²	39.99	53.02	63.52	93.94
Armature Resistor	R _a	Ω	0.08	0.05	0.04	0.02
Armature Inductance	L _a	mH	1.48	0.89	0.68	0.43
Mechanical Time Constant	T _m	ms	0.70	0.62	0.56	0.51
Electrical Time Constant	T _e	ms	18.75	16.54	17.46	18.00
Weight(Standard)	W	kgw	19.5	26.2	30.0	42.0
Insulation Grade	—	—	Class F (155°C)			
Operating Ambient Temp.	T	°C	0 ~ 40			
Operating Ambient Humidity	RH	%	<90			
Storage Temp.	T	°C	-20 ~ 60			
Storage Humidity	RH	%	<90			

$$1(\text{ kgf} \cdot \text{cm}) = 0.0980665(\text{N} \cdot \text{m}) \quad ; \quad 1(\text{gf} \cdot \text{cm} \cdot \text{s}^2) = 0.980665(\text{kg} \cdot \text{cm}^2)$$

※Standard Specifications for JSMA (400V Class)

Motor Mode	Symbol	Unit	JSMA-P□□□□			
			MB10B	MB15B	MB20B	MB30B
Drive Model			25B	25B	25B	35B
Rated Output	P _R	KW	1	1.5	2	3
Rated Torque	T _R	N · m	4.782	7.164	9.545	14.327
Max. Torque	T _{max}	N · m	14.327	21.492	28.645	42.693
Rated Speed	N _R	rpm	1500			
Max. Speed	N _{max}	rpm	2000			
Rated Current	I _R	A	2.58	4.36	5.78	8.9
Max. Armature Current	I _{max}	A	7.74	13.08	17.34	26.7
Torque Constant	K _T	N · m/A	2.06	1.80	1.76	1.78
Rotor Moment of Inertia	J _M	Kg · cm ²	6.26	8.88	12.14	17.92
Armature Resistor	R _a	Ω	5.38	2.39	1.45	1.07
Armature Inductance	L _a	mH	23	12	8.96	5.89
Mechanical Time Constant	T _m	ms	1.32	0.97	0.865	0.93
Electrical Time Constant	T _e	ms	4.28	5.02	6.18	5.5
Weight(Standard)	W	kgw	6.47	8.08	10.16	13.87
Insulation Grade	—	—	Class B (130°C)			Class F (155°C)
Operating Ambient Temp.	T	°C	0 ~ 40			
Operating Ambient Humidity	RH	%	<90			
Storage Temp.	T	°C	-20 ~ 60			
Storage Humidity	RH	%	<90			

$$1(\text{ kgf} \cdot \text{cm}) = 0.0980665(\text{N} \cdot \text{m}) \quad ; \quad 1(\text{gf} \cdot \text{cm} \cdot \text{s}^2) = 0.980665(\text{kg} \cdot \text{cm}^2)$$


Motor Mode	Symbol	Unit	JSMA-P□□□□			
			MH30B	MH44B	MH55B	MH75B
Drive Model			35B	50B	75B	100B
Rated Output	P _R	KW	3	4.4	5.5	7.5
Rated Torque	T _R	N · m	19.1	28.0	35.1	47.8
Max. Torque	T _{max}	N · m	47.8	70.0	87.8	119.5
Rated Speed	N _R	rpm	1500			
Max. Speed	N _{max}	rpm	2000			
Rated Current	I _R	A	8.0	11.5	16.0	22.0
Max. Armature Current	I _{max}	A	20.8	29.9	41.6	57.2
Torque Constant	K _T	N · m/A	2.39	2.43	2.19	2.17
Rotor Moment of Inertia	J _M	Kg · cm ²	43.70	61.77	77.98	112.20
Armature Resistor	R _a	Ω	0.64	0.38	0.20	0.12
Armature Inductance	L _a	mH	14.94	9.34	5.00	3.19
Mechanical Time Constant	T _m	ms	0.75	0.60	0.48	0.44
Electrical Time Constant	T _e	ms	23.45	24.51	25.63	26.82
Weight(Standard)	W	kgw	17.5	22.5	27.0	36.5
Insulation Grade	—	—	Class F (155°C)			
Operating Ambient Temp.	T	°C	0 ~ 40			
Operating Ambient Humidity	RH	%	<90			
Storage Temp.	T	°C	-20 ~ 60			
Storage Humidity	RH	%	<90			

$$1(\text{ kgf} \cdot \text{cm}) = 0.0980665(\text{N} \cdot \text{m}) \quad ; \quad 1(\text{gf} \cdot \text{cm} \cdot \text{s}^2) = 0.980665(\text{kg} \cdot \text{cm}^2)$$

※JSMA-PSC/PLC dimension diagram (200V Class)

200V Class													
Motor Mode			LZ φ	LA φ	LC	E	W	S φ	LB φ	QK	LE	LR	LL
JSMA-PL Series	Without Brake	LC03AB/H	5.5	90	76	2	5	14	70	20	3	30	113.4
		LC08AB/H	6.5	100	86	2	5	16	80	25	3	35	148
		LC08AB/H-0C	6.5	100	86	2	5	19	80	25	3	35	148
	With Brake	LC03AB/H	5.5	90	76	2	5	14	70	20	3	30	147.8
		LC08AB/H	6.5	100	86	2	5	16	80	25	3	35	183.2
		LC08AB/H-0C	6.5	100	86	2	5	19	80	25	3	35	183.2
JSMA-PS Series	Without Brake	SCP5AB/H	3.5	48	42	-	-	8	30	16	2.5	25.5	85.3
		SC01AB/H	3.5	48	42	-	-	8	30	16	2.5	25	106.8
		SC02AB/H	5.5	70	60	2	5	14	50	22	3	30	114.8
		SC04AB/H	5.5	70	60	2	5	14	50	22	3	30	132.8
		SC08AB/H	5.5	90	80	2.5	6	19	70	30	3	40	139
	With Brake	SC01AB/H	3.5	48	42	-	-	8	30	16	2.5	25	144.1
		SC02AB/H	5.5	70	60	2	5	14	50	22	3	30	147.3
		SC04AB/H	5.5	70	60	2.5	5	14	50	22	3	30	167.3
		SC08AB/H	5.5	90	80	2.5	6	19	70	30	3	40	172

Unit: mm




※ JSMA-PM/PH motor dimension diagram (200V Class)

200V Class												
Motor Mode			LZ φ	LA φ	LC	E	W	S φ	LB φ	LE	LR	LL
JSMA-PM JSMA-PH Series	Without Brake	MA05	9	145	130.4	2.5	6	22	110	6	58	163.8
		MH05	9	145	130.4	2.5	6	22	110	6	58	163.8
		MA10	9	145	130.4	2.5	6	22	110	6	58	213.8
		MB10	9	145	130.4	2.5	6	22	110	6	58	163.8
		MC10	9	145	130.4	2.5	6	22	110	6	58	148.8
		MH10	9	145	130.4	2.5	6	22	110	6	58	213.8
		MA15	9	145	130.4	2.5	6	22	110	6	58	263.8
		MB15	9	145	130.4	2.5	6	22	110	6	58	184.8
		MC15	9	145	130.4	2.5	6	22	110	6	58	163.8
		MB20	9	145	130.4	2.5	6	22	110	6	58	213.8
		MC20	9	145	130.4	2.5	6	22	110	6	58	184.8
		MB30	9	145	130.4	2.5	6	22	110	6	58	263.8
		MC30	9	145	130.4	2.5	6	22	110	6	58	213.8
		MH30	13.5	200	180	3	10	35	114.3	3.2	79	254
		MH44	13.5	200	180	3	10	35	114.3	3.2	79	283
		MH55	13.5	200	180	3	12	42	114.3	3.2	113	297
		MH75	13.5	200	180	3	12	42	114.3	3.2	113	382
		MH110	13.5	235	220	3	12	42	200	4	116	352
		MH150	13.5	235	220	4	16	55	200	4	116	429
		HH30	13.5	200	180	3	10	35	114.3	3.2	79	245
		HH44	13.5	200	180	3	10	35	114.3	3.2	79	273.5
		HH55	13.5	200	180	3	12	42	114.3	3.2	113	282.5
		HH75	13.5	200	180	3	12	42	114.3	3.2	113	371

Unit: mm

200V Class												
Motor Mode			LZ φ	LA φ	LC	E	W	S φ	LB φ	LE	LR	LL
JSMA-PM JSMA-PH Series	With Brake	MA05	9	145	130.4	2.5	6	22	110	6	58	218.3
		MH05	9	145	130.4	2.5	6	22	110	6	58	218.3
		MA10	9	145	130.4	2.5	6	22	110	6	58	268.3
		MB10	9	145	130.4	2.5	6	22	110	6	58	218.3
		MC10	9	145	130.4	2.5	6	22	110	6	58	203.3
		MH10	9	145	130.4	2.5	6	22	110	6	58	268.3
		MA15	9	145	130.4	2.5	6	22	110	6	58	318.3
		MB15	9	145	130.4	2.5	6	22	110	6	58	238.3
		MC15	9	145	130.4	2.5	6	22	110	6	58	218.3
		MB20	9	145	130.4	2.5	6	22	110	6	58	268.3
		MC20	9	145	130.4	2.5	6	22	110	6	58	238.3
		MB30	9	145	130.4	2.5	6	22	110	6	58	318.3
		MC30	9	145	130.4	2.5	6	22	110	6	58	268.3


Unit: mm



※ JSMA-PM/PH motor dimension diagram (400V Class)

400 Class												
Motor Mode			LZ φ	LA φ	LC	E	W	S φ	LB φ	LE	LR	LL
JSMA-PM JSMA-PH Series	Without Brake	MB10	9	145	130.4	2.5	6	22	110	6	58	163.8
		MB15	9	145	130.4	2.5	6	22	110	6	58	183.8
		MB20	9	145	130.4	2.5	6	22	110	6	58	213.8
		MB30	9	145	130.4	2.5	6	22	110	6	58	263.8
		MH30	13.5	200	180	3	10	35	114.3	3.2	79	221
		MH44	13.5	200	180	3	10	35	114.3	3.2	79	249
		MH55	13.5	200	180	3	12	42	114.3	3.2	113	275
		MH75	13.5	200	180	3	12	42	114.3	3.2	113	330
	With Brake	MB10	9	145	130.4	2.5	6	22	110	6	58	218.3
		MB15	9	145	130.4	2.5	6	22	110	6	58	238.3
		MB20	9	145	130.4	2.5	6	22	110	6	58	268.3
		MB30	9	145	130.4	2.5	6	22	110	6	58	318.3

Unit: mm






Appendix A: Accessories


Power Connectors

Part No.	Description	Model
JSSCNM04	For JSMA-S/L Series (50W~750W)	CAP: 172159-1 SCOKEt: 170362-1
JSSCNML04	For JSMA-M Series without brake (550W~3kW)	CONNECTOR: MS3108A20-4S MS3057-12A(SR)
JSSCNBL04	For JSMA-MM/MH Series without brake (3kW~15kW)	CONNECTOR: MS3108A32-17S MS3057-20A(SR)
JSSCNML07	For JSMA-M Series with brake (550W~3kW)	CONNECTOR: MS3108A20-15S MS3057-12A(SR)

Power Cables

Part No.	L (Meter)	Description	Model
JSSLM001	1	For JSMA-S/L Series (50W~750W)	 <p>CAP: 172159-1 SCOKEt: 170362-1</p>
JSSLM003	3		
JSSLM005	5		
JSSLM010	10		
JSSLM015	15		
JSSLM020	20		
JSSMLM001	1	For JSMA-M Series without brake (550W~3kW)	 <p>CONNECTOR: MS3108A20-4S MS3057-12A(SR)</p>
JSSMLM003	3		
JSSMLM005	5		
JSSMLM010	10		
JSSMLM015	15		
JSSMLM020	20		
JSSBLM001	1	For JSMA-MM/MH Series without brake (3kW~15kW)	 <p>CONNECTOR: MS3108A32-17S MS3057-20A(SR)</p>
JSSBLM003	3		
JSSBLM005	5		
JSSBLM010	10		
JSSBLM015	15		
JSSBLM020	20		



Battery Module (For JSDA+ Series)

Part No.	Description	Model
JSSBAT	For absolute encoder	



Encoder Connectors

Part No.	Description	Model
JSSCNP09	For JSMA-S/L Series	CONNECTOR: 172161-1 TERMINAL: 170361-1
JSSCNPL09	For JSMA-M Series	CONNECTOR: MS3108A20-18S MS3057-12A(SR)
JSSCN20P	For JSDA ⁺ Series (CN2)	CONNECTOR: 10320-52A0-008 10120-3000PE
JSSECN09P	For JSDE ⁺ Series (CN2)	CONNECTOR: D-SUB9PM Male COVER: DC-9CT Screw



Encoder Cables (For JSDA⁺ Series 15-bit / 17-bit encoders)

Part No.	L (Meter)	Description	Model
JSSLG001	1	For JSMA-S/L Series and JSDA ⁺ Amplifiers	 <p>JSSLG</p> <p>CONNECTOR: 172161-1 TERMINAL: 170361-1</p> <p>CONNECTOR: 10320-52A0-008 10120-3000PE</p>
JSSLG003	3		
JSSLG005	5		
JSSLG010	10		
JSSLG015	15		
JSSLG020	20		
JSSMLG001	1	For JSMA-M Series and JSDA ⁺ Amplifiers	 <p>JSSMLG</p> <p>CONNECTOR: 10320-52A0-008 10120-3000PE</p> <p>CONNECTOR: MS3108A20-18S MS3057-12A(SR)</p>
JSSMLG003	3		
JSSMLG005	5		
JSSMLG010	10		
JSSMLG015	15		
JSSMLG020	20		


Encoder Cables (For JSDA⁺ Series 2500ppr / 8192ppr encoders)

Part No.	L (Meter)	Description	Model
JSSLP001	1	For JSMA-S / L / T Series and JSDA+ Series	 <p>L</p> <p>CONNECTOR: 172161-1 TERMINAL: 170361-1</p> <p>CONNECTOR: 10320-52A0-008 10120-3000PE</p>
JSSLP003	3		
JSSLP005	5		
JSSLP010	10		
JSSLP015	15		
JSSLP020	20		
JSSMLP001	1	For JSMA-S / L / T Series and JSDA+ Series	 <p>L</p> <p>CONNECTOR: 10320-52A0-008 10120-3000PE</p> <p>CONNECTOR: MS3108A20-18S MS3057-12A(SR)</p>
JSSMLP003	3		
JSSMLP005	5		
JSSMLP010	10		
JSSMLP015	15		
JSSMLP020	20		



Encoder Cables (For JSDE⁺ Series 2500ppr / 8192ppr encoders)

Part No.	L (Meter)	Description	Model
JSSEL001	1	For JSMA-S/L Series and JSDE ⁺ Series	 <p>L</p> <p>CONNECTOR: 172161-1 TERMINAL: 170361-1</p> <p>CONNECTOR: D-SUB 9P Male COVER: DC-9CT Screw</p>
JSSEL003	3		
JSSEL005	5		
JSSEL010	10		
JSSEL015	15		
JSSEL020	20		
JSSEMLP001	1	For JSMA-M Series and JSDE ⁺ Series	 <p>L</p> <p>CONNECTOR: D-SUB 9PM Male COVER: DC-9CT Screw</p>
JSSEMLP003	3		
JSSEMLP005	5		
JSSEMLP010	10		
JSSEMLP015	15		
JSSEMLP020	20		


I/O Signal Connector

Part No.	Description	Model
JSSCN50P	For JSDA ⁺ Series (CN1)	 CONNECTOR: 10350-52A0-008 10150-3000PE
JSSECN25P	For JSDE ⁺ Series (CN1)	 CONNECTOR: D-SUB 25P M Male COVER: DC-25 CT Screw

Terminal Block (For JSDA⁺ Series)

Part No.	L (Meter)	Description	Model
JSSTBC0P5	0.5	For JSDA ⁺ Series	 Shell kit: 10350-3210-000*2 SCSI II: 10150-600PE*2
JSSTBC001	1		
JSSTBC002	2		
JSSTB50P	—	For JSDA ⁺ Series	

Terminal Block (For JSDE⁺ Series)

Part No.	L (Meter)	Description	Model
JSSETBC0P5	0.5	For JSDE ⁺ Series	 CONNECTOR: D-SUB 25P M Male × 2 COVER: DC-25 CT Screw × 2
JSSETBC001	1		
JSSETBC002	2		
JSSETB25P	—	For JSDE ⁺ Series	

Communication Cables

Part No.	L (Meter)	Description	Model
JSSDTC001	1	Connection to PC	 D-9S — MD-8P
JSSDTC002	2		
JSSDTD001	1	Connection to Drive	 MD-8P — MD-8P
JSSDTD002	2		

Appendix B Battery Module

For the absolute encoder, JSDAP series has an optional battery module, which is divided into two parts of the battery and installation, described as below.


Battery Specification

NO.	ITEMS	Characteristics
1	Nominal Capacity	2400 mAh (Continuosly discharged under 2mA current till 2.0V end-point voltage at the temperature of $23^{\circ}\text{C} \pm 3^{\circ}\text{C}$)
2	Nominal Voltage	3.6V
3	Operating Temperature Range	-40~+85°C
4	Max. Continuos Discharge Current	100mA
5	Structures	Thiony chloride, lithium anode, acetylene black, separator, and stainless steel cell shell etc.
6	Weight for reference	19.0g


Installation

When customers received the battery modules, battery and casing has been installed properly, please refer to the following steps to install.


- The drive has a black lightning symbol protective cover, such as the circle marked.





b. Remove the protective cover




c. Removed the protective cover, the customers can find the two connectors and select one of them, reference the attached manual which was in battery module for installation. Another connector is reserved for replacing the battery that is in order to avoid power supply outage.



- d. When the battery module is installed, pay attention to installation marked on the drive, as below.



- e. Installation completed.





TECO Electric & Machinery Co., Ltd.

10F., No.3-1, Yuancyu St., Nangang District,
Taipei City 115, Taiwan
Tel :+886-2-6615-9111
Fax :+886-2-6615-0933

Distributor

<http://globalsa.teco.com.tw/tw>
<http://www.taian-technology.com>

Ver.04 2015.05

This manual may be modified when necessary because of improvement of the product, modification, or changes in specifications, This manual is subject to change without notice.