

SPOD

Comtech is an ISO9001 / AS9100 Registered Company





PS 1, PS 1.5, and PS 2 C, X, or Ku-Band Outdoor Amplifier Installation and Operation Manual

Part Number MN-SPODPSX

Revision 2

December 14, 2022

IMPORTANT NOTE: The information contained in this document supersedes all previously published information regarding this product. Product specifications are subject to change without prior notice.



Copyright © 2022 Comtech Satellite Network Technologies. All rights reserved. Printed in the USA. Comtech Satellite Network Technologies, 2114 West 7th Street, Tempe, Arizona 85281 USA, 480.333.2200, FAX: 480.333.2161

Revision History

Rev	Date	Description		
1		nitial Release.		
2	11/8/2022	Editorial		



Table of Contents

TABLE OF CONTENTS	
LIST OF TABLES	V
LIST OF FIGURES	v
PREFACE	
About this Manual	
Related Documents	
Disclaimer	
Conventions and References	i
	· · · · · · · · · · · · · · · · · · ·
	i
	i
	i
Č	
Electrical Safety Notice	ii
Installation Guidolines Pegarding Power	Line Qualityii
installation Guidelines Regarding Fower	Line Quantyii
Product Support	i\
Comtook Hoodquarters	iv
Contecti Headquarters	
Warranty Policy	iv
	i\
	\
CHAPTER 1. INTRODUCTION	1–1
4.4	
1.1 Overview	1–1
1.2 Functional Description	1–1
1.3 Features	1–2
	1–2
	1–2
•	1–2
	1-2 evel) and OPS1-2
1.3.5 Over Drive (Excessive KF Output L	.ever) and OP31-2
1.4 Summary of Specifications	1–4
	1–
1.4.2 Environmental	1–6



1.4.3	Physical	1–6
1.5	Dimensional Envelopes	1–7
	SPOD PS 1 Dimensional Envelopes	
	SPOD PS 1.5 Dimensional Envelopes	
	SPOD PS 2 Dimensional Envelopes	
	·	
CHAPT	ER 2. SYSTEM CONNECTIONS, INSTALLATION AND STARTUP	2–1
	Cabling Connection Types	
	Coaxial Cable Connections	
2.1.2	Circular Cable Connections	2–2
2.2	SPOD SSPA Cabling Connections	2–2
	nterface Connectors	
2.3.1	Connector 'J1 L-BAND IN' or 'J1 Tx IN'	2–4
2.3.2	Connector 'J2 RF OUT'	2–4
2.3.3	Connector 'J3 POWER IN' (AC Power Mains)	2–5
2.3	.3.1 SPOD PS 1, PS 1.5 'J3 POWER IN' (AC Power Main)	2–5
2.3	.3.2 SPOD PS 2 'J3 POWER IN' (AC Power Main)	2-5
2.3.4	Connector 'J3 POWER IN' (DC Power Mains)	2–6
_	.4.1 SPOD PS 1 'J3 POWER IN' (DC Power Main)	
	.4.2 SPOD PS 1.5 'J3 POWER IN' (DC Power Main)	
	.4.3 SPOD PS 2 'J3 POWER IN' (DC Power Main)	2–7
	.4.4 SPOD PS 2 'J3 POWER IN' 48VDC Power Main Option	
	Connector 'J6 COM1' (Remote Communications and Discrete Control Port)	
	Connector 'J9 OUTPUT SAMPLE' (PS 2 Only)	
2.3.7	Ground Connector	2–9
2.4	SPOD Standalone Installation	2–10
2.5 F	Power-up the SPOD	2–10
CHAPT	ER 3. UPDATING FIRMWARE	3–1
3.1	Overview	3–1
	Getting Started: Prepare for the Firmware Download	
	Download and Extract the Firmware Update	
	·	
3.4 F	Perform the FTP Upload Procedure	3–9
CHAPT	ER 4. ETHERNET-BASED REMOTE PRODUCT MANAGEMENT	4–1
4.1 I	ntroduction	4–1
4.2 E	Ethernet Management Interface Protocols	4–2



.4–2
.4–2
.4–3
.4–3
.4–6
4 0
.4–8
.4–8
.4–9
1–10
4–10 4–10
4–10 4–10
4–10 4–11
 4–11
4–11
1–12
4–12
4–12
4–13
4–14
4–15
4–15
4–17
4–18
4–18
4–20 4–22
4–22 4–23
- 23 4–23
4–24
4–24
4–25
4–26
4–28
4–30
.5–1
.5–1
<i>-</i> 4
.5–1
.5–1
.5–2
.5–2
.5–2
.5–3
.5–3
.5–4
.5–5
.5–5 .5–5



5.3.2 EIA-232	5–6
5.3.3 Basic Protocol	5–6
5.3.4 Packet Structure	5–6
5.3.4.1 Start of Packet	
5.3.4.2 Target Address	
5.3.4.3 Address Delimiter	
5.3.4.4 Instruction Code	
5.3.4.6 Optional Message Arguments	
5.3.4.7 End of Packet	
5.1 Remote Commands and Queries	5–10
APPENDIX A. 1:1 REDUNDANCY	A–1
A.1 SPOD Redundancy Operation Overview	A–1
A.2 1:2 Redundancy Mode (FUTURE)	A–1
A.3 1:1 Redundancy Mode	A-1
A.3.1 Ethernet-based Monitor and Control	
A.3.1.1 1:1 Redundant System Setup (Using a Single Ethernet Interface)	
A.3.2 Serial-based Monitor and Control	
A.3.2.1 Applicable Serial-based Redundancy Commands and Queries	A-5
A.4 Troubleshooting Connectivity Issues	A-5
A.5 1:1 Redundancy System Cabling and Installation	A-7
A.6 Redundancy System Assembly Kit Examples	A-9
A.6.1 SPOD PS 1 1:1 Redundancy Kit Examples	
A.6.2 SPOD PS 1.5 1:1 Redundancy Kit Examples	
A.6.3 SPOD PS 2 1:1 Redundancy Kits	A–34
APPENDIX B. CABLE DRAWINGS	B-1
B.1 Overview	B-1
B.2 Control and Data Cables	
B.2.1 Serial Interface Cable	
B.2.2 Ethernet Interface Cable	
B.2.3 19-Pin COMMS Cable (100')	
B.2.4 19-Pin COMMS Cable (250')	
B.2.5 Redundant Loop Cable – Tx Only	B-7
B.3 RF Cables	
B.3.1 RF Cable (Type 'N')	B-9
APPENDIX C. MAINTENANCE	C 4
AFFLINDIA C. IVIAIN I ENANCE	ا — ا



C.1	Overview	C–1
C.2	Clean the SPOD PS 1 Heat Sinks	C–2
C.3	Clean the SPOD PS 1.5 Heat Sinks	C–5
C.4	Clean the SPOD PS 2 Heat Sinks	C–9
	List of Tables	
Table	2-1. 'J2 RF OUT' Output Types	2–4
	2-2. SPOD PS 1/PS 1.5 'J3 POWER IN' Pin Assignments	
	2-3. SPOD PS 2 'J3 POWER IN' Pin Assignments	
	2-4. SPOD PS 1 'J3 POWER IN' Pin Assignments	
	2-6. SPOD PS 2 'J3 POWER IN' Pin Assignments	
	2-7. SPOD PS 2 'J3 POWER IN' 48VDC Pin Assignments	
	2-8. SPOD 'J6 COM1' Pin Assignments	
Table	A-1. Parts List for KT-0000104 PS 1 1:1 Redundancy Kit	A–10
	A-2. Parts List for KT-0000090 PS 1 C-Band Coax Output 1:1 Redundancy Kit	
	A-3. Parts List for KT-0000089 PS 1 Ku-Band 1:1 Redundancy Kit	
	A-4. Parts List for KT-0000170 PS 1 X-Band 1:1 Redundancy Kit	
	A-5. Parts List for KT-0020526 PS 1.5 C-Band DC Option 1:1 Redundancy Kit A-6. Parts List for KT-0000060 PS 1.5 Ku-Band 1:1 Redundancy Kit	
	A-7. Parts List for KT-0000091 PS 2 C-Band 1:1 Redundancy Kit	
	A-8. Parts List for KT-0000254 PS 2 Ku-Band 1:1 Redundancy Kit	
	List of Figures	
Figure	2 1-1. Comtech SPOD Outdoor Amplifiers	1–1
	e 1-2. SPOD PS 1 C-Band Dimensional Envelope (Coax Output)	
	e 1-4. SPOD PS 1 Ku-Band Dimensional Envelope	
Figure	e 1-5. SPOD PS 1.5 C-Band Dimensional Envelope (DC Option Shown)	1–12
Figure	e 1-6. SPOD PS 1.5 X-Band Dimensional Envelope	1–13
_	e 1-7. SPOD PS 1.5 Ku-Band Dimensional Envelope	
	e 1-8. SPOD PS 2 C-Band Dimensional Envelope	
_	e 1-9. SPOD PS 2 X-Band Dimensional Envelope	
	e 1-10. SPOD PS 2 Ku-Band Dimensional Envelopee 2-1. Coaxial Connector Example	
	e 2-2. Circular Connector Example	
	2-3. SPOD PS 1 Connections	
Figure	e 2-4. SPOD PS 1.5 Connections	2–3
	2-5. SPOD PS 2 Connections	
	e 2-6. SPOD Ground Connections	
	e 2-7. PL/12319-1 Universal Pole Mounting Kit	
	e 2-8. KT-0000095 PS 1/PS 1.5 Single Unit Mounting Kit e 2-9. KT-0000125 PS 2 Single Unit Mounting Kit	
	e 2-10. KT-0020524 PS 2 Single Unit Shelf Style Mounting Kit	
J	, , , , , , , , , , , , , , , , , , , ,	



Figure 4-1. SPOD Home Home Page	4–12
Figure 4-2. Home Contact Page	
Figure 4-3. Home Support Page	4–14
Figure 4-4. Admin Access Page	4–15
Figure 4-5. Admin SNMP Page	4–17
Figure 4-6. Config Amplifier Page	4–18
Figure 4-7. Config Utility Page	4–20
Figure 4-8. Config Redundancy Page	
Figure 4-9. Status Summary Page	
Figure 4-10. Status Status page	
Figure 4-11. Status FETs page	
Figure 4-12. Status Events Page	4–26
Figure 4-13. Status Statistics page	
Figure 4-14. Status Graphs Page	
Figure A-1. Ethernet-based M&C using Comtech Kit KT-0000203	
Figure A-2. Serial-based M&C using Comtech Kit KT-0020518	
Figure A-3. Typical SPOD 1:1 Redundancy System Cabling Schematic	
Figure A-4. KT-0000104 PS 1 C-Band 1:1 Redundancy Kit (Exploded View)	
Figure A-5. KT-0000104 PS 1 C-Band 1:1 Redundancy Kit (Assembled Isometric View)	
Figure A-6. KT-0000090 PS 1 C-Band Coax Output 1:1 Redundancy Kit (Assembled Isometric View) Figure A-6. KT-0000090 PS 1 C-Band Coax Output 1:1 Redundancy Kit Example (Exploded Isometric View)	
View)Views	
Figure A-7. KT-0000090 PS 1 C-Band Coax Output 1:1 Redundancy Kit Example (Assembled I	
View)View)	
Figure A-8. KT-0000089 PS 1 Ku-Band 1:1 Redundancy Kit Example (Exploded Isometric View	
Figure A-9. KT-0000089 PS 1 Ku-Band 1:1 Redundancy Kit Example (Assembled Isometric Views A-40. KT-0000470 RS 4 V Band 4:4 Redundancy Kit Example (Explanded Isometric Views)	
Figure A-10. KT-0000170 PS 1 X-Band 1:1 Redundancy Kit Example (Exploded Isometric View	
Figure A-11. KT-0000170 PS 1 X-Band 1:1 Redundancy Kit (Assembled Isometric View)	
Figure A-12. KT-0020526 PS 1.5 C-Band DC Option 1:1 Redundancy Kit (Assembled View)	
Figure A-13. KT-0020526 PS 1.5 C-Band DC Option 1:1 Redundancy Kit (Exploded View, Step	s 1 & 2) A-
28	۵) ، ۵
Figure A-14. KT-0020526 PS 1.5 C-Band DC Option 1:1 Redundancy Kit (Exploded View, Step	
Figure A-15. KT-0000060 PS 1.5 Ku-Band 1:1 Redundancy Kit Example (Exploded Isometric V	
Figure A-16. KT-0000060 PS 1.5 Ku-Band 1:1 Redundancy Kit Example (Assembled Isometric	View)A-
32	
Figure A-17. KT-0000091 PS 2 C-Band 1:1 Redundancy Kit Example (Exploded Isometric View	
Figure A-18. KT-0000091 PS 2 C-Band 1:1 Redundancy Kit Example (Assembled Isometric Vie	
Figure A-19. KT-0000254 PS 2 Ku-Band 1:1 Redundancy Kit Example (Exploded Isometric Vie	
Figure A-20. KT-0000254 PS 2 Ku-Band 1:1 Redundancy Kit Example (Assembled Isometric Vi	
Figure A-21. 1:1 or 1:2 Free Standing Unitstrut Kit (Comtech Kit KT-0020827)	
Figure A-22. PS 2 C-Band 1:1 Redundancy Free Standing Example Using Kit KT-0020827 (Ass	sembled
Isometric View)	A-42
Figure A-23. PS 2 C-Band 1:1 Redundancy Free Standing Example Using Kit KT-0020827 (Ass	sembled
Views)	
Figure B-1. Serial Interface Cable (Comtech P/N CA-0020526, part of KT-0020518)	B-3
Figure B-2. Ethernet Interface Cable (Comtech P/N CA-0000352, part of KT-0000203)	
Figure B-3. COMMS Cable, 100' (Comtech P/N CA-0000318)	
Figure B-4. COMMS Cable, 250' (Comtech P/N CA-0000543)	
Figure B-5. Redundant Loop Cable – Tx Only (Comtech P/N CA-0020655)	
Figure B-6. 1/4" Heliax Coaxial Cable (CA/3722-X)	
Figure C-1. Comtech SPOD Outdoor Amplifiers	
Figure C-2. SPOD Web Server Interface 'Status Trending Graphs' Page Temperature Graph	
Figure C-3. SPOD PS 1 Shroud Screw Locations	
Figure C-4. Remove the Fan Shroud	
Figure C-5. Disconnect the Fan Power Supply	
Figure C-6. SPOD PS 1 Heat Sink Locations	
COURT OF CALCULATION CONTROL OF CONTROLS	·4



Figure C-7. Reconnect the Fan Power Supply	C–4
Figure C-8. SPOD PS 1.5 Shroud Screw Locations	C–6
Figure C-9. Remove the Fan Shroud	
Figure C-10. Disconnect the Fan Power Supplies	C–7
Figure C-11. SPOD PS 1.5 Heat Sink Location	
Figure C-12. Reconnect the Fan Power Supplies	C–8
Figure C-13. SPOD PS 2 Shroud Screw Locations	C-10
Figure C-14. Remove the Fan Shroud	C-10
Figure C-15. Disconnect the Fan Power Supplies	C-11
Figure C-16. SPOD PS 2 Heat Sink Locations	C-11
Figure C-17. Reconnect the Fan Power Supplies	C–12



Units of Measurement

Unit / Symbol	Definition		
Ω	Ohm		
Α	Ampere		
AC	Alternating Current		
bps	bits per second		
°C	Celsius (degrees)		
DC	Direct Current		
Hz	Hertz		
kHz	kiloHertz		
dB	decibel		
dBc	Decibels relative t the carrier		
dBm	Decibel-milliwatts		
°F	Fahrenheit (degrees)		
Kbps	Kilobit per second		
kg	kilogram		
ksps	Kilosymbols per second		
lbs.	pounds		
mA	Milli-amp		
Mbps	Megabit per second		
MHz	Megahertz		
mm	millimeter		
ms	millisecond		
Msps	Megasymbols per second		
mW	milliwatt		
in.	inch		
Pps	Packets per second		
ųF	100 micro-farads		
W	Watt		
V	Volt		



PREFACE

About this Manual

This manual provides installation and operation information for the Comtech Satellite Network Technologies, Inc. (Comtech) SPOD family of Outdoor Amplifiers. This manual is an informational document intended for the persons responsible for the operation and maintenance of the SPOD PS 1. PS 1.5, or PS 2.



This manual supersedes Comtech Manuals MN/SPOD.IOM Rev. 2 and MN-SPODPS2 Rev. 1 in their entirety. This manual documents the latest product availability and functionality; additionally, this replacement publication (Comtech P/N MN-SPODPSX) has been prepared in accordance with the latest Comtech Technical Publications Standards and Practices.

Related Documents

- Comtech CLC-10 Handheld Terminal M&C Accessory for LPOD or SPOD PS 1, PS 1.5, PS 2 User's Guide (Comtech P/N MN-CLC10)
- Comtech LPODnet M&C Netbook Accessory for LPOD or SPOD PS 1, PS 1.5, PS 2 Operation Manual (Comtech P/N MN-LPODNET)

Disclaimer

Comtech has reviewed this manual thoroughly in order to provide an easy-to-use guide to this equipment. All statements, technical information, and recommendations in this manual and in any guides or related documents are believed reliable, but the accuracy and completeness thereof are not guaranteed or warranted, and they are not intended to be, nor should they be understood to be, representations or warranties concerning the products described. Further, Comtech reserves the right to make changes in the specifications of the products described in this manual at any time without notice and without obligation to notify any person of such changes.

If there are any questions regarding this equipment or the information in this manual, please contact Comtech Product Support.

Preface i MN-SPODPSX



Conventions and References

Patents and Trademarks

See all of Comtech's Patents and Patents Pending at http://patents.Comtechefdata.com. Comtech acknowledges that all trademarks are the property of the trademark owners.

Warnings, Cautions, and Notes



A <u>WARNING</u> informs you about a possible hazard that MAY CAUSE DEATH or SERIOUS INJURY.



A CAUTION informs you about a possible hazard that MAY CAUSE INJURY or PROPERTY DAMAGE.



A NOTE gives you important information about a task or the equipment.



A <u>REFERENCE</u> directs you to additional information about a task or the equipment.

Examples of Multi-Hazard Notices





Recommended Standard Designations

The Electronic Industries Association (EIA) designations replace Recommended Standard (RS) Designations. References to the old designations may appear when depicting actual text (e.g., RS-232) as displayed on the Web Server pages or CLI (serial Command Line Interface) for the unit. All other references in the manual address the EIA designations.

Preface ii MN-SPODPSX



Electrical Safety Notice



CAUTION – Neutral Fusing: Double pole/neutral fusing is used on the prime power supply input.

This equipment is designed to minimize exposure of personnel to hazards. For further information, contact Comtech Customer Support Department. The operators and technicians must:

- Know how to work around, with, and on high voltage equipment.
- Exercise every precaution to ensure personnel safety.
- Exercise extreme care when working near high voltages.
- Be familiar with the warnings presented in this manual.

Installation Guidelines Regarding Power Line Quality



Comtech has become familiar with the varying quality of the AC power grid around the world. Observing the following installation guidelines should help ensure a reliable installation.

- **Surge suppression:** High voltage surges can cause failure of the power supply. These surges are typically caused by circuit switching on the main AC power grid, erratic generator operation, as well as lightning strikes. While the SPOD does have built in surge suppression, if unit installation occurs in a location where there may be questionable power grid quality, Comtech recommends installation of additional power conditioning/surge suppression at the power junction box.
- **Grounding:** The SPOD provides a grounding terminal. This is provided to allow grounding of the SPOD to the antenna's grounding network. All installed components should be grounded to a common grounding point at the antenna.
- **Electrical welding:** If welding needs to take place at the antenna, disconnect all cables from the SPOD except for the ground wire. Cap all RF connections with terminations. This will prevent damage to the input/output circuitry of the SPOD.
- **Lightning:** Lightning strikes on or around the antenna will generate extremely high voltages on all cables connected to the SPOD. Depending on the severity of the strike, the SPOD's internal surge protection combined with the recommended external suppression may protect the SPOD's power supply. However, if the installation will be in an area with a high probability of lightning strikes, Comtech recommends the installation of surge suppression on the RF and IF cables. One source of these suppressors is PolyPhaser (2Hwww.polyphaser.com).

Preface iii MN-SPODPSX



Product Support

For all product support, please call:

- +1.240.243.1880
- +1.866.472.3963 (toll free USA)

Comtech Headquarters

http://www.Comtechefdata.com

Comtech Satellite Network Technologies, Inc. 2114 West 7th Street
Tempe, Arizona USA 85281
+1.480.333.2200

Warranty Policy

Comtech products are warranted against defects in material and workmanship for a specific period from the date of shipment, and this period varies by product. In most cases, the warranty period is two years. During the warranty period, Comtech will, at its option, repair or replace products that prove to be defective. Repairs are warranted for the remainder of the original warranty, or a 90-day extended warranty, whichever is longer. Contact Comtech for the warranty period specific to the product purchased.

For equipment under warranty, the owner is responsible for freight to Comtech and all related customs, taxes, tariffs, insurance, etc. Comtech is responsible for the freight charges only for return of the equipment from the factory to the owner. Comtech will return the equipment by the same method (i.e., Air, Express, Surface) as the equipment was sent to Comtech.

All equipment returned for warranty repair must have a valid RMA number issued prior to return and be marked clearly on the return packaging. Comtech strongly recommends all equipment be returned in its original packaging.

Comtech's obligations under this warranty are limited to repair or replacement of failed parts, and the return shipment to the buyer of the repaired or replaced parts.

Limitations of Warranty

The warranty does not apply to any part of a product that has been installed, altered, repaired, or misused in any way that, in the opinion of Comtech, would affect the reliability or detracts from the performance of any part of the product, or is damaged as the result of use in a way or with equipment that had not been previously approved by Comtech.

The warranty does not apply to any product or parts thereof where the serial number or the serial number of any of its parts has been altered, defaced, or removed.

The warranty does not cover damage or loss incurred in transportation of the product.

Preface iv MN-SPODPSX



The warranty does not cover replacement or repair necessitated by loss or damage from any cause beyond the control of Comtech, such as lightning or other natural and weather related events or wartime environments.

The warranty does not cover any labor involved in the removal and or reinstallation of warranted equipment or parts on site, or any labor required to diagnose the necessity for repair or replacement.

The warranty excludes any responsibility by Comtech for incidental or consequential damages arising from the use of the equipment or products, or for any inability to use them either separate from or in combination with any other equipment or products.

A fixed charge established for each product will be imposed for all equipment returned for warranty repair where Comtech cannot identify the cause of the reported failure.

Exclusive Remedies

Comtech's warranty, as stated is in lieu of all other warranties, expressed, implied, or statutory, including those of merchantability and fitness for a particular purpose. The buyer shall pass on to any purchaser, lessee, or other user of Comtech's products, the aforementioned warranty, and shall indemnify and hold harmless Comtech from any claims or liability of such purchaser, lessee, or user based upon allegations that the buyer, its agents, or employees have made additional warranties or representations as to product preference or use.

The remedies provided herein are the buyer's sole and exclusive remedies. Comtech shall not be liable for any direct, indirect, special, incidental, or consequential damages, whether based on contract, tort, or any other legal theory.

Preface v MN-SPODPSX



Notes:		



Chapter 1. INTRODUCTION

1.1 Overview

Comtech's SPOD family of C-, X-, and Ku-Band Outdoor Amplifiers – referred to throughout this manual as the **SPOD** – deliver their rated power, guaranteed, to the transmit waveguide flange at the 1 dB compression point. The SPOD provides a cost effective, more reliable replacement for Traveling Wave Tube (TWT) amplifiers in satellite communications.



Figure 1-1. Comtech SPOD Outdoor Amplifiers

1.2 Functional Description

The compact size and weight of the SPOD lends itself to any installation with limited available mounting space. These include ship-borne antenna systems, small "flyaway" systems, and Satellite News Gathering (SNG) installations.

As shown in Figure 1-1, the SPOD is available in three models: the PS 1, PS 1.5, and PS 2. Each SPOD consists of a Comtech Solid-State Power Amplifier (SSPA) module with a Monitor/Control Processor (MCP), a power supply, and one or two fan assemblies. The amplifier features a Comtech low-loss combining technique and MCP-based temperature-versus-gain compensation.

The SPODs are configured as SSPAs (RF in, RF out). The PS 1 and PS 1.5 models have available power levels to 100W; the PS 2 model can be configured at power levels to 250W.

Introduction 1–1 MN-SPODPSX



1.3 Features

1.3.1 The Solid-State Advantage

The SPOD is constructed with gallium arsenide field-effect transistors (GaAs FETs) to ensure high reliability. With third-order intermodulation products that are 4 to 6 dB better than TWT ratings, the Comtech unit replaces TWTs with saturated power levels of up to twice the SPOD's rated output. The SPODs also provide mean time between failures (MTBF) that is four to five times greater than the typical TWT MTBF.

1.3.2 Enhanced Standard Features

The SPOD comes equipped with features that other manufacturers offer only as options. Included in the base price are temperature compensation, sample ports (on the PS 2 only), power monitor, power factor corrected supply, and full Ethernet- or serial-based remote monitor and control (M&C) capabilities.

1.3.3 Built-in Redundancy Controller

The SPOD has the ability to function as a 1:1 (one backup for one primary) redundant controller in a redundant mode without the use of an external device. The optional redundancy configuration is implemented by attaching a ganged waveguide/coax transfer switch(es) to the input and output connectors of the amplifiers, using a combination coaxial cable and waveguide kit.

When the backup SPOD is commanded into redundant mode, it monitors the online SPOD for faults and status, and automatically maintains a configuration based on the online unit.

A faulted online unit may be disconnected and replaced without affecting the online power amplifier.

1.3.4 Data Logging Capability

The SPOD includes a built-in data logging capability to enhance system maintainability. By recording critical operational parameters (e.g., temperature, output power, mute status, etc.) at time stamped intervals, you can quickly gather intelligence not only about the unit itself, but also about the unit's operational environment.

1.3.5 Over Drive (Excessive RF Output Level) and OPS

The unit's specified linear rated output power level, Plinear, can be found in the unit datasheet. Although the unit may be capable, operating beyond its Plinear level is discouraged. As the input drive level is increased, excessive distortion of the output sets in which will result in degraded throughput and possible adjacent carrier interference.

Although the best protection against potentially degrading overdrive conditions is user attention and vigilance to the input and output levels as mentioned above, Comtech has implemented an overdrive protection software option1 or "OPS", which will help protect the unit from damage and warn the user of gross overdrive conditions.

Introduction 1–2 MN-SPODPSX



However, it will be noted that the OPS feature is only an aid in preventing and notifying the operator of overdriven conditions, it does not guarantee protection of hardware or continuous unit operation in the "usable power" region in extreme or persistent overdriven conditions.

The overdrive protection setting is on the amplifier webpage and the information is displayed on the Status webpage. The settings are also available via serial commands (RS232/RS485). With the overdrive protection mode activated, the operator can set a predetermined activation level (P1dB rated to P1dB - 10) which will trigger the OPS to start attenuation if the forward power is greater than the activation level. The OPS will continue to attenuate in 0.1 or 0.25dB step2 until the forward power is less than the activation level. If the OPS cannot lower forward power below the activation level because there is no available attenuation left or the amount of attenuation added has exceeded 10dB, then the OPS will consider this an overdrive fault and enable the mute setting.

The overdrive protection mode has 5 states: N/A, IDLE, ACTIVE, ALARM and FAULT.

- When the overdrive protection mode is not selected (off), "N/A" is displayed in the status.
- When the overdrive protection mode is on and the forward power has not exceeded the activation level, "IDLE" is displayed in the status.
- When the overdrive protection mode is on and OPS has added attenuation to lower the forward power below the activation level and amount of attenuation is less than 2.2dB, "ACTIVE" is displayed in the status.
- When the overdrive protection mode is on and OPS has added more than 2.2dB of attenuation to lower the forward power below the activation level, "ALARM" is displayed in the status.
- When the overdrive protection mode is on and the software could not attenuate the forward power below the activation level or the amount of attenuation has exceeded 10dB, "FAULT" is displayed in the status.

The OPS also has a 'release feature'. If overdrive protection status state was "ACTIVE" or "ALARM" and then the forward power has decrease by 5dB less than the activation level, the OPS will return the customer attenuation setting to its previous level when the overdrive protection mode status state was at "IDLE." This release feature will only activate if the mute is disabled, and the AMP is on. The software is assuming the operator will correct the overdrive condition by lowering the input power level.

It will also be noted when the overdrive protection mode is in "FAULT" state, that the OPS will not change the "FAULT" state if the mute is enabled, or the amplifier is off. The OPS is assuming the operator will correct the overdrive condition by lowering the input power level and then will disable the mute. Furthermore, if an overdrive 'FAULT' has occurred it will be noted that in a redundancy configuration, that there will be no switch over between the online and offline units while there is overdrive fault.

Notes:

- 1) Overdrive protection is only available in Firmware version 1.6.1 or newer.
- 2) 0.1 or 0.25dBm steps are dependent on hardware options.

Introduction 1–3 MN-SPODPSX



1.4 Summary of Specifications

1.4.1 Characteristics

Band	Package size/Band	RF Output Frequency (see Note)	P _{sat} (Typical)	P1dB (Guaranteed)
	PS1/C		45 dBm (32 W)	44 dBm (25 W)
	PS1/C		47 dBm (50 W)	46 dBm (40 W)
	PS1/C	Standard:	48 dBm (60 W)	47 dBm (50 W)
	PS1.5/C	5.850 – 6.425 GHz Optional:	49 dBm (80 W)	48.5 dBm (70 W)
C Dand	PS1.5/C	5.850 – 6.650 GHz	50.4 dBm (110 W)	49.5 dBm (90 W)
C-Band	PS1.5/C	5.850 – 6.725 GHz	51 dBm (125 W)	50 dBm (100 W)
	PS2/C	InSat C:	51 dBm (125 W)	50 dBm (100 W)
	PS2/C	- 6.725 - 7.025 GHz	51.8 dBm (150 W)	51 dBm (125 W)
	PS2/C		53 dBm (200 W)	52.5 dBm (175 W)
	PS2/C		54 dBm (250 W)	53dBm (200 W)
	PS1/X		45 dBm (32 W)	44 dBm (25 W)
	PS1/X		47 dBm (50 W)	46 dBm (40 W)
	PS1/X		48 dBm (60 W)	47 dBm (50 W)
	PS1.5/X		49 dBm (80 W)	48.5 dBm (70 W)
V Dand	PS1.5-X	7.900 – 8.400 GHz	50.4 dBm (110 W)	49.5 dBm (90 W)
X-Band	PS1.5/X		51 dBm (125 W)	50 dBm (100 W)
	PS2/X		51 dBm (125 W)	50 dBm (100 W)
	PS2/X		51.8 dBm (150 W)	51 dBm (125 W)
	PS2/X		53 dBm (200 W)	52.5 dBm (175 W)
	PS2/X		54 dBm (250 W)	53dBm (200 W)
	PS1/Ku		43 dBm (20 W)	42 dBm (16 W)
	PS1/Ku		45 dBm (32 W)	44 dBm (25 W)
	PS1/Ku	Standard: 14.00 – 14.50 GHz Optional: 13.75 – 14.50 GHz	46 dBm (40 W)	45 dBm (32 W)
Ku-Band	PS1.5/Ku		47 dBm (50 W)	46 dBm (40 W)
	PS1.5/Ku		48 dBm (60 W)	47 dBm (50 W)
	PS2/Ku		50 dBm (100 W)	49 dBm (80 W)
	PS2/Ku		51 dBm (125 W)	50 dBm (100 W)

Note: Allow 1 dB degradation from 13.75 to 14.0 GHz and 6425 to 6725 MHz.

Introduction 1–4 MN-SPODPSX



Parameter		Specification		
Gain Min (Typical) All Power Levels		70 (75dB)		
Input Power Supply Requirements		90-264 VAC, 47-63 Hz, Power Factor Corrected, .96 (typical) (48 VDC optional)		
Max Input level (no d	lamage)	+10 dBm		
Gain Adjust		20 dB in 0.25 dB steps		
Gain Flatness		±1.5 dB full band (optional ±2.0 dB full band, -50 to +55 °C) ±0.30 dB per 40 MHz (optional ±0.50 dB per 40 MHz, -50 to +55 °C)		
Gain variation over t	emp	±1.5 dB max, -40 to +55 °C (±2.0 dB max, -50 to +55 °C)		
Input or Output Retu	rn Loss	19.1 dB (1.25:1 VSWR)		
Noise Figure		8 to 10 dB typical,15 dB max. @ min. attenuation		
RF Mute Isolation		-60 dB min		
AM/PM Conversion		2° typical, 3.5° max. @ Rated P1dB output power		
Third-order Intermodulation Level (2 tones, @ -3 dB Total Backoff from P1 dB (-6 dBc SCL), Δ 1MHz)		-30 dBc typical, -25 dBc Guaranteed		
	Harmonics	-50 dBc @ Prated – 3 dB		
Spurious Level	Non-Harmonics Related	-65 dBc max.		
	Linear	± 0.03 ns/MHz		
Group delay variation	Parabolic	±0 .003 ns/MHz ²		
	Ripple	± 1.0 ns pk-pk		
Data Logging Parameters		Non-Volatile RAM: Capacity 30 days @ 90 minute intervals. Includes: RF Output Power Mute Status Heatsink Temperature		

Introduction 1–5 MN-SPODPSX



1.4.2 Environmental

Parameter			Specification	
Temperature	Operating	Standard	-40° to 122°F (-40° to 50°C)	
		Optional	-40° to 140°F (-40° to 60°C) or -58° to 131°F (-50° to 55°C)	
	Storage		-67° to 167°F (-55° to 75°C)	
Humidity			100% condensing rain 2" per hour	
Altitude			10,000 AMSL (derate 2ºC/1000 ft. AMSL	
Shock			Normal commercial shipping and handling	

1.4.3 Physical

Parameter		Specification		
	PS 1	47 lba (0.4 las) Naminal		
Weight	PS 1.5	17 lbs. (9.1 kg) Nominal		
	PS 2	47 lbs. (21.32 kg) Nominal		
Dimensions	PS 1	12.65 x 6.26 x 7.37 in. (321.3 x 159 x 187.2 mm)		
(excluding connectors)	PS 1.5	12.78 x 6.14 x 7.05 in. (324.6 x 156 x 179.1 mm)		
See Sect. 1.5 for all dimensional envelope figures	PS 2	16.18 x 8.80 x 9.78 in. (427 x 223.5 x 248.4 mm)		
	RF Input	Type 'N' Female		
		PS 1 C-Band: Type 'N' Female		
	DE Outmit	PS 1.5, PS 2 C-Band : CPR137G		
Connectors	RF Output	PS 1, PS 1.5, PS 2 X-Band : CPR112G		
		PS 1, PS 1.5, PS 2 Ku-Band: WR75G		
	M&C/Ethernet/ Redundancy Switches	19-pin MS style (single integrated cable assembly available, dependent upon configuration)		



1.5 Dimensional Envelopes

Notes:

Typical for all figures in each subsection, all dimensions are in inches. Bracketed dimensions, where shown, are in metric units (mm).

Unless otherwise noted, all figures depict AC Option, Waveguide Output units.

Subsection / Product	FIGURE	DESCRIPTION	
	1-2	PS 1 C-Band Dimensional Envelope (Coaxial Output)	
1.5.1 SPOD PS 1	1-3	PS 1 X-Band Dimensional Envelope	
	1-4	PS 1 Ku-Band Dimensional Envelope	
	1-5	PS 1.5 C-Band Dimensional Envelope (DC Option Shown)	
1.5.2 SPOD PS 1.5	1-6	PS 1.5 X-Band Dimensional Envelope	
	1-7	PS 1.5 Ku-Band Dimensional Envelope	
	1-8	PS 2 C-Band Dimensional Envelope	
1.5.1 SPOD PS 2	1-9	PS 2 X-Band Dimensional Envelope	
	1-10	PS 2 Ku-Band Dimensional Envelope	

Introduction 1–7 MN-SPODPSX



BLANK PAGE



1.5.1 SPOD PS 1 Dimensional Envelopes




Figure 1-2. SPOD PS 1 C-Band Dimensional Envelope (Coax Output)

Introduction 1–9 MN-SPODPSX






Figure 1-3. SPOD PS 1 X-Band Dimensional Envelope

Introduction 1–10 MN-SPODPSX






Figure 1-4. SPOD PS 1 Ku-Band Dimensional Envelope

Introduction 1–11 MN-SPODPSX



1.5.2 SPOD PS 1.5 Dimensional Envelopes




Figure 1-5. SPOD PS 1.5 C-Band Dimensional Envelope (DC Option Shown)

Introduction 1–12 MN-SPODPSX






Figure 1-6. SPOD PS 1.5 X-Band Dimensional Envelope

Introduction 1–13 MN-SPODPSX






Figure 1-7. SPOD PS 1.5 Ku-Band Dimensional Envelope

Introduction 1–14 MN-SPODPSX



1.5.3 SPOD PS 2 Dimensional Envelopes




Figure 1-8. SPOD PS 2 C-Band Dimensional Envelope

Introduction 1–15 MN-SPODPSX






Figure 1-9. SPOD PS 2 X-Band Dimensional Envelope

Introduction 1–16 MN-SPODPSX






Figure 1-10. SPOD PS 2 Ku-Band Dimensional Envelope

Introduction 1–17 MN-SPODPSX



Notes:			
	 <u> </u>		

Introduction 1–18 MN-SPODPSX



Chapter 2. SYSTEM CONNECTIONS, INSTALLATION AND STARTUP

2.1 Cabling Connection Types

2.1.1 Coaxial Cable Connections



Figure 2-1. Coaxial Connector Example


The SPOD SSPA uses Type 'N' coaxial cables. Type 'N' Coaxial cables (plugs) and their mating connectors (jacks/sockets) are available in a *threaded coupling* style (**Figure 2-1**). The jack for this coupling style features external threads. The plug shell features internal threads and has either a knurled outer surface (to permit hand tightening of the connection) or hex flats (to accommodate torqued installation).

Connection Instructions – Engage the plug onto the jack threads, and then turn the plug clockwise until it is fully threaded onto the jack. Do not over-tighten the connection.



2.1.2 Circular Cable Connections

The circular connectors provided on the SPOD SSPA accommodate weatherproof outdoor applications. The connector pairs (**Figure 2-2**) feature a sleeve lock configuration, with an array of pins (male side) coupled to mating sockets (female side).



Feature	Description	
1	Primary Alignment features	
2	Secondary Alignment features	
3	Sleeve Lock features	

Figure 2-2. Circular Connector Example

Connection Instructions – Engage all of the alignment and lock features between the male connector (on the interconnection cable) and female socket.

To install the male connector into the female connector, do these steps:

- 1) Engage the primary and secondary alignment tabs on the male connector with the mating cutouts on the female socket.
- 2) Push the male connector into the female socket.
- 3) Turn the male connector sleeve clockwise until the sleeve lock cutouts engage fully with the female socket tabs and you hear a "click" sound.





2.2 SPOD SSPA Cabling Connections

The SPOD SSPA external connectors provide all necessary connections between the SPOD PS 1 (**Figure 2-3**), PS 1.5 (**Figure 2-4**), or PS 2 (**Figure 2-5**) units and other equipment. Additionally:

- Detailed installation and operational information for using SPODs in 1:1 redundancy configurations is provided in **Appendix A. 1:1 REDUNDANCY**.
- Information on the SPOD's remote M&C functionality via Ethernet is provided in Chapter 4.
 ETHERNET-BASED REMOTE PRODUCT MANAGEMENT.
- Information on the SPOD's remote M&C functionality via serial-based commands and queries is provided in CHAPTER 5. SERIAL-BASED REMOTE PRODUCT MANAGEMENT.






Figure 2-3. SPOD PS 1 Connections




Figure 2-4. SPOD PS 1.5 Connections




Figure 2-5. SPOD PS 2 Connections



2.3 Interface Connectors

2.3.1 Connector 'J1 | L-BAND IN' or 'J1 | Tx IN'





PS 1/PS 1.5

PS₂

The RF input connector is a Type 'N' female connector, labeled 'J1 | LBAND IN' on the SPOD PS 1 and PS 1.5 units, or 'J1 | Tx IN' on the SPOD PS 2 unit. Typical input levels (-30 dBm) depend on desired output power and unit attenuation. To prevent damage to the SPOD, RF input levels should not exceed +15 dBm.

2.3.2 Connector 'J2 | RF OUT'



WARNING! For safety reasons, never look directly into the waveguide output.

The 'J2 | RF OUT' connector may be a waveguide or coaxial interface – the type of interface used depends on the SPOD unit and/or frequency range of the unit, as described in Table 2-1 and as shown in Figure 2-3, Figure 2-4, or Figure 2-5.

Table 2-1. 'J2 | RF OUT' Output Types

Unit	Frequency Band	Output Type	FIGURE
	С	Type 'N' Female (Coaxial)	
PS 1	X	CPR112G (Waveguide)	2-3
	Ku	WR75G (Waveguide)	
	С	CPR137G (Waveguide)	
PS 1.5	X	CPR112G (Waveguide)	2-4
	Ku	WR75G (Waveguide)	
	С	CPR137G (Waveguide)	
PS 2	Х	CPR112G (Waveguide)	2-5
	Ku	WR75G (Waveguide)	



2.3.3 Connector 'J3 | POWER IN' (AC Power Mains)



WARNING! For safety reasons, TAKE CARE TO note that the 'J3' AC power connection pin assignments for EACH SPOD unit are not the same. Failure to CAREFULLY review the information provided IN THE SECTIONS THAT FOLLOW MAY RESult in product damage or personal injury.

For all SPOD units, the prime power input requirement is as follows:

- 90-264 VAC
- 47-63 Hz
- The power supply is power factor corrected. The total power required from the prime power supply depends on the unit used. See **Sect. 1.4 Summary of Specifications**.

2.3.3.1 SPOD PS 1, PS 1.5 'J3 | POWER IN' (AC Power Main)



The mating connector specification and pin assignments (**Table 2-2**) unique to the SPOD PS 1 and PS 1.5 AC power interfaces are as follows:

Mating Connector: Comtech P/N CN/MS-STPG03F02 (ITT Cannon KPT06B-12-35).

Table 2-2. SPOD PS 1/PS 1.5 'J3 | POWER IN' Pin Assignments

Pin	n Description	
А	LINE (L1)	
В	NEUTRAL (L2)	
С	GND	

2.3.3.2 SPOD PS 2 'J3 | POWER IN' (AC Power Main)



The mating connector specification and the pin assignments (**Table 2-3**) unique to the SPOD PS 2 AC power interface are as follows:

Mating Connector: Comtech P/N CN/MS-STPG03F07 (Glenair ITS-3106F20-19SF7).

Table 2-3. SPOD PS 2 'J3 | POWER IN' Pin Assignments

Pin	Description	
Α	GND	
В	NEUTRAL (L2)	
С	LINE (L1)	



2.3.4 Connector 'J3 | POWER IN' (DC Power Mains)



WARNING! FOR SAFETY REASONS, TAKE CARE TO NOTE THAT THE 'J3' DC POWER CONNECTION PIN ASSIGNMENTS FOR EACH SPOD UNIT ARE NOT THE SAME. FAILURE TO CAREFULLY REVIEW THE INFORMATION PROVIDED IN THE SECTIONS THAT FOLLOW MAY RESULT IN PRODUCT DAMAGE OR PERSONAL INJURY.

For all SPOD units, the prime power input requirement is 38-72 VDC. The total power required from the prime power supply depends on the unit used. See Sect. 1.4 Summary of Specifications.

2.3.4.1 SPOD PS 1 'J3 | POWER IN' (DC Power Main)



The mating connector specification and the pin assignments (**Table 2-4**) unique to the SPOD PS 1 DC power interface are as follows:

Mating Connector: Comtech P/N CN/STPG04F01 (Glenair IPT06E-12-4-SSR-F7).

Table 2-4. SPOD PS 1 'J3 | POWER IN' Pin Assignments

Pin	SPOD PS 1 Assignment	
Α	V+	
В	GND	
С	V-	
D	NO CONNECT	

2.3.4.2 SPOD PS 1.5 'J3 | POWER IN' (DC Power Main)



The mating connector specification and the pin assignments (**Table 2-5**) unique to the SPOD PS 1.5 DC power interface are as follows:

Mating Connector: Comtech P/N CN-0020517 (MS3116E-14-5S(476), Amphenol PT06E-14-5S(476)).

Table 2-5. SPOD PS 1.5 'J3 | POWER IN' Pin Assignments

Pin	SPOD PS 1.5 Assignment
Α	+48V
В	+48V
С	-48V
D	-48V
E	GND



2.3.4.3 SPOD PS 2 'J3 | POWER IN' (DC Power Main)



The mating connector specification and the pin assignments (**Table 2-6**) unique to the SPOD PS 2 DC power interface are as follows:

Mating Connector: Comtech P/N CN/CA3106E2222SB (ITT Cannon CA3106E22-22SB).

Table 2-6. SPOD PS 2 'J3 | POWER IN' Pin Assignments

Pin	SPOD PS 2 Assignment
А	V+
В	NO CONNECT
С	NO CONNECT
D	V-

2.3.4.4 SPOD PS 2 'J3 | POWER IN' 48VDC Power Main Option

The connector type and mating connector specification and the pin assignments (**Table 2-7**) unique to the SPOD PS 2 48 VDC power interface option are as follows:

Unit Connector Type: Comtech P/N CN-0000288 (ITT Cannon CA3102E20-15SB-F80A232).

Supplied Mating Connector: Comtech P/N CN-0000289 (ITT Cannon CA3106E20-15SB-F80A232).

Table 2-7. SPOD PS 2 'J3 | POWER IN' 48VDC Pin Assignments

Pin	SPOD PS 2 Assignment
А	V+
В	V+
С	NO CONNECT
D	NO CONNECT
Е	V-
F	V-
G	GROUND (Note 2)

Notes:

- 1) Use 12 AWG wire to each of the appropriate pins, according to the individual pin assignments.
- 2) As an alternative, make the ground connection to the unit's external ground stud.



2.3.5 Connector 'J6 | COM1' (Remote Communications and Discrete Control Port)





PS 1/PS 1.5 PS 2

The 'J6 | COM 1' discrete control connector is the primary input for the Monitor and Control (M&C) of the SPOD. It is a 19-pin circular connector, type MS3112E14-19S. The pinout specification is contained in Table 2-8.

Mating connector: MS3116J14-19P or ITT KPT06J14-19P.

Table 2-8. SPOD 'J6 | COM1' Pin Assignments

Pin	Name	Description
Α	RS485_+RX	
В	RS485RX	
С	RS485_+TX	
D	RS485TX	
Е	RS232_RD	Pin 3 of DB9 female connector
F	Ethernet TX+	Pin 3 of RJ45 female connector
G	RS232_TD	Pin 2 of DB9 female connector
Н	Ethernet TX-	Pin 6 of RJ45 female connector
J	TX/RX Switch Drive 1 Pos	Not for customer use
K	GND	Ground (also Pin 5 of DB-9F connector)
L	SUMFLT In	Open when faulted, else +5VDC
М	SUMFLT Out	When faulted, tied to Pin K, else open
N	TX Switch Pos 1 Ind	Online/Offline indication
Р	RX Switch Pos 1 Ind	Not for customer use
R	+24V	Not for customer use
S	System Mute Control	When AUX=1, unit is muted until this pin is tied to ground (Pin 'K'). When tied to ground, the unit unmutes. See the AUX remote command in Chapter 5. SERIAL-BASED REMOTE PRODUCT MANAGEMENT.
Т	Switch Common	GND reference for Pin N
U	Ethernet RX-	Pin 2 of RJ45 female connector
V	Ethernet RX+	Pin 1 of RJ45 female connector



2.3.6 Connector 'J9 | OUTPUT SAMPLE' (PS 2 Only)



The 'J9 | OUTPUT SAMPLE' port is a Type 'N' female connector available only on the PS 2 unit. It provides a nominal -40 dB sample of the output signal. A calibration label is provided near the connector that shows the actual coupling values vs. frequency.

2.3.7 Ground Connector



A #10-32 stud is provided at the locations shown in **Figure 2-6** for connecting a common chassis ground among equipment.




Figure 2-6. SPOD Ground Connections



2.4 SPOD Standalone Installation

Several kits are available from Comtech to mount and install Standalone or 1:1 Redundancy SPODs, depending on the type of unit ordered and its operational frequency.

Figures on the pages that follow illustrate available Standalone mounting kits:

FIGURE	Comtech PART NO.	DESCRIPTION
2-7	PL/12319-1	Universal Pole Mounting Kit
2-8	KT-0000095	PS 1/PS 1.5 Single Unit Mounting Kit
2-9	KT-0000125	PS 2 Single Unit Mounting Kit
2-10	KT-0020524	PS 2 Single Unit Shelf Style Mounting Kit

See **Appendix A. 1:1 REDUNDANCY** for the available assembly kit options for 1:1 SPOD redundancy configurations.

See **Appendix B. CABLE DRAWINGS** for information pertaining to the cables that are available for use with the SPOD in Standalone or 1:1 Redundancy operation.


2.5 Power-up the SPOD



WARNING! NEVER TURN THE UNIT ON WITHOUT PROPER WAVEGUIDE TERMINATION ON THE 'J2 | RF OUT' PORT. INDIVIDUALS CAN BE EXPOSED TO DANGEROUSLY HIGH ELECTROMAGNETIC LEVELS.

The SPOD does not have a 'Power On/Off' switch. It is powered ON by connecting the 'J3 | **POWER IN'** connector to the appropriate prime power source. The Mute or Transmit status of the SPOD automatically comes up in the last stored state (factory default = Transmit on, not muted).








This kit accommodates a pole diameter (OD) of up to 13.00" (33.02 cm) maximum.

	PL/12319-1 Universal Pole Mounting Kit		
ITEM	QTY	Comtech PART NO.	DESCRIPTION
1	1	N/A	BRACKET, UNISTRUT (SHOWN FOR CLARITY ONLY, INCLUDED IN Comtech P/N FP/BR0078 BRACKET MODIFICATION POLE MOUNTING KIT)
2	1	FP/BR0072	BRACKET, STRAP TENSIONER
3	1	FP/BR0070	BRACKET, STRAP-TERMINATION POLE MOUNTING KIT
4	1	FP/BR0071	BRACKET, 1-1/4 STRAP (TRIM LENGTH AS REQUIRED)
5	1	FP/BR0069	BRACKET, STRAP-FIXED, POLE MOUNTING KIT
6	2	HW/M8X1.25X25HEXSS	BOLT, HEXHEAD, M8X1.25X25, SS
7	7	HW/M8FLATSS	WASHER, FLAT, M8 SS, METRIC
8	7	HW/M8LOCKSS	LOCK WASHER, SPLIT, M8, SS, METRIC
9	2	HW/M8SPRINGNUT	SPRINGNUT, M8X1.25
10	5	HW/M8X1.25MMHEXNUT SS	NUT, HEX M8X1.25X16MM, SS
11	2	HW/BLK-PIPE2-8	PIPE, BLOCK

Figure 2-7. PL/12319-1 Universal Pole Mounting Kit






KT-0000095 PS 1/PS 1.5 Single Unit Mounting Kit			
ITEM	QTY	Comtech PART NO.	DESCRIPTION
1	1	FP-0000534	BRACKET, MOUNTING, PS 1
2	1	FP/BR0078	BRACKET MODIFICATION POLE MOUNTING KIT
3	2	HW/1/4-20X1/2FH	SCREW, 1/4-20 X 1/2 FH PHIL, 82, UCUT, SS
4	2	HW-000070	SCREW, HEX, SERR FLANGE HD, 3/8-16 x 3/4, SS
5	2	HW/3/8SPRINGNUT	SPRINGNUT, 3/8-16, SHORT SPRING, SS (P3300)

Figure 2-8. KT-0000095 PS 1/PS 1.5 Single Unit Mounting Kit






KT-0000125 SPOD PS 2 Single Unit Mounting Kit			
ITEM	QTY	Comtech PART NO.	DESCRIPTION
1	2	FP-0000677	SS BRACKET, MOUNTING, PS 2
2	1	FP/BR0078	BRACKET MODIFICATION POLE MOUNTING KIT
3	2	HW-000070	SCREW, HEX, SERR FLANGE HEAD, 3/8-16 x 3/4, S.S
4	2	HW/3/8SPRINGNUT	SPRINGNUT, 3/8-16, SHORT SPRING, SS (P3300)
5	4	HW/5/16-18X3/4B	BOLT, HEX HEAD, 5/16-18 X 3/4, SS
6	4	HW/5/16-SPLIT	LOCK WASHER, SPLIT, 5/16
7	4	HW/5/16-FLT	WASHER, FLAT, 5/16

Figure 2-9. KT-0000125 PS 2 Single Unit Mounting Kit





KT-0020524 PS 2 Single Unit Shelf Style Mounting Kit						
ITEM	QTY	Comtech PART NO.	DESCRIPTION			
1	1	FP-0020545	BRACKET, MOUNTING, PS 2			
2	2	HW/5/16-FLT	FLAT WASHER, 5/16			
3	2	HW/5/16-SPLIT	LOCK WASHER, SPLIT 5/16			
4	2	HW/5/16-18X3/4B	BOLT, HEX HEAD, 5/16-18 X 3/4 LG			
5	4	HW/3/8-FLT	FLAT WASHER, 3/8			
6	4	HW/3/8-SPLIT	LOCK WASHER, SPLIT 3/8			
7	2	HW/3/8-16X1B	BOLT, HEX HEAD, 3/8-16 X 1 LG			
8	2	HW/3/8-16X1.25B	BOLT, HEX HEAD, 3/8-18 X 1.25 LG			

Figure 2-10. KT-0020524 PS 2 Single Unit Shelf Style Mounting Kit



Chapter 3. UPDATING FIRMWARE

3.1 Overview



TO ENSURE OPTIMAL PERFORMANCE, IT IS IMPORTANT TO OPERATE THE SPOD WITH ITS LATEST AVAILABLE FIRMWARE.

Comtech's SPOD family of Outdoor Amplifiers are factory-shipped with the latest version of operating firmware. Firmware updates may be applied to an SPOD system without having to remove it from operation. If you need to update the product firmware, you may download the update from the Comtech Web site (www.comtechefdata.com). You may also receive the firmware update archive file via e-mail from Comtech Product Support.

The SPOD Firmware Update process is as follows:

- Download the firmware update archive file via the Internet to a user-supplied Microsoft Windows®-compatible PC such as Comtech's optional LPOD*net* (right). The LPOD*net* is also used for Ethernet-based Remote Product Management/Monitor and Control (M&C).
- Use Comtech's optional CLC-10 Handheld Terminal M&C Accessory Kit (Comtech Kit KT-0020518) (right) for serial-based Remote Product Management/M&C.
- Alternately, use an adapter cable to directly connect the SPOD to the serial port of a user-supplied Microsoft Windows®-compatible PC such as the LPODnet.
- Extract the firmware update files from the archive download file, and then transfer the files from the User PC to the SPOD via File Transfer Protocol (FTP).






3.2 Getting Started: Prepare for the Firmware Download


1) First, identify the firmware number and its version number.

A. User-supplied items needed:

- A Microsoft Windows-based PC equipped with available serial and Ethernet ports, a compatible Web browser (e.g., Internet Explorer), and a terminal emulator program (e.g., Tera Term or HyperTerminal) if needed. Optionally, Comtech's optional LPOD*net* (part of M&C Netbook Accessory Kit Comtech Kit KT-0000203).
 - Your serial connection may use either a user-fabricated adapter cable to connect the User PC serial port to the SPOD, or the optional CLC-10 Handheld Terminal (part of M&C Accessory Kit (Comtech Kit KT-0020518). The following diagram depicts use of the CLC-10 for 1:1 Redundant or Standalone serial connection:




1:1 REDUNDANCY APPLICATIONS



Updating Firmware 3–2 MN-SPODPSX



O Your Ethernet connection may use either the CAT5 Ethernet adapter cable (Comtech P/N CA-0000352) to directly connect the User PC Ethernet port to the SPOD, or the optional LPODnet M&C Netbook Accessory Kit (Comtech Kit KT-0000203). The following diagram depicts use of the LPODnet for 1:1 Redundant or Standalone Ethernet connection:



STANDALONE APPLICATIONS

B. On the User PC – If not using the CLC-10, configure the terminal emulator program if applicable.



Refer to your terminal emulator program HELP feature or user guide for operating and configuration instructions.

Configure the utility program serial port communication and terminal display operation:

- 38400 bps (Baud Rate)
- 8 Data Bits
- 1 Stop Bit

LPODnet SAMSUNG NB30 PLUS NETBOOK (Comtech P/N PP-0000134)

- Parity = NO
- Port Flow Control = NONE
- Display New line Rx/Tx: CR

- Local Echo = ON
- C. On the SPOD Power up the unit. Your power connection varies depending on your ordered unit.



See Sect. 2.3.3 Connector 'J3 | POWER IN' (AC Power Mains) or Sect. 2.3.4 Connector 'J3 | POWER IN' (DC Power Mains) in this manual for your specific power connectors.

Updating Firmware 3–3 MN-SPODPSX




- D. Obtain the firmware information via one of the following methods:
 - If using serial remote control, you may use the terminal emulator program or the CLC-10 to execute remote commands and queries with the SPOD. The firmware revision levels can be obtained with the following remote queries:
 - o Abbreviated: <0/SWR? (returns basic Boot, Bulk1 and Bulk2 information)
 - Detailed: <0/FRW? (returns complete Boot, Bulk1 and Bulk2 information)



See Chapter 5. SERIAL-BASED REMOTE PRODUCT MANAGEMENT for more information on remote commands/queries.

• If using the Web Server Interface, the Bootrom, Image1 and Image2 firmware loads may be viewed using the Firmware Information section of the 'Config | Utility' page, or the 'Status | Status' page.





See Chapter 4. ETHERNET-BASED REMOTE PRODUCT MANAGEMENT for more information on using the SPOD Web Server Interface

2) Next, create a temporary folder (subdirectory) on the User PC for the firmware archive download.



Drive letter 'c:' is used in these examples. Any valid, writable drive letter can be used.


Typical for all tasks: Type the command without quotes, and then press Enter to execute.

There are several ways you may use create a temporary folder on a Windows-based PC:

- A. Use the Windows Desktop to create and rename the temporary folder.
 - Right-click anywhere on the desktop to open the popup submenu, and then select
 New > Folder to create the new, temporary folder on the desktop.
 - Right-click on the new folder and then select 'Rename' from the popup submenu. Rename this folder to "temp" or some other convenient, unused name.

Updating Firmware 3–4 MN-SPODPSX






B. Use Windows Explorer to create and rename the temporary folder.

- Select **File > New > Folder** to create the new, temporary folder in the active location.
- Right-click the 'New Folder' folder name, and then rename this folder to "temp" or some other convenient, unused name.



C. Use the 'Run' and 'Browse' windows to create and rename the temporary folder.

- Select [Start] on the Windows taskbar and then click the Run... icon. The 'Run' window will open.
- Click [Browse] in the 'Run' window. The 'Browse' window will open.
- Click the **Create New Folder** icon in the '**Browse**' window to create the new folder in the active location.
- Right-click the 'New Folder' folder name, and then rename this folder to "temp" or some other convenient, unused name.



D. Use Windows Command-line to create the temporary folder.

• **First,** click [**Start**] on the Windows taskbar, and then click the '**Run...**' icon (or, depending on Windows OS versions *prior* to Windows 95, click the '**MS-DOS Prompt**' icon from the Main Menu).


Updating Firmware 3–5 MN-SPODPSX



- Next, open a Command-line window...
 - o For Windows 95 or Windows 98 Type "**command**".
 - o For any Windows OS versions later than Windows 98 Type "**cmd**" or "**command**".



- Alternately, from [Start], select All Programs > Accessories > Command Prompt.
- o Finally, from the Command-line 'c:\>' prompt, type "mkdir temp" or "md temp" (mkdir and md stand for make directory), and then click [OK].



There should now be a 'temp' folder created and available for placement of the firmware file download.

Updating Firmware 3–6 MN-SPODPSX



3.3 Download and Extract the Firmware Update

- 1) First, download the firmware update file from the Comtech Web site:
 - **A.** Go online to <u>www.comtechefdata.com</u>.
 - **B.** On the *Main* page Under **Support Information** or the **Support** tab, select the **Software Downloads** hyperlink.
 - **C.** On the *Software Downloads* page Click **Download Flash and Software Update Files**.
 - **D.** On the *Flash Updates Index* page Select the (**Select a Product Line**) **Amplifiers** hyperlink.
 - **E.** On the *Amplifiers* product page Select the **LPOD** product hyperlink.
 - **F.** Select the appropriate firmware archive EXE or ZIP file download hyperlink.



 About Firmware Numbers, File Versions, and Formats: The Comtech Web site catalogues its firmware update files by product type (e.g., router, modem, etc.), the specific model, and optional hardware configurations.

The firmware download hyperlink appears as F0000078X_V###, where 'X' denotes the revision letter, and '###' represents the firmware version number (e.g., V151 = Version 1.5.1).

- About File Archive Formats: Comtech provides its downloadable files in two compressed archive formats: *.exe (self-extracting) and *.zip (compressed).
- The *.exe file does not require a file archiver and compression utility program such as PKZIP for Windows, WinZip, ZipCentral, etc. (PKZIP for DOS is not supported due to file naming conventions). Comtech does not provide this utility program.

Some firewalls do not allow the download of *.exe files. Download the *.zip file instead, and extract the firmware files from the archive download with a user-supplied utility program. For detailed information on handling archived files, refer to the utility program Help documentation.

- **G.** Download the archive file to the temporary folder.
 - Once the EXE or ZIP hyperlink is selected the 'File Download' window opens and prompts selection of [Open] or [Save]:
 - Click [Open] to turn over file extraction to the user-supplied utility program. Be sure to extract the firmware files to the 'temp' folder created earlier.
 - O Click [Save] to open the 'Save As' window. Be sure to select and [Save] the archive *.exe or *.zip file to the 'temp' folder created earlier.

Otherwise, click [Cancel] to quit and exit the file download process.

Updating Firmware 3–7 MN-SPODPSX





2) Next, extract the firmware files from the archive file.

- (If not already done with **File Download** > **[Open]**) Extract the firmware files from the downloaded *.exe or *.zip archive file with the user-supplied utility program:
 - O Double-click on the archive file name, and then follow the prompts provided by the user-supplied utility program. Extract, at a minimum, two files:
 - **FW-0000078x_LPOD_**#_#_#.**bin** The Firmware Bulk image file (where 'x' denotes the revision letter and '#_#_#' denotes the firmware version number).
 - **ReleaseNotes_LPOD-PSx_v#-#-#.pdf** The Firmware Release Notes PDF file (where '#-#-#' denotes the firmware version number).

3) Confirm availability of the firmware files in the temporary folder.

There are several ways you may view the contents of the temporary folder on a Windows-based PC:

A. From the Windows Desktop:

- Double-left-click the 'temp' folder saved to the Windows Desktop.
- Use Windows Explorer to locate, and then double-left-click the 'temp' folder.
- Use the 'Browse' window ([Start] > ...Run > [Browse]) to locate, and then double-click the 'c:\temp' folder.

B. Using Command-line:

- Type "cd c:\temp" at the Command-line prompt to change to the temporary directory created earlier using Command-line.
- Type "dir" to list the files extracted to the temporary directory from the downloaded archive file.

The firmware files have been successfully downloaded and are now available for transfer to the SPOD.

Updating Firmware 3–8 MN-SPODPSX



3.4 Perform the FTP Upload Procedure



To proceed with the firmware update procedure, assumptions are made that:

- The SPOD is connected to a user-supplied, Windows-based PC, and:
 - The User PC serial port is connected to the SPOD's 'J6 |COM1' port using the appropriate adaptive cabling,
 OR -
 - The User PC Ethernet port is connected to the SPOD's 'J6 |COM1' port with a user-supplied hub, switch, or a direct adaptive Ethernet cable connection.
 - The User PC is running a terminal emulation program (for operation of the SPOD Serial or Telnet interfaces) and a compatible Web browser (for operation of the SPOD Web Server Interface).
- The latest firmware files have been downloaded or otherwise received from Comtech and are available on the User PC in an accessible temporary folder.
- 1) Use Command-line to send a 'PING' command to confirm proper connection and communication between the User PC and the SPOD:
 - Obtain the IP Address of the unit using serial remote control or the SPOD Web Server Interface:
 - O Using Serial Remote Control Type the "<0/IPA?" remote query (without quotes) at the command prompt. The unit returns the configured IP Address.
 - Using the SPOD Web Server Interface View the entry for *IP Address/Range* in the Network Maintenance section of the 'Admin | Access' page:



Once the IP Address is known – use Command-line to PING: Type "ping xxx.xxx.xxx." at the Command-line prompt (where 'xxx.xxx.xxx.' is the unit IP Address).

The response should confirm whether the unit is properly connected and communicating.

- 2) Use Command-line to transfer (FTP) the files from the User PC to the SPOD:
 - Type "ftp xxx.xxx.xxx" (where 'xxx.xxx.xxx' denotes the unit IP Address).
 - Type "bin" to set the binary transfer mode.
 - Type "prompt" and then type "hash" to facilitate the file transfers.
 - Type "put FW-0000078x.bin bulk:" (where 'x' denotes the firmware revision letter) at the Command-line prompt, without quotes, to begin the file transfer. The destination "bulk:" must be all lower-case. Wait while the file transfers.
 - Type "bye" to terminate the FTP session, and then close the Command-line window.

Updating Firmware 3–9 MN-SPODPSX



- 3) To verify that the User PC-to-Unit FTP file transfer was successful, review the current firmware information via the serial or Ethernet interfaces (see Sect. 3.2, Step 1D).
- 4) Use the SPOD Web Server Interface to select the firmware and soft-reboot the unit:
 - A. Select the desired Active Firmware Image:
 - Using the SPOD Web Server Interface Use the Next Reboot Image drop-down list on the 'Config | Utility' page to select Image 1 or 2, and then click [Submit].



- B. Soft-reboot the SPOD:
 - Using the SPOD Web Server Interface Click [Reboot Now] in the Perform Soft Reboot section of the 'Config | Utility' page to reboot the SPOD using the Current Active Firmware Image.



- Wait while the SPOD reboots.
- 5) To load the second image, repeat Step 4.
- 6) Once the unit has rebooted (after switching to the new firmware), type the "<0/CTD=1?" remote command (without quotes) at the command prompt to clear the trending data.

The SPOD is now operating with its latest firmware. The firmware update process is now complete.

Updating Firmware 3–10 MN-SPODPSX



Chapter 4. ETHERNET-BASED REMOTE PRODUCT MANAGEMENT

4.1 Introduction

Ethernet-based remote management and control of the SPOD is available when the appropriate adapter cable, connected to the SPOD 'J6 | COM1' 19-pin communications port.

This interface is generally modeled after Comtech's LPOD Outdoor Amplifier/ Block Up Converter (BUC) product interface. LPOD-specific operation (e.g., BUC and LNB) is disabled for the SPOD Ethernet interface.



- 1) TO PROCEED WITH ETHERNET-BASED REMOTE PRODUCT MANAGEMENT, ASSUMPTIONS ARE MADE THAT:
 - The SPOD is operating with the latest version firmware files.
 - The SPOD is connected to a user-supplied Windows-based PC as follows:
 - The PC's Ethernet port is connected to the SPOD 'J6 | COM1' port using the available CA-0000352 Ethernet Interface Cable (part of Comtech Kit KT-0000203) in combination with a user-supplied hub or switch.
 - The PC is running a terminal emulation program (for operation of the SPOD Telnet Interface) and a compatible web browser (for operation of the SPOD Web Server Interface).
 - The SPOD's Management IP Address has been noted.
- 2) USE OF THE ETHERNET-BASED SNMP INTERFACE IS RECOMMENDED ONLY FOR ADVANCED USERS. ALL OTHER USERS ARE STRONGLY ENCOURAGED TO USE THE SPOD WEB SERVER INTERFACE FOR REMOTE MONITOR AND CONTROL (M&C) OF THE SPOD.



4.2 Ethernet Management Interface Protocols

The user PC facilitates access to Ethernet-based remote monitor and control (M&C) of the SPOD 100BaseT/10BaseTx Ethernet Management Interface through three separately operated protocols:

- **Simple Network Management Protocol (SNMP).** This requires a user-supplied Network Management System (NMS) and a user-supplied Management Information Base (MIB) File Browser.
- **Telnet Interface.** This requires use of the user PC's Command-line interface, or a user-supplied terminal emulation program such as HyperTerminal.
- **Web Server (HTTP) Interface.** This requires a compatible user-supplied web browser such as Internet Explorer.

4.3 SNMP Interface

The *Simple Network Management Protocol* (SNMP) is an Internet-standard protocol for managing devices on IP networks. An SNMP-managed network consists of three key components:

- The managed device. This includes the SPOD.
- **The SNMP Agent.** The software that runs on the SPOD. The SPOD SNMP Agent supports both **SNMPv1** and **SNMPv2c**.
- The user-supplied Network Management System (NMS). The software that runs on the manager.

4.3.1 Management Information Base (MIB) Files

An MIB file is used for SNMP remote management of a unique device and consist of a tree of nodes called Object Identifiers (OIDs). Each OID provides remote management of a particular function. These MIB files should be compiled in a user-supplied MIB Browser or SNMP Network Monitoring System server.

The following MIB files are associated with the SPOD:

MIB File/Name (where 'x' is revision letter)	Description
FW-0000291x.mib ComtechEFData Root MIB file	ComtechEFData MIB file gives the root tree for ALL Comtech SPOD products (PSx) and consists of only the following OID: Name: comtechEFData Type: MODULE-IDENTITY OID: 1.3.6.1.4.1.6247 Full path: iso(1).org(3).dod(6).internet(1).private(4).enterprises(1).comtechEFData(6247) Module: ComtechEFData
FW-0000289x.mib SPOD-PSx MIB file	MIB file of all OIDs for management of the SPOD functions
FW-0000290x.mib SPOD-PSx SNMP Traps MIB file	MIB file for SNMPv1 traps common for SPOD.



4.3.2 SNMP Community Strings



CAUTION – In SNMP v1/v2c, the SNMP Community String is sent unencrypted in the SNMP packets. Caution must be taken by the network administrator to ensure that SNMP packets travel only over a secure and private network if security is a concern.

The SPOD uses Community Strings as a password scheme that provides authentication before gaining access to the router agent's MIBs. They are used to authenticate users and determine access privileges to the SNMP agent. The SPOD defines three Community Strings for SNMP access:

- Read Community default = public
- Write Community default = private
- Trap Community default = comtech

Type the SNMP Community String into the user-supplied MIB Browser or Network Node Management software.



For proper SNMP operation, the SPOD MIB files must be used with the associated version of the SPOD M&C. Please refer to the SPOD FW Release Notes for information on the required FW/SW compatibility.

4.3.3 SNMP Traps

The SPOD has the ability to send out SNMP traps both when a fault occurs and when a fault clears in the unit. The SNMP agent supports both "SNMPv1" and "v2c". The "Traps" file only needs to be compiled if "SNMPv1" traps are to be used.

You may configure which style of traps the SPOD sends by using the SPODSNMPTrapVersion OID.

The SPOD supports the following MIB2 v1traps and v2 notifications:

MIB2 SNMPv1 trap: Authentication Failure	5
MIB2 SNMPv2 notifications: Authentication Failure	1.3.6.1.6.3.1.1.5.5



The SPOD supports the following Faults v1 traps and v2 notifications, excluding those denoted with **italics:


Faults SNMPv1 traps:	
ODUPowerSupply24V1StatusV1	62474801
ODUPowerSupply24V2StatusV1	62474802
ODUPowerSupplyLNBStatusV1	62474803
ODUPowerSupply13VStatusV1	62474804
ODUPowerSupply10VStatusV1	62474805
ODURFPowerSupply10V1StatusV1	62474806
ODURFPowerSupply10V2StatusV1	62474807
ODUPowerSupply7V8TStatusV1	62474808
ODUPowerSupply5V8TStatusV1	62474809
ODUPowerSupply2V5TStatusV1	62474810
ODUPowerSupply1V2TStatusV1	62474811
ODUPowerSupplyNeg5V8TStatusV1	62474812
ODUFan1StatusV1	62474813
ODUFan2StatusV1	62474814
ODUTemperatureStatusV1	62474815
ODUShutdownStatusV1	62474816
ODUI2CStatusV1	62474817
ODUForwardPowerStatusV1	62474818
ODUChecksumStatusV1	62474819
ODUFPGADoneStatusV1	62474820
** ODUBUCLockDetectStatusV1	62474821 **
ODURefLockDetectStatusV1	62474822
** ODULNBCSStatusV1	62474823**
ODUSwitchStatusV1	62474824
oduPowerSupply10V2StatusV1	62474825
oduFan3StatusV1	62474826
oduReversePowerStatusV1	62474827
oduRedundantLinkStatusV1	62474828
oduOverDriveStatusV1	62474829




Faults SNMPv2 notifications:				
ODUPowerSupply24V1Status	1.3.6.1.4.1.6247.48.1.3.1.1			
ODUPowerSupply24V2Status	1.3.6.1.4.1.6247.48.1.3.1.2			
** ODUPowerSupplyLNBStatus	1.3.6.1.4.1.6247.48.1.3.1.3**			
ODUPowerSupply13VStatus	1.3.6.1.4.1.6247.48.1.3.1.4			
ODUPowerSupply10VStatus	1.3.6.1.4.1.6247.48.1.3.1.5			
ODURFPowerSupply10V1Status	1.3.6.1.4.1.6247.48.1.3.1.6			
ODURFPowerSupply10V2Status	1.3.6.1.4.1.6247.48.1.3.1.7			
ODUPowerSupply7V8TStatus	1.3.6.1.4.1.6247.48.1.3.1.8			
ODUPowerSupply5V8TStatus	1.3.6.1.4.1.6247.48.1.3.1.9			
ODUPowerSupply2V5TStatus	1.3.6.1.4.1.6247.48.1.3.1.10			
ODUPowerSupply1V2TStatus	1.3.6.1.4.1.6247.48.1.3.1.11			
ODUPowerSupplyNeg5V8TStatus	1.3.6.1.4.1.6247.48.1.3.1.12			
ODUFan1Status	1.3.6.1.4.1.6247.48.1.3.1.13			
ODUFan2Status	1.3.6.1.4.1.6247.48.1.3.1.14			
ODUTemperatureStatus	1.3.6.1.4.1.6247.48.1.3.1.15			
ODUShutdownStatus	1.3.6.1.4.1.6247.48.1.3.1.16			
ODUI2CStatus	1.3.6.1.4.1.6247.48.1.3.1.17			
ODUForwardPowerStatus	1.3.6.1.4.1.6247.48.1.3.1.18			
ODUChecksumStatus	1.3.6.1.4.1.6247.48.1.3.1.19			
ODUFPGADoneStatus	1.3.6.1.4.1.6247.48.1.3.1.20			
** ODUBUCLockDetectStatus	1.3.6.1.4.1.6247.48.1.3.1.21**			
ODURefLockDetectStatus	1.3.6.1.4.1.6247.48.1.3.1.22			
** ODULNBCSStatus	1.3.6.1.4.1.6247.48.1.3.1.23**			
ODUSwitchStatus	1.3.6.1.4.1.6247.48.1.3.1.24			
oduPowerSupply10V2Status	1.3.6.1.4.1.6247.48.1.3.1.25			
oduFan3Status	1.3.6.1.4.1.6247.48.1.3.1.26			
oduReversePowerStatus	1.3.6.1.4.1.6247.48.1.3.1.27			
oduRedundantLinkStatus	1.3.6.1.4.1.6247.48.1.3.1.28			
oduOverDriveStatus	1.3.6.1.4.1.6247.48.1.3.1.29			



The SPOD provides a Telnet interface for the purpose of equipment M&C via the standard Remote Control protocol. The Telnet interface requires user login at the **Administrator** level and **Read/Write** level. An example of the login process is shown here:



Once logged into the Telnet interface as the Administrator, you can access the standard remote-control interface defined in **Chapter 5. SERIAL-BASED REMOTE PRODUCT MANAGEMENT**, as shown here:



4.3.4 Using HyperTerminal for Telnet Remote Control Operation


There is a disadvantage when using Windows Command-line as a Telnet client with the standard Remote Control protocol. Since Command-line cannot translate a '\r' (i.e., carriage return or "CR") to a '\r\n' (i.e., CR+line feed "LF") for the messages coming from Telnet Server, any multi-line Target-to-Controller response (e.g., the response to the FRW? query) will be displayed as one line, with the latter lines overwriting the previous lines.

In order to view the full response messages, use of the HyperTerminal terminal emulation program configured as a Telnet client is permissible.




Configure HyperTerminal as follows:

- Be sure to properly define the "Connect To" Telnet connection properties (File → Properties), as shown below at the near right:
 - Enter the SPOD's
 Management IP Address as
 the <u>Host Address</u> (e.g.,
 192.168.1.1).
 - Enter TCP Port <u>23</u> as the **Port** number.
 - Set Connect using to TCP/IP (Winsock) instead of COM1 or COM2.



- 2) For **ASCII Setup** (**File** → **Properties** → **Settings** → **ASCII Setup**), as shown above at the far right:
 - A. Check the "**Send line ends with line feeds**" option in the *ASCII Sending* section.
 - B. Check the "**Append line feeds to incoming line ends**" option in the *ASCII Receiving* section.

An example of login and remote command/query execution, when using HyperTerminal as the interface, appears as follows:





4.4 Web Server (HTTP) Interface

A user-supplied web browser allows the full monitor and control (M&C) of the SPOD through its Web Server Interface. This non-secure embedded web application is designed for, and works best with, Microsoft's Internet Explorer Version 5.5 or higher.

See the Remote Commands and Queries specifications tables found in **Chapter 5. SERIAL-BASED REMOTE PRODUCT MANAGEMENT** for detailed descriptions of many of the functions depicted throughout **Sect. 4.5.4 Web Server Page Descriptions**.


4.4.1 Enabling the Web Server Interface

To enable the Web Server Interface in the SPOD using only a 100BaseTx remote interface (this assumes that you are running a Microsoft Windows OS):

 Select **Start**, then **Run**, then type "**cmd**" to open the command prompt window:



- 2) Start a Telnet session with the unit at the default IP address of **192.168.1.4**:
- 3) Enter the Telnet username and password (the default for both parameters is **comtech**):





4) Set the remote access parameter to accept Ethernet remote control using the **LRS** command.

LRS=3, the default remote command, provides Serial +
Ethernet control, while remote command LRS=2 provides Ethernet control only.







You must assign a unique IP Address for each unit on the network before connecting to an existing network. As the IP address may need to be changed to something other than the factory default setting, use the command IPA=xxx.xxx.xxx.yy, where: xxx.xxx.xxx is a valid IP address on the network where the unit is to be installed, and yy is the range (typically, yy = 24).

Changing the **IPA** value requires that you cycle power on the unit, and then start a new Telnet session using the new IP address.

See Chapter 5. SERIAL-BASED REMOTE PRODUCT MANAGEMENT for more information on the LRS and IPA commands.

4.4.2 User Login

1) From the PC, type **http://192.168.1.4** (the default IP address for the SPOD) into the **Address** area of the browser:



2) The Login window will appear, similar to the example shown here. Type the **User name** and **Password**, and then click **[OK]**. The default User Name and Password are both **comtech**.



Once the valid User Name and Password is accepted, the SPOD Web Server Interface "splash" page displays, as per the example shown to the right (note that the Firmware Version listed here is subject to change):





4.4.3 Web Server Interface - Operational Features

4.4.3.1 Menu Tree

This menu tree diagram lists the features available through the SPOD Web Server Interface. This interface features four navigation tabs (shown in blue). The nested page hyperlinks (grey) provide access to individual Web pages.

Home	Admin	Config	Status
Home	Access	Amplifier	Summary
Contact	SNMP	LNB**	Status
Support		Utility	FETs
		Redundancy	Events
			Statistics
			Trending Graphs



** The CONFIG | LNB page is inoperable for the SPOD PS2. For this reason, while the LNB page hyperlink is visible under the CONFIG tab and selectable on this interface, it is not documented in this manual.

4.4.3.2 Page Navigation

The Web Server Interface features four navigation tabs located at the top of each page. After you click a navigation tab, you may click an available page hyperlink.



This manual uses a naming format for all web pages to indicate to you the navigation needed to view the referenced page: "Navigation Tab | Page Hyperlink."

For example, interpret "**Home** | **Support**" to mean, "*first* click the '**Home**' navigation tab, and *then* click the '**Support**' page hyperlink."

4.4.3.3 Page Sections

Each page features one or more sections. The title at the upper-left corner of each page or page section describes its operational features. Each section can feature editable fields, action buttons, and read-only displays for a specific function.



This manual explains the purpose and operation for each Web page on a **per-page**, **per-section** basis.



4.4.3.4 Action Buttons

Action buttons are important in the SPOD Web Server Interface. Click an action button to do one of these tasks:



- Refresh the page with current data.
- Reset changed parameters to remove **unsaved** changes.
- Submit (permanently save) changes.



If you edit a field, make sure to click the action button before you leave the page. If you go to another page without first clicking the action button, your changes are <u>not</u> saved.

4.4.3.5 Drop-down Lists

A drop-down list lets you choose from a list of selections. Left-click the drop-down button to open the list. Then, left-click on an item to select that choice.



4.4.3.6 Text or Data Entry

Text boxes let you type data into a field. An action button may be associated with a single text box, or a group of text boxes.



For any text box, left-click anywhere inside the box, type the desired information into that field, and be sure to press **[ENTER]** when done.

Click the related action button to save the data.



If you edit any field, make sure to click the action button before you leave the page. If you go to another page without first clicking the action button, your changes are not saved.



4.4.4 Web Server Interface – Web Page Descriptions



The SPOD Web Server Interface pages, as depicted in the figures featured through the end of this chapter, show operational examples that will vary from your actual implemented network. These figures are provided for reference only.

4.4.4.1 Home Pages

Click the **Home** tab, and then click the **Home**, **Contact**, or **Support** hyperlink to continue.

4.4.4.1.1 Home | Home

Use this page to identify the SPOD Web Server Interface, the specific product, and its assigned serial number. Click the **Home** tab and/or the nested **Home** hyperlink to return to this page from anywhere in the Web Server Interface.



Figure 4-1. SPOD Home | Home Page



4.4.4.1.2 Home | Contact

Use this page to see the contact information (phone, fax, or Web/e-mail hyperlinks) for Comtech Product Support.



Figure 4-2. Home | Contact Page



4.4.4.1.3 Home | Support



For this page to operate correctly, the Administrator must define the SMTP server, domain name, and destination on the Admin | Access page (see Sect.4.4.4.2.1).

This page uses SMTP (Simple Mail Transport Protocol) to compose and send an e-mail message to Comtech Product Support (techsupport@comtechefdata.com). Use this communications portal for questions about or problems with the unit.



Figure 4-3. Home | Support Page

Contact Information

Provide your contact information – Name, Company, Telephone, and E-mail – to Comtech here.

Problem Report

Use this section to compose the required message of up to a maximum of 256 characters.

Provide your **Contact Information**; compose your message in the **Problem Report** box, and then click [**Submit Email**] to send the message.



4.4.4.2 Admin Pages



The Admin pages are available only to users who have logged in using the Administrator Name and Password.

Click the **Admin** tab, and then select the **Access** or **SNMP** hyperlink to continue.

4.4.4.2.1 Admin | Access

The Administrator must use this page to manage the Web Server Interface user access settings.




Figure 4-4. Admin | Access Page

Click [Refresh] (at the top of the page) to update the page appearance to the current operating configuration.

Network Maintenance

- **IP Gateway, IP Address/Range:** Enter the desired IP Gateway Address and IP Address/Range in these text boxes.
- MAC Address (*read-only*): The MAC is set at the factory to a guaranteed unique address that you cannot modify.

Click [Change IP Address] to save any changes. Otherwise, click [Reset] if you wish to revert to the previously assigned IP Gateway and IP Address/Range.



System Account Access Information

• Admin, Read/Write, and Read Only Names and Passwords:

The factory defaults for these names/passwords are:

Admin comtech/comtech
 Read/Write opcenter/1234
 Read Only monitor/1234

Note the following:

- o These **Name** fields can be any alphanumeric combination with a maximum length of 10 characters.
- o These **Password** fields can be any alphanumeric combination with a maximum length of 10 characters.
- **SMTP Server:** Specify the mail server IP address from where you want to send the e-mail.
- **SMTP Domain Name / Destination:** The Administrator can assign the SMTP Domain Name and Destination. This is required if you wish to use the **Home | Support** page email feature (**Sect.4.4.4.1.3**).
 - o For **SMTP Domain Name**, specify the domain of the e-mail server (usually found to the right of the @ symbol in an e-mail address).
 - o For **SMTP Domain Destination**, specify the e-mail recipient name (usually found to the left of the @ symbol in an e-mail address).

Click [Change Access] to save any changes. Otherwise, click [Reset] to revert to the previously assigned System Account Access Information.

Webpage Timeout

The Webpage Timeout determines a desired time lapse before the SPOD Web Server Interface pages time out. Use the drop-down list to select **five minutes** or **eight hours**. The default timeout setting is five minutes. Click **[Submit]** when done.



The 'Status' page (Figure 4-10 in Sect. 4.4.4.4.2) will automatically refresh once every ten seconds, and will reset the timeout counter.



4.4.4.2.2 Admin | SNMP



Sect. 4.3 SNMP INTERFACE

The Administrator must use this page to manage the SPOD SNMP (Simple Network Management Protocol) settings.



Figure 4-5. Admin | SNMP Page

Click [Refresh] (at the top of the page) to update the page appearance to the current operating configuration.

SNMP

- **Simple Network Management** (Operational Status) Use the drop-down list to select the Simple Network Management operational setting as **Enabled** or **Disabled**.
- The **Read Community String** and **Write Community String** fields can be any combination of characters and a length of 0 to 20 characters:
 - o The factory default for the **Read Community String** parameter is **public**.
 - The factory default Write Community String is private.
- **Authentication Trap Operational Status** Use the drop-down list to select the Enable Authentication Trap operational setting as **Enabled** or **Disabled**.
- The Administrator can assign up to two **SNMP Trap IP** addresses and one **SNMP Trap Community String.**
- The **SNMP Trap Community String** field can be any combination of characters and a length of 0 to 20 characters. The factory default for the **SNMP Trap Community String** is **comtech**.

Click [**Submit SNMP**] to save any changes. Otherwise, click [**Reset**] to revert to the previously assigned SNMP designations.



4.4.4.3 Config Pages



The CONFIG | LNB page is inoperable for the SPOD PS2. For this reason, while the LNB page hyperlink is visible and selectable on this interface, it is not documented in this manual.

Click the **Config** tab, and then click the **Amplifier**, **Utility**, or **Redundancy** hyperlink to continue.

4.4.4.3.1 Config | Amplifier

Use this page to configure the communications, operations, and alarms/faults handling for the amplifier.



Figure 4-6. Config | Amplifier Page

Click [Refresh] (at the top of the page) to update the page appearance to the current operating configuration.



The Reference and FSK Address sections of this page are non-functional on the SPOD Web Server Interface.



Serial

- Remote Address Enter a valid physical remote address from 0001 to 9999.
- Baud Rate Use the drop-down list to select the operating baud rate as 2400, 4800, 9600, 19200, or 38400 baud

Click [Change Serial Configuration] to save any changes.

Amplifier

- Amplifier Use the drop-down list to select the amplifier as either **On** or **Off**.
- Attenuation (dB) Enter a valid attenuation level (00.00 to 20.00 dB) in 0.25 dB steps.
- **Attenuation Offset** Enter a valid value, in dB, for the attenuation offset.
- Fault Recovery Use the drop-down list to select Fault Recovery as either Automatic or Manual.
- **Overdrive Protection Mode -**Use the drop-down list to select **On** or **Off**.
- Overdrive Activate Level -Enter a valid power level. Range is P1dB rated to P1dB rated 10. Note: Maximum value can be 10.0. However, current customer attenuation (ATT) setting will factor into how large the overdrive activate level value can be used. For example: if ATT is 12.00 and ATT max range is 20.0, then maximum value the activate level can set to is 8.0.
- Mute Use the drop-down list to select the Mute function as either Enabled or Disabled.
- AUX Mute Use the drop-down list to select the Auxiliary Mute Mode as either Enabled or Disabled.
- Offline Mute Use the drop-down list to select the Offline Mute function as **Enabled** or **Disabled**.



The MuteRx, MuteTx, MuteRx+LNB, and MuteTx+LNB selections are nonfunctional on the SPOD Web Server Interface.

Click [Change Configuration] to save any changes. Otherwise, click [Reset] to revert to the previously assigned Amplifier settings.

Low Power Forward Threshold (dBm)

Use this field to set the threshold value, in dBm, for the low forward power alarm/fault. When the forward power monitor is set to **Alarm** or **Fault** instead of the factory default of **Mask**, and the forward power drops below the specified value, the alarm/fault is indicated.

Setting this parameter to the default value of 00.00 effectively disables the threshold.

Click [Change] to save any changes. Otherwise, click [Reset] to revert to the previously assigned Low Power Forward Threshold setting.



4.4.4.3.2 Config | Utility

Use this page to configure SPOD operating parameters.




Figure 4-7. Config | Utility Page

Click [Refresh] (at the top of the page) to update the page appearance to the current operating configuration.

Date and Time

- Enter a date using international format in the form DD/MM/YY (where DD = day [01 to 31], MM = month [01 to 12], and YY = year [00 to 99]).
- Enter a time using HH:MM:SS format (where HH = hour [00 to 23], MM = minutes [00 to 59], and SS = seconds [00 to 59]).

Click [Change Date/Time] once you enter the desired date and time.

Circuit ID

Enter a Circuit ID (unit identification label) string of up to 48 characters.

Click [Change CID] once you compose the desired unit identification label.



Current Active Firmware Image # (read-only)

The selected **Current Active Firmware Image** is identified here. In this example, **Image 2** is the **Current Active Firmware Image**.

Next Reboot Image

Use the drop-down list to select the Next Reboot Image as **Image 1** or **2**. Press [**Submit**] when done.

Perform Soft Reboot

Click [Reboot Now] to reboot the SPOD using the Current Active Firmware Image.

Firmware Information (read-only)

This **read-only** scrollable window provides information about the currently loaded Bootrom. For the complete Bulk1 and Bulk2 information, scroll through all the constituent firmware blocks that make up the bulk.

Part Number (read-only)

This **read-only** scrollable window provides identifying part number information for the unit in use.



4.4.4.3.3 Config | Redundancy



Appendix A. 1:1 REDUNDANCY

Use this page to configure the SPOD's Redundancy Switch Mode.




Figure 4-8. Config | Redundancy Page

Click [Refresh] (at the top of the page) to update the page appearance to the current operating configuration.

Redundancy

To update the page to the current redundancy configuration: Click [Refresh].

Enable Redundancy Switch Mode

Use the drop-down list to select the Switch Mode as follows:

- Off Disables redundancy.
- 1:1 Red TX Enables 1:1 redundancy with transmit switch control.
- Manual: Enables manual redundancy mode.



The 1:1 Red TX+RX selection is non-functional on the SPOD Web Server Interface.

Click [Change] once the desired mode selection has been made.

Online Status

This **read-only** section displays the active status for the unit as either **Online** or **Offline**.

Force Online

To force a unit to go active (online): Click [Force Online].



4.4.4.4 Status Pages

Use these pages to access to event logging, operational statistics, status, FET windows, and operational trending graphs.

Click the **Status** tab, and then click the **Summary**, **Status**, **FETs**, **Events**, **Statistics**, or **Trending Graphs** hyperlink to continue.

4.4.4.4.1 Status | Summary

Use this *read-only* page to view pertinent condensed information about the SPOD unit and its current operating state.




Figure 4-9. Status | Summary Page

Click [Refresh] (at the top of the page) to update the page appearance to the current polled configuration and operating conditions.

Summary

The **Summary Fault** line indicates that no faults are present with "**OK**" on green background. If a fault exists, the **Summary Fault** message changes to "**FAULT**" on a red background. Should this occur, review the logged faults and alarms on the **Status** | **Events** page (see **Sect. 4.4.4.4.2**).

Terminal Status Change

Use this section to determine if any configuration changes have been made to the unit since the last time the Terminal Status Change flag was reset by clicking [Clear].

If Terminal Status Change reads **NO**, this indicates that there have been no changes in the unit configuration since the last time the Status Change flag was Cleared. Otherwise, the Terminal Status Change will read **YES**, when a "status change" occurs for one or more of the following reasons:

- An operating parameter is changed, e.g., when a command that changes an operational value is executed successfully;
- A fault condition is triggered;
- A redundant switchover occurs.



4.4.4.4.2 Status | Status

Use this *read-only* page to review all pertinent information about the SPOD.



Unlike the remaining pages available through this interface that refresh/update only when manually selected, the 'Status' page updates automatically once every 10 seconds. Even with this automatic refresh function, you may click [Refresh] to update the operational status parameters found on this page.





Figure 4-10. Status | Status page

Status

Click [Refresh] to see the latest page data.

4.4.4.5 Status | MOP



Mop

Click [Refresh] to see the latest page data.



4.4.4.5.1 Status | FETs

Use this **read-only** page to monitor the current operating status of the SPOD's Q01 through Q09 RF Power Field Effect Transistors (FETs) that are installed in the RF amplifier.




Figure 4-11. Status | FETs page

Click [Refresh] (at the top of the page) to update the page appearance to the current polled configuration and operating conditions.



4.4.4.5.2 Status | Events

Use this page to view with all pertinent information about stored events, and to define the alarm parameters that determine how ongoing SPOD operations shall trigger events and alarms.




Figure 4-12. Status | Events Page

Click [Refresh] (at the top of the page) to update the page appearance to the current polled configuration and operation conditions.

Unread Stored Events

This **read-only** scrollable window displays the unread stored events log in sequential, date-stamped format. A running tally of the number of unread stored events is displayed in the window header. The unit returns and displays the five oldest stored events in the alarm log. All events that are read from the log are also automatically removed from the log.

Manage the unread Stored Events window as follows:

- **Read Next Five Events** Select to display the next five unread stored events in the log.
- Clear Events Log Select to clear all stored events from the log.
- **Initialize Events Pointer** Select to reset the internal pointer to allow queries to start at the beginning of the stored events log.

Click [Submit] to execute the choice – the window will update according to the selection made.



Alarm Mask

Use the drop-down lists to select each alarm as Fault, Alarm, or Masked for:

- Low Forward RF Power
- Fan Speed



The LNB 22V Power Supply, LNB Current Detect, and External Reference Lock Detected selections are non-functional on the SPOD Web Server Interface.

Click [Change Alarm Mask] to save these settings. Otherwise, click [Reset] if you wish to revert to the previously assigned Alarm Mask settings.



4.4.4.5.3 Status | Statistics

Use this page to review all unread (stored) statistics, and to configure how the SPOD handles and displays statistics.




Figure 4-13. Status | Statistics page

Click [**Refresh**] (at the top of the page) to update the page appearance to the current polled operating conditions.

Unread Stored Statistics:

This scrollable window displays the unread stored statistics log in sequential, date-stamped format. This page displays a running tally of the number of unread stored statistics in the window header. The unit returns and displays the five oldest stored statistics; all events that are read from the log are also automatically removed from the log.

Manage the Unread Stored Statistics window as follows:

- **Read Next Five Statistics** Unit returns the oldest five unread stored statistics that have not yet been read in the log. If there are less than five events to be retrieved, the remaining positions are padded with zeros. If there are no new events, the counter in the header reads **000**.
- **Initialize Statistics Pointer** Resets the internal pointer to allow queries to start at the beginning of the statistics log.

Click [Submit] to execute the choice – the window updates according to the selections made.



Statistics Configuration



The Statistics Logging drop-down list is non-functional on the SPOD Web Server Interface. Statistics Logging is always Enabled on the SPOD.

- Statistics Interval Enter the interval, in minutes, at which statistics are logged. Minimum resolution is 1 minute (001); maximum is 99 minutes (099). Default is 90 minutes (090).
- Statistics Averaging Use the drop-down list to select either Enable or Disable to set the Statistics Averaging function:
 - o When **Enabled**, statistics data is averaged at a rate of once per second for 10 seconds.
 - o If **Disabled**, burst values will be logged instead of averaged values.

Click [Submit] once you have completely defined the statistics' reporting parameters.



4.4.4.5.4 Status | Trending Graphs

This scrollable page features a universal page controls bar plus seven trending and operations graphs that provide statistics for the following parameters:

- Temperature
- Power
- LNB Current
- Amplifier Status

- Tx Mute Status
- Online Status
- Minimum Fan Speed



Figure 4-14. Status | Graphs Page





The LNB CURRENT and RX MUTE STATUS graphs are non-functional on the SPOD Web Server Interface.

Click [Refresh] (at the top of the page) to update the graphs to their current polled states.

Control Bar and Refresh Tab



Use the Control Bar to choose the time, date, and duration of the trending information displayed on the graphs. The graphs are all tied to the same 'x' scale so that you can more easily correlate data between the graphs.

Note the following:

- **Start Date (mm/dd/yy):** Once a unit has been in operation for 24 hours or more, use the drop-down list to select a date up to a maximum of 28 days, including the present date from which to compile data. If a unit has *not* been in operation for 24 hours, only **present** will be available.
- **Time:** Once a unit has been in operation for 24 hours or more, use this drop-down list to select the time on the hour 24 hours, from **12 am** to **11 pm**, are available. Note that, for the first 24 hours of operation (or beyond if the time has accrued), if you select **present** as the **Start Date**, then the **Time** drop-down list becomes unavailable for selection and dim as shown here.



• **Duration:** Use the drop-down list to select the block of time in which data is compiled for the graphs. Select **30 minutes**, **1 hour**, **2 hours**, **4 hours**, **6 hours**, **8 hours**, **12 hours**, **24 hours**, or **48 hours**.




The trending data is stored to the unit's flash memory once per hour. If the unit is powered off before the data can be written to memory, the last 60 minutes of data will be lost.

Click [Submit] to execute the choice once the configuration parameters have been defined; then, click the [Refresh] tab to update the graphs with the most current trending parameters (note that when the page refreshes, the Power Graph resets to display the default unit of dBm).




Temperature Graph



As noted by the graph legend, the blue line displays the unit's Amplifier (heat sink) temperature; the red line displays the Ambient (outdoor) temperature, if the required sensor has been installed in the unit.

You may control the appearance of either temperature by deselecting the pertinent checkbox provided at the bottom of the graph. The graph will dynamically update after the next polling cycle (every five seconds), when the deselected parameter is removed from both the graph and its legend.

Power Graph




The power graph displays the unit's output power with 1dB resolution. You may define whether the graph depicts the unit of measurement as **dBm** (the default setting) or **watts** by selecting the desired Amplified Output Power unit at the bottom of the graph. The graph will dynamically update after the next polling cycle (every five seconds) to the desired parameter.



Clicking the [Refresh] tab reverts the graph to the default display (Unit in dBm).




LNB Current Graph




This graph displays the LNB current only if an LNB is connected to the system and is drawing current from the LNB current source.

Amplifier Status Graph



This graph displays the state of the RF amplifier (On/Off). Note that, as shown in the example, On is represented by a 1 (one); Off is represented by a 0 (zero); if no data is available, then a -1 (negative one) is displayed.

Mute Status Graph






This graph displays the mute status (i.e., bias tee switch state as open = *muted*, or through path = *unmuted*) for the Tx Mute (red line). **The Rx Mute** (**blue line**) **is non-funtional on the SPOD Web Server Interface.** Note that a logic high on the graph equals a *muted* condition; a logic **0** (zero) indicates an *unmuted* condition; a **-1** (negative one) is displayed if the data is *unavailable*.


You may control the appearance of the Tx Mute by deselecting the checkbox provided at the bottom of the graph. The graph will dynamically update after the next polling cycle (every five seconds), when the deselected parameter is removed from both the graph and its legend.

Online Status Graph



This graph displays the unit's online state. Note that a 1 (one) indicates the unit is *online*; a 0 (zero) indicates the unit is *offline*; a -1 (negative one) indicates that the data is *unavailable*.

Minimum Fan Speed Graph



This graph displays the slowest fan speed of any of the fans installed in the system. The fan speed is proportional to the unit's heatsink temperature from -5°C and +15°C. At temperatures at or below -5°C, the SPOD minimizes its fan speed; at temperatures at or above +15°C, the SPOD maximizes its fan speed. The example provided here demonstrates the fan running at minimum, proportional, and maximum speeds.



Chapter 5. SERIAL-BASED REMOTE PRODUCT MANAGEMENT

5.1 Overview

Serial-based remote product management of Comtech's SPOD family of Outdoor Amplifiers is available using the SPOD's 'J6 | COM 1' port. Some key parameters and procedures and their associated remote commands and queries are summarized, followed by detailed instructions for use of the serial remote control communication command and query interface.

5.2 Key Operational Parameters

For detailed information about the remote commands and queries mentioned in this section, see **Sect. 5.4 Remote Commands and Queries** in this chapter.

5.2.1 RF Input Level

The required RF input level to reach the full rated output power of the SSPA is determined by the individual amplifier maximum gain and power rating.

For Example: If the test data of an SSPA rated for 250W (54 dBm) indicated a gain of 75 dB, then a signal of **54 dBm** – **75 dB** = -**21 dBm** would approximately give the rated output power. Increasing input power beyond this level would result in an output signal with increasingly higher levels of distortion. Of course, if the SPOD Attenuator Control is utilized, a higher level input signal level can be accommodated. *The maximum input level should never exceed 15dBm, or permanent damage to the unit may occur.*



5.2.2 Attenuator Control

The SPOD gain can be attenuated over its specified range by exercising the **ATT** command. The details for the format of this command are found later in this chapter.

5.2.3 Mute Control

The SPOD may be muted via software or discrete control:

- Software Exercising the MUT=1 command will "software" mute the unit.
- Discrete Control When exercising the AUX=1 command, the SPOD will be muted <u>until</u> Pin 'S' (on the 'J6 | COM1' Discrete Control Connector) is pulled to ground (Pin 'K'). At that time, the unit unmutes.

The Mute command provides over 60 dB of RF on/off isolation. However, the Mute command only turns off the first few low power stages of the amplifier, the high power stages remain on. By allowing the higher power transistors to stay on, the SPOD remains in more thermally stable state should the mute condition be removed.

If the user desires to completely turn off the bias to the entire amplifier (perhaps to conserve energy in a redundant system), both the MUT=1 and AMP=0 commands should be executed. For normal transmit operation, MUT=0 and AMP=1 are required.

5.2.4 Faults

The M&C system monitors certain key functions of the SPOD for proper operation. Should any of these parameters exceed predetermined limits, the M&C system will declare a fault. The conditions that trigger a fault are:

- Any power supply more than \pm 10% outside its nominal value.
- Fan less than 25% of maximum speed.
- I2C internal bus communications fault.
- Thermal Shutdown A temperature fault is indicated if the unit is >95°C. This creates a summary fault and will cause the unit to mute itself and switch to the back-up unit (if in a redundant system). However, the 10V supply to the FET transistors will remain on until the unit reaches the thermal shutdown temperature of >100°C. For protection reasons, the unit will shut down the 10V supply to the power transistors at temperatures >95°C.
- Firmware checksum error at power up.
- FPGA done indicator error at power up.
- Redundant waveguide switch position fault (applies to redundant mode operation only).
- Redundant inter-unit link fault (applies to redundant mode operation only).



The following parameters can be user-defined to report an alarm condition or a fault condition, or the parameter can be ignored completely by masking it:

- RF amplifier low output power (user adjustable value).
- Fan speed.

5.2.5 Power Detector

A power detector is provided to monitor the output power. It has a useful range of over 20 dB, referenced to the unit's rated P1dB point, and its value can be read by exercising the **RMS** command. The test data supplied with each unit gives an indication of the excellent accuracy and flatness of the power monitor over the frequency band of operation.

5.2.6 Some Common Commands

A few of the most common commands and queries are:

- RMS Retrieve Maintenance Status. Displays voltages, fan speeds, Heatsink temperature, output power monitor reading, etc.
- RCS Retrieve Configuration Status. Displays current attenuation, mute, amplifier, online, etc. status.
- RAS Retrieve Alarm Status. Displays current alarm or fault status.

Full details for each of these are listed in **Sect. 5.4** of this chapter.



5.2.7 End-of-Life Commands

Certain commands/queries are being marked by Comtech as End-of-Life (EOL). As noted in the format *<description>*^E in the **Parameter Type** field (in the Remote Commands and Queries tables in **Sect. 5.4**), while these commands are fully supported in this product, it is highly recommended that the equivalent new commands be used for new implementations. The new commands generally follow the outdated commands:

EOL-designated Command/Query (Page #)	New Command/Query (Page #) / Comment
CAA (5-11)	CAE (5-12)
CUS (5-14)	Functionality not included in any other remote command/query
DAT (5-15)	DAY (5-16)
LNA (5-19)	RNE (5-28)
RET (5-26)	PNM (5-23) New query provides more exact unit hardware information
RSN (5-29)	SNO (5-31)
SFS (5-30)	Functionality not included in any other remote command/query
TNA (5-33)	TNE (5-33)



5.3 Remote Control Protocol and Structure

The electrical interface is either an EIA-485 multi-drop bus (for the control of many devices) or an EIA-232 connection (for the control of a single device), and data is transmitted in asynchronous serial form, using ASCII characters. Control and status information is transmitted in packets, of variable length, in accordance with the structure and protocol defined in later sections.

5.3.1 EIA-485

For applications where multiple devices are to be monitored and controlled, a full-duplex (or 4-wire) EIA-485 is preferred. Half-duplex (2-wire) EIA-485 is possible but *is not preferred*.

In full-duplex EIA-485 communication there are two separate, isolated, independent, differential-mode twisted pairs, each handling serial data in different directions. It is assumed that there is a 'Controller' device (a PC or dumb terminal), which transmits data, in a broadcast mode, via one of the pairs. Many 'Target' devices are connected to this pair, which all simultaneously receive data from the Controller. The Controller is the only device with a line-driver connected to this pair – the Target devices only have line-receivers connected.

In the other direction, on the other pair, each Target has a Tri-Stateable line driver connected, and the Controller has a line-receiver connected. All the line drivers are held in high-impedance mode until one (and only one) Target transmits back to the Controller.

Each Target has a unique address, and each time the Controller transmits, in a framed 'packet' of data, the address of the intended recipient Target is included. All of the Targets receive the packet, but only one (the intended) will reply. The Target enables its output line driver and transmits its return data packet back to the Controller, in the other direction, on the physically separate pair.

EIA-485 (Full Duplex) Summary:						
Two differential pairs One pair for Controller to Target, one pair for Target to Controller.						
Controller-to-Target pair	Pair has one line driver (Controller), and all Targets have line-receivers.					
Target-to-Controller pair	Pair has one line receiver (Controller), and all Targets have Tri-State drivers.					



5.3.2 EIA-232

This is a much simpler configuration in which the Controller device is connected directly to the Target via a two-wire-plus-ground connection. Controller-to-Target data is carried, via EIA-232 electrical levels, on one conductor, and Target-to-Controller data is carried in the other direction on the other conductor.

5.3.3 Basic Protocol

Whether in EIA-232 or EIA-485 mode, all data is transmitted as asynchronous serial characters, suitable for transmission and reception by a UART. The character format should be 8N1 (8 data bits, no parity, 1 stop bit). The baud rate may vary between 2400 and 38400 baud.

All data is transmitted in framed packets. The Controller is assumed to be a PC or ASCII dumb terminal, which is in charge of the process of monitor and control. The Controller is the only device that is permitted to initiate, at will, the transmission of data. Targets are only permitted to transmit when they have been specifically instructed to do so by the Controller.

All bytes within a packet are printable ASCII characters, less than ASCII code 127. In this context, the Carriage Return and Line Feed characters are considered printable.

All messages from Controller-to-Target require a response – with one exception. This will be either to return data that has been requested by the Controller, or to acknowledge reception of an instruction to change the configuration of the Target. The exception to this is when the Controller broadcasts a message (such as Set time/date) using Address 0, when the Target is set to EIA-485 mode.

5.3.4 Packet Structure

Controller-to-Target										
Start of Packet	Target Address	Address Delimiter	Instruction Code	Code Qualifier	Optional Arguments	End of Packet				
<	0-9	/	A-Z, a-z	= or?		Carriage Return				
ASCII code 60	ASCII codes 48-57	ASCII code 47	ASCII codes 65- 90, 97-122	ASCII codes 61 or 63		ASCII code 13				
(1 character)	(4 characters)	(1 character)	(3 characters)	(1 character)	(n characters)	(1 character)				

Example: <0412/MUT=1{CR}



Target-to-Controller										
Start of Packet	Target Address	Address Delimiter	Instruction Code	Code Qualifier	Optional Arguments	End of Packet				
> ASCII code 62	0-9 ASCII codes 48-57	/ ASCII code 47	A-Z, a-z ASCII codes 65- 90, 97-122	=, ?, !, <i>or</i> * ASCII codes 61,63,33 or 42	(From 0 to n characters)	Carriage Return, Line Feed ASCII codes 13,10				
(1 character)	(4 characters)	(1 character)	(3 characters)	(1 character)		(2 characters)				

Example: >0412/MUT=1{CR}{LF}

5.3.4.1 Start of Packet

Because this is used to provide a reliable indication of the start of packet, these two characters may not appear anywhere else within the body of the message:

- Controller-to-Target: This is 'less-than' the character '<' (ASCII code 60).
- **Target-to-Controller:** This is the 'greater-than' character '>' (ASCII code 62).

5.3.4.2 Target Address

Up to 9,999 devices can be uniquely addressed. In EIA-232 applications this value is set to 0. In EIA-485 applications, the permissible range of values is 1 to 9999.



The Controller sends a packet with the address of a Target – the destination of the packet. When the Target responds, the address used is the same address, to indicate to the Controller the source of the packet. The Controller does not have its own address.

5.3.4.3 Address Delimiter

This is the 'forward slash' character '/' (ASCII code 47).



5.3.4.4 Instruction Code

This is a three-character alphabetic sequence that identifies the subject of the message. Wherever possible, the instruction codes have been chosen to have some significance.

For Example: GAC for Global Amplifier Configuration; **IPA** for **IP** Address, etc. This aids in the readability of the message, should it be displayed in its raw ASCII form.

Both upper case and lower case alphabetic characters may be used (A-Z and a-z, ASCII codes 65-90 and 97-122).

5.3.4.5 Instruction Code Qualifier

This single character further qualifies the preceding instruction code. Code Qualifiers obey the following rules:

1) From Controller-to-Target, the only permitted values are:

= (ASCII code 61	This character is used as the assignment operator, and is used to indicate that the parameter defined by the preceding byte should be set to the value of the argument(s) that follow it. For Example: In a message from Controller-to-Target, MUT=1 would mean 'enable the Mute function'.
? (ASCII code 63)	This character is used as the query operator, and is used to indicate that the Target should return the current value of the parameter defined by the preceding byte. For Example: In a message from Controller-to-Target, SWR? would mean 'returns the value of the internal software revision installed in the unit'.

2) From **Target-to-Controller**, the only permitted values are:

= (ASCII code 61)	This character is used in two ways: First, if the Controller has sent a query code to a Target (for Example: MUT?, meaning 'is the Mute enabled or disabled?'), the Target would respond with MUT=x, where x represents the state in question: 1 being 'enable' and 0 being 'disable'. Second, if the Controller sends an instruction to set a parameter to a particular value, and if the value sent in the argument is valid, then the Target will acknowledge the message by replying with MUT= (with no message arguments).
? (ASCII code 63)	This character is used only if the Controller sends an instruction to set a parameter to a particular value, then, if the value sent in the argument is not valid, the Target will acknowledge the message by replying, for example, with MUT? (with no message arguments). This indicates that there was an error in the message sent by the Controller.
! (ASCII code 33)	This character is used only if the Controller sends an instruction code which the Target does not recognize, the Target will acknowledge the message by echoing the invalid instruction, followed by the ! character. Example: XYZ!



(ASCII code 42)

This character is used only if the Controller sends an instruction to set a parameter to a particular value, then, if the value sent in the argument is valid, BUT the Target is in the wrong mode (e.g., standby mode in redundancy configuration) and will not permit that particular parameter to be changed at that time, the Target will acknowledge the message by replying, for example, with **MUT*** (with no message arguments).

(ASCII code 35)

This character is used only if the Controller sends an instruction code which the Target cannot currently perform because of hardware resource issues, then the Target will acknowledge the message by echoing the invalid instruction, followed by the # character. This response can only occur if the operator sends two or more 'hardware configuration' type commands without allowing adequate time between commands for the hardware to be configured. For example, if the operator issued commands to change both the frequency and the attenuation with less than 100 milliseconds between commands, and if this response is returned, then the command has not been accepted and the operator must resend the command.

5.3.4.6 Optional Message Arguments

Arguments are not required for all messages. Arguments are ASCII codes for any printable character.

5.3.4.7 End of Packet

- **Controller-to-Target**: This is the 'carriage return' character (ASCII code 13).
- Target-to-Controller: This is the two-character sequence 'carriage return' (ASCII code 13), and 'line feed' (ASCII code 10).

Both indicate the valid termination of a packet.



5.1 Remote Commands and Queries

Column 'C' = Command; **Column 'Q'** = Query; columns marked **'X'** designate instruction code as *Command only*, *Query only*, or *Command/Query*.

- Where an Instruction Code is noted XXX^E this denotes a command/query designated as **End of Life (EOL)**. While the underlying command remains available, the specific functionality is obsolete and should not be used for new implementations. There generally will be a different command elsewhere that encapsulates the marked functionality. See **Sect. 5.2.7** for more information.
- Where an Instruction Code is noted XXX^O this denotes a command/query that is available only when a reference oscillator is installed.

CODE	С	Q	CODE	С	Q	CODE	С	Q	CODE	С	Q
AMP	Х	Χ	GAC	Х	X	PNM		X	SSL	Х	Χ
AOF	Х	Х							SSN	Х	Х
ATT	X	X	IEP	X					STA	X	X
AUX	X	X	IMG	X	X	RAS		X	STB	X	X
			IPA	х	х	RBT	X		STV	X	X
			IPG	Х	Х	RCS		Х	SWC	Х	Х
CAAE	Х		ISP	х		RED	X	X	SWR		X
CAE	Χ					RETE		Х			
CAS		X				RFS		X			
CCS		Х	LNA ^E		Х	RMS		Х			
CFS		Х	LPT	Х	Х	RNE		Х	TIM	Х	Х
CID	Х	Х	LRS	Х	Х	RNS		Х	TMP		Х
CMS		X				RSN ^E		Х	TNA ^E		X
CUSE		X				RUS		Χ	TNE		X
			MAC		X				TPE		X
			MOP		X				TPS	X	X
DATE	X	X	MSK	X	X	SBR	X	X	TSC	X	X
DAY	Х	X	MUT	X	X	SFS ^E		Χ			
			NUE		X	SNA	X	Χ			
			NUS		X	SNM	X	Χ			
ESA	X	X				SNO	X	Χ			
ESW	X	X	OFM	X	X	SPA	X	X			
			ONL	Х	X	SRC	X	X	XRM	X	X
			OVU	X	X	SSC	X	Х			
FRW		X	OVR	X	X	SSI	X	X			

Note: The following codes are used in the 'Response to Command' column:						
CODE	MEANING					
=	Message OK					
?	Received OK, but invalid arguments found					
*	Message OK, but not permitted in Current mode					
#	Message OK, but only permitted in Remote mode					
!	Unknown command					



Parameter Type	Command (Instruction Code and Qualifier)	Arguments for Command or Response to Query	Description of Arguments (Note that all arguments are printable ASCII characters)	Response to Command (Target to Controller)	Query (Instruction Code and Qualifier)	Response to Query (Target to Controller)
RF Power Amplifier State	AMP=	1 byte	Command or Query. Sets or returns the RF power amplifier state in the form x, where: 0 = Off (Default value) 1 = On Note: turning the amplifier off will disable the +10V supply, and mask it during fault checking. Example: <1/AMP=1'cr' >0001/AMP='cr''lf'	AMP= AMP? AMP*	AMP?	AMP=x (See Description of Arguments)
Attenuation Offset	AOF=	5 bytes	Command or Query. Sets or returns the attenuation offset level in the form xx.xx, where: xx.xx = 00.00 to 20.00, in dB, in 0.25 dB steps as factory default. Default value: 00.00 This value is not copied to the offline unit in a redundant system, but is added to the attenuation value upon a switchover. This provides a unit-specific fine-tune to maintain power levels appropriately in a redundant system. Example: <1/AOF=12.25'cr' >0001/AOF='cr''If'	AOF= AOF? AOF*	AOF?	AOF=xx.xx (See Description of Arguments)
Attenuation	ATT=	5 bytes	Command or Query. Sets or returns attenuation level in the form xx.xx, where: xx.xx=00.00 to 20.00, in dB, in 0.25 dB steps as factory default. Default value: 10.00 Example: <1/ATT=12.25'cr' >0001/ATT='cr"lf'	ATT= ATT? ATT*	ATT?	ATT=xx.xx (See Description of Arguments)



Parameter Type	Command (Instruction Code and Qualifier)	Arguments for Command or Response to Query	Description of Arguments (Note that all arguments are printable ASCII characters)	Response to Command (Target to Controller)	Query (Instruction Code and Qualifier)	Response to Query (Target to Controller)
Auxiliary Mute	AUX=	1 byte	Command or Query.	AUX=	AUX?	AUX=x
Enable			Sets or returns the auxiliary mute mode in the form x, where:	AUX?		(See
			0=Disabled (default value)	AUX*		Description of
			1=Enabled			Arguments)
			Notes:			
			1. When AUX=1, the SPOD will be muted until Pin 'S' (on the 'J6 COM1' Discrete Control Connector) is pulled to ground. At that time, the unit unmutes.			
			2. Auxiliary mute is one of several hardware mute states that can cause a MUT=2 to be reported. See the MUT command for more info on mute states.			
			3. Auxiliary mute overrides the user mute state so if the command MUT=1 is sent, then AUX=1 is sent, and the user shorts Pin K to Pin S on the discrete control connector then the RF mute will be disabled (MUT=0).			
			Example (AUX Mute Enabled): AUX=1'cr'			



Parameter Type	Command (Instruction Code and Qualifier)	Arguments for Command or Response to Query	Description of Arguments (Note that all arguments are printable ASCII characters)	Response to Command (Target to Controller)	Query (Instruction Code and Qualifier)	Response to Query (Target to Controller)
Concise Alarm Status	N/A	44 bytes	Query only. This is the concise version of the RAS query. Returns the alarm status of the unit, response is semicolon delimited. Example: CAS=a;b;c;d;e;f;g;h;t;j;k;l;m;n;o;p;q;r;s;t;u;v;w;x;y;'cr'lf' where: a thru z = 0 (FT), 1 (OK), 2 (AL), 3 (NO), 4 (YS), 5 (MS), 6 (??), or 7 (NA) a = +24V Power Supply b = +24V Switch Power Supply (Not applicable on the SPOD) d = +13.5V Power Supply e = +10V Power Supply f = +10V1 Amplifier Power Supply (see Note) h = +7.8V Power Supply g = +10V2 Amplifier Power Supply (see Note) h = +7.8V Power Supply i = +5.8V Power Supply i = +5.8V Power Supply l = -5.8V Power Supply m = Fan#1 State n = Fan#1 State n = Fan#2 State (see Note) o = Heatsink Temp p = Overtemp Shutdown q = IIC Status r = Forward Power Alarm s = Flash Checksum t = FPGA Done u = BUC Lock Detect (Not applicable on the SPOD) v = External Ref Lock Detect (Not applicable on the SPOD) x = Redundant Switch Condition (see Note) y = Redundant Link Status (see Note) z = Terminal Status Change Notes: 1. c, g, n, x, and y appear if the appropriate model/options have been selected/installed. 2. ?? is an invalid fault condition because hardware failed to respond to query (this value is accompanied by an I2C fault). 3. NA = not applicable. The unit does not include hardware support for this parameter.	CAS=	CAS?	CAS=xx (See Description of Arguments)



Parameter Type	Command (Instruction Code and Qualifier)	Arguments for Command or Response to Query	Description of Arguments (Note that all arguments are printable ASCII characters)	Response to Command (Target to Controller)	Query (Instruction Code and Qualifier)	Response to Query (Target to Controller)
Clear All Stored Alarms ^E	CAA=	None	Command only. Instructs the SPOD to clear all Stored Alarms. This command takes no arguments. Example: <1/CAA='cr' >0001/CAA='cr''lf'	CAA= CAA*	N/A	N/A
Clear All Stored Events	CAE=	None	Command only. Instructs the SPOD to clear all Stored Events. This command takes no arguments. Example: <1/CAE='cr' >0001/CAE='cr' f'	CAE= CAE*	N/A	N/A
Concise Configuration Status	N/A	26 bytes	Query only. This is the concise version of the RCS query. Returns the configuration status of the unit, in the form aa.aa;b;c;d;e;ff.ff;g;hhh, where: aa.aa = attenuation in dB (ATT) b = RF power amplifier state, 0 = Off, 1 = On (AMP) c = mute state, 0 = un-muted, 1 = muted (MUT) d = online status (ONL) e = redundancy state and mode (ESW) ff.ff = Attenuator offset in dB (AOF) g = auto fault recovery mode (AFR) hhh = External reference status, N/A = no external reference, 05M for 5 MHz, and 10M for a 10 MHz (See Note) Note: hhh will always be N/A if the internal reference oscillator option is not installed. Example: CCS=aa.aa;b;c;d;e;ff.ff;g;hhh; 'cr''lf'	CCS=	CCS?	CCS= aa.aa;b;c;d;e; ff.ff;g;hhh (See Description of Arguments)
Concise RF Power FET Current Status	N/A	Length varies depending on number of FETs installed in the amplifier	Query only. This is the concise version of the RFS query. Returns the RF Power FET Current status. Example: CFS=xxx,xxx,x.x,x.x,,x.x,	CFS=	CFS?	CFS=xx (See description of RFS. Note that each argument is separated by a comma.)



Parameter Type	Command (Instruction Code and Qualifier)	Arguments for Command or Response to Query	Description of Arguments (Note that all arguments are printable ASCII characters)	Response to Command (Target to Controller)	Query (Instruction Code and Qualifier)	Response to Query (Target to Controller)
Circuit Identification	CID=	48 bytes	Command or Query. Sets or returns a 48-byte user-defined string that identifies or names the unit or station. The CID is entered as one line, but it reads back from the unit as two 24-byte lines of data. Default value: Examples: <1/CID= Station #001SSPA #01'cr' >0001/CID= <1/CID?'cr' >0001/CID='cr' Station #001'cr'SSPA #01'cr''lf'	CID= CID? CID*	CID?	CID=xx (See Description of Arguments)



aaa.a;bbb.b;ccc.c;ddd.d;eee.e;fff.f;ggg.g;hhh.h;iii.i;jjj.j;kkk.k;lll.l;mmm.m;nnn.n; ooo.oppp.p;qqq;rrr.r;sss.s;ttt.t where: aaa.a = P24V1 bbb.b = P24V2 ccc.c = LNBVT (Not applicable on the SPOD) ddd.d = P13VT eee.e=P10V1 fff.f = A10V1 ggg.g = A10V2 (see Note) hhh.h = P7V8T iii.i = P5V8T jjj.j = P2V5T kkk.k = P1V2T Ill.1 = N5V8T mmm.m = FANR1 (see Note) nnn.n = FANR2 (see Note) ooo.o = BUCVT (Not applicable on the SPOD) ppp.p = FWPWR qqq.q = REFVT (Not applicable on the SPOD) rrr.r = LNBCS (Not applicable on the SPOD) sss.s = ATEMP ttt.t = OTEMP (see Note)	Parameter Type	Command (Instruction Code and Qualifier)	Arguments for Command or Response to Query	Description of Arguments (Note that all arguments are printable ASCII characters)	Response to Command (Target to Controller)	Query (Instruction Code and Qualifier)	Response to Query (Target to Controller)
have been selected/installed. Otherwise, the unused fields will display XXXXX.	Maintenance	N/A	95 bytes	This is the concise version of the RMS command. Returns the Maintenance status of the unit, response is semicolon delimited, in the form aaa.a;bbb.b;ccc.c;ddd.d;eee.e;fff.f;ggg.g;hhh.h;iii.i;jjj.j;kkk.k;lll.l;mmm.m;nnn.n; ooo.o;ppp.p;qqq.q;rrr.r;sss.s;ttt.t where: aaa.a = P24V1 bbb.b = P24V2 ccc.c = LNBVT (<i>Not applicable on the SPOD</i>) ddd.d = P13VT eee.e=P10V1 fff.f = A10V1 ggg.g = A10V2 (see Note) hhh.h = P7V8T iii.i = P5V8T jjj.j = P2V5T kkk.k = P1V2T lll.l = N5V8T mmm.m = FANR1 (see Note) nnn.n = FANR2 (see Note) ooo.o = BUCVT (<i>Not applicable on the SPOD</i>) ppp.p = FWPWR qqq.q = REFVT (<i>Not applicable on the SPOD</i>) rr.r = LNBCS (<i>Not applicable on the SPOD</i>) sss.s = ATEMP ttt.t = OTEMP (see Note)	CMS=	CMS?	(See Description of



Parameter Type	Command (Instruction Code and Qualifier)	Arguments for Command or Response to Query	Description of Arguments (Note that all arguments are printable ASCII characters)	Response to Command (Target to Controller)	Query (Instruction Code and Qualifier)	Response to Query (Target to Controller)
Concise Utility Status ^E	N/A	15 bytes	Query only. Returns the Maintenance status of the unit, response is semicolon delimited, in the form aaaa;bbbbb;ccc where: aaaa = Remote Unit Address bbbbb = Remote Baud Rate ccc = Reference oscillator tuning voltage DAC value (see Note) Note: ccc is only present if a reference oscillator is installed. Example: <1/CUS?'cr' >0001/CUS=aaaa;bbbbb;ccc;'cr''lf'	CUS=	CUS?	CUS=xx (See Description of Arguments)
Set RTC (Real-Time- Clock) Date ^E	DAT=	6 bytes	Command or Query. Sets or returns the real-time clock date in the form mmddyy, where; dd = day of the month, from 01 to 31, mm = month of the year, from 01 to 12 yy = year, from 00 to 96 (2000 to 2096) Example (date = April 24, 2003): <1/DAT=042403'cr' >0001/DAT='cr''lf'	DAT= DAT? DAT*	DAT?	DAT= mmddyy (See Description of Arguments)
Set RTC (Real-Time- Clock) Date	DAY=	6 bytes	Command or Query. Sets or returns the real-time clock date in the form ddmmyy, where; dd = day of the month, from 01 and 31, mm = month of the year, from 01 to 12 yy = year, from 00 to 99 (2000 to 2099) Example (date = April 24, 2003): <1/DAY=240403'cr' >0001/DAY='cr''If'	DAY= DAY? DAY*	DAY?	DAY= ddmmyy (See Description of Arguments)



Parameter Type	Command (Instruction Code and Qualifier)	Arguments for Command or Response to Query	Description of Arguments (Note that all arguments are printable ASCII characters)	Response to Command (Target to Controller)	Query (Instruction Code and Qualifier)	Response to Query (Target to Controller)
Enable Statistics Averaging	ESA=	1 byte	Command or Query. Enables or Disables averaging of statistics data at a rate of once per second for 10 seconds, in the form x, where: 0 = Disable (default value)(see Note) 1 = Enable Note: If Disabled, burst values will be logged instead of averaged values. Example: <1/ESA=0'cr' >0001/ESA='cr''lf'	ESA= ESA? ESA*	ESA?	ESA=x (See Description of Arguments)
Enable Redundancy Switch Mode	ESW=	1 byte	Command or Query. Sets or returns the redundancy state in the form x, where: 0 = Off (default value) 1 = 1:1 Redundancy TX (Only TX switch installed) 2 = 1:1 Redundancy TX + RX (TX and RX switch installed) 5 = 1:1 Manual redundancy mode (used for debugging, or redundant system setup)(see Note) Note: Manual redundancy does not support automatic switching, and the offline unit will not poll the online unit to update its configuration. Example: <1/ESW=1'cr' >0001/ESW='cr''lf'	ESW= ESW? ESW *	ESW?	ESW=x



Parameter Type	Command (Instruction Code and Qualifier)	Arguments for Command or Response to Query	Description of Arguments (Note that all arguments are printable ASCII characters)	Response to Command (Target to Controller)	Query (Instruction Code and Qualifier)	Response to Query (Target to Controller)
Retrieve Firmware Number	N/A		Query only Returns the firmware type(s) loaded into the unit in the form FW-AAAAAA B.B.BB DD/MM/YY, where: FW-AAAAAAA = the firmware part number B.B.BB = the version number DD/MM/YY = Day/Month/Year firmware released Example: <1/FRW?'cr' >0001/FRW= Boot: FW-0000082 0.0.1a 04/09/08 Bulk1: FW-0000078 0.0.1a 04/09/08 FW-0000081 0.0.1a 04/09/08 Bulk2: FW-0000078 0.0.1a 04/09/08 FW-0000081 0.0.1a 04/09/08	FRW=	FRW?	FRW={CR}Bo ot:{CR}abc{CR} Bulki:{CR}abc {CR}abc (See Description of Arguments)



Parameter Type	Command (Instruction Code and Qualifier)	Arguments for Command or Response to Query	Description of Arguments (Note that all arguments are printable ASCII characters)	Response to Command (Target to Controller)	Query (Instruction Code and Qualifier)	Response to Query (Target to Controller)
Global Amplifier Configuration	GAC=	43 bytes	Command or Query. Sets or returns the global status of the SPOD with a semicolon delimited string in the form a;b;cc.cc;dd.dd; e;fffff;g;hh;l;j;k;l;m;n;o where: a = redundancy mode (ESW) b = online status (ONL) cc.cc = Attenuation Offset (AOF) dd.dd = Customer Attenuation(ATT) e = Auto Fault Recovery (AFR) fffff = Unit Alarm Mask (MSK) g = LNB Current Source (LCS) (Not applicable on the SPOD) hh = LNB Current Window (LCW) (Not applicable on the SPOD) i = LNB Current Window Enable (CWE) (Not applicable on the SPOD) j = Enable Statistics Averaging (ESA) k = Set Statistics Interval (SSI) I = Enable Statistics Logging (ESL) (Command is always '1' Enabled) m = Auxiliary Mute (AUX) n = user mute state (MUT) o = RF power amplifier state (AMP) Example (set GAC): GAC=a;b;cc.cc;dd.dd;e;fffff;j;k;l;m;n;o;'cr'	GAC= GAC* GAC? GAC#	GAC?	GAC=xx (See Description of Arguments)
Initialize Events Pointer	IEP=	None	Command only. Resets internal pointer to allow RNE? queries to start at the beginning of the stored events log. Example: <1/IEP='cr' >0001/IEP='cr'If	IEP= IEP? IEP*	N/A	N/A



Parameter Type	Command (Instruction Code and Qualifier)	Arguments for Command or Response to Query	Description of Arguments (Note that all arguments are printable ASCII characters)	Response to Command (Target to Controller)	Query (Instruction Code and Qualifier)	Response to Query (Target to Controller)
Software Image	IMG=	1 byte	Command or Query. Sets or returns the current active software image in the form x, where: 1=Bulk Image # 1 currently active 2=Bulk Image # 2 currently active Note: if you send the IMG command, and then query the IMG value the numbers may not be equal because the command tells the firmware which image to boot from at the next bootup, and the query reports the image that the firmware booted from on the last bootup. Examples: <1/IMG=1'cr' (instructs the unit to load firmware from image #1 at the next reset / power up).	IMG= IMG? IMG* IMG#	IMG?	IMG=x (See Description of Arguments)
IP Address	IPA=	18 bytes	<1/IMG?'cr' (queries the image number that the firmware loaded during bootup) Command or Query. Sets or returns the IP address and network prefix for the 10/100 BaseT Ethernet management port, in the form xxx.xxx.xxx.xxx.xxx.yy, where: xxx.xxx.xxx.xxx.xxx is the IP address, and yy is the network prefix (8-30) Default value: 192.168.001.004.24 Note: Changing the IP address through the Telnet interface requires the user to power cycle the unit, and then restart a new Telnet session with the new IP address. The IP address that you type into the Telnet client software does not include the range parameter so it would be: 192.168.1.4 Example: <1/IPA=192.168.001.004.24'cr' >0001/IPA='cr''lf'	IPA= IPA? IPA* IPA#	IPA?	IPA= xx.xxx.xxx.xxx. yy (See Description of Arguments)
Gateway Address	IPG=	15 bytes	Command or Query. Sets or returns the Gateway IP address for the 10/100 Base Tx Ethernet management port, in the form xxx.xxx.xxx. Default value: 192.168.001.005 Example: <1/IPG=192.168.001.005'cr' >0001/IPG='cr''If'	IPG= IPG? IPG*	IPG?	IPG = xxx.xxx.xxx x



Parameter Type	Command (Instruction Code and Qualifier)	Arguments for Command or Response to Query	Description of Arguments (Note that all arguments are printable ASCII characters)	Response to Command (Target to Controller)	Query (Instruction Code and Qualifier)	Response to Query (Target to Controller)
Initialize Statistics Pointer	ISP=	None	Command only. Resets internal pointer to allow RNS? queries to start at the beginning of the stored statistics log. Example: <1/ISP='cr' >0001/ISP='cr''If'	ISP= ISP? ISP*	N/A	N/A
Retrieve next 5 unread Stored Alarms ^E	N/A	145 bytes	Query only. Returns the five oldest stored events in the alarm log. If there are no events in the log the unit will reply with LNA*. All events that are read from the log are also automatically removed from the log. Reply format: YYYYYYYYY ZZ mmddyy hhmmss'cr' YYYYYYYYYY ZZ mmddyy hhmmss'cr' YYYYYYYYYY ZZ mmddyy hhmmss'cr' YYYYYYYYYY ZZ mmddyy hhmmss'cr' YYYYYYYYYY ZZ mmddyy hhmmss'cr' YYYYYYYYYYY ZZ mmddyy hhmmss'cr' IF YYYYYYYYYY ZZ mmddyy hhmmss'cr' YYYYYYYYYYY ZZ mmddyy hhmmss'cr' YYYYYYYYYYY ZZ mmddyy hhmmss'cr' IF = Fault OK = Clear IF = Information IF	LNA=	LNA?	LNA=YYss (See Description of Arguments)



Parameter Type	Command (Instruction Code and Qualifier)	Arguments for Command or Response to Query	Description of Arguments (Note that all arguments are printable ASCII characters)	Response to Command (Target to Controller)	Query (Instruction Code and Qualifier)	Response to Query (Target to Controller)
Low Power Forward Threshold	LPT=	5 bytes	Command or Query. Sets or returns the threshold for the low forward power alarm/fault in the form xx.xx. If the forward power drops below the specified value, the alarm/fault will be indicated. Setting this parameter to the default value of 00.00 effectively disables the threshold Example: <1/LPT=00.00'cr' >0001LPT='cr''lf'	LPT = LPT? LPT *	LPT?	LPT =xx.xx (See Description of Arguments)
Local/Remote State	LRS=	1 byte	Command or Query. Sets or returns Local or Remote state for Indoor SSPA (always in remote mode for Outdoor SSPA) in the form x, where x=0, 1, 2, or 3:: 0 = Local 1=Serial 2=Ethernet 3=Serial+Ethernet (default value) Note: The user will always have query access in any mode. The LRS command is also available in all modes as a means of acquiring control. The intent of this command is to limit changes from being made on multiple interfaces at the same time. Units without a front panel will treat an entry of 0 as reserved, and will refuse the command by returning a mode error. The web page GUI will refuse connections unless LRS is set to enable Ethernet remote control. Example: <1/LRS=3'cr' >0001/LRS='cr''lf'	LRS= LRS?	LRS?	LRS=x (See Description of Arguments)
Unit MAC Address	N/A	17 bytes	Query only. Returns the MAC address of the unit, in hexadecimal format xx-xx-xx-xx-xx Example: <1/MAC?'cr' >0001/MAC=00-06-B0-00-D2-A7'cr''lf'	MAC=	N/A	MAC=xx-xx- xx-xx-xx (See Description of Arguments)



Parameter Type	Command (Instruction Code and Qualifier)	Arguments for Command or Response to Query	Description of Arguments (Note that all arguments are printable ASCII characters)	Response to Command (Target to Controller)	Query (Instruction Code and Qualifier)	Response to Query (Target to Controller)
Maximum Operating point	N/A	272 bytes	Query only. Returns the maximum operating point of the unit along with its timestamp Reply format: MAXFET=sYYYC mmddyy hhmmss'cr' MINFET=sYYYC mmddyy hhmmss'cr' MAXPTT=sYYYC mmddyy hhmmss'cr' MAXDTP=sYYYC mmddyy hhmmss'cr' MAXHTS=sYYYC mmddyy hhmmss'cr' MINHTS=sYYYC mmddyy hhmmss'cr' MAXOST=sYYYC mmddyy hhmmss'cr' MAXRFP=sZZ.ZZ mmddyy hhmmss'cr' MAXRFP=sZZ.ZZ mmddyy hhmmss'cr' Where: sYYYC is the temperature sZZ.ZZ is the power Note: not all SPODs have outside temperature monitor. In that case, MAXOST and MINOST will report XXXXX XXXXXX XXXXXX Example: <1/MOP?'cr' >0001/mop='cr' MAXFET=+000C 010208 180729'cr' MAXFET=+000C 010208 180729'cr' MAXPFT=+000C 010208 180729'cr' MAXPFT=+000C 010208 180729'cr' MAXDTP=+000C 010208 180729'cr' MINHTS=+050C 010208 180729'cr' MAXHTS=+050C 010208 180729'cr' MAXOST=XXXXX XXXXXX XXXXXX'cr' MINOST=XXXXX XXXXXX XXXXXX'cr' MINOST=XXXXX XXXXXX XXXXXX'cr' MAXRFP=+00.00 010208 180659'cr' MINRFP=+00.00 010208 180659'cr' MINRFP=+00.00 010208 180659'cr'	MOP=	N/A	(See Description of Arguments)



Parameter Type	Command (Instruction Code and Qualifier)	Arguments for Command or Response to Query	Description of Arguments (Note that all arguments are printable ASCII characters)	Response to Command (Target to Controller)	Query (Instruction Code and Qualifier)	Response to Query (Target to Controller)
Unit Alarm Mask	MSK=	5 bytes	Command or Query. Sets or returns alarm mask conditions in the form abcde, where: 0 = Fault, 1 = Alarm, 2 = Masked a = Low Forward RF Power b = External Reference Lock detect c = Fan Speed d = LNB Current Detect e = LNB 22V Power Supply Default value: 22111 Example: <1/MSK=22111'cr' >0001/MSK=1'cr''lf'	MSK= MSK? MSK*	MSK?	MSK=abcde (See Description of Arguments)
Mute State	MUT=	1 byte	Command or Query. Sets or return the unit mute state in the form x, where: 0 = Disable (Not Muted) 1 = Enable (Muted) (default value) 2 = Unit muted due to AUX mute signal (see Note) Note: This value is only shown in the response to a query and cannot be given as a command. When MUT returns a '2' it indicates that one of the "hardware" mute conditions is present. For example, an auxiliary mute could be present if the auxiliary mute has been enabled, and the signal to unmute the unit is not provided. If MUT returns an unexpected value of '2' then check the active faults and the status of the auxiliary mute. Example: <1/MUT=1'cr' >0001/MUT=1'cr'If'	MUT= MUT? MUT*	MUT?	MUT=x (See Description of Arguments)
Number of Unread Stored Events	N/A	3 bytes	Query only. Returns the number, in the form xxx, of unread stored events Example: <1/NUE?'cr' >0001/NUE=126'cr''lf'	NUE=	NUE?	NUE=xxx
Number of Unread Stored Statistics	N/A	3 bytes	Query only. Returns the number, in the form xxx, of unread stored statistics Example: NUS=126	NUS=	NUS?	NUS=xxx



Parameter Type	Command (Instruction Code and Qualifier)	Arguments for Command or Response to Query	Description of Arguments (Note that all arguments are printable ASCII characters)	Response to Command (Target to Controller)	Query (Instruction Code and Qualifier)	Response to Query (Target to Controller)
Offline Mute	OFM=	1 byte	Command or Query. Sets or returns offline mute in the form x, where: 0 = Disable (Not Muted) 1 = Enable (Muted) 2 = Mute Rx (Not applicable on the SPOD) 3 = Mute Tx 4 = Mute Rx+LNB (Not applicable on the SPOD) 5= Mute Tx+LNB (Not applicable on the SPOD) Example: <1/OFM=1'cr' >0001/OFM=1'cr'If	OFM= OFM?	OFM?	OFM=x
Online Status	ONL=	1 byte	Command or Query. Sets or returns the Redundancy Online status in the form x, where: 0 = Offline (Query only) (see Note 2) 1 = Online Notes: 1. The ONL query always returns an online response if the unit is not running in redundant mode. If redundancy is enabled then the query will indicate the position of the Tx waveguide switch that enables one of the units to be connected to the antenna. 2. Sending ONL=0 will not generate a syntax error; however setting ONL to zero will not cause the unit to go offline. The online status is determined by the TX waveguide redundant switch position, and only the offline unit may drive the switches. Instead of sending ONL=0 to the online unit the ONL=1 command should be sent to the offline unit to generate a redundant switchover. Example: <1/ONL=1'cr' >0001/ONL='cr''If'	ONL= ONL? ONL*	ONL?	ONL=x



Parameter Type	Command (Instruction Code and Qualifier)	Arguments for Command or Response to Query	Description of Arguments (Note that all arguments are printable ASCII characters)	Response to Command (Target to Controller)	Query (Instruction Code and Qualifier)	Response to Query (Target to Controller)
Overdrive Trigger Level	OVU=	4 bytes	Command or Query. Sets or returns the overdrive trigger level in the form xx.x, where: xx.x=P1dB rated to (P1dB rated - 10.00, in dB) Default value: P1dB rated value. COMMAND EXAMPLE: <0001/OVU=42.5{CR} NOTES: Maximum value can be 10.0. However, current customer attenautation (ATT) setting will factor into how large OVU value can be used. For example: if ATT is 12.00 and ATT max range is 20.0, then maximum value OVU can be is 8.0.	OVU= OVU? OVU*	OVU?	OVU=xx.x
Overdrive Protection Mode	OVR=	1 byte	Command or Query. Sets or returns the overdrive mode in the form x, where: 0=Disabled (DEFAULT) 1=Enabled	OVR= OVR? OVR*	OVR?	OVR=x
Part Number	N/A	Various 1- 96 bytes	Query only. Returns the Comtech part number of the unit. This part number is the unit's DOTCODE at the time of manufacture. The DOTCODE may be up to 96 printable ASCII characters long. Example: <1/PNM?'cr' >0001/PNM=HPODC0.350WRSW00'cr''lf'	PNM=	PNM?	PNM=xx (See Description of Arguments)



Retrieve N/A 168 bytes Query only.	AS=	RAS?	RAS=xx
Returns the alarm status of the unit, where: OK = no fault condition, FT = faulted, AL = alarm, YS = Yes, NO = No, MS = masked, ?? = invalid due to hardware failure, NA = not applicable because hardware/options not installed. Example: Alarm</td <td></td> <td></td> <td>(See Description of Arguments)</td>			(See Description of Arguments)



Parameter Type	Command (Instruction Code and Qualifier)	Arguments for Command or Response to Query			Query (Instruction Code and Qualifier)	Response to Query (Target to Controller)
Reboot	RBT=	1 byte	Command only. Performs a soft reboot in the form x, where: 1 = Reboot System	RBT = RBT? RBT*	N/A	RBT=x (See Description of Arguments)
Retrieve Configuration Status	N/A	45 bytes	Query only. Returns the configuration status of the unit. Examples: RCS='cr' ATT=12.75'cr' AMP=1'cr' MUT=1'cr' ONL=1'cr' ESW=1'cr' AOF=00.00'cr' AFR=1'cr' XRF=N/A'cr''If' (Not applicable on the SPOD) OVR=0'cr' Where: ATT= attenuation in dB AMP= RF power amplifier state, 0=OFF, 1=ON MUT=RF mute state, 0=un-muted, 1=muted RED=Online status for redundancy ESW=Redundancy state and mode, states: 0=OFF, 1=ON Tx only, 2=ON Tx & Rx AOF=Attenuator Offset in dB AFR= auto fault recovery, 0=manual, 1=auto OVR = Overdrive Protection	RCS=	RCS?	RCS=xx (See Description of Arguments)
Online Status	RED=	1 byte	Command or Query. Sets or returns Redundancy Online status in the form x, where: 0 = Offline 1 = Online Note: this command is functionally identical to the ONL command. Example: <1/RED=1'cr' >0001/RED='cr''If'	RED= RED? RED*	RED?	RED=x



Parameter Type	Command (Instruction Code and Qualifier)	Arguments for Command or Response to Query	Description of Arguments (Note that all arguments are printable ASCII characters)	Response to Command (Target to Controller)	Query (Instruction Code and Qualifier)	Response to Query (Target to Controller)
Retrieve Equipment Type ^E	N/A	22 bytes	Query only. Returns a string indicating the Model Number and the version of the M&C firmware installed in the unit. Example: <1/RET?'cr' >0001/RET=PS2053-5967-C REF BUC VER: 1.5.2'cr"lf'	RET=	RET?	RET=xx (See Description of Arguments)
RF Power FET Current Status	N/A	variable length depending on the number of FETs installed in the RF amplifier	Query only. Returns all FET currents in the form xx.x when the value is >1 Amp, or xxx when the value is < 1 AMP Example: <1/RFS? 'cr' >0001/RFS='cr' Q01=.xxx'cr' Q02=.xxx'cr' Q03=xx.x'cr' Q04=xx.x'cr' Q05=xx.x'cr' Q06=xx.x'cr' Q07=xx.x'cr' Q09=xx.x'cr' Q10=xx.x'cr' Q10=xx.x'cr' Q10=xx.x'cr' Q11=xx.x'cr' Q11=xx.x'cr' Q12=xx.x'cr' Q13=xx.x'cr' Q14=xx.x'cr' Q15=xx.x'cr' Q15=xx.x'cr' Q16=xx.x'cr'	RFS=	RFS?	RFS=xx (See Description of Arguments)



Parameter Type	Command (Instruction Code and Qualifier)	Arguments for Command or Response to Query	Description of Arguments (Note that all arguments are printable ASCII characters)	Response to Command (Target to Controller)	Query (Instruction Code and Qualifier)	Response to Query (Target to Controller)
Retrieve Maintenance Status	N/A	213 bytes, alphanumeric	Query only. Returns maintenance status where: P24V1 = +24V power supply P24V2 = +24V switch power supply LNBVT = +13/18V LNB power supply (Not applicable on the SPOD) P13VT = +13.5V power supply P10V1 = +10V1 power supply A10V1 = 10V1 on RF Module A10V2 = 10V2 on RF Module (see Note) P7V8T = +7.8V power supply P5V8T = +5.8V power supply P5V8T = +5.8V power supply P1V2T = +1.2V power supply P1V2T = +1.2V power supply FANR1 = Fan 1 speed in percent (see Note) BUCVT = BUC tuning voltage (Not applicable on the SPOD) FWPWR = Forward power in dBm REFVT = Reference osc. tuning voltage (Not applicable on the SPOD) LNBCS = LNB current supply in mA (Not applicable on the SPOD) ATEMP = Heatsink temperature in Celsius OTEMP = Outdoor temperature in Celsius (see Note) Note: FANR2, A10V2, and OTEMP will appear if the appropriate options are installed; otherwise, the values will report XXXX. Example: <1/RMS?'cr' >0001/RMS='cr', P24V1=024.1'cr' P24V2=024.1'cr', LNBVT=000.0'cr' P13VT=013.4'cr', P10V1=010.1'cr' A10V1=010.1'cr', A10V2=010.1'cr' P7V8T=007.8'cr', P5V8T=005.8'cr' P24V5T=002.5'cr', P5V8T=005.8'cr' P24V5T=002.5'cr', FANR1=100.0'cr' FNPVRR=+83.2'cr', REFVT=001.8'cr' LNBCS=000.0'cr', ATEMP=+40.0'cr' OTEMP=+25.0'cr', ATEMP=+40.0'cr'	RMS=	RMS?	RMS=xx (See Description of Arguments)



Parameter Type	Command (Instruction Code and Qualifier)	Arguments for Command or Response to Query	Description of Arguments (Note that all arguments are printable ASCII characters)	Response to Command (Target to Controller)	Query (Instruction Code and Qualifier)	Response to Query (Target to Controller)
Retrieve Next 5 Unread Stored Events	N/A	75 bytes	Query only. Returns the oldest 5 Stored Events which have not yet been read over the remote control in the format {CR}Sub-body{CR}Sub-body{CR}Sub-body{CR}Sub-body{CR}Sub-body{CR}Sub-body{CR}Sub-body{CR}Sub-body-ABCCddmmyyhhmmss: A being the fault/clear indicator. F=Fault C=Clear I=Info B being the fault type where: 1=Unit 2=RF 3=Log CC is Fault Code numbers, as in RAS? or Info Code, which is: 0=Power Off 1=Power On 2=Log Cleared 3=Global Config Change 4=Redundancy Config Change RAS fault codes map as follows: 1. P24V1 2. P24V2 3. LNBVT (Not applicable on the SPOD) 4. P13VT 5. A10V1 6. A10V2 7. 10VPS 8. P5V8T 9. P2VST 10. P1VZT 11. N5V8T 12. P7V8T 13. FANR1 14. FANR2 15. ATEMP 16. SHTDN 17. IICST 18. FWPWR 19. CHKSM 20. FPGAD 21. BUCLD (Not applicable on the SPOD) 23. LNBCS (Not applicable on the SPOD) 24. SWITC 25. OVERD If there are less than 5 events to be retrieved, the remaining positions are padded with zeros. If there are no new events, the response is RNE*. A Global Config Change is defined as any time a command is successfully executed. A query does not set the status change.	RNE=	RNE?	RNE={CR}AB CCddmmyyhh mmss{CR}AB CCddmmyyhh mmss{CR}AB CCddmmyyhh mmss{CR}AB CCddmmyyhh mmss{CR}AB CCddmmyyhh mss (See Description of Arguments)



Parameter Type	Command (Instruction Code and Qualifier)	Arguments for Command or Response to Query	Description of Arguments (Note that all arguments are printable ASCII characters) Co (T Co		Query (Instruction Code and Qualifier)	Response to Query (Target to Controller)
Retrieve Next 5 Unread Stored Statistics	N/A	75 bytes	Query only. Returns the oldest 5 unread stored statistics entries in the reply format: {CR}Sub-body{CR}Sub-body{CR}Sub-body{CR}Sub-body, where: Sub-body= ddmmyyhhmmssaaa.abbb.bccc.cdd.ddefghhh.hiii.i ddmmyy = day/month/year hhmmss = hour:minute:second aaa.a = Operating Temperature (I.E. +40.0) bbb.b = Amp Temperature (I.E. +40.0) ccc.c = RF Power output dd.dd = Attenuation Setting e = Amp On/Off f = Mute On/Off g = Online/Offline Status hhh.h = Not applicable on the SPOD iii.i = Not applicable on the SPOD If there are less than 5 entries to be retrieved, the remaining positions are padded with zeros. If there are no new entries, the response is RNS*.	RNS=	RNS?	RNS={CR}Sub-body{CR}Sub-body{CR}Sub-body{CR}Sub-body{CR}Sub-body (See Description of Arguments)
Serial Number ^E	N/A	9 bytes	Query only. Returns the unit's 9 digit serial number in the form of xxxxxxxxx. Example: <1/RSN?'cr' >0001/RSN=072282040'cr''lf'	RSN=	RSN?	RSN=xxxxxx xx (See Description of Arguments)
Retrieve Utility Status	N/A	23 bytes, alpha- numeric	Query only. Returns the utility status of the unit. Example: <1/RUS='cr' >0001/RUS='cr' ADR=0001'cr' BDR=09600'cr' REF=087'cr"lf' (see Note) Note: REF will only appear if a reference oscillator is installed.	RUS=	RUS?	RUS=xx (See Description of Arguments)



Parameter Type	Command (Instruction Code and Qualifier)	Arguments for Command or Response to Query	Description of Arguments (Note that all arguments are printable ASCII characters) Command or Query.		Query (Instruction Code and Qualifier)	Response to Query (Target to Controller)
Remote Baud Rate	SBR=	4 bytes	Command or Query. Sets or returns the remote baud rate in the form xxxx, where: 2400 = 2400 baud 4800 = 4800 baud 9600 = 9600 baud (default value) 19K2 = 19200 baud 38K4 = 38400 baud Note: When changing baud rates remotely the response to the command will be returned using the same baud rate as that used to send the command. Examples: <1/SBR=9600'cr' >0001/SBR=9600'cr''lf' <1/SBR?'cr'		SBR?	SBR=xxxx (See Description of Arguments)
Set FSK Address	SFA=	2 bytes, numeric	>0001/SBR=09600'cr''lf' Command or Query. Sets or returns the FSK Address in the form xx, where:	SFA = SFA? SFA*	SFA?	SFA=xx (See Description of Arguments)
Summary Fault Status ^E	N/A	1 byte	>0001/SFA='cr''lf' Query only. Returns the condition of the summary fault relay in the form x, where: 0 = Not Faulted (SumFLT_COM J6 pin K is not connected to SumFLT_NC J6 pin M) 1 = Faulted (SumFLT_COM J6 pin K is connected to SumFLT_NC J6 pin M) Example: <1/SFS? >0001/SFS=0'cr''lf'	SFS=	SFS?	SFS=x (See Description of Arguments)
SNMP Authenticatio n Trap Enable	SNA=	1 byte	Command or Query. Sets or returns the SNMP Authentication in the form x, where: 0=Disabled 1=Enabled Example: <1/SNA=0	SNA= SNA?	SNA?	SNA=x (See Description of Arguments)



Parameter Type	Command (Instruction Code and Qualifier)	Arguments for Command or Response to Query	Description of Arguments (Note that all arguments are printable ASCII characters) Co (Ta Co) Command or Query.		Query (Instruction Code and Qualifier)	Response to Query (Target to Controller)
SNMP Enable	SNM=	1 byte	Command or Query. Sets or returns SNMP in the form x, where: 0=Disabled 1=Enabled Example: <1/SNM=0	SNM= SNM?	SNM?	SNM=x (See Description of Arguments)
Serial Number	N/A	9 bytes	Query only. Returns the unit's nine-digit serial number in the form xxxxxxxx Note: this command is functionally identical to RSN. Example: <1/SNO?'cr' >0001/SNO=072282040'cr"lf'	SNO=	SNO?	SNO=xxxxxxx xx (See Description of Arguments)
Remote Address	SPA=	4 bytes	Command or Query. Sets or returns the Physical Address in the form xxxx, where: xxxx = 0001 to 9999, resolution=0001 Default value: 0001 Example: <1/SPA=0412'cr' >0001/SPA='cr''lf'	SPA= SPA? SPA*	SPA?	SPA=xxxx (See Description of Arguments)
SNMP Read Community	SRC=	16 bytes, characters, no spaces	Command or Query. Sets or returns the SNMP Read Community string. Empty string is not allowed Example: <1/SRC=public	SRC = SRC!	SRC?	SRC =x (see Description of Arguments))
SNMP System Contact	SSC=	255 bytes, characters,	Command or Query. Sets or returns the SNMP System Contact string. Example: <1/SSC=Joe Net Admin. If not configured it returns empty string: <1/SSC=	SSC = SSC!	SSC?	SSC =x [1128] (see Description of Arguments)
Set Statistics Interval	SSI=	2 bytes	Command or Query. Sets or returns the interval at which statistics are logged, in the form xx, where: xx = 01 to 99 minutes, resolution is in 01 minute increments Default value: 90	SSI= SSI?	SSI?	SSI=xx (See Description of Arguments)
			Example: <1/SSI=90'cr' >0001/SSI='cr''lf'			



Parameter Type	Command (Instruction Code and Qualifier)	Arguments for Command or Response to Query	Description of Arguments (Note that all arguments are printable ASCII characters)	Response to Command (Target to Controller)	Query (Instruction Code and Qualifier)	Response to Query (Target to Controller)
SNMP System Location	SSL=	255 bytes, characters,	Command or Query. Sets or returns the SNMP System Location string Example: <1/SSL=Upstairs back right. Note: If not configured it returns empty string. <1/SSL=	SSL = SSL!	SSL?	SSL =x [1128] (see Description of Arguments)
SNMP Unit Name	SSN=	16 bytes, characters,	Command or Query. Sets or returns the SNMP System Name string Example: <1/SSN=Remote1. Note: If not configured it returns empty string. <1/SSC=	SSN = SSN!	SSN?	SSN =x [1128] (see Description of Arguments)
SNMP Trap Destination IP Address 1	STA=	15 bytes, Numerical	Command or Query. Sets or returns the IP address of the first SNMP Trap destination IP Address 1 where traps will be sent, in the form xxx.xxx.xxx Example: <1/STA=010.006.030.001 Note: When not configured, returns >0001/STA=0.0.0.0	STA = STA!	STA?	STA=xxx.xxx.x xx.xxx (see Description of Arguments)
SNMP Trap Destination IP Address 2	STB=	15 bytes, Numerical	Command or Query. Sets or returns the IP address of the first SNMP Trap destination IP Address 2 where traps will be sent, in the form xxx.xxx.xxx Example: <1/STB=010.006.030.001 Note: When not configured, returns >0001/STB=0.0.0.0	STB = STB!	STB?	STB=xxx.xxx.x xx.xxx (see Description of Arguments)
SNMP Trap Version	STV=	1 byte			STV?	STV =x (see Description of Arguments)
SNMP Write Community	SWC=	16bytes, characters, no spaces	Command or Query. Sets or returns the SNMP write community string. Empty string is not allowed Example: <1/SWC=private	SWC = SWC!	SWC?	SWC =x (see Description of Arguments)



Parameter Type	Command (Instruction Code and Qualifier)	Arguments for Command or Response to Query	Description of Arguments (Note that all arguments are printable ASCII characters)	Response to Command (Target to Controller)	Query (Instruction Code and Qualifier)	Response to Query (Target to Controller)
Software Revision	N/A	34-37 bytes	Query only. Returns the value of the internal software revision installed in the unit, in the form: Boot:x.y.z Bulk1:x.y.z Bulk2:x.y.z -or- Boot:x.y.zz Bulk1:x.y.zz Bulk2:x.y.zz	SWR=	SWR?	SWR=Boot:x.y .zz Bulk1:x.y.zz Bulk2:x.y.zz (See Description of Arguments)
Set RTC Time	TIM=	6 bytes	Command or Query. Sets or returns the real-time clock time, from midnight, in the form hhmmss, where: hh = hours, from 00 to 23 mm = minutes, from 00 to 59 ss = seconds, from 00 to 59 Example (time = 23 hours, 12 minutes, and 59 seconds since midnight): <1/TIM=231259'cr' >0001/TIM='cr''lf'	TIM = TIM? TIM *	TIM?	TIM=xxxxxx (See Description of Arguments)
Temperature	N/A	5 bytes	Query only. Returns the temperatures of the Heatsink in the form of sxxxx, where: s = sign (+) or (-) xxxx = temperature. Example: <1/TMP=+26.0	TMP=	TMP?	TMP=sxxxx (See Description of Arguments)
Retrieve Number of Unread Stored Alarms ^E	N/A	2 bytes	Query only. Returns the number of stored alarms that remain unread in the alarm log, in the form xx. A maximum of 255 events may be stored in the alarm log. Numbers over 99 are reported as 99. Example reply: <1/TNA? 'cr' >0001/TNA=14'cr''lf'	TNA=	TNA?	TNA=xx (See Description of Arguments)
Retrieve Number of Unread Stored Events	N/A	2 bytes, numerical	Query Only. Returns the number of stored events that remain unread in the events logs, in the form xx. Example: <1/TNE? 'cr' >0001/TNE=18'cr"If'	TNE=	TNE?	TNE=xx (See Description of Arguments)



Parameter Type	Command (Instruction Code and Qualifier)	Arguments for Command or Response to Query	Description of Arguments (Note that all arguments are printable ASCII characters)	Response to Command (Target to Controller)	Query (Instruction Code and Qualifier)	Response to Query (Target to Controller)
Time Protocol Enable	TPE=	1 byte, numerical	Command or Query. Sets or returns the Time Protocol setting in the form x, where: 0 = Time protocol disabled 1 = Time protocol enabled Example (Time protocol enabled): <1/TPE=1'cr'	TPE= TPE?	TPE?	TPE=x (See Description of Arguments)
Time Protocol Server	TPS=	15 bytes, alpha- numeric	Command or Query. Sets or returns the Time Server IP address for the Unit Tx Ethernet management port, in the form xxx.xxx.xxx Default value: 255.255.255 Example: <1/TPS=192.168.001.005	TPS= TPS?	TPS?	TPS= xx.xxx.xxx.xxx. yy (See Description of Arguments)
Terminal Status Change	N/A	1 byte	Query only. Indicates if there has been a change in the configuration since the last time a command was issued, in the form x, where: 0 = no status change 1 = there has been a status change. A status change is defined as any time a parameter is changed, such as when command that changes a value is successfully executed. A status change also results when there is a redundant switchover, or a fault condition. A query does not set the status change flag. The status change flag is cleared after being read. Example: <1/TSC?'cr' >0001/TSC=0'cr''lf'	TSC=	TSC?	TSC=x (See Description of Arguments)



Parameter Type	Command (Instruction Code and Qualifier)	Arguments for Command or Response to Query	Description of Arguments (Note that all arguments are printable ASCII characters)	Response to Command (Target to Controller)	Query (Instruction Code and Qualifier)	Response to Query (Target to Controller)
External Reference Mute ^O	XRM=	1 byte numeric	Command or Query. Sets or returns the external reference mute state in the form x, where: 0 = Disable 1 = Enable (see Note) Note: To enable this command, the internal reference oscillator option must be installed; otherwise, a mode error will result. A hardware mute condition generated by the XRM mute is one of the conditions that can cause the MUT command to return MUT=2. When enabled, the unit will mute if an external reference oscillator is not detected. Example: <1/XRM=1'cr'	XRM= XRM? MSK*	XRM?	XRM=x (See Description of Arguments)



BLANK PAGE



Notes:				
,				



Appendix A. 1:1 REDUNDANCY

A.1 SPOD Redundancy Operation Overview

The SPOD Outdoor Amplifier / Block Up Converter can be used in a redundancy configuration by connecting the appropriate 1:1 Redundancy cable to the 'J6|COM1' Connector (see Chapter 2. SYSTEM CONNECTIONS, INSTALLATION AND STARTUP). Once the cable is attached, with the units placed in Redundancy Mode via the correct remote command the system automatically configures the backup (offline) unit by copying the configuration from the active (online) unit.

A.2 1:2 Redundancy Mode (FUTURE)

The SPOD will support 1:2 Redundancy Mode in future releases via an external controller box. **1:2 Redundancy Mode is not addressed in this appendix.**

A.3 1:1 Redundancy Mode

In 1:1 Redundancy Mode, the unit that is currently not the active (online) unit (as determined by the switch position) will be the controlling backup (offline) unit.

A.3.1 Ethernet-based Monitor and Control



See Chapter 4. ETHERNET-BASED REMOTE PRODUCT MANAGEMENT for detailed information about using this interface.

Ethernet-based Remote Product Management/Monitor and Control (M&C) of any SPOD Standalone or 1:1 Redundancy application is available through use of the optional LPODnet M&C Netbook Accessory Kit (Comtech Kit KT-0000203). This kit provides the user with on-site access to the SPOD's remote Telnet, SNMP, or HTTP Web Server interfaces. For detailed information about this optional accessory, see the **LPODnet M&C Accessory for LPOD or SPOD PS 1, PS 1.5, PS 2 Operation Manual** (Comtech P/N MN-LPODNET).

Appendix A A–1 MN-SPODPSX






Figure A-1. Ethernet-based M&C using Comtech Kit KT-0000203

A.3.1.11:1 Redundant System Setup (Using a Single Ethernet Interface)



See Chapter 5. SERIAL-BASED REMOTE PRODUCT MANAGEMENT for detailed information about the remote commands and queries specified in this section.

To set up a 1:1 Redundancy System using a single Ethernet interface, do these steps:

Step	Task			
1	Turn both units off, and then connect them to the redundant system hardware using the proper cables.			
2	Turn on Unit #2, and change its serial remote address from 1 (factory default) to a valid unique value (typically 2) so that it does not conflict with any other unit in the system.			
3	Change Unit #2's IP address from the factory default (192.168.1.4/24) to a valid unique value (typically 192.168.1.3/24) so that it does not conflict with any other unit in the system.			
4	Enable redundant mode by setting the ESW serial remote command (ESW=1). The waveguide switch / switches throw may be heard when redundant mode is enabled. Unit #2 is now the online unit.			
5	Turn on Unit #1.			
6	Change Unit #1's serial remote address / IP address if necessary (typically the factory default values are correct).			
7	Enable redundant mode by setting the ESW command (ESW=1). The waveguide switch / switches throw may be heard when redundant mode is enabled. Unit #1 is now the online unit.			
8	Set up all parameters for Unit #1 so that the configuration can be copied to Unit #2 (AMP , MUT , ATT , etc.).			

Appendix A A–2 MN-SPODPSX



A.3.2 Serial-based Monitor and Control




The EIA-232 Interface is not available for 1:1 Redundancy.




See Chapter 5. SERIAL-BASED REMOTE PRODUCT MANAGEMENT for detailed information about the remote commands and queries specified in this section.

Serial-based Remote Product Management/Monitor and Control (M&C) of any SPOD Standalone or 1:1 Redundancy application is available through use of the optional CLC-10 Handheld Terminal M&C Accessory Kit (Comtech Kit KT-0020518). This kit provides the user with onsite access to the SPOD's serial remote control interface. For detailed information about this optional accessory, see the CLC-10 Comtech LPOD Controller User's Guide (Comtech P/N MN-CLC10).



1:1 REDUNDANCY APPLICATIONS



STANDALONE APPLICATIONS

Figure A-2. Serial-based M&C using Comtech Kit KT-0020518

Serial command **ESW** determines system operation. If **ESW=1** is executed in both units, the system will be in Automatic Redundancy mode. In this mode, if a fault is detected with the active (online) unit – either by loss of communications between the backup (offline) and active units, or via the summary fault – the backup unit will trigger the waveguide switch and, assuming the backup unit is not faulted, will become the active unit. The backup unit will also poll the active unit at regular intervals attempting to maintain configuration compatibility with the active unit; ensuring that, should a fault occur, the backup unit is configured exactly the same as the active unit.

The SPOD redundant mode does not specify which unit must be the backup (offline) unit. Instead, the status of the backup (offline) and active (online) units are determined by the waveguide switch position.

Appendix A A–3 MN-SPODPSX



The advantage to using this redundant method is that, after a failure is detected and the backup unit causes a redundant switchover to occur, the failed unit can be replaced without forcing a second switchover to occur. This is because the backup unit becomes the active unit, and when *another* unit is installed in the system it automatically becomes the *new* backup unit.

Redundant mode allows the backup (offline) unit to take control of the redundant system and force a redundant switchover when there is a problem with the active (online) unit. Currently, 1:1 redundancy is supported with either *transmit switching* or *transmit and receive switching*. The backup unit controls the waveguide switches and polls the active unit through the inter-unit redundant link, so that it will be ready to take over for the active unit if necessary.

Because the inter-unit redundant link uses the EIA-232 interface to communicate, the user remote commands to the redundant system must instead be sent through one of the other remote communications interfaces (i.e., EIA-485, Telnet, HTTP, or SNMP). The inter-unit redundant link is not used when the units are in manual redundant mode or when they are in standalone (redundancy disabled).

The following parameters are updated via the inter-unit redundant link (the equivalent remote command is shown in parentheses):

- Amplifier state (AMP)
- Attenuation (**ATT**)
- Auxiliary Mute (AUX)
- *Date (**DAY**)
- Enable Statistics Averaging (**ESA**)
- Enable Statistics Logging (ESL)
- Low Power Threshold (**LPT**)

- User fault mask (MSK)
- RF mute (**MUT**)
- Offline Mute (**OFM**)
- Set Baud Rate (**SBR**)
- Set Statistics Interval (SSI)
- *Time (TIM)
- Local / Remote Setting (**LRS**)



* Day and Time are only updated when the inter-unit redundant link is either established or re-established.

The **online status** of a unit in a redundant system is determined by the position of the Tx waveguide switch. When the Tx waveguide switch is oriented to allow a unit to send RF power to the antenna (as determined by the waveguide switch failsafe indicator), the unit is considered to be **online**. Otherwise, the unit is considered to be **offline**.

When redundant mode is disabled, the unit will always report that it is online. This is because standalone mode does not use the Tx waveguide switch position to determine online status, since there are no waveguide switches monitored and controlled by the unit in standalone mode.

Only the offline unit is allowed to initiate a redundant switchover by throwing the waveguide switches. The offline unit will initiate a redundant switchover if any of the following conditions are met:

- Online unit faulted, and offline unit is not faulted.
- Inter-unit redundant link established, and then timed out.
- Mismatched waveguide switch condition is detected.
- Unit is forced online through a remote command.

If the unit has offline mute (**OFM**) enabled, then the unit will mute the RF output when it is offline.

Appendix A A–4 MN-SPODPSX



A.3.2.1 Applicable Serial-based Redundancy Commands and Queries



See Chapter 5. SERIAL-BASED REMOTE PRODUCT MANAGEMENT for detailed information about the remote commands and queries specified in this section.

Remote commands applicable to redundancy operations are as follows:

Remote Command	Meaning	Functional Description
RED	Redundancy Online/Offline	Reports the appropriate unit's online/offline status. Also used to force a unit to go active (online).
ESW	Enable Switch Mode	Puts the unit into redundancy or standalone (manual) mode.
AOF	Attenuation Offset	Individual attenuation command, used to adjust out small differences in power levels of different amplifier.

A.4 Troubleshooting Connectivity Issues



Each network is unique, and network configuration and management are outside the scope of this manual. This information is provided as a helpful troubleshooting tool, but trained network specialists may be required to make an Ethernet-enabled product work in a specific network. This section offers common solutions to network connectivity issues experienced by Comtech technical support personnel while developing or testing Ethernet-enabled products using the Windows XP operating system.

The most common connectivity issue is neglecting to properly connect the SPOD to the external PC Ethernet interface.

Check for link and activity LEDs to light up on the NIC or network switch where the SPOD is connected to the Ethernet network. If the link LED is lit, validate the Ethernet connection by pinging the SPOD at its IP address using the Windows Command-line interface:

- To access the Command-line interface, click Start → Run... from the external PC's Taskbar.
- Type "CMD" (without the quotes) into the **Run** dialog box, and then click **OK**.
- At the Command-line prompt (typically C:\>), type "ping 192.168.1.4" (without the quotes).

If the IP address of the unit is not set to factory default (192.168.1.4), then use the unit's user-assigned IP address. If the ping command responds with the "**Request timed out.**" error message, then the SPOD cannot be seen by the computer. Otherwise, if there is a time listed in milliseconds, then the SPOD properly responded to the ping command and it is visible to the computer at the IP address that was pinged.

Another common connection problem is due to conflicts in the Address Resolution Protocol (ARP) table, caused when a user connects two different pieces of hardware (with unique MAC addresses) to a single Ethernet port while both pieces of hardware are configured with the same Ethernet address.

Appendix A A–5 MN-SPODPSX



This often happens when configuring new units set to the factory default IP address with a laptop that has a single Ethernet port (e.g., Comtech's LPODnet M&C Netbook Accessory product). If there are multiple units to be configured that are all set to the factory default IP address, then turn on one unit at a time, and reinitialize the Address Resolution Protocol (ARP) table each time a new unit is connected to the network as follows:

- First, check the values in the Address Resolution Protocol (ARP) table on the computer. This can be accomplished using the Windows Command-line interface:
 - To access the Command-line interface, click Start → Run... from the external PC's Taskbar.
 - o Type "CMD" (without the quotes) into the **Run** dialog box, and then click **OK**.
- From the Command-line interface window, type "ARP -a" (without the quotes), and then press the Enter key.
- If the SPOD IP address is not displayed in the ARP table, then re-initialize the ARP table by typing "ARP -d" at the Command-line window prompt. The SPOD IP address should now be displayed when the ARP table is queried again.
- If the unit's IP address is still not shown and the ping test has failed, then verify the Ethernet settings of the unit using another remote control interface that is not dependant on the Ethernet port (e.g., EIA-485, EIA-232, or FSK).

Appendix A A–6 MN-SPODPSX



A.5 1:1 Redundancy System Cabling and Installation

Figure A-3 shows the schematic diagram for cabling 1:1 Redundancy applications. For any 1:1 Redundancy System setup, care should be exercised in cable installation:

- Install the cables using the most direct route avoid all sharp bends.
- Secure all cables with clamps and ties.
- Cable connectors used in outdoor applications Type 'N' connectors and military style (MS) connectors in particular must be sealed to avoid moisture seepage. Moisture can seep into junctions at the plug end of the connector, between the fixed and movable parts, and where the cable connects to the connector. In the presence of such seepage, signal attenuation and possible loss of signal can occur. Therefore, seal all cable junctions with a self-amalgamating tape, such as 3M Type 23 Scotch Self-Amalgamating tape, or equivalent.

For details about the cables used in both Standalone and 1:1 Redundancy applications, see **Appendix B. CABLE DRAWINGS**.

Appendix A A–7 MN-SPODPSX






Figure A-3. Typical SPOD 1:1 Redundancy System Cabling Schematic

Appendix A A–8 MN-SPODPSX



A.6 Redundancy System Assembly Kit Examples

Several kits are available from Comtech to mount and install standalone or redundant SPODs. These kits are tailored to the unit model and its operational frequency. The figures and tables provided in the subsections that follow provide examples of these currently available kits.



The illustrations provided in this appendix are intended as reference examples only. The dimensions shown in these example figures are subject to change and may not reflect your installed configuration.

See Chapter 2. SYSTEM CONNECTIONS, INSTALLATION AND STARTUP for the available assembly kit options for 1:1 SPOD Standalone configurations.

The figures and tables provided in the subsections that follow illustrate the Comtech kits currently available for assembling SPOD PS 1, PS 1.5 or PS 2 1:1 Redundancy Systems. Unless otherwise noted, all 1:1 Redundancy Kit figures depict use of AC Option, Waveguide Output SPODs.

Sect. / Product	TABLE (Parts List)	FIGURE(S)	Comtech PART NO.	EXAMPLE DESCRIPTION
	A-1	A-4, A-5	KT-0000104	PS 1 C-BAND 1:1 KIT, MTG & CABLE, Tx SWITCH
A.6.1	A-2	A-6, A-7	KT-0000090	PS 1 C-BAND COAX OUTPUT1:1 KIT, MTG & CABLE, Tx SWITCH
SPOD PS 1	A-3	A-8, A-9	KT-0000089	PS 1 Ku-BAND 1:1 KIT, MTG & CABLE, Tx SWITCH
	A-4	A-10, A-12	KT-0000170	PS 1 X-BAND 1:1 KIT, MTG & CABLE, Tx SWITCH
A.6.2	A-5	A-12, A-13	KT-0020526	PS 1.5 C-BAND DC OPTION 1:1 KIT, MTG & CABLE, Tx SWITCH
SPOD PS 1.5	A-6	A-15, A-16	KT-0000060	PS 1.5 Ku-BAND 1:1 KIT, MTG & CABLE, Tx SWITCH
	A-7	A-17, A-18	KT-0000091	PS 2 C-BAND 1:1 KIT, MTG & CABLE, Tx SWITCH
A.6.3	A-8	A-19, A-20	KT-0000254	PS 2 Ku-BAND 1:1 KIT, MTG & CABLE, Tx SWITCH
SPOD PS 2	N/A	A-21 through A- 23	KT-0020827	PS 2 C-BAND 1:1 FREE STANDING 1:1 MOUNTING AND Tx SWITCH KIT

Appendix A A—9 MN-SPODPSX



A.6.1 SPOD PS 1 1:1 Redundancy Kit Examples

Table A-1. Parts List for KT-0000104 PS 1 1:1 Redundancy Kit

	KT-0000104 PS 1 C-Band 1:1 Redundancy Kit (as per Figure A-12)						
ITEM	QTY	Comtech PART NO.	DESCRIPTION				
1	4	FP-0000534	BRACKET, MOUNTING, PS 1				
2	2	FP-0000542	CHANNEL, DUAL, UNISTRUT, 1:1 RDNT, PS 1				
3	1	FP-0000537	BRACKET, UNIVERSAL, 1:1 RDNT, PS 1				
5	2	FP-0000580	SPACER PLATE, RF SPLITTER / COMBINER				
6	1	FP-0000645	BRACKET, SUPPORT, 1:1 RED., PS 1				
10	2	CA/RF0097	CABLE ASSY, ROHS CONNECTOR, CSAT-7075 OUTPUT RF				
11	1	HW/CAP-SS14	DUST COVER, RECEPTACLE W/CHAIN & RING, NON-SHORTING, SIZE 14, SS				
12	2	CA/6357-2	CABLE, ROHS TX (2FT)				
20	1	SW/WGS28V-137S	SWITCH, WAVEGUIDE, CPR137, +28V SEALED				
21	1	FP/WG0034	PNQ, WAVEGUIDE TERMINATION, SMALL FINS				
22	1	RF-0000105	RF POWER SPLITTER/COMBINER, 2-WAY, 0 DEGREES, 1-2GHZ				
23	4	GA/CPR-137-R-H-C	GASKET, D SHAPE, CPR-137, HALF THICKNESS, CONDUCTIVE				
24	2	FP/5683	WELDMENT, WAVEGUIDE ADAPTER CPRG137 TO N				
30	8	HW/1/4-20X1/2FH	1/4-20 x 1/2 LG FH PHILLIPS SCREW, 82°, UCUT, SS				
31	10	HW-0000070	3/8-16 x 3/4 LG SERR HD FLNG HEX SCREW				
32	10	HW/3/8SPRINGNUT	SPRINGNUT, 3/8-16, SHORT SPRING, SS (P3300)				
33	2	HW/4-40X1.38PH	#4-40 x 1-3/8 LG PHILLIPS HD SCREW, SS				
34	2	HW/4-SPLIT	#4 SPLIT LOCK WASHER, SS				
35	2	HW/4-FLT	#4 FLAT WASHER, SS				
37	4	HW/6-32X5/16P.H	#6-32 x 5/16 LG PHILLIPS HD SCREW, SS				
38	4	HW/6-SPLIT	#6 SPLIT LOCK WASHER, SS S				
39	4	HW/6-FLT	#6 FLAT WASHER, SS				
40	26	HW/#10-32X1/2SH	#10-32 x 1/2 LG SOCKET HD CAP SCREW				
41	14	HW/#10-32X5/8SHC	#10-32 x 5/8 LG SOCKET HD CAP SCREW				
42	32	HW/10-SPLIT	#10 SPLIT LOCK WASHER, SS				
43	32	HW/10-FLT	#10 FLAT WASHER, SS				
49	12	HW/TW14.5HDBLK	CABLE TIE, 14.5", HEAVY DUTY, BLACK				
50	2	HW/8-32X1/2SHCS	#8-32 x 1/2 LG SOCKET HD CAP SCREW, SS				
51	4	HW/8-FLT	#8 FLAT WASHER, SS				
52	2	HW/8-SPLIT	#8 SPLIT LOCK WASHER, SS				
53	2	HW/8-32HEXNUT	#8-32, HEX NUT, SS				






Figure A-4. KT-0000104 PS 1 C-Band 1:1 Redundancy Kit (Exploded View)

Appendix A A–11 MN-SPODPSX






Figure A-5. KT-0000104 PS 1 C-Band 1:1 Redundancy Kit (Assembled Isometric View)





Table A-2. Parts List for KT-0000090 PS 1 C-Band Coax Output 1:1 Redundancy Kit

	KT-0000090 PS 1 C-Band Coax Output 1:1 Redundancy Kit (as per Figure A-14)				
ITEM	QTY	Comtech PART NO.	DESCRIPTION		
1	4	FP-0000534	BRACKET, MOUNTING, PS 1		
2	2	FP-0000542	CHANNEL, DUAL, UNISTRUT, 1:1 RDNT, PS 1		
3	1	FP-0000537	BRACKET, UNIVERSAL, 1:1 RDNT, PS 1		
5	2	FP-0000580	SPACER PLATE, RF SPLITTER / COMBINER		
10	4	CA/6357-2	CABLE, ROHS, TX, 2FT		
11	1	HW/CAP-SS14	DUST COVER, RECEPTACLE, NON-SHORTING, SIZE 14, SS, W/CHAIN & RING		
20	1	SW/COAX-N-F-SEALED	SWITCH COAX N-FEMALE, 25VDC 5.9-6.5 SEALED		
21	1	RF-0000104	TERMINATION, MOD, TYPE N, M, 50 W, DC-8.5 GHz		
22	1	RF-0000105	SPLITTER/COMBINER, RF POWER, 2-WAY, 0 DEGREES, 1-2GHZ		
30	8	HW/1/4-20X1/2FH	1/4-20 x 1/2 LG FH PHILLIPS SCREW, 82, UCUT, SS		
31	10	HW-0000070	3/8-16 x 3/4 LG HEX, FLNG, SERR SCREW, SS		
32	10	HW/3/8SPRINGNUT	SPRINGNUT, 3/8-16, SHORT SPRING, SS (P3300)		
33	2	HW/4-FLT	#4 FLAT WASHER, SS		
34	2	HW/4-SPLIT	#4 SPLIT LOCK WASHER, SS		
35	2	HW/4-40X1.38PH	#4-40 x 1/38 P.H. PHIILIPS SCREW, SS		
37	4	HW/6-FLT	#6 FLAT WASHER, SS		
38	4	HW/6-SPLIT	#6 SPLIT LOCK WASHER, SS		
39	4	HW/6-32X5/16P.H	#6-32 x 5/16 LG PHILLIPS SCREW		
40	2	HW-0000170	M4X0.7 x 8 LG PAN HD PHILLIPS SCREW, SS		
41	2	HW/M4LOCK	M4 LOCK WASHER, SS		
42	2	HW/M4FLAT	M4 FLAT WASHER, SS		
43	12	HW/TW14.5HDBLK	CABLE TIE, 14.5", HEAVY DUTY, BLACK		






Figure A-6. KT-0000090 PS 1 C-Band Coax Output 1:1 Redundancy Kit Example (Exploded Isometric View)






Figure A-7. KT-0000090 PS 1 C-Band Coax Output 1:1 Redundancy Kit Example (Assembled Isometric View)





Table A-3. Parts List for KT-0000089 PS 1 Ku-Band 1:1 Redundancy Kit

_	KT-0000089 PS 1 Ku-Band 1:1 Redundancy Kit (as per Figure A-9)				
ITEM	QTY	Y Comtech PART NO. DESCRIPTION			
1	4	FP-0000534	BRACKET, MOUNTING, PS 1		
2	2	FP-0000542	CHANNEL, DUAL, UNISTRUT, 1:1 RDNT, PS 1		
3	1	FP-0000537	BRACKET, UNIVERSAL, 1:1 RDNT, PS 1		
4	1	FP-0000548	WAVEGUIDE, Ku, WR-75, GRVD FLGS, E TO H TO FLEX, LH, 1:1, PS 1		
5	1	FP-0000549	WAVEGUIDE, Ku, WR-75, GRVD FLGS, E TO H TO FLEX, RH, 1:1, PS 1		
7	2	FP-0000580	SPACER PLATE, RF SPLITTER / COMBINER		
8	1	FP-0000645	BRACKET, SUPPORT, 1:1 RED., PS 1		
11	2	CA/RF0097	CABLE ASSY, ROHS CONNECTOR, CSAT-7075 OUTPUT RF, ROHS		
12	1	HW/CAP-SS14	DUST COVER, RECEPTACLE, NON-SHORTING, SIZE 14, SS, W/CHAIN & RING		
20	1	SW/WGS28V-75SB	SWITCH, WAVEGUIDE, WR75, +28VDC, SEALED, SIDE & BOTTOM MNT		
21	1	RF/TERM-11923-5	RF TERMINATION, WR75G, 14-14.5GHz, 1.05:1 VSWR, 150W		
22	1	RF-0000105	RF POWER SPLITTER/COMBINER, 2-WAY, 0 DEGREES, 1-2GHZ		
23	6	GA/WR75-R-H-C	GASKET, O RING, WR-75, HALF THICKNESS, CONDUCTIVE		
24	12	HW/TW14.5HDBLK	CABLE TIE, 14.5", HEAVY DUTY, BLACK		
30	8	HW/1/4-20X1/2FH	1/4-20 x 1/2 FLAT HD PHILLIPS SCREW, 82°, UCUT, SS		
33	10	HW-0000070	3/8-16 x 3/4 LG SCREW, HEX, FLNG, SERR, SS		
34	10	HW/3/8SPRINGNUT	SPRINGNUT, 3/8-16, SHORT SPRING, SS (P3300)		
35	2	HW/4-FLT	#4 FLAT WASHER, SS		
36	2	HW/4-SPLIT	#4 SPLIT LOCK WASHER, SS		
37	2	HW/4-40X1.38PH	#4-40 x 1-3/8 LG PAN HD PHILLIPS SCREW, SS		
39	28	HW/6-FLT	#6 FLAT WASHER, SS		
40	28	HW/6-SPLIT	#6 SPLIT LOCK WASHER, SS		
41	4	HW/6-32X5/16P.H	#6-32 x 5/16 LG PHILLIPS SCREW		
42	20	HW/6-32X1/2SHCS	#6-32 x 1/2 LG SOCKET HD CAP SCREW, SS		
43	4	03P1111	#6-32 x 9/16 LG SOCKET HD SCREW, SS		
44	2	HW/8-32X1/2SHCS	#8-32 x 1/2 LG SOCKET HD CAP SCREW, SS		
45	4	HW/8-FLT	#8 FLAT WASHER, SS		
46	2	HW/8-SPLIT	#8 SPLIT LOCK WASHER, SS		
47	2	HW/8-32HEXNUT	#8-32 HEX NUT, SS		






Figure A-8. KT-0000089 PS 1 Ku-Band 1:1 Redundancy Kit Example (Exploded Isometric View)






Figure A-9. KT-0000089 PS 1 Ku-Band 1:1 Redundancy Kit Example (Assembled Isometric View)





Table A-4. Parts List for KT-0000170 PS 1 X-Band 1:1 Redundancy Kit

	KT-0000170 PS 1 X-Band 1:1 Redundancy Kit (as per Figure A-11)				
ITEM	QTY	Comtech PART NO. DESCRIPTION			
0	2	CA-0000348	CABLE ASSY, RF, 2 FT		
0	12	HW/TW14.5HDBLK	CABLE TIE, 14.5", HEAVY DUTY, BLACK		
1	4	FP-0000534	BRACKET, MOUNTING, PS 1		
2	2	FP-0000542	CHANNEL, DUAL, UNISTRUT, 1:1 RDNT, PS 1		
3	1	FP-0000537	BRACKET, UNIVERSAL, 1:1 RDNT, PS 1		
4	1	FP-0000948	WAVEGUIDE, PREFORMED SEAMLESS FLEX, X, CPRG-112, LH, 1:1, PS 1		
5	1	FP-0000949	WAVEGUIDE, PREFORMED SEAMLESS FLEX, X, CPRG-112, RH, 1:1, PS 1		
7	2	FP-0000580	SPACER PLATE, RF SPLITTER / COMBINER		
8	1	FP-0000645	BRACKET, SUPPORT, 1:1 RED., PS 1		
12	1	HW/CAP-SS14	DUST COVER, RECEPTACLE, NON-SHORTING, SIZE 14, SS, W/CHAIN & RING		
20	1	SW/WG-HAGS	SWITCH, WR112G, +24V, SEALED, STANDARD THREAD, COLD TEMP RATING		
21	1	FP/WG0039	CNTRC, WAVEGUIDE FP - WAVEGUIDE, TERMINATION, 250W, CPR-112		
22	1	RF-0000105	RF POWER SPLITTER/COMBINER, 2-WAY, 0 DEGREES, 1-2GHZ		
23	6	GA/CPR112-R-F-C	GASKET, ROUND, CPR112, FULL THICKNESS, CONDUCTIVE		
30	8	HW/1/4-20X1/2FH	1/4-20 x 1/2 LG FLAT HD PHILLIPS SCREW, 82°, UCUT, SS		
33	10	HW-0000070	3/8-16 x 3/4 LG SCREW, HEX, FLNG, SERR, SS		
34	10	HW/3/8SPRINGNUT	SPRINGNUT, 3/8-16, SHORT SPRING, SS (P3300)		
35	2	HW/4-FLT	#4 FLAT WASHER, SS		
36	2	HW/4-SPLIT	#4 SPLIT LOCK WASHER, SS		
37	2	HW/4-40X1.38PH	#4-40 x 1-3/8 LG PAN HD PHILLIPS SCREW, SS		
40	44	HW/8-FLT	#8 FLAT WASHER, SS		
41	42	HW/8-SPLIT	#8 SPLIT LOCK WASHER, SS		
42	36	HW-0000325	#8-32 x 1/2 LG SCREW, HEX HD, SS		
43	6	HW-0000326	#8-32 x 5/8 LG SCREW, HEX HD, SS		
44	2	HW/8-32HEXNUT	#8-32 HEX NUT, SS		
45	4	HW/6-FLT	#6 FLAT WASHER, SS		
46	4	HW/6-SPLIT	#6 SPLIT LOCK WASHER, SS		
47	4	HW/6-32X5/16P.H	#6-32 x 5/16 LG PHILLIPS SCREW		






Figure A-10. KT-0000170 PS 1 X-Band 1:1 Redundancy Kit Example (Exploded Isometric View)






Figure A-11. KT-0000170 PS 1 X-Band 1:1 Redundancy Kit (Assembled Isometric View)

Appendix A A–24 MN-SPODPSX





A.6.2 SPOD PS 1.5 1:1 Redundancy Kit Examples

Table A-5. Parts List for KT-0020526 PS 1.5 C-Band DC Option 1:1 Redundancy Kit

	KT-0020526 PS 1.5 C-Band DC Option 1:1 Redundancy Kit (as per Figures A-20 and A-21)				
ITEM	QTY	Comtech PART DESCRIPTION			
30	2	FP-0000542	CHANNEL, DUAL, UNISTRUT		
40	10	HW-000070	SCREW, HEX, FLNG, 0.375-16 x 0.750, SS, SERR		
50	10	HW/3/8SPRINGNUT	SPRINGNUT, 3/8-16, SHORT SPRING, SS (P3300)		
60	4	FP-0020593	BRACKET, MOUNTING, DC SPOD		
70	4	CA-0000348	CABLE ASSY, RF, 2 FT		
80	1	HW/CAP-SS14	DUST COVER, RECEPTACLE, NON-SHORTING, SIZE 14, SS, W/CHAIN & RING		
90	1	SW/WGS28V-137S	SWITCH, WAVEGUIDE, CPR137		
100	1	FP/WG0034	MPS, BLANKET FP TERM		
110	1	RF-0000105	RF POWER SPLITTER/COMBINER, 2-WAY, 0 DEGREES, 1-2GHZ		
130	2	FP-0000580	SPACER PLATE, RF SPLITTER / COMBINER		
140	1	FP-0020594	SUPPORT BRACKET		
150	1	FP-0020595	OUTPUT WAVEGUIDE, UNIT 1 TO PORT 4		
160	1	FP-0020596	OUTPUT WAVEGUIDE UNIT 2 TO PORT 2		
170	1	FP-0020592	BRACKET, MOUNTING, PS 1.5		
180	5	GA/GSKTCP137HLF	GASKET, CP137, HALF THK		
190	40	HW/10-FLT	#10 FLAT WASHER, SS		
200	40	HW/10-SPLIT	#10 SPLIT WASHER, SS		
210	40	HW/#10-32X5/8SHC	#10-32 x 5/8 LG SOCKET HD CAP SCREW, SS		
220	4	HW/SEM632X5/16PH	#6-32 x 5/16 LG PHILLIPS HD SCREW, SS		
230	1	PP-0020512	BALL DRIVER		
240	8	HW/1/4-SPLIT	1/4" SPLIT WASHER., SS		
250	8	HW/1/4-20X3/4BT	1/4-20 x 3/4 LG BOLT		
260	12	HW/TW14.5HDBLK	CABLE TIE, 14.5", HEAVY DUTY, BLACK		
270	2	HW/SEM440X3/8PH	#4-40 x 3/8 LG PAN HD SCREW		
280	5	HW/632X5/16FHMS	#6-32 x 5/16 FLAT HD MACHINE SCREW		






Figure A-12. KT-0020526 PS 1.5 C-Band DC Option 1:1 Redundancy Kit (Assembled View)



STEP 1: SSPA INSTALLATION

STEP 2: SPLITTER/COMBINER/WAVEGUIDE BRACKET INSTALLATION




Figure A-13. KT-0020526 PS 1.5 C-Band DC Option 1:1 Redundancy Kit (Exploded View, Steps 1 & 2)

Appendix A A–28 MN-SPODPSX






Figure A-14. KT-0020526 PS 1.5 C-Band DC Option 1:1 Redundancy Kit (Exploded View, Step 3)



Table A-6. Parts List for KT-0000060 PS 1.5 Ku-Band 1:1 Redundancy Kit

	KT-0000060 PS 1.5 Ku-Band 1:1 Redundancy Kit (as per Figure A-23)				
ITEM	QTY	Comtech PART NUMBER	DESCRIPTION		
0	2	CA-0000348	CABLE ASSY, RF, 2 FT		
0	12	HW/TW14.5HDBLK	CABLE TIE, 14.5", HEAVY DUTY, BLACK		
1	4	FP-0000534	BRACKET, MOUNTING, PS 1		
2	2	FP-0000542	CHANNEL, DUAL, UNISTRUT, 1:1 RDNT, PS 1		
3	1	FP-0000537	BRACKET, UNIVERSAL, 1:1 RDNT, PS 1		
4	1	FP-0000939	WAVEGUIDE, FORMED BENDS, Ku, WR-75, LH, 1:1, PS 1.5		
5	1	FP-0000940	WAVEGUIDE, FORMED BENDS, Ku, WR-75, RH, 1:1, PS 1.5		
7	2	FP-0000580	SPACER PLATE, RF SPLITTER / COMBINER		
8	1	FP-0000645	BRACKET, SUPPORT, 1:1 RED., PS 1		
12	1	HW/CAP-SS14	DUST COVER, RECEPTACLE, NON-SHORTING, SIZE 14, SS, W/CHAIN & RING//(RE		
20	1	SW/WGS28V-75SB	SWITCH, WAVEGUIDE, WR75, +28VDC, SEALED SIDE & BOTTOM MNT		
21	1	RF/TERM-11923-5	RF TERMINATION, WR75G, 14-14.5GHz, 1.05:1 VSWR, 150W, FLAT BLACK, G		
22	1	RF-0000105	RF POWER SPLITTER/COMBINER, 2-WAY, 0 DEGREES, 1-2GHZ		
23	5	GA/GSKTWR75HALF	GASKET, WR75, HALF THK		
30	8	HW/1/4-20X1/2FH	/4-20 x 1/2 LG FLAT HD PHILLIPS SCREW, 82°, UCUT, SS		
33	10	HW-0000070	/8-16 x 3/4 LG SCREW, HEX, FLNG, SS, SERR		
34	10	HW/3/8SPRINGNUT	SPRINGNUT, 3/8-16, SHORT SPRING, SS (P3300)		
35	2	HW/4-FLT	4 FLAT WASHER, SS		
36	2	HW/4-SPLIT	#4 SPLIT LOCK WASHER, SS		
37	2	HW/4-40X1.38PH	#4-40 x 1/38 P.H. PHIILIPS SCREW, SS		
39	24	HW/6-FLT	#6 FLAT WASHER, SS		
40	24	HW/6-SPLIT	#6 SPLIT LOCK WASHER, SS		
41	4	HW/6-32X5/16P.H	#6-32 x 5/16 LG PHILLIPS SCREW		
42	16	HW/6-32X1/2SHCS	#6-32 x 1/2 LG SOCKET HD CAP SCREW, SS		
43	4	03P1111	#6-32 x 9/16 LG, SOCKET HD CAP SCREW, SS		
44	2	HW/8-32X1/2SHCS	#8-32 x 1/2 LG SOCKET HD CAP SCREW, SS		
45	4	HW/8-FLT	#8 FLAT WASHER, SS		
46	2	HW/8-SPLIT	#8 SPLIT LOCK WASHER, SS		
47	2	HW/8-32HEXNUT	#8-32 HEX NUT, SS		






Figure A-15. KT-0000060 PS 1.5 Ku-Band 1:1 Redundancy Kit Example (Exploded Isometric View)

Appendix A A–31 MN-SPODPSX






Figure A-16. KT-0000060 PS 1.5 Ku-Band 1:1 Redundancy Kit Example (Assembled Isometric View)

Appendix A A–32 MN-SPODPSX





A.6.3 SPOD PS 2 1:1 Redundancy Kits

Table A-7. Parts List for KT-0000091 PS 2 C-Band 1:1 Redundancy Kit

	KT-0000091 PS 2 C-Band 1:1 Redundancy Kit (as per Figure A-25)				
ITEM	QTY	Comtech PART NO. DESCRIPTION			
1	1	FP-0000552	WAVEGUIDE, C-BAND, CPR-137 G, E TO H TO FLEX, LH, 1:1, PS 2		
2	1	FP-0000553	WAVEGUIDE, C-BAND, CPR-137 G, E TO H TO FLEX, RH, 1:1, PS 2		
3	4	FP-0000442	BRACK, MOUNTING, HPOD-PS 2		
4	2	FP-0000543	CHANNEL, DUAL, UNISTRUT, 1:1 RDNT, PS 2		
5	1	FP-0000626	BRACKET, RF SW, UNIVERSAL, 1:1 RED., PS 2		
6	2	FP-0000580	SPACER PLATE, RF SPLITTER / COMBINER		
11	2	CA/RF0097	ASSY CABLE, ROHS CONNECTOR, CSAT-7075 OUTPUT RF, ROHS		
12	1	HW/CAP-SS14	DUST COVER, RECEPTACLE, NON-SHORTING, SIZE 14, SS, W/CHAIN & RING		
20	1	SW/WGS28V-137S	SWITCH, WAVEGUIDE, CPR137, +28V SEALED		
212	1	FP/WG0034	PNQ, WAVEGUIDE TERMINATION, SMALL FINS		
22	1	RF-0000105	RF POWER SPLITTER/COMBINER, 2-WAY, 0 DEGREES, 1-2GHZ		
23	4	GA/CPR-137-R-H-C	GASKET, D SHAPE, CPR-137, HALF THICKNESS, CONDUCTIVE		
24	2	GA/CPR137-R-F-C	GASKET, ROUND, CPR137, FULL THICKNESS, CONDUCTIVE		
25	12	HW/TW14.5HDBLK	CABLE TIE, 14.5", HEAVY DUTY, BLACK		
30	10	HW/3/8SPRINGNUT	SPRINGNUT, 3/8-16, SHORT SPRING, SS (P3300)		
31	10	HW-0000070	/8-16 x 3/4 LG SCREW, HEX, FLNG, SERR, SS		
33	2	HW/4-40X1.38PH	#4-40 x 1-3/8 LG PAN HD PHIILIPS SCREW, SS		
34	2	HW/4-SPLIT	#4 SPLIT LOCK WASHER, SS		
35	2	HW/4-FLT	#4 FLAT WASHER, SS		
36	4	HW/6-32X5/16P.H	#6-32 x 5/16 PHILLIPS SCREW		
37	4	HW/6-SPLIT	#6 SPLIT LOCK WASHER, SS		
38	4	HW/6-FLT	#6 FLAT WASHER, SS		
39	26	HW/#10-32X1/2SH	#10-32 x 1/2 LG SOCKET HD CAP SCREW, SS		
40	30	HW/#10-32X5/8SHC	#10-32 x 5/8 LG SOCKET HD CAP SCREW, SS		
41	48	HW/10-SPLIT	#10 SPLIT LOCK WASHER, SS		
42	48	HW/10-FLT	#10 FLAT WASHER, SS		
43	8	HW/5/16-18X3/4B	5/16-18 x 3/4 LG HEX HD BOLT, SS		
44	8	HW/5/16-SPLIT	5/16" SPLIT LOCK WASHER		
45	8	HW/5/16-FLT	5/16" FLAT WASHER		






Figure A-17. KT-0000091 PS 2 C-Band 1:1 Redundancy Kit Example (Exploded Isometric View)

Appendix A A–35 MN-SPODPSX






Figure A-18. KT-0000091 PS 2 C-Band 1:1 Redundancy Kit Example (Assembled Isometric View)





Table A-8. Parts List for KT-0000254 PS 2 Ku-Band 1:1 Redundancy Kit

	KT-0000254 PS 2 Ku-Band 1:1 Redundancy Kit (as per Figure A-27)				
ITEM	QTY	Comtech PART NO. DESCRIPTION			
1	1	FP-0001170	WAVEGUIDE, Ku-BAND, WR-75, LH, 1:1, PS 2		
2	1	FP-0001171	WAVEGUIDE, Ku-BAND, WR-75, RH, 1:1. PS 2		
3	4	FP-0000442	BRACK, MOUNTING, HPOD & PS 2		
4	2	FP-0000543	CHANNEL, DUAL, UNISTRUT, 1:1 RDNT, PS 2		
5	1	FP-0000626	BRACKET, RF SW, UNIVERSAL, 1:1 RED., PS 2		
6	2	FP-0000580	SPACER PLATE, RF SPLITTER / COMBINER		
8	1	FP-0000762	SUPPORT BRACKET, 1:1 REDUNDANT, PS 2		
12	1	HW/CAP-SS14	DUST COVER, RECEPTACLE, NON-SHORTING, SIZE 14, SS, W/CHAIN & RING		
20	1	SW/WGS28V-75SB	SWITCH, WAVEGUIDE, WR75, +28VDC, SEALED, SIDE & BOTTOM MOUNT		
21	1	RF/TERM-11923-5	RF TERMINATION, WR75G, 14-14.5GHz, 1.05:1 VSWR, 150W, FLAT BLACK, G		
22	1	RF-0000105	RF POWER SPLITTER / COMBINER, 2-WAY, 0 DEGREES, 1-2GHZ		
23	5	GA/GSKTWR75HALF	GASKET, WR75, HALF THICK		
30	10	HW/3/8SPRINGNUT	SPRINGNUT, 3/8-16, SHORT SPRING, SS (P3300)		
31	10	HW-0000070	3/8-16 x 3/4 LG SCREW, HEX, SERR FLNG HD, SS		
33	2	HW/4-40X1.38PH	SCREW #4-40 x 1-3/8 LG PHILLIPS HD, SS		
34	2	HW/4-SPLIT	#4 SPLIT LOCK WASHER, SS		
35	2	HW/4-FLT	#4 FLAT WASHER, SS		
39	24	HW/6-FLT	#6 FLAT WASHER, SS		
40	24	HW/6-SPLIT	#6 SPLIT LOCK WASHER, SS		
41	4	HW/6-32X5/16P.H	#6-32 x 5/16 LG PHILLIPS SCREW		
42	16	HW/6-32X1/2SHCS	#6-32 x 1/2 LG SOCKET HD CAP SCREW, SS		
43	4	03P1111	#6-32 x 9/16 LG SCREW, SOCKET HD, SS		
44	2	HW/#10-32X1/2SH	#10-32 x 1/2 LG SOCKET HD CAP SCREW, SS		
45	2	HW/10-SPLIT	#10 SPLIT LOCK WASHER, SS		
46	2	HW/10-FLT	#10 FLAT WASHER, SS		
47	8	HW/5/16-18X3/4B	5/16-18 x 3/4 LG HEX HD BOLT, SS		
48	8	HW/5/16-SPLIT	5/16" SPLIT LOCK WASHER		
49	8	HW/5/16-FLT	5/16" FLAT WASHER		






Figure A-19. KT-0000254 PS 2 Ku-Band 1:1 Redundancy Kit Example (Exploded Isometric View)

Appendix A A–39 MN-SPODPSX







Figure A-20. KT-0000254 PS 2 Ku-Band 1:1 Redundancy Kit Example (Assembled Isometric View)





COMTECH FREE STANDING UNISTRUT KIT (Comtech P/N KT-0020827)				
ITEM QTY Comtech P/N		Comtech P/N	DESCRIPTION	
1	2	FP/BR11931-1	Bracket, Unistrut	
2	20	HW-0000070	Screw, Hex, Flanged Head 0.3	
3	6	HW-0020764	Bracket, Unistrut, 90°	
4	2	HW-0020765	Bracket, Flat, Unistrut	
5	20	HW/3/8SPRINGNUT	Springnut	

Figure A-21. 1:1 or 1:2 Free Standing Unitstrut Kit (Comtech Kit KT-0020827)






Figure A-22. PS 2 C-Band 1:1 Redundancy Free Standing Example Using Kit KT-0020827 (Assembled Isometric View)






Figure A-23. PS 2 C-Band 1:1 Redundancy Free Standing Example Using Kit KT-0020827 (Assembled Views)



Notes:	

Appendix A A–44 MN-SPODPSX



Appendix B. CABLE DRAWINGS

B.1 Overview

This appendix provides line details for the cables available for use with the SPOD C-, X-, or Ku-Band Outdoor Amplifier in Standalone or 1:1 Redundancy applications. Each figure illustrates the cable's technical specifications – e.g., connector types used, cable labeling, wiring lists, etc.



The European EMC Directive (EN55022, EN50082-1) requires that you use properly shielded cables for DATA I/O. These cables must be double-shielded from end-to-end, ensuring a continuous ground shield.



The tables in this appendix cross-reference cable use in SPOD Standalone applications as well as the various 1:1 Redundancy application examples provided in Appendix A. 1:1 REDUNDANCY.



B.2 Control and Data Cables

App B FIG	Comtech CABLE P/N	DESCRIPTION	USED FOR:	REF App A FIG
B-1	CA-0020526	Serial Interface Cable (19-pin circular connector to RJ-11)	Connecting1:1 Redundant Loop Cable 'J1' receptacle or Standalone SPOD 'J6 COM1' receptacle to CLC-10 RJ-11 comms jack (Cable and CLC-10 are furnished as part of optional Comtech KIT KT-0020518)	A-1, A-3 through A-23
B-2	CA-0000352	Ethernet Interface Cable (19-pin circular connector to <2X> RJ-45)	Connecting 1:1 Redundant Loop Cable 'J1' receptacle or Standalone SPOD 'J6 COM1' receptacle to LPODnet Ethernet jack (Cable and LPODnet are furnished as part of optional Comtech KIT KT-0000203)	A-2, A-3 through A-23
B-3	CA-0000318	100' COMMS Cable (19-pin circular connector to bare end)	Connecting 1:1 Redundant Loop Cable 'J1' receptacle or	A-3 through A-23
B-4	CA-0000543	250' COMMS Cable (19-pin circular connector to bare end)	Standalone SPOD ' J6 COM1 ' receptacle to user-specified M&C interface	A-3 through A-23
B-5	CA-0020657	Tx-only Redundant Loop Cable (19-pin circular receptacle to <1X> Type 'N' connector, <2X> 19-pin circular connectors)	Interconnecting 1:1 Redundancy System SPOD units, Tx switch, and user M&C interface	A-3 through A-23



B.2.1 Serial Interface Cable

The Comtech CLC-10 Serial M&C Accessory Kit (Comtech P/N KT-0020518) includes the CA-0020526 Serial Interface Cable. This kit is optionally available to provide serial-based monitor and control of 1:1 Redundancy or Standalone SPOD applications using the CLC-10 Comtech SSPA Controller (a preconfigured Two Technologies, Inc. TechTerm Handheld Terminal). The circular connector installs onto the Redundant Loop Cable 'J1' connector in 1:1 SPOD Redundant applications, or the 'J6 | COM 1' connector on a Standalone SPOD. The RJ-11 connector plugs directly into the CLC-10.




Figure B-1. Serial Interface Cable (Comtech P/N CA-0020526, part of KT-0020518)

Appendix B B-3 MN-SPODPSX



B.2.2 Ethernet Interface Cable

The Comtech Ethernet Utility Kit (Comtech P/N KT-0000203) includes the CA-0000352 Ethernet Interface Cable. This kit is optionally available to provide Ethernet-based M&C of 1:1 Redundancy or Standalone SPOD applications using a Samsung NB30 Plus Netbook (LPOD*net*). The 'P1' circular connector installs onto the Redundant Loop Cable 'J1' connector in 1:1 SPOD Redundant applications, or the 'J6 | COM 1' connector on a Standalone SPOD. Use the 'J2' and 'J3' RJ-45 connectors to either connect directly to the LPOD*net*'s Ethernet network jack (for Standalone use) or via a user-provided Ethernet switch or hub (for 1:1 Redundancy use).





Figure B-2. Ethernet Interface Cable (Comtech P/N CA-0000352, part of KT-0000203)

Appendix B B-4 MN-SPODPSX



B.2.3 19-Pin COMMS Cable (100')

This cable connects between your designated data interface and the Redundant Loop Cable's 'J1' connector in 1:1 Redundancy applications, or the 'J6 | COM 1' port on a Standalone SPOD.



WIRE LIST

PIN	COLOR	SIGNAL
Α	RED/BRN	RS485_+RX
В	BRN/RED	RS485RX
С	WHT/BLU	RS485_+TX
D	BLU/WHT	RS485TX
E	WHT/ORN	ENET_TX+_UNIT1
F	RED/ORN	ENET_TX+_UNIT2
G	ORN/WHT	ENET_TXUNIT1
Н	ORN/RED	ENET_TXUNIT2
J	GRN/WHT	ENET_RXUNIT1
K	GRY/RED	GND
L	WHT/BRN	UNIT1_OK
М	BRN/WHT	UNIT2_OK
N	RED/BLU	TX_SW_POS1_LOW
Р	WHT/GRN	ENET_RX+_UNIT1
R	RED/GRY	+24V
S	GRY/WHT	AUX_MUTE_LOW
Т	BLU/RED	SWITCH_COM
U	GRN/RED	ENET_RXUNIT2
V	RED/GRN	ENET_RX+_UNIT2


Figure B-3. COMMS Cable, 100' (Comtech P/N CA-0000318)

Appendix B B-5 MN-SPODPSX



B.2.4 19-Pin COMMS Cable (250')

This cable connects between your designated data interface and the Redundant Loop Cable's 'J1' connector in 1:1 Redundancy applications, or the 'J6 | COM 1' port on a Standalone SPOD.



WIRE LIST				
FROM	COLOR	LPOD / SPOD SINGLE UNIT	LPOD / SPOD REDUNDANT	
P1-A	RED/BRN	RS485 +RX	RS485 +RX	
P1-B	BRN/RED	RS485 -RX	RS485 -RX	
P1-C	WHT/BLU	RS485 +TX	RS485 +TX	
P1-D	BLU/WHT	RS485 -TX	RS485 -TX	
P1-E	WHT/ORN	RS232 RD	10BASE-T TX+(B)	
P1-F	RED/ORN	ETHERNET TX+	10BASE-T TX+(A)	
P1-G	ORN/WHT	RS232 TD	10BASE-T TX-(B)	
P1-H	ORN/RED	ETHERNET TX-	10BASE-T TX-(A)	
P1-J	GRN/WHT	TX / RX SWITCH DRIVE 1 POS	10BASE-T TX-(B)	
P1-K	GRY/RED	GROUND	GROUND	
P1-L	WHT/BRN	SUM FAULT IN	CUST COMM UNIT A STATUS	
P1-M	BRN/WHT	SUM FAULT OUT	CUST COMM UNIT B STATUS	
P1-N	RED/BLU	TX SWITCH POS 1 IND	TX SWITCH POS 1 IND	
P1-P	WHT/GRN	RX SWITCH POS 1 IND	10BASE-T TX+(B)	
P1-R	RED/GRY	+24V	+24V	
P1-S	GRY/WHT	SYSTEM MUTE CONTROL	SYSTEM MUTE	
P1-T	BLU/RED	SWITCH COMMON	SWITCH COMMON	
P1-U	GRN/RED	ETHERNET RX-	10BASE-T RX-(A)	
P1-V	RED/GRN	ETHERNET RX+	10BASE-T RX+(A)	


Figure B-4. COMMS Cable, 250' (Comtech P/N CA-0000543)

Appendix B B-6 MN-SPODPSX



B.2.5 Redundant Loop Cable – Tx Only

Use the CA-0020655 Redundant Loop Cable for interconnection of 1:1 Redundancy *Tx-only* applications. Use the 'J1' connector to connect to your M&C interface. See the CONNECTOR LIST table in **Figure B-5** for routing the remaining connectors.



	WIRE LIST				
FROM	ТО	DESCRIPTION			
J1-A	J2-A, J3-A	RS485_+RX			
J1-B	J2-B, J3-B	RS485RX			
J1-C	J2-C, J3-C	RS485_+TX			
J1-D	J2-D, J3-D	RS485TX			
J1-E	J3-F	10BASE-T_TX+(B)			
J1-F	J2-F	10BASE-T_TX+(A)			
J1-G	J3-H	10BASE-T_TX-(B)			
J1-H	J2-H	10BASE-T_TX-(A)			
J1-J	J3-U	10BASE-T_RX-(B)			
J1-K	J2-K, J3-K	GND			
J1-L	J2-L, J3-M	CUST. COMM. UNIT A STATUS			
J1-M	J1-M J2-M,J3-L CUST. COMM. UNIT J1-N J2-N, J5-D TX SWITCH POS				
J1-N					
J1-P	J3-V	10BASE-T_RX+(B)			
J1-R	J2-R, J3-R	+24V			
J1-S	J2-S, J3-S	SYSTEM MUTE			
J1-T	J2-T, J3-T, J5-B, J5-E	SWITCH COMMON			
J1-U	J2-U	10BASE-T_RX-(A)			
J1-V	J2-V	10BASE-T_RX+(A)			
J2-E	J3-G	RS232_RD/RS232_TD			
J2-G	J3-E	RS232_TD/RS232_RD			
J2-J	J5-A	TX SWITCH DRIVE POS. 1			
J3-J	J5-C	TX SWITCH DRIVE POS. 2			
J3-N	J5-F	TX SWITCH POS. 2 IND.			

CONNECTOR LIST

CONNECTOR	REF DES	TO:	P/N	MANUFACTURER P/N	
Α	J1	USER	CN/MS3114E14-19S	AMPHENOL PT07E-14-19S(027) (PREFERRED)	
^	,,	M&C	CIV/IVI33114E14-133	GLENAIR IPT07E-14-19S-F7 (ALTERNATE)	
	J2	UNIT 2			
В	12	J6 COM1	- 28P1038	AMPHENOL PT06E-14-19P(476) (PREFERRED)	
В	J3	UNIT 1		GLENAIR IPT06E-14-19PSR-F7 (ALTERNATE)	
		J6 COM1			
	J5	TX	011/0TD 000500	AMPHENOL PT06E-10-6S(476) (PREFERRED)	
С		SPLITTER	CN/STPG06F02	GLENAIR IPT06E-10-6SSR (ALTERNATE)	

Figure B-5. Redundant Loop Cable – Tx Only (Comtech P/N CA-0020655)

Appendix B B-7 MN-SPODPSX



B.3 RF Cables

App B FIG	Comtech CABLE P/N	DESCRIPTION	USED FOR:	REF App A FIG
B-6	CA/3722-X	Type 'N' to Type 'N' 1/4" Heliax Coaxial Cable (lengths vary)	SPOD Rx or Tx connections in 1:1 Redundancy or Standalone SPOD applications	A-3



B.3.1 RF Cable (Type 'N')

Use this Type 'N' cable for the Rx or Tx connections in SPOD Standalone or 1:1 Redundancy applications:

- For SPOD PS 1 C-Band and X-Band applications For Standalone use, the cable connects the unit's 'J2 | RF OUT' port directly to your Rx signal destination. For 1:1 Redundancy applications, use the cable to connect each SPOD's 'J2 | RF OUT' port to the Tx Waveguide switch.
- For all SPOD applications For Standalone use, the cable connects directly from these SPOD interfaces to your Rx signal destination or Tx signal source. For 1:1 Redundancy applications, use the cable to connect the 'J1 | LBAND IN / Tx IN' or 'J10 | MODEM Rx' ports in 1:1 Redundancy applications to the system's respective signal splitters.

PART NO.	DIM A
CA/3722	144.00 ± 4.00
CA/3722-1	48.00 ± 1.50
CA/3722-2	60.00 ± 2.00
CA/3722-3	90.00 ± 2.00
CA/3722-4	264.00 ± 4.00
CA/3722-5	288.00 ± 4.00
CA/3722-6	72.00 ± 2.00
CA/3722-7	240.00 ± 4.00
CA/3722-8	120.00 ± 4.00
CA/3722-9	180.00 ± 4.00
CA/3722-10	192.00 ± 12.00
CA/3722-11	108.00 ± 4.00

NOTE: CABLE MUST MEET VSWR 10.96-12.75 ≤ 1.40:1 WITH INSERTION LOSS AS FOLLOWS:

FREQUENCY	ATTENUATION	1	AVERAGE POWER
MHz	db/100ft	db/100 M	kW
10000	21.8	71.5	0.054
12000	24.3	79.7	0.049
14000	26.7	86.3	0.044
16000	29.0	95.2	0.040




Figure B-6. 1/4" Heliax Coaxial Cable (CA/3722-X)

Appendix B B-9 MN-SPODPSX



Notes:			
-			
-			

Appendix B B-10 MN-SPODPSX



Appendix C. MAINTENANCE

C.1 Overview



Figure C-1. Comtech SPOD Outdoor Amplifiers

The fans used by Comtech's SPOD family of Outdoor Amplifiers (**Figure C-1**) are designed for long life, even in harsh environments. Still, they are mechanical devices, subject to wear, and may need replacement after several years.

In most environments, Comtech recommends clearing the heat sinks of dust and debris approximately once per year to ensure optimal fan life. You can use the temperature trending data, available from the SPOD Web Server Interface 'Status | Trending Graphs' page (Figure C-2) as a guide to determine if more or less frequent preventative maintenance is required.



Sect. 4.5.5.4.6 Status | Trending Graphs (Chapter 4. ETHERNET-BASED REMOTE PRODUCT MANAGEMENT)

This appendix outlines the procedures for uninstalling the SPOD PD-1, PS 1.5, or PS 2 fan shroud, inspecting and cleaning the heat sinks, and then re-installing the fan shroud.

Appendix C C–1 MN-SPODPSX






Figure C-2. SPOD Web Server Interface 'Status |Trending Graphs' Page Temperature Graph

C.2 Clean the SPOD PS 1 Heat Sinks

To clean the SPOD PS 1 Heat Sinks, do these steps:

Step	Task
1	Disconnect power from the SPOD.
	Remove the eight screws – four on either side of the fan shroud – see Figure C-3 .
2	Be sure to use an appropriate screwdriver, such as the one provided with the SPOD, to avoid damaging the screws.
3	Lift the fan shroud assembly far enough off the chassis to expose the heat sinks and access the fan's power supply connection – see Figure C-4 .
4	Disconnect the fan power supply. First, depress the connector's locking mechanism, and then pull apart the mated components – see Figure C-5 .
5	Visually inspect the exposed SPOD heat sinks, located on the top and either side of the chassis, for any accumulated debris or blockage that may be obstructing airflow. Use compressed air to clear and clean the heat sinks as needed – see Figure C-6 .
	Be sure to blow between the heat sink fins to remove any foreign object accumulation.
6	Reconnect the fan power supply by pressing the male and female connectors together until the locking mechanism snaps and locks – see Figure C-7 .
7	Re-install the fan shroud onto the chassis – be sure to keep the fan power supply cable clear of the fan and heat sink surfaces. Then, re-install the eight screws as described in Step 2.
	Torque the screws to 11 ±2 inch lbs.
8	Reconnect the power source to the SPOD.

Appendix C C–2 MN-SPODPSX






Figure C-3. SPOD PS 1 Shroud Screw Locations




Figure C-4. Remove the Fan Shroud

Appendix C C–3 MN-SPODPSX






Figure C-5. Disconnect the Fan Power Supply




Figure C-6. SPOD PS 1 Heat Sink Locations




Figure C-7. Reconnect the Fan Power Supply

Appendix C C–4 MN-SPODPSX



C.3 Clean the SPOD PS 1.5 Heat Sinks

To clean the SPOD PS 1.5 Heat Sinks, do these steps:

10 Clean	tile St OD 13 1.3 Heat Shiks, ut these steps:
Step	Task
1	Disconnect power from the SPOD.
2	Remove the screws from all four sides of the SPOD as needed – see Figure C-8 .
	Be sure to use an appropriate screwdriver, such as the one provided with the SPOD, to avoid damaging the screws.
	 The length of the four screws indicated in green are longer than those indicated elsewhere. Be sure to re-install these longer screws at the same locations.
	 The two screws located behind the waveguide may be difficult to remove without first removing the waveguide from the chassis.
3	Lift the fan shroud assembly far enough off the chassis to expose the heat sink and access the fan power supply connections – see Figure C-9 .
4	Disconnect each fan power supply by carefully pulling the mated connector components straight apart — see Figure C-10 .
	Do not twist the mated cable connection when disconnecting the cable assemblies.
5	Visually inspect the exposed SPOD heat sink, located on the top of the chassis, for any accumulated debris or blockage that may be obstructing airflow. Use compressed air to clear and clean the heat sink as needed – see Figure C-11 .
	Be sure to blow between the heat sink fins to remove any foreign object accumulation.
6	Reconnect each fan power supply. First, align the male and female connector's tabs. Then, push the connectors together until the connection locks – see Figure C-12
	Do not twist the mated cable connections when reconnecting the fan power supplies.
	 The fan power supply cables are labeled Fan 1 and Fan 2. Make sure to connect the chassis Fan 1 cable to the fan shroud Fan 1 cable, and the chassis Fan 2 cable to the fan shroud Fan 2 cable.
7	Re-install the fan shroud onto the chassis – take care to keep the fan power supply cables clear of the fan and heat sink surfaces. Then, re-install all screws as described in Step 2 , making sure to re-install the four longer screws at their same locations.
	Torque the screws to 8 ±1 inch lbs.
8	Reconnect the power source to the SPOD.

Appendix C C–5 MN-SPODPSX






Figure C-8. SPOD PS 1.5 Shroud Screw Locations

Appendix C C–6 MN-SPODPSX






Figure C-9. Remove the Fan Shroud




Figure C-10. Disconnect the Fan Power Supplies

Appendix C C–7 MN-SPODPSX






Figure C-11. SPOD PS 1.5 Heat Sink Location



Figure C-12. Reconnect the Fan Power Supplies

Appendix C C–8 MN-SPODPSX



C.4 Clean the SPOD PS 2 Heat Sinks

To clean the SPOD PS 2 Heat Sink:, do these steps:

10 cicum	the STOP 18 2 Heat Sinks, do these steps.
Step	Task
1	Disconnect the power source from the SPOD.
2	Remove the screws from the sides and end of the SPOD as needed – see Figure C-13 .
	Be sure to use an appropriate screwdriver, such as the one provided with the SPOD, to avoid damaging the screws
3	Lift the fan shroud assembly far enough off the chassis to expose the heat sink and access the fan power supply connections – see Figure C-14 .
4	Disconnect each fan power supply by carefully pulling the mated connector components straight apart — see Figure C-15 .
	Do not twist the mated cable connection when disconnecting the cable assemblies.
5	Visually inspect the exposed SPOD heat sinks, located on the top of the chassis, for any accumulated debris or blockage that may be obstructing airflow. Use compressed air to clear and clean the heat sink as needed – see Figure C-16 .
	Be sure to blow between the heat sink fins to remove any foreign object accumulation.
6	Reconnect each fan power supply. First, align the male and female connector's tabs. Then, push the connectors together until the connection locks – see Figure C-17 .
	Do not twist the mated cable connections when reconnecting the fan power supplies.
	 The fan power supply cables are labeled Fan 1 and Fan 2. Make sure to connect the chassis Fan 1 cable to the fan shroud Fan 1 cable, and the chassis Fan 2 cable to the fan shroud Fan 2 cable.
7	Re-install the fan shroud onto the chassis – take care to keep the fan power supply cables clear of the fan and heat sink surfaces. Then, re-install all screws as described in Step 2 .
	Torque the screws to 8 ±1 inch lbs.
8	Reconnect the power source to the SPOD.

Appendix C C–9 MN-SPODPSX






Figure C-13. SPOD PS 2 Shroud Screw Locations




Figure C-14. Remove the Fan Shroud

Appendix C C-10 MN-SPODPSX






Figure C-15. Disconnect the Fan Power Supplies




Figure C-16. SPOD PS 2 Heat Sink Locations

Appendix C C-11 MN-SPODPSX





Figure C-17. Reconnect the Fan Power Supplies



2114 WEST 7TH STREET TEMPE ARIZONA 85281 USA 480 • 333 • 2200 PHONE 480 • 333 • 2161 FAX