

# IBM FlashSystem 5100 IBM Storwize V5100 Control Enclosures Getting Started Guide



## Overview

This document describes the installation procedures for the following IBM FlashSystem® and Storwize® systems. It also contains information to help you plan the system configuration. This information applies to the following machine type and model (MTM) numbers.

Control Enclosure	MTM	Comments
IBM® FlashSystem 5100	2077-4H4 / 2078-4H4	Control enclosure
	2078-UHB	Utility control enclosure
Storwize V5100	2077-424 / 2078-424	Control enclosure with the ability to add hybrid expansions.
	2077-AF4 / 2078-AF4	Control enclosure with support to add all-Flash expansions (IBM Storwize V5100F).
	2078-U5B	Utility control enclosure

**Important:** This document is intended to be used by persons who are experienced with installing these systems. Before you use this information and the product it supports, read the following topics:

- [Installation worksheets](#) on page 8
- [Safety and environmental notices](#) on page 10
- [Notices](#) on page 11
- [IBM Systems Environmental Notices](#) and [IBM Systems Safety Notices](#) (provided on a DVD with your product order)

IBM Knowledge Center (<https://ibm.biz/BdqxdY>) contains more information about preparing the physical environment before the installation; it also provides information about configuring, managing, and servicing the system after installation. The IBM Knowledge Center is updated between product releases to provide the most current documentation.

## Unpacking and verifying the contents

Before you start the installation process, ensure that the following items are available.

- Philips screw driver
- Box knife
- Flat-blade screw driver (optional)
- Three Ethernet cables



The control enclosure and the following related parts are included in one box. The enclosed inventory sheet lists the part numbers of the items that were ordered. Items, such as drives and networking adapters, are preinstalled inside each node canister.

- Control enclosure with the following components preinstalled:
  - Two node canisters with optional networking adapters, SFPs, and memory.
  - Two power supply units (PSUs).
  - A combination of 24 drives and drive blanks.

The number of drives and drive blanks varies, according to the number of drives that were specified in the product order. For example, if 12 drives were ordered, the drives and 12 drive blanks are preinstalled in the control enclosure.

- Rail kit, which includes the left and right rails, and 8 securing M5 screws and locating pins.
- Cables, if they were ordered, for the type and number of networking adapters that are installed in each node canister.
- Two power cables.



**CAUTION:** The weight of this part or unit is between 32 and 55 kg (70.5 and 121.2 lb). It takes three persons to safely lift this part or unit. (C010)

## Unpack the control enclosure

To unpack the control enclosure, complete the following steps. If three persons or a lift are not available, more steps are required to remove some parts before the control enclosure can be installed.

1. Cut the box tape and open the lid of the shipping carton.
2. Remove the rail kit box and set it aside in a safe location.
3. Lift the front and rear foam packing pieces from the carton.
4. Remove the four corner reinforcement pieces from the carton.
  - If three people lift the control enclosure out of the carton or you are using lifting equipment, go to Step 15 on page 2.
  - Otherwise, continue to Step 5 on page 2.
5. Using the box knife, carefully cut the four corners of the carton from top to bottom.
6. Fold the sides and back of the carton down to uncover the rear of the control enclosure. If necessary, carefully cut along the lower fold line of the sides and remove them.
7. Carefully cut the raised section of the foam packing away from the rear of the enclosure.
8. Carefully cut open the bag that covers the rear of the enclosure.
9. Remove the left and right PSU, as described in [Removing and replacing a power supply unit](#) on page 3.
10. Record the last 6 digits of the serial number on the back of each PSU; then, set the power supplies aside.

Item	Left PSU	Right PSU
Serial Number		

11. Remove the upper and lower node canisters; see [Removing and replacing a node canister in the control enclosure](#) on page 4.
12. Record the serial number on the release handle of each node canister; then, set the canisters aside.

Item	Upper Node Canister	Lower Node Canister
Serial Number		


13. Carefully cut the raised section of the foam packing away from the front of the enclosure.
14. Remove all of the drives from the front of the enclosure, as described in [Removing and replacing a drive](#) on page 4.
15. Lift the enclosure from the shipping carton or push it on to a lift.
16. Record the serial number that is listed on the left end cap of the control enclosure.

Item	Serial Number	MTM
Control Enclosure		


## Installing the support rails and enclosure into the rack

Before you can install the control enclosure into the rack, you must first install the side support rails.

1. At each end of the side rail, grasp the tab and pull firmly to open the hinge bracket.




2. Align the holes in the rail bracket with the holes on the front (1) and rear rack cabinet flanges. Ensure that the rails are aligned on the inside (2) of the rack cabinet.




3. Close the front hinge bracket (3) to secure the rail to the rack cabinet flange.
4. Extend the length of the side rail, as needed.
5. Close the hinge at the rear of the rail (4).


6. Secure the rear of the rail to the rear rack flange with two black M5 screws (5).
7. Repeat Step 1 on page 2 through Step 6 on page 3 to secure the opposite rail to the rack cabinet.
8. Remove each end cap from the front of the enclosure. Lift the bottom of each end cap



9. At the front of the enclosure, use two rack mounting screws to secure each side of the enclosure to the rack.



10. Reinstall the left and right end caps to the front of the enclosure.



## Removing and replacing parts

If three persons or a lift are not available to install the control enclosure, the weight of the control enclosure must be reduced before it can be safely lifted. Follow the procedures to remove several parts of the control enclosure. Reinstall the parts after the control enclosure is installed in the rack. If you did not remove any parts, continue to [Connecting SAS cables](#) on page 5.

## Removing and replacing a power supply unit

To reduce weight during the installation procedure, you must remove and replace the power supply units (PSUs) in a control enclosure. When the system is running, the redundant PSUs operate in parallel; one PSU continues to provide power if the other PSU fails.


### About this task



- Follow recommended procedures for handling electrostatic discharge (ESD)-sensitive devices.
- No tools are required to complete this task. Do not remove or loosen any screws.
- Do not insert a PSU if the PSU slot does not contain a power interposer.

### Procedure

1. Fold out the handle (3) so that it extends perpendicular to the PSU.



- 1 Cable retention clip
- 2 LED indicator
- 3 PSU handle
- 4 PSU release tab
- 5 Power interposer release tab

2. Hold the PSU handle and press the PSU release tab (4). Steadily pull the handle horizontally to slide the PSU from the control enclosure. Support the PSU with your other hand as it is released.



3. To replace the PSU, fold out the handle so that it extends perpendicular to the PSU.
4. Extend the PSU handle and support the PSU. Slide the PSU into the control enclosure until the release tab engages with a "click".

## Removing and replacing a node canister in the control enclosure

During installation, you need to remove, and then reinstall, the node canisters from the control enclosure.

### About this task



**CAUTION:** This part or unit is heavy but has a weight smaller than 18 kg (39.7 lb). Use care when lifting, removing, or installing this part or unit. (C008)

- Use care when you remove a node canister from the enclosure. The node canister is long and its center of gravity is far forward. It can be helpful to have a lift or other sturdy, flat surface ready to receive the node canister during removal.
- No tools are needed to complete this task. Do not remove or loosen any screws.

### Procedure


1. To remove the node canister, locate the left and right release levers for the node canister.

On the upper node canister, the release levers are at the top of the control enclosure. On the bottom node canister, the release levers are at the bottom of the enclosure. The serial number is on a label on the release lever;

2. Pull the left and right levers by the blue ends so that they both unlatch and swing out into an open position, as shown.



3. Use the release levers to slowly pull the node canister and partially extract it from the enclosure.



**Warning:** Observe safe handling practices as you complete the following steps. The node canister is long and heavy. Use a lifting platform or other nearby surface to support the node canister as it is extracted from the control enclosure.

4. Hold the node canister by its sides so that it is level and its weight is balanced. Then, slide the node canister out of the control enclosure.
5. Place the node canister on a flat, level surface; the lid must face up.



**Note:** The top node canister is inverted; after you remove the top node canister, you must turn it over.

6. To replace the node canister, ensure that both of the canister release levers are in the open position.
7. Push the node canister into the enclosure, ensuring that both release levers engage with the canister and close.
8. Press the release levers closed to fully engage the node canister into the enclosure. Press the latch ends to ensure that the latches are engaged with the control enclosure.

## Removing and replacing a drive

Use the following procedures to remove and replace a drive or an IBM FlashCore Module (FCM) from a node canister.

### About this task



- Follow the recommended procedures for handling electrostatic discharge (ESD)-sensitive devices.
- No tools are required to complete this task. Do not remove or loosen any screws during this procedure.
- Every drive slot of an operational control enclosure must contain either a drive or a blank filler. Do not leave a drive slot empty for more than 10 minutes during servicing.
- IBM FlashCore Modules are not interchangeable with the flash modules in IBM FlashSystem 900 storage enclosures.

### Procedure

1. To remove the drive, press the blue touchpoint to unlock the latching handle.



2. Lower the handle and slide the drive out of the enclosure as shown.



3. To replace the drive, ensure that the LED indicators are at the top of the new drive.
4. Press the blue touchpoint to unlock the latching handle on the drive.
5. Slide the new drive into the node canister. Press on the drive label near the bottom of the new drive to ensure that it is fully inserted.




6. Close the handle on the drive until the latch clicks into place.



## Connecting SAS cables

This task applies if you are installing one or more SAS-attached expansion enclosures. Each control enclosure can manage two chains of 2U and 5U expansion enclosures. The system supports an intermix of 2U and 5U expansion enclosures with a total chain weight of 10 in each of two SAS chains. For more information about expansion enclosures, see IBM Knowledge Center (<https://ibm.biz/BdqxdY>).

1. Using the supplied SAS cables, connect the control enclosure to the first expansion enclosure.
  - a. Connect SAS port 1 of the top node canister (node 1) in the control enclosure to SAS port 1 of the left expansion canister in the first expansion enclosure.
  - b. Connect SAS port 1 of the bottom node canister (node 2) in the control enclosure to SAS port 1 of the right expansion canister in the first expansion enclosure.
2. To add a second expansion enclosure chain to the control enclosure, complete the following steps.
  - a. Connect SAS port 3 of the top node canister in the control enclosure to SAS port 1 of the left expansion canister in the second expansion enclosure.
  - b. Connect SAS port 3 of the bottom node canister in the control enclosure to SAS port 1 of the right expansion canister in the second expansion enclosure.



**Important:** In the control enclosure, node canister 1 is on top and node canister 2 is on the bottom. Because the node canisters are inverted, the location of the ports and the numbering of the ports are oriented differently on each node canister. It is important to remember this orientation when you are installing adapters and cables.

## Connect networking cables


To provide connectivity for the system, you must connect cables to the appropriate ports on the control enclosure.

Four 10 Gbps Ethernet ports on each node canister provide system management connections and iSCSI host connectivity. The onboard 10 Gbps Ethernet ports use RJ-45 connections and operate at 1 Gbps when connected to a 1 Gbps switch. A separate technician port provides access to initialization and service assistant functions.

Onboard Ethernet Port	Speed	Function
1	10 Gbps	Management IP, Service IP, Host I/O
2	10 Gbps	Secondary Management IP, Host I/O
3	10 Gbps	Host I/O
4	10 Gbps	Host I/O
T	1 Gbps	Technician Port - DHCP/DNS for direct attach service management.

## Connecting Ethernet cables

1. Connect Ethernet port 1 of each node canister to the IP network that will provide connection to the system management interfaces.



Ethernet port 1 can be used for iSCSI connectivity to the system by hosts on the network. If the system has more than one control enclosure, ensure port 1 of every node canister is connected to the same network to provide access if the configuration node fails.

2. Optionally, connect Ethernet port 2 of each node canister in the system to a second IP network that will provide redundant connection to the system management interfaces. Port 2 can also be used for iSCSI connectivity to the system by hosts on the network. If the system contains more than one control enclosure, ensure that port 2 of every node canister is connected to the same network to provide access if the configuration node fails.

## Connecting other networking cables

Each control enclosure has two PCI slots that support optional networking adapters. Use the information that you provided in the tables in [Network cable worksheet](#) on page 9 to establish the proper connections.

1. Ensure that the networking adapters are installed in the appropriate PCIe slot.
2. Connect the required number of FC or Ethernet cables to the ports on each node canister. Both node canisters must have the same number of cables connected.

## Powering on the system

After you install all hardware components, you must power on the system and check its status. Each control enclosure has two power supply units (PSUs). To provide redundancy in a power failure, connect the power cords to separate power circuits.



**Attention:** Do not power on the system with any open drive bays or host interface adapter slots. Open bays or PCIe slots disrupt the internal air flow, causing the drives to receive insufficient cooling. Filler panels must be installed in all empty drive bays and PCIe slots.

1. Ensure that the circuit breakers or switches of the power sources are turned on.
2. Ensure that each power cable is secured to each PSU on the back of the node. To do so, route each power cable through the retainer.

The cable retainer has a curved opening that faces the rear of the PSU. After you plug the power cable in to the PSU, slip the power cable behind the retainer. Pull the cable back into the retainer opening to secure it. Then, route each power cable through the cable retainer.



For PSU 1, hook the power cable underneath the cable retainer so the cable can extend to the left.

For PSU 2, make a loop to secure the cable under the retainer and extend the power cable to the right side of the node.

To remove a power cable, push the cable forward to unhook it from the cable retainer. Then, unplug the cable from the PSU.

3. Connect the PSUs of the control enclosure and each expansion enclosure to their power sources.
4. Check the status LED indicators to verify the status of the enclosure. The control enclosure is ready and running without critical errors when the LEDs indicate the following status.

Location	LEDs	Indicator Status		
		Back of each node canister (and 2U expansion enclosures, if applicable)		Ⓢ Power LED is on <b>(1)</b> .
Front of the control enclosure, left end cap		Ⓢ Node operational LED is on.	Ⓢ Identify node LED is off (default).	! Node fault LED is off.


## Setting up the system or adding the control enclosure to an existing system

The system can contain 1-4 control enclosures. If you are adding a control enclosure to an existing system, go to [Adding a control enclosure to an existing system](#) on page 7. Otherwise, continue to [Setting up the system](#) on page 7.

### Setting up the system

Each node canister in the control enclosure has a 1 Gbps Ethernet technician port. Before you initiate a new system, you must connect an Ethernet cable to the technician port on the control enclosure.

1. Locate the technician ports on the control enclosure. Because node canister 1 is inverted, the plug of the Ethernet cable also needs to be inverted to connect to the technician port.



2. Connect an Ethernet cable to a technician port. The cable must be long enough to connect easily to a notebook computer.

If Dynamic Host Configuration Protocol (DHCP) is available, the notebook computer is automatically configured. If DHCP is not available, use the following information to configure the computer.

Static IPv4 Address	Subnet Mask	Gateway	DNS
192.168.0.2	255.255.255.0	192.168.0.1	192.168.0.1

3. Use the notebook computer to open a new web browser page. The web browser might display a warning about a potential security risk. It is safe to accept the risk and continue. See [Browser considerations](#) on page 8 for more information.
4. If the node canisters communicate with each other using RDMA over Ethernet, browse to address `http://service` or press the wrench icon on the initialization page to access the Service Assistant Tool. Use the following credentials to sign in to the system.

User ID	Initial Password
superuser	passw0rd

5. Use the **Change node IP** tab of the Service Assistant to configure the node IP settings for the node. Repeat this step for each node canister in the system.
6. Use the initialization GUI to enter the requested information, such as the management IP address and service IP addresses.



You need to set the IP address, subnet mask, and DNS server only when you do not want to use DHCP.

For more information, see [Management and service address worksheet](#) on page 8.

### Adding a control enclosure to an existing system

If the system was already set up on another control enclosure, do not install it again on this control enclosure. Instead, use the management GUI to add the control enclosure to the system.

1. Connect the node canisters to the storage area network or to a 25 Gbps (or faster) Ethernet.
2. Configure the zoning on the SAN switches. The correct zoning provides a way for the FC ports to connect to each other.

If the new node canisters use RDMA over Ethernet to communicate with other node canisters, use the service assistant tool or the `satask chnodeip` command to set the node IP of each node that will be in the system.

3. In the management GUI, select **Monitoring > System**. On the **System - Overview** page, select **Add Enclosure**.

When a new enclosure is cabled correctly to the system, this action automatically displays on the **System - Overview** page. If this action does not appear, ensure that the new enclosure is cabled correctly. You can also add a new enclosure by selecting **Add Enclosure** from the **System Actions** menu.

4. Complete the instructions in the **Add Enclosure** wizard until the control enclosure is added to the system.
5. If two control enclosures are in the system, you must set up a quorum disk or application outside of the system. If the two control enclosures lose communication with each other, the quorum disk prevents both I/O groups from going offline.

## Browser considerations

The management GUI supports the following HTML5-compliant browsers. Certain features must be enabled on the browser. Review the documentation that is provided with your browser to determine how to enable each item.

Browser	Required enabled features
<ul style="list-style-type: none"> <li>• Mozilla Firefox 80.0.1</li> <li>• Mozilla Firefox Extended Support Release (ESR) 78.2.0</li> <li>• Microsoft Edge 85.0</li> <li>• Google Chrome 85.0</li> </ul>	<ul style="list-style-type: none"> <li>• JavaScript</li> <li>• Cookies</li> <li>• Scripts allowed to disable or replace context menus (Mozilla Firefox only)</li> </ul>

In addition, review the following considerations about browser security features and certificates.

- Browser security features might prompt you before the browser accepts the self-signed certificate that the system issues.
- You might need to remove old certificates that are stored in the browser before the browser accepts the request.
- The web browser might display a warning about a potential security risk. It is safe to accept the risk and continue.
- After the technician port physical connection is completed (that is, connected both ends), it can take up to 45 seconds before the port is fully up and able to process requests. Submitting requests before this interval might result in 404 error responses.
- If the `http://service` request causes a 404 error or does not produce a response, you might need to use URL `https://192.168.0.1` to connect to the system.

## Installation worksheets

Worksheets can help you plan and install the system. You can also use the worksheets to track important information as you remove and reinstall parts from the control enclosure during the installation process.

### Drive configuration worksheet

The control enclosure supports up to 24 drives, which are installed in drive slots on the front of the enclosure. Non-Volatile Memory Express (NVMe) drives and Storage Class Memory (SCM) drives can be installed in any drive slot. However, the highest capacity drive must be installed in the lowest-numbered available drive slot. Drive slots cannot be empty; each slot must contain a drive or drive blank.

Use the following table to record information about the drives in the control enclosure. For each slot number, specify the type and capacity of the drive or whether a drive blank is installed.

Control Enclosure S/N:																								
Content	Drive Slots																							
Type NVMe / SCM																								
Capacity																								
Drive Blank																								
Slot	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24

### Management and service address worksheet

Use the following table to record the management address and service addresses for each control enclosure. The primary system address is bound to Ethernet port 1. The secondary system address, if specified, is bound to Ethernet port 2. Both IPv4 and IPv6 addresses can be used. Specify the type of installation and the serial number (S/N) of the control enclosure.

- If you are installing a new system installation, designate new, unused IP addresses.
- If you are adding an I/O group (control enclosure) to an existing system, use the management address of the existing system.

Control Enclosure S/N:	Are you adding this control enclosure to an existing system? <input type="checkbox"/> Yes <input type="checkbox"/> No		
Address Type	IP Address	Network Mask	Default Gateway
Primary system address (required)			



<b>Control Enclosure S/N:</b>	<b>Are you adding this control enclosure to an existing system? <input type="checkbox"/> Yes <input type="checkbox"/> No</b>		
<b>Address Type</b>	<b>IP Address</b>	<b>Network Mask</b>	<b>Default Gateway</b>
Secondary system address (optional)			
Node canister 1 service address (required)			
Node canister 2 service address (required)			

## Network cable worksheet

Use the following worksheets to record the location and type of cable connections for each control enclosure in the system.

### Ethernet cable standards

The control enclosure supports Ethernet connections by using onboard ports and networking adapters. The following table summarizes the Ethernet cable standards for each connection.

Ethernet Port Type	Cable Type	Minimum Standard	Connector
1 Gbps Ethernet technician port	TP	Cat 5e	RJ45
10 Gbps onboard Ethernet ports	TP	Cat 6 (up to 55 m), Cat 6a or Cat 7 (up to 100 m) at 10 Gbps, or Cat 5e at 1 Gbps	RJ45
25 Gbps Ethernet host interface adapter (must be ordered)	Optical	OM3 (up to 70 m), OM4 (up to 100 m)	LC

### Onboard Ethernet port connection worksheet

Ethernet port 1 of each node canister is connected to an enabled port on your Ethernet switch or router. Ethernet port 1 is used to access the management GUI, the service assistant GUI for the node canister, and for iSCSI host attachment. You can also attach an Ethernet cable from Ethernet port 2 on the node canister your Ethernet network. Port 2 can be used for the management GUI and for iSCSI host attachment. Ethernet ports 3 and 4 are for iSCSI attachment only.

<p>The ports on the upper node canister (canister 1) are numbered from right to left.</p>	
<p>The ports on the lower node canister (canister 2) are numbered from left to right.</p>	

Record information about the onboard Ethernet port connections in the following table.

<b>Node Canister 1 (upper)</b>	<b>Component</b>	<b>Ethernet Port 4</b>	<b>Ethernet Port 3</b>	<b>Ethernet Port 2</b>	<b>Ethernet Port 1</b>	<b>Technician Port</b>
	Switch					None
	Port					None
	Speed: 1 or 10 Gbps					1 Gbps
<b>Node Canister 2 (lower)</b>	<b>Component</b>	<b>Ethernet Port 1</b>	<b>Ethernet Port 2</b>	<b>Ethernet Port 3</b>	<b>Ethernet Port 4</b>	<b>Technician Port</b>
	Switch					None
	Port					None
	Speed: 1 or 10 Gbps					1 Gbps

### Ethernet network connection worksheet

Each node canister supports 2-port 25 Gbps internet Wide-area RDMA Protocol (iWARP) or RDMA over Converged Ethernet (RoCE) Ethernet adapters. Install the adapters according to the following guidelines.

- iWARP and RoCE Ethernet adapters cannot be mixed within a node canister.
- Fibre Channel adapters are installed before Ethernet adapters, beginning with slot 1 and then slot 2.
- Ethernet adapters are installed beginning with the first available slot.

- To connect to expansion enclosures, you must order a 4-port 12 Gbps SAS adapter that is installed in slot 1. However, only ports 1 and 3 are used to establish a SAS connection

Use the following table to plan your system connections using the optional Ethernet networking adapter.

Node Canister 1 (upper)	Ethernet Adapter Slot 2		Adapter Slot 1
	Port 2	Port 1	
Switch			N/A
Port			
Speed: 10 or 25 Gbps			
Node Canister 2 (lower)	Adapter Slot 1	Ethernet Adapter Slot 2	
		Port 1	Port 2
Switch	N/A		
Port			
Speed: 10 or 25 Gbps			

### Fibre Channel connection worksheet

Each node canister supports one 4-port 32 Gbps Fibre Channel (FC) adapter or a 4-port 16 Gbps FC adapter. Use the following table to record the FC port connections.

Node Canister 1 (upper)	FC Adapter Slot 2				Adapter Slot 1
	Port 4	Port 3	Port 2	Port 1	
Switch or host					N/A
Port 1					
Speed: 32, 16, or 8 Gbps					
Node Canister 2 (lower)	Adapter Slot 1	Adapter Slot 2			
		Port 1	Port 2	Port 3	Port 4
Switch or host	N/A				
Port 2					
Speed: 32, 16, or 8 Gbps					

## Safety and environmental notices

Review all safety notices, environmental notices, and electronic emission notices before you install and use the product.

**Suitability for telecommunication environment:** This product is not intended to connect directly or indirectly by any means whatsoever to interfaces of public telecommunications networks.

To find the translated text for a caution or danger notice, complete the following steps.

1. Look for the identification number at the end of each caution notice or each danger notice. In the following examples, the numbers (C001) and (D002) are the identification numbers.

**CAUTION:** A caution notice indicates the presence of a hazard that has the potential of causing moderate or minor personal injury. (C001)

**DANGER:** A danger notice indicates the presence of a hazard that has the potential of causing death or serious personal injury. (D002)

2. Locate the *IBM Systems Safety Notices* document with the user publications that were provided with your system hardware.
3. Find the matching identification number in *IBM Systems Safety Notices*. Then, review the topics about the safety notices to ensure that you are in compliance.
4. (Optional) Read the multilingual safety instructions on the system website.
  - a. Go to [www.ibm.com/support](http://www.ibm.com/support)
  - b. Enter the name of your system in the Search field (for example, "FlashSystem 5100").

- c. Click the documentation link.

## Environmental notices

---

This information contains all the required environmental notices for IBM Systems products in English and other languages.

The [IBM Systems Environmental Notices](#) information includes statements on limitations, product information, product recycling and disposal, battery information, flat panel display, refrigeration and water-cooling systems, external power supplies, and safety data sheets.

## Compliance standards

---

**Note:** This product was designed, tested, manufactured, and certified for safe operation. It complies with IEC 60950-1 and/or IEC 62368-1 and where required, to relevant national differences/deviations (NDs) to these IEC base standards. This includes, but is not limited to: EN (European Norms including all Amendments under the Low Voltage Directive), UL/CSA (North America bi-national harmonized and marked per accredited NRTL agency listings), and other such derivative certifications according to corporate determinations and latest regional publication compliance standardized requirements.

Regulatory Model ID (RMID) or Machine Type - Modelsl (MT-Ms) may also be used to supplement identification (ID) for worldwide (WW) co-compliance filings or registrations with regulatory bodies.

## Accessibility features for the system

---

Accessibility features help users who have a disability, such as restricted mobility or limited vision, to use information technology products successfully.

### Accessibility features

These are the major accessibility features for the system:

- You can use screen-reader software and a digital speech synthesizer to hear what is displayed on the screen. HTML documents are tested by using JAWS version 15.0.
- This product uses standard Windows navigation keys.
- Interfaces are commonly used by screen readers.
- Industry-standard devices, ports, and connectors.

■ For information about the accessibility features of the online documentation, see [IBM Knowledge Center \(https://ibm.biz/BdqxdY\)](https://ibm.biz/BdqxdY).

### Keyboard navigation

You can use keys or key combinations for operations and to initiate menu actions that can also be done through mouse actions. You can go to the system online documentation from the keyboard by using the keyboard shortcuts for your browser or screen-reader software. See your browser or screen-reader software Help for a list of keyboard shortcuts that it supports.

### IBM and accessibility

See the [IBM Human Ability and Accessibility Center](#) for more information about the commitment that IBM has to accessibility.

## Notices

---

This information was developed for products and services offered in the US. This material might be available from IBM in other languages. However, you may be required to own a copy of the product or product version in that language in order to access it.

IBM may not offer the products, services, or features discussed in this document in other countries. Consult your local IBM representative for information on the products and services currently available in your area. Any reference to an IBM product, program, or service is not intended to state or imply that only that IBM product, program, or service may be used. Any functionally equivalent product, program, or service that does not infringe any IBM intellectual property right may be used instead. However, it is the user's responsibility to evaluate and verify the operation of any non-IBM product, program, or service.

IBM may have patents or pending patent applications covering subject matter described in this document. The furnishing of this document does not grant you any license to these patents. You can send license inquiries, in writing, to:

*IBM Director of Licensing  
IBM Corporation  
North Castle Drive  
Armonk, NY 10504-1785  
U.S.A.*

For license inquiries regarding double-byte character set (DBCS) information, contact the IBM Intellectual Property Department in your country or send inquiries, in writing, to:

*Intellectual Property Licensing  
Legal and Intellectual Property Law  
IBM Japan, Ltd.  
19-21, Nihonbashi-Hakozakicho, Chuo-ku  
Tokyo 103-8510, Japan*

INTERNATIONAL BUSINESS MACHINES CORPORATION PROVIDES THIS PUBLICATION "AS IS" WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF NON-INFRINGEMENT, MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. Some jurisdictions do not allow disclaimer of express or implied warranties in certain transactions, therefore, this statement may not apply to you.

This information could include technical inaccuracies or typographical errors. Changes are periodically made to the information herein; these changes will be incorporated in new editions of the publication. IBM may make improvements and/or changes in the product(s) and/or the program(s) described in this publication at any time without notice.

Any references in this information to non-IBM websites are provided for convenience only and do not in any manner serve as an endorsement of those websites. The materials at those websites are not part of the materials for this IBM product and use of those websites is at your own risk.

IBM may use or distribute any of the information you provide in any way it believes appropriate without incurring any obligation to you.

Licensees of this program who wish to have information about it for the purpose of enabling: (i) the exchange of information between independently created programs and other programs (including this one) and (ii) the mutual use of the information which has been exchanged, should contact:

*IBM Director of Licensing  
IBM Corporation  
North Castle Drive, MD-NC119  
Armonk, NY 10504-1785  
US*

Such information may be available, subject to appropriate terms and conditions, including in some cases, payment of a fee.

The licensed program described in this document and all licensed material available for it are provided by IBM under terms of the IBM Customer Agreement, IBM International Program License Agreement or any equivalent agreement between us.

The performance data discussed herein is presented as derived under specific operating conditions. Actual results may vary.

Information concerning non-IBM products was obtained from the suppliers of those products, their published announcements or other publicly available sources. IBM has not tested those products and cannot confirm the accuracy of performance, compatibility or any other claims related to non-IBM products. Questions on the capabilities of non-IBM products should be addressed to the suppliers of those products.

Statements regarding IBM's future direction or intent are subject to change or withdrawal without notice, and represent goals and objectives only.

All IBM prices shown are IBM's suggested retail prices, are current and are subject to change without notice. Dealer prices may vary.

This information is for planning purposes only. The information herein is subject to change before the products described become available.

This information contains examples of data and reports used in daily business operations. To illustrate them as completely as possible, the examples include the names of individuals, companies, brands, and products. All of these names are fictitious and any similarity to the names and addresses used by an actual business enterprise is entirely coincidental.

#### COPYRIGHT LICENSE:

This information contains sample application programs in source language, which illustrate programming techniques on various operating platforms. You may copy, modify, and distribute these sample programs in any form without payment to IBM, for the purposes of developing, using, marketing or distributing application programs conforming to the application programming interface for the operating platform for which the sample programs are written. These examples have not been thoroughly tested under all conditions. IBM, therefore, cannot guarantee or imply reliability, serviceability, or function of these programs. The sample programs are provided "AS IS", without warranty of any kind. IBM shall not be liable for any damages arising out of your use of the sample programs.

If you are viewing this information softcopy, the photographs and color illustrations may not appear.

## Where to find the Statement of Limited Warranty

---

The *Statement of Limited Warranty* is available in both hardcopy format and in the FlashSystem 5100 IBM Knowledge Center.

## Trademarks

---

IBM, the IBM logo, and [ibm.com](http://ibm.com)<sup>®</sup> are trademarks or registered trademarks of International Business Machines Corp., registered in many jurisdictions worldwide. Other product and service names might be trademarks of IBM or other companies. The current list of IBM trademarks is available on the web at Copyright and trademark information at [www.ibm.com/legal/copytrade.html](http://www.ibm.com/legal/copytrade.html).

Microsoft and Windows are trademarks of Microsoft Corporation in the United States, other countries, or both.

## Homologation statement

---

This product may not be certified in your country for connection by any means whatsoever to interfaces of public telecommunications networks. Further certification may be required by law prior to making any such connection. Contact an IBM representative or reseller for any questions.

## Electromagnetic compatibility notices

---

The following Class A statements apply to IBM products and their features unless designated as electromagnetic compatibility (EMC) Class B in the feature information.

When attaching a monitor to the equipment, you must use the designated monitor cable and any interference suppression devices that are supplied with the monitor.

### Canada Notice

CAN ICES-3 (A)/NMB-3(A)

### European Community and Morocco Notice

This product is in conformity with the protection requirements of Directive 2014/30/EU of the European Parliament and of the Council on the harmonization of the laws of the Member States relating to electromagnetic compatibility. IBM cannot accept responsibility for any failure to satisfy the protection requirements resulting from a non-recommended modification of the product, including the fitting of non-IBM option cards.

This product may cause interference if used in residential areas. Such use must be avoided unless the user takes special measures to reduce electromagnetic emissions to prevent interference to the reception of radio and television broadcasts.

**Warning:** This equipment is compliant with Class A of CISPR 32. In a residential environment this equipment may cause radio interference.

### Germany Notice

#### **Deutschsprachiger EU Hinweis: Hinweis für Geräte der Klasse A EU-Richtlinie zur Elektromagnetischen Verträglichkeit**

Dieses Produkt entspricht den Schutzanforderungen der EU-Richtlinie 2014/30/EU zur Angleichung der Rechtsvorschriften über die elektromagnetische Verträglichkeit in den EU-Mitgliedsstaaten und hält die Grenzwerte der EN 55032 Klasse A ein.

Um dieses sicherzustellen, sind die Geräte wie in den Handbüchern beschrieben zu installieren und zu betreiben. Des Weiteren dürfen auch nur von der IBM empfohlene Kabel angeschlossen werden. IBM übernimmt keine Verantwortung für die Einhaltung der Schutzanforderungen, wenn das Produkt ohne Zustimmung von IBM verändert bzw. wenn Erweiterungskomponenten von Fremdherstellern ohne Empfehlung von IBM gesteckt/eingebaut werden.

EN 55032 Klasse A Geräte müssen mit folgendem Warnhinweis versehen werden:

"Warnung: Dieses ist eine Einrichtung der Klasse A. Diese Einrichtung kann im Wohnbereich Funk-Störungen verursachen; in diesem Fall kann vom Betreiber verlangt werden, angemessene Maßnahmen zu ergreifen und dafür aufzukommen."

#### **Deutschland: Einhaltung des Gesetzes über die elektromagnetische Verträglichkeit von Geräten**

Dieses Produkt entspricht dem "Gesetz über die elektromagnetische Verträglichkeit von Geräten (EMVG)." Dies ist die Umsetzung der EU-Richtlinie 2014/30/EU in der Bundesrepublik Deutschland.

#### **Zulassungsbescheinigung laut dem Deutschen Gesetz über die elektromagnetische Verträglichkeit von Geräten (EMVG) (bzw. der EMC Richtlinie 2014/30/EU) für Geräte der Klasse A**

Dieses Gerät ist berechtigt, in Übereinstimmung mit dem Deutschen EMVG das EG-Konformitätszeichen - CE - zu führen.

Verantwortlich für die Einhaltung der EMV-Vorschriften ist der Hersteller:

International Business Machines Corp.  
New Orchard Road  
Armonk, New York 10504  
Tel: 914-499-1900

Der verantwortliche Ansprechpartner des Herstellers in der EU ist:

IBM Deutschland GmbH  
Technical Relations Europe, Abteilung M456  
IBM-Allee 1, 71139 Ehningen, Germany  
Tel: +49 800 225 5426  
e-mail: Halloibm@de.ibm.com

Generelle Informationen:

**Das Gerät erfüllt die Schutzanforderungen nach EN 55024 und EN 55032 Klasse A.**

## Japan Electronics and Information Technology Industries Association (JEITA) Notice

(一社) 電子情報技術産業協会 高調波電流抑制対策実施  
要領に基づく定格入力電力値： Knowledge Centerの各製品の  
仕様ページ参照

This statement applies to products less than or equal to 20 A per phase.

高調波電流規格 JIS C 61000-3-2 適合品

This statement applies to products greater than 20 A, single phase.

高調波電流規格 JIS C 61000-3-2 準用品

本装置は、「高圧又は特別高圧で受電する需要家の高調波抑制対策ガイドライン」対象機器（高調波発生機器）です。

- 回路分類：6（単相、PFC回路付）
- 換算係数：0

This statement applies to products greater than 20 A per phase, three-phase.

高調波電流規格 JIS C 61000-3-2 準用品

本装置は、「高圧又は特別高圧で受電する需要家の高調波抑制対策ガイドライン」対象機器（高調波発生機器）です。

- 回路分類：5（3相、PFC回路付）
- 換算係数：0

## Japan Voluntary Control Council for Interference (VCCI) Notice

この装置は、クラスA情報技術装置です。この装置を家庭環境で使用すると電磁妨害を引き起こすことがあります。この場合には使用者が適切な対策を講ずるよう要求されることがあります。

VCCI-A

## Korea Notice

이 기기는 업무용 환경에서 사용할 목적으로 적합성평가를 받은 기기로서 가정용 환경에서 사용하는 경우 전파간섭의 우려가 있습니다.

## People's Republic of China Notice

### 声 明

此为 A 级产品,在生活环境  
中,该产品可能会造成无线电干扰。  
在这种情况下,可能需要用户对其  
干扰采取切实可行的措施。

## Russia Notice

ВНИМАНИЕ! Настоящее изделие относится к классу А.  
В жилых помещениях оно может создавать  
радиопомехи, для снижения которых необходимы  
дополнительные меры

0100007

## Taiwan Notice

### 警告使用者：

此為甲類資訊技術設備，  
於居住環境中使用時，  
可能會造成射頻擾動，在此種情況下，  
使用者會被要求採取某些適當的對策。

### IBM Taiwan Contact Information:

台灣IBM產品服務聯絡方式：  
台灣國際商業機器股份有限公司  
台北市敦仁路7號3樓  
電話：0800-016-888

12c00790

## United States Federal Communications Commission (FCC) Notice

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference, in which case the user will be required to correct the interference at his own expense.

Properly shielded and grounded cables and connectors must be used in order to meet FCC emission limits. IBM is not responsible for any radio or television interference caused by using other than recommended cables and connectors, or by unauthorized changes or modifications to this equipment. Unauthorized changes or modifications could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) this device might not cause harmful interference, and (2) this device must accept any interference received, including interference that might cause undesired operation.

### Responsible Party:

International Business Machines Corporation  
New Orchard Road  
Armonk, NY 10504

Contact for FCC compliance information only: [fccinfo@us.ibm.com](mailto:fccinfo@us.ibm.com)

---

This edition applies to version 8, release 4, modification 0, and to all subsequent modifications until otherwise indicated in new editions.

© **Copyright International Business Machines Corporation 2018, 2020.**

US Government Users Restricted Rights – Use, duplication or disclosure restricted by GSA ADP Schedule Contract with IBM Corp.

(1P) P/N: 03GU854

