

Installing Universal Flat Wall Mount to Metal Stud Walls (Metal Stud Accessory Kit ACC 215 Required)

Models: SF 630, SF 630-S,
SF 630P, SF 630P-S,
SF 632, SF 632-S,
SF 632P, SF 632P-S,
SF 635, SF 635-S,
SF 635P, SF 635P-S

⚠ WARNING

- Drywall must be 1/2" or thicker, and metal stud must be 24 gauge or thicker.
- Make sure that the supporting surface will safely support the combined load of the equipment and all attached hardware and components.

1 Use a stud finder to locate the edges of the stud. Use of an edge-to-edge stud finder is highly recommended. Based on its edges, draw a vertical line down the stud's center. Place wall plate (A) on wall as a template, making sure that the two mounting holes are over the stud centerline. Level plate, and mark the center of the two holes. Drill two 1/2" holes through drywall and metal studs. **Note:** It may be necessary to drill 5/32" pilot holes prior to drilling 1/2" holes.

Refer to instruction sheet included with Peerless accessory kit ACC 215 for metal studs to install togglers. Loosely fasten mount assembly (A) to wall using two 1/4-20 x 2-1/2" screws as shown.

Level, hold, and then tighten all screws.

Skip to step 2 on page 6 of main instruction sheet.

