

## NOSE ASSEMBLY DATA SHEET





## ASSEMBLY:

Note: If nose assy is assembled as it is when purchased new, follow steps 1, 4 & 5 to attach to tool.

- 1. Insert spring (9) into piston on tool.
- 2. Place jaw set (6) inside collet (5).
- 3. Place bumper (8) over follower (7) and place this assy in collet (5) against jaw set (6) making sure tapered end on follower (7) lines up with the split line of jaw set (6).
- Screw this assembly onto end of piston on tool. Tighten securely using wrenches on flats provided.
- 5. Thread sleeve (3), which contains jam nut (4), snugly onto end of head cylinder. Tighten jam nut (4) securely.

## **DISASSEMBLY:**

Reverse assembly instructions.



5/99 Rev. 8/16

MADE in USA

44766 Centre Court Clinton Twp. MI 48038 USA Ph: +1 (586) 226-1500 Fax: +1 (586) 226-1505 solutions@gagebilt.com / www.gagebilt.com

Туре:			Fastener:	
Non Self-Releasing 1/8", 5/32" & 3/16" Ø			CHERRYMAX®, CHERRYMAX® 'AB', MBC® LOCK CREATOR BACR15FR/FP, BACR15GF/GK	Recommended Tool: GB704
Ref. No.	Qty.	Description		456MAX-701-17
1	1	Retaining Ring		70101
2	2	Stem Stop		70102
3	1	Sleeve		70103
4	1	Jam Nut		70104
5	1	Collet		70105
6	1	Jaw Set (2 pcs.)		30513
7	1	Follower		40506
8	1	Bumper		70108
9	1	Spring		70109