

AIPTEK		BELL & HOWELL		CANON (CONT'D)	
<b>Model to Empire Battery #</b>		<b>Model to Empire Battery #</b>		<b>Model to Empire Battery #</b>	
A-HD-1	203	BH-725	248	EOS-REBEL T2i/T3i/T4i	384
A-HD720P/HD1080P	203	JMJ-20910	150	EOS-REBEL T3	415
AHD2/2PRO	203	JSJ-20900	146	EOS-REBEL XS / XSI	350
DAM-Z5X/Z5X2	203	<b>Battery to Empire Battery #</b>		EOS-REBEL XT/REBEL XTi	204
DVPW-V3	203	64324217	150	EOS-60D/60DA	357
DZO, DZO-V37	203	HELIX HLX-U02	248	EOS-400D	204
DZO-V38	248	<b>BEN Q</b>		EOS-450D	350
DZO-V58N	203	<b>Model to Empire Battery #</b>		EOS-550D	384
DZO-Z33/Z53	203	DC C500	269	<b>EOS-M</b>	437
GO HD-720P	203	DC E43, DC E53, DC E63	269	EQ-350	118
HD-1080P	203	<b>Battery to Empire Battery #</b>		ES-10V/20V/40/70/80/90/100	118
HDDV 8300	228	NP-900, 02491-0015-00	269	ES-50/55/60/65/75	161
MINI STB-1	228	<b>BLAUPUNKT</b>		ES-170/180/190/200/200A/270	118
POCKET DV 5700	203	<b>Model to Empire Battery #</b>		ES-280/290/300/400/400V/500	118
POCKET DV AHD100/200/300	203	CR-1500/1800/2000S	100C	ES-300V/410V/420V/520/520A	161
POCKET DV Z300HD	203	CR-4800/5000/6000	110	ES-550/600/750/800/870/900	118
POCKET DV AHDZ500PLUS	203	CR-8000/8010/8080	107	ES-970/1000/2000/2500/3000	118
POCKET DV AHDZ600	203	PTV-260	100C	ES-4000/5000/6000/6500	161
POCKET CAM8900	203	PTV8-77	109	ES-6500V/7000/7000V/8000	161
POCKET DVDDV-V1	203	<b>Battery to Empire Battery #</b>		ES-8000V/8100V/8200V	161
POCKET DV8800LE	203	AX-77/80	109	ES-8400V/8600/8600V	161
POCKET DV8800N	203	<b>CANON</b>		EX-1	118
POCKET DV H100	203	<b>Model to Empire Battery #</b>		F-1000S	100C
POCKET DV T200	203	7084A001/7084A002	252	FR-1	161
POCKET DVZ100LE/200	203	A-1, A-1.MARK II	132	FS10*/11*/40*/100*/400*	376
POCKET DV Z100PRO	203	A-2/10	118	FS-20/21/22/31/200/300	376
POCKET DV Z200PRO	203	A-5/50/520	194	FV-2/10/20/30/40/50	193
POCKET DV Z300HD	203	BG-E4	193	FV-100/200/300/400	193
POCKET DV Z300HD-V	203	CR-30A, CV-T60/65/70	100C	FV500	204
TZA	203	D30, D60	193	FVM1/10	193
V5V	203	DC10/20/22/40/50/51/100	279	FVM20/30/100/100KIT/200	204
V5VP	203	DC210/220/230	279	G1, G2, G3, G4, G5, G6	193*
Z5X5P	203	DC310/320/330	204	G10Hi/G15Hi/G20Hi	161
<b>Battery to Empire Battery #</b>		DC410/420	338	G30Hi/G35Hi/G45Hi	161
DZO-V58N	203	DIGITAL	357	G1000/G1500/G2000	161
FNP120	228	DIGITAL 50/40	256	GL1,	161
NP60	203	DIGITAL REBEL XT/Xti	204	GL2	436
<b>ANTON/BAUER</b>		DM-MV30/100X/100Xi	193	H-440/460/480/520	118
DIONIC 90/160	292	DM-MV400/430/450	193	H-640/660/680/800/850	118
<b>AIWA</b>		E-06/07/08/09/20/30/40/50/51	118	H18 A1	132
<b>Model to Empire Battery #</b>		E-53/5760/61/63/65/66/67	118	HG-10	204
CV-50/60/80, VF-80	103	E-70/77/80/90/210/230/250	118	HR-10	279
<b>Battery to Empire Battery #</b>		E-350/440/460/520	118	HV-10	280
NP-22	103	E-640/660/700/708/800/808	118	HV-20/30	204
<b>AKAI</b>		ELURA	169	IXUS-85IS	348
<b>Model to Empire Battery #</b>		ELURA 2, 2MC, 10, 20MC	199	IXUSi, IXUS II	233
PVC-4/8/8S/100E	110	ELURA 40MC,50,60,65,70	204	IXUS-30/40	256
<b>Battery to Empire Battery #</b>		ELURA 80, 85, 90	204	IXUS-200a/300a/320	198
BPN100/800	110	ELURA 100	279	IXUS-300/330	194
<b>BAUER-BOSCH</b>		EOS-1D/1D Mark II/Mark II N	252	IXUS-400/430/500	198
<b>Model to Empire Battery #</b>		EOS-1D/1D Mark II	252	IXUS-700/750	233
VCC-306/506	104	EOS-1DS/1DS MARK III	347	IXUS-1100HS	398
VCC-326	107	EOS-1D MARK IV	347	IXUS i ZOOM/IXUS Wireless	256
VCC-400	112C	EOS-1V/1V HS/3	369	IXUS i5, IXUS IIs	233
VCC-516/526/550	100C	EOS-5D/10/10D/10Da/10Ds	193	IXUS-v/v2/v3/VII	198
VCC-606AF/610/616AF	110	EOS-5DMARK II/7D/MARKIII	357	IXY-DV3/DVM3/DV5	204
VCC-651	150	EOS-6D	357	IXY-DVM	193
VCC-656/660AF	110	EOS-20D/20DA/30D/300D	193	IXY-DVM5	280
VCC-806/816AH/826	107	EOS-40D/50D	193	J10/J100	118
VRP-30	100C	EOS-350D/Kiss Digital N	204	L1, L2	132
<b>Battery to Empire Battery #</b>		EOS-D30/D60	193*	LX-100	132
BA20	101C	EOS-1100D	415	MV3/3MC/3i/3iMC/4/4iMC	199
BA32-1	100C	EOS-D2000/D6000	358	MV5/MV5i/MV5iMC/MV6iMC	204
BA400	112C	EOS-Digital Rebel/Kiss Digital	193	MV20/MV20i/MV100	169
BA600/601	110	EOS-KISS X50	415	MV200/MV200i	161
BA800	107	EOS-REBEL 10D	193*	MV-30/MV30i/300/400/400i/430	193
		EOS-REBEL T11	350	MV-430i/430iMC/450/450i	193
				MV-500/500i/530/530i/550/550i	193

CANON (CONT'D)		CANON (CONT'D)		CANON (CONT'D)	
MV-600/600i/630i/650i	193	POWERSHOT SD1100IS	256	BP-80/85	161
MV-700/700i/730i/750i	193	POWERSHOT SD1300IS	348	BP-100	100C
MV-800/830/830i/850i/880X	204	POWERSHOT SD1400IS	256	BP-208/214	279
MVX1/MVX1i/MVX2i/MVX3i	193	POWERSHOT SD3500IS	348	BP-308/308B/308S/310/315	280
MVX4i	280*	POWERSHOT SD4500IS	398	BP-406/407/412/422	199
MVX10i	199	POWERSHOT SD980IS/1200IS	348	BP-508/511/511A/512	193
MVX20i/25i/30i/35i/40/45i	204	POWERSHOT SX30 IS	356	BP-514/522/535	193
MVX100i/150i/Li	193	POWERSHOT SX40HS/50	420	BP-608/617	169
MVX200/200i/250i/300/330i/350i	204	POWERSHOT SX200IS/210IS	297	BP-711/714/729/818	118
OPTURA	161*	POWERSHOT SX230HS	297	BP-807/808	376
OPTURA 10, 20	193	POWERSHOT SX500	348	BP-809/819/827	338
OPTURA 30, 40, 50, 60	204	POWERSHOT TX1	256	BP-911/914/915/924/927/930	161
OPTURA 50MC, 100MC, 200MC	193	PRO1, PRO90IS, PV130	193	BP-930G/941/945/950G/970G	161
OPTURA 300/300MC	199	SD790	297	BP-955	436
OPTURA 400, 500	204	SD 1000	256	BP-975	436
OPTURA 600	280	SD3500/4000IS	348	BP-E22	116
OPTURA D74b, PI, Xi	193	UC-1/10/20/8000/8500/9500	118	BP-E30A	101C
OPTURA PI MiniDV	193	UC-S1/S2/S3/S5	118	BP-E722/E77/E77K	118
OPTURA S1	279	UC-V20Hi/V200/V300/X2/X40Hi	161	BP-E708	116
PC1018	204	UC-X65Hi	118	BP-E711/E714/E729	118
POWERSHOT 520	194	ULTURA	161	BP-E718	132
POWERSHOT 4000IS	348	V40Hi/V50Hi/V60Hi/V65H	161	ES-410	161
POWERSHOT A5/A5 ZOOM/A50	194	V65Hi/V75Hi/V400/V420/V520	161	LP-E4	347
POWERSHOT A80	233	VC-1	118	LP-E5	350
POWERSHOT A2200/33000IS	378	VC-10/20/30/200	101C	LP-E6	357
POWERSHOT A2300/A2400IS	424	VCS-1/2/3/5	118	LP-E8	384
POWERSHOT A3000IS/31000IS	378	VCX-2	161	LP-E10	415
POWERSHOT A3400IS/4000IS	424	VHS PORT	101C	LP-E12	437
POWERSHOT D10	348	VISTURA	161*	NB-1L/1LH	198
POWERSHOT D350	194	VIXIA-HF10/11/20/21/100/200	338	NB-2JH/2L/2LH	204
POWERSHOT ELPH 100/300HS	256	VIXIA-HG10/HG20/HG21	338	NB-3L	233
POWERSHOT ELPH 110HS	424	VIXIA-HG10	376	NB-4L	256
POWERSHOT ELPH 31/310HS	256	VIXIA-HFM30/31/40/41/300/400	338	NB-5H	194
POWERSHOT ELPH 320HS	424	VIXIA-HF M32	376	NB-5L	297
POWERSHOT ELPH 500HS	348	VIXIA-HFR10/HFR11/HFR100	204	NB-6L	348
POWERSHOT ELPH 51/510HS	398	VIXIA-HFS10/HFS100	338	NB-6N	NYA
POWERSHOT ELPH 520HS	398	VIXIA-HFS11/20/21/30/200	338	NB-7L	356
POWERSHOT ELPH 530HS	398	VIXIA-HV30/40	204	NB-8L	378
POWERSHOT G1/G2/G3/G5/G6	193	VM-E2/2A/2N	116	NB-9L	398
POWERSHOT G7/G9	204	VME-70A	118	NB-10L	420
POWERSHOT G10/G11/G12	356	VR-10/20/20A/30A/40A/50A	101C	NB-11L	424
POWERSHOT G15	420	VT-LC50	118	NP-2	369
POWERSHOT PRO90/PRO90 IS	193	XA10	338	NP-E3	252
POWERSHOT S10/20	194	XF100/105/300/305	436	<b>CASIO</b>	
POWERSHOT S30/S40/S45	204	XHG1S	161	<b>Model to Empire Battery #</b>	
POWERSHOT S50/S60/S70	204	XHA1/XHA1S/ XHG1	436	EX-85	337
POWERSHOT D60/D80	204	XL1,XL1S,XLH1, XM1, XM2	161	EX-F1	349
POWERSHOT S90/95	348	XL2	436	EX-FC100/FC150	251
POWERSHOT S100/110/200/230	198	XLH1S/XLH15/XLH1-S/A	161	EX-FH100	374
POWERSHOT S230/300/330/400	198	XTI	204	EX-FS10	337
POWERSHOT S410/430/500	198	ZR	169*	EX-G1/EX-H5	365
POWERSHOT SD10/20/100	233	ZR-10/20/20MC/25/25MC	193	EX-H10/H15/H20G	374
POWERSHOT SD30/SD40	256	ZR-30/30MC/40/45MC/50MC	193	EX-H30	414
POWERSHOT SD200/SD300	256	ZR-60/65MC/70MC	193	EX-M1/M2/M20/M20U	216
POWERSHOT SD400/430/450	256	ZR-80/85/85MC/90/90MC	193	EX-P505/P600/P700	251
POWERSHOT SD500/SD550	233	ZR-100/200/300/400/500/600	204	EX-S1/S1PM/S2/S2BU/S2PW	216
POWERSHOT SD600/SD630	256	ZR-700/800/830/850/960	204	EX-S3/S20/S20U/S100	216
POWERSHOT SD750/750S	256	ZR-900*/930*/950*	204	EX-S5/S6/S7/S8	365
POWERSHOT SD780IS/850	256			EX-S10/S12	337
POWERSHOT SD940IS/960IS	256			EX-S100WE/S500/S500EO	216
POWERSHOT SD1000	256			EX-S200	397
POWERSHOT SD700IS/800IS	297			EX-S500GY/S500WE	216
POWERSHOT SD770IS	348			EX-S600/S600BE/S600EO	216
POWERSHOT SD790IS	297	<b>Battery to Empire Battery #</b>		EX-S600GD/S600SR/S770	216
POWERSHOT SD850IS/870IS	297	BP-2L5/2L12/2L14/2L18/2LH	204	EX-S770BE/RD/SR/S880	216
POWERSHOT SD880IS/890IS	297	BP-2L13	204	EX-V8SR	316
POWERSHOT SD880IS/890IS	297	BP-2L24H	204	EX-Z1/Z16/Z19/Z35/Z270	365
POWERSHOT SD900/950IS	297	BP-10/10A	101C	EX-Z3	203
POWERSHOT SD970IS/990IS	297	BP-30/30A31/32	100C		

\*Indicates Internal Fit

NLA: No Longer Available

NYA: Not Yet Available

NR: No Replacement

**EMPIRE VIDEO/DIGITAL CROSS-REFERENCE**

CASIO (CONT'D)	
EX-Z4/Z4U/Z4V	216
EX-Z9/Z29/80/85/90	337
EX-Z33	272
EX-	251
Z30/Z40/Z50/Z55/Z57	216
EX-Z60/Z70/Z75 SERIES	216
EX-Z77BK/Z77RD	353
EX-Z280	365
EX-Z100/200/300	251
EX-Z550/Z800	365
EX-Z450/500/600/700/750/850	251
EX-Z1000/1050/1080/1200	251
EX-Z2000/Z2300	383
EX-ZR10	383
EX-ZR100	414
EX-ZS5	365
EX-ZS10	397
EXILIM EX-S10/EX-Z80	337
EXILIM V7	316
FINEPIX 402	251
QV-3EX PLUS	216
QV-R3/R4, RR-10	203
TRYX BLACK / TRYX WHITE	414
VF-3000	104
<b>Battery to Empire Battery #</b>	
NP-20/20DBA	216
NP-30	203
NP-40/40DBA/40DCA	251
NP-50	316
NP-60	337
NP-70	353
NP-82/92	272
NP-80	365
NP-90	374
NP-100	349
NP-110	383
NP-120	397
NP-130	414
<b>CHINON</b>	
<b>Model to Empire Battery #</b>	
C8, C8-1003, C8-C60	107
C8-SC70/SC80/SC90	107
C8-SC96/SC98	150
C8-SL70	110
CV-765/770/C70/C800	100C
CV-C600	110
CV-T7/T60/T60G/T63/T65	100C
CV-T70/T72/T73/T80/T124	100C
CV-T84	130C
<b>Battery to Empire Battery #</b>	
BP-80	100C
C8-B33	107
C8-B36-1/B36-2	150
CV-BP80/BP82	100C
CV-BP89	130C
CVC-BP82	110
<b>CONCORD</b>	
<b>Model to Empire Battery #</b>	
DV2020	203
<b>Battery to Empire Battery #</b>	
LP37	203
<b>CONTAX</b>	
<b>Model to Empire Battery #</b>	
i4R	264
U4R, U4RB, U4RBK	276
<b>Battery to Empire Battery #</b>	
BP760S	264
BP1100S	276

CONTOUR	
<b>Model to Empire Battery #</b>	
CONTOUR GPS	433
CONTOUR HD	433
CONTOUR +	433
<b>Battery to Empire Battery #</b>	
CT-3650	433
<b>CURTIS MATHES</b>	
<b>Model to Empire Battery #</b>	
768, 770	100C
AV800	100C
AV850	110
BV880, CV800	100C
DV600	110
DV700	130C
DV800	100C
FV600	150
FV500/700/800	130C
FV900	150
GV700	130C
HV773	100C
MV800	112C
PV800, QD00004	100C
<b>Battery to Empire Battery #</b>	
14B655-001	101C
VSBS001	112C
VSBS0016	130C
<b>DAEWOO</b>	
<b>Model to Empire Battery #</b>	
DVM-131X, DVM-210N	109
DVM-239F	104
<b>DURACELL</b>	
<b>Battery to Empire Battery #</b>	
DR5	153-1.5C
DR7	164
DR8	143
DR9	158
DR10, DR11	159
DR12	118
<b>ELMO</b>	
<b>Model to Empire Battery #</b>	
ECR-8	107
ECR-600	112C
ER-10	100C
PRO.ECR-8S	107
<b>Battery to Empire Battery #</b>	
BP-10	100C
EA-BP8	107
EA-BP60	112C
PVBP80	100C
<b>EMERSON</b>	
<b>Model to Empire Battery #</b>	
70-2026	101C
V-CAM-14/18	110
VHS	100C
<b>Battery to Empire Battery #</b>	
1411200001	110
ERB-22/122	101
ERB-150/151	110
ERB-155	150
<b>EPSON</b>	
<b>Model to Empire Battery #</b>	
L-500V	266
<b>Battery to Empire Battery #</b>	
B32B818242	266
B31B173003CU	266
EPALB2	266
EU-94	266

FERGUSON	
<b>Model to Empire Battery #</b>	
C303/08	110
3V01/ 3V41/ 3V50	110
FC15/FC23/FC27/FC28	110
<b>Battery to Empire Battery #</b>	
VA282/283293/310	110
VA314/315/337	110
<b>FISHER</b>	
<b>Model to Empire Battery #</b>	
DMX-C1	244
FVC-10/10A	109
FVC-701/720/730/750/770/800	109
FVC-801	103
FVC-860/880/901/950/990	109
FVC-1000/2000/4000	109
FVC-P701/730/750/770	109
FVC-P880/P901/950/990	109
FVC-S2	109
FVP-201/501/503/803	103
<b>Battery to Empire Battery #</b>	
DB-L20, SL20	244
<b>FLIP</b>	
<b>Model to Empire Battery #</b>	
ULTRA/ULTRA HD	375
U1120B/U1120P	375
U1120W/U1120Y	375
<b>Battery to Empire Battery #</b>	
ABT1W	375
<b>FUJI</b>	
<b>Model to Empire Battery #</b>	
A-205/210/310	234
F60FD	329
F-60Y/120SW/122SW	109
F-401/601	203
F-402	222
F-440/450	255
F-610/615/620/810	109
FF-60/66, FH-80	109
FINEPIX 50i	203
FINEPIX 210FD	222
FINEPIX 480	329
FINEPIX 601	203
FINEPIX 1700Z/2700/2900Z	183
FINEPIX 4800/4900/6800/6900	183
FINEPIX A205, A210, A310	234
FINEPIX F20/40FD/45FD	301
FINEPIX F30, F31fd	299
FINEPIX F401Z/F410/F601/601Z	203
FINEPIX F70EXR/F75EXR	329
FINEPIX F80EXR/F85EXR	329
FINEPIX 50FD/60FD/F250FD	329
FINEPIX F100FD/F200EXR	329
FINEPIX F300EXR/305EXR	329
FINEPIX F420	249
FINEPIX F455/460/ 480	222
FINEPIX F500EXR/505EXR/550EX	329
FINEPIX F600EXR/F605EXR	329
FINEPIX F650/700/710/811	222
FINEPIX F660EXR/F665EXR	329
FINEPIX F750EXR/F770EXR	329
FINEPIX F775EXR/F800EXR	329

\*Indicates Internal Fit  
 NLA: No Longer Available  
 NYA: Not Yet Available  
 NR: No Replacement

**EMPIRE VIDEO/DIGITAL CROSS-REFERENCE**

FUJI (CONT'D)		GATEWAY		G.E. (CONT'D)	
FINEPIX J10/15/20/26/27/30/35	331	<b>Model to Empire Battery #</b>		AV-8MM	109
FINEPIX J50	222	DC-T50	203	D016	272
FINEPIX J100/110W/120/150W	331	<b>Battery to Empire Battery #</b>		DS-	272
FINEPIX J250/550/580/590	331	024-91001-10	203	5370	272
FINEPIX J700/710	331			GB-20	326
FINEPIX JV100/105/150/200	331			GB-40	325
FINEPIX JV205/250/255	331			GB-50	339
FINEPIX JX200/205/250/280/300	331			GB-90	152
FINEPIX JX305/350/355/400/405	331			SV-LB5	152
FINEPIX JZ100/110/250/260	331			<b>GOLDSTAR</b>	
FINEPIX JZ300/305/500/505	331			<b>Model to Empire Battery #</b>	
FINEPIX JX370/375/420/500/520	331	1CVD4020/4021	101	GS-8AF	103
FINEPIX JX580/590	331	1CVD5021/5021X/5023	100C	GS-E2/GS-HE1	109
FINEPIX REAL 3D W1	299	1CVD5025B/5025X	100C	GS-LT1	NLA (02/10)
FINEPIX REAL 3D W3	329	1CVD5027/5028B/5040	100C	GS-V1M	104
FINEPIX S5	317	1CVM6060E	112C	GS-V21M	NLA (02/10)
FINEPIX S100FS/200EXR/205EX	342	1CVM8080	100C	GVC-A425/C425/D425	NLA (02/10)
FINEPIX T200/205/300/305/350	331	1CVP4020X/4022/4022X	101	GVC-D475/E475/F475	NLA (02/10)
FINEPIX T360/400	331	1CVP4024/4024X	101	GVC-F477	NLA (02/10)
FINEPIX V10	222	1CVP5021/5022B/5022X	100C	LC-E76M (REAR)	109
FINEPIX X100	299	1CVP5024/5026X/5027	100C	VM-BP3M	NLA (02/10)
FINEPIX XP10/11/20/22/30/50	331	1CVP5028B/5030	100C	<b>Battery to Empire Battery #</b>	
FINEPIX XP100/150/170	329	1CVP6022/6024/6026/6028	100C	243-696T	NLA (02/10)
FINEPIX Z1/2/3/5FD	222	1CVP6030	100C	243-949A	NLA (02/10)
FINEPIX Z10FD/20FD/30/31	331	5036, 5200, 5424, 5426, 5428	100C	534-014EE	NLA (02/10)
FINEPIX Z35/37/33WP/70/80/81	331	9-9605/9606	100C	GS-E2	109
FINEPIX Z71/700EXR/707EXR	331	9-9607/9608/9609/9610	100C	VM-BP2M	104
FINEPIX Z110/115	331	9-9705/9709/9710/9711	110	VM-BP4M/6M	NLA (02/10)
FINEPIX Z100FD/200FD	331	9-9712/9715/9719	110	<b>GO PRO</b>	
FINEPIX Z800EXR/808EXR	331	9-9805/9806/9807/9808	100C	<b>Model to Empire Battery #</b>	
FINEPIX Z90/91/900EXR/950EXR	331	9-9810/9815	100C	HD HERO	385
FINEPIX Z1000EXR/1010EXR	331	CG-400	109	HD HERO2	385
H-80/128SW	109	CG-501/504/505/506/515	150	<b>Battery to Empire Battery #</b>	
HS30EXR/33EXR	425	CG-650/670/671/680/681	130C	AHDBT-001	385
J-100/100W/120W/150W	331	CG-683/703	152	AHDBT-002	385
M-6AF	103	CG-684/686	130C	<b>GRAETZ</b>	
M-600AF/680/690/830HR/890	109	CG-690/691/695/696/697/698	150	<b>Model to Empire Battery #</b>	
MX-500/600/600Z/700	174	CG-700/701	100C	SK-60	109
MX-1700/1700Z/2700/2900	183	CG-706/708/732/733/735	142S	<b>GRAETZ (CONT'D)</b>	
MX-2900Z/4900/4900/6800/6900	183	CG-800/805	150	TMC-93, TMC-4877	110
P-90/100/300AF/600AF	103	CG-812/814/818	109	TMC-4888	109
P-40U/650/660/850	109	CG-895	130C	<b>Battery to Empire Battery #</b>	
S-6500fd	301	CG-911/9805/9806/9807	100C	<b>GRUNDIG</b>	
X10/XF1	329	CG-9808/9809/9810	100C	<b>Model to Empire Battery #</b>	
X-E1	425	CG-9906/9907/9908/9910/9911	130C	VS-150AF	104
X-PRO1	425	CG-9915/9920	100C	VS-160/170/180	100C
Z-30/30WP/200FD	331	E840	326	VS-8000/8100/8320/8500/8800	109
Z-600AF	103	E850, E1030, E1040, E1240	325	VS-C05/20/30/40/45/50	110
<b>Battery to Empire Battery #</b>		E1035/1050/1235/1250TW	325	VS-C55	109
NH-10	234	E1055W/E1255W/E1276W	272	VS-C60/70/80/85	110
NH-20	249	E1410SW/E1450W	272	VS-C75	109
NP-30	255	E1480W/E1486TW/E1680W	272	VS4-8	109
NP-40, NP-40N	222	G1/G1SL/G2	326	<b>Battery to Empire Battery #</b>	
NP-45/45A/45B	331	G3WP/G5WP	272	BP-60	110
NP-50	329	G100	339	BP-70	109
NP-55	109	H855/H1055	325	BP-80	110
NP-60	203	J1050/J1250/J1455/J1456W	272	BP-82	109
NP-70	301	J1455/J1456W	272	BP-122	100C
NP-77H	109	J1470S	339	BP-150/151	104
NP-80	183	PJ1	339	<b>HEWLETT PACKARD</b>	
NP-95	299	<b>Battery to Empire Battery #</b>		<b>Model to Empire Battery #</b>	
NP-100	174	1CVA115	101C	BMW-F1	203
NP-120	228	1CVA125	100C	C8872	208
NP-140	342	1CVA135	112C	HP-R725/R727/R927	203
NP-150	317	1CVA145	110	PHOTO SMART C912	208
NP-W126	425	1CVA150	110	R607/707v/717/725/827/847	203
VM-BPL30A	166	1CVA155	100C	R937/967	203
VMBPL60A	166	1CVA156	130C	R742	222
		1CVA157C/158C	150		
		1CVA190	146		
		AV-608	109		

\*Indicates Internal Fit

NLA: No Longer Available

NYA: Not Yet Available

NR: No Replacement

**EMPIRE VIDEO/DIGITAL CROSS-REFERENCE**

HEWLETT PACKARD (CONT'D)		HITACHI (CONT'D)		IDX	
<b>Battery to Empire Battery #</b>		VM-D865/D865LA	166	<b>Model to Empire Battery #</b>	
A920	208	VM-D873LA/D875LA	166	DXC-3A/3000/M22	114
A1812A, L1812A	203	VM-D965/D965LA/D975LA	166	KV-5300	114
LI-40	222	VME10A/10E	143	SL-2000	114
R07, R607, R707V, R717	203	VME15A/15E	143	ENDURA E-10/80/50	250
		VME22A/22E/23A/23E	143	ENDURA E10S/80S	250
<b>HITACHI</b>		VME25A/25E/44/52A/53A	143	<b>Battery to Empire Battery #</b>	
<b>Model to Empire Battery #</b>		VME54/54A/55A/56A/58A	143	NP-25N/L50/L50S	114
DZ-BD10HA/BD70A/HA	230	VME71A/81A/110A	143	<b>IKEGAMI</b>	
DZ-BD7HA	230	VME110/130A	143*	HC-400	250
DZ-BX35A/GX20MA	230	VME220A/220A/230A	143*	HL-45/57/59/59W	250
DZ-GX3100A/3200A/3300A	230	VME310	143*	HTM-1003	292
DZ-GX5020/GX5080A	230	VME310A	143	MR20SR	292
DZ-HS300A/HS500A	230	VME340A/340LA/350A	166	TM10/TM20SR/TM9-1	292
DZ-M580/M730/M780	230	VME368E/368LE	166	<b>INSIGNIA</b>	
DZ-MV100A/MV200/MV200A	172	VME410	143*	<b>Model to Empire Battery #</b>	
DZ-MV230/MV230A/MV270A	172	VME420	143	NS-DCC5HB09	203
DZ-MV270A	172	VME455LA/465LA	166	NS-DSC10SL	331
DZ-MV350A/380A/550A/730A	230	VME510A	143	NS-DV720P/DV1080P	203
HDC-831E/831ER	315	VME510/520A/521A	143*	NS-DV111080F	228
THIN-MAN	145	VME530A/535LA	166	<b>Battery to Empire Battery #</b>	
TWIST/SHOOT	145	VME540A/540LA/545LA	166	<b>ITT</b>	
VLH-100L	166	VME555LA	166	<b>Model to Empire Battery #</b>	
VM-H945LA/955LA	166	VME565/565LA	166	VMC-3639A/3865	110
VM30	106	VME620A/625LA	143	VMC-3875/3877	110
VM100/200A/500E/600E	104	VME635A/635LA/645LA	166	VMC-3875/3877	110
VM825LA	143*	VME710A	143	VMC-3877AF/3888	110
VM-645LA/835LA/945LA	166	VME755LA	166	VMC-6000	110
VM1200/1280E	104	VME835LA/855LA	166	<b>JC PENNEY</b>	
VM1300/1350/1350A/1400A	142S	VMH10/18A	143	<b>Model to Empire Battery #</b>	
VM1600A/1700A/1800A/1900A	142S	VMH35LA	166	686-5019/5042	101C
VM2000A/2100A	104	VMH38A/39A	143*	686-5110/5111/5115/5116	100C
VM2140	142S	VMH57A/59A	143	686-5330	112C
VM2250A/2270A	NLA (02/10)	VMH71A/81A	143*	686-5335/5350	100C
VM2300/VM2300A/VM2300E	142S	VMH100LA	153	686-5600	110
VM2380	NLA (02/10)	VMH620A	143*	686-6009	104
VM2400A	142S	VMH625	143	686-6009	104
VM2400E	143	VMH635A/640A/645LA	166	686-6015/6062	130C
VM2410CL/2500A/2580A/2580E	142S	VMH650/650A/665LA/675LA	166	686-6016	100C
VM2600A/2700A/2800A/2900A	142S	VMH710A/720A/725LA	143*	686-6093	152
VM3000A/3100A/3150/3150A	104	VMH725U	143	676-6204	109
VM3200E	110	VMH755LA/765LA	166	686-6228	NLA (02/10)
VM3200/3250A/3260/3270A	NLA (02/10)	VMH825LA	143*	686-6232	130C
VM3260A/3280E	110	VMH835LA/845LA/855LA	166	855-2879	152
VM3300A/3350/3350A	142S	VMH865LA/875LA	166	855-8314	115
VM3700/3700A/3800A	142S	VMH945LA/955LA/965LA/975L	166	866-8363	152
VM4400A/4400E	142S	VMS7200A/7200E/7280E	NLA (02/10)	855-8421	115
VM5000A/5100A	104	VMS8100A	104	855-8520/8959	130C
VM5200	NLA (02/10)	VMS8200A	142S	855-8967	100C
VM5300A/5350A	142S	VMSP1A	143	855-8975	104
VM5400A/5400C/5400U	142S	VTCL50EM	NLA (02/10)	855-9163	100C
VM5720A	NLA (02/10)	<b>Battery to Empire Battery #</b>		890-1886/1902/2454	130C
VM6000A/6100A	104	DZ-BP7S/BP14S/BP21S	230	890-1894	150
VM6300A/6500A	142S	DZ-BP16/BP28	172	890-2447	NLA (02/10)
VM7000A/7200A	104	VMBP6M	142S	890-2561	142S
VM7300/7300A/7400A/7400LA	142S	VMBP21/22	104	890-2579	150
VM7500A/7500LA	142S	VMBP51/52	106	932-0300	109
VM8200A/8300A	142S	VMBP61A/63/63A	NLA (02/10)	932-0318	118
VM8400LA/8500LA	142S	VMBP64/64AS	142S	932-0334	113
VMBP82G	143	VMBP65/66/67/67A	142S	932-1829	109
VMBP84	143	VMBP71	NLA	932-2017/2488	143
VMBP826	143*	(02/10)		932-2744	109
VMC1A/1E/1R/1S	145	VMBP81	145	932-2819	118
VMC2A	145	VMBP82/82A/83/84/84A	143	932-8378	113
VMC11A/VMC30A	106	VMBP502	166	<b>Battery to Empire Battery #</b>	
VMC34	NLA (02/10)	VM-BPL13/13A/13J	166	686-6023	130C
VMC40E	106	VM-BPL27/27A/30/30A/60A	166	686-6063	152
VMC50A/52/60	106	VME38A/39A/58A	143	688-2922	100C

\*Indicates Internal Fit

NLA: No Longer Available

NYA: Not Yet Available

NR: No Replacement

**EMPIRE VIDEO/DIGITAL CROSS-REFERENCE**



JC PENNEY (CONT'D)		JVC (CONT'D)		JVC (CONT'D)	
688-2925	101C	GR-AX920/920U/930U	150	GR-DVL355/355U/357	192
688-2942	112C	GR-AX940U/941U/957U	150	GR-DVL357U/400U/410/450	192
688-2948/2949	110	GR-AX970/970U/1010U	150	GR-DVL500U/505U/507U/510	192
855-3026	130C	GR-AXH1	150	GR-DVL510U/515/517/517U	192
855-8371	115	GR-AXM1U/2/2U/4/4U	150	GR-DVL520522/522U	192
855-8611	130C	GR-AXM10U/17U/17US	150	GR-DVL555/557/557U/600	192
890-2595	142S	GR-AXM20/20U/25U/27U	150	GR-DVL715/720/725/725U	192
934-0332	143	GR-AXM30U/40/40U/50U	150	GR-DVL800U/805U/815/815U	192
934-0340	118	GR-AXM70U/80U/100U	150	GR-DVL817/820/820U	192
934-0357	109	GR-AXM151/151U/210U/205	150	GR-DVL822/822U/910/915	192
NB-E60A	109	GR-AXM217U/220U/225U/226	150	GR-DVL915U/920/920U	192
SV-LB5	152	GR-AXM230U/231/237U/241	150	GR-DVL9000/9000U	162*
VMBP-61	NLA (02/10)	GR-AXM241U/270/300U/310U	150	GR-DVL9200U/9300/9300U/9500	170
<b>JVC</b>		GR-AXM317U/330U/341/341U	150	GR-DVL9600/9600U/9700/9800U	170
<b>Model to Empire Battery #</b>		GR-AXM405/510/510U	150	GR-DVM1	162
ADIXXION GC-XA1	341	GR-AXM511/511U	150	GR-DVM5/5U	170*
CU-VH1US	192	GR-AXM650/650U670	150	GR-DVM50U/55U/70U/75U	175
DDNP-100	174	GR-AXM700/700U/710U	150	GR-DVM76U/DVM96U	220
DR-X5	270	GR-AXM717U/750U/800	150	GR-DVM80U/90U	175
DY-70U/90WU	292	GR-AXM840U/841U/900U	150	GR-DVP1/3/3U/5/7U/9U/9US	202
EVERIO GZ-MG20US/21/27	270	GR-AXM910U/917U/920U	150	GR-DVP7/DVP9	192
EVERIO GZ-MG30US/35US/37	270	GR-AXM970U/1000U	150	GR-DVX	168
EVERIO GZ-MG40US/50US	270	GR-AXTEG	150	GR-DVX4	175
EVERIO GZ-MG70US/77/500	270	GR-C1U/2U/7/7U/9/11/11S/25	110	GR-DVX6K	200
GC-S5/S5E	174	GR-C7S	150	GR-DVX7/DVX8/DVX9/DVX10	175
GF-450/500U/700U	110	GR-C25U/30/30U/35U/40/40U	110	GR-DVX40/44/48/49	175
GF-S550U	110	GR-C55/55U/70U/75/250/707	110	GR-DVX70/DVX77/DVX78	175
GR-15U/25U/30U/35U	110	GR-D22US/27/30/30US/31	192	GR-DVX80/DVX88/DVX90	175
GR-40/40U/45	110	GR-D31US/32US/33/33US	192	GR-DVX307U	202
GR-60E	150	GR-D70/70US/71US/72/72US	192	GR-DVX400/DVX407/DVX408	220
GR-60U/65EG/65U/70U	110	GR-D73US/74US/90/90US/91	192	GR-DVX507/50/707/709	220
GR-303/303EG/303U/305U/505	110	GR-D91US/93/93US/94US	192	GR-DVXPROU/DVXU	168
GR-277U/323U	150	GR-D200/200US/230US	192	GR-DX75/77/95/97/300	202
GR-400/450/5550U/5505	110	GR-D240/250/250US/270	270	GR-DX307U	192
GR-A1E/1U/30/30E/30S/30U	110	GR-D270US/271/271US/275	270	GR-DZ7/DZ7U/7US	192
GR-A60S/60U	110	GR-D275US/290/290US/295US	270	GR-EX1/EZ1/HF805/LT7	150
GR-AK5BKU/5GYU	150	GR-D295/350/370/395/396/650	270	GR-FX10/11/12/16/23/30/33	150
GR-AW1/1U/10	150	GR-D347U	202	GR-FX36/40/43/50/53/60	150
GR-AX2/2U/5/5EG/5U/7EG/7U	150	GR-D720/728/740/740AC/746	309	GR-FX101/102/120/220/305	150
GR-AX10/10EG/10U	150	GR-D750/750AC/760/770/771	309	GR-FX401/405/505/601	150
GR-AX17/17U/25U/26/26U	150	GR-DV775/790/796/850/870	309	GR-FXM15/16/17/25/35/37	150
GR-AX30/30U/33/33U	150	GR-D875/DA30US	309	GR-FXM40/45/55/65/66/75	150
GR-AX34/34U/35/35U/37/37U	150	GR-DF420/430/430US/450	270	GR-FXM105/FXM106	150
GR-AX46/46U/47U/48U	150	GR-DF450US/470/470US/540	270	GR-FXM161/170/270/333/373	150
GR-AX50/50U/55/55U/65U	150	GR-DF550/550US/565/570	270	GR-FXM404/405/555/605	150
GR-AX70U/74/74U/75U	150	GR-DF570US	270	GR-HD1/HD1US	192
GR-AX76/77/77U	150	GR-DV1/1U/1W/2/7OE/14	160	GR-HD3/5/6/10/40/300/320	309
GR-AX81U/84/84U/90U/91	150	GR-DV3/3U	170*	GR-HF705U/805U	150
GR-AX94/94U/96/96U/97/97U	150	GR-DV500/500US/800/800US	192	GR-HM1SUS/HM200/HM400	309
GR-AX200U/201U/202/202U	150	GR-DV510U	150	GR-M3/M3U/M5/M5U	150
GR-AX210/210U/220/220U	150	GR-DV1800/2000/2000US	192	GR-M7/7PRO/7U/M44	150
GR-AX230U/250	150	GR-DV3000U/4000/4000US	192	GR-S3V/S7/S7U/S27/29	150
GR-AX300U/301/310U/323U	150	GR-DVA1/1U	150	GR-S35/55/55U/70EG/70U	110
GR-AX350U	150*	GR-DVAXU	168	GR-S75/75U/77E/77	110
GR-AX400U/401/401U/404U	150	GR-DVF3A/10/10U/20/20U	150	GR-S99/99EG/99EU	110
GR-AX410U/420U/430U	150	GR-DVF11/11U/21/21U	182	GR-S500U/505EG/505U/550U	110
GR-AX500U/501/510U	150	GR-DVF31/DVF31U	182	GR-S707/E/EG/EU/U	110
GR-AX606U/610/610U	150	GR-DVJ70/70E	160	GR-SK20/SV3/SV7U	150
GR-AX640U/650/655/655U	150	GR-DVL20/25U/30/45U	182	GR-SX9U/SX90/20/21/22	150
GR-AX657U/660U/700U/704U	150	GR-DVL100U/DVL105U	192	GR-SX26/41/51/52/56	150
GR-AX710U/717UM/720/720U	150	GR-DVL107U/DVL108U	192	GR-SX202/210/750U/760U	150
GR-AX730U/750U/754U/760U	150	GR-DVL109U/120/150/150U	192	GR-SX850U/851U/860/860U	150
GR-AX761/761U/767U/777	150	GR-DVL157/200/210/210U	192	GR-SX867U/877/950U/960U	150
GR-AX800U/808U/810/810U	150	GR-DVL200/220U/257/257U	192	GR-SXM25/26/27/37/37US	150
GR-AX820U/820US/830US	150	GR-DVL300U/305/305U	192	GR-SXM46/47/50/55/57	150
GR-AX840U/841U/844U/857U	150	GR-DVL307/307U/308/309U	192	GR-SXM61/62/71/72/75/76/77	150
GR-AX880US/890U/890US	150	GR-DVL310/310U/315/315U	192	GR-SXM81/82/86/91/92	150
GR-AX900U/910/910U/911U	150	GR-DVL317/317U/320/320U	192	GR-SXM230U/235/235U	150

\*Indicates Internal Fit

NLA: No Longer Available

NYA: Not Yet Available

NR: No Replacement

**EMPIRE VIDEO/DIGITAL CROSS-REFERENCE**



KYOCERA (CONT'D)		MAGNAVOX (CONT'D)		METZ	
KD-S820	113	CVL335/345/610/611/612/620	150	<b>Model to Empire Battery #</b>	
KD-S5530/S5550	109	CVL810, CVM310/315	130C	9622, 9624, 9625	110
KX-1/70/70E/77/77CV/77U	109	CVM320/325/610/620/630	150	9628, 9629	107
KX-90/90E/H1/H1U	109	CVM710/720, CVN310AV	130C	9637, 9702	150
KX-V10	153C	CVN610/620/630/630AV	150	<b>MGA</b>	
MD-MS200	191	CVN715	151	<b>Model to Empire Battery #</b>	
SAMURAI 2100DG	191	CVR315AV	NLA (02/10)	HSC20	110
SL-300R/300RT/400R	245	CVR325AV/330AV/335AV	130C	<b>MINOLTA</b>	
U4R, U4RB, U4RBK	276	CVR630	150	<b>Model to Empire Battery #</b>	
<b>Battery to Empire Battery #</b>		CVS315AV/325AV	NLA (02/10)	8-80/81	113
BAP-100	103	CVS620	150	8-308/308E/378/406/406E	143
BP-150/170	109	CVT325/330/340AV	NLA (02/10)	8-418/428/438/761/761C	143
BP-760S	264	CVT620/630/640	150	8-762CS/778/838/842/848	143
BP-780S	245	VR8207GY01	112C	8-808/808E/812/832	113
BP-800S/880S/900S/1000S	207	VR8208AV01/8245BK01	100C	8-852/862/863S/864S	143*
BP-1100R	183	VR8285, VR8285AV01	110	8-878/912/918	143
BP-1100S	276	VR8290GY01	112C	8-8000/8100/8200	143
BP-1501/1502/1550	109	VR8292/8293/8294/8294AF	100C	a Sweet Digital/ a-7 Digital	238
BP-1600R	191	VR8295/8357/9297	110	C-1E	128
BP-F550	153-1.5	VR8380/8382/8400/8450/8451	100C	C-50/51	110
BP-F750	153-3	VR8453/8454/8455/8456/8457	100C	C-503/512/513/516/518/522	150
<b>LEICA</b>		VR8356/8462/8470/8481	101C	C-532/538/542/550/552/560	150
<b>Model to Empire Battery #</b>		VR8471/8472/8474/8475/8480	100C	C-560C/561/562CL/563CLS	150
C-LUX2/LUX3	319	VR8484/8485/8486/8570/8572	100C	C-570/606/606E/618	150
D-LUX	226	VR8585/8590/8592/9143	100C	CR-80AF/81AF	NLA (02/10)
D-LUX2	404	VR9240AV/9244/9246	100C	CR-800S/880	113
D-LUX3/LUX4	301	VR9254/9256AV/9260	110	CR-1000A	110
D-LUX5/LUX6	403	VR9297/9656	110	CR-1000S/1100S/1200S	104
DIGILUX 1, 2	218	<b>Battery to Empire Battery #</b>		CR-8000AF/8000S	113
DIGILUX ZOOM	183	AR8378BK01	100C	CR-8100/8100AF/8200	113
M7/8/8.2/9/9-P/MP	312	AR8395BK01	101C	DG-5W	201
M-E	312	V80039BK01/V80086BK01	100C	DG-X50K/X50R/X50S	259
V-LUX1	283	V80063BK01	112C	DIMAGE A1, A2	238
V-LUX20/VLUX30/VLUX40	368	V80076BK01/80085BK01	110	DIMAGE A200	201
X1	399	V80096BK01	130C	DIMAGE E40, E50	269
<b>Battery to Empire Battery #</b>		V80115BK01/80116BK01	150	DIMAGE G400/500/530/600	243
14464	312	V80139BK01	151	DIMAGE X, Xg, Xi, Xt, Xt BIZ	217
BP-DC1	218	V80146BK01/80149BK01	NLA (02/10)	DIMAGE X1	281
BP-DC2	226	VE550UE	101C	DIMAGE X50	259
BP-DC4	301	VSBS0011	100C	DYNAX 5D/7D	238
BP-DC5	283	VSBS0016	130C	KR-1000	104
BP-DC6U	319	<b>MARANTZ</b>		Maxxum 5D/7D	238
BP-DC7-E	368	<b>Model to Empire Battery #</b>		MS-2100	104
BP-DC7-U	368	CV-B800	100C	REVIO	243
BP-DC8	399	<b>MEMOREX</b>		V-10/10R/11/11R	NLA (02/10)
BP-DC9	404	<b>Model to Empire Battery #</b>		V-16/16R/18/18R/20/20R	142S
BP-DC10	403	16-827/828	146	V-118/218/228	142S
BP-DP20	312	16-858/859	109	V-700	101C
NP80	183	CRD-0050	150	V-1400/2000/2100	104
NP-100	174	MODEL 103	142S	<b>Battery to Empire Battery #</b>	
<b>LOEW OPTA</b>		MODEL 127, 128	146	B-8002	113
<b>Model to Empire Battery #</b>		MODEL 153, 154, 158	109	BP-800	113
CC90	104	MODEL 155	150	BP-1001/1002	104
PROF1800/1810/1820	113	MODEL 157	143	BP-3001	110
<b>MAGNAVOX</b>		MODEL 16837	130C	BP-3301	128
<b>Model to Empire Battery #</b>		SM1000	104	BP-8001/8002	113
8290	112C	SM2000	106	BP-M3001	110
8292, 8293, 8380	100C	SM4200/4300/4400	130C	NP-1	281
8400, 8450, 8451, 8474, 8900	101C	SM8400	150	NP-200	217
CK300	101C	<b>Battery to Empire Battery #</b>		NP-400	238
CV5320AV	100C	BP-30RS	130C	NP-500/600	243
CVJ310/312/320/322/340/350	100C	BT-30RS	146	NP-700	259
CBK300/K310/K315/K320	130C	BT-70	109	NP-800	201
CVJ360	130C	CS6012	109	NP-900	269
CVK321/332/342/352	100C	OB-15	150	VBC-166	142S
CVK300/610	130C	T16-BP64	142S	VBP-100/101	NLA (02/10)
CVL300/301/310/318/319/320	130C	VM-BP21M	104	VBP-160/161/165/166	142S
CVL325	100C	VSBW0003	150		

\*Indicates Internal Fit

NLA: No Longer Available

NYA: Not Yet Available

NR: No Replacement

**EMPIRE VIDEO/DIGITAL CROSS-REFERENCE**



MINOLTA (CONT'D)		NIKON (CONT'D)		NIKON (CONT'D)	
VBP-400/401/410	143	COOLPIX S50/50C/51/51C/52	275	EN-EL19	413
VBP-500/501	110	COOLPIX S60/S70/S80/S200	320	EN-EL20	422
VBP-600/601/630	150	COOLPIX S100	413	EN-4	212
VBP-912	143	COOLPIX S202/210/220/230	320	LRHM3WM	201
02491-0015-00	269	COOLPIX S500/510/520/570	320	NP-55/66H/77/77H	109
<b>MINOX</b>		COOLPIX S550/560/710	345	NP-500	153-1.5C
<b>Model to Empire Battery #</b>		COOLPIX S600/700/3000/4000	320	<b>NORCENT</b>	
DC1022 / DC8111	315	COOLPIX S70/610/620/630/640	354	<b>Model to Empire Battery #</b>	
DC52222	269	COOLPIX S800C	354	DC420/S760/S860/S1050	269
DMP3 / DMP 4	269	COOLPIX S1000PJ/1100PJ	354	<b>NORMANDE</b>	
<b>MITSUBISHI</b>		COOLPIX S2500/2550/3100	413	<b>Model to Empire Battery #</b>	
<b>Model to Empire Battery #</b>		COOLPIX S3300/4300	413	CV100/155/301/1100	110
CVK-G99	110	COOLPIX S4100	413	CV2001/2101/2201	110
HS-C1XE	150	COOLPIX S5100	320	RP300, SV500	110
HS-C4U/C7U/CX1/CX4	150	COOLPIX S1200/4150	354	<b>Battery to Empire Battery #</b>	
HS-C20U, HS-C30U	110	COOLPIX S6000/6100/6150	354	AC-155/2005	110
HS-C45/50	110	COOLPIX S6300/6200	354	<b>OLYMPUS</b>	
HS-VX4E	150	COOLPIX S1200PJ/8000/8100	354	<b>Model to Empire Battery #</b>	
HS-F10UR	104	COOLPIX S8200/9100/9300	354	AZ-1, AZ-2	203
<b>Battery to Empire Battery #</b>		COOLPIX SO1	345	C-50/50Z/60Z/70Z	224
BY-B99/C101/C102	110	COOLPIX SQ	210	C-470/507/590Z	224
BY-F101/F102	104	COOLPIX SX610, SX610C, S71	354	C-630	272
BY-U1/U2	150	D1, D1H, D1X	212	C-760UZ/765UZ/770M/770UZ	224
<b>MUSTEK</b>		D2H, D2HS, D2X, D2Z	242	C-5000/5000Z/5050	224
<b>Model to Empire Battery #</b>		D3/3X/3S	242	C-5060/5060Z/5060WZ	240
DV-2032/3032/3500	NMH-2/AA	D4	435	C-7000/7000Z	224
DV-4000	248	D40/D40X/D60/D3000/D5000	304	C-7070/7070WZ/8080/8080WZ	240
DV-5000	NMH-2/AA	D50/70/70S/100/100SL	211	D-630	272
<b>Battery to Empire Battery #</b>		D80/90/200/300/300S/700	293	DS-2300/3300 voice recorders	381
DV3M	248	D600/800/7000	406	DS-4000/5000ID voice recorders	381
<b>NEC</b>		D2100/2200/3100/3200/5100	401	DS-5000 voice recorders	381
<b>Model to Empire Battery #</b>		F6	242	E3/5/30	407
CV-10U	112C	NIKON 1 J1 / NIKON 1 J2	422	E-1/3/30/300/330/500/510/520	240
CV-30U/40U	100C	NIKON 1 V1	406	E400/410/420/450/600/620	306
CVB-70U	110	P5000/6000	239	E-P1/P2/PL1/PL2/P3/PL3/PM1	306
EM-ABU	103	S60/5100	320	E-PL5/PM2	409
NCVK400	110	S560	345	FE-20/190/230/240/250/280	272
V-20U/40U	100C	S1100PJ/S1200PJ	354	FE-200	224
V-50U (REAR)	112C	S6150/6200/8200	354	FE-290/300/320/340/350	272
V-300/400	100C	VHS SPORT	101C	FE-360/370	355
VM10U	112C	VN-300/310/330/340/360	109	FE-3000/3010/4000/4010/4030	272
VM40U	100C	VN-400/500/550/700/750	109	FE-4020/4040	389
VMA80	103	VN-720/730	153-1.5C	FE-5000/5010/5020/5500	272
<b>Battery to Empire Battery #</b>		VN-800/801/810	107	IR-300	272
BC-10	112C	VN-820/830/840/850/860/870	109	IR-500	224
VB-10U	112C	VN-900/910/960	109	MJU-700	272
VB-30U/50U	100C	VN-3000	101C	MJU-MINI DIGITAL/DIGITAL S	257
<b>NIKON</b>		VN-7000/8200/9000/9100/9500	109	OM-DE-M5	438
<b>Model to Empire Battery #</b>		VS-BL71	156	SP-500UZ	224
1 J1/J2	422	<b>Battery to Empire Battery #</b>		SP-700	272
ACTION PRO	107	BP-80	107	SP-800UZ/810UZ	339
COOLPIX AW100/AW100S	354	BP-300	101C	STYLUS 300/400/410/500/600	224
COOLPIX 775/880/885/995	201	EN-EL1	201	STYLUS 550WP/7000/7010	272
COOLPIX 2500/3500	210	EN-EL2 / BP-NKL2 / 9904	210	STYLUS 700/710/720/730/740	272
COOLPIX 3700/4200	239	EN-EL3/EL3a	211	STYLUS 750/760/770SW/780	272
COOLPIX 4300/4500/4800/5000	201	EN-EL3E	293	STYLUS 790SW/820/830	272
COOLPIX 5200/5900/7900	239	EN-EL4/EN-EL4A	242	STYLUS 800/810/1000	224
COOLPIX 5400/5700/8700	201	EN-EL5	239	STYLUS 1010/1020/1030	339
COOLPIX 8400	NYA	EN-EL7	NYA	STYLUS 840/850/1040/1200	272
COOLPIX 8800	NYA	EN-EL8	275	STYLUS 1050SW/7000/7010	272
COOLPIX P1/P2	275	EN-EL9/EN-EL9A	304	STYLUS 5010/7030/7040	272
COOLPIX P3/4/50/80/90/100	239	EN-EL10	320	STYLUS 9000	339
COOLPIX P500/510	239	EN-EL11	345	STYLUS TOUGH 3000	272
COOLPIX P300/310	354	EN-EL12	354	STYLUS TOUGH 6000/6020	339
COOLPIX P5100/6000	239	EN-EL14	401	STYLUS TOUGH 8000/8010	339
COOLPIX P7000/7100/7700	401	EN-EL15	406	STYLUS VERVE/S	257
COOLPIX S1/2/3/5/6/7C/9	275	EN-EL18	435	STYLUS XZ-2	427
COOLPIX S10	239			SZ-10/SZ11/SZ12/SZ20	339

\*Indicates Internal Fit

NLA: No Longer Available

NYA: Not Yet Available

NR: No Replacement

**EMPIRE VIDEO/DIGITAL CROSS-REFERENCE**

OLYMPUS (CONT'D)		PANASONIC (CONT'D)		PANASONIC (CONT'I )	
SZ30MR/31MR	339	AG-DVC30/DVC80	262	HDC-SD40/60/80/90	400
T-100	269	AG-DVC200/DVX100	172	HDC-SD700/SX5	307
TG-1	427	AG-DVX100A/AE/AP/B	262	HDC-SD800/900	423-1.3
TG-310/320	272	AG-EZ1/EZ20/EZ30	162*	HDC-SDT750	331
TG-610/620IHS/810/820	339	AG-HMC40/50/70	393	HDC-SDX1	400
U-10D/15D/20D/25D/30D/40D	224	AG-HSC1	307	HDC-TM1/40/41	400
UD-400/410/500/600/800	224	AG-V50	100C	HDC-TM10/TM20/TM30/TM200	307
VC-103/106A	101C	AJ-D400/D410A/D700	250	HDC-TM55/80/90	400
VC-104/105/106	100C	AJ-SDC615/905	292	HDC-TM60	400-1.8
VG-110/120/140/160	389	AJ-SDX900/800/SPC700	292	HDC-TM300/TM350/TM700	307
VR-310/320/330	272	BTS-1000N/100Y/1050/950	292	HDC-TM900	423-1.3
VR-340/350	339	DMC-3D/3D1	368	HDC-TMX1	400
VX-43/54/81/82/82E	109	DMC-F1/F1S	226	HM-TA1H/TA1R/TA1V	319
VX-401/402 (REAR)	112C	DMC-F7	219	HX-DC1/DC10	363
VX-403	110	DMC-F3/FH1/FH3/FH20/FH22	367	HX-WA2	339
VX-402/404/405/S405/406	100C	DMC-FH2/FH5/FH24/FH25/FH2	418	HX-WA10	363
VX-407	130C	DMC-FH6/FH8	418	IQ-PBA306	150
VX-801/802/802E/803/804	107	DMC-FH20/FH30/FH33	367	M-810	150
VX-806	109	DMC-FP1/FP2/FP8	367	M-3000	130C
VX-H804	107	DMC-FP5/FP7	418	MC-50	110
WPP-1000/1500/5000	107	DMC-FP3	391	NV61/61E/62/62E/63	150
X-1/2/3/450/500	224	DMC-FS2/FS4/FS6/FS7/FS8	367	NV-100	101C
X-560WP/600/825/960	272	DMC-FS3/FS5/FS20	319	NV-180	100C
X-940	389	DMC-FS10/12/15/25/42/62	367	NV-500/595	150
XZ-1	339	DMC-FS16/18/35/37	418	NV-6500/6600/8420	101C
<b>Battery to Empire Battery #</b>		DMC-FT1/FT2	367	NV-A1EN	155
BLM-5	407	DMC-FT10	391	NV-C1	172
BLN-1	438	DMC-FX01/07/3/8/9/12	284	NV-CS1EN	155
BLS-5	409	DMC-FX2/FX7	260	NV-DA1/DA1EN	172
BR403	381	DMC-FX30/33/35/37K	319	NV-DE3	162
Li10B, Li12B	224	DMC-FX40/48/66/75/700	367	NV-DJ1/DJ100/DS1/DS5	162
Li20B	203	DMC-FX77/78/90	418	NV-DS77/DS77EN	172
Li30B	257	DMC-FX50/55/100/150/500	319	NV-DX1/DX100	162
Li40B/Li42B	272	DMC-FX500/550/580/FZ35	367	NV-EX1/EX1EN	172
Li50B	339	DMC-FZ1/FZ7	225	NV-G1/G1E/G2/G2E/G3/G3E	150
Li60B	355	DMC-FZ8/10/FZ/18/FX20/FZ28	283	NV-G100/200/202/300/303	150
Li70B	389	DMC-FZ30/FZ35/FZ38/FZ50	283	NV-GS11/15	396
Li80B	269	DMC-FZ40/45/47/48/100/Z00	404	NV-GS50/GS70	230
Li90B	427	DMC-FZ60/FZ150	404	NV-GS90/GS98/GS328	307
NP-55/77H	109	DMC-G1/G2/G1K/GF1/GH1/G1	361	NV-M5/M7/M7EO/M7EW	100C
PS-BLM1	240	DMC-GH1K/GH1WW	361	NV-M7EG	110
PS-BLS1	306	DMC-L1/LC5/LC40	218	NV-M8PX/M9/M10	100C
VFBA5U	112C	DMC-L10	307	NV-M10K/M30/M33K/M33PX	110
VFBP1	101C	DMC-LX1/LX2/LX3	284	NV-M20EG	150
VFBP3, VFBP3U	100C	DMC-LX5/LX7	403	NV-M50/55/70/90/350/550	110
VFBP6, VFBP6U	112C	DMC-S1/S2/S3	418	NV-M400	130C
VFBP7, VFBP7U	100C	DMC-SZ1/SZ5/SZ7	418	NV-M810EN	150
VFBP8U	130C	DMC-TS1/TS2/TS3/TS4/A1008	367	NV-M1000/M8000	100C
VFBP81	107	DMC-TS5/TS7	368	NV-MC5/MC5EG/MC6/MC6EG	110
<b>ORION</b>		DMC-TS10	391	NV-MC10EG/MC10EGF/MC20	110
<b>Model to Empire Battery #</b>		DMC-TS20	418	NV-MC30/MC30EG/MC70	110
C-MV1/MV11/MV103/MV203	110	DMC-TZ1/TZ3/TZ4/TZ5/TZ50	298	NV-MS1/MS2	100C
VC-M0300	150	DMC-TZ6/TZ7/TX8/TZ10/TZ65	368	NV-MS50/MS50EG/MS60/MS90	110
<b>Battery to Empire Battery #</b>		DMC-ZR1/ZR3/ZS1/ZS3/ZX3	368	NV-MS70/MS70E/MS95/MS95B	150
OD-18	150	DMC-ZS5/ZS7/ZS8/ZS10/ZS15	368	NV-MS95E/MS95EG	150
<b>PANASONIC</b>		DMC-ZS19/ZS20	368	NV-MS950/MS950EN	150
<b>Model to Empire Battery #</b>		DMX-FX580	367	NV-MV1	110
AFX3	100C	EB362	100C	NV-MV5	150
AFX8, AFX12	130C	HC-700	400	NV-MX350/500	396
AG-40U	110	HC-V10/100/100M/500/500M	400	NV-R50E/R60E/R200/R200PN	155
AG-160/170/180/190	100C	HC-V700M	400	NV-R500EN/R550EN	155
AG-185U/187/188/195/196U	130C	HDC-DX1/DX3	307	NV-RS7	181
AG-400P/450/460	100C	HDC-HS9/HS20/HS100/HS200	307	NV-RX1/RX2/RX5/RX7EN	155
AG-455/456/459/461	130C	HDC-HS40/60/80	400	NV-RX9/RX11B	150
AG-2400/6400/7400	100C	HDC-HS250/HS300/HS700	307	NV-RX14B/RX64	181
AG-B20P/BP188U	130C	HDC-HS900	423-1.3	NV-RX15B/RX18B/RX19	150
AG-BP202/212DX	100C	HDC-SD1/SD3/SD5/SD7/SD9	307	NV-RX21B/RX31B/RX49/RX61B	150
AG-DCV 7/DVC15	172	HDC-SD10/SD20/SD100/SD20	307	NV-RX70B	150

\*Indicates Internal Fit

NLA: No Longer Available

NYA: Not Yet Available

NR: No Replacement

**EMPIRE VIDEO/DIGITAL CROSS-REFERENCE**

PANASONIC (CONT'D)		PANASONIC (CONT'D)		PANASONIC (CONT'D)	
NV-RZ1/RZ2	181	PV-5850/6000	101C	PV-L590/L600/L600C/L601	150
NV-S1/S1B/S1E/S1K/S1S/S2	150	PV-6100	130C	PV-L606/L607/L647/L650	150
NV-S5/S5B/S5E/S6/S6B/S6E	150	PV-6110	100C	PV-L650K/L651/L651D/L652	150
NV-S7/S7B/S7E/S7EG/S8/S9	150	PV-6500/6600	101C	PV-L657/L658/L659/660	150
NV-S20/S20B/S20EG/S30	150	PV-8000/8100/8110	100C	PV-L660D/L670/L671/L677	150
NV-S78E/S100/S100EN	150	PV-8206/8306	150	PV-L678/L679/L679K/L680	150
NV-S200/S500/S500EN	150	PV-8440/8484/8485/8500	100C	PV-L681/L690/L691/L750	150
NV-S600/S700/S700EN/S800	150	PV-8600/8650/9000/9000A	100C	PV-L750K/L751/L757/L758	150
NV-S850EN/S950EN	155	PV-9600/9600A	100C	PV-L759/L779/L779K/L780	150
NV-VX17EN/VX27EN/VX57EN	181	PV-A206/A207/A208/A216	150	PV-L780D/L781/L850/L850K	150
PB-10B	150	PV-A227/A228/A266/A286	150	PV-L857/L858	150
PK-410/412/450/452	100C	PV-A296/A306/A307/A308	150	PV-L859/L859K/L958	150
PK-500/503/530/557/558	100C	PV-A376/A386/A396/A406	150	PV-LCD35	150
PK-597/972	101C	PV-A407	150	PV-M429	100C
PK-700	130C	PV-D10DK/D19DK/D29	150	PV-MC10EQ	110
PK-802/805/903/956/957/958	100C	PV-D101	172	PV-S43/S53/S62/S63/S64	150
PK-959/973/975/976/980	100C	PV-D209/D209KJ	150	PV-S70	130C
PRO-846	150*	PV-D300/D300K/D301	150	PV-S140/S150/S160	110
PSC15C	150	PV-D308/D318/D326	150	PV-S332	150
PV-2A216	150	PV-D406/D407/D414/D417	150	PV-S350	100C
PV-10/10B/10PX/11DK	150	PV-D426/D427/D476/D486	150	PV-S362/S372/S630	150
PV-14/14D/14K/15K/17/18	150	PV-D496/D506/D507/D526	150	PV-S4420/S440/S445/S460	100C
PV-19/19D/20/21/21D/22/22D	150	PV-D606/D607	150	PV-S540/S545/S550	100C
PV-31/32/32D/40/40D/40DK	150	PV-D700/D710	162	PV-S565/S575	100C
PV-41/42/42DK/42K	150	PV-D705/D776	150	PV-S770	130C
PV-43/43D/43DK	150	PV-D900	172	PV-S770A	150
PV-50/53	110	PV-D1000	162	PV-SD4090/SD5000	162
PV-52/54/54D/62/64	150	PV-DC152/DC252/DC352	172	PV-VM202	172
PV-100/110/120/122/140	110	PV-DV10/DV10i/DV51/DV52	172	SD-VA100	241
PV-200	100C	PV-DV53/DV73/DV100/DV100K	172	SDR-H18/H20/H200	230
PV-200D	112C	PV-DV102/DV103/DV200/200K	172	SDR-H40/H41/H48/H60	307
PV-210/220	100C	PV-DV201/DV202/DV203	172	SDR-H68/H80/H90/H258	307
PV-213A/214A/215A	150	PV-DV400/DV400K/DV401	172	SDR-H288	307
PV-300/320/330	100C	PV-DV402/DV600/DV600K	172	SDR-H85/95/100/101	400
PV-308/332/332D/332DK/333	150	PV-DV601/DV602	172	SDR-HS60/80	400
PV-350	100C	PV-DV700	162*	SDR-S7/S10/S15/S26	319
PV-362/362D/372D/372DK	150	PV-DV701/DV702/DV710	172	SDR-S100/S150/S300	290
PV-400/420/425/430/460	100C	PV-DV800/DV800K/DV852	172	SDR-SW20/SW21	319
PV-500/501/502/510	130C	PV-DV900/DV900K/DV900/910	172	SDR-S45/50/70/71	400
PV-506/507	150	PV-DV950/1000	162	SDR-T50/55/70/71/76	400
PV-515/520/530/535	100C	PV-DV952/DV953	172	SV-AV10/20U/30/35	203
PV-558/563	150	PV-GS9/12/14/15	172	SV-AV50/A510	237
PV-602/604	130C	PV-GS19/29/31/35/39/50S/59/7	230	SV-AS10	172
PV-606	150	PV-GS55/65	230	TC-7-WMSI	292
PV-610	130C	PV-GS120/150/200/250	230	VDR-D50/D51/D58	307
PV-611A	150	PV-GS300/308/400/500/508	230	VDR-D100/D105/D200/D210	230
PV-645/650/660	100C	PV-GS80/83/85/90/320/500	307	VDR-D220/230/250/300/310	230
PV-700/704/710/720	130C	PV-IQ202/IQ203/IQ204/IQ205	150	VDR-M10	172
PV-750	100C	PV-IQ205D/IQ214/IQ215/IQ225	150	VDR-M30/M50/M70	230
PV-760/760A/760B/800	130C	PV-IQ244/244D/245/255	150	VM-539/D100/L451	150
PV-808	150	PV-IQ294/295/303/303A	150	VSF-0164	130C
PV-810	130C	PV-IQ304/304A/305/314	150	WV-3400/4850	101C
PV-822	100C	PV-IQ315/325/344/375/375A	150	VW-VBN130	423-1.3
PV-900	130C	PV-IQ384/384A/393/394/403	150		
PV-908/910A	150	PV-IQ403D/IQ403DK/IQ404	150		
PV-910/918/940/950/960	130C	PV-IQ404A/405/425/434/475	150		
PV-2200	100C	PV-IQ485/IQ493/IQ494/IQ495	150		
PV-3200	100C	PV-IQ503/504/504A/505	150	<b>Battery to Empire Battery #</b>	
PV-5000	101C	PV-IQ511/IQ525/IQ575/IQ594	150	AG-3	150
PV-5110	100C	PV-IQ604/604D/635/705	150	AG-BP15/BP15P	162
PV-5150	110	PV-IQPBA306	150	AG-BP20	130C
PV-5200/5350	100C	PV-L50/L59/L60	150	AG-B20P	100C
PV-5372	150	PV-L352/L353/L354	150	AG-B21P	130C
PV-5400	101C	PV-L450K/451/452/453/L454	150	AG-BP25	166
PV-5420	100C	PV-L457/L459K/L501/L550	150	BP-508	150
PV-5500	101C	PV-L551/L552/L552H/L557	150	BP-BP20P	130C
PV-5630	150	PV-L558/L559/L560/L560K	150	CGA-D54	262
PV-5800/5810	100C	PV-L568/L571/L578/L579/L580	150	CGA-DU07/DU12/DU14/DU21	230
				CGA-S001/S001E	226

\*Indicates Internal Fit  
 NLA: No Longer Available  
 NYA: Not Yet Available  
 NR: No Replacement

**EMPIRE VIDEO/DIGITAL CROSS-REFERENCE**

PANASONIC (CONT'D)		PANASONIC (CONT'D)		PENTAX (CONT'D)	
CGA-S002	225	PV-DBP5	162	OPTIO VS20	333
CGA-S003	237	PV-DBP8/DBP9	172	OPTIO W10/20, WP, WPi, X	222
CGA-S003A/1B	172	PV-GS80/GS85/GS320	230	OPTIO W30	311
CGA-S004A/S004E	260	PV-GS320	230	OPTIO W60/ W80	344
CGA-S005	284	PV-IQ225D	150	OPTIO W90/ WS80	363
CGA-S006	283	PV-L354/L454	150	OPTIO WG-1/WG-1GPS	364
CGA-S007/S007A/S007E	298	PV-V213	150	OPTIO WG-2/WG-2GPS	364
CGA-S008A/S008E	319	UP10V1.1AN/UP10V1.IN	110	OPTIO X70	364
CGA-S009A/S009E	367	VS0-0011	100C	OPTIO Z10	259
CGA-S101A/S101B	219	VS0-0016	130C	PV800E	103
CGA-S106B	367	VS0-0190/0200	155	PVC1SA/11A/33/55A/66A/67A	104
CGA-S301A1	203	VS0-0470	230	PVC77A/78A	NLA (02/10)
CGA-S302	241	VW-VB30/VB31	100C	PVC480E/840E/PVC860E	109
CGA-S303	290	VW-VBC1E/VBC3	110	PVC800A/850A/880A/900A	113
CGA-S603E	284	VW-VBC4E/VBC5E	110	PVC905A/909A	143
CGP-D28A/D110/D210/D320	172	VW-VBA05	237	PVEM100E	109
CGR-B202/B403/B814	162	VW-VBA10/VBA21	203	PVR1000A	104
CGR-D08/D14/D16/D28	172	VW-VBCE4E	110	PVR1100A	100C
CGR-D120/D220/D320/D815	172	VW-VBD1/VBD1E/VBD2	162	PVR83030AV01	150
CGR-DU06/DU06A/1B	230	VW-VBD07/VBD14/VBD21	230	Q BLACK/Q WHITE	333
CRG-DU12A/1B	230	VW-VBD19/VBD19PP-K	396	Q10	333
CGR-S002	225	VW-VBD23/VBD24/VBD25	172	RS1000	272
CGR-S006,006A	283	VW-VBF2	130C	RZ10	364
CGR-S101A	219	VW-VBG6/VBG6K/VBG6PPK	393	V1	104
CGR-S602A/S603E	218	VW-VBG070/VBG130	307	W90	363
CGR-V14S	181	VW-VBJ10/VBJ10E-K	319	WG-2/2GPS	364
CGR-V610/V620	181	VW-VBJ10PP1K	319	X90	371
DMW-BC7	219	VW-VBK180	400-1.8	Z10	259
DMW-BCA7	226	VW-VBK360	400-3.6	<b>Battery to Empire Battery #</b>	
DMW-BCB7	260	VW-VB260	307	D-Li1	208
DMW-BCC12	284	VW-VBL090	400	D-Li2	203
DMW-BCD10/S007E	298	VW-VBM7E/VBM10	100C	D-Li7	228
DMW-BCE10/S008E	319	VW-VBM10E	155	D-Li8	222
DMW-BCF10/10E/10GK/10PP	367	VW-VBN260	423-2.6	D-Li22	333
DMW-BCG10/BCG10E	368	VW-VBN390	423-3.9	D-Li50	238
DMW-BCG10PP	368	VW-VBS1E/VBS2E	150	D-Li63	311
DMW-BCH7/BCH7E/BCH7PP	391	VW-VBS20E	155	D-Li68	333
DMW-BCJ13	403	VW-VBX070	363	D-Li72	259
DMW-BCK7/BCK7E/BCK7PP	418	VW-VBX090	339	D-Li78	344
DMW-BL14	218	<b>PENTAX</b>		D-Li85 / D-Li 95	222
DMW-BLA13E	307	<b>Model to Empire Battery #</b>		D-Li88	363
DMW-BLB13/13E/13PP	361	645D	372	D-Li90	372
DMW-BLE9	419	EI-2000	208	D-Li92	364
DMW-BM7	225	K-01	372	D-Li106	371
DMW-BMB9	404	K5/K5II/K5IIS/K5SILVER/7	372	D-Li108	272
DMW-BMA7/S006E	283	K-10D/20D	238	D-Li109	402
EPK1185	100C	K-r/K30	402	D-Li122	333
HHR-V20A/V20A1B/V40A	150	MB-02	150-2	K-20D	238
HHR-V40A1B/V60A/V60A1B	150	MB-02	159-2.1	PVBT1A/11/12	104
HHR-V214	150	OPTIO 330,330RS,430,430RS	203	PVBT71/72	NLA (02/10)
HX-WA2/WA20	339	OPTIO 550, OPTIO MX	228	PVBT810/820	113
LCS-2012APC/2012AV	100C	OPTIO A10/20/30	222	PVBT901/902	143
LCS-2012DVBNC	130C	OPTIO A36/A40	333	RZ10	364
LCS-2012P/2012VBNC	101C	OPTIO E65/E75/ E85	222	VE-258	130C
LCS-2312AVBNC	100C	OPTIO H90	363	<b>PHILCO</b>	
LCS-A122R3EU100C	100C	OPTIO I10	364	<b>Model to Empire Battery #</b>	
LCS-D122BU/D122EU	130C	OPTIO N20	222	V1728SL01, V1728TSL01	100C
LCT-1912AP	100C	OPTIO M30/40	311	VC1726SL01, VC1727SL01	101C
NCA-YN101H	418	OPTIO M50	344	VCR740SL01, VCR790SL01	112C
NVA3	155	OPTIO M90	272	VCR800SL01	112C
P-9AS/8U13	110	OPTIO P70/P80	363	VCR801AV01, VCR802AV01	100C
PV-122D	110	OPTIO RS1500	272	VCR807AV01, VCR809AV01	100C
PV-214A/215A/611A	150	OPTIO RZ18	364	VCR901AV01	100C
PV-BP10/BP11/BP12	110	OPTIO S1	344	VKR110	130C
PV-BP15/16/17/18/19	150	OPTIO S/4/4i/5i/5n/5z/6/7/V/Vi	222	<b>Battery to Empire Battery #</b>	
PV-BP50	130C	OPTIO S10, S12	333	SC2154	101C
PV-BP80/BP88	100C	OPTIO T10/20	222	V80039BK01	100C
PV-D200	172	OPTIO T30/ V10	311	V80063BK01	112C

\*Indicates Internal Fit  
 NLA: No Longer Available  
 NYA: Not Yet Available  
 NR: No Replacement

**EMPIRE VIDEO/DIGITAL CROSS-REFERENCE**





RCA (CONT'D)		REALISTIC (CONT'D)		RICOH (CONT'D)	
PRO 844	143*	16-3843	247C	DB-65	284
PRO 845	109	16-3882	216	DB-70	323
PRO 846	143*	16-3848	251	DB-80	344
PRO 847	109	MODEL 100	104	DB-90	299
PRO 850	143	MODEL 101	NLA (02/10)	DB-100	364
PRO 852	109	MODEL 102/103/126	142S	DRP-2	109
PRO 854	143*	MODEL 125	NLA (02/10)	DS-6365	331
PRO 860/865/867/870	143	MODEL 126	142S	NP-22	103
PRO 880/880HB	143	MODEL 150	106	NP-55/77/99	109
PRO 881HB/883HB/884HB	143	MODEL 151/152/153/154	109	NP-500	153
PRO 898LH	166	MODEL 155	150	SL-58, SL-68	331
PRO 930/932	143	MODEL 157	143	<b>ROLLEI</b>	
PRO 942/943/943S	143*	<b>Battery to Empire Battery #</b>		<b>Model to Empire Battery #</b>	
PRO 949	143	16-804, 16-BP65	142S	DP-8300/8330, NP-83	315
PRO 998LH	166	23-183	104	PREGO DP4200, DP5200	269
PRO B712	164	23-184	109	PREGO DP6200, DP6300	269
PRO EDIT	NLA (02/10)	23-186	NLA (02/10)	<b>Battery to Empire Battery #</b>	
PRO V712/V714	158	23-187	130C	02491-0015-00	269
PRO V730/V741/V742	166	BT-22RS	115	02491-0028-01	315
PRO V801C	150	P16-BP63	NLA (02/10)	02491-0037-00	269
PRO V949HB	143*	P16-BT-22	115	02491-0045-00	315
PRO V950HB	156	T16-BP64	142S	<b>SABA</b>	
PRO V2000D	156	VM-BP21ARS	104	<b>Model to Empire Battery #</b>	
PSC10	143	VM-BP61RS	106	CVK-2600	110
PSC15C	150	VM-BP66RS	142S	VM-6800/6930/6940CD/6990	110
PSC20HB	143	VM-BP82	143	VM-6995CD, VMK-6700	110
VTR-100	106	VM-PB21ARS	104	<b>SAMSUNG</b>	
<b>Battery to Empire Battery #</b>		R-800H	107	<b>Model to Empire Battery #</b>	
AV-096	NLA (02/10)	<b>RICOH</b>		AD43-00136A/00148A	271
AV-8M3W	109	<b>Model to Empire Battery #</b>		AQ100	382
AV-8MLED+D1126	150	CAPLIO GX/8	228	CL80	370
AV-8MM	109	CAPLIO GX100	284	DIGIMAX 301	268
AV-8MSW	150	CAPLIO R1, R2, Z1	300	DIGIMAX i5, i50	222
AV-55	109	CAPLIO RR1	183	DIGIMAX i6	288
AV-120	104	CAPLIO R3/4/5	284	DIGIMAX i8	332
AV-158C/608/609	109	CAPLIO R6/R7	323	DIGIMAX i85	314
AV-622	103	CAPLIO RR30	228	DIGIMAX L55W/85W	295
AV-650	110	CAPLIO R30/40	284	DIGIMAX L50/L60/L73/L80	288
AV-800	143	CAPLIO R50	344	DIGIMAX L74	314
BB-060	143	CAPLIO 300G/500G/500SE	228	DIGIMAX L77	259
BB-44/45/50	158	CX1/CX2/R8/R10	323	DIGIMAX L700	288
BB-65L	166	CX3/4/5	364	DIGIMAX L830	332
BB-75	156*	DS-6370	331	DIGIMAX NV3, NV7	288
BB-90	156	G-600/700/700SE	284	DIGIMAX NV10/15/20	303
BB-120/150	143	GR-DIGITAL/DIGITAL II	284	DIGIMAX NV11	314
BB-700	150	GR-DIGITAL III, GX-200	284	DIGIMAX PRO-815	289
BC-40, BDC-40	160	GXR	299	DIGIMAX ST10	332
BP-96	110	RDC-7/6000, RDC-1500	183	DIGIMAX U-CA3/4/5	203
BP-96FL/96FS	NLA (02/10)	RDC-I700	174	DIGIMAX U-CA401/501/505	203
BV-060	143	R-16/17/17C/18H/66/67/86	109	DIGIMAX V3/4/5/6/50/70	268
CB-060/120	104	R-87H	153C	DIGIMAX V700, V800	203
CB-096FL/096FS/096 LONG	142S	R-86S/88/88H/105/108H/200	109	DIGIMAX V4000	268
CB-120	104	R-250/500/600	103	DV200/300/300F	428
CBC-060/120	106	R-260/600S/610/612/615/620	109	ES-55	341
EP-096FL/096FS	142S	R-630/680/800/808H/810	109	ES-65/70/80	382
FB-096FS/120/1260	150	R-800H	107	GX-10/20	238
<b>REALISTIC</b>		R-830/831/850/860/861/880	109	H304	411
<b>Model to Empire Battery #</b>		TF-200	109	HMX-E10/100	405
16-801	104	VC-H815	109	HMX-F80/500/530	411
16-802/803/825	NLA (02/10)	<b>Battery to Empire Battery #</b>		HMX-H100/104/105/106	335
16-826	115	DB-20	183	HMX-H200/203/204/205/220	411
16-830	142S	DB-30	174	HMX-H300/303/305/320	411
16-851	106	DB-34	228	HMX-M20	390
16-852/853	109	DB-40	203	HMX-Q10	390
16-2433	271	DB-43	228	HMX-R10	371
16-2434/2435	246C	DB-50	300	HMX-S10/15/16	411
16-2436	230	DB-60	284	HMX-T10/T100	390
16-3840	253C				

\*Indicates Internal Fit  
 NLA: No Longer Available  
 NYA: Not Yet Available  
 NR: No Replacement

**EMPIRE VIDEO/DIGITAL CROSS-REFERENCE**

SAMSUNG (CONT'D)		SAMSUNG (CONT'D)		SAMSUNG (CONT'D)	
HMX-U20	341	SC-MX10R/20/20C/25E	335	VP-L150	150
HZ10W/HZ15	341	SC-W61/62/71/73/80/87/97	195	VP-L100/L300/L330/L350	109
HZ30W/35W/50W	370	SC-X105L/X110L	282	VP-L500/520/530/550/700	195
I6pmp/70	288	SC-X205/X210/X300/X300L	302	VP-L700U/710/750/750D/770	195
i7	318	SC-X704	130C	VP-L800/850/870/900/903/907	195
i8	332	SC-X800X/803/X804/X854	109	VP-L980	109
i80/85/100	314	SC-X904X/915/X953	109	VP-M50/51/52/53/54	195
IT-100	341	SDC-K50/64/128/512	296	VP-M102/102B/102S	282
L60/73/700	288	SDC-D256/D512	296	VP-M105/105B/105R/105S	282
L70/83T/201/301	303	SDC-MS61	305	VP-M110/110B/110L/110R	282
L74	314	SH-100	412	VP-M110S/M2100	282
L77	259	SL-50/600/630	382	VP-MS10/11/12/15	296
L100/110/200/210/310W	341	SL102/202/310/420/620/820	341	VP-MX10/MX20	335
L730, L830	332	SL201	303	VP-X110/X110L	282
M900/M900F	434	SL-600/605	382	VP-W70U/W71W/75W/75D	195
NV4	332	SMX-C10/C14/C20/C24	373	VP-W80/W87/W90/W97	195
NV5	288	SMX-F30/F34	335	WB-100/1000	370
NV8	303	SMX-F40/43/44/50/53/54	411	WB-210	412
NV9	341	SMX-F400/401	411	WB-500/550	341
NV30/40/24HD/100HD	314	ST-10	332	WB-700/5000	370
NX10/20/100	386	ST-50/500/550/600	366		
NX200/210/1000	421	ST-60/65/70/80/90/95/100/700	382	<b>Battery to Empire Battery #</b>	
PC600	411	ST-200	412	AC-43-1001R	109
PL10	332	ST-1000	370	B-9527	302
PL20	382	SV-C3/C8	103	BP-70A	382
PL-50/51/55/60/65/70	341	SV-C9	110	BP-85A	412
PL-80/90/100/120/170/200	382	SV-E27	100C	BP-88A	428
PL-150	366	SV-H30/H33	109	BP-88B	434
PL-210/211	412	TL9	341	BP-90A / IA-BP-90A	405
SB-P90AB/P90ASL	282	TL34HD	314	BP125A	390
SC-A12/14/20/23/25/30/33/35	109	TL100/200/205/210/220/225	366	BP-1030	421
SC-A80/A85	109	TL105/110/125	382	BP-1310	386
SC-D20/21/23/24/27/29/31/33/34	200	TL320/350/500	370	CAB-05/06	152
SC-D37/39/55/60/67/70/73/75	200	VC-E27N/H15N/H815	109	ED-BH1310	386
SC-D77/80/81/86/87/93/99	200	VM-A650/930	200	FB-1260	150
SC-D105L	282	VM-B97HS/710/730/770	200	IA-BH125C	371
SC-D107/130/370	200	VM-B990/1300/1900/3710	200	IA-BH130LB	373
SC-D164	271	VM-C630/670/690/730/790	200	IA-BP80W/BP80WA	377
SC-D180/190/323/325/327/340	200	VM-C890/1500/2000	200	IA-BP125A	390
SC-D351/352/353/354/355/357	271	VM-C5000	235	IA-BP85OM	343
SC-D363/364/365/366/372	271	VM-M102/M105/M110	282	IA-BP85ST	335
SC-D382/D385	377	VP-A20/22/30/31/33/34	109	IA-BP105R/BP210E/BP210R	411
SC-D453/455/457/557	271	VP-A50/55/57/800/A850	109	IA-BP105R/BP210R/BP420E	411-4
SC-D530/530T/D590/590T	200	VP-D7L/D10/D11/D15/D15i	200	NB-E60A/E70A	109
SC-D903	278	VP-D20/D21/D21i/D23/D23i	200	NC-120N	109
SC-D5000	235	VP-DD24/D26/D30/D31	200	SB-L10A/ SLB-10A	341
SC-D6040/D6550	200	VP-D33/D33i/D34/D34i/D39	200	SB-L70/L70A	200
SC-DC164/165/173/575	271	VP-D55/D60/D63/D65	200	SB-L70G	235
SC-DX10	343	VP-D70/D73/D75/D76/D76i/D77	200	SB-L110	200
SC-DX103/205	377	VP-D80/D81/D82/D83i/D85/D87	200	SB-L110A	195
SC-F30/32/34/35/703	130C	VP-D87i/D93/D97/D99/D99i	200	SB-L110G	235
SC-F500/501	104	VP-D101/103	200	SB-L160	195
SC-F700/702/710/712	152	VP-D103i/D303i/323i	278	SB-L220	200
SC-704/F754/755/756/765	130C	VP-D105/D107/D130/D130i	200	SB-L320/L480	195
SC-H985/H996	109	VP-D190/D190i/D190MSi	200	SB-LH73	305
SC-HMX10/HMX20C	335	VP-D230/D250/D270/D301/D30	200	SB-LH82	296
SC-K60/K70/K75/K80/K85	109	VP-D305/D307/D327i/D340	200	SB-LS80	271
SC-L100/L300/L320/L330/350	109	VP-D351/351i/352/352i/353	271	SB-LS110/LS220	278
SC-L520/L530/L540/L550	195	VP-D353i/354/354i/355/355i	271	SB-LSM80/LSM160/LSM320	271
SC-L600/L610/L630/L650	195	VP-D380i	200	SB-P90A	282
SC-L700/L710/L750/L770	195	VP-D451i/453i/454i/455i	271	SB-P120A/P240A	302
SC-L800	109	VP-D530/D530R/D590/D590i	200	SB-P180A	282
SC-L810/L860/L870	195	VP-D903i/D907i/6050i	278	SC-W62	195
SC-L901/L903/L906/L907	195	VP-D5000/D5000i	235	SLB-07A	366
SC-M51/M52/M53	195	VP-D6040/D6050/D6050i	200	SLB-07B	366
SC-M105S	282	VP-DX10	343	SLB-0637	259
SC-MS10/11/15	296	VP-DX100/100i/105i/200	377	SLB-0737	222
SC-MX10/MX10A/MX10P	335	VP-HMX20C	335	SLB-0837	288

\*Indicates Internal Fit  
 NLA: No Longer Available  
 NYA: Not Yet Available  
 NR: No Replacement

SAMSUNG (CONT'D)		SANYO (CONT'D)		SEARS (CONT'D)	
SLB-0837B	303	XACTI DMX-CG65/CG65G	244	55624, 55625, 55634	150
SLB-0937	332	XACTI DMX-CG65K/CG65S	244	55635, 55814, 55824, 55844	109
SLB-10A	341	XACTI DSC-C4	244	55914	NLA (02/10)
SLB-11A	370	XACTI HD1	294	55428, 58428, 58457, 58458	164
SLB-1037/1137	203	XACTI SH1	387	58537, 58538	142S
SLB-1137C	318	XACTI VPC-A5	259	58628, 58657, 58658	150
SLB-1137D	314	XACTI VPC-C4E/CA6/CA8/CA6	244	58667, 58668	150
SLB-1237	295	XACTI VPC-CG6/CG9/E60	244	58827	109
SLB-1437	268	XACTI VPC-E60EXJ4EX	244	58828	153
SLB-1674	238	<b>Battery to Empire Battery #</b>		58847	109
SLB-1974	289	BNP-22	103	58848	153
SV-LB5	152	DB-L10	224	58857	109
SV-LB6	130C	DB-L20	244	58878	153
SV-NB3/NB4	104	DB-L30	259	58917, 58937, 58968	150
<b>SANYO</b>		DB-L40	294	<b>Battery to Empire Battery #</b>	
<b>Model to Empire Battery #</b>		DB-L50	236	5399	100C
DMC-FE30	294	DB-L80	363	52061	109
DMX-C1/C4D/C4L/C4N	244	DB-L90	387	52074	150
DMX-C5S/C5T/C5W	244	DS-5370	272	53834	142S
DMX-C6K/C6R/C6S	244	LA2312	100C	53981	NLA (02/10)
DMX-CG10/11/100/110	363	NB-111	191	53982	142S
DMX-CS1	363	NP-1/1A	114	53983	142S
DMX-GH1	363	NP-40	222	53988	109
DMX-HD800	294	SL20	244	53991	130C
DMX-SH1	387	UR-110	191	53994, 53995	104
DSC-MZ3	224	UR-121/121D/124	221	VMBP61AS	NLA (02/10)
DSC-C4/C5/E6/J4	244	UR-211	183	<b>SELECO</b>	
IDC-1000U/1000Z	221	VR-151	158	<b>Model to Empire Battery #</b>	
VC-8/10	103	<b>SEALIFE</b>		SVM-7000	110
VCR-88	103	<b>Model to Empire Battery #</b>		<b>SHARP</b>	
VEM-8, VEM-800, VEM-D3	103	BS-8300	315	<b>Model to Empire Battery #</b>	
VEM-H100/S1/S2	109	DC800/DC1000	315	AC-2000	110
VISION 8	103	REEFMASTER DC500	269	AD-M20BT	187
VM-8/10/800P	103	S5	269	AD-MS10BT	191
VM-D1P	103	<b>SEARS</b>		AD-S30BT/S31BT	207
VM-D1/D3/D5/D5P/D6/D6P/D8P	109	<b>Model to Empire Battery #</b>		AD-T50BT/T51BT	207
VM-D66/D66P	109	934	142S	MD-MS702MK/MS722	207
VM-ES77/ES99/H100P	109	5368, 5369, 5370	100C	MD-MT821GL	207
VM-P5P/PS12	109	5372, 5374, 5376, 5377	104	MS-S10BK	187
VM-RZ1/RZ1A	109	5379	NLA (02/10)	QC-50	110
VME-S88/S88P	109	5524, 5526	142S	SLIMCAM	146
VPC-C1/C1EX/C4/C4EX/C4GX	244	53601, 53612	150	VC-20/250	110
VPC-C4S/C5/C5E/C5EX/C5GX	244	53661, 53662, 53671, 53672	130C	VC-C10U	112C
VPC-C6/C40	244	53684, 53685	130C	VC-C20UA	115
VPC-CA6/CA8/CA9/CA65	244	53683, 53691, 53703	100C	VC-C50/C50UA/C500A	110
VPC-CA100/CA102/CA102YL	363	53704, 53705, 53706	109	VIEWCAM Z	229
VPC-CG6/CG9/CG65	244	53708, 53709	109	VL-50/60/62U/63U/64U	146
VPC-CG10/20/21/88/100	363	53721	104	VL-73/74UA	108
VPC-CG102	363	53722, 53725	143	VL-100UP	109
VPC-CS1/CS1P	363	53729, 53730, 53732	104	VL-780H/780S/780X	110
VPC-E1/E2/E6/E6EX/E6U/E7	244	53733, 53734, 53735	142S	VL-A10U/A110U/111U/150U	164
VPC-E760/E870	222	53740, 53741, 53742	104	VL-A160U/260U	164
VPC-FH1/FH1A	236	53743, 53744	104	VL-AD260U	176
VPC-GH1/GH2/GH3/GH4	363	53745	NLA (02/10)	VL-AH30U/AH50U/AH60U	164
VPC-HD1/1A/2/700/800	294	53746	142S	VL-AH130U/AH131U	164
VPC-HD1000/1010/2000	236	53749, 53761	104	VL-AH150U/AH151U	164
VPC-J4/J4EX/S7	244	53762, 53763, 53764	142S	VL-AH160U/AH161U	164
VPC-PD1/PD2BK	363	53781, 53782, 53783	142S	VL-AH500U/1500/1510	164
VPC-SH1	387	53790	NLA (02/10)	VL-AX1H	176
VPC-T700/T850	272	53791	104	VL-C2/C65	108
VPC-TH1/WH1	236	53792, 53793	142S	VL-C72UA	110
VPC-X1200/X1220/X1420	363	53794	124	VL-C73U/C74UA/C77UA	108
VRC-200	112C	53795, 53796, 53801	142S	VL-C80	104
VRC-7300, VTC-5800	114	53832	104	VL-C650U/C670	108
XACTI C6/CG65/E1/E60	244	53833, 53834, 53843, 53882	NLA (02/10)	VL-C690HC/690S/C690X	110
XACTI DMX-C4/CA6/CA8/CG6	244	53851, 53884	109	VL-C750U/C770/C780	108
XACTI DMX-CA6L/CG6P/CG6S	244	55514	150	VL-C855UA/C860/C6100	108
XACTI DMX-CG9/C40S/CA65	244	55534	143		

\*Indicates Internal Fit

NLA: No Longer Available

NYA: Not Yet Available

NR: No Replacement

**EMPIRE VIDEO/DIGITAL CROSS-REFERENCE**

SHARP (CONT'D)		SHARP (CONT'D)		SONY	
VL-C7500/7950S	110	VL-L4100U/L4300U	115	<b>Model to Empire Battery #</b>	
VL-D5000U	156	VL-L8100U	146	AC-VQ11	173
VL-DC1U/DC3U	156	VL-LXXU	146	AC-VQ/H10/P10	246C
VL-E7E/E8E	109	VL-M6GY/M6SL/M6U	109	BC-L100CE	250
VL-E33/E34	158	VL-ME10H/ME100 PRO	176	BETA-CAM	114
VL-E33U/E34U	164	VL-MS7SL	109	BC-TR1	247C
VL-E36	NR	VL-MX6/MX7GY/MX7U	109	BC-V500/V615	153C
VL-E37/E37U/E39/E39U	158	VL-MX70	109	BKW-L601/2	250
VL-E40U/E42	109	VL-N1U	109	BVP-5/7/50/70/90	250
VL-E43/E46/E47/E49	158	VL-NZ8U/NZ10U	205	BVP-550W/BVV-5/DNV-5	250
VL-E43U/E46U/E47U/E49U	164	VL-NZ50U/NZ55U/NZ100U	205	BVW-200/300/400/400A/400P	250
VL-E60/E62DU/E65DU/E66	164	VL-NZ105U/NZ150U	205	BVW-505/507/550/570/590	250
VL-E66U/E77/E77U/E78/E78U	164	VL-PD1U	179	BVW-D600	250
VL-E79/E89/E96/E98	164	VL-PD3U	177	CCD-20061	109
VL-E42U	158	VL-PD6	176	CCD-CR1	173*
VL-E450	156	VL-RD1U	178	CCD-CR1E	173C
VL-E500U	158	VL-S1/S1U/S5/S5U	164	CCD-F30/33/34/35/36/38/40/45	109
VL-E550	156	VL-S860	108	CCD-F46/50/55/56/70/77	109
VL-E600/E600U/E610U	164	VL-SD20U	176	CCD-F150/201/250/280/301	109
VL-E620/E620U	164-2.5*	VL-SE10/SE10U/SE15	164	CCD-F302/330/335/340/350	109
VL-E630U	164	VL-SE20/SE20U/SE50U	164	CCD-F355E/370/375E/380/401	109
VL-E650/E650U	164-2.5*	VL-SW50U	164	CCD-F402/450/455E/500/501	109
VL-E660U/E665U/E680U	164	VL-WD200U	176	CCD-F550/F555E	109
VL-E685U/E700/E700U/E720	164	VL-WD250H/WD250U/WD255	176	CCD-FX3	109
VL-E720U/E750/E750U	164	VL-WD450U/WD650U	176	CCD-FX228/FX230/FX280E	109
VL-E760/E760U/E765/E765U	164	VL-Z1U/Z3U/Z5U/Z7U	229	CCD-FX310/FX311/FX330	109
VL-E780U/E785U	164	WD-250U/450U/650U	164	CCD-FX400/FX410/FX420	109
VL-E850/E980U	164	<b>Battery to Empire Battery #</b>		CCD-FX500/FX510/FX511	109
VL-FD1/FD1U	196 (NLA)	AD-S30BT/S31BT	207	CCD-FX520/FX530	109
VL-400	109	AD-T50BT/T51BT	207	CCD-FX620/FX630	109
VL-H9E	109	BT-5C	108	CCD-FX710/FX730V	109
VL-H47U	156	BT-20	112C	CCD-FX810/FX830VE	109
VL-H80DU/H95	164	BT-21/22	115	CCD-G100ST	109
VL-H400U	109*	BT-30N	146	CCD-GV200/GV500	109
VL-H410/H410U/H420/H420U	164	BT-51/52	110	CCD-M7U	109
VL-H450/H450U	156	BT-70	109	CCD-M8E/8EK/8U/9U/10	103
VL-H500/H520/H520U	156	BT-71/72	110	CCD-RV100/RV200	153C
VL-H550/H550U	156	BT-73	108	CCD-SC5/SC5E/SC6	153C
VL-H700/H800/H800U	164	BT-75/76	110	CCD-SC6E/SC8E	109
VL-H810U	156	BT-77	109	CCD-SC7/SC7E/SC9	153C
VL-H850/H850U	164	BT-80/80BKP	159-4S	CCD-SC55/55E/65	153C
VL-H860/H860U	176	BT-BH70U/BH85U	109	CCD-SP5/SP5G/SP5Y	109
VL-H870/H870U/H875/H875U	176	BT-C4	108	CCD-SP7/SP9	109
VL-H880/H880U	176	BT-C20	112C	CCD-TR1/TR1E/TR2/TR3	153C
VL-H890/H890U/H950U	176	BT-H11U	158	CCD-TR4/TR5/TR6	109
VL-HL50	156	BT-H21U/H22U/H32U/H42U	164	CCD-TR7/TR8/TR9	109
VL-HL100U	109	BT-L1U/L2U	156	CCD-TR11/TR12/TR18/TR18E	153C
VL-L10/L10U	115	BT-L1U/L2U/L11U/L12U	156	CCD-TR21/TR23	109
VL-L30U	146	BT-L43U	179	CCD-TR30/TR31/TR33/TR36	109
VL-L40U	109	BT-L44U	178	CCD-TR40/TR45/TR44	109
VL-L50/L50U	146	BT-L221	177	CCD-TR50/TR50E	109
VL-L60U/L62U/L63U	146	BT-L221U	176	CCD-TR54/TR55/TR56	109
VL-L64U/L65U/L72U	146	BT-L223U	196(NLA)	CCD-TR57	153C
VL-L80U/L80UA	115	BT-L225U	205	CCD-TR61/TR64/TR65/TR66	109
VL-L94U/L95U	146	BT-L226U	229	CCD-TR67	153C
VL-L133	158	BT-L241/L241U/L441/L441U	176	CCD-TR70/72/74/75/75BR	109
VL-L150U/L170U/L175/L175U	115	BT-L445U	205	CCD-TR76	153C
VL-L180U/L210U	115	BT-LS222U/LS242U	214	CCD-TR78/TR81/TR82/TR83	109
VL-L240U	146	BT-N1U/N11U	158	CCD-TR84/TR86	109
VL-L250U	115	VB-BL5	156	CCD-TR87	153C
VL-L270U/L270U/L280/L285U	115	VR-BL71	156	CCD-TR88/91/93/94/96	109
VL-L290/L290U	146	VR-BL74	196	CCD-TR97	153C
VL-L310U/L330U	115	VR-BL75/BL81	156	CCD-TR98/99/100/101C	109
VL-L340U/L380U/L390U	146	<b>SIEMENS</b>		CCD-TR105/105E/112/150	109
VL-L410U	115	FA-108-4	103	CCD-TR200	153C*
VL-L490/L490U	146	FA-114/118/122/126	109		
VL-L510U	115				
VL-L630/L634	146				

\*Indicates Internal Fit

NLA: No Longer Available

NYA: Not Yet Available

NR: No Replacement

**EMPIRE VIDEO/DIGITAL CROSS-REFERENCE**

SONY (CONT'D)		SONY (CONT'D)		SONY (CONT'D)	
CCD-TR205	109	CCD-TRV408/TRV408E	180C	DCR-HC1000/1000E	209C
CCD-TR215/280PK/290PK/300	153C	CCD-TRV416	153C	DCR-IP1/IP1E/IP1K/IP5E	209C
CCD-TR311E/315/315E/317	153C	CCD-TRV418/418E/428/428E	180C	DCR-IP7/IP7BT/IP7E	209C
CCD-TR380/TR385E/TR400	109	CCD-TRV428E/TRV438E	180C	DCR-IP45/45E/55/55E	209C
CCD-TR408E	180C	CCD-TRV512	109	DCR-IP200K/210/210E	209C
CCD-TR411E/412E/413/414	153C	CCD-TRV517	153C	DCR-IP220/220BT/220E/220K	209C
CCD-TR415E/416/417/417E	153C	CCD-TRV608	180C	DCR-PC1/PC1E/PC2/PC2E	173C
CCD-TR425E/427/427E/500	153C	CCD-TRV615/620/715/716/720	153C	DCR-PC3/PC3E/PC4/PC4E	173C
CCD-TR505K/TR514	109	CCD-TRV728	153C	DCR-PC5/PC5E	173C
CCD-TR511/511E/512E/515E	153C	CCD-TRV730/740/748E	180C	DCR-PC6/PC6E	180C
CCD-TR516/516E/517/555/610	153C	CCD-TRV815/TRV900	153C	DCR-PC8/PC8E/PC9/PC9E	180C
CCD-TR600/TR614	109	CCD-TRV911	109	DCR-PC7/PC10	163
CCD-TR617/617E/618/618E	153C	CCD-TRV930/940	153C	DCR-PC55/55B/55R/55S/55W	263
CCD-TR640E/710/713E/716	153C	CCD-TRV3000	153C	DCR-PC100/101/101E/101K	180C
CCD-TR700/705/705E/714	109	CCD-V1/V3	103	DCR-PC103/103E/104/104E	180C
CCD-TR717/717E/718/718E	153C	CCD-V4	109	DCR-PC105/105E/105K	180C
CCD-TR728/728E/730E/760E	153C	CCD-V5/V7/V7F/V8/V8AFU	103	DCR-PC106/106E/107/107E	209C
CCD-TR748	180C	CCD-V9/V11/V22	109	DCR-PC108E/109/109E	209C
CCD-TR805E/TR814	109	CCD-V30/V35/V50E/V50F	103	DCR-PC110/110E/115/115E	180C
CCD-TR810E/818/840E/845E	153C	CCD-V88/V90/V95E/V99	109	DCR-PC120/120BT/120E	180C
CCD-TR880E/TR900	109	CCD-V101	109	DCR-PC300K/330/330E	180C
CCD-TR910/913E/918E	153C	CCD-V100/V110/V200/V220	103	DCR-PC350/PC350E	209C
CCD-TR916	109	CCD-V700E/V701	109	DCR-PC1000	263
CCD-TR917/930/940/950E	153C	CCD-V800/800E/801/801E	109	DCR-R1	180C
CCD-TR1100E/2200E/2300	153C	CCD-V900/V5000/V5000E	109	DCR-SC100	153-1.5C
CCR-TR2300E/3000	153C	CCD-VD1	103	DCR-SR30/32/33/35/36/37/38	308
CCD-TR3000E	109	CCD-VX3	109	DCR-SR40/42/45/46/50/52/55	308
CCD-TR3100E/TR3200E	153C	CRX10U	153C	DCR-SR57/60/62/65/67/70/72	308
CCD-TR3300/TR3300E	153C	CVX-V18NS/V18NSP	153C	DCR-SR75/77/80/82/82C/85/87	308
CCD-TRV4/TRV5/TRV9	153C	D-V500	153C	DCR-SR90/100/190/200/220	308
CCD-TRV11/TRV12	109	DCM-M1	153-1.5C*	DCR-SR220D/290/300/300C	308
CCD-TRV15/TRV16/TRV16E	153C	DCR-30	246C	DCR-SR58/68/78/88	380C
CCD-TRV19/TRV21/TRV22	109	DCR-DVD7	263	DCR-SX34/44/53/63/83	380C
CCD-TRV20	180C	DCR-DVD91/91E	180C	DCR-SX30/31/37/40/41/50/60	308
CCD-TRV22	109	DCR-DVD92/92E	246C	DCR-SX45/SX65/SX85	380C
CCD-TRV25/TRV27E	153C	DCR-DVD100/100E/101/101E	180C	DCR-TR7000/7000E/7100E	153C
CCD-TRV29/30/32/33	109	DCR-DVD103/105	246C	DCR-TR8000E/8100E	153C
CCD-TRV35/36/37/37E	153C	DCR-DVD106/108/109/110	308	DCR-TRU47E	153C
CCD-TRV40	109	DCR-DVD115/304/306/310	308	DCR-TRV1VE	173C
CCD-TRV41/43/45K/46/46E/47	153C	DCR-DVD200/200E/201/201E	180C	DCR-TRV6/TRV6E	180C
CCD-TRV47E/48/48E/49/51	153C	DCR-DVD202E/203/203E	246C	DCR-TRV5/TRV7/TRV9	153C
CCD-TRV52/TRV53	109	DCR-DVD404/406/410/450	308	DCR-TRV8/TRV8K	180C
CCD-TRV54E/55/56E/57/57E	153C	DCR-DVD505	308	DCR-TRV10/10E/11/11E	180C
CCD-TRV58/59/59E/61E	153C	DCR-DVD610/710/810/910	308	DCR-TRV12/12E/14/14E	180C
CCD-TRV62/63/64E	153C	DCR-DVD203KIT1/205	246C	DCR-TRV15/15E/16/16E	180C
CCD-TRV65/65E/66/66E/66K	153C	DCR-DVD300/301	180C	DCR-TRV17/17E/17K	180C
CCD-TRV67/67E/68/71/72/75	153C	DCR-DVD305/403/403E/405	246C	DCR-TRV18/18E/18K	180C
CCD-TRV78/78E/80PK/81/82	153C	DCR-DVD308/408/508/608	308	DCR-TRV19/19E/20/20E	180C
CCD-TRV85/85K/86PK/87/87E	153C	DCR-DVD650/850	308	DCR-TRV22/22E/22K/23	180C
CCD-TRV88/90/91/91E/92/93	153C	DCR-DVD505/602/605/653	308	DCR-TRV24/24E/25/25E	180C
CCD-TRV93/93E/94E	153C	DCR-DVD703/705/708/755	308	DCR-TRV27/27E/30/30E	180C
CCD-TRV95/95E/95K	153C	DCR-DVD803/805/808/905/908	308	DCR-TRV33/33E/33K/38/39	180C
CCD-TRV96K	180C	DCR-HC14/14E/15/15E	180C	DCR-TRV40/40E/50/50E	180C
CCD-TRV98/98E/99/101	153C	DCR-HC16/16E/17/17E	246C	DCR-TRV49E/TRV58E	153C
CCD-TRV106K/107/108/108E	180C	DCR-HC18/18E/19E	246C	DCR-TRV60/60E/70/70K	180C
CCD-TRV112	109	DCR-HC20/21/26/30	308	DCR-TRV75/75E/80/80E	180C
CCD-TRV116/TRV118	180C	DCR-HC23/22/24/26/27/29	246C	DCR-TRV103/110/110E/110K	153C
CCD-TRV119	109	DCR-HC30/35/37/39/44/45	246C	DCR-TRV116/116E/118/118E	180C
CCD-TRV126/128/138	180C	DCR-HC30E/30G/30L/30S	246C	DCR-TRV120/120E/125E	153C
CCD-TRV201	153C	DCR-HC47/53/62/94	246C	DCR-TRV130/130E	153C
CCD-TRV208/208E	180C	DCR-HC32/32E/33E/36/39E	308	DCR-TRV138/140/140E/140U	180C
CCD-TRV211/TRV212	109	DCR-HC40/43/46	308	DCR-TRV145/145E	180C
CCD-TRV215	153C	DCR-HC41/42/42E	246C	DCR-TRV203/210/210E/220K	153C
CCD-TRV218/TRV218E	180C	DCR-HC65/85/85E/96	308	DCR-TRV230/230E/235E	180C
CCD-TRV228/228E/238/238E	180C	DCR-HC28/38/48/52/54/62	308	DCR-TRV238/238E/239	180C
CCD-TRV312	109	DCR-HC88	180C	DCR-TRV240/240E/240K	180C
CCD-TRV315	153C	DCR-HC90	263-1	DCR-TRV245/245E/250/250E	180C
CCD-TRV308/318/328/338	180C	DCR-HC96	308	DCR-TRV255/255E/260	180C

\*Indicates Internal Fit

NLA: No Longer Available

NYA: Not Yet Available

NR: No Replacement

EMPIRE VIDEO/DIGITAL CROSS-REFERENCE



SONY (CONT'D)		SONY (CONT'D)		SONY (CONT'D)	
DCR-TRV265/265E/270E/280	180C	DSC-P150L/P150LJ/P150S	253C	ED-CAM	114
DCR-TRV285E/300K/310	180C	DSC-P200/P200B/P200R	253C	EDC-50	114
DCR-TRV310E/310K/315	153C	DSC-P200S	253C	EV-P10	103
DCR-TRV318	180C	DSC-R1	180C	EVC-8/10	103
DCR-TRV320/320E	153C	DSC-RX100	431	EVC-X7	109
DCR-TRV325/330/330E/338	180C	DSC-S30/S50/S70/S75/S85	180C*	EVO-250	153C
DCR-TRV340/340E/345/345E	180C	DSC-S950/S980	351	EVO-9100	109
DCR-TRV350/355/355E/360	180C	DSC-S750/780	287	EVW-300L	114
DCR-TRV420E	153C	DSC-T2	334	GRD 750US	173
DCR-TRV430E/460/460E	180C	DSC-T3	153C	GV-8/9/9E/100/300/500	109
DCR-TRV480/480E	180C	DSC-T1/3B/3S/5/5B/5N/5R/5S	247C	GV-A100/A500/A500E/A700	153C
DCR-TRV510/520/520E/525	153C	DSC-T7/T7B/T7S	274	GV-D200/D300/D800/D900	153C
DCR-TRV530/530E	180C	DSC-T9	147C	GV-D1000	180C*
DCR-TRV620E/620K/720/720E	153C	DSC-T10/T10B/T10W/T11	247C	GV-U5/U5K	109
DCR-TRV725/730/730E	180C	DSC-T20/20B/20W/20P	287	GVH-D700	153C
DCR-TRV735K	153C	DSC-T30/T50/T50B	253C	HCR-HC21/HC33/HC43	246C
DCR-TRV738/738E/740/740E	180C	DSC-T33	247C	HCR-UX5/UX7	308
DCR-TRV820/820E/820K	153C	DSC-T70/T77/T90	334	HDC-930	250
DCR-TRV828/828E/830/830E	180C	DSC-T99/T110	379	HDR-AS10	431
DCR-TRV840	180C	DSC-T100/100R	287	HDR-AX2000	153C
DCR-TRV900/900E/935K	153C	DSC-T200/300/500/700/900	334	HDR-CX6/7/11/12/100/105	308
DCR-TRV940E/950/950E	180C	DSC-TX1	334	HDR-CX106/500V/520V	308
DCR-TV900/TV900E	153C	DSC-TX5/TX7/TX9/TX10/TX20	379	HDR-CX110/115/116/150/300	380C
DCR-VX700/1000/1000E/2000	153C	DSC-TX55/TX66/TX100V	379	HDR-CX130/160/B/190	380C
DCR-VX2000E/2100/2100E	153C	DSC-V1	206C*	HDR-CX200/210/260/360	380C
DCR-VX9000	153C	DSC-V3	253C	HDR-CX305/350V/505/550V	380C
DEV-3/5	380-2C	DSC-W30/35/40/50/55/60/70/75	287	HDR-CX560/580/760	380C
DEV-5	380-4C	DSC-W80/90/100/100B/110/120	287	HDR-CX360V/560V/700/700V	380C
DIGITAL MINI DISC	215	DSC-W130/150/170/200/210	287	HDR-DVD508/650	380C
DKC-1D	153-1.5C*	DSC-W180/190/370	351	HDR-FX1/FX1E/FX7/FX1000	153C
DKC-FP3	153C	DSC-W220/230/270/290/300	287	HDR-GW77	287
DNW-7/7P/9WS/90/90WS	250	DSC-W310/330/350/360/380	379	HDR-HC1	180C
DNW-A25P/WS/WSP	250	DSC-W390/510/530/560/570	379	HDR-HC3/5/7/9/28/38	308
DNW-A28/28P		DSC-W650/660	379	HDR-PJ30/50/60	380C
DNW-9WSP/90WSP	250	DSC-WX1/WX10	287	HDR-PJ10/10V/130V/150V	380C
DSC-750/780	351	DSC-WX5/WX9	379	HDR-PJ200/260/580	380C
DSC-A700	NYA	DSLR-A33	395	HDR-PJ710	380
DSC-CD250/CD400	153-1.5C*	DSLR-A100/200/300/350/500/5	180G	HDR-S1/SK/SR1/UX1	180C
DSC-D700/D770	153C	DSLR-A560/580/700/850/900	180G	HDR-SR5/5C/7/8/9/10/10D/11/12	308
DSC-F1/F2	185	DSLR-A230/290/330/380/390	308C	HDR-TD10/TD20	380C
DSC-F55/F55DX/F55K/F55V	173C	DSP-P1	173C*	HDR-TG1/TG5V	308
DSC-F77	180C	DSR-1/130/130P	114	HDR-UX3/5/7/9/10/19/20/40	308
DSC-F77A	206C	DSR-200	153C	HDR-XR100/105/106/200V	308
DSC-F88	253C	DSR-250/250P	250	HDR-XR150/155/350V/550V	380C
DSC-F505/F505K/F505V	173C*	DSR-300/A/AP/F/K/L/P/PF/PK/P	250	HDR-XR160/260	380C
DSC-F707/F717/F828	180C*	DSR-370K1/K2/L/P/PK1/PK2	250	HDR-XR500V/520V	308
DSC-FV505	173C*	DSR-390/K1/K2/L/P	250	HDW-700A/750/F900	114
DSC-FX77	180C	DSR-400/K/L/P/PK/PL	250	HVL-10DC	173
DSC-G1	253C	DSR-450WS/WSL/WSP/WSP	250	HVL-20DW2	153C
DSC-G3	334	DSR-500WS/WSL/WSP/WSP	250	HVL-IRM/ML20M	180C
DSC-H3/H5/H7/H7B/H9/H9B	287	DSR-570WS/WSL/WSP/WSP	250	HVR-A1U	180C
DSC-H10/H20/H20B/H50/H55	287	DSR-600PL/650W SPL	250	HVR-M10C/10E/10N/10P/10U	153C
DSC-H70	287	DSR-70/A/AP		HVR-V1U/Z1C/Z1U/Z5U/Z7U	153C
DSC-HX1	308	DSR-PD1	163	HXR-NX30	380C
DSC-HX5V/N1/N2/HX30	287	DSR-PD100/100A/100AP/100P	153C	KV-5300	114
DSC-HX7V/HX9V	287	DSR-PD150/170/170P	153C	MHS-CM5/PM1/PM5	351
DSC-HX100V/HX200	308C	DSR-PD150P/PDX10/PDX10P	180C	MICRO MV	209
DSC-L1/L1B/L1R/L1S/L1W/M1	247C	DSR-V10/V10P	153C	MPK-DVF4	153C
DSC-M2	253C	DVW-7/707/707P	250	MPK-M8	103
DSC-N1/N2	287	DVW-709/WS/790WS/WSP	250	MVC-5000	109
DSC-P1	173C	DVW-90/90WS/970/970P/970W	250	MVC-CD200/CD250/CD300	180C*
DSC-P2/3/5/7/8/9/10	206C*	DXC-637/3000	114	MVC-CD350/CD400/CD500	180C*
DSC-P8L/8R/8S/9/10L/10S	206C	DXC-D30/D35/D35L/D35P	250	MVC-CD1000/FD5/FD7/FD51	153-1.5C*
DSC-P12	180C	DXC-D35PL/D35WS/D35WSP	250	MVC-FD71/FD73/FD75	153-1.5C*
DSC-P20/P30/50/70	173C*	DXC-D35WSPL/D50/D50H	250	MVC-FD73K/83K/88K	153C
DSC-P100/P100L/P100LJ	253C	DXC-D50K/L/P/PH/PK/PL/WS	250	MVC-FD81/83/85/87/88/90/91	153-1.5C*
DSC-P100PP/P100R/P100S	253C	DXC-D50WHS/WSL/WSP/WS	250	MVC-FD92/95/97	153-1.5C*
DSC-P120/P150/P150B	253C	DXC-M2A/M3A	250	MVC-FD100/FD200	153-1.5C*

\*Indicates Internal Fit

NLA: No Longer Available

NYA: Not Yet Available

NR: No Replacement

EMPIRE VIDEO/DIGITAL CROSS-REFERENCE

SONY (CONT'D)		SONY (CONT'D)		TECHNIKA (CONT'D)	
MVC-FDR1/R1E/R3/R3E	153C	NP-FH30/40/50/60/70/90/100	308	CX-700/711	100C
NEX-3/5/5N/6/7	395	NP-FM30/FM50/FM55/FM70	180C	CX-751/757	110
NEX-C3	395	NP-FM90/FM91	180C	CX-811	100C
NEX-F3	395	NP-FM500H	180G	CX-911	104
NEX-VG30/VG900	380C	NP-FP30/FP50/FP70/	246C	CX-921	130C
NEX-VG10/VG20	380-4C	NP-FP71/FP90	246C	CX-971S	100C
NP-QM51	180C	NP-FQM71/FQM91	180C	<b>Battery to Empire Battery #</b>	
PAK-7	103	NP-FS10/FS12/FS22/FS32	173C	CB-520	112C
PBD-D50/V30	153C	NP-FS11/FS21/FS31	173C	CB-620	100C
PCR-TRV7	173C	NP-FR1	253C	CB-752	110
PLM-50/100/A35/A55	153C	NP-FT1	247C	CB-812	100C
PMW-EX1	346(NYA)	NP-FV30/50/70/100	380C	CB-911	104
PVM-8040/8041Q/8044Q/8045Q	292	NP-FW50	395	CB-920	130C
PVM-9041Q/9044Q	292	NP-QM71/QM71D/QM91/QM91	180C	<b>TELEFUNKEN</b>	
PVV-3/637	114	NPA-55	103	<b>Model to Empire Battery #</b>	
Q002-HDR1	153C	NPE-BP36	103	A-858P/885P/895P/890	110
SL-2000/2005	114	PVM-9044Q/9041Q	292	A-2000P	110
SLF-1	114	<b>SUNPAK</b>		VM-4000/4100/4200/4300	110
SLO-340	114	<b>Model to Empire Battery #</b>		VR-289	110
SLT-A33/A35/A37/A55	395	SV8	118	VR-1890/2890/2891	110
SLT-A57/A65/A77/A99	180G	SV10, SV11	109	VR-2892	110
TR-670E/V70E	109	<b>SYLVANIA</b>		<b>Battery to Empire Battery #</b>	
UPX-2000/C21	153C	<b>Model to Empire Battery #</b>		VZ-925/926/933	110
VCL-ES06A	153C	VC4511SL01, VC4512SL01	100C	<b>THOMSON</b>	
VO-6800	114	VC4513SL01, VC4514SL	100C	<b>Model to Empire Battery #</b>	
WATCHMAN	109	VC4515SL01	100C	CRV-04P/05	110
XV-M30/MH30	109	VC4520, VC4525SL01	100C	CVM-01P	110
<b>Battery to Empire Battery #</b>		VC4526, VC4527SL01	100C	VM-30	110
BP-2X/2EX	NLA (07/12)	VC4530	100C	<b>TOSHIBA</b>	
BP-GL65/GL95/IL75	250	VC4530BK01	101C	<b>Model to Empire Battery #</b>	
BP-L40/40A/60/60A/60S/65H	250	VC4540SL01	100C	3D-CAM	110
BP-L90/90A	250	VC4545, VC4546	100C	151	100C
BP-U30/U60	346(NYA)	VCC140SL01/ VCC150	112C	AI-33AFK/420P	110
EB-55	109	VCC145	110	CAMILEO H10	203
HL-45/57/59/59W	292	VCC151, VCC151AV01	100C	CAMILEO H30	228
LIP-8	184	VCC152	100C	CAMILEO X100	228
LIP-10/10B	185	VCC155	110	DC-5080	269
LIP-12/12H	186	VCC157, VCC159	100C	DC-5300/6300	203
NP-1/1A/1B/1H/1SB/23	114	VCC161	100C	DC-8300/8600	315
NP-22/22H	103	VCC165	110	DC-XZ6	315
NP-33/55/55H	109	VKC210, VKC221	130C	DV-5000/5070	203
NP-60D/66/66H/68/77/77H/78	109	VKC242	100C	GIGASHOT V10	322
NP-80/80D/88	109	VLC218, VLC225	130C	GSC-A40F/A100F/K80H	340
NP-90/98/98D/99	109	VMC226	130C	GSC-R30/R60	313
NP-500/510/520/530	153C	VMC260	150	HD-10X	203
NP-720/730/930	153C	<b>Battery to Empire Battery #</b>		IK-2200	110
NP-BD1	334	AR8378BK01	100C	PDR-5300	203
NP-BG1	287	AR8395BK01	100C	PDR-M3	174
NP-BK1	351	SC2154	101C	PDR-M4/M5/M60/M70	183
NP-BN1	379	V80039BK01	100C	PDR-T30	203
NP-BX1	431	V80076BK01, V80085BK01	110	PDR-3010/3310	207
NP-F10/F20/F30	173	V80086BK01	100C	SK-3D5/3D7	110
NP-F100/F200/F300	163	V80096BK01	130C	SK-40/50P/57/60/70/80	110
NP-F330/F500/F530	153C	V80115BK01, V80016BK01	150	SK-S80U/S90U	110
NP-F550/F550J/F570	153C	VE550UE	101C	V-8030T/9035	114
NP-F730/F730H	153-3.2C	VSBS0016	130C	X-4/5/6/S7	269
NP-F750/F750SP/F760/F770	153C	<b>TAMRON</b>		<b>Battery to Empire Battery #</b>	
NP-F930/F950/F960	153C	<b>Model to Empire Battery #</b>		GSC-BT5	313
NP-F970	153-6.6C	C-8100	109	GSC-BT6, 7	340
NP-FA50	263	CX-7MU	109	MEHBT4	322
NP-FA70	263-1	<b>Battery to Empire Battery #</b>		NP-80	183
NP-FC10/FC11	206C	NP-55/55H/60D/77/77H	109	NP-100	174
NP-FD1	334	<b>TECHNIKA</b>		PDR-BT1/BT1A/BT2/BT2A	183
NP-FE1	274	<b>Model to Empire Battery #</b>		PDR-BT3	203
NP-FF50/51/51S/70/71	209C	C-5000	112C	PDR-BT9	207
NP-FG1	287	C-5010/6000/6010/7000	100C	TBP-7U/8U/9U	110
		C-7500	110	TBP-100	114
				TBP-120	110

\*Indicates Internal Fit  
 NLA: No Longer Available  
 NYA: Not Yet Available  
 NR: No Replacement

VIVITAR		ZENITH (CONT'D)	
<b>Model to Empire Battery #</b>		VM-7060	NLA (02/10)
MAGIC 8	103	VM-7065	NLA (02/10)
MAGIC VHS	104	VM-7070	110
TRAVELER DC8300, DC8600	315	VM-7076	NLA (02/10)
VM-8350	103	VM-7130/7150/7170	110
VM-9350	104	VM-7500	110
6330s	324	VM-8000	109
7500I	222	VM-8300	110
8300s, 8330, 8600	315	VMC-450	150
VIVI CAM 4000	203	VMG-100/200	110
X-30	315	VPM-1000	110
X-60	315	VR-9500/9800/9850	114
<b>Battery to Empire Battery #</b>		<b>Battery to Empire Battery #</b>	
NP-22/22H	103	NP-22/22H	103
02491-0028-00	315	VAC-110	150
02491-0045-01	315	VAC-402/403/415/445	110
02491-0057-00	324	VAC-560	150
<b>WARDS</b>		VAC-620/645/690	110
<b>Model to Empire Battery #</b>		VAC-695	NLA (02/10)
10650, 10651, 10652	100C	VAC-790/791	110
10655	108	VAC-795	NLA (02/10)
10687	100C	VAC-900	103
SIGNATURE	108	VAC-901	104
SIGNATURE 2000	130C	VAC-902	118
UBATN0018GEZZ	108	VAC-903	115
<b>YASHICA</b>		VAC-904	143
<b>Model to Empire Battery #</b>		VAC-905	100C
DSC-F707	180	VAC-906	109
DSC-P1	173C*	VAC-907	130C
DSC-S75/S85	180	VAC-8045/8050	109
FINECAM 3L	207	VRB-9851	114
FINECAM S3/S3L/S3R/S3X	207		
FINECAM S4/S5/S5R	207		
KD-200K/1100U	103		
KD-1700	109		
KD-5010/5050/5820	109		
KD-H130/H150/H170	109		
KD-M710/M770	109		
KD-S820	113		
KX-35U	109		
KX-70/70E/77	109		
KX-90/90E/95/95U	109		
KX-H1	109		
KX-V1U	153C		
MICRO ELITE 3300	183		
SL-300R	245		
<b>Battery to Empire Battery #</b>			
BAP-100	103		
BP-150/170	109		
BP-780S	245		
BP-800S/880S/900S/1000S	207		
BP-1100R	183		
BP-1501/1502/1550	109		
BP-V1	153C		
<b>ZENITH</b>			
<b>Model to Empire Battery #</b>			
HQ-800	110		
VM-5000/6000/6100	110		
VM-6150/6175/6180/6190/6200	110		
VM-6300	110		
VM-6400	150		
VM-6500	110		
VM-6700C	150		
VM-7030/7050	110		