## User Replaceable Items effective 12/01/2005

## PowerLite 30c

DESCRIPTION	PART NUMBER
AC Power Cable	201 7328
Lamp (V13H010L19)	110 5774
Remote Control	117 8031
Lens Cap with String	110 8344
Cinema Filter Unit	117 5092
Navy Blue Carrying Case with handle and shoulder strap	
(outside compartment for cables)	112 4164

Order user replaceable parts from an Epson authorized parts distributor.

---- or ----

Locate an Epson Authorized Service Center to order user replaceable parts by using the "Help me find..." tool in the right column of the <u>Epson Support</u> home page.