



**SST Storage System
Master Index
JULY 2023**

To Order Special Service Tools Call Bosch/OTC at 1-800-933-8335

Table of Contents

	Page #
Part Number References	2-8
Drawer Liner References	9-20
Drawer 1	9
Drawer 2	9
Drawer 3	10
Drawer 4	10
Drawer 5	11
Drawer 6	11
Drawer 7	12
Drawer 8	12
Drawer 9	13
Drawer 10	13
Drawer 11	14
Drawer 12	14
Drawer 13	15
Drawer 14	15
Drawer 15	16
Drawer 16	16
Drawer 17	17
Drawer 18	17
Drawer 19	18
Drawer 20	18
Drawer 21	19
Drawer 22	19
Drawer 23	20
Drawer 24	20
Essential Tools Not Located in Storage Cabinets	21-23
Hybrid Electric Vehicle (HEV) Workstation	24

To Order Special Service Tools Call Bosch/OTC at 1-800-933-8335

Part Number References

TOOL #	TOOL DESCRIPTION	DRAWER #	TOOL #	TOOL DESCRIPTION	DRAWER #
00002-00039	39MM SOCKET	3	*01060-01	18MM JAW SET	9
00002-01775	SEAT HEATER ATTACHMENT KIT	22	*01070-01	105MM JAW SET	9
*00002-01780	REPLACEMENT NEEDLES	22	*01080-01	SLIDING JAW SET	9
00002-02955	BEAM TORQUE WRENCH	2	*01216-00111	TAPERED TAP	20
00002-06020-02	PLASTIC PRY TOOL KIT	21	*01216-00112	STRAIGHT TAP	20
*00002-06100	LARGE ANGLED GROMMET PRY TOOL	21	*01216-00113	SLIDE HAMMER	20
*00002-06200	LARGE ANGLED PRY TOOL	21	*01216-00114	PLUG PULLER (X3)	20
*00002-06300	THIN, FLAT PRY TOOL	21	*01216-00115	RUBBER PLUG (X5)	20
*00002-06400	INTERIOR CURVED PRY TOOL	21	*01216-00116	PIPE PLUG (X10)	20
*00002-06500	ANGLED GROMMET PRY TOOL	21	*01216-00117	TAP ALIGNMENT BRIDGE W/ BOLTS	20
*00002-06600	FLAT GROMMET PRY TOOL	21	01413-00002 (GRX-5100T)	HIGH VOLTAGE BATTERY SERVICE UNIT	HEV
*00002-06700	PANEL CLIP PRY TOOL	21	01413-00003 (A580)	INTERLOCK CONNECTOR	HEV
*00002-06800	SMALL ANGLED GROMMET PRY TOOL	21	01413-00004 (A533)	LOW VOLTAGE CABLE (R)	HEV
*00002-06900	SMALL PRY TOOL	21	01413-00005 (A573)	AC POWER CORD (S)	HEV
*00002-09077-01	OCCUPANT SEAT WEIGHTS	23	01413-00006 (A574 / A575)	D/C ADAPTER KIT (T / U)	HEV
*00002-09077-TRY	SEAT WEIGHT TRAY	23	01413-00007 (A571)	UNIVERSAL HIGH VOLTAGE CABLE (V)	HEV
00002-09090-01	OCCUPANT CLASSIFICATION SEAT WEIGHT SET	23	01413-00008 (A572)	UNIVERSAL LOW VOLTAGE CABLE (W)	HEV
00002-11100-02	TRANSMISSION FILL SYSTEM	IN SHOP	01413-00009 (A505)	HIGH VOLTAGE CABLE (E)	HEV
00002-12000-01	KDSS FLUID PRESSURE PUMP KIT	IN SHOP	01413-00010 (A296)	UNIVERSAL FUSE BOX	HEV
00002-12001-01	VEHICLE DRAIN TUBE AUGER	5	01413-00012 (A586)	A/C CIRCUIT TESTER	HEV
*00002-12010-01	PRESSURE GAUGE	IN SHOP	01413-00013 (A501)	HIGH VOLTAGE CABLE (A)	HEV
*00002-12030-01	PNEUMATIC/HYDRAULIC FOOT PUMP	IN SHOP	01413-00014 (A502)	HIGH VOLTAGE CABLE (B)	HEV
*00002-12040-01	HOSE AND MANIFOLD SET	IN SHOP	01413-00015 (A503)	HIGH VOLTAGE CABLE (C)	HEV
*00002-12050-01	STORAGE CONTAINER	IN SHOP	01413-00016 (A504)	HIGH VOLTAGE CABLE (D)	HEV
*00002-12060-01	BLEED BOTTLE SET (2 QTY.)	IN SHOP	01413-00017 (BCU - 64)	INTERFACE ECU - 64	HEV
*00002-16500	FABRIC FASTENERS	22	01413-00018 (A507)	HIGH VOLTAGE CABLE (G)	HEV
*00002-17750	SEAT HEATER ATTACHMENT TOOL	22	01413-00019 (A541)	CELL VOLTAGE CABLE (J)	HEV
00002-1ESBU-KIT	ENGINE SUPPORT BAR BRACKET	IN SHOP	01413-00020 (A551)	TEMPERATURE SENSOR CABLE (K)	HEV
*00002-211711-01	SHAFT PROTECTOR	6	01413-00021 (A552)	CELL VOLTAGE CABLE (L)	HEV
00002-2SUPP	RATCHETING STRAP (2)	4	01413-00022 (A531)	LOW VOLTAGE CABLE (P)	HEV
00002-35000	3/4 INCH DRIVE TORQUE WRENCH	IN SHOP	01413-00023 (A532)	LOW VOLTAGE CABLE (Q)	HEV
00002-35001	NUT WRENCH HOLDING TOOL	2	01413-00024 (A521)	STACK BALANCE HARNESS (I)	HEV
00002-35027	27MM HEX SOCKET	2	01413-00031 (A564)	BANANA JACK EXTENSION CABLE (X)	HEV
00002-42920	TIRE SERIAL NUMBER DEFACER	1	(A810)	HIGH VOLTAGE CABLE BLACK	HEV
00002-47883-02	FUEL INJECTION SERVICE TOOL SET	15	(A811)	HIGH VOLTAGE CABLE RED	HEV
00002-90080	SUBFRAME ALIGNMENT PINS	12	(A812)	HIGH VOLTAGE CABLE ORANGE	HEV
*00002-A0830	CABLE KIT	IN SHOP	(A813)	CELL VOLTAGE/DATA CABLE	HEV
*00002-A0870	PRINTER	IN SHOP	*01413-00069	MILLIOHM METER UNIT	HEV
00002-ESUPPT-01	ENGINE SUPPORT BAR	IN SHOP	*01413-00070	CLIP-TYPE TEST LEAD SET	HEV
00002-JUMPR-KIT	OBD-II JUMPER CONNECTOR KIT (4 COMPONENTS)	21	*01413-00071	TEMPERATURE SENSOR	HEV
00095-00010	BELT TENSION GAUGE WITH CABLE	3	01413-00072	INSULATED GLOVE SET, RUBBER WITH LEATHER PROTECTORS, SIZE M	HEV
*01010-01	HANDLE	9	01413-00073	INSULATED GLOVE SET, RUBBER WITH LEATHER PROTECTORS, SIZE L	HEV
*01014-00094	RADIO ANTENNA	17	01413-00074	INSULATED GLOVE SET, RUBBER WITH LEATHER PROTECTORS, SIZE XL	HEV
*01014-00095	RADIO ADAPTER	17	01413-00075	CANVAS GLOVE BAG (3)	HEV
*01014-00096	GPS ANTENNA	17	01413-00076	GLOVE INFLATOR	HEV
*01014-00097	GPS ANTENNA ADAPTER	17	01413-00077-1	42" LOOPER TUBE, ORANGE (4)	HEV
*01014-00098	XM ANTENNA	17	01413-00077-2	BASE, CONE (4)	HEV
*01014-00099	XM ANTENNA ADAPTER	17			
*01030-01	CROSSBAR	9			
*01040-01	50MM JAW SET	9			

* This tool is a component of an essential kit.

Part Number References

TOOL #	TOOL DESCRIPTION	DRAWER #	TOOL #	TOOL DESCRIPTION	DRAWER #
01413-00078	4-6FT ADJUSTABLE BARRIER (4)	HEV	01813-00059	DIE CUT FOAM	HEV
01413-00080	ARC PROTECTIVE HELMET & FACE SHIELD	HEV	*01815-00102	DIGITAL ANGLE GAUGE	IN SHOP
01413-00081	LARGE INSULATED MAT (30" X 48")	HEV	*01815-00105	LASER MEASURE	IN SHOP
01413-00082	SMALL INSULATED MAT (12" X 30") (3)	HEV	*01816-00103	3 LINE LASER, SMALL TRIPOD, TARGET	
01413-00083	CAUTION TAPE, ROLL	HEV		LASER BOARD	IN SHOP
01413-00088	INSULATED APRON	HEV	*01816-00104	TRIPOD	IN SHOP
01416-00119 A AND B (A619)	HIGH VOLTAGE CABLE	HEV	*01816-00108	DIGITAL T-BEVEL	IN SHOP
01416-00120 (A620)	CELL VOLTAGE CABLE	HEV	*01816-00109	LASER ENHANCING GLASSES	IN SHOP
01416-00121 (A621)	TEMPERATURE SENSOR CABLE	HEV	07112-66040-01	PRESSURE PLATE REMOVER	11
01418-00106 (A702)	CELL VOLTAGE INTERFACE	HEV	07112-76060	MAGNETIC CLUTCH STOPPER	22
01418-00107 (A703)	TEMPERATURE SENSOR INTERFACE	HEV	09013-6C600-01	LONG BALL HEXAGON WRENCH 5MM	14
01418-00109 (A704)	CELL VOLTAGE INTERFACE	HEV	09013-7C310	10MM BI-HEXAGON SOCKET (1/2 INCH DRIVE)	1
01418-00110 (A705)	TEMPERATURE SENSOR INTERFACE	HEV	09032-00100	GASKET SEAL CUTTER	1
01418-00111 (A706)	CELL VOLTAGE AND TEMPERATURE SENSOR INTERFACE	HEV	09043-20060	SOCKET HEXAGON WRENCH 6MM	1
01418-00112 (A707)	UNIVERSAL CELL VOLTAGE BCU CABLE	HEV	09043-20080	SOCKET HEXAGON WRENCH 8MM	1
01418-00113 (A708)	UNIVERSAL TEMPERATURE BCU CABLE	HEV	09043-88010	HEXAGON 8MM ALLEN SOCKET	1
01418-00114 (A709)	VOLTAGE BCU CABLE	HEV	09213-38010-01	CRANKSHAFT HOLDING TOOL	5
01421-00151	3K LIFT TABLE	IN SHOP	09213-54015-02	CRANKSHAFT PULLEY HOLDING TOOL	15
*01717-00122	TPWS TESTER	23	09213-58013-01	CRANKSHAFT PULLEY HOLDING TOOL	1
*01717-00123	OBD-II DONGLE	23	09213-58014-01	CRANKSHAFT PULLEY HOLDING TOOL	1
*01717-00124	POWER SUPPLY	23	09213-70011	CRANKSHAFT PULLEY HOLDING TOOL	5
*01717-00125	USB CABLE	23	09213-70011-01	CRANKSHAFT PULLEY HOLDING TOOL	5
*01717-00126	MAGNET	23	*09214-00011-01	BOLT (2) M8 X 1.25 X 120	15
*01717-00127	RJ45 CABLE	23	*09214-00021-01	BOLT (2) M8 X 1.25 X 110	15
01813-00034	SOCKET-8MM STD 3/8", 6 PT	HEV	*09214-00030-01	BOLT (2) M6 X 1.0 X 85	15
01813-00035	SOCKET-10MM STD 3/8", 6 PT	HEV	*09216-00021	BELT TENSION GAUGE	3
01813-00036	SOCKET-12MM STD 3/8", 6 PT	HEV	*09216-00030	BELT TENSION CABLE	3
01813-00037	SOCKET-14MM STD 3/8", 6 PT	HEV	09222-30010	CONNECTING ROD BUSHING REMOVER/REPLACER	20
01813-00038	SOCKET-8MM DP 3/8", 6 PT	HEV	09223-15020	CRANKSHAFT REAR OIL SEAL REPLACER	20
01813-00039	SOCKET-10MM DP 3/8", 6 PT	HEV	09223-15030	CRANKSHAFT REAR OIL SEAL REPLACER	20
01813-00040	SOCKET-12MM DP 3/8", 6 PT	HEV	09223-46011	CRANKSHAFT FRONT OIL SEAL REPLACER	20
01813-00041	SOCKET-14MM DP 3/8", 6 PT	HEV	09223-51010-01	CRANKSHAFT FRONT OIL SEAL INSTALLER	11
01813-00042	10MM MAGNETIC EXTENSION	HEV	09223-56010-01	CRANKSHAFT REAR OIL SEAL REPLACER	20
01813-00043	TORQUE WRENCH 3/8"	HEV	09224-50011-01	FLEXIBLE EXHAUST HOLDING TOOL	16
01813-00044	RATCHET 3/8"	HEV	09228-06500-02A	OIL FILTER WRENCH	1
01813-00045	3/8" X 6" EXTENSION	HEV	09228-07502	OIL FILTER WRENCH	1
01813-00046	3/8" X 3" EXTENSION	HEV	09249-37010-01	VVT SET BOLT WRENCH	11
01813-00047	#2 X 6" PHILLIPS SCREWDRIVER	HEV	09249-63010	TORQUE WRENCH ADAPTER	12
01813-00048	#1 X 6" PHILLIPS SCREWDRIVER	HEV	09260-39015-01	INJECTOR SEAL TOOL SET	1
01813-00049	3/16" X 6" CABINET TIP SCREWDRIVER	HEV	09260-39021-01	INJECTOR SEAL TOOL SET	1
01813-00050	5/16" X 6" FLAT TIP SCREWDRIVER	HEV	09260-39030-01	INJECTOR SEAL TOOL SET	1
01813-00051	7" DIAGONAL CUTTERS	HEV	09260-39040-01	INJECTOR SEAL TOOL SET	1
01813-00052	8" NEEDLE NOSE PLIER	HEV	09260-48010-01	FUEL INJECTOR REMOVER	9
01813-00053	6" NEEDLE NOSE PLIER	HEV	09260-48020-01	DELIVERY PIPE GUIDE PIN	9
01813-00054	MAGNETIC PICKUP TOOL	HEV	*09261-03011-01	HOLDER	1
01813-00055	FLASHLIGHT	HEV	*09261-03011-01	HOLDER	1
01813-00056	3/8" DRIVE EXT W/SCREWDRIVER HANDLE	HEV	*09261-03020-01	GUIDE	1
01813-00057	8MM MAGNETIC EXTENSION	HEV	*09261-03030-01	GUIDE	1
01813-00058	NUTSTARTER - COMPOSITE	HEV	*09268-00020-01	T-JOINT	15
			*09268-00030-01	FUEL TUBE CONNECTOR	15

* This tool is a component of an essential kit.

Part Number References

TOOL #	TOOL DESCRIPTION	DRAWER #	TOOL #	TOOL DESCRIPTION	DRAWER #
*09268-03010	HOLDER	1	09330-00021	COMPANION FLANGE HOLDING TOOL	2
*09268-03020	GUIDE	1	*09330-00030	PIN	2
*09268-08070-01	HOSE	15	09330-50010	PROPELLER SHAFT CENTER BEARING REPLACER	2
*09268-27011	NO. 2 UNION	15	09387-00090	BEARING RETAINER INSTALLER	5
09268-41047-02	INJECTION MEASURING TOOL SET	15	09509-25011-01	REAR AXLE BEARING LOCKNUT WRENCH	12
*09268-41061	NO. 3 UNION	15	09520-01010-02	DRIVE SHAFT REMOVER	13
*09268-41071	NO. 4 UNION	15	09520-10021	TRANS HOUSING REMOVER	4
*09268-41081	NO. 6 UNION	15	09520-32012-01	DIFFERENTIAL SIDE GEAR SHAFT PULLER	11
*09268-41091	NO. 7 UNION	15	09521-24010	DRIVE SHAFT BOOT CLAMPING TOOL	13
*09268-41100	CLAMP	15	09521-25011-01	REAR AXLE SHAFT PULLER	5
*09268-41110	ADAPTER	15	09521-26000-01	REAR AXLE SHAFT PULLER SPACER	12
*09268-41120	3-WAY	15	09521-60010-01	REAR AXLE SHAFT PULLER ADAPTER	13
*09268-41130	ADAPTER	15	09521-60020-01	REAR AXLE TOOL NO. 3	9
*09268-41140	ADAPTER	15	09564-50010-01	DIFFERENTIAL PRELOAD ADAPTER	1
*09268-41160	ADAPTER	15	*09570-01011	NUT & BOLT SET (QTY. 2)	10
*09268-41250-01	T-JOINT	15	09570-22011	DIFFERENTIAL MOUNT SERVICE TOOL	5
*09268-41260-01	EFI FUEL PRESSURE GAUGE ASSEMBLY	15	09570-24010	DIFFERENTIAL MOUNTING CUSHION REMOVER	
*09268-41280-01	HOSE JOINT	15		AND REPLACER	10
*09268-41300	CLAMP	15	09570-48010-01	DIFFERENTIAL MOUNTING CUSHION REMOVER	
*09268-41310	CLAMP	15		AND REPLACER	3
*09268-41400	CLAMP	15	09572-50010	DIFFERENTIAL MOUNTING CUSHION HOLDING TOOL	11
*09268-41500	CLAMP	15	09607-60020-01	FRONT WHEEL ADJUSTING NUT WRENCH	13
*09268-41500-01	FUEL TUBE CONNECTOR	15	09608-04031	INNER BEARING CONE REPLACER	12
*09268-41600	ADAPTER	15	09608-06041	FRONT HUB INNER BEARING CONE REPLACER	13
*09268-41700-01	HOSE BANDS (6)	15	09608-10010-01	STEERING KNUCKLE OIL SEAL REPLACER	10
*09268-43080-01	UNION, M8	15	09608-32010	STEERING KNUCKLE OIL SEAL REPLACER	10
*09268-43100-01	UNION, M10	15	09610-20012-01	PITMAN ARM PULLER	12
*09268-43120-01	UNION, M12	15	09612-00012-01	RACK AND PINION HOLDING TOOL	12
*09268-44080-01	ADAPTER, M8	15	09613-22011	STEERING RACK SHAFT BUSHING PULLER	12
*09268-44100-01	ADAPTER, M10	15	09616-00010-02	STEERING WORM BEARING ADJUSTING SOCKET	12
*09268-44120-01	ADAPTER, M12	15	09616-00020-01	STEERING WORM BEARING ADJUSTING SOCKET	12
09268-45101-1A	EFI FUEL PRESSURE GAUGE SET	15	09628-00011-01	BALL JOINT PULLER	13
*09268-52011	INJECTION MEASURING ATTACHMENT	15	09628-50010-01	BALL JOINT PULLER	20
09276-75010-01	HYDRAULIC LASH ADJUSTER	1	09628-62011-01	BALL JOINT PULLER	12
*09285-76010	INJECTION PUMP CAMSHAFT BEARING		09631-10021-01	RACK AND PINION STOPPER ADJUSTMENT TOOL	12
	CONE REPLACER	15	09631-12071	STEERING RACK OIL SEAL TEST TOOL	12
*09286-46011	ALTERNATOR PULLEY PULLER	15	09631-12090	SEAL RING TOOL	2
09307-12010	EXTERNAL HOUSING BUSHING REPLACER	1	09631-32020	SEAL RING TOOL	12
09308-00010	OIL SEAL PULLER	3	09636-20010	UPPER BALL JOINT DUST COVER REPLACER	10
09318-12010-4PIN	4 PIN FRONT WHEEL BEARING LOCK NUT SOCKET KIT	10	09650-17011	HUB BOLT REMOVER	13
*09318-12010-INST	PIN INSTALLER/REMOVER	10	09650-53010-01	WHEEL GUIDE PINS	1
*09318-12010-PINS	SOCKET PIN SET (QTY. 4)	10	09709-00002	BRAKE PEDAL FORCE GAUGE	20
*09318-12010-SOCK	4 PIN FRONT WHEEL BEARING LOCK NUT SOCKET	10	*09709-00060	NO. 1 NIPPLE	20
*09322-03010-01	INPUT SHAFT HOLDING SOCKET	2	*09709-00070	NO. 2 NIPPLE	20
*09322-03020-01	INPUT SHAFT HOLDING JOINT BAR	2	*09709-00080	NO. 3 NIPPLE	20
*09322-03030-01	INPUT SHAFT HOLDING PLATE	2	09709-29018	LSPV GAUGE SET	20
09322-35010-01	INPUT SHAFT HOLDING TOOL SET	2	*09709-35010	LSPV GAUGE ADAPTER	20
09325-40010-01	TRANSMISSION OIL PLUG	1	*09710-00011	REPLACER	7
09326-03020-01	SOCKET ADAPTER	2	*09710-00021	PIPE	7
09326-35020-01	OUTPUT SHAFT ADJUSTING NUT WRENCH	2	*09710-00031	REPLACER	7

* This tool is a component of an essential kit.

Part Number References

TOOL #	TOOL DESCRIPTION	DRAWER #	TOOL #	TOOL DESCRIPTION	DRAWER #
*09710-00041	PIPE	7	*09726-01041	SEAT	11
*09710-00061	REPLACER	7	*09726-01052	SPACER	11
*09710-02041	REMOVER	6	09726-10011	LOWER SUSPENSION ARM BUSHING REMOVER/REPLACER	11
*09710-02051	BASE	6	09726-12023	LOWER SUSPENSION ARM BUSHING REMOVER/REPLACER	11
*09710-02061	REPLACER	6	09727-58010-01	REBOUND SPRING ADJUST PULLER	14
*09710-02071	BUSHING REMOVER AND REPLACER	6	09727-58020-01	ADAPTER 12	14
*09710-03031	BUSHING REMOVER	8	09727-58030-01	ADAPTER 14	14
*09710-03041	BUSHING REMOVER BASE	8	09727-58100-01	SHOCK ROD HOLDING TOOL	14
*09710-03051	BUSHING REPLACER	8	09727-58110-01	ATTACHMENT 12	14
*09710-03061	BUSHING REPLACER BASE	8	09727-58120-01	ATTACHMENT 16	14
*09710-03071	BUSHING REMOVER	8	09727-58130-01	ATTACHMENT 22	14
*09710-03081	BUSHING REMOVER SPACER	8	09727-58140-01	ATTACHMENT 25	14
*09710-03091	BUSHING REMOVER BASE	8	09729-22031	FRONT SPRING UPPER SEAT HOLDER	10
*09710-03101	BUSHING REPLACER	8	09730-00010	AIR TUBE SEPARATOR	11
*09710-03111	BUSHING REMOVER	8	09730-00020	TUBE REMOVER	11
*09710-03121	BUSHING REMOVER BASE	8	09737-00013-01	BRAKE BOOSTER PUSH ROD GAUGE	18
09710-03130-02	LOWER ARM BUSHING REPLACER	13	09737-00020-01	BRAKE BOOSTER PUSH ROD WRENCH	18
*09710-03131	BUSHING REMOVER	8	09756-48020-1B	ELECTRONIC PARKING BRAKE RELEASE TOOL	6
*09710-03141	BUSHING REMOVER BASE	8	*09756-48040-01	EPB TOOL COMPONENT	6
*09710-05031	REMOVER	11	*09756-48050-01	EPB TOOL COMPONENT	6
*09710-05041	GATE	11	*09756-48060-01	EPB TOOL COMPONENT	6
*09710-05051	REMOVER	11	*09756-48070-01	EPB TOOL COMPONENT	6
*09710-05061	REPLACER	11	09760-60020	KDSS FLUID PRESSURE PUMP KIT	IN SHOP
*09710-05071	FRONT BASE	11	09761-50010-01	NITROGEN GAS INJECTION TOOL	17
*09710-05081	REAR BASE	11	*09761-05010-01	REGULATOR ASSY	17
*09710-07021	BUSHING REMOVER	7	*09761-05020-01	PORT ASSY	17
*09710-07031	BUSHING REPLACER	7	*09761-05030-01	CASE ASSY	17
*09710-07041	UPPER ARM BASE	7	09802-00010-02	ROOF LINE GAUGE	IN SHOP
*09710-07051	UPPER ARM BASE	7	09802-11010-01	FASTENER CLOSER	21
*09710-07062	BUSHING REPLACER	7	09802-11020-01	ACTIVE ROLL BAR PROTECTOR	21
*09710-07071	UPPER ARM SPACER	7	09803-00010-02	LUGGAGE DOOR LINK SUB-ASSEMBLY GAUGE	IN SHOP
*09710-07081	LOWER ARM SPACER	7	09803-10010-01	LUGGAGE DOOR HINGE ADJUSTING GAUGE	IN SHOP
*09710-08021	BUSHING REMOVER	11	09804-24010	LUGGAGE COMPARTMENT TOOL SET	22
*09710-08031	BASE	11	09808-14031-KIT	FUEL SENDER LOCK NUT WRENCH	9
*09710-08041	BUSHING REMOVER	11	09808-14040-01	FUEL PUMP RETAINER TOOL	22
09710-14013-02	REAR SUSPENSION BUSHING TOOL SET	7	09808-14050-01	FUEL PUMP HOLDING TOOL	22
09710-22042-02	REAR SUSPENSION BUSHING TOOL SET	6	09812-00010	DOOR HINGE SET BOLT WRENCH (12MM)	21
09710-26011-02	FRONT SUSPENSION BUSHING TOOL SET	11	09813-00020	PILLAR GARNISH CLIP TOOL	9
09710-28012-01	FRONT SUSPENSION BUSHING TOOL SET	7	09817-33190-01	STRUT SENSOR SOCKET	11
09710-28021	FRONT SUSPENSION BUSHING TOOL SET	11	*09820-63010-02	INSERT	22
09710-30021-02	SUSPENSION BUSHING TOOL SET	8	09820-63020-02	ALTERNATOR CLUTCH HOLDING TOOL SET	22
09710-30050	SUSPENSION ARM BUSHING REPLACER	11	*09842-30050	WIRING "A" EFI INSPECTION	15
09710-50010	SUSPENSION BUSHING SPACER	11	*09842-30055	WIRING "G" EFI INSPECTION	15
*09726-00011	REMOVER	11	*09842-30070	WIRING "F" EFI INSPECTION	15
*09726-00021	REPLACER	11	*09843-18020	DIAGNOSIS CHECK WIRING	15
*09726-00031	SPACER	11	09843-18040	DIAGNOSIS CHECK WIRE #2	21
*09726-00041	SEAT	11	09843-18050	NAVIGATIONAL WIRING HARNESS	21
*09726-01011	REMOVER	11	09843-18061	SRS CHECK WIRE	21
*09726-01021	REPLACER	11			
*09726-01031	SPACER	11			

* This tool is a component of an essential kit.

Part Number References

TOOL #	TOOL DESCRIPTION	DRAWER #	TOOL #	TOOL DESCRIPTION	DRAWER #
09870-00005-02	A/C LINE DISCONNECT KIT	22	*09951-00230-01	REPLACER 23	4
*09870-00015	LOW SIDE A/C LINE DISCONNECT TOOL	22	*09951-00240-01	REPLACER 24	4
*09870-00025	HIGH SIDE A/C LINE DISCONNECT TOOL	22	*09951-00250-01	REPLACER 25	4
09870-60000	LASER RADAR ADJUSTING REFLECTOR	IN SHOP	*09951-00260-01	REPLACER 26	4
09870-60040-02	REFLECTOR C	6	*09951-00270-01	REPLACER 27	4
09870-60060-01	STAND SUPPORT	IN SHOP	*09951-00280-01	REPLACER 28	4
09870-61100-01	TARGET BOARD NO. 1	IN SHOP	*09951-00290-01	REPLACER 29	4
09870-62100-01	TARGET SHEET NO. 1	IN SHOP	*09951-00300-01	REPLACER 30	4
09870-62200-01	TARGET SHEET NO. 2	IN SHOP	*09951-00310-01	REPLACER 31	4
09870-DYEKIT	A/C DYE INJECTION TOOL KIT	23	*09951-00320-01	REPLACER 32	4
09872-50040	CABLE, ETHERNET CHECK, NO 1	21	*09951-00330-01	REPLACER 33	4
09890-47010-01	ANTI-STATIC MAT SET	4	*09951-00340-01	REPLACER 34	4
*09891-04010-01	ANTI-STATIC MAT	4	*09951-00350-01	REPLACER 35	4
*09891-04020-01	WRIST BAND	4	*09951-00360-01	REPLACER 36	4
*09891-04030-01	GROUNDING WIRE NO.1	4	*09951-00370-01	REPLACER 37	4
*09891-04040-01	GROUNDING WIRE NO.2	4	*09951-00380-01	REPLACER 38	4
*09891-47010-01	SQUEEGEE	4	*09951-00390-01	REPLACER 39	4
09893-00020-01	GUIDE PINS	12	*09951-00400-01	REPLACER 40	4
09893-10060-01	A/C LEAK TEST ADAPTER (HIGH)	12	*09951-00410-01	REPLACER 41	4
09893-10070-01	A/C LEAK TEST ADAPTER (LOW)	12	*09951-00420-01	REPLACER 42	4
09893-42010-01	BATTERY HANGER	12	*09951-00430-01	REPLACER 43	4
09893-42040-01	BATTERY HANGER 100MM	12	*09951-00440-01	REPLACER 44	4
09893-72010-01	LIFT ATTACHMENTS	16	*09951-00450-01	REPLACER 45	4
*09898-00020-01	ATTACHMENT B	IN SHOP	*09951-00460-01	REPLACER 46	4
09910-00015-02	PULLER SET	8	*09951-00470-01	REPLACER 47	4
*09911-00011	PULLER CLAMP	8	*09951-00480-01	REPLACER 48	4
*09912-00010	PULLER SLIDE HAMMER	8	*09951-00490-01	REPLACER 49	4
*09913-00010	MAIN DRIVE GEAR PULLER ATTACHMENT	8	*09951-00500-01	REPLACER 50	4
*09914-00011	REAR AXLE SHAFT PULLER ATTACHMENT	8	*09951-00510-01	REPLACER 51	4
*09915-00010	SPLINE SHAFT PULLER ATTACHMENT	8	*09951-00520-01	REPLACER 52	4
*09916-00010	REVERSE IDLER GEAR SHAFT PULLER ATTACHMENT	8	*09951-00530-01	REPLACER 53	4
*09917-00011	PULLER ATTACHMENT	8	*09951-00540-01	REPLACER 54	4
*09918-00010	EXTENSION HOUSING BEARING PULLER	8	*09951-00550-01	REPLACER 55	4
*09919-00010	CASE	8	*09951-00560-01	REPLACER 56	4
09922-10010-01	VARIABLE OPEN WRENCH	12	*09951-00570-01	REPLACER 57	4
09929-00020-01	CRIMPING TOOL S	9	*09951-00580-01	REPLACER 58	4
09930-00010-01	DRIVE SHAFT NUT CHISEL	12	*09951-00590-01	REPLACER 59	4
09950-00020	BEARING REMOVER	13	*09951-00600-01	REPLACER 60	4
09950-00040-01	JOINT, BEARING REMOVER	2	*09951-00610-01	REPLACER 61	4
09950-30012-02	UNIVERSAL PULLER SET "A"	17	*09951-00620-01	REPLACER 62	4
09950-40011-02	UNIVERSAL PULLER SET "B"	8	*09951-00630-01	REPLACER 63	4
09950-50013-02	UNIVERSAL PULLER SET "C"	6	*09951-00640-01	REPLACER 64	4
09950-60010-02	REPLACER SET #1	4	*09951-00650-01	REPLACER 65	4
09950-60020-02	REPLACER SET #2	23	*09951-00680-01	REPLACER 68	23
09950-60030-01	REPLACER SET #3	10	*09951-00710-01	REPLACER 71	23
*09951-00180-01	REPLACER 18	4	*09951-00720-01	REPLACER 72	23
*09951-00190-01	REPLACER 19	4	*09951-00730-01	REPLACER 73	23
*09951-00200-01	REPLACER 20	4	*09951-00750-01	REPLACER 75	10
*09951-00210-01	REPLACER 21	4	*09951-00770-01	REPLACER 77	10
*09951-00220-01	REPLACER 22	4	*09951-00780-01	REPLACER 78	23

* This tool is a component of an essential kit.

Part Number References

TOOL #	TOOL DESCRIPTION	DRAWER #	TOOL #	TOOL DESCRIPTION	DRAWER #
*09951-00790-01	REPLACER 79	23	*09955-05020-01	ADAPTER NO. 2	6
*09951-00810-01	REPLACER 81	10	*09955-05030-01	ADAPTER NO. 3	6
*09951-00890-01	REPLACER 89	23	*09955-05040-01	ADAPTER NO. 4	6
*09951-00900-01	REPLACER 90	10	*09956-03010-01	ADAPTER 16MM	17
*09951-00910-01	REPLACER 91	23	*09956-03020-01	ADAPTER 18MM	17
*09951-01000-01	REPLACER 100	10	*09956-03030-01	ADAPTER 20MM	17
*09951-01030-01	REPLACER 103	10	*09956-03040-01	ADAPTER 22MM	17
*09951-01100-01	REPLACER 110	10	*09956-03050-01	ADAPTER 24MM	17
*09951-03010-01	PULLER HEAD	17	*09956-03060-01	ADAPTER 26MM	17
*09951-04010	HANGER 150	8	*09956-03070-01	ADAPTER 28MM	17
*09951-04020	HANGER 200	8	*09956-03080-01	ADAPTER 10MM	17
*09951-05010	HANGER 150	6	*09957-04010	ATTACHMENT	8
09951-07100-01	HANDLE ASSEMBLY 100 - 4.25"	1	*09958-04011	HOLDER	8
09951-07150-01	HANDLE ASSEMBLY 150 - 6.25"	1	*09959-04010	CASE	8
09951-07200-01	HANDLE ASSEMBLY 200 - 8.25"	1	09960-10010	VARIABLE PIN WRENCH SET	2
09951-07360-01	HANDLE ASSEMBLY 360 - 14.625"	1	09960-20010-01	BALL JOINT PULLER	5
*09952-04010	SLIDE ARM	8	*09961-00010	CASE	2
*09952-05010	SLIDE ARM	6	*09961-00020	HOLDER ASSEMBLY	2
*09952-06010-01	ADAPTER	4	09961-00950	TORQUE WRENCH ADAPTER	12
*09953-03010-01	FORCING SCREW	17	*09962-00010	ARM A	2
*09953-04010	CENTER BOLT 100	8	*09962-00020	ARM B	2
*09953-04020	CENTER BOLT 150	8	*09962-01000	VARIABLE PIN WRENCH ARM ASSEMBLY	2
*09953-04030	CENTER BOLT 200	8	*09963-00350	PIN 3.5	2
*09953-05010	CENTER BOLT 100	6	*09963-00400	PIN 4	2
*09953-05020	CENTER BOLT 150	6	*09963-00450	PIN 4.5	2
*09954-03010-01	PULLER LEG (SET OF 3)	17	*09963-00500	PIN 5	2
*09954-04010	ARM 25	8	*09963-00600	PIN 6	2
*09954-04020	ARM 100	8	*09963-00700	PIN 7	2
*09954-04030	ARM 150	8	*09963-01000	PIN 10	2
*09954-04040	ARM 200	8	*09989-00010-01	ATTACHMENT A	IN SHOP
*09954-05010	CLAW NO. 1	6	*09989-0010-L	ATTACHMENT A (LONG)	IN SHOP
*09954-05020	CLAW NO. 2	6	09991-00610	NIGHT VIEW INSPECTION TOOL	21
*09954-05030	CLAW NO. 3	6	09992-00095-02	TRANSMISSION OIL PRESSURE GAUGE SET	8
*09954-05040	CLAW NO. 4	6	*09992-00151	ADAPTER	8
*09954-05050-01	CLAW NO. 5	6	*09992-00231	CURVED ADAPTER	8
*09954-05060-01	CLAW NO. 6	6	*09992-00271	GAUGE ASSEMBLY	8
*09954-05070	CLAW NO. 7	6	*09992-00280	GASKET	8
*09954-05080	CLAW NO. 8	6	*09992-00290	GASKET	8
*09955-03011-01	PULLER JAW (SET OF 2)	17	*09992-00301	O-RING	8
*09955-03021-01	PULLER JAW (SET OF 3)	17	09992-00350-01	ABS TRAC ACTUATOR AIR BLEED TOOL	18
*09955-03030-01	LOWER PLATE 130MM	17	*09993-01010	OVERFLOW LEVEL GAUGE	17
*09955-03040-01	LOWER PLATE 150MM	17	*09993-01020	VACUUM REGULATOR	17
*09955-04011	CLAW NO. 1	8	*09993-01030	FILLER PLUG ADAPTER	17
*09955-04021	CLAW NO. 2	8	09993-01100	18MM ADAPTER	1
*09955-04031	CLAW NO. 3	8	09993-01110	10MM ADAPTER	1
*09955-04041	CLAW NO. 4	8	09993-01120	ADAPTER, FILLER PLUG EXTENSION	1
*09955-04051	CLAW NO. 5	8	09993-19025	OVERFLOW LEVEL GAUGE SET	17
*09955-04061	CLAW NO. 6	8	*09993-20010	TANK ASSEMBLY	17
*09955-04071-01	CLAW NO. 7	8	09999-00210	MASTER WHEEL LOCK KEY SET	18
*09955-05010-01	ADAPTER NO. 1	6	09999-00300	SPARE TIRE LOCK KEY SET	18

* This tool is a component of an essential kit.

Drawer Liner Reference


TOOL #	TOOL DESCRIPTION	DRAWER #	TOOL #	TOOL DESCRIPTION	DRAWER #
09999-00410	TRD MASTER KEY SET	18	*PP691-1	PROTECTIVE RUBBER BOOT AND HOOK FOR PS4X24 SCOPES	8
09999-00610	WHEEL LOCK MASTER KEY SET SUPPLEMENT	9	*TA000-2	BNC TO 4MM TEST LEADS 3M, BLACK	8
11014-00007	ANTENNA TEST KIT	17	*TA001-1	MULTI-METER PROBE - BLACK	8
11021-00027	TERMINAL GAUGE TOOL	19	*TA002-1	MULTI-METER PROBE - RED	8
11216-00011	ENGINE BLOCK OIL PLUG REPAIR	20	*TA003-1	SMALL CROCODILE CLIP BLACK	8
11413-00005	MILLIOHM METER KIT	HEV	*TA004-1	SMALL CROCODILE CLIP RED	8
11717-00012	TPWS TESTER KIT	23	*TA005-1	DOLPHIN CLIP - BLACK	8
*11815-00009	DIGITAL ANGLE GAUGE KIT	IN SHOP	*TA006-1	DOLPHIN CLIP - RED	8
11816-00010	RADAR SENSOR CALIBRATION KIT	IN SHOP	*TA008-1	BACK-PINNING PROBES	8
11819-00026	TERMINAL REMOVAL TOOL KIT	19	*TA010-1	20:1 ATTENUATOR	8
*2002019	TESTER	8	*TA018-1	20/60A CLAMP	8
*217396	ADAPTER	8	*TA019-1	600A CLAMP	8
*2-02765A	BLOW MOLDED CASE	8	*TA030-1	CABLE IDENTIFIER KIT (5MM)	8
*2-11142A	DLC 1/2 CABLE SET (W/POWER CABLE)	8	*TA034-1	FUSE BREAKOUT ATC	8
*2-11242A	TRIGGER SWITCH CABLE	8	*TA035-1	FUSE BREAKOUT MINI	8
*307313	CARRYING CASE	20	*TA081	USB TO MINI-USB CHARGING CABLE	8
*308342	STORAGE CASE	8	*TA125, 126, 127, 128-4	BNC TO 4MM, 3M (10FT) PREMIUM, BLUE, RED, GREEN, YELLOW	8
*3-04006A	DVD DRIVE SET	8	*TA129	UNIVERSAL VACUUM HOSE ADAPTER	8
*3-05206A02	STYLUS (W/RETAINING CORD)	8	*TA130	CABLE: INSULATED BNC TO INSULATED BNC 5M	8
*3-05206A04	SCREEN PROTECTOR	8	*TA071	WPS500X PRESSURE TRANSDUCER	8
541808	MAGNETIC CAR TOPPER, HIGH VOLTAGE (2)	HEV	*TA085	VACUUM HOSE ADAPTER	8
*90119-08216	BOLT M8 X 1.25 X 90	15	*TA086	BLEED HOSE	8
*90155-60003	SCREW	4	*TA087	EXHAUST ADAPTER	8
*90179-10016	NUT	2	*TA142	FOSTER 2 SERIES 1/8" COUPLER W/VALVE, MALE NPT	8
*90201-15012	WASHER (QTY. 4)	10	*TA212	STANDARD COMPRESSION HOSE	8
*90405-09015	NO. 1 UNION	15	*TA216	12MM DEEP REACH ADAPTER TIP	8
*90467-13001	CLIP	15	*TA217	14MM SHORT REACH ADAPTER TIP	8
*90480-01601	GROMMET	2	*TA218	14MM DEEP REACH ADAPTER TIP	8
*90480-13005	GROMMET	2	*TA456	ADAPTER, RECTUS TO WPS500X	8
*91111-51014	BOLT	8	*TA457	HOSE, TMS OIL PRESSURE CANISTER ADAPTER HOSE	8
*91551-80650-01	BOLT (2)	15	*TA458	TMS FUEL HOSE KIT (09268-45015-01) TO WPS500X ADAPTER	8
*91651-60855-01	BOLT	15	*TA459	TMS FUEL HOSE ADAPTER (NIPPLE TIP)	8
95079-00003-KIT	NAVIGATION UPDATE TOOL KIT	17	*TA460	TMS FUEL HOSE KIT (09268-45101-1A) (TAPERED TIP)	8
*95079-00790	HDD NAVIGATION UPDATE	17	TLBEV-00001	LIFT STRAPS	16
*95079-12280	USB CABLE 3.0	17	TS2PS2CH-REQ	PICOSCOPE KIT 2-CHANNEL	8
*95079-12300	VEHICLE EXCHANGE CABLE	17	TS2PS4CH-UPG	PICOSCOPE KIT 4-CHANNEL	8
*95171-10321	AC POWER ADAPTER	17	TSADVUNIT	TECHSTREAM ADVI	IN SHOP
*95333-06030	HOSE	15			
*95336-08070	HOSE	15			
*96150-02000	C-RING	15			
DCA-8000P T	DIAGNOSTIC CHARGER	IN SHOP			
DSS-5000P T	HANDHELD TESTER	IN SHOP			
ESUPPT-HOOK3	ENGINE SUPPORT BAR HOOK SET NO. 3	IN SHOP			
KP355	PICO PRESSURE TRANSDUCER	8			
N/A	USB NAVIGATION AND FIRMWARE UPDATE	1			
*PA179	TMS BRANDED CARRY CASE	8			
*PP972	VACUUM TAP FOR WPS500X	8			
*PP973	FUEL HOSE PRESSURE TAP (SMALL)	8			
*PP974	FUEL HOSE PRESSURE TAP (MEDIUM)	8			
*PP207-1	STANDARD CASE	8			

Drawer Liner Reference

TOOLS

- 00002-12001-01 VEHICLE DRAIN TUBE AUGER
- 09213-38010-01 CRANKSHAFT HOLDING TOOL
- 09213-70011-01 CRANKSHAFT PULLEY HOLDING TOOL
- 09387-00090 BEARING RETAINER INSTALLER
- 09521-25011-01 REAR AXLE SHAFT PULLER
- 09570-22011 DIFFERENTIAL MOUNT SERVICE TOOL
- 09960-20010-01 BALL JOINT PULLER


DRAWER 5



TOOLS

- 09710-22042-02 REAR SUSPENSION BUSHING TOOL SET
- 09756-48020-1B ELECTRONIC PARKING BRAKE RELEASE TOOL
- 09870-60040-02 REFLECTOR C
- 09950-50013-02 UNIVERSAL PULLER SET "C"

DRAWER 6




Drawer Liner Reference

TOOLS

09260-48010-01	FUEL INJECTOR REMOVER
09260-48020-01	DELIVERY PIPE GUIDE PIN
009521-60020-01	REAR AXLE TOOL NO. 3
09808-14031-KIT	FUEL SENDER LOCK NUT WRENCH
09813-00020	PILLAR GARNISH CLIP TOOL
09929-00020-01	CRIMPING TOOL S
09999-00610	WHEEL LOCK MASTER KEY SET SUPPLEMENT


DRAWER 9



TOOLS

09318-12010-4PIN	4 PIN FRONT WHEEL BEARING LOCK NUT SOCKET KIT
09570-24010	DIFFERENTIAL MOUNTING CUSHION REMOVER AND REPLACER
09608-10010-01	STEERING KNUCKLE OIL SEAL REPLACER
09608-32010	STEERING KNUCKLE OIL SEAL REPLACER
09636-20010	UPPER BALL JOINT DUST COVER REPLACER
09729-22031	FRONT SPRING UPPER SEAT HOLDER
09951-00750-01	REPLACER 75
09951-00770-01	REPLACER 77
09951-00810-01	REPLACER 81
09951-00900-01	REPLACER 90
09951-01000-01	REPLACER 100
09951-01030-01	REPLACER 103
09951-01100-01	REPLACER 110

DRAWER 10



Drawer Liner Reference

TOOLS

























07112-66040-01
09223-51010-01
09249-37010-01
09520-32012-01
09572-50010

09710-05031
09710-05041
09710-05051
09710-05061
09710-05071
09710-05081
09710-08021
09710-08031
09710-08041
09710-30050
09710-50010
09726-00011
09726-00021
09726-00031
09726-00041
09726-01011
09726-01021
09726-01031
09726-01041
09726-01052
09730-00010
09730-00020
09817-33190-01

PRESSURE PLATE REMOVER
CRANKSHAFT FRONT OIL SEAL INSTALLER
VVT SET BOLT WRENCH
DIFFERENTIAL SIDE GEAR SHAFT PULLER
DIFFERENTIAL MOUNTING CUSHION HOLDING TOOL

REMOVER
GATE
REMOVER
REPLACER
FRONT BASE
REAR BASE
BUSHING REMOVER
BASE
BUSHING REMOVER
SUSPENSION ARM BUSHING REPLACER
SUSPENSION BUSHING SPACER
REMOVER
REPLACER
SPACER
SEAT
REMOVER
REPLACER
SPACER
SEAT
REMOVER
REPLACER
SPACER
SEAT
SPACER
GATE
AIR TUBE SEPARATOR
TUBE REMOVER
STRUT SENSOR SOCKET

DRAWER 11






















<p>09710-05081 REAR BASE COMPONENT OF (09710-20010-02) 09710-20011-02 FRONT SUSPENSION BUSHING TOOL SET</p> 	<p>09710-06071 FRONT BASE COMPONENT OF (09710-20010-02) 09710-20011-02 FRONT SUSPENSION BUSHING TOOL SET</p> 	<p>09710-05061 REPLACER COMPONENT OF (09710-20010-02) 09710-20011-02 FRONT SUSPENSION BUSHING TOOL SET</p> 	<p>09710-05051 REMOVER COMPONENT OF (09710-20010-02) 09710-20011-02 FRONT SUSPENSION BUSHING TOOL SET</p> 	<p>09710-05041 GATE COMPONENT OF (09710-20010-02) 09710-20011-02 FRONT SUSPENSION BUSHING TOOL SET</p> 	<p>09710-05031 REMOVER COMPONENT OF (09710-20010-02) 09710-20011-02 FRONT SUSPENSION BUSHING TOOL SET</p> 	<p>09726-01052 SPACER COMPONENT OF (09726-10022) 09726-10023 LOWER SUSPENSION ARM BUSHING REMOVER / REPLACER</p> 	<p>09726-01041 SEAT COMPONENT OF (09726-10022) 09726-10023 LOWER SUSPENSION ARM BUSHING REMOVER / REPLACER</p> 	<p>09726-01031 SPACER COMPONENT OF (09726-10022) 09726-10023 LOWER SUSPENSION ARM BUSHING REMOVER / REPLACER</p> 	<p>09726-01021 REPLACER COMPONENT OF (09726-10022) 09726-10023 LOWER SUSPENSION ARM BUSHING REMOVER / REPLACER</p> 	<p>09726-01011 REMOVER COMPONENT OF (09726-10022) 09726-10023 LOWER SUSPENSION ARM BUSHING REMOVER / REPLACER</p> 	<p>09520-32012-01 DIFFERENTIAL SIDE GEAR SHAFT PULLER</p> 	<p>09223-51010-01 CRANKSHAFT FRONT OIL SEAL INSTALLER</p> 	<p>09730-00020 TUBE REMOVER</p> 	<p>09730-00010 AIR TUBE SEPARATOR</p> 	<p>09710-08041 BUSHING REMOVER COMPONENT OF (09710-20020) 09710-20021 FRONT SUSPENSION BUSHING TOOL SET</p> 	<p>09710-08031 BASE COMPONENT OF (09710-20020) 09710-20021 FRONT SUSPENSION BUSHING TOOL SET</p> 	<p>09710-08021 BUSHING REMOVER COMPONENT OF (09710-20020) 09710-20021 FRONT SUSPENSION BUSHING TOOL SET</p> 	<p>09249-37010-01 VVT SET BOLT WRENCH</p> 	<p>07112-66040-01 PRESSURE PLATE REMOVER</p> 	<p>09726-00041 SEAT COMPONENT OF (09726-10022) 09726-10011 LOWER SUSPENSION ARM BUSHING REMOVER / REPLACER</p> 	<p>09726-00031 SPACER COMPONENT OF (09726-10022) 09726-10011 LOWER SUSPENSION ARM BUSHING REMOVER / REPLACER</p> 	<p>09726-00021 REPLACER COMPONENT OF (09726-10022) 09726-10011 LOWER SUSPENSION ARM BUSHING REMOVER / REPLACER</p> 	<p>09726-00011 REMOVER COMPONENT OF (09726-10022) 09726-10011 LOWER SUSPENSION ARM BUSHING REMOVER / REPLACER</p> 
---	--	--	---	--	--	--	--	--	--	--	---	---	---	---	---	--	--	---	--	--	--	--	--

TOOLS

00002-90080
09249-63010
09509-25011-01
09521-26000-01
09608-04031
09610-20012-01
09612-00012-01
09613-22011
09616-00010-02
09616-00020-01
09628-62011-01
09631-10021-01
09631-12071
09631-32020
09893-00020-01
09893-10060-01
09893-10070-01
09893-42010-01
09893-42040-01
09922-10010-01
09930-00010-01
09961-00950

SUBFRAME ALIGNMENT PINS
TORQUE WRENCH ADAPTER
REAR AXLE BEARING LOCKNUT WRENCH
REAR AXLE SHAFT PULLER SPACER
INNER BEARING CONE REPLACER
PITMAN ARM PULLER
RACK AND PINION HOLDING TOOL
STEERING RACK SHAFT BUSHING PULLER
STEERING WORM BEARING ADJUSTING SOCKET
STEERING WORM BEARING ADJUSTING SOCKET
BALL JOINT PULLER
RACK AND PINION STOPPER ADJUSTMENT TOOL
STEERING RACK OIL SEAL TEST TOOL
SEAL RING TOOL
GUIDE PINS
A/C LEAK TEST ADAPTER (HIGH)
A/C LEAK TEST ADAPTER (LOW)
BATTERY HANGER
BATTERY HANGER 100MM
VARIABLE OPEN WRENCH
DRIVE SHAFT NUT CHISEL
TORQUE WRENCH ADAPTER

DRAWER 12


<p>00002-90080 SUBFRAME ALIGNMENT PINS</p> 	<p>09831-10021-01 RACK & PINION STOPPER ADJUSTMENT TOOL</p> 	<p>09816-00020-01 STEERING WORM BEARING ADJUSTING SOCKET</p> 	<p>09893-42010-01 BATTERY HANGER</p> 	<p>09893-00020-01 GUIDE PINS</p> 	<p>09893-10070-01 A/C LEAK TEST ADAPTER (LOW)</p> 	<p>09893-42040-01 BATTERY HANGER 100MM</p> 	<p>09610-20012-01 PITMAN ARM PULLER</p> 	<p>09249-63010 OR 09961-00950 TORQUE WRENCH ADAPTER</p> 	<p>09613-22011 STEERING RACK SHAFT BUSHING PULLER</p> 	<p>09631-32020 SEAL RING TOOL</p> 	<p>09922-10010-01 DRIVE SHAFT NUT CHISEL</p> 	<p>09893-10060-01 A/C LEAK TEST ADAPTER (HIGH)</p> 	<p>09893-10021-01 RACK & PINION HOLDING TOOL</p> 	<p>09893-42010-01 BATTERY HANGER</p> 	<p>09893-42040-01 BATTERY HANGER 100MM</p> 	<p>09616-00020-01 STEERING WORM BEARING ADJUSTING SOCKET</p> 	<p>09922-10010-01 DRIVE SHAFT NUT CHISEL</p> 	<p>09922-10010-01 DRIVE SHAFT NUT CHISEL</p> 	<p>09922-10010-01 DRIVE SHAFT NUT CHISEL</p> 	<p>09922-10010-01 DRIVE SHAFT NUT CHISEL</p> 
--	--	--	--	--	---	--	---	---	---	--	--	--	---	--	--	---	--	--	--	--

Drawer Liner Reference

TOOLS

- 09520-01010-02 DRIVE SHAFT REMOVER
- 09521-24010 DRIVE SHAFT BOOT CLAMPING TOOL
- 09521-60010-01 REAR AXLE SHAFT PULLER ADAPTER
- 09607-60020-01 FRONT WHEEL ADJUSTING NUT WRENCH
- 09608-06041 FRONT HUB INNER BEARING CONE REPLACER
- 09628-00011-01 BALL JOINT PULLER
- 09650-17011 HUB BOLT REMOVER
- 09710-03130-02 LOWER ARM BUSHING REPLACER
- 09950-00020 BEARING REMOVER


DRAWER 13



TOOLS

- 09013-6C600-01 LONG BALL HEXAGON WRENCH 5MM
- 09727-58010-01 REBOUND SPRING ADJUST PULLER
- 09727-58020-01 ADAPTER 12
- 09727-58030-01 ADAPTER 14
- 09727-58100-01 SHOCK ROD HOLDING TOOL
- 09727-58110-01 ATTACHMENT 12
- 09727-58120-01 ATTACHMENT 16
- 09727-58130-01 ATTACHMENT 22
- 09727-58140-01 ATTACHMENT 25

DRAWER 14



Drawer Liner Reference

TOOLS

- 00002-47883-02 FUEL INJECTION SERVICE TOOL SET
- 09213-54015-02 CRANKSHAFT PULLEY HOLDING TOOL
- 09268-31012-02 INJECTION MEASURING TOOL SET
- 09268-45101-1A EFI FUEL PRESSURE GAUGE SET

DRAWER 15

00002-47883-02
FUEL INJECTION SERVICE TOOL SET

COMPONENTS:

- 0926-7610 INJECTION PUMP CAMSHAFT BEARING CONE REPLACER
- 0926-8011 ALTERNATOR PULLEY PULLER
- 0942-3000 WIRING "A" EFI INSPECTION
- 0942-3000 WIRING "C" EFI INSPECTION
- 0942-3070 WIRING "F" EFI INSPECTION
- 0943-1020 DIAGNOSIS CHECK WIRING

09268-45101-01
EFI FUEL PRESSURE GAUGE SET

COMPONENTS:

- 0926-4125-01 T-JOINT
- 0926-4125-01 HOSE JOINT
- 0926-4125-01 HOSE JOINT
- 0926-4125-01 FUEL TUBE CONNECTOR
- 0926-4170-01 HOSE BANDS (R)
- 0926-0870-01 HOSE
- 0926-4300-01 UNION, M8
- 0926-4310-01 UNION, M10
- 0926-4120-01 UNION, M12
- 0926-4400-01 ADAPTER, M8
- 0926-4410-01 ADAPTER, M10
- 0926-4420-01 ADAPTER, M12
- 0926-0020-01 T-JOINT
- 0926-0030-01 FUEL TUBE CONNECTOR

09268-41045-02
09268-41046-02
09268-41047-02
09268-31012-02

INJECTION MEASURING TOOL SET

COMPONENTS:

<ul style="list-style-type: none"> 0926-2701 NO. 2 UNION 0926-4001 NO. 3 UNION 0926-4071 NO. 4 UNION 0926-4101 NO. 6 UNION 0926-4101 NO. 7 UNION 0926-4100 CLAMP 0926-4110 ADAPTER 0926-4120 3-WAY 	<ul style="list-style-type: none"> 0926-4130 ADAPTER 0926-4140 ADAPTER 0926-4160 ADAPTER 0926-4300 CLAMP 0926-4310 CLAMP 0926-4340 CLAMP 0926-4350 CLAMP 0926-4160 ADAPTER 	<ul style="list-style-type: none"> 0926-5011 INJECTION MEASURING ATTACHMENT 9045-0015 NO. 1 UNION 9047-1201 CLP 9533-0600 HOSE 9535-0670 HOSE 9536-0600 C-RING
--	--	--

09213-54015-02

CRANKSHAFT PULLEY HOLDING TOOL

COMPONENTS:

<ul style="list-style-type: none"> 014810 09214-0001-01 BOLT (2) M6 X 1.25 X 120 019460 09214-0002-01 BOLT (2) M6 X 1.25 X 110 019460 09214-0003-01 BOLT (2) M6 X 1.0 X 85 	<ul style="list-style-type: none"> 013210 90110-0010 BOLT M6 X 1.25 X 90 017100 01651-0005-01 BOLT M6 X 1.25 X 95 01651-0006-01 BOLT (2) M6 X 1.0 X 85
---	--

DRAWER #15 SPECIAL TOOLS
L232
FN LB030405-015


JANUARY 2016

TOOLS


- 09224-50011-01 FLEXIBLE EXHAUST HOLDING TOOL
- 09893-72010-01 LIFT ATTACHMENTS
- TLBEV-00001 LIFT STRAPS

DRAWER 16


09224-50011-01
FLEXIBLE EXHAUST HOLDING TOOL



09893-72010-01
LIFT ATTACHMENTS



TLBEV-00001
LIFT STRAPS



DRAWER #16 SPECIAL TOOLS
L232
FN LB030405-016

JANUARY 2016


Drawer Liner Reference

TOOLS

- 09761-50010-01 NITROGEN GAS INJECTION TOOL
- 09950-30012-02 UNIVERSAL PULLER SET "A"
- 09993-19025 OVERFLOW LEVEL GAUGE SET
- 11014-00007 ANTENNA TEST KIT
- 95079-00003-KIT NAVIGATION UPDATE TOOL KIT

DRAWER 17


09761-50010-01
NITROGEN GAS INJECTION TOOL



COMPONENTS:
09761-50010-01 REGULATOR ASSEMBLY
09761-50020-01 PORT ASSEMBLY
09761-50030-01 CASE ASSEMBLY

(09950-30017-02)
(09950-30018-02)
09950-30012-02


UNIVERSAL PULLER SET "A"



COMPONENTS:
09950-30010-01 PULLER HEAD
09950-30018-02 FORGING SCREW
09950-30019-01 FORGING SCREW
09950-30010-01 PULLER LEG (SET OF 2)
09950-30014-01 PULLER JAW (SET OF 2)
09950-30023-01 PULLER JAW (SET OF 3)
09950-30021-01 LOWER PLATE 10MM
09950-30048-01 LOWER PLATE 10MM
09950-30080-01 ADAPTER 10MM
09950-30010-01 ADAPTER 10MM
09950-30024-01 ADAPTER 18MM
09950-30030-01 ADAPTER 20MM
09950-30040-01 ADAPTER 22MM
09950-30050-01 ADAPTER 24MM
09950-30060-01 ADAPTER 26MM
09950-30070-01 ADAPTER 28MM

(95079-00002-KIT)
95079-00003-KIT


NAVIGATION UPDATE TOOL KIT



COMPONENTS:
95079-00001 HDD NAVIGATION UPDATE
95079-10001 AC POWER ADAPTER
95079-12000 VEHICLE EXCHANGE CABLE
95079-12200 USB CABLE 3.0

11014-00007


ANTENNA TEST KIT



COMPONENTS:
01014-00004 RADIO ANTENNA
01014-00005 RADIO ADAPTER
01014-00008 GPS ANTENNA
01014-00007 GPS ANTENNA ADAPTER
01014-00009 XM ANTENNA
01014-00008 XM ANTENNA ADAPTER

(10002-00101)
09993-19025

OVERFLOW LEVEL GAUGE SET



COMPONENTS:
(10002-00101-1) OVERFLOW LEVEL GAUGE
(10002-00101-2) VACUUM REGULATOR
(10002-00101-3) FILLER PLUG ADAPTER
(10002-00101-4) TANK ASSEMBLY


DRAWER #17 SPECIAL TOOLS
LINK: P/N: 09993-19025-017

TOOLS

- 09737-00013-01 BRAKE BOOSTER PUSH ROD GAUGE
- 09737-00020-01 BRAKE BOOSTER PUSH ROD WRENCH
- 09992-00350-01 ABS TRAC ACTUATOR AIR BLEED TOOL
- 09999-00210 MASTER WHEEL LOCK KEY SET
- 09999-00300 SPARE TIRE LOCK KEY SET
- 09999-00410 TRD MASTER KEY SET


DRAWER 18

09992-00350-01
ABS TRAC ACTUATOR AIR BLEED TOOL




(09737-00010)
(09737-00011-01A)
(09737-00012-01)
09737-00013-01

BRAKE BOOSTER PUSH ROD GAUGE



09737-00020-01
BRAKE BOOSTER PUSH ROD WRENCH



09999-00300
SPARE TIRE LOCK KEY SET

09999-00210
MASTER WHEEL LOCK KEY SET

09999-00410
TRD MASTER KEY SET


DRAWER #18 SPECIAL TOOLS
LINK: P/N: 09999-00300-018

Drawer Liner Reference

TOOLS

- 00002-06020-02 PLASTIC PRY TOOL KIT
- 00002-JUMPR-KIT OBD-II JUMPER CONNECTOR KIT
(4 COMPONENTS)
- 09802-11010-01 FASTENER CLOSER
- 09802-11020-01 ACTIVE ROLL BAR PROTECTOR
- 09812-00010 DOOR HINGE SET BOLT WRENCH (12MM)
- 09843-18040 DIAGNOSIS CHECK WIRE #2
- 09843-18050 NAVIGATIONAL WIRING HARNESS
- 09843-18061 SRS CHECK WIRE
- 09872-50040 CABLE, ETHERNET CHECK, NO 1
- 09991-00610 NIGHT VIEW INSPECTION TOOL


DRAWER 21



TOOLS

- 00002-01775 SEAT HEATER ATTACHMENT KIT
- 07112-76060 MAGNETIC CLUTCH STOPPER
- 09804-24010 LUGGAGE COMPARTMENT TOOL SET
- 09808-14040-01 FUEL PUMP RETAINER TOOL
- 09808-14050-01 FUEL PUMP HOLDING TOOL
- 09820-63020-02 ALTERNATOR CLUTCH HOLDING TOOL SET
- 09870-00005-02 A/C LINE DISCONNECT KIT

DRAWER 22



Drawer Liner Reference


TOOLS

00002-09090-01 OCCUPANT CLASSIFICATION SEAT WEIGHT SET
 09870-DYEKIT A/C DYE INJECTION TOOL KIT
 09950-60020-02 REPLACER SET #2
 11717-00012 TPWS TESTER KIT

DRAWER 23

00002-09090-01

 OCCUPANT CLASSIFICATION SEAT WEIGHT SET
 SET CONTAINS QTY. (5) - 10 KG. WEIGHT BAGS



COMPONENTS:
 00002-09077-01
 OCCUPANT SEAT WEIGHTS

00002-09077-TRY
 SEAT WEIGHT TRAY

IMPORTANT: DO NOT REMOVE STORAGE TRAY FROM DRAWER

<p>09950-60020-02 REPLACER SET #2</p> <div style="border: 1px solid black; padding: 5px; margin: 5px;"> <p>COMPONENTS:</p> <ul style="list-style-type: none"> 09951-00880-01 REPLACER 68 09951-00710-01 REPLACER 71 09951-00720-01 REPLACER 72 09951-00730-01 REPLACER 73 09951-00740-01 REPLACER 74 09951-00750-01 REPLACER 75 09951-00760-01 REPLACER 76 09951-00770-01 REPLACER 77 09951-00780-01 REPLACER 78 09951-00790-01 REPLACER 79 09951-00800-01 REPLACER 80 09951-00910-01 REPLACER 91 </div>	<p>(00002-TTPWS) 11717-00012 TPWS TESTER KIT</p> <div style="border: 1px solid black; padding: 5px; margin: 5px;"> <p>COMPONENTS:</p> <ul style="list-style-type: none"> 01717-00102 TPWS TESTER 01717-00123 OBD II DONGLE 01717-00124 POWER SUPPLY 01717-00125 USB CABLE 01717-00126 MAGNET 01717-00127 RJ45 CABLE </div>	<p>09870-DYEKIT A/C DYE INJECTION TOOL KIT</p> <div style="border: 1px solid black; padding: 5px; margin: 5px;"> <p>COMPONENTS:</p> <ul style="list-style-type: none"> 09870-20010-Y R-134A COUPLER FOR ND11 09870-20010-B R-134A COUPLER FOR ND12 09870-20010-V R-1234YF COUPLER FOR ND11 09870-20010-G R-1234YF COUPLER FOR ND12 09870-TP984S EZ-EJECT™ DYE INJECTOR ASSEMBLY 09870-TP903P OPTI-PRO™ UV PLUS RECHARGEABLE VIOLET LIGHT LED LEAK DETECTION LIGHT 09870-01914 USB CHARGER FOR OPTI-PRO™ LIGHT 09870-TP994D FLUORESCENCE ENHANCING GLASSES 09870-01918 GLO-AWAY™ PLUS FLUORESCENT DYE CLEANER 09870-CASE GREEN CARRYING CASE </div>
--	--	--

DRAWER 23 SPECIAL TOOLS
 LUGS
 P/N: US303493-023

JANUARY 2016


TOOLS

DRAWER 24


DRAWER 24 SPECIAL TOOLS
 LUGS
 P/N: US303493-024

JANUARY 2016


Essential Tools Not Located in Storage Cabinets




00002-11100-02 TRANSMISSION FILL SYSTEM




00002-ESUPPT-01 ENGINE SUPPORT BAR




00002-12000-01 KDSS FLUID PRESSURE PUMP KIT OR
09760-60020 KDSS FLUID PRESSURE PUMP KIT



09802-00010-02 ROOF LINE GAUGE




00002-1ESBU-KIT ENGINE SUPPORT BAR BRACKET



ESUPPT-HOOK3 ENGINE SUPPORT BAR HOOK SET NO. 3




00002-35000 3/4 INCH DRIVE TORQUE WRENCH




09803-00010-02 LUGGAGE DOOR LINK SUB-ASSEMBLY GAUGE

Note: Size of tools shown on this page are not to scale.


Essential Tools Not Located in Storage Cabinets




09870-60000 LASER RADAR ADJUSTING REFLECTOR




09870-60060-01 STAND SUPPORT




09870-61100-01 TARGET BOARD NO. 1



09870-62100-01 TARGET SHEET NO. 1




09870-62200-01 TARGET SHEET NO. 2




01421-00151 3K LIFT TABLE

Note: Size of tools shown on this page are not to scale.

Essential Tools Not Located in Storage Cabinets



09803-10010-01 LUGGAGE DOOR HINGE ADJUSTING GAUGE




TSADVUNIT TECHSTREAM ADVI



DCA-8000P T DIAGNOSTIC CHARGER



DSS-5000P T HANDHELD TESTER




11816-00010 RADAR SENSOR CALIBRATION KIT


Note: Size of tools shown on this page are not to scale.

Essential Tools Not Located in Storage Cabinets


Hybrid Electric Vehicle (HEV) Workstation



11413-00002 HIGH VOLTAGE BATTERY SERVICE KIT (GRX 5100)




11813-00003 INSULATED TOOLS



11413-00004 PERSONAL PROTECTIVE EQUIPMENT (PPE)

(11413-00007 INSULATED TOOLS AND PPE KIT)



11413-00006 HEV TOOL STORAGE CABINET



11413-00005 MILLIOHM METER KIT



SST Storage System Master Index

To Order Special Service Tools Call Bosch/OTC at 1-800-933-8335