Slim but Powerful



How to use?

Charge the Power Bank



Plug in the Power Bank to a wall charger or your computer's USB port via a USB charging cable. Please charge the Power Bank before first use.

Charge other devices

Check battery level



Plug in your device to the Power Bank's output port via a USB charging cable.

5V/2.4A (Max.)



Press the Power Button to check the current battery level. We recommend charging it when the last LED indicator is blinking.

Attention

- Keep this device away from water, fire, and extreme temperatures.
- Do not deliberately drop or impact this device.
- Do not attempt to extrude or pierce this device, which may cause it to short circuit.
- Do not attempt to disassemble, modify or repair this device yourself.
- Do not use a damaged wall charger or USB charging cable to charge this device.
- If the product appears to be bulging or any other visible abnormalities, stop using the product immediately and contact us or distributor.
- Please recycle this device at an approved disposal location.
- Please charge this device once every three months to avoid shortening its battery life.
- Please use the recommended power adapter to charge this device. Power adapter is not provided by TP-LINK.

If you have any questions related to this product, please refer to the support page at www.tp-link.com. Tel:+86 755 2650 4400