



**Mounts (J-Numbers)**

		AP-103	AP-103H	AP-205H	AP-204/205	AP-207	AP-214/215	AP-224/225	AP-304/305	AP-314/315	AP-324/325	AP-334/335	RAP-3WN / RAP-3WNP	RAP-100/100P	RAP-155/155P	AP-228	AP-365	AP-367	AP-274	AP-275	AP-277
<b>Indoor</b>																					
AP-103H-MNT1	JW036A	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●
AP-103H-MNT2	JW037A	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●
AP-200-MNT-W2	JW038A	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●
AP-200-MNT-W3	JY705A	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●
AP-200-MNT-T	JW039A	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●
AP-205H-MNT1	JW040A	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●
AP-205H-MNT2	JW041A	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●
AP-205H-MNTR	JW042A	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●
AP-210-MNT-T	JW043A	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●
AP-220-MNT-C2	JW045A	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●
AP-220-MNT-W1	JW046A	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●
AP-220-MNT-W1W	JW047A	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●
AP-220-MNT-W2	JW048A	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●
AP-220-MNT-W2W	JW049A	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●
AP-220-MNT-W3	JY706A	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●
AP-220-MNT-T	JW051A	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●
AP-320-MNT-T	JW059A	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●
AP-MNT-CM1	JX961A	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●
RAP-100-MNT	JW057A	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●
RAP-3WN-MNT	JW058A	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●

<b>Outdoor</b>																					
AP-270-MNT-V1	JW052A															●	●	●	●	●	●
AP-270-MNT-V2	JW053A															●	●	●	●	●	●
AP-270-MNT-H1	JW054A															●	●	●	●	●	●
AP-270-MNT-H2	JW055A															●	●	●	●	●	●
AP-270-MNT-ADP	JW056A															●	●	●	●	●	●

Requires AP-270-MNT-ADP