


# FLEX

Product Description: Circular Saw  
Model Number: FX2131A-Z  
Body Number: 0740038001  
Version: A  
Issue Date: 2021/07/15



No.	Product Model#	Part Number	Description	Qty
1	FX2131A-Z	5640370001	Flange Screw	1
2	FX2131A-Z	3550938001	Out Flange	1
3	FX2131A-Z	3580102001	Inner Flange	1
4	FX2131A-Z	5660190001	Circlips For Shaft	1
5	FX2131A-Z	5610345001	Thread Forming Screw	1
6	FX2131A-Z	3121051002	Stopper	1
7	FX2131A-Z	3660830001	Tension Spring	1
8	FX2131A-Z	5620169004	Tapping Screw	5
9	FX2131A-Z	2828363001	Pothead Assembly	1
10	FX2131A-Z	3131380001	Lock off Button	1
11	FX2131A-Z	3660028003	Stop Spring	2
12	FX2131A-Z	3130784001	Vacuum Adapter	1
13	FX2131A-Z	3131382001	Adapter	1
14	FX2131A-Z	5620016002	Hexagon Socket Screw	3
15	FX2131A-Z	3128712001	Rubber Gasket	1
16	FX2131A-Z	5640198001	Bolt	1
17	FX2131A-Z	5630007004	Prevailing Torque Hexagon Nut	1
18	FX2131A-Z	5620597001	Screw with Washer	1
19	FX2131A-Z	5620594001	Hexagon Socket Screw	1
20	FX2131A-Z	5650617001	Washer	1
21	FX2131A-Z	3706392001	Lock Lever	1
22	FX2131A-Z	5630313001	Acorn Nut	1
23	FX2131A-Z	5660252001	Circlip	1
24	FX2131A-Z	2830861001	Electric Assembly	1
25	FX2131A-Z	3131383001	Clapboard	1
26	FX2131A-Z	2827684001	Base Plate Assembly	1
27	FX2131A-Z	3126849001	LED Cover	1
28	FX2131A-Z	3127485001	LED Cover	1
29	FX2131A-Z	2828375001	Upper Guard Set	1
30	FX2131A-Z	3131388001	Switch Trigger	1
31	FX2131A-Z	3900397001	L R Handle Set	1
32	FX2131A-Z	3580280001	Bushing	1
33	FX2131A-Z	3422799001	Lower Guard	1
34	FX2131A-Z	3707539001	Moving Guard Lever	1
35	FX2131A-Z	5620164008	Hexagon Socket Screw	2
36	FX2131A-Z	2730341001	Motor & Small Belt Pulley Assembly	1
37	FX2131A-Z	5610346001	Thread Forming Screw	2
38	FX2131A-Z	2828377001	Gear Case Cover Assembly	1
39	FX2131A-Z	2827683001	Gear Case Assembly	1
40	FX2131A-Z	5610237001	Tapping Screw	3
41	FX2131A-Z	5610342001	Thread Forming Screw	6
42	FX2131A-Z	3800164001	Poly V-Belt	1
43	FX2131A-Z	5610241004	Screw	2
44	FX2131A-Z	3403134001	Spindle Lock	1
45	FX2131A-Z	3660072002	Spring	1
46	FX2131A-Z	3130785001	Spindle Lock Cover	1
47	FX2131A-Z	2828374001	Lock Assembly	1
48	FX2131A-Z	3707538001	Depth Adjusting Lever	1
49	FX2131A-Z	3553553001	Lock Pole	1
50	FX2131A-Z	5650640001	Plain Washer	1
51	FX2131A-Z	5610343001	Tapping Screw	4
301	FX2131A-Z	3129000001	Mounting	1
302	FX2131A-Z	5680028002	Hexagon Wrench	1