

Category	SubCategory	PN	DESCRIPTION	EUR
Audio & Video	Audio	4XD1C82055	Lenovo Go Wired Speakerphone (USB-C & MS Teams)	99
Audio & Video	Audio	4XD1C99223	Lenovo Go Wired ANC Headset (MS Teams)	88
Audio & Video	Audio	4XD0S92991	Lenovo Pro Wired Stereo VoIP Headset (MS Teams)	93
Audio & Video	Audio	4XD0J65079	ThinkPad Headphones In-Ear	15
Audio & Video	Audio	4XD0K25030	Lenovo Essential Stereo Analog Headset	23
Audio & Video	Audio	4XD0T32974	Lenovo 700 Ultraportable Bluetooth Speaker	130
Audio & Video	Audio	4XD0X88524	Lenovo 100 USB Stereo Headset	38
Audio & Video	Audio	4XD1B61617	Lenovo 100 Mono USB Headset	34
Audio & Video	Audio	4XD1B65028	Lenovo Bluetooth In-ear Headphones	45
Audio & Video	Audio	4XD1C99222	Lenovo Go Wireless ANC Headset w/ Charging Stand (MS Teams)	186
Audio & Video	Audio	4XF1C99224	Lenovo Go Charging Stand for Wireless Headset	49
Audio & Video	Audio	4XD1J77351	Lenovo USB-C Wired In-Ear Headphones (with inline control)	15
Audio & Video	Audio	4XD1J05151	ThinkVision MS30 Monitor Soundbar	26
Audio & Video	Audio	4XD1C99220	Lenovo Go USB-C ANC In-Ear Headphones (MS Teams)	69
Audio & Video	Audio	4XD1K18260	Lenovo USB-A Wired Stereo On-Ear Headset with Control Box	44
Audio & Video	Audio	4XD1C99221	Lenovo Go Wireless ANC Headset (MS Teams)	169
Audio & Video	Audio	4XD0U47635	ThinkPad X1 Active Noise Cancellation Headphones	169
Audio & Video	Video	4XC1B34802	Lenovo Essential FHD Webcam	39
Audio & Video	Video	4XC1D66055	Lenovo Performance FHD Webcam	61
Audio & Video	Video	4XC1D66056	ThinkVision MC50 Monitor WebCam	64
Audio & Video	Video	4XC1J05150	ThinkVision MC60 Monitor Webcam	83
Cases & Bags	Backpack	4X41A30364	ThinkPad Essential Plus Eco 15.6" Backpack	51
Cases & Bags	Backpack	4X40K09936	ThinkPad 15.6 Basic Backpack	21
Cases & Bags	Backpack	4X40Q26383	ThinkPad Professional 15.6" Backpack	84
Cases & Bags	Backpack	4X41C12468	ThinkPad Essential 16" Backpack (Eco)	36
Cases & Bags	Backpack	4X40T84058	LENOVO 15.6" LAPTOP CASUAL BACKPACK B210 GREY	20
Cases & Bags	Backpack	4X40T84059	LENOVO 15.6" LAPTOP CASUAL BACKPACK B210 BLACK	20
Cases & Bags	Backpack	4X40X54260	Lenovo Business Casual 17-inch Backpack	59
Cases & Bags	Protective Case	4X41A08251	ThinkPad X12 Tablet Protective Case	41
Cases & Bags	Protective Case	4X41E40077	Lenovo Go Tech Accessories Organizer	56
Cases & Bags	Sleeve	4X40X67058	ThinkBook 14" Sleeve	15
Cases & Bags	Sleeve	4X40N18007	ThinkPad 12" Sleeve	21
Cases & Bags	Sleeve	4X40N18008	ThinkPad 13" Sleeve	25
Cases & Bags	Sleeve	4X40N18009	ThinkPad 14" Sleeve	26
Cases & Bags	Sleeve	4X40N18010	ThinkPad 15" Sleeve	26
Cases & Bags	Sleeve	4X41K79634	ThinkPad 13-inch Vertical Carry Sleeve	38
Cases & Bags	Topload	4X40Q26384	ThinkPad Professional 15.6" Top-load	86
Cases & Bags	Topload	4X40Q26385	ThinkPad Professional 15.6" Slim Top-load	61

Category	SubCategory	PN	DESCRIPTION	EUR
Cases & Bags	Topload	4X40Y95214	Lenovo 15.6" Basic Topload	16
Cases & Bags	Topload	4X40W19826	ThinkPad 14-inch Professional Slim Topload	53
Cases & Bags	Topload	4X41A30365	ThinkPad Essential Plus Eco 15.6" Topload	46
Cases & Bags	Topload	4X41C12469	ThinkPad Essential 16" Topload (Eco)	31
Cases & Bags	Topload	4X41D97727	ThinkPad 13/14-inch Essential Topload (Eco)	26
Cases & Bags	Topload	4X40T84060	LENOVO 15.6" LAPTOP CASUAL TOPLOADER T210 GREY	19
Cases & Bags	Topload	4X40T84061	LENOVO 15.6" LAPTOP CASUAL TOPLOADER T210 BLACK	19
Hubs	Hubs	4X91A30366	Lenovo USB-C Travel Hub Gen 2	73
Hubs	Hubs	4X90S92381	Lenovo Powered USB-C Travel Hub	88
Hubs	Hubs	4X90V55523	Lenovo USB-C 7-in-1 Hub	63
Hubs	Hubs	4X90X21427	Lenovo USB-C to 4 Ports USB-A Hub	29
Input	Combo	4X30H56796	Lenovo Professional Wireless Keyboard and Mouse Combo - US English	69
Input	Combo	4X30H56799	Lenovo Professional Wireless Keyboard and Mouse Combo - Belgium/French	69
Input	Combo	4X30H56800	Lenovo Professional Wireless Keyboard and Mouse Combo - Belgium/UK	69
Input	Combo	4X30H56803	Lenovo Professional Wireless Keyboard and Mouse Combo - Czech (489)	69
Input	Combo	4X30H56804	Lenovo Professional Wireless Keyboard and Mouse Combo - Danish	69
Input	Combo	4X30H56806	Lenovo Professional Wireless Keyboard and Mouse Combo - French	69
Input	Combo	4X30H56809	Lenovo Professional Wireless Keyboard and Mouse Combo - German	69
Input	Combo	4X30H56816	Lenovo Professional Wireless Keyboard and Mouse Combo - Italy	69
Input	Combo	4X30H56819	Lenovo Professional Wireless Keyboard and Mouse Combo - Norwegian	69
Input	Combo	4X30H56820	Lenovo Professional Wireless Keyboard and Mouse Combo - Portugese	69
Input	Combo	4X30H56822	Lenovo Professional Wireless Keyboard and Mouse Combo - Slovak	69
Input	Combo	4X30H56823	Lenovo Professional Wireless Keyboard and Mouse Combo - Spanish	69
Input	Combo	4X30H56824	Lenovo Professional Wireless Keyboard and Mouse Combo - Swedish/Finnish	69
Input	Combo	4X30H56825	Lenovo Professional Wireless Keyboard and Mouse Combo - Swiss French/German	69
Input	Combo	4X30H56828	Lenovo Professional Wireless Keyboard and Mouse Combo - UK English	69
Input	Combo	4X30H56829	Lenovo Professional Wireless Keyboard and Mouse Combo - US English with Euro symbol	69
Input	Combo	4X30L79883	Lenovo Essential Wired Keyboard and Mouse Combo - US English	34
Input	Combo	4X30L79886	Lenovo Essential Wired Keyboard and Mouse Combo - Belgian/ French	34
Input	Combo	4X30L79887	Lenovo Essential Wired Keyboard and Mouse Combo - Belgian/ UK	34
Input	Combo	4X30L79891	Lenovo Essential Wired Keyboard and Mouse Combo - Czech (489)	34
Input	Combo	4X30L79892	Lenovo Essential Wired Keyboard and Mouse Combo - Danish	34
Input	Combo	4X30L79893	Lenovo Essential Wired Keyboard and Mouse Combo- Dutch	34
Input	Combo	4X30L79894	Lenovo Essential Wired Keyboard and Mouse Combo - French	34
Input	Combo	4X30L79897	Lenovo Essential Wired Keyboard and Mouse Combo - German	34
Input	Combo	4X30L79902	Lenovo Essential Wired Keyboard and Mouse Combo - Icelandic	34
Input	Combo	4X30L79903	Lenovo Essential Wired Keyboard and Mouse Combo - Italian	34
Input	Combo	4X30L79908	Lenovo Essential Wired Keyboard and Mouse Combo - Norwegian	34

Input	Combo	4X30L79909	Lenovo Essential Wired Keyboard and Mouse Combo - Polish	34
Input	Combo	4X30L79910	Lenovo Essential Wired Keyboard and Mouse Combo - Portuguese	34
Input	Combo	4X30L79914	Lenovo Essential Wired Keyboard and Mouse Combo - Slovak	34
Input	Combo	4X30L79915	Lenovo Essential Wired Keyboard and Mouse Combo - Spanish	34
Input	Combo	4X30L79916	Lenovo Essential Wired Keyboard and Mouse Combo - Swedish/Finnish	34
Input	Combo	4X30L79917	Lenovo Essential Wired Keyboard and Mouse Combo Swiss French/German	34
Input	Combo	4X30L79921	Lenovo Essential Wired Keyboard and Mouse Combo - UK English	34
Input	Combo	4X30L79922	Lenovo Essential Wired Keyboard and Mouse Combo - US Euro	34
Input	Combo	4X30L79925	Lenovo Essential Wired Keyboard and Mouse Combo - Lithuanian	34
Input	Combo	4X30L79928	Lenovo Essential Wired Keyboard and Mouse Combo - Estonia	34
Input	Combo	4X30L79929	Lenovo Essential Wired Keyboard and Mouse Combo - Nordic	34
Input	Combo	4X30M39461	Lenovo Essential Wireless Keyboard and Mouse Combo Belgian / French	46
Input	Combo	4X30M39462	Lenovo Essential Wireless Keyboard and Mouse Combo Belgian / U.K. English	46
Input	Combo	4X30M39466	Lenovo Essential Wireless Keyboard and Mouse Combo Czech (489)	46
Input	Combo	4X30M39467	Lenovo Essential Wireless Keyboard and Mouse Combo Danish (159)	46
Input	Combo	4X30M39468	Lenovo Essential Wireless Keyboard and Mouse Combo Dutch (143)	46
Input	Combo	4X30M39469	Lenovo Essential Wireless Keyboard and Mouse Combo French (189)	46
Input	Combo	4X30M39472	Lenovo Essential Wireless Keyboard and Mouse Combo German	46
Input	Combo	4X30M39477	Lenovo Essential Wireless Keyboard and Mouse Combo Icelandic (197)	46
Input	Combo	4X30M39478	Lenovo Essential Wireless Keyboard and Mouse Combo Italian (141)	46
Input	Combo	4X30M39483	Lenovo Essential Wireless Keyboard and Mouse Combo Norwegian (155)	46
Input	Combo	4X30M39484	Lenovo Essential Wireless Keyboard and Mouse Combo Polish	46
Input	Combo	4X30M39485	Lenovo Essential Wireless Keyboard and Mouse Combo Portuguese (163)	46
Input	Combo	4X30M39489	Lenovo Essential Wireless Keyboard and Mouse Combo Slovak (245)	46
Input	Combo	4X30M39490	Lenovo Essential Wireless Keyboard and Mouse Combo Spanish (172)	46
Input	Combo	4X30M39491	Lenovo Essential Wireless Keyboard and Mouse Combo Swedish / Finnish (153)	46
Input	Combo	4X30M39492	Lenovo Essential Wireless Keyboard and Mouse Combo Swiss-French/German (150)	46
Input	Combo	4X30M39496	Lenovo Essential Wireless Keyboard and Mouse Combo U.K. English (166)	46
Input	Combo	4X30M39497	Lenovo Essential Wireless Keyboard and Mouse Combo U.S. English with Euro symbol (103P)	46
Input	Combo	4X30M39500	Lenovo Essential Wireless Keyboard and Mouse Combo Lithuanian	44
Input	Combo	4X30M39503	Lenovo Essential Wireless Keyboard and Mouse Combo Estonian	44
Input	Combo	4X30M39504	Lenovo Essential Wireless Keyboard and Mouse Combo Nordic	44
Input	Combo	4X31D64771	Lenovo Essential Wired Combo - Czech/Slovakia	34
Input	Combo	4X31D64773	LENOVO Professional Wireless Keyboard and Mice Combo -Czech/Slovakia	69
Input	Combo	4X31D64774	LENOVO Professional Wireless Keyboard and Mice Combo -Iceland	69
Input	Combo	4X31D64778	LENOVO Essential Wireless Keyboard and Mice Combo -Czech/Slovakia	46
Input	Combo	4Y41D64795	LENOVO Professional Wireless Keyboard -Czech/Slovakia	48
Input	Combo	4Y41D64796	LENOVO Professional Wireless Keyboard -Iceland	48
Input	Combo	4X31K03931	Lenovo Professional Wireless Rechargeable Keyboard and Mouse Combo US English	95
Input	Combo	4X31K03935	Lenovo Professional Wireless Rechargeable Keyboard and Mouse Combo Belgium English	95

Category	SubCategory	PN	DESCRIPTION	EUR
Input	Combo	4X31K03939	Lenovo Professional Wireless Rechargeable Keyboard and Mouse Combo Czech/Slovak	95
Input	Combo	4X31K03942	Lenovo Professional Wireless Rechargeable Keyboard and Mouse Combo French	95
Input	Combo	4X31K03945	Lenovo Professional Wireless Rechargeable Keyboard and Mouse Combo German	95
Input	Combo	4X31K03951	Lenovo Professional Wireless Rechargeable Keyboard and Mouse Combo Italy	95
Input	Combo	4X31K03957	Lenovo Professional Wireless Rechargeable Keyboard and Mouse Combo Portugese	95
Input	Combo	4X31K03961	Lenovo Professional Wireless Rechargeable Keyboard and Mouse Combo Spanish	95
Input	Combo	4X31K03963	Lenovo Professional Wireless Rechargeable Keyboard and Mouse Combo Swiss French/German	95
Input	Combo	4X31K03967	Lenovo Professional Wireless Rechargeable Keyboard and Mouse Combo UK English	95
Input	Combo	4X31K03968	Lenovo Professional Wireless Rechargeable Keyboard and Mouse Combo US Euro	95
Input	Combo	4X31K03975	Lenovo Professional Wireless Rechargeable Keyboard and Mouse Combo Nordic	95
Input	Keyboard	4X30H56841	Lenovo Professional Wireless Keyboard- US English	48
Input	Keyboard	4X30H56844	Lenovo Professional Wireless Keyboard - Belgian/ French	48
Input	Keyboard	4X30H56845	Lenovo Professional Wireless Keyboard - Belgian/ UK	48
Input	Keyboard	4X30H56846	Lenovo Professional Wireless Keyboard - Bulgarian	48
Input	Keyboard	4X30H56848	Lenovo Professional Wireless Keyboard - Czech(489)	48
Input	Keyboard	4X30H56849	Lenovo Professional Wireless Keyboard - Danish	48
Input	Keyboard	4X30H56851	Lenovo Professional Wireless Keyboard - French	48
Input	Keyboard	4X30H56854	Lenovo Professional Wireless Keyboard - German	48
Input	Keyboard	4X30H56861	Lenovo Professional Wireless Keyboard - Italian	48
Input	Keyboard	4X30H56864	Lenovo Professional Wireless Keyboard - Norwegian	48
Input	Keyboard	4X30H56865	Lenovo Professional Wireless Keyboard - Portuguese	48
Input	Keyboard	4X30H56867	Lenovo Professional Wireless Keyboard - Slovak	48
Input	Keyboard	4X30H56868	Lenovo Professional Wireless Keyboard - Spanish	48
Input	Keyboard	4X30H56869	Lenovo Professional Wireless Keyboard - Swedish/ Finnish	48
Input	Keyboard	4X30H56870	Lenovo Professional Wireless Keyboard - Swiss French/ German	48
Input	Keyboard	4X30H56873	Lenovo Professional Wireless Keyboard - UK English	48
Input	Keyboard	4X30H56874	Lenovo Professional Wireless Keyboard - US Euro	48
Input	Keyboard	4X30M86882	Lenovo Preferred Pro II USB Keyboard-Black Belgian / French	35
Input	Keyboard	4X30M86883	Lenovo Preferred Pro II USB Keyboard-Black Belgian / U.K. English	35
Input	Keyboard	4X30M86887	Lenovo Preferred Pro II USB Keyboard-Black Czech (489)	35
Input	Keyboard	4X30M86888	Lenovo Preferred Pro II USB Keyboard-Black Danish (159)	35
Input	Keyboard	4X30M86889	Lenovo Preferred Pro II USB Keyboard-Black Dutch (143)	35
Input	Keyboard	4X30M86890	Lenovo Preferred Pro II USB Keyboard-Black French (189)	35
Input	Keyboard	4X30M86893	Lenovo Preferred Pro II USB Keyboard-Black German	35
Input	Keyboard	4X30M86898	Lenovo Preferred Pro II USB Keyboard-Black Icelandic (197)	35
Input	Keyboard	4X30M86899	Lenovo Preferred Pro II USB Keyboard-Black Italian (141)	35
Input	Keyboard	4X30M86904	Lenovo Preferred Pro II USB Keyboard-Black Norwegian (155)	35
Input	Keyboard	4X30M86905	Lenovo Preferred Pro II USB Keyboard-Black Polish	35

Category	SubCategory	PN	DESCRIPTION	EUR
Input	Keyboard	4X30M86906	Lenovo Preferred Pro II USB Keyboard-Black Portugese (163)	35
Input	Keyboard	4X30M86910	Lenovo Preferred Pro II USB Keyboard-Black Slovak (245)	35
Input	Keyboard	4X30M86911	Lenovo Preferred Pro II USB Keyboard-Black Spanish (172)	35
Input	Keyboard	4X30M86912	Lenovo Preferred Pro II USB Keyboard-Black Swedish / Finnish (153)	35
Input	Keyboard	4X30M86913	Lenovo Preferred Pro II USB Keyboard-Black Swiss-French/German (150)	35
Input	Keyboard	4X30M86917	Lenovo Preferred Pro II USB Keyboard-Black U.K. English (166)	35
Input	Keyboard	4X30M86918	Lenovo Preferred Pro II USB Keyboard-Black .US. English with Euro symbol (103P)	35
Input	Keyboard	4X30M86920	Lenovo Preferred Pro II USB Keyboard-Black (470)	35
Input	Keyboard	4X30M86921	Lenovo Preferred Pro II USB Keyboard-Black Lithuanian	35
Input	Keyboard	4X30M86924	Lenovo Preferred Pro II USB Keyboard-Black Estonian	35
Input	Keyboard	4X30M86925	Lenovo Preferred Pro II USB Keyboard-Black Nordic	35
Input	Keyboard	4Y41B69353	Lenovo USB Smart Card keyboard II -US English	61
Input	Keyboard	4Y41B69357	Lenovo USB Smart Card keyboard II -US Eng with Euro	61
Input	Keyboard	4Y41B69363	Lenovo USB Smart Card keyboard II -Belgium/Fren	61
Input	Keyboard	4Y41B69364	Lenovo USB Smart Card keyboard II -Belgium/UK	61
Input	Keyboard	4Y41B69365	Lenovo USB Smart Card keyboard II -Bulgarian	61
Input	Keyboard	4Y41B69368	Lenovo USB Smart Card keyboard II -Danish	61
Input	Keyboard	4Y41B69369	Lenovo USB Smart Card keyboard II -French	61
Input	Keyboard	4Y41B69371	Lenovo USB Smart Card keyboard II -Fren Cana(058)	61
Input	Keyboard	4Y41B69372	Lenovo USB Smart Card keyboard II -German	61
Input	Keyboard	4Y41B69376	Lenovo USB Smart Card keyboard II -Italy	61
Input	Keyboard	4Y41B69377	Lenovo USB Smart Card keyboard II -Norwegian	61
Input	Keyboard	4Y41B69378	Lenovo USB Smart Card keyboard II -Portugese	61
Input	Keyboard	4Y41B69380	Lenovo USB Smart Card keyboard II -Spanish	61
Input	Keyboard	4Y41B69381	Lenovo USB Smart Card keyboard II -Swedish/Finn	61
Input	Keyboard	4Y41B69382	Lenovo USB Smart Card keyboard II -Swi Fren/Ger	61
Input	Keyboard	4Y41B69384	Lenovo USB Smart Card keyboard II -UK English	61
Input	Keyboard	4Y41B69388	Lenovo USB Smart Card keyboard II -Cze/Slov	61
Input	Keyboard	4Y41B69389	Lenovo USB Smart Card keyboard II -Icelandic	61
Input	Keyboard	4Y41B69390	Lenovo USB Smart Card keyboard II -Nordic	61
Input	Keyboard	4Y40X49493	ThinkPad TrackPoint Keyboard II US English	128
Input	Keyboard	4Y40X49502	ThinkPad TrackPoint Keyboard II Belgian	128
Input	Keyboard	4Y40X49504	ThinkPad TrackPoint Keyboard II Danish	128
Input	Keyboard	4Y40X49505	ThinkPad TrackPoint Keyboard II Spanish	128
Input	Keyboard	4Y40X49506	ThinkPad TrackPoint Keyboard II French	128
Input	Keyboard	4Y40X49507	ThinkPad TrackPoint Keyboard II German	128
Input	Keyboard	4Y40X49511	ThinkPad TrackPoint Keyboard II Icelandic	128
Input	Keyboard	4Y40X49512	ThinkPad TrackPoint Keyboard II Italian	128

Category	SubCategory	PN	DESCRIPTION	EUR
Input	Keyboard	4Y40X49513	ThinkPad TrackPoint Keyboard II Norwegian	128
Input	Keyboard	4Y40X49514	ThinkPad TrackPoint Keyboard II Portuguese	128
Input	Keyboard	4Y40X49517	ThinkPad TrackPoint Keyboard II Swedish/Finnish	128
Input	Keyboard	4Y40X49518	ThinkPad TrackPoint Keyboard II Swiss	128
Input	Keyboard	4Y40X49520	ThinkPad TrackPoint Keyboard II UK English	128
Input	Keyboard	4Y40X49521	ThinkPad TrackPoint Keyboard II US English Euro	128
Input	Keyboard	4Y40X49525	ThinkPad TrackPoint Keyboard II Estonian	128
Input	Keyboard	4Y40X49527	ThinkPad TrackPoint Keyboard II Nordic	128
Input	Keyboard	4Y40X49528	ThinkPad TrackPoint Keyboard II Czech/Slovak	128
Input	Keyboard	4Y41C33748	Lenovo Go Split Keyboard-US English	118
Input	Keyboard	4Y41C33752	Lenovo Go Split Keyboard-Belgium Eng	118
Input	Keyboard	4Y41C33755	Lenovo Go Split Keyboard-Cze/Slov	118
Input	Keyboard	4Y41C33756	Lenovo Go Split Keyboard-Danish	118
Input	Keyboard	4Y41C33758	Lenovo Go Split Keyboard-French	118
Input	Keyboard	4Y41C33761	Lenovo Go Split Keyboard-German	118
Input	Keyboard	4Y41C33767	Lenovo Go Split Keyboard-Italy	118
Input	Keyboard	4Y41C33769	Lenovo Go Split Keyboard-Norwegian	118
Input	Keyboard	4Y41C33771	Lenovo Go Split Keyboard-Portugese	118
Input	Keyboard	4Y41C33775	Lenovo Go Split Keyboard-Spanish	118
Input	Keyboard	4Y41C33776	Lenovo Go Split Keyboard-Swed/Fin	118
Input	Keyboard	4Y41C33777	Lenovo Go Split Keyboard-Swiss FR/DE	118
Input	Keyboard	4Y41C33781	Lenovo Go Split Keyboard-UK English	118
Input	Keyboard	4Y41C33782	Lenovo Go Split Keyboard-US Euro	118
Input	Keyboard	4Y41C33789	Lenovo Go Split Keyboard-Nordic	118
Input	Keyboard	4Y41K04031	Lenovo Professional Wireless Rechargeable Keyboard US English	69
Input	Keyboard	4Y41K04035	Lenovo Professional Wireless Rechargeable Keyboard Belgium English	69
Input	Keyboard	4Y41K04039	Lenovo Professional Wireless Rechargeable Keyboard Czech/Slovak	69
Input	Keyboard	4Y41K04042	Lenovo Professional Wireless Rechargeable Keyboard French	69
Input	Keyboard	4Y41K04045	Lenovo Professional Wireless Rechargeable Keyboard German	69
Input	Keyboard	4Y41K04051	Lenovo Professional Wireless Rechargeable Keyboard Italy	69
Input	Keyboard	4Y41K04057	Lenovo Professional Wireless Rechargeable Keyboard Portugese	69
Input	Keyboard	4Y41K04061	Lenovo Professional Wireless Rechargeable Keyboard Spanish	69
Input	Keyboard	4Y41K04063	Lenovo Professional Wireless Rechargeable Keyboard Swiss French/German	69
Input	Keyboard	4Y41K04067	Lenovo Professional Wireless Rechargeable Keyboard UK English	69
Input	Keyboard	4Y41K04068	Lenovo Professional Wireless Rechargeable Keyboard US Euro	69
Input	Keyboard	4Y41K04075	Lenovo Professional Wireless Rechargeable Keyboard Nordic	69
Input	Mouse	4Y50R20863	Lenovo Essential USB Mouse	10
Input	Mouse	4Y51D20848	ThinkPad USB-C Wireless Compact Mouse	25

Category	SubCategory	PN	DESCRIPTION	EUR
Input	Mouse	4Y51D20850	ThinkPad USB-C Wired Compact Mouse	15
Input	Mouse	4X30H56886	Lenovo Professional Wireless Laser Mouse	28
Input	Mouse	4X30M56887	THINKPAD ESSENTIAL WIRELESS MOUSE	18
Input	Mouse	4Y50R20864	LENOVO ESSENTIAL WIRELESS COMPACT MOUSE	16
Input	Mouse	4Y50U45359	ThinkPad X1 Presenter Mouse	81
Input	Mouse	4Y50U59628	Lenovo Yoga Mouse with Laser Presenter	59
Input	Mouse	4Y50X88822	ThinkPad Bluetooth Silent Mouse	28
Input	Mouse	4Y50X88824	ThinkBook Bluetooth Silent Mouse	28
Input	Mouse	4Y51C21216	Lenovo Go USB-C Wireless Mouse	48
Input	Mouse	4Y51C21217	Lenovo Go Wireless Multi-Device Mouse	61
Input	Mouse	4Y51C33792	Lenovo Go Wireless Vertical Mouse	54
Input	Mouse	4Y51J62544	Lenovo Professional Bluetooth Rechargeable Mouse	30
Power	AC Adapter	4X20E50562	ThinkPad 135W AC Adapter (Slim tip) - EU1 Countries/Indonesia/Vitenam	94
Power	AC Adapter	4X20E50563	ThinkPad 135W AC Adapter (Slim tip) - Denmark	94
Power	AC Adapter	4X20E50566	ThinkPad 135W AC Adapter (Slim tip) - UK,HK,Malaysia	94
Power	AC Adapter	4X20E50567	ThinkPad 135W AC Adapter (Slim tip) - Switzerland	94
Power	AC Adapter	4X20E50568	ThinkPad 135W AC Adapter (Slim tip) - Italy/Chile	94
Power	AC Adapter	4X20M26256	Lenovo 45W Standard AC Adapter (USB Type-C) EU	30
Power	AC Adapter	4X20M26257	Lenovo 45W Standard AC Adapter (USB Type-C) Denmark	30
Power	AC Adapter	4X20M26260	Lenovo 45W Standard AC Adapter (USB Type-C) UK	30
Power	AC Adapter	4X20M26261	Lenovo 45W Standard AC Adapter (USB Type-C) Switzerland	30
Power	AC Adapter	4X20M26262	Lenovo 45W Standard AC Adapter (USB Type-C) Italy	30
Power	AC Adapter	4X20M26272	Lenovo 65W Standard AC Adapter (USB Type-C) EU	35
Power	AC Adapter	4X20M26273	Lenovo 65W Standard AC Adapter (USB Type-C) Denmark	35
Power	AC Adapter	4X20M26276	Lenovo 65W Standard AC Adapter (USB Type-C) UK	35
Power	AC Adapter	4X20M26277	Lenovo 65W Standard AC Adapter (USB Type-C) Switzerland	35
Power	AC Adapter	4X20M26278	Lenovo 65W Standard AC Adapter (USB Type-C) Italy	35
Power	AC Adapter	4X20Q88539	ThinkPad Slim 135W AC Adapter (Slim tip) US	71
Power	AC Adapter	4X20Q88543	ThinkPad Slim 135W AC Adapter (Slim tip) EU	71
Power	AC Adapter	4X20Q88544	ThinkPad Slim 135W AC Adapter (Slim tip) Denmark	54
Power	AC Adapter	4X20Q88547	ThinkPad Slim 135W AC Adapter (Slim tip) UK/HK/SGP/SRI	54
Power	AC Adapter	4X20Q88548	ThinkPad Slim 135W AC Adapter (Slim tip) Switzerland	54
Power	AC Adapter	4X20Q88549	ThinkPad Slim 135W AC Adapter (Slim tip) Italy/Chile	54
Power	AC Adapter	4X20S56717	ThinkPad Slim 230W AC Adapter (Slim-tip) - EU/INA/VIE/ROK	99
Power	AC Adapter	4X20S56718	ThinkPad Slim 230W AC Adapter (Slim-tip) - DENMARK	99
Power	AC Adapter	4X20S56721	ThinkPad Slim 230W AC Adapter (Slim-tip) - UK/HK/SGP/SRI	100
Power	AC Adapter	4X20S56722	ThinkPad Slim 230W AC Adapter (Slim-tip) - SWITZERLAND	99
Power	AC Adapter	4X20S56723	ThinkPad Slim 230W AC Adapter (Slim-tip) - ITALY/CHILE	99

Category	SubCategory	PN	DESCRIPTION	EUR
Power	AC Adapter	4X20V24678	ThinkPad Slim 65W AC Adapter (USB-C) - EU/INA/VIE/ROK	41
Power	AC Adapter	4X20V24679	ThinkPad Slim 65W AC Adapter (USB-C) - DENMARK	43
Power	AC Adapter	4X20V24682	ThinkPad Slim 65W AC Adapter (USB-C) - UK/HK/SGP/SRI	43
Power	AC Adapter	4X20V24683	ThinkPad Slim 65W AC Adapter (USB-C) - SWITZERLAND	41
Power	AC Adapter	4X20V24684	ThinkPad Slim 65W AC Adapter (USB-C) - ITALY/CHILE	41
Power	AC Adapter	4X20Z84001	ThinkCentre 230W AC Adapter (slim tip) - Italy/Chile	94
Power	AC Adapter	4X21H27804	ThinkPad 135W AC Adapter (USB-C) - EU	69
Power	AC Adapter	4X21H27805	ThinkPad 135W AC Adapter (USB-C) - DK	70
Power	AC Adapter	4X21H27808	ThinkPad 135W AC Adapter (USB-C) - UK	70
Power	AC Adapter	4X21H27809	ThinkPad 135W AC Adapter (USB-C) - CH	70
Power	AC Adapter	4X21H27810	ThinkPad 135W AC Adapter (USB-C) - IT	70
Power	AC Adapter	4X21K07722	Lenovo 65W AC Adapter (Round tip) - EU	35
Power	AC Adapter	4X21K07723	Lenovo 65W AC Adapter (Round tip) - DK	35
Power	AC Adapter	4X21K07726	Lenovo 65W AC Adapter (Round tip) - UK	35
Power	AC Adapter	4X21K07727	Lenovo 65W AC Adapter (Round tip) - CH	35
Power	AC Adapter	4X21K07728	Lenovo 65W AC Adapter (Round tip) - IT	35
Power	Power Bank	40ALLG2WWW	Lenovo Go USB-C Laptop Power Bank (20000mAh)	131
Power	Power Bank	40ALLG1WWW	Lenovo Go USB-C Mobile Power Bank (10000mAh + Qi Wireless)	76
Power	Travel Adapter	40AW0045EU	Lenovo 45W USB-C AC Portable Adapter (Eu Plug)	34
Power	Travel Adapter	40AK0065WW	65W USB-C DC Travel Adapter	50
Power	Travel Adapter	40AW0065EU	Lenovo 65W USB-C AC Travel Adapter EU	65
Power	Travel Adapter	40AW0065WW	Lenovo 65W USB-C AC Travel Adapter - WW	74