

- : Canonet G-III 17
- : Canonet 28
- : Canon A35F
- ▲: Canon Datematic

Canon

35MM RANGEFINDER CAMERA ACCESSORIES



● ■ 5-00242-20 Canolite D

The Canolite D permits completely automatic flash photography with the Canonet G-III 17 or Canonet 28. The user simply connects the unit, focuses and shoots. If the meter needle is outside the camera's metering range, the camera-to-subject distance should be altered.


▲ ● ■ □ 5-63061-00

Release 30

▲ ● ■ □ 5-63062-00

Release 50

These Cable Releases are for use when slow shutter speeds are used on either of the Canonets, and vibration must be kept to a minimum, such as when the cameras are tripod mounted for time exposures.



■ 5-64017-00 Self Timer 8

The Self Timer 8 allows the photographer to get himself into the picture. It screws into the release socket on the Canonet 28, and after winding, gives a ten-second delay before tripping the shutter.



■ 5-01341-00 Hot Shoe Adapter

The Hot Shoe Adapter permits conventional flash units with PC cord to be used with the Canonet 28.



▲ ● ■ □ 4-45015-00 Canonet Hood 4

A lens hood is essential for preventing excessive flare and ghosts and for enabling the owner of a Canonet to get the most out of his superb Canon lens.



▲ 5-00291-20 Canolite ED

The Canolite ED is an automatic electronic flash unit designed for use with the Canon Datematic or the Canon 110 cameras. To use it, the photographer simply mounts the unit, focuses and takes the picture with perfect flash results every time.