



Xerox Part Number	OEM	Cartridge designation	Color	OEM Part Number	Page Yields
006R03322	HP	HP LJ Pro M201, M225 series High Yield	MONO	CF283X	2900
006R03336	HP	HP LJ Enterprise M604, M605, M606, M625, M630 Series	MONO	CF281A	13300
006R03337	HP	HP LJ Enterprise M605, M606, M625, M630 Series	MONO	CF281X	31200
006R03331	HP	HP CLJ Enterprise M680 Series Black High Yield	K	CF320X	21400
006R03332	HP	HP CLJ Enterprise M680 Series Cyan	C	CF321A	17100
006R03333	HP	HP CLJ Enterprise M680 Series Yellow	Y	CF322A	17100
006R03334	HP	HP CLJ Enterprise M680 Series Magenta	M	CF323A	17100
006R03338	HP	HP CLJ Enterprise flow MFP M880 Series Black	K	CF300A	29500
006R03339	HP	HP CLJ Enterprise flow MFP M880 Series Cyan	C	CF301A	32000
006R03340	HP	HP CLJ Enterprise flow MFP M880 Series Yellow	Y	CF302A	32000
006R03341	HP	HP CLJ Enterprise flow MFP M880 Series Magenta	M	CF303A	32000
006R03342	HP	HP CLJ CM6030, CLJ CM6040 MFP Series Black	K	CB390A	19500
006R03343	HP	HP CLJ Enterprise M855 Series Black	K	CF310A	29000
006R03344	HP	HP CLJ Enterprise M855 Series Cyan	C	CF311A	31500
006R03345	HP	HP CLJ Enterprise M855 Series Yellow	Y	CF312A	31500
006R03346	HP	HP CLJ Enterprise M855 Series Magenta	M	CF313A	31500
006R03326	Brother	Brother HL-3142CW, HL-3152CDW, HL-3172CDW, DCP-9017CDW, DCP-9022CDW, MFC-9142CDN, MFC-9332CDW, MFC-9342CDW Black	K	TN242BK	2500
006R03327	Brother	Brother HL-3142CW, HL-3152CDW, HL-3172CDW, DCP-9017CDW, DCP-9022CDW, MFC-9142CDN, MFC-9332CDW, MFC-9342CDW Cyan	C	TN246C	2300
006R03329	Brother	Brother HL-3142CW, HL-3152CDW, HL-3172CDW, DCP-9017CDW, DCP-9022CDW, MFC-9142CDN, MFC-9332CDW, MFC-9342CDW Yellow	Y	TN246Y	2300
006R03328	Brother	Brother HL-3142CW, HL-3152CDW, HL-3172CDW, DCP-9017CDW, DCP-9022CDW, MFC-9142CDN, MFC-9332CDW, MFC-9342CDW Magenta	M	TN246M	2300
006R03330	Brother	Brother HL-L2300D, HL-L2340DW, HL-L2360DN, HL-L2365DW, DCP-L2500D, DCP-L2520DW, DCP-L2540DN, DCP-L2560DW, MFC-L2700DW, MFC-L2720DW, MFC-L2740DW	MONO	TN2320	2600
006R03352	Brother	Brother HL-1110, HL-1112, HL-1112A, HL-1212W, DCP-1510, DCP-1512, DCP-1512A, DCP-1610W, DCP-1612W, MFC-1810, MFC-1910W	MONO	TN1050	1000
006R03350	OKI	OKI MC851, MC861 Series Black	K	44059168	7000
006R03349	OKI	OKI MC851, MC861 Series Cyan	C	44059167	7300
006R03348	OKI	OKI MC851, MC861 Series Magenta	M	44059166	7300
006R03347	OKI	OKI MC851, MC861 Series Yellow	Y	44059165	7300
006R03353	Canon	i-SENSYS LBP6000, LBP6020, LBP6030, MF3010	MONO	3484B002	1600
006R03354	Kyocera	Kyocera ECOSYS FS-2100, M3040, M3540	MONO	TK-3100	12500