














Machine	Explode	Code	Description
GL346 Buffalo Manual Fill Water Boiler 10Ltr	1		Lid Handle
GL346 Buffalo Manual Fill Water Boiler 10Ltr	2		S/S Lid
GL346 Buffalo Manual Fill Water Boiler 10Ltr	3		Body Handle
GL346 Buffalo Manual Fill Water Boiler 10Ltr	4		S/S Reservoir
GL346 Buffalo Manual Fill Water Boiler 10Ltr	5	AF336	Tap
GL346 Buffalo Manual Fill Water Boiler 10Ltr	6	AK109	140C Thermostat
GL346 Buffalo Manual Fill Water Boiler 10Ltr			Manual-Reset Assembly
GL346 Buffalo Manual Fill Water Boiler 10Ltr	7		Steel Support Bracket
GL346 Buffalo Manual Fill Water Boiler 10Ltr	8		S/S Base
GL346 Buffalo Manual Fill Water Boiler 10Ltr	9		Bottom Cover
GL346 Buffalo Manual Fill Water Boiler 10Ltr	10		Plastic Foot
GL346 Buffalo Manual Fill Water Boiler 10Ltr	11		105 Thermostat
GL346 Buffalo Manual Fill Water Boiler 10Ltr	12	AK110	Temperature Dial
GL346 Buffalo Manual Fill Water Boiler 10Ltr	13		Red Control Light
GL346 Buffalo Manual Fill Water Boiler 10Ltr			Green Control Light
GL346 Buffalo Manual Fill Water Boiler 10Ltr	14		Power Cord & Plug
GL346 Buffalo Manual Fill Water Boiler 10Ltr	15		Power Cord Clip