






ENG - Do not begin to install product until you have read and understood the instructions and warnings contained in this user guide. Before installing make sure the supporting surface will support the combined load of the equipment and hardware. Screws must be tightly secured. Do not overtighten screws or damage can occur and product may fail. Never exceed the Maximum Load Capacity. Always use an assistant or mechanical lifting equipment to safely lift and position equipment. This product is intended for indoor use only. Use of this product outdoors could lead to product failure or personal injury. To reduce the risk of electric shock or fire, do not expose product to water or moisture. Be sure power cord is routed so that it will not be tripped on, stepped on, or pinched by heavy items. Avoid overloading electrical outlets or extension cords. Always disconnect the power cord from the power outlet when installing, servicing, or not using the product for an extended period of time. Do not block ventilation slots or fan exhaust on product. Blocking airflow could damage product. Arrange product to allow air to flow freely around product. Keep product away from direct sunlight or any source of heat. For support please call 800-4-SIGNAGE.




ENG Parts (Before beginning, make sure you have all parts shown below).

Pa	arts List	O 1	D. 14
A	Description	Qty	Part #
A	base assembly	4	454 04005 0
	KILH540-EUK	1 1	151-P1995-S
	KILH540-S-EUK		151-4995-S
	KILH542-EUK	1	151-P1995-S
	KILH542-S-EUK	1	151-4995-S
	KILH543-EUK	1	151-P1995-S
	KILH543-S-EUK	1	151-4995-S
	KILH546-EUK	1	151-P1995-M
	KILH546-S-EUK	1	151-4995-M
	KILH547-EUK	1	151-P1995-M
	KILH547-S-EUK	1	151-4995-M
	KILH548-EUK	1	151-P1995-M
	KILH548-S-EUK	1	151-4995-M
	KILH549-EUK	1	151-P1995-L
	KILH549-S-EUK	1	151-4995-L
	KILH550-EUK	1	151-P1995-L
	KILH550-S-EUK	1	151-4995-L
	KILH555-EUK	1	151-P1995-XL
	KILH555-S-EUK	1	151-4995-XL
в	adaptor bracket	2	202-SG1695
С	display hood		
	KILH540-EUK	1	151-P1957
	KILH540-S-EUK	1	151-4957
	KILH542-EUK	1	151-P1959
	KILH542-S-EUK	1	151-4959
	KILH543-EUK	1	151-P1961
	KILH543-S-EUK	1	151-4961
	KILH546-EUK	1	151-P1963
	KILH546-S-EUK	1	151-4963
	KILH547-EUK	1	151-P1965
	KILH547-S-EUK	1	151-4965
	KILH548-EUK	1	151-P1967
	KILH548-S-EUK	1	151-4967
	KILH549-EUK	1	151-P1969
	KILH549-S-EUK	1	151-4969
	KILH550-EUK	1	151-P1971
	KILH550-S-EUK	1	151-4971
	KILH555-EUK	1	151-P1973
-	KILH555-S-EUK	1	151-4973
D	4mm allen wrench	1	560-1146
E	M4 x 12mm	4	520-1079
F	M4 x 25mm	4	520-1082
G	M6 x 12mm	4	520-1050
н	M6 x 25mm	4	520-1211
1	M8 x 12mm	4	520-1724
J	M8 x 25mm	4	520-1101
K	M4 x 1mm washer	4	540-9400
L	M6/M8 x 1.5mm washer	8	540-9406
N	1/4" (6mm) height spacer	8	600-1215
IN	M8 x 50mm	4	521-1013













ENG Center adaptor brackets vertically on back of screen.












6


- ENG Height adjustment: Tighten or loosen. ESP Ajuste de la altura: Apretar o afloje.
- FRN Réglage de la hauteur : Serrer ou desserrez.
- DEU Höheneinstellung: Anziehen oder lösen.
- NEL Aanpassing van hoogte: Aandraaien of losdraaien. ITL Regolazione dell'altezza: Stringere oppure allentare. ČEŠ Nastavení výšky: Utáhněte anebo uvolnit. SLK Nastavenie výšky: Utáhněte alebo uvoľniť. POR Ajuste da altura: Apertar ou desaperte.

- TÜR Yükseklik ayarı: Sıkmak veya gevşetin.











ENG Back view











ENG Insert media player (not included).



9-3 New cover bracket so it rests on media player. Tighten crews to secure bracket in place.



ENG Cable management



NILПЭ40-EUN, NILПЭ40-Э-EUN, NILПЭ42-EUN, NILПЭ42-Э-EUN, NILПЭ43-EUN, NILПЭ43-S-EUN, NILПЭ50-S-EUN, NILПЭ50-S-EUN, NILПЭ50-S-EUN, NILПЭ50-S-EUN, NILПЭ53-S-EUN, NILПЭ53-S-EUN

LIMITED FIVE-YEAR WARRANTY

Peerless Industries, Inc. ("Peerless") warrants to original end-users of Peerless[®] products will be free from defects in material and workmanship, under normal use, for a period of five years from the date of purchase by the original end-user (but in no case longer than six years after the date of the product's manufacture). At its option, Peerless will repair or replace, or refund the purchase price of, any product which fails to conform with this warranty.

In no event shall the duration of any implied warranty of merchantability or fitness for a particular purpose be longer than the period of the applicable express warranty set forth above. Some states do not allow limitations on how long a implied warranty lasts, so the above limitation may not apply to you.

This warranty does not cover damage caused by (a) service or repairs by the customer or a person who is not authorized for such service or repairs by Peerless, (b) the failure to utilize proper packing when returning the product, (c) incorrect installation or the failure to follow Peerless' instructions or warnings when installing, using or storing the product, or (d) misuse or accident, in transit or otherwise, including in cases of third party actions and force majeure.

In no event shall Peerless be liable for incidental or consequential damages or damages arising from the theft of any product, whether or not secured by a security device which may be included with the Peerless® product. Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you.

This warranty is in lieu of all other warranties, expressed or implied, and is the sole remedy with respect to product defects. No dealer, distributor, installer or other person is authorized to modify or extend this Limited Warranty or impose any obligation on Peerless in connection with the sale of any Peerless® product.

This warranty gives specific legal rights, and you may also have other rights which vary from state to state.



Peerless-AV

2300 White Oak Circle Aurora, IL 60502 Email: tech@peerlessmounts.com Ph: (800) 865-2112 Fax: (800) 359-6500 www.peerless-av.com

© 2018, Peerless Industries, Inc.

Peerless-AV Europe

Unit 3 Watford Interchange, Colonial Way, Watford, Herts, WD24 4WP, United Kingdom Customer Care 44 (0) 1923 200 100 www.peerless-av.com

© 2018, Peerless Industries, Inc.

Peerless-AV de Mexico Ave de las Industrias 413 Parque Industrial Escobedo Escobedo N.L Mexico 66062 Servicio al Cliente 01-800-849-65-77 www.peerless-av.com

© 2018, Peerless Industries, Inc.