

Early Streamer Emission lightning rod

Principle and operating

The Active property excitation advance is obtained by a device named « impulse device ». Its principle consists in storing electrostatic energy present in the atmosphere at a stormy cloud approach to release the ascending discharge excitation in a good

This device operates with an integrated sensor which measures the surrounding electrical field value.

It generates then a polarity inversion of the lightning rod head, creating a sudden amplification of the electrical field on its point.

Active 112® characteristics

- · Consideration of the energy character to choose the streamer able to become an ascending leader,
- Autonomous and clean energy source : atmospheric electrical
- · Cloud polarity consideration,
- · Optimized head bending radius to reduce the corona effect and guarantee the excitation advance,
- · Guarantee of functioning in all weather conditions,
- High resistance to corrosion thanks to its manufacture in 304 L stainless steel,
- In compliance with NFC 17-102 standard of September 2011

Active 12® radii of protection

The Active 120 has been tested in laboratory according to NFC 17-102 standard protocol.

These tests showed, according to models, excitation advances from 12 µs to 60µs regarding to a simple rod.








Enhanced protection zone

The Active 112 radii of protection here below mentioned, are defined for the four Np levels of protection (from I to IV) regarding to h real height between the lightning rod point and the highest point of the structure to protect.

ΔT : Excitation advance, for *Active* 128, ΔT=12, 25, 45 and 60μs

- Np: level of protection with more or less severity (I to IV) determined by
- the lightning risk assessment with the Lightning Risk software according to NFC 17-102 standard.
- h(m): height between the lightning rod point and the highest point of the structure to protect.



Active 10®	AFB10121D			AFB10251D			AFB10451D			AFB10601D						
h (m)	I	II	III	IV	I	II	III	IV	- I	П	III	IV	I	II	Ш	IV
2	11	13	16	19	17	20	23	26	25	28	32	36	31	34	39	43
4	23	27	32	37	34	39	46	52	51	57	65	72	63	69	78	85
5	28	34	41	46	42	49	57	65	63	71	81	89	79	86	97	107
6	29	34	42	48	43	49	58	66	63	71	81	90	79	87	97	107
8	30	36	43	50	43	50	59	67	64	72	82	91	79	87	98	108
10	30	37	45	52	44	51	61	69	64	72	83	92	79	88	99	109
20	32	41	51	60	45	54	65	73	65	74	86	97	80	89	102	113
30	32	42	55	65	45	55	68	80	65	75	89	101	80	90	104	116
60	32	42	57	72	45	55	70	85	65	75	90	105	80	90	105	120

• Active range

Model	ΔT (μs)	Lightning counter
AFB10121D	12	Not included
AFB17121D	12	Included

Model	ΔT (μs)	Lightning counter			
AFB10451D	45	Not included			
AFB17451D	45	Included			

Model	ΔT (μs)	Lightning counter
AFB10251D	25	Not included
AFB17251D	25	Included

Model	ΔT (μs)	Lightning counter			
AFB10601D	60	Not included			
AFB17601D	60	Included			

Lightning counter AFV0907CF



Active test

The *Active* can be tested on site with AFV0050TT wire test case (initial check, periodical checks according to NFC 17-102 standard and decrees in force, maintenance,...)

Simple and fast, this test can be done either disassembling the lightning rod, either using the AFV0087PT test perch, to check lightning rods at a height of 8 meters without dismantling.

This tester power supply operates with a battery (provided). The display with indicator lights indicates instantly the obtained result (positive or negative).



Wired tester AFV0050TT

Packing

Complete lightning rod packed in reinforced cardboard box

- Weight: 3,00 Kg

- Dimensions: 430 x 110 x 110 mm













