

How to configure DAP-1365 as Access Point with non-default wireless SSID?

(Note: Please ensure the device LED is blinking orange colour before you do setup. If it is not blinking in orange colour, follow the guide on page 4 on how to reset the device before follow the guide to setup.)


Step 1: Copy down the wireless name and password that was on the sticker of the device.



Step 2: Plug **DAP-1365** direct to power outlet.



Step 3: Click on the **Computer Icon** on the right bottom side of the Windows.



Step 4: Select the **Wireless network name** that was copy down.



Step 5: Enter the **Wifi Password** which had copy down earlier on. Click on **OK**.

Type the network security key

Security key:

Hide characters

You can also connect by pushing the button on the router.

Step 6: Open Internet Explorer and enter **http://192.168.0.50** on the URL bar.



Step 7: Click on **X**.

WELCOME

Internet — Existing Router — DAP-1365 — Wi-Fi Client

This wizard will guide you through configuring your new DAP-1365

Step 1: Connecting your device
Step 2: Configuring your settings
Step 3: Setting a password for your device


Language:

Step 8: Click on **OK**.

Message from webpage

Do you want to abandon all changes you made to this wizard?

Step 9: Click on **Settings** and select **Extender**.



Step 10: Select Ethernet for Existing Network.

Existing Network

Existing Network:

Step 11: 2.4Ghz Extended Wi-Fi

- Give a different **Wi-Fi Name** in the box beside **Wi-fi Name (SSID)**.
- Give a different **Wi-Fi Password** in the box beside **Password**

2.4GHz Extended Wi-Fi

Status: Enabled

Wi-Fi Name(SSID):

Security:

Password:

Show Password:

Wi-Fi Channel:

Channel Width:

HT20/40 coexistence: Enabled

Step 12: Click on Save.

Settings >> Wireless

Save

Step 13 a) Plug DAP-1365 direct to power outlet.

- Connect LAN Cable from **DAP-1365** to LAN port of the **Router**.



Step 14: Use computer to connect to the wireless you had setup.


--- END ---

How to reset DAP-1365.

Step 1: Plug **DAP-1365** direct to power outlet.

Step 2: Power on **DAP-1365** and wait for 1 min.

Step 3: Use a paper clip to press and hold the **Reset Button** for 30 second.



Step 4: Wait for **2 min** for the device to fully power on after reset.

--- END ---