



ROTUNDA

# Replace your Missing T-Kits! Now 10% off! Buy Online and Save an Addition 5%\*

## CO-TKIT-2015P1-FL

ESST,6F15,TRANS & PTU

- 307-724, Protector, Center Support Seal
- 307-725, Fixture, Bench Mounting
- 307-421-01, Adapter for 307-421
- 308-941, Installer, Intermediate Shaft Seal
- 310-206-01, Adapter for 310-206



## CO-TKIT-2019P9-F

ESST, 6.7L 7.3L

- 303-050-01 - Adapter for - 303-050
- 303-1250-01 - Installer, Rear Seal
- 303-1509-01 - Adapter for - 303-1509
- 303-1661/3 - Socket, OVC
- 303-1700 - Installer, Front Seal
- 303-1702 - Locking Tool, VCT
- 303-1703 - Guards, RTV



## CO-TKIT-2018P6-F

ESST,RANGER FRT&RR AXLE,T-CASE

- 205-1059, Gauge, Tube
- 205-1060, Bearing, Dummy Pinion
- 308-614, Installer, Output Shaft Seal
- 308-976, Installer, Output Shaft Seal
- 205-1051, Remover/Installer, Axle Tube Bushing
- 205-1052, Installer, Axle Seal
- 205-1053, Installer, Axle Tube Needle Bearing
- 205-1054, Protector, Pinion Thread
- 205-1055, Installer, Companion Flange
- 205-1058, Installer, Differential Side Bearing



## CO-TKIT-2019P8-FL

ESST,FRONT AXLE, BI TURBO

- 205-1068 - Installer, Companion Flange
- 303-1611-03 - Adapter for 303-1611
- 303-1635 - Remover/Installer, Fuel Injection Pump
- 303-1637 - Tool, Crankshaft Holding
- 303-1642 - Remover/Installer, Viscous Van
- 303-1650 - Tool, Timing Belt Mounting
- 303-1651 - Adapter, Compression Test



## CO-TKIT-2016P1-FL

ESST,SUPERDUTY AXLE

- 205-1018, Tube, Installation
- 205-1020, Installer, Pinion Seal
- 205-1021, Protector, Protection, Pinion Thread
- 205-1022, Installer, Companion Flange
- 205-1023, Installer, Inner Pinion Bearing Cup
- 205-1024, Installer, Outer Pinion Bearing Cup
- 205-1025, Tube, Gauge
- 205-1026, Pinion, Dummy Pinion Bearing
- 205-1027, Adjuster, Differential Bearing Adjustment
- 205-1028, Installer, Inner Pinion Bearing Cup
- 205-1029, Installer, Inner wheel end bearing cup
- 205-1030, Installer, Outer wheel end bearing cup
- 205-1031, Installer, Pinion Seal

- 205-1032, Protector, Pinion Thread
- 205-1033, Installer, Companion Flange
- 205-1034, Installer, Differential Bearing
- 205-1035, Pinion, Dummy Pinion Bearing
- 205-1036, Gauge, Tube
- 205-1037, Installer, Pinion Bearing Cup
- 205-1038, Installer, Pinion Bearing Head
- 308-942, Installer, Slip Yoke Seal
- 308-943, Installer, Input Seal
- 308-944, Installer, Front Output Seal
- 308-945, Installer, Fixed Yoke Output Seal
- 205-1019, Pinion, Dummy Bearing Pinion



\* Must include Promo Code 2021ESSTCOTKIT when placing your online order.

To Order Visit [www.OneRotunda.com](http://www.OneRotunda.com) today!

Promo #F021-60  
Pricing effective through June 30, 2021.

Products sold F.O.B. Shipping Point.  
Pricing subject to change without notice.



<b>Item</b>	<b>Description</b>	<b>Tools Included</b>
CO-TKIT-2005D1-F	ESST, FORD 500, FREESTYLE, MONTEGO	204-362, Front Subframe Bushing Remover/Installer 205-813, Rear Drive Unit Bushing Remover/Installer 303-1139, Installer, Camshaft Seal 303-1140, Bracket, Engine Lifting 303-290A-12, Adapter For 303-290A (Support Hook) 307-524, Installer, Fluid Pump Seal 307-526, Installer, Transfer Gear Dust Cover 307-527, Installer, Output Shaft Seal 307-528, Installer, Output Shaft Seal 307-529, Installer, Output Shaft Seal 307-537, Installer, Output Shaft Inner Seal 307-538, Installer, Shift Shaft Fluid Seal 307-539, Installer, Forward Clutch Seal 307-541, Installer, Transfer Gear Bearing 307-542, Installer, Front Pump Cover
CO-TKIT-2011AW-FLM	ESST, PTU SEAL REMOVER & INSTALLER	308-777, PTU Input Shaft Seal Remover / Installer
CO-TKIT-2011MT-FL	ESST, MIRROR RR TOOLS	501-190, Remover, Auto Dimming Rear View Mirror 501-191, Installer, Rear View Mirror
CO-TKIT-2012A-FL	ESST, ESCAPE	205-990, Installer, Axle Seal 303-1502, Eye, Lifting 303-1550, Alignment Tool, Crankshaft Vibration Damper 303-1552, Alignment Tool, Camshaft 303-290-05A, Adapter for 303-290A 303-290B-18, Adapter for 303-290B 303-290B-19, Adapter for 303-290B 303-393-02, Adapter For 303-393 303-393A, Locking Tool, Flywheel 308-875, Installer, Inboard Cover Seal 308-876, Installer, Outboard Cover Seal 308-877, Installer, Pinion Output Seal 308-878, Installer, Input Seal 310-250, Disconnect Tool, Fuel Line
CO-TKIT-2012B-FL	ESST, 6F50/55/6R80 TRANSMISSION	307-689, Installer, Bearing Cup 307-691, Tester, Torque Converter Leak
CO-TKIT-2012C-FL	ESST, HF35 & B6 TRANSMISSION	307-692, Tool, Transfer Gear Preload 307-693, Installer, Transfer Gear Bearing Cup 307-694, Installer, Manual Lever Seal 307-695, Tool, Quick Disconnect, 1/2 Inches 205-075, Installer, Rear Wheel Hub Seal 205-062, Installer, Differential Bearing 308-847, Installer, Input Shaft Seal 308-849, Installer, Shift Shaft 308-880, Installer, Driveshaft Seal
CO-TKIT-2012D-FL	ESST, 6F50/55 TRANS. & SEATBELT	307-696, TRS Retaining Pin Remover 501-403, Pretensioner Quick Connect Tool
CO-TKIT-2012E-F	ESST, SUPERDUTY AXLE	205-991, Front Axle Radius Bushing Remover/Installer
CO-TKIT-2012J-FL	ESST, FOCUS MMT6 TRANSMISSION	308-112, Output Drive Flange Seal Installer
CO-TKIT-2013B-FL	ESST, 6R80 TRANSMISSION	307-713, Installer, Roller Bearing 307-714, Installer, Needle Bearing 307-715, Installer, Output Seal (4X2) 307-716, Installer, Teflon Seal 307-717, Remover, Kostal Sleeve 307-718, Installer, Axle Seal
CO-TKIT-2013B-ROW	ESST, 6R80 TRANSMISSION	307-713, Installer, Roller Bearing 307-714, Installer, Needle Bearing 307-715, Installer, Output Seal (4X2) 307-716, Installer, Teflon Seal 307-717, Remover, Kostal Sleeve 307-718, Installer, Axle Seal

**To Order Visit [www.OneRotunda.com](http://www.OneRotunda.com) today!**



<b>Item</b>	<b>Description</b>	<b>Tools Included</b>
CO-TKIT-2013D-FL	ESST,CHILD SAFETY LOCK GAUGE	501-407, Child Lock Tester Tool
CO-TKIT-2013F-ROW2	ESST,FIESTA ST-1.0L FOX ENG	303-1602, Locking Tool, Crankshaft 303-1603, Installer, Front Cover Seal 303-1604, Timing Peg, Crankshaft TDC 303-1605, Alignment Tool, Camshaft 303-1606, Locking Tool, Variable Camshaft Timing 303-1611, Multiplier, Torque 303-1611-01, Adapter for 303-1611 307-708, Installer, Lube Tube
CO-TKIT-2014A-ROW	ESST,DPS6 CLUTCH BEARING	307-722, Protector, Clutch Bearing 307-723, Installer, Turbine Seal 303-1611-02, Adapter for 303-1611, Torque Multiplier
CO-TKIT-2014J-FL	ESST,BLOCK HEATER SOCKET	303-1638, Block Heater Socket
CO-TKIT-2015P1-ROW	ESST,6F15,TRANS & PTU	307-724, Protector, Center Support Seal 307-725, Fixture, Bench Mounting 307-421-01, Adapter for 307-421 310-206-01, Adapter for 310-206 308-941, Installer, Intermediate Shaft Seal
CO-TKIT-2016P1-ROW	ESST, SUPERDUTY AXLE	308-942, Installer, Slip Yoke Seal 308-943, Installer, Input Seal 308-944, Installer, Front Output Seal 308-945, Installer, Fixed Yoke Output Seal 205-1018, Tube, Installation 205-1019, Pinion, Dummy Bearing Pinion 205-1020, Installer, Installer, Pinion Seal 205-1021, Protector, Protection, Pinion Thread 205-1022, Installer, Companion Flange 205-1023, Installer, Inner Pinion Bearing Cup 205-1024, Installer, Outer Pinion Bearing Cup 205-1025, Tube, Gauge 205-1026, Pinion, Dummy Pinion Bearing 205-1027, Adjuster, Differential Bearing Adjustment 205-1028, Installer, Inner Pinion Bearing Cup 205-1029, Installer, Inner wheel end bearing cup 205-1030, Installer, Outer wheel end bearing cup 205-1031, Installer, Pinion Seal 205-1032, Protector, Pinion Thread 205-1033, Installer, Companion Flange 205-1034, Installer, Differential Bearing 205-1035, Pinion, Dummy Pinion Bearing 205-1036, Gauge, Tube 205-1037, Installer, Pinion Bearing Cup 205-1038, Installer, Pinion Bearing Head
CO-TKIT-2016P2-FL	ESST, TREMEC,MUSTANG & GT350	308-957, Installer, Input Shaft Seal 308-958, Remover, 4th Gear 308-959, Installer, Output Shaft Seal
CO-TKIT-2016P2-ROW	ESST,TREMEC,MUSTANG & GT350	308-957, Installer, Input Shaft Seal 308-958, Remover, 4th Gear 308-959, Installer, Output Shaft Seal
CO-TKIT-2016P6-REPL	ESST,10R80 TRANSMISSION REPL	307-747, Installer, Sizer, Input Shaft Solid Sealing Rings; Large
CO-TKIT-2016P6-ROW	ESST,10R80 TRANSMISSION PH2	307-747, Installer, Sizer, Input Shaft Solid Sealing Rings; Large 307-748, Installer, Sizer, Input Shaft Solid Sealing Rings; Small 307-749, Installer, Sizer, R2-S3 Shaft Solid Seal 307-750, Installer, Converter Seal
CO-TKIT-2017P2-FL	ESST, GTDI ENGINE	303-1643, Tool, Flywheel Locking 303-1645, Installer, Front Crankshaft Seal 303-1647, Tool, Balance Shaft Alignment 303-1648, Tool, Scissor Gear

**To Order Visit [www.OneRotunda.com](http://www.OneRotunda.com) today!**



Item	Description	Tools Included
CO-TKIT-2017P3-ROW	ESST, 9.75 PLENUM 4 PIN SOCKET	205-1049, Socket, 9.75 Plenum 4 pin
CO-TKIT-2017W2-ROW	ESST, 6F35 AWD ADAPTER	307-718-01, Adapter for 307-718-01
CO-TKIT-2018P1-F	ESST, 3.0L LION DIESEL ENGINE	303-1670, Pin, Camshaft Locking 303-1671, Pin, Crankshaft Locking 303-1672, Installer, Crankshaft Sea 303-1675, Adapter, Seal Remover 303-1677, Locking Tool, Flywheel 303-1679, Timing Tool, Fuel Pump Rear Access 303-1674, Holding Tool, Camshaft Sprocket 303-1678, Remover, Fuel Pump Pulley Holding Tool 303-1673, Installer, Camshaft Seal 303-1676, Installer, Crankshaft Position Sensor Ring 303-1511-01, Adapter for 303-1511 303-1682, Adapter, Compression Tester 310-266, Remover, Fuel Injector 303-1681, Bar, Spreader 303-1684, Lifting Eye
CO-TKIT-2018P2-FL	ESST, 8F24,35,40,57 XMSN	307-589-01, Adapter for 307-589 307-753, Tester, Electric One Way Clutch 307-756, Installer, Input Shaft Support Seal 307-757, Installer, Turbine Snap Ring 307-758, Installer, Axle Seal -FWD 307-759, Installer, Axle Seal -AWD 307-754, Installer, 2,8 Piston & Snap Ring 307-755, Fixture, Bench Mount 307-764, Installer/Sizer, Stator Teflon Seal 307-766, Installer, Input Shaft Snap Ring 307-760, Installer, Converter Seal 307-761, Installer, Turbine Seal 307-762, Staking Tool, Turbine Seal 307-765, Protector, Turbine Seal 307-767, Compressor, 3-8 Spring 307-768, Compressor, Manual Lever Detent Spring 307-763, Tool, Turbine Seal Deburring 307-769, Fixture, Bench Mount 307-770, Compressor, 1-5_2-8 Piston Spring 307-771, Release Tool, Accumulator 307-772, Installer, Oil Funnel 307-773, Fixture, Bench Mount
CO-TKIT-2018P3-FL	ESST, DV5 R NEO 1.5L ENGINE	303-172-01, Adapter for 303-172 303-172-02A, Adapter for 303-172 303-172-05, Adapters for 303-172-02A 303-732, Alignment Peg, Crankshaft 303-733, Installer, Crankshaft Front Seal 303-735, Alignment Peg, Camshaft 303-737, Guide, Crankshaft Bearing 303-738, Installer, Crankshaft Rear Seal 303-1662, Installer, Camshaft Seal
CO-TKIT-2018P3-ROW	ESST, DV5 R NEO 1.5L ENGINE	303-1662, Installer, Camshaft Seal 303-172-01, Adapter for 303-172 303-172-02A, Adapter for 303-172 303-172-05, Adapters for 303-172-02A 303-732, Alignment Peg, Crankshaft 303-733, Installer, Crankshaft Front Seal 303-735, Alignment Peg, Camshaft 303-737, Guide, Crankshaft Bearing 303-738, Installer, Crankshaft Rear Seal

**To Order Visit [www.OneRotunda.com](http://www.OneRotunda.com) today!**



Item	Description	Tools Included
CO-TKIT-2018P4-ROW	ESST,MAVERICK 2.0L&3.0L ENGINE	303-1511-02, Adapter for 303-1511 303-1685, Alignment Tool, Camshaft 303-1686, Holding Tool, Camshaft 303-1687, Installer, VCT Solenoid Seal 303-1688, Preload Tool, Balance Shaft 303-1689, Holding Tool, Crank Damper
CO-TKIT-2018P6-F	ESST,RANGER FRT&RR AXLE,T-CASE	205-1059, Gauge, Tube 205-1060, Bearing, Dummy Pinion 308-614, Installer, Output Shaft Seal 308-976, Installer, Output Shaft Seal 205-1051, Remover/Installer, Axle Tube Bushing 205-1052, Installer, Axle Seal 205-1053, Installer, Axle Tube Needle Bearing 205-1054, Protector, Pinion Thread 205-1055, Installer, Companion Flange 205-1058, Installer, Differential Side Bearing
CO-TKIT-2019P12-F	ESST, MOTORHOME BRACKET	303-1704, Brackets, Engine Removal
CO-TKIT-2019P13-F	ESST, ENGINE PLATE VN127	303-1701, Plate, Engine Lift
CO-TKIT-2019P1-FL	ESST,10R80MHT,3.0L,8.15,8.8RDU	307-651-03, Adapter, Lift Fixture 307-661-02, Adapter for 307-661 307-802, Installer, Input Shaft 303-1696, Holding Fixture, Camshaft 205-1061, Installer, 8.8 Pinion Seal 205-1062, Installer, 8.1 Pinion Seal 205-1065, Installer, Pinion Seal 205-1066, Installer, Bushing 205-1067, Installer, Output Shaft, AWD
CO-TKIT-2019P1-ROW	ESST,10R80MHT,3.0L,8.15,8.8RDU	307-651-03, Installer, Output Shaft, AWD 307-802, Installer, Input Shaft 307-661-02, Adapter for 307-661 303-1696, Holding Fixture, Camshaft 205-1061, Installer, 8.8 Pinion Seal 205-1062, Installer, 8.1 Pinion Seal 205-1065, Installer, Pinion Seal 205-1066, Installer, Bushing 205-1067, Installer, Output Shaft, AWD
CO-TKIT-2019P1-ROW2	ESST,10R80MHT,8.15,8.8RDU, FRT	205-1061, Installer, 8.8 Pinion Seal 205-1062, Installer, 8.1 Pinion Seal 205-1065, Installer, Pinion Seal 205-1066, Installer, Bushing 205-1067, Installer, Output Shaft, AWD 307-651-03, Adapter, Lift Fixture 307-661-02, Adapter for 307-661 307-802, Installer, Input Shaft
CO-TKIT-2019P2-L	ESST,HUD EYEBOXES	501-421, Gauge, HUD Eye Box 501-422, Gauge, HUD Eye Box
CO-TKIT-2019P3-FL	ESST,10R60 XMSN	307-651-02, Adapter, Super Sub Assembly Lifting 307-732-02, Adapter for 307-732 307-780, Installer, Converter Seal 307-781, Remover/Installer, R2 Needle Bearing 307-782, Installer, Output Shaft Seal 307-783, Installer, Roll Pin 307-784, Tool, OWC Alignment 307-785, Compressor, Clutch Spring 307-786, Installer/Sizer, F7 Seal, Input Shaft 307-787, Installer/Sizer, F8 Seal, Input Shaft 307-788, Installer, Sleeve 307-789, Installer, R3 Bearing 307-790, Adapter, Endplay Check 307-796, Installer/Sizer, Input Shaft Solid Sealing Rings, F2 307-803, Installer/Sizer, F1 Seal Guide 307-804, Installer/Sizer, F9 Seal Guide

**To Order Visit [www.OneRotunda.com](http://www.OneRotunda.com) today!**



Item	Description	Tools Included
CO-TKIT-2019P3-ROW	ESST,10R60 XMSN	307-651-02, Adapter, Super Sub Assembly Lifting 307-732-02, Adapter for 307-732 307-780, Installer, Converter Seal 307-781, Remover/Installer, R2 Needle Bearing 307-782, Installer, Output Shaft Seal 307-783, Installer, Roll Pin 307-784, Tool, OWC Alignment 307-785, Compressor, Clutch Spring 307-786, Installer/Sizer, F7 Seal, Input Shaft 307-787, Installer/Sizer, F8 Seal, Input Shaft 307-788, Installer, Sleeve 307-789, Installer, R3 Bearing 307-790, Adapter, Endplay Check 307-796, Installer/Sizer, Input Shaft Solid Sealing Rings, F2 307-803, Installer/Sizer, F1 Seal Guide 307-804, Installer/Sizer, F9 Seal Guide
CO-TKIT-2019P3-ROW2	ESST, 10R60 TOOLS	307-780, Installer, Converter Seal 307-804, Installer/Sizer, F9 Seal Guide
CO-TKIT-2019P4-FL	ESST 1.5L, 2.5L	303-1649, Tool, Camshaft Locking 303-1699, Alignment Tool, Crank Sensor
CO-TKIT-2019P4-ROW	ESST 1.5L, 2.5L	303-1649, Tool, Camshaft Locking 303-1699, Alignment Tool, Crank Sensor
CO-TKIT-2019P4-ROW1	ESST 2.5L	303-1699, Alignment Tool, Crank Sensor
CO-TKIT-2019P5-FL	ESST, HF35_HF45 XMSN	307-791, Installer, Differential Bearing 307-792, Gauge, Differential Preload 307-793, Installer, Bearing Cup 307-794, Gauge, Transfer Gear Preload 307-795, Installer, Differential Bearing Cup 307-805, Pin Set, Alignment
CO-TKIT-2019P5-ROW	ESST, HF35_HF45 XMSN	307-791, Installer, Differential Bearing 307-792, Gauge, Differential Preload 307-793, Installer, Bearing Cup 307-794, Gauge, Transfer Gear Preload 307-795, Installer, Differential Bearing Cup 307-805, Pin Set, Alignment
CO-TKIT-2019P6-FL	ESST, TREMEC XMSN	307-778, Installer, Input shaft Seal 307-779, Installer, Output Shaft Seal
CO-TKIT-2019P6-ROW	ESST, TREMEC XMSN	307-778, Installer, Input shaft Seal 307-779, Installer, Output Shaft Seal
CO-TKIT-2019P7-FL	ESST,10R140 XMSN,M275,M300 AXL	205-1069, Installer, Wheel End Seal - M275_M300HD 205-1070, Installer, Wheel End Seal - M300LD & M300 BRG 307-421A, Leak Tester, Torque Converter 307-651-04, Adapter for 307-651 307-732/1A, Base 307-732-03, Adapter for 307-732 307-741-01, Front Support/Cover 307-798, Remover/Installer, OWC 307-799, Gauge, End Play 307-800, Gauge, Endplay Puck 307-807, Installer, Converter Seal 307-809, Installer/Sizer, Input Shaft Solid Sealing Rings, F0 307-810, Installer/Sizer, Input Shaft Solid Sealing Rings, F9 307-811, Installer/Sizer, Input Shaft Solid Sealing Rings, F2 307-812, Installer/Sizer, Input Shaft Solid Sealing Rings, F1 307-813, Installer, Output Shaft Seal

**To Order Visit [www.OneRotunda.com](http://www.OneRotunda.com) today!**



Item	Description	Tools Included
CO-TKIT-2019P7-ROW	ESST,10R140 XMSN,M275,M300 AXL	205-1069, Installer, Wheel End Seal - M275_M300HD 205-1070, Installer, Wheel End Seal - M300LD & M300 BRG 307-421A, Leak Tester, Torque Converter 307-651-04, Adapter for 307-651 307-732/1A, Base 307-732-03, Adapter for 307-732 307-741-01, Front Support/Cover 307-798, Remover/Installer, OWC 307-799, Gauge, End Play 307-800, Gauge, Endplay Puck 307-807, Installer, Converter Seal 307-809, Installer/Sizer, Input Shaft Solid Sealing Rings, F0 307-810, Installer/Sizer, Input Shaft Solid Sealing Rings, F9 307-811, Installer/Sizer, Input Shaft Solid Sealing Rings, F2 307-812, Installer/Sizer, Input Shaft Solid Sealing Rings, F1 307-813, Installer, Output Shaft Seal
CO-TKIT-2019P7-ROW1	ESST,10R140 XMSN,M275,M300 AXL	205-1069, Installer, Wheel End Seal - M275_M300HD 205-1070, Installer, Wheel End Seal - M300LD & M300 BRG 307-421A, Leak Tester, Torque Converter 307-732/1A, Base 307-732-03, Adapter for 307-732 307-741-01, Front Support/Cover 307-807, Installer, Converter Seal 307-813, Installer, Output Shaft Seal
CO-TKIT-2019P9-ROW	ESST, 6.7L 7.3L	303-050-01, Adapter for - 303-050 303-1250-01, Installer, Rear Seal 303-1509-01, Adapter for - 303-1509 303-1661/3, Socket, OVC 303-1700, Installer, Front Seal 303-1702, Locking Tool, VCT 303-1703, Guards, RTV
CO-TKIT-2019W1-FL	ESST,10R80-MUSTANG 4 CYL ONLY	307-776, Socket, Output Shaft Locknut
CO-TKIT-2019W1-ROW	ESST,10R80-MUSTANG 4 CYL ONLY	307-776, Socket, Output Shaft Locknut
CO-TKIT-2020W1-FL	ESST, ALIGNMENT PINS	307-797, Pins and Studs, Alignment
CO-TKIT-2020W1-ROW	ESST, ALIGNMENT PINS	307-797, Pins and Studs, Alignment
CO-TKIT-2020W2-FL	ESST, 10R80 LATE ADDS	307-817, Installer, Sleeve 307-818, Installer, R2 Bearing 307-819, Cup, Receiver 307-820, Installer, R3 roller bearing
CO-TKIT-2020W2-ROW	ESST, 10R80 LATE ADDS	307-817, Installer, Sleeve 307-818, Installer, R2 Bearing 307-819, Cup, Receiver 307-820, Installer, R3 roller bearing

**To Order Visit [www.OneRotunda.com](http://www.OneRotunda.com) today!**