

---

# **SST Storage System Master Index**

---

**MARCH 2023**

**To Order Special Service Tools Call Bosch/OTC at 1-800-933-8335**

# Table of Contents

---

	<i>Page #</i>
<b>Part Number References</b> .....	<b>2-8</b>
<b>Drawer Liner References</b> .....	<b>9-21</b>
Drawer 1 .....	9
Drawer 2 .....	9
Drawer 3 .....	10
Drawer 4 .....	10
Drawer 5 .....	11
Drawer 6 .....	11
Drawer 7 .....	12
Drawer 8 .....	12
Drawer 9 .....	13
Drawer 10 .....	13
Drawer 11 .....	14
Drawer 12 .....	14
Drawer 13 .....	15
Drawer 14 .....	15
Drawer 15 .....	16
Drawer 16 .....	16
Drawer 17 .....	17
Drawer 18 .....	17
Drawer 19 .....	18
Drawer 20 .....	18
Drawer 21 .....	19
Drawer 22 .....	19
Drawer 23 .....	20
Drawer 24 .....	20
Drawer 25 .....	21
<b>Essential Tools Not Located in Storage Cabinets</b> .....	<b>22-24</b>
<b>Hybrid Electric Vehicle (HEV) Workstation</b> .....	<b>25</b>

**To Order Special Service Tools Call Bosch/OTC at 1-800-933-8335**

# Part Number References

TOOL #	TOOL DESCRIPTION	DRAWER #	TOOL #	TOOL DESCRIPTION	DRAWER #
00001-00010-01	POWER STEERING PUMP PRESSURE GAUGE SET	9	*00002-A0830	CABLE KIT	IN SHOP
*00001-47092	ADAPTER	9	*00002-A0870	PRINTER	IN SHOP
*00001-47093	ADAPTER	9	00002-ESUPPT-01	ENGINE SUPPORT BAR	IN SHOP
*00002-00008	90 DEGREE FITTING	9	00002-JUMPR-KIT	OBD-II JUMPER CONNECTOR KIT (4 COMPONENTS)	5
00002-00039	39MM SOCKET	11	*00002-V8150	TESTER	IN SHOP
*00002-00907-10	PULLER RING HALF	15	*01014-00094	RADIO ANTENNA	8
*00002-00907-11	REPLACER SHAFT COLLAR	15	*01014-00095	RADIO ADAPTER	8
*00002-00907-12	TUBE REMOVER / REPLACER (140MM/ 5 1/2 INCH)	15	*01014-00096	GPS ANTENNA	8
*00002-00907-13	COLLET HALVES (FOR ATM FRONT PUMP)	15	*01014-00097	GPS ANTENNA ADAPTER	8
*00002-00907-14	5TH GEAR HUB PULLER	15	*01014-00098	XM ANTENNA	8
*00002-00907-7	REMOVER / REPLACER (400MM/ 15 3/4 INCH)	15	*01014-00099	XM ANTENNA ADAPTER	8
*00002-00907-8	FORCING SCREW	15	01018-00118	SUPRA DIAGNOSTIC CABLE	21
*00002-00907-9	BEARING PULLER 304839 JAW	15	*01216-00111	TAPERED TAP	5
00002-00909-01	ALL TRAC TOOL SET	9	*01216-00112	STRAIGHT TAP	5
00002-00920	DRIVER HANDLE	12	*01216-00113	SLIDE HAMMER	5
00002-00921	REAR AXLE SEAL & BEARING DRIVER	6	*01216-00114	PLUG PULLER (X3)	5
00002-00922	REAR AXLE SEAL & BEARING DRIVER	6	*01216-00115	RUBBER PLUG (X5)	5
00002-01775	SEAT HEATER ATTACHMENT KIT	21	*01216-00116	PIPE PLUG (X10)	5
*00002-01780	REPLACEMENT NEEDLES	21	*01216-00117	TAP ALIGNMENT BRIDGE W/ BOLTS	5
00002-02955	BEAM TORQUE WRENCH	1	01413-00002 (GRX-5100T)	HIGH VOLTAGE BATTERY SERVICE UNIT	HEV
00002-04020-KIT	PRIUS-PHV HV BATTERY STRAP	6	01413-00003 (A580)	INTERLOCK CONNECTOR	HEV
00002-06020-01	PLASTIC PRY TOOL KIT	21	01413-00004 (A533)	LOW VOLTAGE CABLE (R)	HEV
*00002-06100	LARGE ANGLED GROMMET PRY TOOL	21	01413-00005 (A573)	AC POWER CORD (S)	HEV
*00002-06200	LARGE ANGLED PRY TOOL	21	01413-00006 (A574 / A575)	D/C ADAPTER KIT (T / U)	HEV
*00002-06300	THIN, FLAT PRY TOOL	21	01413-00007 (A571)	UNIVERSAL HIGH VOLTAGE CABLE (V)	HEV
*00002-06400	INTERIOR CURVED PRY TOOL	21	01413-00008 (A572)	UNIVERSAL LOW VOLTAGE CABLE (W)	HEV
*00002-06500	ANGLED GROMMET PRY TOOL	21	01413-00009 (A505)	HIGH VOLTAGE CABLE (E)	HEV
*00002-06600	FLAT GROMMET PRY TOOL	21	01413-00010 (A296)	UNIVERSAL FUSE BOX	HEV
*00002-06700	PANEL CLIP PRY TOOL	21	01413-00012 (A586)	A/C CIRCUIT TESTER	HEV
*00002-06800	SMALL ANGLED GROMMET PRY TOOL	21	01413-00013 (A501)	HIGH VOLTAGE CABLE (A)	HEV
*00002-06900	SMALL PRY TOOL	21	01413-00014 (A502)	HIGH VOLTAGE CABLE (B)	HEV
*00002-09077-01	OCCUPANT SEAT WEIGHTS	24	01413-00015 (A503)	HIGH VOLTAGE CABLE (C)	HEV
*00002-09077-TRY	SEAT WEIGHT TRAY	24	01413-00016 (A504)	HIGH VOLTAGE CABLE (D)	HEV
00002-09090-01	OCCUPANT CLASSIFICATION SEAT WEIGHT SET	24	01413-00017 (BCU - 64)	INTERFACE ECU - 64	HEV
*00002-10001	CARRYING CASE W/ INSERT	15	01413-00018 (A507)	HIGH VOLTAGE CABLE (G)	HEV
00002-11100-02	TRANSMISSION FILL SYSTEM	IN SHOP	01413-00019 (A541)	CELL VOLTAGE CABLE (J)	HEV
00002-12000-01	KDSS FLUID PRESSURE PUMP KIT	IN SHOP	01413-00020 (A551)	TEMPERATURE SENSOR CABLE (K)	HEV
00002-12001-01	VEHICLE DRAIN TUBE AUGER	7	01413-00021 (A552)	CELL VOLTAGE CABLE (L)	HEV
*00002-12020-01	FORCING BOLT	13	01413-00022 (A531)	LOW VOLTAGE CABLE (P)	HEV
*00002-13525-01	POWER STEERING ADAPTER	9	01413-00023 (A532)	LOW VOLTAGE CABLE (Q)	HEV
*00002-13526-01	POWER STEERING ADAPTER	9	01413-00024 (A521)	STACK BALANCE HARNESS (I)	HEV
*00002-16500	FABRIC FASTENERS	21	01413-00031 (A564)	BANANA JACK EXTENSION CABLE (X)	HEV
*00002-17750	SEAT HEATER ATTACHMENT TOOL	21	(A810)	HIGH VOLTAGE CABLE BLACK	HEV
00002-1ESBU-KIT	ENGINE SUPPORT BAR BRACKET	IN SHOP	(A811)	HIGH VOLTAGE CABLE RED	HEV
*00002-211711-01	SHAFT PROTECTOR	24	(A812)	HIGH VOLTAGE CABLE ORANGE	HEV
00002-2SUPP	RATCHETING STRAP (2)	6	(A813)	CELL VOLTAGE/DATA CABLE	HEV
00002-35000	3/4 INCH DRIVE TORQUE WRENCH	IN SHOP	*01413-00069	MILLIOHM METER UNIT	HEV
00002-35001	NUT WRENCH HOLDING TOOL	1	*01413-00070	CLIP-TYPE TEST LEAD SET	HEV
00002-35027	27MM HEX SOCKET	5	*01413-00071	TEMPERATURE SENSOR	HEV
*00002-48043-01	POWER STEERING PUMP ADAPTER	9	01413-00072	INSULATED GLOVE SET, RUBBER WITH LEATHER PROTECTORS, SIZE M	HEV
*00002-48044-01	POWER STEERING PUMP ADAPTER	9	01413-00073	INSULATED GLOVE SET, RUBBER WITH LEATHER PROTECTORS, SIZE L	HEV
00002-71368-01	PRY TOOL	20			
00002-90080	SUBFRAME ALIGNMENT PINS	11			

\* This tool is a component of an essential kit.

# Part Number References

TOOL #	TOOL DESCRIPTION	DRAWER #	TOOL #	TOOL DESCRIPTION	DRAWER #
01413-00074	INSULATED GLOVE SET, RUBBER WITH LEATHER PROTECTORS, SIZE XL	HEV	01813-00055	FLASHLIGHT	HEV
01413-00075	CANVAS GLOVE BAG (3)	HEV	01813-00056	3/8" DRIVE EXT W/SCREWDRIVER HANDLE	HEV
01413-00076	GLOVE INFLATOR	HEV	01813-00057	8MM MAGNETIC EXTENSION	HEV
01413-00077-1	42" LOOPER TUBE, ORANGE (4)	HEV	01813-00058	NUTSTARTER - COMPOSITE	HEV
01413-00077-2	BASE, CONE (4)	HEV	01813-00059	DIE CUT FOAM	HEV
01413-00078	4-6FT ADJUSTABLE BARRIER (4)	HEV	*01815-00102	DIGITAL ANGLE GAUGE	IN SHOP
01413-00080	ARC PROTECTIVE HELMET & FACE SHIELD	HEV	01815-00104	DRIVE HANDLE ADAPTER	12
01413-00081	LARGE INSULATED MAT (30" X 48")	HEV	01815-00105	DRIVE HANDLE ADAPTER	12
01413-00082	SMALL INSULATED MAT (12" X 30") (3)	HEV	*01816-00103	3 LINE LASER, SMALL TRIPOD, TARGET LASER BOARD	IN SHOP
01413-00083	CAUTION TAPE, ROLL	HEV	*01816-00104	TRIPOD	IN SHOP
01413-00088	INSULATED APRON	HEV	*01816-00105	LASER MEASURE	IN SHOP
*01414-00100	INVERTER CAP PLUG	21	*01816-00108	DIGITAL T-BEVEL	IN SHOP
01416-00119 A & B (A619)	HIGH VOLTAGE CABLE	HEV	*01816-00109	LASER ENHANCING GLASSES	IN SHOP
01416-00120 (A620)	CELL VOLTAGE CABLE	HEV	07112-66040-01	PRESSURE PLATE REMOVER	20
01416-00121 (A621)	TEMPERATURE SENSOR CABLE	HEV	07112-76060-01	MAGNETIC CLUTCH STOPPER	20
01418-00106 (A702)	CELL VOLTAGE INTERFACE	HEV	09013-1C160-01	TORXPLUS SOCKET, T40	1
01418-00107 (A703)	TEMPERATURE SENSOR INTERFACE	HEV	09013-1C551-01	TORX SOCKET, E14	1
01418-00109 (A704)	CELL VOLTAGE INTERFACE	HEV	09013-1C560-01	TORX SOCKET, E16	1
01418-00110 (A705)	TEMPERATURE SENSOR INTERFACE	HEV	09013-6C600-01	LONG BALL HEXAGON WRENCH 5MM	10
01418-00111 (A706)	CELL VOLTAGE AND TEMPERATURE SENSOR INTERFACE	HEV	09013-7C310	10MM BI-HEXAGON SOCKET (1/2 INCH DRIVE)	1
01418-00112 (A707)	UNIVERSAL CELL VOLTAGE BCU CABLE	HEV	09032-00100-01	GASKET SEAL CUTTER	4
01418-00113 (A708)	UNIVERSAL TEMPERATURE BCU CABLE	HEV	09042-2C100	CRIMPER	20
01418-00114 (A709)	VOLTAGE BCU CABLE	HEV	09043-50080	8MM BI-HEXAGON WRENCH (1/2 INCH DRIVE)	1
01421-00151	3K LIFT TABLE	IN SHOP	*09200-WA020	FUEL HOSE ADAPTER	25
*01717-00122	TPWS TESTER	24	*09200-WA190	CRANKSHAFT SOCKET	25
*01717-00123	OBD-II DONGLE	24	*09200-WA520	FUEL INJECTOR FIXTURE	25
*01717-00124	POWER SUPPLY	24	*09200-WA550-01	6CYL OIL PRESSURE ADAPTER	25
*01717-00125	USB CABLE	24	*09200-WA570	FLEX PLATE ALIGNMENT PIN	25
*01717-00126	MAGNET	24	*09200-WA680	FUEL INJECTOR FIXTURE SPACERS	25
*01717-00127	RJ45 CABLE	24	*09200-WA830	FUEL INJECTOR INSTALLATION GAUGE	25
01813-00034	SOCKET-8MM STD 3/8", 6 PT	HEV	*09200-WA960	CRANKCASE PRESSURE ADAPTER	25
01813-00035	SOCKET-10MM STD 3/8", 6 PT	HEV	*09200-WA970	4 CYL OIL PRESSURE ADAPTER	25
01813-00036	SOCKET-12MM STD 3/8", 6 PT	HEV	*09200-WA980	FUEL INJECTOR CAPS	25
01813-00037	SOCKET-14MM STD 3/8", 6 PT	HEV	*09202-00010-01	ADAPTER	4
01813-00038	SOCKET-8MM DP 3/8", 6 PT	HEV	09202-00018-01	VALVE SPRING COMPRESSOR ADAPTER 12	4
01813-00039	SOCKET-10MM DP 3/8", 6 PT	HEV	09202-00020-01	VALVE SPRING COMPRESSOR ADAPTER	4
01813-00040	SOCKET-12MM DP 3/8", 6 PT	HEV	**09202-43013-01	VALVE SPRING COMPRESSOR W/ADAPTER	4
01813-00041	SOCKET-14MM DP 3/8", 6 PT	HEV	09213-54015-01	CRANKSHAFT PULLEY HOLDING TOOL	8
01813-00042	10MM MAGNETIC EXTENSION	HEV	09213-58012-01	CRANKSHAFT PULLEY HOLDING TOOL	3
01813-00043	TORQUE WRENCH 3/8"	HEV	09213-58013-01	CRANKSHAFT PULLEY HOLDING TOOL	3
01813-00044	RATCHET 3/8"	HEV	09213-58014-01	CRANKSHAFT PULLEY HOLDING TOOL	3
01813-00045	3/8" X 6" EXTENSION	HEV	09213-70011-01	CRANKSHAFT PULLEY HOLDING TOOL	3
01813-00046	3/8" X 3" EXTENSION	HEV	*09214-00011	BOLT	8
01813-00047	#2 X 6" PHILLIPS SCREWDRIVER	HEV	*09214-00021-01	BOLT	8
01813-00048	#1 X 6" PHILLIPS SCREWDRIVER	HEV	*09214-00030-01	BOLT	8
01813-00049	3/16" X 6" CABINET TIP SCREWDRIVER	HEV	*09216-04010	BELT TENSION WRENCH	1
01813-00050	5/16" X 6" FLAT TIP SCREWDRIVER	HEV	09216-42010	BELT TENSION WRENCH SET	1
01813-00051	7" DIAGONAL CUTTERS	HEV	*09216-42020	ADAPTER	1
01813-00052	8" NEEDLE NOSE PLIER	HEV	09221-18010-01	PISTON PIN REMOVER	2
01813-00053	6" NEEDLE NOSE PLIER	HEV	09221-18020-01	GUIDE PIN REMOVER	2
01813-00054	MAGNETIC PICKUP TOOL	HEV	09223-15020	CRANKSHAFT REAR OIL SEAL REPLACER	3
			09223-15030	CRANKSHAFT REAR OIL SEAL REPLACER	3
			09223-22010	CRANKSHAFT FRONT OIL SEAL REPLACER	2

# Part Number References

TOOL #	TOOL DESCRIPTION	DRAWER #	TOOL #	TOOL DESCRIPTION	DRAWER #
09223-46011-01	CRANKSHAFT FRONT OIL SEAL REPLACER	13	*09268-41600	ADAPTER	22
09223-47020-01	REAR CRANKSHAFT SEAL INSTALLER	5	*09268-43080-01	UNION, M8	23
09223-56010-01	CRANKSHAFT REAR OIL SEAL REPLACER	7	*09268-43100-01	UNION, M10	22
09223-63010-01	CRANKSHAFT REAR OIL SEAL REPLACER	2	*09268-43120-01	UNION, M12	22
09223-75010-01	OIL SEAL REPLACER	6	*09268-44080-01	ADAPTER, M8	22
09223-78010-01	CRANKSHAFT OIL SEAL REPLACER	3	*09268-44100-01	ADAPTER, M10	22
09224-00010-01	OXYGEN SENSOR SOCKET	1	*09268-44120-01	ADAPTER, M12	22
09224-74010-01	ENGINE BALANCER BACKLASH TOOL	1	09268-45101-1A	EFI FUEL PRESSURE GAUGE SET	22
09228-06500-02A	OIL FILTER WRENCH	3	*09268-52011	INJECTION MEASURING ATTACHMENT	22
09228-07502	OIL FILTER WRENCH	3	09268-74010-01	INJECTOR REMOVER	1
*09248-05410	VALVE LIFTER PRESS	4	09276-75010-01	HYDRAULIC LASH ADJUSTER	1
*09248-05420	VALVE LIFTER STOPPER (7MM AND 9MM)	4	*09300-WA070	8MM HEX EXTENSION	25
*09248-07010-01	VALVE CLEARANCE ADJUSTING COMPRESSOR	3	09308-00010	OIL SEAL PULLER	3
*09248-07020-01	ADJUSTING SHIM REMOVER	3	09309-12020-01A	5TH GEAR REPLACER	13
09248-55040	VALVE CLEARANCE ADJUST TOOL SET	4	*09309-36010-01	TRANSMISSION REAR BEARING REPLACER	9
09248-77010-01	VALVE CLEARANCE ADJUSTING COMPRESSOR SET	3	09309-37010-01	TRANSMISSION BEARING REPLACER	2
09249-37010-01	VVT SET BOLT WRENCH	1	*09316-12010	TRANSFER BEARING REPLACER	9
09249-37020-01	STRAIGHT PIN PULLER	21	*09316-20011-01	TRANSFER BEARING REPLACER	9
09249-63010-01	TORQUE WRENCH ADAPTER	13	*09318-12010	SPANNER WRENCH	9
09250-53010-01	SPACER, ENGINE MOUNT	1	09318-12010-4PIN	4 PIN FRONT WHEEL BEARING LOCK NUT SOCKET KIT	14
09260-39021-01	INJECTOR SEAL TOOL SET	1	09318-12010-8PIN	8 PIN SOCKET KIT	14
09260-39030-01	INJECTOR SEAL TOOL SET	1	*09318-12010-8PIN-1	8 PIN SOCKET	14
09260-39040-01	INJECTOR SEAL TOOL SET	17	*09318-12010-8PIN-2	PIN INSTALLER/REMOVER	14
09260-48010-01	FUEL INJECTOR REMOVER	17	*09318-12010-8PIN-3	REPLACEMENT PINS (QTY. 8)	14
09260-48020-01	DELIVERY PIPE GUIDE PIN	17	*09318-12010-INST	PIN INSTALLER/REMOVER	14
*09261-03011-01	HOLDER	1	*09318-12010-PINS	SOCKET PIN SET (QTY. 4)	14
*09261-03020-01	GUIDE	1	*09318-12010-SOCK	4 PIN FRONT WHEEL BEARING LOCK NUT SOCKET	14
*09261-03030-01	GUIDE	1	*09318-20010-01	SIDE BEARING NUT WRENCH	9
*09268-00020-01	T-JOINT	22	*09322-03010-01	INPUT SHAFT HOLDING SOCKET	5
*09268-00030-01	FUEL TUBE CONNECTOR	22	*09322-03020-01	INPUT SHAFT HOLDING JOINT BAR	5
*09268-08070-01	HOSE	22	*09322-03030-01	INPUT SHAFT HOLDING PLATE	5
09268-21010-01	FUEL HOSE PULLER	1	09322-35010-01	INPUT SHAFT HOLDING TOOL SET	5
*09268-27011	NO. 2 UNION	22	09325-40010-01	TRANSMISSION OIL PLUG	7
09268-31012	INJECTION MEASURING TOOL SET	22	*09326-03010-01	OUTPUT SHAFT ADJUSTING NUT WRENCH	6
*09268-41061	NO. 3 UNION	22	*09326-03020-01	SOCKET ADAPTER	6
*09268-41071	NO. 4 UNION	22	09326-35010-01	OUTPUT SHAFT ADJUSTING NUT WRENCH AND ADAPTER	6
*09268-41081	NO. 6 UNION	22	09326-35020-01	OUTPUT SHAFT ADJUSTING NUT WRENCH	4
*09268-41091	NO. 7 UNION	22	09326-71010-01	OUTPUT SHAFT HOLDING WRENCH	10
*09268-41100	CLAMP	22	09326-71020-01	LOCK NUT SOCKET WRENCH	7
*09268-41110	ADAPTER	22	09326-71030-01	OUTPUT SHAFT HOLDING PLATE	10
*09268-41120	3-WAY	22	09330-00021	COMPANION FLANGE HOLDING TOOL	12
*09268-41130	ADAPTER	22	*09330-00030	PIN	12
*09268-41140	ADAPTER	22	09340-00010-01	QUICK CONNECT REMOVER	12
*09268-41160	ADAPTER	22	09387-00010-01	TRANSFER OIL SEAL REPLACER	6
*09268-41250-01	T-JOINT	22	09387-00090	BEARING RETAINER INSTALLER	2
*09268-41260-01	EFI FUEL PRESSURE GAUGE ASSEMBLY	22	09387-00130-01	COUNTER DRIVE GEAR NUT WRENCH	1
*09268-41280-01	HOSE JOINT	22	09388-40010-01	INPUT SHAFT OIL SEAL REPLACER	2
*09268-41300	CLAMP	22	09500-WA020	AXLE SHAFT REMOVAL TOOL	23
*09268-41310	CLAMP	22	*09500-WA030	AXLE SHAFT COLLAR	25
*09268-41400	CLAMP	22	*09500-WA170	50MM WRENCH	25
*09268-41500	CLAMP	22	*09502-12010-01	BEARING REPLACER	9
*09268-41500-01	FUEL TUBE CONNECTOR	22	09506-42010-01	BEARING RACE REPLACER	17
*09268-41500-01	HOSE BANDS (6)	22			

\* This tool is a component of an essential kit.

# Part Number References

TOOL #	TOOL DESCRIPTION	DRAWER #	TOOL #	TOOL DESCRIPTION	DRAWER #
09506-42020-01	BEARING RACE REPLACER	17	09631-10021-01	RACK & PINION STOPPER ADJUSTMENT TOOL	13
09506-42030-01	BASE	17	09631-12071	STEERING RACK OIL SEAL TEST TOOL	11
09509-25011	REAR AXLE BEARING LOCK NUT WRENCH	12	09631-12090	SEAL RING TOOL	13
09518-36030-01	OIL SEAL & BEARING REPLACER	2	09634-60013	STEERING KNUCKLE CENTERING GAUGE	12
09520-01010-02	DRIVE SHAFT REMOVER ATTACHMENT	5	09634-60014	STEERING KNUCKLE CENTERING GAUGE	12
09520-10021	TRANS HOUSING REMOVER	3	09649-17010	STEERING KNUCKLE TOOL	15
09520-32040-01	SLIDE HAMMER (5LB.)	7	*09650-14010-01	WHEEL GUIDE PINS	25
09521-25011-01	REAR AXLE SHAFT PULLER	7	09650-53010-01	WHEEL GUIDE PINS	18
09521-25023-01	REAR AXLE SHAFT PULLER ADAPTER	6	09670-00010-01	FRONT CROSS MEMBER GUIDE TOOL	12
09521-26000-01	REAR AXLE SHAFT PULLER SPACER	6	*09700-WA010	STRUT BOLT SOCKET	25
09521-60010-01	REAR AXLE SHAFT PULLER ADAPTER	6	*09700-WA020	5MM STRUT BOLT	25
09521-60020-01	REAR AXLE TOOL NO. 3	12	*09700-WA040	FLEX PLATE HOLDING TOOL	25
09527-10011-01	REAR AXLE SHAFT BEARING REMOVER	15	09700-WA050-01	TRANSMISSION RELEASE TOOL	17
09527-17011	REAR AXLE BEARING REMOVER	14	09700-WA250	STRUT BOLT SOCKET 6MM STRUT BOLT	17
*09528-00002-1	GUIDE PIN C	14	09709-00002	BRAKE PEDAL FORCE GAUGE	18
*09528-00002-2	GUIDE PIN B	14	09709-29018	LSPV GAUGE SET	18
*09528-00002-3	GUIDE PIN A	14	09710-04101-01	FRONT SPEED SENSOR INSTALLER	7
*09528-05000-01	CENTER BOLT	14	*09710-07021	BUSHING REMOVER	13
*09528-05010-01	HANDLE, COMPRESSOR PLATE 1&2	14	*09710-07031	BUSHING REPLACER	13
*09528-05030-01	WRENCH, SIDE GEAR A	14	*09710-07041	UPPER ARM BASE	13
*09528-05040-01	WRENCH, SIDE GEAR B	14	*09710-07051	UPPER ARM BASE	13
*09528-05050-01	WRENCH, SIDE GEAR C	14	*09710-07062	BUSHING REPLACER	13
09528-52010-01	DIFFERENTIAL GEAR REMOVER & REPLACER SET	14	*09710-07071	UPPER ARM SPACER	13
09554-14010-01	SEAL INSTALLER	13	*09710-07081	LOWER ARM BASE	13
09554-42010-01	OIL SEAL REPLACER	17	09710-18010-01	REAR SUSPENSION BUSH KIT	13
09556-16030-01	DIFFERENTIAL DRIVE PINION HOLDING TOOL #28	11	09710-18020-01	REAR SUSPENSION BUSH KIT	13
09556-30010	DIFFERENTIAL BEARING REMOVER	12	09710-18030-01	REAR SUSPENSION BUSH KIT	13
09564-32011-01	PRELOAD ADAPTER	11	09710-18040-01	FRONT SUSPENSION BUSH KIT	13
09564-33010	DIFFERENTIAL PRELOAD ADAPTER	1	09710-28012-01	FRONT SUSPENSION BUSHING TOOL SET	13
09564-50010-01	DIFFERENTIAL PRELOAD ADAPTER	5	*09711-40010-01	TOE CONTROL LINK REPLACER ARM NO. 1	14
09570-18010-01	REAR DIFF MOUNT CUSHION, R/R	15	*09712-40010-01	TOE CONTROL LINK REPLACER ARM NO. 2	14
09570-18020-01	REAR DIFF MOUNT CUSHION, R/R	15	09716-18010-01	REAR SUSPENSION BUSH R/R	13
09570-22011	DIFFERENTIAL MOUNTING CUSHION		09716-18020-01	FRONT SUSPENSION BUSH R/R	13
	REMOVER / REPLACER	7	09716-18030-01	FRONT SUSPENSION BUSH	13
09570-60010-01	DIFFERENTIAL MOUNTING CUSHION REMOVER AND REPLACER	15	*09719-00010	COMPRESSOR	16
			*09719-00020	PISTON DRIVER	16
09607-60020-01	FRONT WHEEL ADJUSTING NUT WRENCH	15	09719-14020	REAR DISC BRAKE TOOL SET	16
*09608-02011	COVER	15	09726-02041-01	OIL SEAL REPLACER	6
*09608-02021	BOLT & NUT COVER	15	09726-18010-01	STUD BOLT SOCKET	13
*09608-02041	RETAINER (WASHER)	15	*09727-00010	BOLT SET	14
09608-10010-01	STEERING KNUCKLE OIL SEAL REPLACER	11	*09727-00031-01	TOE CONTROL LINK COMPRESSOR ARM	14
09608-16042	FRONT HUB BEARING ADJUSTING TOOL	15	09727-22011-ST	COIL SPRING COMPRESSOR	14
09608-32010	STEERING KNUCKLE OIL SEAL REPLACER	12	09727-30050-01	TOE CONTROL LINK REPLACEMENT KIT	14
09610-20012-01	PITMAN ARM PULLER	13	09727-58010-01	REBOUND SPRING ADJUST PULLER	10
09611-20015-01	TIE ROD END PULLER	14	09727-58020-01	ADAPTER 12	10
09611-22012-01	TIE ROD END PULLER	13	09727-58030-01	ADAPTER 14	10
09612-00012-01	RACK & PINION HOLDING TOOL	13	09727-58100-01	SHOCK ROD HOLDING TOOL	10
09612-30012	STEERING WORM BEARING PULLER	12	09727-58110-01	ATTACHMENT 12	10
09613-22011	STEERING RACK SHAFT BUSHING PULLER	11	09727-58120-01	ATTACHMENT 16	10
09616-00010-02	STEERING SOCKET	12	09727-58130-01	ATTACHMENT 22	10
09616-00020-01	STEERING WORM BEARING ADJUSTING SOCKET	12	09727-58140-01	ATTACHMENT 25	10
09628-00011-01	BALL JOINT PULLER	14	09729-22031	FRONT SPRING UPPER SEAT HOLDER	11
09628-62011-01	BALL JOINT PULLER	13	09730-00010	AIR TUBE SEPARATOR	11

\* This tool is a component of an essential kit.

# Part Number References

TOOL #	TOOL DESCRIPTION	DRAWER #	TOOL #	TOOL DESCRIPTION	DRAWER #
09737-00013-01	BRAKE BOOSTER PUSH ROD GAUGE	16	09891-47020-01	INVERTER CASE SEPERATOR	21
09737-00020-01	BRAKE BOOSTER PUSH ROD WRENCH	16	09893-00020-01	GUIDE PINS	13
09756-00010	REAR DISC BRAKE ADJUSTER	16	09893-10060-01	AC LEAK TEST HIGH ADAPTER	17
09756-48020-1B	ELECTRONIC PARKING BRAKE RELEASE TOOL	24	09893-10070-01	AC LEAK TEST LOW ADAPTER	17
*09756-48060-01	EPB TOOL COMPONENT	24	09893-42010-01	BATTERY HANGER	17
*09756-48070-01	EPB TOOL COMPONENT	24	09893-42040-01	BATTERY HANGER 100MM	13
09760-60020	KDSS FLUID PRESSURE PUMP KIT	IN SHOP	09893-72010-01	LIFT ATTACHMENTS	23
*09800-WA020	WIPER ARM PULLER	25	*09898-00020-01	ATTACHMENT B	IN SHOP
*09800-WA030	HOOD SUPPORT EXTENSIONS	25	*09900-WA040	BREAKER BAR	25
*09800-WA070	FUEL FILLER TUBE	25	09900-WA230-01	WINDOW PLASTIC PRY TOOL	10
*09800-WA110	WINDOW ADJUSTMENT TOOL	25	*09900-WA280-01	DRIVE WRENCH ADAPTER	25
09800-WA120-01	WINDOW SUCTION CUP TOOL	23	*09902-WA010	FUEL INJECTOR SEAL INSTALLER	25
*09800-WA130	WINDOW ADJUSTMENT WRENCH	25	*09902-WA020	FUEL INJECTOR SEAL REMOVAL PLIERS	25
*09800-WA220	WINDOW ADJUSTMENT MEASURING TOOL	25	09905-00040	CONNECTOR PLIER	17
*09800-WA290	FUEL PUMP LOCK RING	25	09922-10010-01	VARIABLE OPEN WRENCH	12
09800-WA300-01	ACC100 RAIL	IN SHOP	09929-00020-01	CRIMPING TOOL S	17
09800-WA320	WINDOW ADJUSTER	20	09930-00010-01	DRIVE SHAFT NUT CHISEL	15
*09800-WA330	DOOR LATCH SPACER	25	09930-42010-01	DRIVE PINION SHAFT NUT CHISEL	17
*09800-WA340	BODY GAP GAUGES	25	09950-00020-01	BEARING RACE PULLER	15
09801-18010-01	DOOR GLASS BOLT HOLDING TOOL	11	09950-30012-01	UNIVERSAL PULLER SET "A"	9
*09808-01010-01	HANDLE	4	09950-40011	UNIVERSAL PULLER SET "B"	8
*09808-01030-01	CROSSBAR	4	09950-50013-01	UNIVERSAL PULLER SET "C"	24
*09808-01040-01	50MM JAW SET	4	09950-60010-01	REPLACER SET #1	24
*09808-01060-01	18MM JAW SET	4	09950-60020-01	REPLACER SET #2	8
*09808-01070-01	105MM JAW SET	4	09950-60030-01	REPLACER SET #3	11
*09808-01080-01	SLIDING JAW SET	4	*09951-00180-01	REPLACER 18	24
09808-01110-01	CLAW	10	*09951-00190-01	REPLACER 19	24
09808-14010-01	FUEL SENDER LOCK RING WRENCH	4	*09951-00200-01	REPLACER 20	24
09808-14031-KIT	FUEL SENDER LOCK NUT WRENCH	4	*09951-00210-01	REPLACER 21	24
09808-14040-01	FUEL PUMP RETAINER TOOL	22	*09951-00220-01	REPLACER 22	24
09808-14050-01	FUEL PUMP HOLDING TOOL	22	*09951-00230-01	REPLACER 23	24
09812-18010-01	TOOL, FRONT DOOR GLASS ADJ	20	*09951-00240-01	REPLACER 24	24
09812-18020-01	TOOL, FRONT DOOR GLASS FIX	20	*09951-00250-01	REPLACER 25	24
09813-00020	PILLAR GARNISH CLIP TOOL	1	*09951-00260-01	REPLACER 26	24
09820-63020-02	ALTERNATOR CLUTCH HOLDING TOOL SET	20	*09951-00270-01	REPLACER 27	24
*09821-63010-02	INSERT	20	*09951-00280-01	REPLACER 28	24
09843-18040	DIAGNOSIS CHECK WIRE #2	18	*09951-00290-01	REPLACER 29	24
09843-18061	SRS CHECK WIRE	21	*09951-00300-01	REPLACER 30	24
09870-00005-01	A/C LINE DISCONNECT KIT	11	*09951-00310-01	REPLACER 31	24
*09870-00015	LOW SIDE A/C LINE DISCONNECT TOOL	11	*09951-00320-01	REPLACER 32	24
*09870-00025	HIGH SIDE A/C LINE DISCONNECT TOOL	11	*09951-00330-01	REPLACER 33	24
09870-60000	LASER RADAR ADJUSTING REFLECTOR	IN SHOP	*09951-00340-01	REPLACER 34	24
09870-60040-02	REFLECTOR C	23	*09951-00350-01	REPLACER 35	24
09870-60060-01	STAND SUPPORT	IN SHOP	*09951-00360-01	REPLACER 36	24
09870-61100-01	TARGET BOARD NO. 1	IN SHOP	*09951-00370-01	REPLACER 37	24
09870-62100-01	TARGET SHEET NO. 1	IN SHOP	*09951-00380-01	REPLACER 38	24
09870-62200-01	TARGET SHEET NO. 2	IN SHOP	*09951-00390-01	REPLACER 39	24
09890-47010-01	ANTI-STATIC MAT SET	21	*09951-00400-01	REPLACER 40	24
*09891-04010-01	ANTI-STATIC MAT	21	*09951-00410-01	REPLACER 41	24
*09891-04020-01	WRIST BAND	21	*09951-00420-01	REPLACER 42	24
*09891-04030-01	GROUNDING WIRE NO. 1	21	*09951-00430-01	REPLACER 43	24
*09891-04040-01	GROUNDING WIRE NO. 2	21	*09951-00440-01	REPLACER 44	24
*09891-47010-1A	SQUEEGEE	21	*09951-00450-01	REPLACER 45	24

\* This tool is a component of an essential kit.

# Part Number References

TOOL #	TOOL DESCRIPTION	DRAWER #	TOOL #	TOOL DESCRIPTION	DRAWER #
*09951-00460-01	REPLACER 46	24	*09954-04010	ARM 25	8
*09951-00470-01	REPLACER 47	24	*09954-04020	ARM 100	8
*09951-00480-01	REPLACER 48	24	*09954-04030	ARM 150	8
*09951-00490-01	REPLACER 49	24	*09954-04040	ARM 200	8
*09951-00500-01	REPLACER 50	24	*09954-05010-01	CLAW NO. 1	24
*09951-00510-01	REPLACER 51	24	*09954-05020	CLAW NO. 2	24
*09951-00520-01	REPLACER 52	24	*09954-05030	CLAW NO. 3	24
*09951-00530-01	REPLACER 53	24	*09954-05040	CLAW NO. 4	24
*09951-00540-01	REPLACER 54	24	*09954-05050-01	CLAW NO. 5	24
*09951-00550-01	REPLACER 55	24	*09954-05060	CLAW NO. 6	24
*09951-00560-01	REPLACER 56	24	*09954-05070	CLAW NO. 7	24
*09951-00570-01	REPLACER 57	24	*09954-05080	CLAW NO. 8	24
*09951-00580-01	REPLACER 58	24	*09955-03011-01	PULLER JAW (SET OF 2)	9
*09951-00590-01	REPLACER 59	24	*09955-03021-01	PULLER JAW (SET OF 3)	9
*09951-00600-01	REPLACER 60	24	*09955-03030-01	LOWER PLATE 130MM	9
*09951-00610-01	REPLACER 61	24	*09955-03040-01	LOWER PLATE 150MM	9
*09951-00620-01	REPLACER 62	24	*09955-04011	CLAW NO. 1	8
*09951-00630-01	REPLACER 63	24	*09955-04021	CLAW NO. 2	8
*09951-00640-01	REPLACER 64	24	*09955-04031	CLAW NO. 3	8
*09951-00650-01	REPLACER 65	24	*09955-04041	CLAW NO. 4	8
*09951-00680-01	REPLACER 68	8	*09955-04051	CLAW NO. 5	8
*09951-00710-01	REPLACER 71	8	*09955-04061	CLAW NO. 6	8
*09951-00720-01	REPLACER 72	8	*09955-04071-01	CLAW NO. 7	8
*09951-00730-01	REPLACER 73	8	09955-04160-01	CLAW NO.16	17
*09951-00750-01	REPLACER 75	11	*09955-05010-01	ADAPTER NO. 1	24
*09951-00770-01	REPLACER 77	11	*09955-05020-01	ADAPTER NO. 2	24
*09951-00780-01	REPLACER 78	8	*09955-05030-01	ADAPTER NO. 3	24
*09951-00790-01	REPLACER 79	8	*09955-05040-01	ADAPTER NO. 4	24
*09951-00810-01	REPLACER 81	11	*09956-03010-01	ADAPTER 16MM	9
*09951-00890-01	REPLACER 89	8	*09956-03020-01	ADAPTER 18MM	9
*09951-00900-01	REPLACER 90	11	*09956-03030-01	ADAPTER 20MM	9
*09951-00910-01	REPLACER 91	8	*09956-03040-01	ADAPTER 22MM	9
*09951-01000-01	REPLACER 100	11	*09956-03050-01	ADAPTER 24MM	9
*09951-01030-01	REPLACER 103	11	*09956-03060-01	ADAPTER 26MM	9
*09951-01100-01	REPLACER 110	11	*09956-03070-01	ADAPTER 28MM	9
*09951-03010-01	PULLER HEAD	9	*09956-03080-01	ADAPTER 10MM	9
*09951-04010	HANGER 150	8	09956-03090-01	ADAPTER LONG 18 MM	17
*09951-04020	HANGER 200	8	*09957-04010	ATTACHMENT	8
*09951-05010	HANGER 150	24	*09957-04010	ATTACHMENT	24
09951-07100-01	HANDLE ASSEMBLY 100 - 4.25 INCH	12	*09958-04011	HOLDER	8
09951-07150-01	HANDLE ASSEMBLY 150 - 6.25 INCH	12	*09959-04010	CASE	8
09951-07200-01	HANDLE ASSEMBLY 200 - 8.25 INCH	12	09960-10010	VARIABLE PIN WRENCH SET	1
09951-07360-01	HANDLE ASSEMBLY 360 - 14.625 INCH	12	09960-20010-01	BALL JOINT PULLER	14
*09952-04010	SLIDE ARM	8	*09961-00010	CASE	1
*09952-05010	SLIDE ARM	24	*09961-00020	HOLDER ASSEMBLY	1
*09952-06010-01	ADAPTER	24	09961-00950	TORQUE WRENCH ADAPTER	13
*09953-03010-01	FORCING SCREW	9	09961-01270	TORQUE WRENCH ADAPTER	1
*09953-04010	CENTER BOLT 100	8	*09962-00010	ARM	1
*09953-04020	CENTER BOLT 150	8	*09962-00020	ARM B	1
*09953-04030	CENTER BOLT 200	8	*09962-01000	VARIABLE PIN WRENCH ARM ASSEMBLY	1
*09953-05010	CENTER BOLT 100	24	*09963-00350	PIN 3.5	1
*09953-05020	CENTER BOLT 150	24	*09963-00400	PIN 4	1
*09954-03010-01	PULLER LEG	9	*09963-00450	PIN 4.5	1

\* This tool is a component of an essential kit.



# Part Number References

TOOL #	TOOL DESCRIPTION	DRAWER #	TOOL #	TOOL DESCRIPTION	DRAWER #
*09963-00500	PIN 5	1	49E033101	DUST COVER INSTALLER	10
*09963-00600	PIN 6	1	49F011104	INSTALLER	10
*09963-00700	PIN 7	1	49G028205	OIL SEAL INSTALLER	10
*09963-01000	PIN 10	1	49G030796	SEAL INSTALLER	10
*09989-00010-01	ATTACHMENT A	IN SHOP	49U034204	DUST BOOT INSTALLER	10
*09989-0010-L	ATTACHMENT A (LONG)	IN SHOP	49UB71525	BEARING INSTALLER	10
09992-00242-01	TURBO BOOST PRESSURE GAUGE SET	22	541808	MAGNETIC CAR TOPPER, HIGH VOLTAGE (2)	HEV
*09992-00320	GAUGE ASSEMBLY	22	*90119-08216	BOLT	8
*09992-00330	HOSE	22	*90155-60003	SCREW	24
*09992-00340	HOSE	22	*90179-10016	NUT	1
09992-00350-01	ABS TRAC ACTUATOR AIR BLEED TOOL	16	*90405-09015	NO. 1 UNION	22
*09993-01010	OVERFLOW LEVEL GAUGE	9	*90467-13001	CLIP	22
*09993-01020	VACUUM REGULATOR	9	*90480-01601	GROMMET	1
*09993-01030	FILLER PLUG ADAPTER	9	*90480-13005	GROMMET	1
09993-01100	18MM ADAPTER	4	*91111-51014	BOLT	8
09993-01110	10MM ADAPTER	4	*91551-80650-01	BOLTS (2)	8
09993-01120	ADAPTER, FILLER PLUG EXTENSION	4	*91651-60855-01	BOLT	8
09993-19025	OVERFLOW LEVEL GAUGE SET	9	*95333-06030	HOSE	22
*09993-20010	TANK ASSEMBLY	9	*95336-08070	HOSE	22
09999-00110	WHEEL LOCK MASTER KEY SET	16	*96150-02000	C-RING	22
09999-00310	SPARE TIRE LOCK MASTER KEY SET	16	CR435	REPLACEMENT BATTERIES FOR 09800-WA320	20
09999-00410	TRD MASTER KEY SET	16	DCA-8000P T	DIAGNOSTIC CHARGER	IN SHOP
09999-00411	TRD MASTER KEY SET SUPPLEMENT	16	DSS-5000P T	HANDHELD TESTER	IN SHOP
09999-00510	SUPRA MASTER WHEEL LOCK SET	21	ESUPPT-HOOK3	ENGINE SUPPORT BAR HOOK SET NO. 3	IN SHOP
09999-00610	WHEEL LOCK MASTER KEY SET SUPPLEMENT	18	*PP207-1	STANDARD CASE	9
10002-00101-4	FLUID EXTRACT TANK	IN SHOP	*PP207-1	STANDARD CASE	9
11014-00007	ANTENNA TEST KIT	8	*PP691-1	PROTECTIVE RUBBER BOOT AND HOOK FOR PS4X24 SCOPES	9
11021-00027	TERMINAL GAUGE TOOL	5	SU003-03936-01	PULLER FUEL HOSE	1
11216-00011	ENGINE BLOCK OIL PLUG REPAIR	5	*TA000-2	BNC TO 4MM TEST LEADS 3M, BLACK	9
11413-00005	MILLIOHM METER KIT	HEV	*TA001-1	MULTI-METER PROBE - BLACK	9
11717-00012	TPWS TESTER KIT	24	*TA002-1	MULTI-METER PROBE - RED	9
*11815-00009	DIGITAL ANGLE GAUGE KIT	IN SHOP	*TA003-1	SMALL CROCODILE CLIP BLACK	9
11816-00010	RADAR SENSOR CALIBRATION KIT	IN SHOP	*TA004-1	SMALL CROCODILE CLIP RED	9
11819-00026	TERMINAL REMOVAL TOOL KIT	5	*TA005-1	DOLPHIN CLIP - BLACK	9
11919-00023	SUPRA TOOL KIT 1	25	*TA006-1	DOLPHIN CLIP - RED	9
11919-00024	SUPRA TOOL KIT 2	25	*TA008-1	BACK-PINNING PROBES	9
*13847	HOSE	9	*TA010-1	20:1 ATTENUATOR	9
*13850	HOSE	9	*TA018-1	20/60A CLAMP	9
*34661	MALE CONNECTOR	9	*TA019-1	600A CLAMP	9
*34662	FEMALE CONNECTOR	9	*TA030-1	CABLE IDENTIFIER KIT (5MM)	9
*47083	PRESSURE TEST GAUGE (40 INCH HOSE)	18	*TA034-1	FUSE BREAKOUT ATC	9
*47084	PRESSURE TEST GAUGE (100 INCH HOSE)	18	*TA035-1	FUSE BREAKOUT MINI	9
*202851	90 DEGREE ELBOW FITTING (5/8 INCH HEXAGON)	18	*TA125, 126, 127, 128-4	BNC TO 4MM, 3M (10FT) PREMIUM, BLUE, RED, GREEN, YELLOW	9
*206754	HOSE CLAMPS	15	TLBEV-00001	LIFT STRAPS	22
*211711	SHAFT PROTECTOR	15	TS2PS2CH-REQ	PICOSCOPE KIT 2-CHANNEL	9
*308335	ADAPTER, 7MM	18	TS2PS4CH-UPG	PICOSCOPE KIT 4-CHANNEL	9
*308336	ADAPTER, 8MM	18	TSADVUNIT	TECHSTREAM ADVI	IN SHOP
*308337	ADAPTER, 10MM	18	N/A	USB NAVIGATION AND FIRMWARE UPDATE	2
*308344	CARRYING CASE	9			
*310604	PRESSURE GAUGE	9			
49B025001	SEAL INSTALLER	12			
49D0131A0	INJECTOR SEAL INSTALLER SET	10			
49D015001	COOLANT TEMP SENSOR SOCKET	10			


























\* This tool is a component of an essential kit.

# Drawer Liner Reference

## TOOLS

00002-02955	BEAM TORQUE WRENCH
00002-35001	NUT WRENCH HOLDING TOOL
09013-1C160-01	TORXPLUS SOCKET, T40
09013-1C551-01	TORX SOCKET, E14
09013-1C560-01	TORX SOCKET, E16
09013-7C310	10MM BI-HEXAGON SOCKET (1/2 INCH DRIVE)
09043-50080	8MM BI-HEXAGON WRENCH (1/2 INCH DRIVE)
09216-42010	BELT TENSION WRENCH SET
09224-00010-01	OXYGEN SENSOR SOCKET
09224-74010-01	ENGINE BALANCER BACKLASH TOOL
09249-37010-01	VVT SET BOLT WRENCH
09250-53010-01	SPACER, ENGINE MOUNT
09260-39021-01	INJECTOR SEAL TOOL SET
09260-39030-01	INJECTOR SEAL TOOL SET
09268-21010-01	FUEL HOSE PULLER
09268-74010-01	INJECTOR REMOVER
09276-75010-01	HYDRAULIC LASH ADJUSTER
09387-00130-01	COUNTER DRIVE GEAR NUT WRENCH
09564-33010	DIFFERENTIAL PRELOAD ADAPTER
09813-00020	PILLAR GARNISH CLIP TOOL
09960-10010	VARIABLE PIN WRENCH SET
09961-01270	TORQUE WRENCH ADAPTER
SU003-03936-01	PULLER FUEL HOSE









## DRAWER 1

<p>09216-42010 BELT TENSION WRENCH SET COMPONENTS: 09216-42010 BELT TENSION WRENCH</p> 	<p>09961-01270 TORQUE WRENCH ADAPTER</p> 	<p>09276-54010 09960-10010 VARIABLE PIN WRENCH SET COMPONENTS: 09960-10010 CASE 09960-00020 HOLDER ASSEMBLY 09960-00010 ARM 09960-00030 ARM B 09960-00040 ARM C 09960-00050 VARIABLE PIN WRENCH ARM ASSEMBLY 09960-00060 PIN A 09960-00070 PIN B 09960-00080 PIN C 09960-00090 PIN D 09960-00100 PIN E 09176-10016 NUT 09480-01801 GRIMMSET 09480-13005 GRIMMSET</p> 	<p>00002-02955 BEAM TORQUE WRENCH</p> 	<p>09230-53010-01 SPACER, ENGINE MOUNT</p> 
<p>09216-42010 ADAPTER</p> 	<p>09387-00130-01 COUNTER DRIVE GEAR NUT WRENCH</p> 	<p>09268-21010-01 FUEL HOSE PULLER</p> 	<p>00002-35001 NUT WRENCH HOLDING TOOL</p> 	<p>09224-74010-01 ENGINE BALANCER BACKLASH TOOL</p> 
<p>09813-00020 PILLAR GARNISH CLIP TOOL</p> 	<p>09249-37010-01 VVT SET BOLT WRENCH</p> 	<p>09268-74010-01 INJECTOR REMOVER</p> 	<p>09043-50080 10MM BI-HEXAGON SOCKET (1/2 INCH DRIVE)</p> 	<p>09043-50080 8MM BI-HEXAGON WRENCH (1/2 INCH DRIVE)</p> 
<p>09260-39030-01 INJECTOR SEAL TOOL SET COMPONENTS: 09261-03011-01 09261-03020-01</p> 	<p>09564-33010 DIFFERENTIAL PRELOAD ADAPTER</p> 	<p>SU003-03936-01 PULLER FUEL HOSE</p> 	<p>09013-7C310 10MM BI-HEXAGON SOCKET (1/2 INCH DRIVE)</p> 	<p>09224-00010-01 OXYGEN SENSOR SOCKET</p> 
<p>09260-39021-01 INJECTOR SEAL TOOL SET COMPONENTS: 09261-03011-01 09261-03020-01</p> 	<p>09268-74010-01 INJECTOR REMOVER</p> 	<p>09013-1C560-01 TORX SOCKET, E16</p> 	<p>09013-1C551-01 TORX SOCKET, E14</p> 	<p>09013-1C160-01 TORXPLUS SOCKET, T40</p> 

## TOOLS

09221-18010-01	PISTON PIN REMOVER
09221-18020-01	GUIDE PIN REMOVER
09223-22010	CRANKSHAFT FRONT OIL SEAL REPLACER
09223-63010-01	CRANKSHAFT REAR OIL SEAL REPLACER
09309-37010-01	TRANSMISSION BEARING REPLACER
09387-00090	BEARING RETAINER INSTALLER
09388-40010-01	INPUT SHAFT OIL SEAL REPLACER
09518-36030-01	OIL SEAL & BEARING REPLACER
N/A	USB NAVIGATION AND FIRMWARE UPDATE

## DRAWER 2


<p>09221-18010-01 PISTON PIN REMOVER</p> 	<p>09388-40010-01 INPUT SHAFT OIL SEAL REPLACER</p> 
<p>09221-18020-01 GUIDE PIN REMOVER</p> 	<p>09309-37010-01 TRANSMISSION BEARING REPLACER</p> 
<p>09387-00090 BEARING RETAINER INSTALLER</p> 	<p>09518-36030-01 OIL SEAL &amp; BEARING REPLACER</p> 
<p>09223-22010 CRANKSHAFT FRONT OIL SEAL REPLACER</p> 	<p>09223-63010-01 CRANKSHAFT REAR OIL SEAL REPLACER</p> 

# Drawer Liner Reference

## TOOLS

09213-58012-01	CRANKSHAFT PULLEY HOLDING TOOL
09213-58013-01	CRANKSHAFT PULLEY HOLDING TOOL
09213-58014-01	CRANKSHAFT PULLEY HOLDING TOOL
09213-70011-01	CRANKSHAFT PULLEY HOLDING TOOL
09223-15020	CRANKSHAFT REAR OIL SEAL REPLACER
09223-15030	CRANKSHAFT REAR OIL SEAL REPLACER
09223-78010-01	CRANKSHAFT OIL SEAL REPLACER
09228-06500-02A	OIL FILTER WRENCH
09228-07502	OIL FILTER WRENCH
09248-77010-01	VALVE CLEARANCE ADJUSTING COMPRESSOR SET
09308-00010	OIL SEAL PULLER
09520-10021	TRANS HOUSING REMOVER


## DRAWER 3



## TOOLS

09032-00100-01	GASKET SEAL CUTTER
09202-00018-01	VALVE SPRING COMPRESSOR ADAPTER 12
09202-00020-01	VALVE SPRING COMPRESSOR ADAPTER
**09202-43013-01	VALVE SPRING COMPRESSOR W/ADAPTER
09248-55040	VALVE CLEARANCE ADJUST TOOL SET
09326-35020-01	OUTPUT SHAFT ADJUSTING NUT WRENCH
09808-14010-01	FUEL SENDER LOCK RING WRENCH
09808-14031-KIT	FUEL SENDER LOCK NUT WRENCH
09993-01100	18MM ADAPTER
09993-01110	10MM ADAPTER
09993-01120	ADAPTER, FILLER PLUG EXTENSION

## DRAWER 4



# Drawer Liner Reference

## TOOLS

00002-35027  
00002-JUMPR-KIT  
09223-47020-01  
09322-35010-01  
09520-01010-02  
09564-50010-01  
11021-00027  
11216-00011  
11819-00026

27MM HEX SOCKET  
OBD-II JUMPER CONNECTOR KIT  
(4 COMPONENTS)  
REAR CRANKSHAFT SEAL INSTALLER  
INPUT SHAFT HOLDING TOOL SET  
DRIVE SHAFT REMOVER ATTACHMENT  
DIFFERENTIAL PRELOAD ADAPTER  
TERMINAL GAUGE TOOL  
ENGINE BLOCK OIL PLUG REPAIR  
TERMINAL REMOVAL TOOL KIT

## DRAWER 5

**11216-00011**  
ENGINE BLOCK OIL PLUG REPAIR  
COMPONENTS:  
01216-00111 TAPERED TAP  
01216-00112 STRAIGHT TAP  
01216-00113 SLICE HAMMER  
01216-00114 PLUG PULLER (X2)  
01216-00115 RUBBER PLUG (X2)  
01216-00116 PIPE PLUG (X10)  
01216-00117 TAP ALIGNMENT BRIDGE W/ BOLTS

**09322-35010-01**  
INPUT SHAFT HOLDING TOOL SET  
COMPONENTS:  
09322-00010-01 INPUT SHAFT HOLDING SOCKET  
09322-00001-01 INPUT SHAFT HOLDING JOINT BAR  
09322-00002-01 INPUT SHAFT HOLDING PLATE

**11021-00027**  
TERMINAL GAUGE TOOL  
COMPONENTS:  
01021-00101  
01021-00102  
01021-00103  
01021-00104  
01021-00105  
01021-00106  
01021-00107  
01021-00108  
01021-00109  
01021-00110  
01021-00111  
01021-00112  
01021-00113  
01021-00114  
01021-00115  
01021-00116  
01021-00117  
01021-00118  
01021-00119  
01021-00120

**11819-00026**  
TERMINAL REMOVAL TOOL KIT  
COMPONENTS:  
09041-10376-01 DRIVER(L) 120MM  
09041-10380-01 DRIVER(R) 120MM  
09041-00300-01 LANCE TOOL F  
09041-00310-01 LANCE TOOL M  
09041-00320-01 LANCE CANCELLING TOOL NO.1  
09041-00330-01 LANCE CANCELLING TOOL NO.2  
09041-00340-01 LANCE CANCELLING TOOL NO.3  
09041-00350-01 LANCE CANCELLING TOOL NO.4  
09041-00360-01 LANCE CANCELLING TOOL NO.5  
09041-00370-01 LANCE CANCELLING TOOL NO.6  
09041-00380-01 LANCE CANCELLING TOOL NO.7  
09041-00390-01 LANCE CANCELLING TOOL NO.8  
09041-00400-01 LANCE CANCELLING TOOL NO.9  
09041-00410-01 LANCE CANCELLING TOOL NO.10  
09041-00420-01 LANCE CANCELLING TOOL NO.11  
09041-00430-01 LANCE CANCELLING TOOL NO.12  
09041-00440-01 LANCE CANCELLING TOOL NO.13  
09041-00450-01 LANCE CANCELLING TOOL NO.14  
09041-00460-01 LANCE CANCELLING TOOL NO.15  
09041-00470-01 LANCE CANCELLING TOOL NO.16  
09041-00480-01 LANCE CANCELLING TOOL NO.17  
09041-00490-01 LANCE CANCELLING TOOL NO.18  
09041-00500-01 LANCE CANCELLING TOOL NO.19  
09041-00510-01 LANCE CANCELLING TOOL NO.20  
09041-00520-01 LANCE CANCELLING TOOL NO.21  
09041-00530-01 LANCE CANCELLING TOOL NO.22  
09041-00540-01 LANCE CANCELLING TOOL NO.23  
09041-00550-01 LANCE CANCELLING TOOL NO.24  
09041-00560-01 LANCE CANCELLING TOOL NO.25  
09041-00570-01 LANCE CANCELLING TOOL NO.26  
09041-00580-01 LANCE CANCELLING TOOL NO.27  
09041-00590-01 LANCE CANCELLING TOOL NO.28  
09041-00600-01 LANCE CANCELLING TOOL NO.29  
09041-00610-01 LANCE CANCELLING TOOL NO.30  
09041-00620-01 LANCE CANCELLING TOOL NO.31  
09041-00630-01 LANCE CANCELLING TOOL NO.32  
09041-00640-01 LANCE CANCELLING TOOL NO.33  
09041-00650-01 LANCE CANCELLING TOOL NO.34  
09041-00660-01 LANCE CANCELLING TOOL NO.35  
09041-00670-01 LANCE CANCELLING TOOL NO.36  
09041-00680-01 LANCE CANCELLING TOOL NO.37  
09041-00690-01 LANCE CANCELLING TOOL NO.38  
09041-00700-01 LANCE CANCELLING TOOL NO.39  
09041-00710-01 LANCE CANCELLING TOOL NO.40  
09041-00720-01 LANCE CANCELLING TOOL NO.41  
09041-00730-01 LANCE CANCELLING TOOL NO.42  
09041-00740-01 LANCE CANCELLING TOOL NO.43  
09041-00750-01 LANCE CANCELLING TOOL NO.44  
09041-00760-01 LANCE CANCELLING TOOL NO.45  
09041-00770-01 LANCE CANCELLING TOOL NO.46  
09041-00780-01 LANCE CANCELLING TOOL NO.47  
09041-00790-01 LANCE CANCELLING TOOL NO.48  
09041-00800-01 LANCE CANCELLING TOOL NO.49  
09041-00810-01 LANCE CANCELLING TOOL NO.50  
09041-00820-01 LANCE CANCELLING TOOL NO.51  
09041-00830-01 LANCE CANCELLING TOOL NO.52  
09041-00840-01 LANCE CANCELLING TOOL NO.53  
09041-00850-01 LANCE CANCELLING TOOL NO.54  
09041-00860-01 LANCE CANCELLING TOOL NO.55  
09041-00870-01 LANCE CANCELLING TOOL NO.56  
09041-00880-01 LANCE CANCELLING TOOL NO.57  
09041-00890-01 LANCE CANCELLING TOOL NO.58  
09041-00900-01 LANCE CANCELLING TOOL NO.59  
09041-00910-01 LANCE CANCELLING TOOL NO.60  
09041-00920-01 LANCE CANCELLING TOOL NO.61  
09041-00930-01 LANCE CANCELLING TOOL NO.62  
09041-00940-01 LANCE CANCELLING TOOL NO.63  
09041-00950-01 LANCE CANCELLING TOOL NO.64  
09041-00960-01 LANCE CANCELLING TOOL NO.65  
09041-00970-01 LANCE CANCELLING TOOL NO.66  
09041-00980-01 LANCE CANCELLING TOOL NO.67  
09041-00990-01 LANCE CANCELLING TOOL NO.68  
09041-01000-01 LANCE CANCELLING TOOL NO.69  
09041-01010-01 LANCE CANCELLING TOOL NO.70  
09041-01020-01 LANCE CANCELLING TOOL NO.71  
09041-01030-01 LANCE CANCELLING TOOL NO.72  
09041-01040-01 LANCE CANCELLING TOOL NO.73  
09041-01050-01 LANCE CANCELLING TOOL NO.74  
09041-01060-01 LANCE CANCELLING TOOL NO.75  
09041-01070-01 LANCE CANCELLING TOOL NO.76  
09041-01080-01 LANCE CANCELLING TOOL NO.77  
09041-01090-01 LANCE CANCELLING TOOL NO.78  
09041-01100-01 LANCE CANCELLING TOOL NO.79  
09041-01110-01 LANCE CANCELLING TOOL NO.80  
09041-01120-01 LANCE CANCELLING TOOL NO.81  
09041-01130-01 LANCE CANCELLING TOOL NO.82  
09041-01140-01 LANCE CANCELLING TOOL NO.83  
09041-01150-01 LANCE CANCELLING TOOL NO.84  
09041-01160-01 LANCE CANCELLING TOOL NO.85  
09041-01170-01 LANCE CANCELLING TOOL NO.86  
09041-01180-01 LANCE CANCELLING TOOL NO.87  
09041-01190-01 LANCE CANCELLING TOOL NO.88  
09041-01200-01 LANCE CANCELLING TOOL NO.89  
09041-01210-01 LANCE CANCELLING TOOL NO.90  
09041-01220-01 LANCE CANCELLING TOOL NO.91  
09041-01230-01 LANCE CANCELLING TOOL NO.92  
09041-01240-01 LANCE CANCELLING TOOL NO.93  
09041-01250-01 LANCE CANCELLING TOOL NO.94  
09041-01260-01 LANCE CANCELLING TOOL NO.95  
09041-01270-01 LANCE CANCELLING TOOL NO.96  
09041-01280-01 LANCE CANCELLING TOOL NO.97  
09041-01290-01 LANCE CANCELLING TOOL NO.98  
09041-01300-01 LANCE CANCELLING TOOL NO.99  
09041-01310-01 LANCE CANCELLING TOOL NO.100

**09520-01010-02**  
DRIVE SHAFT REMOVER ATTACHMENT

**00002-JUMPR-KIT**  
OBD-II JUMPER CONNECTOR KIT  
(4 COMPONENTS)

**09564-50010-01**  
DIFFERENTIAL PRELOAD ADAPTER

**00002-35027**  
27MM HEX SOCKET

**09223-47020-01**  
REAR CRANKSHAFT SEAL INSTALLER

DRAWER #5 SPECIAL TOOLS  
TOP/CL  
P/N: 00076017-05

JANUARY 2015

## TOOLS

00002-00921  
00002-00922  
00002-04020-KIT  
00002-2SUPP  
09223-75010-01  
09326-35010-01  
09387-00010-01  
09521-25023-01  
09521-26000-01  
09521-60010-01  
09726-02041-01

REAR AXLE SEAL & BEARING DRIVER  
REAR AXLE SEAL & BEARING DRIVER  
PRIUS-PHV HV BATTERY STRAP  
RATCHETING STRAP (2)  
OIL SEAL REPLACER  
OUTPUT SHAFT ADJUSTING NUT WRENCH  
AND ADAPTER  
TRANSFER OIL SEAL REPLACER  
REAR AXLE SHAFT PULLER ADAPTER  
REAR AXLE SHAFT PULLER SPACER  
REAR AXLE SHAFT PULLER ADAPTER  
OIL SEAL REPLACER

## DRAWER 6

**09326-35010-01**  
OUTPUT SHAFT ADJUSTING NUT WRENCH AND ADAPTER  
OUTPUT SHAFT ADJUSTING NUT WRENCH  
ADAPTER

**09521-25000-01**  
**09521-25000-01**  
REAR AXLE SHAFT PULLER SPACER

**09726-02041-01**  
OIL SEAL REPLACER

**00002-00921**  
REAR AXLE SEAL AND BEARING DRIVER

**00002-00922**  
REAR AXLE SEAL AND BEARING DRIVER

**09387-00010-01**  
TRANSFER OIL SEAL REPLACER

**09223-75010-01**  
OIL SEAL REPLACER

**09521-25021-01**  
**09521-25022-01**  
**09521-25023-01**  
OR  
**09521-60010-01**  
REAR AXLE SHAFT PULLER ADAPTER

**00002-2SUPP**  
RATCHETING STRAP (2)

**00002-04020-KIT**  
PRIUS-PHV HV BATTERY STRAP

DRAWER #6 SPECIAL TOOLS  
TOP/CL  
P/N: 00076017-05


JANUARY 2015

# Drawer Liner Reference

## TOOLS

- 00002-12001-01 VEHICLE DRAIN TUBE AUGER
- 09223-56010-01 CRANKSHAFT REAR OIL SEAL REPLACER
- 09325-40010-01 TRANSMISSION OIL PLUG
- 09326-71020-01 LOCK NUT SOCKET WRENCH
- 09520-32040-01 SLIDE HAMMER (5LB.)
- 09521-25011-01 REAR AXLE SHAFT PULLER
- 09570-22011 DIFFERENTIAL MOUNTING CUSHION  
REMOVER/REPLACER
- 09710-04101-01 FRONT SPEED SENSOR  
INSTALLER


## DRAWER 7



## TOOLS

- 09213-54015-01 CRANKSHAFT PULLEY HOLDING TOOL
- 09950-40011 UNIVERSAL PULLER SET "B"
- 09950-60020-01 REPLACER SET #2
- 11014-00007 ANTENNA TEST KIT

## DRAWER 8



# Drawer Liner Reference

## TOOLS

- 00001-00010-01 POWER STEERING PUMP PRESSURE GAUGE SET
- 00002-00909-01 ALL TRAC TOOL SET
- 09950-30012-01 UNIVERSAL PULLER SET "A"
- 09993-19025 OVERFLOW LEVEL GAUGE SET
- TS2PS2CH-REQ PICO SCOPE KIT 2-CHANNEL
- TS2PS4CH-UPG PICO SCOPE KIT 4-CHANNEL

## DRAWER 9

TS2PS2CH-REQ OR TS2PS4CH-UPG

PICO SCOPE KIT

(10002-00101)  
09950-19025

OVERFLOW LEVEL GAUGE SET

COMPONENTS:

- (10002-00101-1) OVERFLOW LEVEL GAUGE
- (09950-01010) VACUUM REGULATOR
- (10002-00101-3) FILLER PLUG ADAPTER
- (10002-00101-4) TANK ASSEMBLY

00002-00909-01

ALL TRAC TOOL SET

COMPONENTS:

- 09320-30010-01 TRANSMISSION REAR BEARING REPLACER
- 0916-12010 TRANSFER BEARING REPLACER
- 0916-20011-01 TRANSFER BEARING REPLACER
- 09135-12010 SPANNER WRENCH
- 0918-20010-01 SIDE BEARING NUT WRENCH
- 0900-13010-01 BEARING REPLACER

(09950-30017)  
(09950-30012-01)

UNIVERSAL PULLER SET "A"

COMPONENTS:

- 0961-03010-01 PULLER HEAD
- 0960-03010-01 FORCING SCREW
- 0960-03010-01 PULLER LEG
- 0965-03011-01 PULLER JAW (SET OF 2)
- 0965-03021-01 PULLER JAW (SET OF 3)
- 0965-03020-01 LOWER PLATE 130MM
- 0965-03040-01 LOWER PLATE 150MM
- 0966-03000-01 ADAPTER 10MM
- 0966-03010-01 ADAPTER 18MM
- 0966-03020-01 ADAPTER 19MM
- 0966-03030-01 ADAPTER 20MM
- 0966-03040-01 ADAPTER 22MM
- 0966-03050-01 ADAPTER 24MM
- 0966-03060-01 ADAPTER 26MM
- 0966-03070-01 ADAPTER 28MM

(00001-00008)  
(00001-00009)  
(00001-00010-01)

POWER STEERING PUMP PRESSURE GAUGE SET

COMPONENTS:

- 0000-47002 ADAPTER
- 0000-47003 ADAPTER
- 0002-00008 90 DEGREE FITTING
- 0002-13028-01 POWER STEERING ADAPTER
- 0002-40004-01 POWER STEERING ADAPTER
- 0002-40044-01 POWER STEERING PUMP ADAPTER
- 15847 HOSE
- 15850 HOSE
- 30044 CARRYING CASE
- 31004 PRESSURE GAUGE
- 34001 MALE CONNECTOR
- 34002 FEMALE CONNECTOR

DRAWER #9 SPECIAL TOOLS  
TOOLKIT  
P/N: 000101-08

JANUARY 2015


## TOOLS

- 09013-6C600-01 LONG BALL HEXAGON WRENCH 5MM
- 09326-71010-01 OUTPUT SHAFT HOLDING WRENCH
- 09326-71030-01 OUTPUT SHAFT HOLDING PLATE
- 09727-58010-01 REBOUND SPRING ADJUST PULLER
- 09727-58020-01 ADAPTER 12
- 09727-58030-01 ADAPTER 14
- 09727-58100-01 SHOCK ROD HOLDING TOOL
- 09727-58110-01 ATTACHMENT 12
- 09727-58120-01 ATTACHMENT 16
- 09727-58130-01 ATTACHMENT 22
- 09727-58140-01 ATTACHMENT 25
- 09808-01110-01 CLAW
- 09900-WA230-01 WINDOW PLASTIC PRY TOOL
- 49D0131A0 INJECTOR SEAL INSTALLER SET
- 49D015001 COOLANT TEMP SENSOR SOCKET
- 49E033101 DUST COVER INSTALLER
- 49F011104 INSTALLER
- 49G028205 OIL SEAL INSTALLER
- 49G030796 SEAL INSTALLER
- 49U034204 DUST BOOT INSTALLER
- 49UB71525 BEARING INSTALLER

## DRAWER 10


49E033101

DUST COVER INSTALLER




09808-01110-01

CLAW




09727-58010-01

REBOUND SPRING ADJUST PULLER




49UB71525

BEARING INSTALLER




09326-71010-01

OUTPUT SHAFT HOLDING WRENCH




09013-6C600-01

LONG BALL HEXAGON WRENCH 5MM




49G030796

SEAL INSTALLER




09326-71030-01

OUTPUT SHAFT HOLDING PLATE




09727-58020-01

ADAPTER 12




49G028205

OIL SEAL INSTALLER




49U034204

DUST BOOT INSTALLER




09727-58030-01

ADAPTER 14




49F011104

INSTALLER




49D0131A0

INJECTOR SEAL INSTALLER SET




09727-58100-01

SHOCK ROD HOLDING TOOL




49D015001

COOLANT TEMP SENSOR SOCKET




09900-WA230-01

WINDOW PLASTIC PRY TOOL




09727-58120-01

ATTACHMENT 16




09727-58130-01

ATTACHMENT 22



09727-58140-01

ATTACHMENT 25



DRAWER #10 SPECIAL TOOLS  
TOOLKIT  
P/N: 000101-010

JANUARY 2015


# Drawer Liner Reference

## TOOLS

00002-00039  
00002-90080  
09556-16030-01  
09564-32011-01  
09608-10010-01  
09613-22011  
09631-12071  
09729-22031  
09730-00010  
09801-18010-01  
09870-00005-01  
09951-00750-01  
09951-00770-01  
09951-00810-01  
09951-00900-01  
09951-01000-01  
09951-01030-01  
09951-01100-01

39MM SOCKET  
SUBFRAME ALIGNMENT PINS  
DIFFERENTIAL DRIVE PINION HOLDING TOOL #28  
PRELOAD ADAPTER  
STEERING KNUCKLE OIL SEAL REPLACER  
STEERING RACK SHAFT BUSHING PULLER  
STEERING RACK OIL SEAL TEST TOOL  
FRONT SPRING UPPER SEAT HOLDER  
AIR TUBE SEPARATOR  
DOOR GLASS BOLT HOLDING TOOL  
A/C LINE DISCONNECT KIT  
REPLACER 75  
REPLACER 77  
REPLACER 81  
REPLACER 90  
REPLACER 100  
REPLACER 103  
REPLACER 110

## DRAWER 11




## TOOLS

00002-00920  
01815-00104  
01815-00105  
09330-00021  
09340-00010-01  
09509-25011  
09521-60020-01  
09556-30010  
09608-32010  
09612-30012  
09616-00010-02  
09616-00020-01  
09634-60013  
09634-60014  
09670-00010-01  
09922-10010-01  
09951-07100-01  
09951-07150-01  
09951-07200-01  
09951-07360-01  
49B025001

DRIVER HANDLE  
DRIVE HANDLE ADAPTER  
DRIVE HANDLE ADAPTER  
COMPANION FLANGE HOLDING TOOL  
QUICK CONNECT REMOVER  
REAR AXLE BEARING LOCK NUT WRENCH  
REAR AXLE TOOL NO. 3  
DIFFERENTIAL BEARING REMOVER  
STEERING KNUCKLE OIL SEAL REPLACER  
STEERING WORM BEARING PULLER  
STEERING SOCKET  
STEERING WORM BEARING ADJUSTING SOCKET  
STEERING KNUCKLE CENTERING GAUGE  
STEERING KNUCKLE CENTERING GAUGE  
FRONT CROSS MEMBER GUIDE TOOL  
VARIABLE OPEN WRENCH  
HANDLE ASSEMBLY 100 - 4.25 INCH  
HANDLE ASSEMBLY 150 - 6.25 INCH  
HANDLE ASSEMBLY 200 - 8.25 INCH  
HANDLE ASSEMBLY 360 - 14.625 INCH  
SEAL INSTALLER  
STEERING WORM BEARING ADJUSTING SOCKET  
STEERING SOCKET  
QUICK CONNECT REMOVER  
REAR AXLE BEARING LOCK NUT WRENCH  
STEERING KNUCKLE OIL SEAL REPLACER

## DRAWER 12





























# Drawer Liner Reference

## TOOLS

09223-46011-01	CRANKSHAFT FRONT OIL SEAL REPLACER
09249-63010-01	TORQUE WRENCH ADAPTER
09309-12020-01A	5TH GEAR REPLACER
09554-14010-01	SEAL INSTALLER
09610-20012-01	PITMAN ARM PULLER
09611-22012-01	TIE ROD END PULLER
09612-00012-01	RACK & PINION HOLDING TOOL
09628-62011-01	BALL JOINT PULLER
09631-10021-01	RACK & PINION STOPPER ADJUSTMENT TOOL
09631-12090	SEAL RING TOOL
09710-18010-01	REAR SUSPENSION BUSH KIT
09710-18020-01	REAR SUSPENSION BUSH KIT
09710-18030-01	REAR SUSPENSION BUSH KIT
09710-18040-01	FRONT SUSPENSION BUSH KIT
09716-18010-01	REAR SUSPENSION BUSH R/R
09716-18020-01	FRONT SUSPENSION BUSH R/R
09716-18030-01	FRONT SUSPENSION BUSH
09726-18010-01	STUD BOLT SOCKET
09961-00950	TORQUE WRENCH ADAPTER
09710-07021	BUSHING REMOVER
09710-07031	BUSHING REPLACER
09710-07041	UPPER ARM BASE
09710-07051	UPPER ARM BASE
09710-07062	BUSHING REPLACER
09710-07071	UPPER ARM SPACER
09710-07081	LOWER ARM BASE
09893-00020-01	GUIDE PINS
09893-42040-01	BATTERY HANGER 100MM










## DRAWER 13

<p>09893-00020-01 GUIDE PINS</p> 	<p>09726-18010-01 STUD BOLT SOCKET</p> 		<p>09710-18040-01 FRONT SUSPENSION BUSH KIT</p> 
<p>09893-42040-01 BATTERY HANGER 100MM</p> 	<p>09716-18020-01 FRONT SUSPENSION BUSH R/R</p> 		<p>09716-18030-01 FRONT SUSPENSION BUSH</p> 
<p>09710-18030-01 REAR SUSPENSION BUSH KIT</p> 	<p>09710-18010-01 REAR SUSPENSION BUSH KIT</p> 	<p>09631-10021-01 RACK &amp; PINION STOPPER ADJUSTMENT TOOL</p> 	<p>09710-18020-01 REAR SUSPENSION BUSH KIT</p> 
<p>09710-07051 UPPER ARM BASE COMPONENT OF 09710-28012-01 FRONT SUSPENSION BUSHING TOOL SET</p> 	<p>09716-18010-01 REAR SUSPENSION BUSH R/R</p> 	<p>09812-00012-01 RACK &amp; PINION HOLDING TOOL</p> 	<p>09223-46011-01 CRANKSHAFT FRONT OIL SEAL REPLACER</p> 
<p>09710-07041 UPPER ARM BASE COMPONENT OF 09710-28012-01 FRONT SUSPENSION BUSHING TOOL SET</p> 	<p>09710-07071 UPPER ARM SPACER COMPONENT OF 09710-28012-01 FRONT SUSPENSION BUSHING TOOL SET</p> 	<p>09249-63010-01 OR 09961-00950 TORQUE WRENCH ADAPTER</p> 	<p>09611-22012-01 TIE ROD END PULLER</p> 
<p>09710-07031 BUSHING REPLACER COMPONENT OF 09710-28012-01 FRONT SUSPENSION BUSHING TOOL SET</p> 	<p>09710-07061 LOWER ARM BASE COMPONENT OF 09710-28012-01 FRONT SUSPENSION BUSHING TOOL SET</p> 	<p>09628-62011-01 BALL JOINT PULLER</p> 	<p>09610-20012-01 PITMAN ARM PULLER</p> 
<p>09710-07021 BUSHING REMOVER COMPONENT OF 09710-28012-01 FRONT SUSPENSION BUSHING TOOL SET</p> 	<p>09710-07062 BUSHING REPLACER COMPONENT OF 09710-28012-01 FRONT SUSPENSION BUSHING TOOL SET</p> 	<p>09631-12090 SEAL RING TOOL</p> 	<p>09309-12020-01A 5TH GEAR REPLACER COMPONENT: 09002-12020-01 FORGING BOLT</p> 

## TOOLS

09318-12010-4PIN	4 PIN FRONT WHEEL BEARING LOCK NUT SOCKET KIT
09318-12010-8PIN	8 PIN SOCKET KIT
09527-17011	REAR AXLE BEARING REMOVER
09528-52010-01	DIFFERENTIAL GEAR REMOVER & REPLACER SET
09611-20015-01	TIE ROD END PULLER
09628-00011-01	BALL JOINT PULLER
09727-22011-ST	COIL SPRING COMPRESSOR
09727-30050-01	TOE CONTROL LINK REPLACEMENT KIT
09960-20010-01	BALL JOINT PULLER

## DRAWER 14

<p>09727-30050-01 TOE CONTROL LINK REPLACEMENT KIT</p> <p>COMPONENTS: 09727-20011-01 TOE CONTROL LINK COMPRESSOR ARM 09711-40010-01 TOE CONTROL LINK REPLACER ARM NO. 1 09712-40010-01 TOE CONTROL LINK REPLACER ARM NO. 2 09727-40010 BOLT SET</p> <p>(PRIOR DEALER KIT)</p> 	<p>09727-22011-ST COIL SPRING COMPRESSOR</p> 	<p>09318-12010-4PIN 4 PIN FRONT WHEEL BEARING LOCK NUT SOCKET KIT</p> <p>COMPONENTS: 09318-12010-SOCK 4 PIN FRONT WHEEL BEARING LOCK NUT SOCKET 09318-12010-FINS SOCKET PIN SET (374-4) 09318-12010-INST. PIN INSTALLER/REMOVER</p> 	<p>09960-20010-01 BALL JOINT PULLER</p> 
<p>09527-17010-01 09527-17011 REAR AXLE BEARING REMOVER</p> 	<p>09611-20015-01 TIE ROD END PULLER</p> 	<p>09318-12010-8PIN 8 PIN SOCKET KIT</p> <p>COMPONENTS: 09318-12010-8PIN-1 8 PIN SOCKET 09318-12010-8PIN-2 PIN INSTALLER/REMOVER 09318-12010-8PIN-3 REPLACEMENT PIN (374-4)</p> 	<p>09528-52010-01 DIFFERENTIAL GEAR REMOVER &amp; REPLACER SET</p> <p>COMPONENTS: 09528-0000-01 CENTER BOLT 09528-0001-01 HANDLE, COMPRESSOR PLATE 1&amp;2 09528-0002-01 WRENCH, SIDE GEAR A 09528-0003-01 WRENCH, SIDE GEAR B 09528-0004-01 WRENCH, SIDE GEAR C 09528-0005-01 GUIDE PIN A 09528-0006-01 GUIDE PIN B 09528-0007-01 GUIDE PIN C</p> 
<p>09628-00011-01 BALL JOINT PULLER</p> 			




# Drawer Liner Reference

## TOOLS

- 09527-10011-01 REAR AXLE SHAFT BEARING REMOVER
- 09570-18010-01 REAR DIFF MOUNT CUSHION, R/R
- 09570-18020-01 REAR DIFF MOUNT CUSHION, R/R
- 09570-60010-01 DIFFERENTIAL MOUNTING CUSHION REMOVER AND REPLACER
- 09607-60020-01 FRONT WHEEL ADJUSTING NUT WRENCH
- 09608-16042 FRONT HUB BEARING ADJUSTING TOOL
- 09649-17010 STEERING KNUCKLE TOOL
- 09930-00010-01 DRIVE SHAFT NUT CHISEL
- 09950-00020-01 BEARING RACE PULLER


## DRAWER 15



## TOOLS

- 09719-14020 REAR DISC BRAKE TOOL SET
- 09737-00013-01 BRAKE BOOSTER PUSH ROD GAUGE
- 09737-00020-01 BRAKE BOOSTER PUSH ROD WRENCH
- 09756-00010 REAR DISC BRAKE ADJUSTER
- 09992-00350-01 ABS TRAC ACTUATOR AIR BLEED TOOL
- 09999-00110 WHEEL LOCK MASTER KEY SET
- 09999-00310 SPARE TIRE LOCK MASTER KEY SET
- 09999-00410 TRD MASTER KEY SET
- 09999-00411 TRD MASTER KEY SET SUPPLEMENT

## DRAWER 16




# Drawer Liner Reference

## TOOLS

09260-39040-01	INJECTOR SEAL TOOL SET
09260-48010-01	FUEL INJECTOR REMOVER NEW
09260-48020-01	DELIVERY PIPE GUIDE PIN NEW
09506-42010-01	BEARING RACE REPLACER
09506-42020-01	BEARING RACE REPLACER
09506-42030-01	BASE
09554-42010-01	OIL SEAL REPLACER
09700-WA050-01	TRANSMISSION RELEASE TOOL
09700-WA250	STRUT BOLT SOCKET 6MM STRUT BOLT
09893-10060-01	AC LEAK TEST HIGH ADAPTER
09893-10070-01	AC LEAK TEST LOW ADAPTER
09893-42010-01	BATTERY HANGER
09905-00040	CONNECTOR PLIER
09929-00020-01	CRIMPING TOOL S
09930-42010-01	DRIVE PINION SHAFT NUT CHISEL
09955-04160-01	CLAW NO.16
09956-03090-01	ADAPTER LONG 18 MM


## DRAWER 17



## TOOLS

09650-53010-01	WHEEL GUIDE PINS
09709-00002	BRAKE PEDAL FORCE GAUGE
09709-29018	LSPV GAUGE SET
09843-18040	DIAGNOSIS CHECK WIRE #2
09999-00610	WHEEL LOCK MASTER KEY SET SUPPLEMENT


## DRAWER 18



# Drawer Liner Reference

## TOOLS

## DRAWER 19




DRAWER #19 SPECIAL TOOLS  
TOOLKIT  
P/N: 08071017-019

JANUARY 2019

## TOOLS

## DRAWER 20

- 00002-71368-01 PRY TOOL
- 07112-66040-01 PRESSURE PLATE REMOVER
- 07112-76060-01 MAGNETIC CLUTCH STOPPER
- 09042-2C100 CRIMPER
- 09800-WA320 WINDOW ADJUSTER
- 09812-18010-01 TOOL, FRONT DOOR GLASS ADJ
- 09812-18020-01 TOOL, FRONT DOOR GLASS FIX
- 09820-63020-02 ALTERNATOR CLUTCH HOLDING TOOL SET
- CR435 REPLACEMENT BATTERIES FOR 09800-WA320



DRAWER #20 SPECIAL TOOLS  
TOOLKIT  
P/N: 08071017-020


JANUARY 2019

# Drawer Liner Reference

## TOOLS

- 00002-01775 SEAT HEATER ATTACHMENT KIT
- 00002-06020-01 PLASTIC PRY TOOL KIT
- 01018-00118 SUPRA DIAGNOSTIC CABLE
- 09249-37020-01 STRAIGHT PIN PULLER
- 09843-18061 SRS CHECK WIRE
- 09890-47010-01 ANTI-STATIC MAT SET
- 09891-47020-01 INVERTER CASE SEPERATOR
- 09999-00510 SUPRA MASTER WHEEL LOCK SET


## DRAWER 21



## TOOLS

- 09268-31012 INJECTION MEASURING TOOL SET
- 09268-45101-1A EFI FUEL PRESSURE GAUGE SET
- 09808-14040-01 FUEL PUMP RETAINER TOOL
- 09808-14050-01 FUEL PUMP HOLDING TOOL
- 09992-00242-01 TURBO BOOST PRESSURE GAUGE SET
- TLBEV-00001 LIFT STRAPS

## DRAWER 22





# Drawer Liner Reference

## TOOLS

11919-00023  
11919-00024

SUPRA TOOL KIT 1  
SUPRA TOOL KIT 2

## DRAWER 25

11919-00023

SUPRA TOOL KIT 1

**COMPONENTS:**

- 0902-WA20 FUEL INJECTOR SEAL REMOVAL PLIERS
- 0900-WA70 FUEL FILLER TUBE
- 0900-WA20 AXLE SHAFT COLLAR
- 0900-WA10 9MM WRENCH
- 0900-WA80 FUEL INJECTOR INSTALLATION GAUGE
- 0200-WA10 CRANKSHAFT FOCKET
- 0900-WA60 BREAKER BAR
- 0900-WA70 FLEX PLATE ALIGNMENT PIN
- 0902-WA10 FUEL INJECTOR SEAL INSTALLER
- 0900-WA20 DRIVE WRENCH ADAPTER
- 0900-WA20 WIPER ARM PULLER
- 0900-WA20 HOOD SUPPORT EXTENSIONS
- 0910-WA10 STRUT BOLT SOCKET
- 0910-WA20 8MM STRUT BOLT
- 0900-WA20 8MM HEX EXTENSION

11919-00024

SUPRA TOOL KIT 2


**COMPONENTS:**

- 0200-WA90 4 CYL OIL PRESSURE ADAPTER
- 0900-WA30 DOOR LATCH SPACER
- 0200-WA50-01 6 CYL OIL PRESSURE ADAPTER
- 0910-WA90 FLEX PLATE HOLDING TOOL
- 0900-WA20 FUEL HOSE ADAPTER
- 0900-WA20 FUEL PUMP LOCK RING
- 0900-WA90 CRANKCASE PRESSURE ADAPTER
- 0900-WA10 WINDOW ADJUSTMENT TOOL
- 0200-WA50 FUEL INJECTOR FITTURE
- 0900-WA90 FUEL INJECTOR CAPS
- 0900-WA90 BODY GAP GAUGES
- 0900-WA90 FUEL INJECTOR FITTURE SPACERS
- 0900-WA20 WINDOW ADJUSTMENT MEASURING TOOL
- 0900-WA10 WINDOW ADJUSTMENT WRENCH
- 0900-14010-01 WHEEL GUIDE PINS

DESIGNED BY SPECIAL TOOLS  
REVISED  
P/N: 09011011-005

JANUARY 2018


# Essential Tools Not Located in Storage Cabinets




00002-11100-02 TRANSMISSION FILL SYSTEM




00002-35000 3/4 INCH DRIVE TORQUE WRENCH




00002-1ESBU-KIT ENGINE SUPPORT BAR BRACKET




09800-WA300-01 ACC100 RAIL




00002-ESUPPT-01 ENGINE SUPPORT BAR



ESUPPT-HOOK3 ENGINE SUPPORT BAR HOOK SET NO. 3




00002-12000-01 KDSS FLUID PRESSURE PUMP KIT OR  
09760-60020 KDSS FLUID PRESSURE PUMP KIT




10002-00101-4 FLUID EXTRACT TANK

Note: Size of tools shown on this page are not to scale.


# Essential Tools Not Located in Storage Cabinets




09870-60000 LASER RADAR ADJUSTING REFLECTOR




09870-60060-01 STAND SUPPORT




09870-61100-01 TARGET BOARD NO. 1



09870-62100-01 TARGET SHEET NO. 1



09870-62200-01 TARGET SHEET NO. 2




01421-00151 3K LIFT TABLE

*Note: Size of tools shown on this page are not to scale.*




# Essential Tools Not Located in Storage Cabinets



11816-00010 RADAR SENSOR CALIBRATION KIT



DCA-8000P T DIAGNOSTIC CHARGER



TSADVUNIT TECHSTREAM ADVI




DSS-5000P T HANDHELD TESTER


Note: Size of tools shown on this page are not to scale.

# Essential Tools Not Located in Storage Cabinets


## Hybrid Electric Vehicle (HEV) Workstation



11413-00002 HIGH VOLTAGE BATTERY SERVICE KIT (GRX 5100)




11813-00003 INSULATED TOOLS



11413-00004 PERSONAL PROTECTIVE EQUIPMENT (PPE)

(11413-00007 INSULATED TOOLS AND PPE KIT)



11413-00006 HEV TOOL STORAGE CABINET



11413-00005 MILLIOHM METER KIT



To Order Special Service Tools Call Bosch/OTC at 1-800-933-8335