


1U 19in Vertical Wall Mount Rack Bracket

Product Diagram (RK119WALLV2)



Component	Function
1 Mounting Rails	<ul style="list-style-type: none"> Features Square Cage Nut Holes to mount the equipment
2 Wall Bracket	<ul style="list-style-type: none"> Mounting Holes along the Wall Bracket are used to Fasten it to a Wall

Package Contents

- Wall-Mount Bracket x 1
- Wood Screws x 6
- M5 Square Cage Nuts x 4
- M5 Screws x 4
- Quick-Start Guide x 1

Requirements

For the latest manuals, product information, technical specifications, and declarations of conformance, please visit: www.startech.com/RK119WALLV2

- Appropriate mounting hardware for the wall or surface type

- Phillips head screwdriver
- Cage nut tool (Optional)

Warnings!

Read the entire Quick-Start Guide and ensure the instructions are fully understood before assembling and/or using this product.

Before adding equipment to this product, ensure this product has been properly mounted.

Never operate this product if parts are missing or damaged.

The mounting hardware included with this product might not be adequate for some wall or mounting structures. If lacking the necessary expertise to mount this product, contact a construction professional to install the Wall Rack Bracket or to provide specific mounting instructions for the wall structure.

Ensure the weight of the equipment does not exceed the weight capacity of this product. If the weight capacity is exceeded, personal injury or damage to the equipment are possibilities. This product can support the following weight: 130 lb (59 kg) for RK119WALLV2.

Ensure the type of wall structure and mounting hardware will properly support the mounted equipment. Failure to do so might result in personal injury and/or equipment damage. The wall or mounting structure should be capable of supporting at least four times the weight of the mounted equipment.

Installation

Mount the Rack Bracket

The mounting holes are spaced 16 inches (2 inner holes) and 18.8 inches (4 outer holes) apart. Test fit the Rack Bracket on the surface to ensure proper fit on the designated location.

1. Mark the **Mounting Points** (x6) using the **Mounting Holes** (x6) on the **Wall Bracket** as a **Template**.
2. Use the **Wood Screws** (x6) to fasten the **Wall Bracket** to the **Mounting Surface**.
The included screws are for wood surfaces only.
3. Install the **M5 Square Cage Nuts** onto the desired **Square Cage Nut Holes** where the **Equipment** will go. Use a **Cage Nut Tool** if available or your preferred installation method.
4. Use a **Phillips Head Screwdriver** to install the **M5 Screws** and secure the **Equipment** onto the **Mounting Rails**.

Regulatory Compliance

Use of Trademarks, Registered Trademarks, and other Protected Names and Symbols

This manual may make reference to trademarks, registered trademarks, and other protected names and/or symbols of third-party companies not related in any way to StarTech.com. Where they occur these references are for illustrative purposes only and do not represent an endorsement of a product or service by StarTech.com, or an endorsement of the product(s) to which this manual applies by the third-party company in question. StarTech.com hereby acknowledges that all trademarks, registered trademarks, service marks, and other protected names and/or symbols contained in this manual and related documents are the property of their respective holders.

PHILLIPS® is a registered trademark of Phillips Screw Company in the United States or other countries.

Warranty Information

This product is backed by a lifetime warranty.

For further information on product warranty terms and conditions, please refer to www.startech.com/warranty.

Limitation of Liability

In no event shall the liability of StarTech.com Ltd. and StarTech.com USA LLP (or their officers, directors, employees or agents) for any damages (whether direct or indirect, special, punitive, incidental, consequential, or otherwise), loss of profits, loss of business, or any pecuniary loss, arising out of or related to the use of the product exceed the actual price paid for the product. Some states do not allow the exclusion or limitation of incidental or consequential damages. If such laws apply, the limitations or exclusions contained in this statement may not apply to you.

StarTech.com Ltd.

45 Artisans Crescent
London, Ontario
N5V 5E9
Canada

StarTech.com LLP

4490 South Hamilton
Road
Groveport, Ohio
43125
U.S.A.

StarTech.com Ltd.

Unit B, Pinnacle 15
Gowerton Road
Brackmills,
Northampton
NN4 7BW
United Kingdom

StarTech.com Ltd.

Siriusdreef 17-27
2132 WT Hoofddorp
The Netherlands

FR: startech.com/fr
DE: startech.com/de
ES: startech.com/es
NL: startech.com/nl
IT: startech.com/it
JP: startech.com/jp