

ORIGINAL



RETROFIT

All the Parts You Need... Before You Need Them!

PARTS REFERENCE GUIDE FOR Rectangular Recessed Wet Well Mounted Pump Stations



Your Helpful Parts Resource

For S&L Product codes: 18

(First Two Numbers of Station Serial Number)

Smith & Loveless, Inc.
www.smithandloveless.com

ENGINEERING DATA



Smith &
Loveless, Inc.®

14040 Santa Fe Trail
Lenexa, KS 66215-1234, USA

After Market
Parts Price Book
Section 4
Rectangular Recessed
WWMPS Parts
Page 1

After Market Parts Catalog

Rectangular Recessed Wet Well Mounted Pump Stations

S&L Product codes: 18 (First Two Letters of Station Serial Number)

ALPHABETICAL PARTS LISTING

PART NAME	PAGE
AIR-VACUUM PRESSURE GAUGES	34
ALARM LIGHT	8, 32
ALARM, PUMP FAILURE	11
ALARMS	32
AUXILIARY CONTACTS	8
AUXILIARY HEATER	9
BLOWER	32
BLOWER CORD	32
BREAKERS	17-22
CHECK VALVES, FLOAT	39
CHECK VALVES, WAFER	44
COMBINED EXHAUST ASSEMBLY- VACUUM PUMP	42
COMBO, AIR-VACUUM GAUGE	33
CONTACTS, AUXILIARY	8
CONTACTORS	8
CONTROLLER	8, 10
CORD CONNECTOR, FLOAT SWITCH	9
DISPLACEMENT (FLOAT) SWITCH	9, 12
DISPLAY FUSE	8
DISPLAY SCREEN	9, 33
DOME, ELECTRODE	39
DOME ASSEMBLY, ELECTRODE	39
DOUBLE BALANCED (High Head) MECHANICAL SEALS	30
ELBOW, PIPING	23-28
EXPANSION CARD	10
FERRULE NUT & SLEEVE	42
FIBERGLASS REPAIR KIT FOR HOOD	35
FILTERS, VAPOR	42
FITTINGS FOR TUBING	42
FLANGE GASKET	33
FLOAT (DISPLACEMENT) SWITCHES	9, 12

ENGINEERING DATA



Smith &
Loveless, Inc.®

14040 Santa Fe Trail
Lenexa, KS 66215-1234, USA

After Market
Parts Price Book
Section 4
Rectangular Recessed
WWMPS Parts
Page 2

PART NAME

PAGE

FLOAT SWITCH CONNECTION PLATE	36
FLOAT (DISPLACEMENT) SWITCH, CORD CONNECTOR	9
FLOAT CHECK VALVES	39
FRONT HEADS & VOLUTES, INTEGRAL	26-28
FUSE, DISPLAY	8
GASKETS	31
GASKETS, FORM-A	32
GASKETS, VOLUTE	31
GAUGES, PRESSURE	33
GFCI RECEPTACLES	9
GLOBE, RED & GAURD	32
HEATER	9
HMI MESSAGE PANEL SCREENS	33, 34
H-O-A SWITCH	12
HOODS	34
HOODS, MISCELLANEOUS PARTS	34
HOOD (FIBERGLASS) REPAIR KIT	35
HORN, ALARM	32
HOW TO CHANGE YOUR SINGLE MECHANICAL SEAL VIDEO	37
IMPELLER BOLTS & WASHERS	26-28
IMPELLERS	31
IMPELLER, X-PELLER®	31
INTEGRAL VOLUTE & FRONT HEAD	26-28
KEYSTOCK (MOTOR SHAFT KEY)	35
LABELS	35
LATCHES, FOR LOCKS	35
LEVEL INDICATION CONNECTION PLATE	36
LIFTING STANCHION	36
LIGHT	32
LIGHT, ALARM	8
LIGHTNING PROTECTION	10
LIMIT SWITCH	12
LINE STRAINER	36
LOCK LATCHES	35
LOUVER, VENT	37
MECHANICAL SEAL	29
MECHANICAL SEAL VIDEO – TRAINING ON HOW TO CHANGE	37
MONITOR RELAY, PHASE	10
MOTOR ADAPTERS	23-28
MOTOR SHAFT KEYSTOCK	35

ENGINEERING DATA



Smith &
Loveless, Inc.®

14040 Santa Fe Trail
Lenexa, KS 66215-1234, USA

After Market
Parts Price Book
Section 4
Rectangular Recessed
WWMPs Parts
Page 3

PART NAME

PAGE

MOTORS	.18
PAINT	.37
PHASE MONITOR RELAYS	.10
PLUG VALVES	.43
PLUG VALVE HANDLE/WRENCH	.43
POWER SUPPLY	.10
PRESSURE TRANSDUCERS/SENSORS, SUBMERSIBLE	.10
PROTECTION, LIGHTNING	.10
PROTRONIX® I	.8, 10
PROTRONIX® II	.8, 10
PUMP FAILURE ALARM	.11
PUMP IMPELLER	.31
PUMP MOTORS	.18
RELAY	.11
RELAY, ELECTRODE	.39
RELAYS, PHASE MONITOR	.10
RESISTOR	.11
ROLLER TRACK & PARTS FOR HOOD	.34
SCREEN, DISPLAY	.9, 33
SEALS, MECHANICAL	.29
SHADE-AIDE™	.37
SINGLE MECHANICAL SEAL	.29
SLINGER RINGS (for Motor Shaft)	.37
SOLENOID VALVES	.43
SONIC START® KITS	.39
SONIC START® OPERATING MODULE	.39
SONIC START® PROBE	.39
SONIC START® REPLACEMENT PARTS	.40
SPRING LOADED WAFER CHECK VALVE	.44
SPRING LOADED WAFER CHECK VALVE SPARE PARTS	.44
STARTERS, IEC RATED	.13
STARTERS, NEMA RATED	.14
SUCTION PIPING	.23-28
SWITCHES	.12
SWITCHES, FLOAT - DISPLACEMENT	.9, 12
SWITCHES, FLOAT CORD CONNECTOR	.9
TEE	.23-28
TEMPERATURE TRANSMITTER	.9, 12
TOUCH-UP PAINT, VERSAPOX®	.37
TRANSFORMER	.12

ENGINEERING DATA



Smith &
Loveless, Inc.®

14040 Santa Fe Trail
Lenexa, KS 66215-1234, USA

After Market
Parts Price Book
Section 4
Rectangular Recessed
WWMPS Parts
Page 4

PART NAME

PAGE

TRANSDUCER, SUBMERSIBLE PRESSURE.....	10
TUBING, VACUUM.....	42
TWO-WAY SOLENOID VALVE.....	39
VACUUM-AIR PRESSURE GAUGES.....	34
VACUUM DOME.....	40
VACUUM DOME ASSEMBLY.....	40
VACUUM PUMP – SINGLE PISTON.....	41
VACUUM PUMP – SINGLE PISTON SPARE PARTS.....	41
VACUUM PUMP – DUAL PISTON.....	41
VACUUM PUMP – DUAL PISTON SPARE PARTS.....	41
VACUUM PUMP-COMBINED EXHAUST ASSEMBLY.....	42
VACUUM TUBING.....	42
VACUUM TUBING FITTINGS.....	42
VALVES, PLUG.....	43
VALVES, SOLENOID.....	43
VALVES, WAFER CHECK.....	44
VALVES, WAFER CHECK SPARE PARTS.....	44
VALVE WRENCH.....	44
VAPOR FILTERS.....	42
VENT LOUVER.....	37
VENTILATION.....	32
VERSAPOX® , TOUCH-UP PAINT.....	37
VIDEO, TRAINING.....	37
VOLUTE GASKETS.....	32
VOLUTES & FRONT HEAD, INTEGRAL.....	26-28
WAFER CHECK VALVES.....	44
WAFER CHECK VALVE SPARE PARTS.....	44
WET WELL MANWAY ACCESS LIDS - 4' WET WELL.....	38
WET WELL MANWAY ACCESS LIDS – 5' & 6' WET WELL.....	38
WRENCH, VALVE.....	44
X-PELLER® IMPELLER.....	31

After Market Parts Catalog

ENGINEERING DATA



Smith &
Loveless, Inc.®

14040 Santa Fe Trail
Lenexa, KS 66215-1234, USA

After Market
Parts Price Book
Section 4
Rectangular Recessed
WWMPS Parts
Page 5

Rectangular Recessed Wet Well Mounted Pump Stations

S&L Product codes: 18 (First Two Letters of Station Serial Number)

PART PAGE

ELECTRICAL COMPONENTS

ALARM LIGHT - RED	8
AUXILIARY CONTACTS	8
CONTROLLER	8
DISPLAY FUSE	8
DISPLAY SCREEN	9
FLOAT DISPLACEMENT SWITCHES, BACKUP	9
FLOAT SWITCH, COAD CONNECTOR	9
GROUND FAULT CIRCUIT INTERRUPTER RECEPTACLE	9
HEATER	9
EXPANSION CARD	10
LIGHTNING PROTECTION	10
PHASE MONITOR RELAYS	10
POWER SUPPLY – 24 VOLT	10
PRESSURE TRANSDUCERS/SENSORS, SUBMERSIBLE	10
PROTRONIX® CONTROLLER	10
PUMP FAILURE ALARM	11
RELAYS	11
RESISTOR	11
SOLENOID VALVE, 2-WAY LARGE PORT	11
SWITCHES	12
TEMPERATURE TRANSMITTER	12
TRANSFORMER	12
STARTERS & MOTOR CIRCUIT PROTECTORS – IEC	13
STARTERS & MOTOR CIRCUIT PROTECTORS – NEMA	14-16
OVERLOAD COILS I.E.C. & NEMA STARTERS	16
BREAKERS- “THREE PHASE MOTOR CIRCUIT BREAKER”	17
BREAKERS- “SINGLE PHASE MOTOR CIRCUIT BREAKER”	17
BREAKERS-MOTORS-VERTICAL “P”	18
BREAKERS – “QUICKLAG C” TYPE	19-21
BREAKERS – “THERMAL MAGNETIC ” TYPE EHD	22
BREAKERS – “MCP MOTOR CIRCUIT PROTECTOR	22
MOTORS	17

ENGINEERING DATA



Smith &
Loveless, Inc.®

14040 Santa Fe Trail
Lenexa, KS 66215-1234, USA

After Market
Parts Price Book
Section 4
Rectangular Recessed
WWMPS Parts
Page 6

PART

PAGE

MECHANICAL, PIPING, & PARTS

PUMP PARTS

Includes: shaft diameter, impeller, maximum diameter, Suction Side - Diameter Eye, front head, pump stand, volute, gaskets, motor adapter, impeller bolt, impeller washer.

4B2B*1, 4B2D	..23
4B3B, 4C2B	..24
4C2D	..25
4C3B, 4D3B	..26
4B2X*1, 4C2X	..27
6B3B, 6C3B, 6D3B	..28

MECHANICAL SEALS

B-SHAFT (1 $\frac{7}{8}$ ") (Seals & Spare Parts)	..29
C-SHAFT (2 $\frac{1}{8}$ ") (Seals & Spare Parts)	..29
D-SHAFT (3") (Seals & Spare Parts)	..29
DOUBLE BALANCED (High Head) MECHANICAL SEALS	..30

VOLUTE GASKETS	..31
-----------------------	------

IMPELLERS	..31
------------------	------

X-PELLER® IMPELLERS	..31
----------------------------	------

OTHER PARTS

ALARMS	..32
BLOWER - VENTILATION	..32
FORM-A-GASKET	..32
GASKETS	..33
GAUGES, COMBO VACUUM-AIR	..34
HMI MESSAGE PANEL SCREENS	..33
HOODS	..34
HOODS – MISCELLANEOUS PARTS	..34
HOOD (FIBERGLASS) REPAIR KIT	..35
KEYSTOCK	..35

ENGINEERING DATA



Smith &
Loveless, Inc.®

14040 Santa Fe Trail
Lenexa, KS 66215-1234, USA

After Market
Parts Price Book
Section 4
Rectangular Recessed
WWMPs Parts
Page 7

PART

PAGE

OTHER PARTS

LABELS	35
LATCHES, FOR LOCKS	35
LEVEL INDIVATION CONNNECTION PLATE	36
LIFTING STANCHION	36
LINE STRAINER	36
LOUVER, VENT	36
PAINT (VERSAPOX ®) & TOUCH-UP KITS	37
SHADE-AIDE ™	37
SLINGER RINGS (for Motor Shaft)	37
VENT LOUVER	37
VIDEOS - TRAINING	37
4' WET WELL MANWAY ACCESS LIDS (ALUMINUM)	38
5' & 6' WET WELL MANWAY ACCESS LIDS (ALUMINUM)	38

VACUUM PRIMING SYSTEM

FLOAT CHECK VALVES	39
SOLENOID VALVES	39
SONIC START ® STREAMLINE ™ KITS	39
SONIC START ® STREAMLINE ™ PROBE	39
SONIC START ® STREAMLINE ™ REPLACEMENT PARTS	40
VACUUM DOME	40
VACUUM DOME ASSEMBLY	40
VACUUM PUMP – HEAVY DUTY – SINGLE PISTON & SPARE PARTS	41
VACUUM PUMP – HEAVY DUTY – DUAL PISTON & SPARE PARTS	41
VACUUM PUMP – COMBINED EXHAUST ASSEMBLY	42
VACUUM TUBING	42
VACUUM TUBING FITTINGS	42
VAPOR FILTER	42

VALVES

PLUG VALVES	43
SOLENOID VALVES	43
WAFER CHECK VALVES, SPRING LOADED	44
WAFER CHECK VALVES, 4" & 6", SPARE PARTS	44
WRENCH, VALVE	44

ENGINEERING DATA



Smith &
Loveless, Inc.®

14040 Santa Fe Trail
Lenexa, KS 66215-1234, USA

After Market
Parts Price Book
Section 4
Rectangular Recessed
WWMPS Parts
Page 8

ELECTRICAL COMPONENTS

ALARM LIGHT - RED

PART DESCRIPTION	PART #
Alarm Light – Complete Assembly - Red, 120V	28B580B
Body Fixture – Alarm Light	5L76
Adapter – Alarm Light	5L77
Globe – Alarm Light	5L78B
Guard – Alarm Light	5L79
Bulb – 12 Volt	4L120
Bulb – 115 Volt	4L95A

AUXILIARY CONTACTS

PART DESCRIPTION	PART #
Auxiliary Contacts one (1) NO (Normally Open)	4L560A
Auxiliary Contacts one (1) NC (Normally Closed)	4L560B
Auxiliary Contacts one (1) NO (Normally Open) & one (1) NC (Normally Closed)	4L560C
Auxiliary Contacts two (2) NO (Normally Open)	4L560D

CONTACTORS

Not descriptive enough. Ask customer if they mean contact terminal block, Auxiliary Relay, Starter, etc.

CONTROLLER – PROTRONIX®

PART DESCRIPTION	PART #
PROTRONIX® I Controller – 4L536A, 4L536B (SOLD THRU RETROFIT ONLY)	Call Retrofits
PROTRONIX® II Controller – 4L536C-1 (SOLD THRU RETROFIT ONLY)	Call Retrofits

DISPLAY FUSE

PART DESCRIPTION	PART #
Fuse, FNQ, 1 AMP	4L371A
Fuse, FNQ-R, ½ AMP	4L371T

ENGINEERING DATA



Smith &
Loveless, Inc.®

14040 Santa Fe Trail
Lenexa, KS 66215-1234, USA

After Market
Parts Price Book
Section 4
Rectangular Recessed
WWMPs Parts
Page 9

ELECTRICAL COMPONENTS (CONTINUED)

DISPLAY SCREEN PART DESCRIPTION	PART #
Display Screen – HMI – Color Touch Screen - 4L523F – current- (SOLD THRU RETROFIT ONLY) Replaces 4L53C & 4L523E	Call Retrofit
Display Screen – HMI – 2-line LED – 4L523D – obsolete (SOLD THRU RETROFIT ONLY)	Call Retrofit
Display Screen – HMI – 4-line LED – 4L523B – obsolete (SOLD THRU RETROFIT ONLY)	Call Retrofit
Display Screen – HMI – Monochrome Touch Screen – 4L523E – obsolete (SOLD THRU RETROFIT ONLY)	Call Retrofit
Communication Cable (PROTRONIX® II to HMI) 536C-4	Call Retrofit

FLOAT (DISPLACEMENT) SWITCHES, BACKUP

Serve as Backup to the Submersible Pressure Transducer

PART DESCRIPTION	PART #
Float Switch (P/N 87A80 Obsolete, Replaced by 4L291A)	4L291A
Float Switch (Normally Open Blue), 30 ft. cord	4L291A
Float Switch (Normally Closed Red), 30 ft. cord	4L291B
Float Switch (Normally Open Blue), 45 ft. cord	4L291C
Submersible Pressure Transducer – Wet Well Level Sensor – 30' Cord hangs down inside of wet well. (Replaces 4L563C).	4L563J

FLOAT SWITCH, CORD CONNECTOR

PART DESCRIPTION	PART #
Cord Connector, Float Switch Adjustment	5L57C

GROUND FAULT CIRCUIT INTERRUPTER (GFCI) RECEPTACLES

PART DESCRIPTION	PART #
GFCI Receptacle, 15 Amp, Color: Ivory	5L269C
Receptacle Box, Aluminum	5L98A

HEATER

PART DESCRIPTION	PART #
Heater, Strip/Panel Mount with Thermostat – UL Listed 120 Volt 500 Watt (OBSOLETE P/N 4L364 replaced with P/N 4L364A)	4L364A
Heater, Auxiliary, with Fan, 120 Volt 1320/1650 Watt	4L84
Fan Motor for 4L84 Heater	OBSOLETE
Temperature Transmitter	5L350AA

ENGINEERING DATA



Smith &
Loveless, Inc.®

14040 Santa Fe Trail
Lenexa, KS 66215-1234, USA

After Market
Parts Price Book
Section 4
Rectangular Recessed
WWMPS Parts
Page 10

ELECTRICAL COMPONENTS (CONTINUED)

LIGHTNING PROTECTION

PART DESCRIPTION	PART #
Surge Capacitor	4L368
Lightning Arrestor	4L369

PHASE MONITOR RELAYS

PART DESCRIPTION	PART #
Phase Monitor, Voltage: 190 to 270	4L336A
Phase Monitor, Voltage: 430 to 480	4L336B

POWER SUPPLY – 24 VOLT

Powers all 24 volt panel components

PART DESCRIPTION	PART #
Power Supply, 24 VDC (2.3 Amp rating)	4L452C

PRESSURE TRANSDUCERS/SENSORS, SUBMERSIBLE

(Submersible Pressure Transducer hangs down from the pump station and into the wet well, in addition to the float switches used for back-up. Both are used for wet well level sensing.)

PART DESCRIPTION	PART #
0-15 PSI, Submersible Pressure Transducer – 25' Cord (old style) (Old PN: 4L563B-Now 4L563J + reprogrammed E-PROM through Retrofit)	See Retrofit
0-7.5 PSI, Submersible Pressure Transducer – 30' Cord (<i>Replaces 4L563A</i>) (CURRENT STYLE) (<i>Replaces 4L563C</i>).	4L563J

PROTRONIX® CONTROLLER

PART DESCRIPTION	PART #
PROTRONIX® II Input/Output Module (8 In/8 Out) Expansion Card	4L536C-2
PROTRONIX® II Controller - 4L452C-1 (<i>SOLD THRU RETROFIT ONLY</i>)	Call Retrofits

ENGINEERING DATA



Smith &
Loveless, Inc.®

14040 Santa Fe Trail
Lenexa, KS 66215-1234, USA

After Market
Parts Price Book
Section 4
Rectangular Recessed
WWMPs Parts
Page 11

ELECTRICAL COMPONENTS (CONTINUED)

PUMP FAILURE ALARM (Check Valve Limit Switch)	
PART DESCRIPTION	PART #
Pump Failure Alarm Retrofit Kit for Relay Logic (two pump – LH & RH)	H87A376
*Pump Failure Alarm Retrofit Kit for Relay Logic (one pump – RH only)	H87A383A
*Pump Failure Alarm Retrofit Kit for Relay Logic (one pump – LH only)	H87A383B
*Pump Failure Alarm – Switch Only – (one pump - RH only)	87B397A
*Pump Failure Alarm – Switch Only – (one pump – LH only)	87B397B
Pump Failure Alarm Tester (Works with all styles)	87B399

**Note: 87B397A & 87B397B are Switch Only & do not include parts required for initial installation of the pump failure alarm. Customer must verify that they have already installed a pump failure alarm. Otherwise, you will either need H87A376, H87A383A, or H87A383B.*

RELAYS	
PART DESCRIPTION	PART #
Relay, Vacuum Pump Contactor	4L609C
Relay, Time Delay (for Pump Failure, Prime Failure, Time Delay)	4L304J
Relay, 24 VDC, Din Rail Mounted (Double Pole, Double Throw)	4L571D
Relay, 24 VDC, Din Rail, SPST	4L571A
SONIC START® Operating Module	4L264S

RESISTOR	
PART DESCRIPTION	PART #
250 OHM Resistor Wire	4L587A

SOLENOID VALVE, 2-WAY LARGE PORT	
PART DESCRIPTION	PART #
2-Way Solenoid Valve (5/16" orifice) Cannot be used with SONIC START® STREAMLINE™	1L545B conduit connection mounted through panel & backpan
2-Way Solenoid Valve Assembly for the FORMULA X®	87B351
SONIC START® STREAMLINE™ Solenoid Valve/Dome Assembly	87B728A

ENGINEERING DATA



Smith &
Loveless, Inc.®

14040 Santa Fe Trail
Lenexa, KS 66215-1234, USA

After Market
Parts Price Book
Section 4
Rectangular Recessed
WWMPS Parts
Page 12

ELECTRICAL COMPONENTS (CONTINUED)

SWITCHES

PART DESCRIPTION	PART #
Switch, 3-POS Operator Selector, Spring Return Left, HOA (Hand-Off-Auto)	4L13C
Switch, Limit for Intrusion Alarm	5L241
Actuator, for use with 5L241	5L241A
Switch, 2-POS Operator Selector, Keyed	4L366A
Switch (Alarm), 2-POS Operator Selector, Maintained	4L71
Switch, 3-POS Operator Selector, Spring Return Left, HOA	4L13C
Switch, Push Button	4L561A
Float Switch (Normally Open Blue), 30 ft. cord	4L291A
Float Switch (Normally Closed Red), 30 ft. cord	4L291B
Float Switch (Normally Open Blue), 45 ft. cord	4L291C
Mercury-Free (Normally Open, Normally Closed) 40ft cord	4L291F

TEMPERATURE TRANSMITTER

PART DESCRIPTION	PART #
Temperature Transmitter	5L350AA

TRANSFORMER DESCRIPTION

DESCRIPTION	PART #
2 KVA, 240/480 TO 120/240	4L402A
3 KVA, 240/480 TO 120/240	4L402B
3 KVA, 208 TO 120/240	4L402D
5 KVA, 240/480 TO 120/240	4L402E
5 KVA, 208 TO 120/240	4L402EA

ENGINEERING DATA



Smith &
Loveless, Inc.®

14040 Santa Fe Trail
Lenexa, KS 66215-1234, USA

After Market
Parts Price Book
Section 4
Rectangular Recessed
WWMPs Parts
Page 13

ELECTRICAL COMPONENTS (CONTINUED)

IEC RATED STARTERS – 4L915 MOTOR CIRCUIT PROTECTORS – 4L531, 4L532						
MOTOR HORSEPOWER	208 VOLTS		230 VOLTS		460 VOLTS	
	STARTER PART #	CIRCUIT PROTECTOR PART #	STARTER PART #	CIRCUIT PROTECTOR PART #	STARTER PART #	CIRCUIT PROTECTOR PART #
1½	4L915D	4L531F	4L915D	4L531F	4L915C	4L531E
2	4L915Q	4L531F	4L915D	4L531F	4L915C	4L531E
3	4L915Q	4L531F	4L915Q	4L531F	4L915D	4L531E
5	4L915F	4L531G	4L915F	4L531G	4L915Q	4L531F
7½	4L915G	4L531A	4L915G	4L531G	4L915E	4L531F
10	4L915B	4L531A	4L915H	4L531A	4L915F	4L531G
15	4L915J	4L531B	4L915J	4L531B	4L915G	4L531G
20	4L915K	4L531C	4L915J	4L531C	4L915H	4L531A
25	4L915L	4L531D	4L915K	4L531C	4L915H	4L531A
30	4L915M	4L532G	4L915L	4L532A	4L915J	4L531A
40	4L915R	4L532H	4L915N	4L532B	4L915J	4L531B
50			4L915R	4L532H	4L915K	4L531C
60					4L915L	4L531D
75					4L915M	4L532B
100					4L915R	4L532B

SPECIAL NOTE: Starter Motor Circuit Protector Sizing has changed slightly over the years. Consult Factory's BOM for Direct Replacement and to check dimensions.

ENGINEERING DATA



Smith &
Loveless, Inc.®

14040 Santa Fe Trail
Lenexa, KS 66215-1234, USA

After Market
Parts Price Book
Section 4
Rectangular Recessed
WWMPS Parts
Page 14

ELECTRICAL COMPONENTS (CONTINUED)

NEMA RATED STARTERS – 4L514 MOTOR CIRCUIT PROTECTORS – 4L531, 4L532						
MOTOR HORSEPOWER	208 VOLTS		230 VOLTS		460 VOLTS	
	STARTER PART #	BREAKER PART #	STARTER PART #	BREAKER PART #	STARTER PART #	BREAKER PART #
1½	4L514A	4L531F	4L514A	4L531F	4L514G	4L531E
2	4L514A	4L531F	4L514A	4L531F	4L514G	4L531E
3	4L514B	4L531F	4L514B	4L531F	4L514A	4L531E
5	4L514C	4L531G	4L514C	4L531G	4L514A	4L531F
7½	4L514C	4L531A	4L514C	4L531G	4L514C	4L531F
10	4L514D	4L531A	4L514D	4L531A	4L514C	4L531G
15	4L514E	4L532F	4L514D	4L531B	4L514D	4L531G
20	4L514E	4L532E	4L514E	4L532F	4L514D	4L531A
25	4L514E	4L532A	4L514E	4L532E	4L514D	4L531A
30	4L514F	4L532G	4L514E	4L532A	4L514E	4L531A
40	4L514F	4L532H	4L514F	4L532B	4L514E	4L532A
50			4L514F	4L532H	4L514E	4L532B
60					4L514F	4L532B
75					4L514F	4L532B
100					4L514F	4L532H

NOTE: Use NEMA rated starters if dimensions are checked and will fit in panel.

ENGINEERING DATA



Smith &
Loveless, Inc.®

14040 Santa Fe Trail
Lenexa, KS 66215-1234, USA

After Market
Parts Price Book
Section 4
Rectangular Recessed
WWMPs Parts
Page 15

ELECTRICAL COMPONENTS (CONTINUED)

NEMA RATED STARTERS – 4L421			
Motor Horsepower	208 Volts	230 Volts	460 Volts
	Part Numbers	Parts Numbers	Parts Numbers
¾ & 1	4L421A	4L421A	4L421A
1½	4L421A	4L421A	4L421A
2	4L421A	4L421A	4L421A
3	4L421A	4L421A	4L421A
5	4L421B	4L421B	4L421B
7½	4L421B	4L421B	4L421B
10	4L421C	4L421C	4L421B
15	4L421D	4L421C	4L421C
20	4L421D	4L421D	4L421C
25	4L421D	4L421D	4L421C
30	4L421E	4L421D	4L421D
40	4L421E	4L421E	4L421D
50	4L421F	4L421E	4L421D
60	4L421F	4L421F	4L421E
75	4L421F	4L421F	4L421E
100	Special Order	4L421F	4L421E

PARTS ORDERING NOTE: If the customer is replacing older starters with new starters (new part numbers listed above), they will also need to purchase new overload coils.

ENGINEERING DATA



Smith &
Loveless, Inc.®

14040 Santa Fe Trail
Lenexa, KS 66215-1234, USA

After Market
Parts Price Book
Section 4
Rectangular Recessed
WWMPS Parts
Page 16

ELECTRICAL COMPONENTS (CONTINUED)

Motor Horsepower	208 Volts	230 Volts	460 Volts
	Part Number	Part Number	Part Number
¼	4L413H	4L416G	4L413E
1	4L413H	4L413H	4L413F
1½	4L413J	4L413J	4L413G
2	4L413K	4L413K	4L413H
3	4L413L	4L413L	4L413J
5	4L413M	4L413M	4L413K
7½	4L413N	4L413N	4L413L
10	4L413P	4L413P	4L413M
15	4L413R	4L413Q	4L413N
20	4L413T	4L413X	4L413P
25	4L413Y	4L413Y	4L413Q
30	4L413Z	4L413Y	4L413W
40	4L413AA	4L413Z	4L413X
50		4L413AA	4L413Y
60			4L413Y
75			4L413Z
100			4L413AA

PARTS ORDERING NOTE: If the customer is replacing older starters with new starters (new part numbers listed above), they will also need to purchase new overload coils.

ENGINEERING DATA



Smith &
Loveless, Inc.®

14040 Santa Fe Trail
Lenexa, KS 66215-1234, USA

After Market
Parts Price Book
Section 4
Rectangular Recessed
WWMPs Parts
Page 17

ELECTRICAL COMPONENTS (CONTINUED)

THREE PHASE MOTOR CIRCUIT BREAKERS –

Use when increasing or decreasing horsepower.

Motor HP	208 Volts	230 Volts	460 Volts
	Part Numbers	Parts Numbers	Parts Numbers
1½	4L531F	4L531F	4L531E
2	4L531F	4L531F	4L531E
3	4L531F	4L531F	4L531E
5	4L531G	4L531G	4L531F
7½	4L531A	4L531A	4L531G
10	4L531A	4L531A	4L531G
15	4L531B	4L531B	4L531G
20	4L531C	4L531C	4L531A
25	4L164P	4L531C	4L531B
30	4L164P	4L164P	4L531C
40	4L431CW	4L164P	4L531C
50	-	-	4L164P
60	-	-	4L164P
	-	-	

REQUIREMENTS FOR 208 VOLTS: 40 HP OR HIGHER SELECT 480 VOLT OPTIONS AS NOTED.

REQUIREMENTS FOR 230 VOLTS: 50 HP OR HIGHER SELECT 480 VOLT OPTIONS AS NOTED.

SINGLE PHASE MOTOR CIRCUIT BREAKERS –

Use when increasing or decreasing horsepower.

	230 Volts
Motor HP	Parts Numbers
¼	4L218B
1/3	4L218B
½	4L218B
¾	4L218B
1	4L218B
1½	4L218C
2	4L218D
3	4L218F
5	4L218H

ENGINEERING DATA



Smith &
Loveless, Inc.®

14040 Santa Fe Trail
Lenexa, KS 66215-1234, USA

After Market
Parts Price Book
Section 4
Rectangular Recessed
WWMPS Parts
Page 18

ELECTRICAL COMPONENTS (CONTINUED)

MOTORS – VERTICAL “P”

BASE PUMP MOTORS, ODP, 3/60/230-460 VOLT			STANDARD SEAL
HORSEPOWER	RPM	OLD PART #	NEW PART #
1 hp, Motor	900	95L39-1	95L39041-1AA001R0
1½ hp, Motor	900	95L39-2	95L39051-1AA001R0
2 hp, Motor	900	95L39-3	95L39061-1AA001R0
2 hp, Motor	1200	95L39-4	95L39161-1AA001R0
3 hp, Motor	900	95L39-5	95L39071-1AA001R0
3 hp, Motor	1200	95L39-6	95L39171-1AA001R0
3 hp, Motor	1800	95L39-28	95L39271-1AA001R0
5 hp, Motor	900	95L39-8	95L39081-1AA001R0
5 hp, Motor	1200	95L39-9	95L39181-1AA001R0
5 hp, Motor	1800	95L39-10	95L39281-1AA001R0
7½ hp, Motor	900	95L39-11	95L39091-1AA001R0
7½ hp, Motor	1200	95L39-12	95L39191-1AA001R0
7½ hp, Motor	1800	95L39-13	95L39291-1AA001R0
10 hp, Motor	900	Consult Factory *	Consult Factory *
10 hp, Motor	1200	95L39-15	95L391A1-1AA001R0
10 hp, Motor	1800	95L39-16	95L392A1-1AA001R0
15 hp, Motor	900	95L39-17	95L390B2-1AA001R0
15 hp, Motor	1200	95L39-18	95L391B2-1AA001R0
15 hp, Motor	1800	95L39-19	95L392B1-1AA001R0
20 hp, Motor	900	Consult Factory *	95L390C3-1AA001R0
20 hp, Motor	1200	Consult Factory *	Consult Factory *
20 hp, Motor	1800	Consult Factory *	Consult Factory *
25 hp, Motor	1200	95L39-23	95L391D3-1AA001R0
25 hp, Motor	1800	95L39-24	95L392D2-1AA001R0
30 hp, Motor	1200	95L39-25	95L391E3-1AA001R0
30 hp, Motor	1800	95L39-26	95L392E2-1AA001R0
40 hp, Motor	1200	95L39-46	95L391F3-1AA001R0
40 hp, Motor	1800	95L39-27	95L392F3-1AA001R0
50 hp, Motor	1200	95L39-47	95L391G3-1AA001R0
50 hp, Motor	1800	95L39-34	95L392G3-1AA001R0
60 hp, Motor	1200	95L39-48	95L391H3-1AA001R0
60 hp, Motor	1800	95L39-52	95L392H3-1AA001R0
75 hp, Motor	1200	95L39-49	95L391J3-3BA002B0
75 hp, Motor	1800	95L39-53	95L392J3-3BA000B0

* Need shaft size confirmation to determine correct motor

MOTORS—TEFC, Explosion-proof, Immersible call factory for sizing, pricing, and delivery

ENGINEERING DATA



Smith &
Loveless, Inc.®

14040 Santa Fe Trail
Lenexa, KS 66215-1234, USA

After Market
Parts Price Book
Section 4
Rectangular Recessed
WWMPs Parts
Page 19

ELECTRICAL COMPONENTS (CONTINUED)

BREAKERS – “QUICKLAG C” TYPE, SINGLE POLE, 5000 AMPERE INTERRUPTING CAPACITY, 120/240 VAC (TYPICALLY CONTROLS CIRCUIT BREAKER)

PART DESCRIPTION	PART #
10, Continuous Amp Rating	4L82B
15, Continuous Amp Rating	4L82C
20, Continuous Amp Rating	4L82D
30, Continuous Amp Rating	4L82F
35, Continuous Amp Rating	4L82G
40, Continuous Amp Rating	4L82H
50, Continuous Amp Rating	4L82J
Handle Tie (California)	4L82P

BREAKERS – “QUICKLAG C” TYPE, AB DE-LON, 2 POLE, 10-100 AMPERES, 240 VAC (TYPICALLY TRANSFORMER CIRCUIT BREAKER OR SINGLE PHASE PUMP MOTORS)

PART DESCRIPTION	PART #
10, Continuous Amp Rating	4L218A
15, Continuous Amp Rating	4L218B
20, Continuous Amp Rating	4L218C
25, Continuous Amp Rating	4L218D
30, Continuous Amp Rating	4L218E
35, Continuous Amp Rating	4L218F
40, Continuous Amp Rating	4L218G
50, Continuous Amp Rating	4L218H
60, Continuous Amp Rating	4L218J
70, Continuous Amp Rating	4L218K
90, Continuous Amp Rating	4L218L
100, Continuous Amp Rating	4L218M
Breaker Handle Lock – “Quicklag C” Type	4L403

PARTS ORDERING NOTE: Each time a Breaker is ordered as a part or with a retrofit, a Breaker Handle Lock is required.

ENGINEERING DATA



Smith &
Loveless, Inc.®

14040 Santa Fe Trail
Lenexa, KS 66215-1234, USA

After Market
Parts Price Book
Section 4
Rectangular Recessed
WWMPS Parts
Page 20

ELECTRICAL COMPONENTS *(CONTINUED)*

**BREAKERS – “QUICKLAG C” TYPE, AB DE-LON, 2 POLE, 10-100
AMPERES, 480 VAC**

**(TYPICALLY TRANSFORMER CIRCUIT BREAKER OR SINGLE PHASE
PUMP MOTORS)**

PART DESCRIPTION	PART #
15, Continuous Amp Rating	4L258BA
20, Continuous Amp Rating	4L258BB
25, Continuous Amp Rating	4L258BC
30, Continuous Amp Rating	4L258BD
35, Continuous Amp Rating	4L258BE
40, Continuous Amp Rating	4L258BF
45, Continuous Amp Rating	4L258BP
50, Continuous Amp Rating	4L258BG
60, Continuous Amp Rating	4L258BH
70, Continuous Amp Rating	4L258BJ
80, Continuous Amp Rating	4L258BQ
90, Continuous Amp Rating	4L258BK
100, Continuous Amp Rating	4L258BL
Breaker Handle Lock – “Quicklag C” Type	4L403

PARTS ORDERING NOTE: Each time a Breaker is ordered as a part or with a retrofit, a Breaker Handle Lock is required.

ENGINEERING DATA



Smith &
Loveless, Inc.®

14040 Santa Fe Trail
Lenexa, KS 66215-1234, USA

After Market
Parts Price Book
Section 4
Rectangular Recessed
WWMPS Parts
Page 21

ELECTRICAL COMPONENTS (CONTINUED)

BREAKERS – “QUICKLAG C” TYPE, AB DE-LON, 3 POLE, 10-100 AMPERES, 240 VAC

(TYPICALLY USED WITH 3 PHASE PUMP MOTORS 240 AND BELOW)

PART DESCRIPTION	PART #
10, Continuous Amp Rating *	4L202A **
15, Continuous Amp Rating	4L202B
20, Continuous Amp Rating	4L202C
25, Continuous Amp Rating	4L202D
30, Continuous Amp Rating	4L202E
35, Continuous Amp Rating	4L202F
40, Continuous Amp Rating	4L202G
45, Continuous Amp Rating	4L202P
50, Continuous Amp Rating	4L202H
55, Continuous Amp Rating	4L202J
60, Continuous Amp Rating	4L202K
70, Continuous Amp Rating	4L202L
80, Continuous Amp Rating	4L202Q
90, Continuous Amp Rating	4L202M
100, Continuous Amp Rating	4L202N
Breaker Handle Lock – “Quicklag C” Type	4L403

PARTS ORDERING NOTE: Each time a Breaker is ordered as a part or with a retrofit, a Breaker Handle Lock is required.

MOUNTING STRAP FOR BREAKERS – “QUICKLAG C” TYPE

PART DESCRIPTION	PART #
Mounting Strap	4L83

* Not UL Listed

** Low Usage Item

ENGINEERING DATA



Smith &
Loveless, Inc.®

14040 Santa Fe Trail
Lenexa, KS 66215-1234, USA

After Market
Parts Price Book
Section 4
Rectangular Recessed
WWMPs Parts
Page 22

ELECTRICAL COMPONENTS (CONTINUED)

BREAKERS – THERMAL MAGNETIC TYPE EHD, 1/2/3 POLE, 10-100 AMPS (15,000 AMPS INTERRUPTING CAPACITY)

(TYPICALLY USED WITH 3 PHASE PUMP MOTORS 480 VOLT)

AMP RATING @ 40°F (CONT.)	1-POLE 277 VAC (MAX.)	2-POLE 277 VAC (MAX.)	3-POLE 480 VAC (MAX.)
10 *	4L258AN **	4L258BN **	4L258CN **
15	4L258AA	4L258BA	4L258CA
20	4L258AB	4L258BB	4L258CB
25	4L258AC	4L258BC	4L258CC
30	4L258AD	4L258BD	4L258CD
35	4L258AE	4L258BE	4L258CE
40	4L258AF	4L258BF	4L258CF
45	4L258AP	4L258BP	4L258CP
50	4L258AG	4L258BG	4L258CG
60	4L258AH	4L258BH	4L258CH
70	4L258AJ	4L258BJ **	4L258CJ
80	4L258AQ	4L258BQ	4L258CQ
90	4L258AK	4L258BK	4L258CK
100	4L258AL	4L258BL	4L258CL
100 NA	4L258AM	4L258BM	4L258CM
Breaker Handle Lock – “EHD” Type			4L404

PARTS ORDERING NOTE: Each time a Breaker is ordered as a part or with a retrofit, a Breaker Handle Lock is required.

BREAKERS – MCP MOTOR CIRCUIT PROTECTOR, 3-POLE

TRIP RANGE AMPS	CONTINUOUS AMP RATING	PART #
100 – 300	30	4L164D
160 – 480	50	4L164E
275 – 1000	100	4L164F
450 – 1550	150	4L164G
Transformer	Breaker	4L218B

* Not UL Listed

** Low Usage Item

ENGINEERING DATA



Smith &
Loveless, Inc.®

14040 Santa Fe Trail
Lenexa, KS 66215-1234, USA

After Market
Parts Price Book
Section 4
Rectangular Recessed
WWMPs Parts
Page 23

MECHANICAL, PIPING, & PARTS

PUMP PARTS	4B2B*1	4B2D
<i>VERIFY ALL CASTED PARTS WITH FACTORY</i>	Pump	Pump
Shaft Diameter	1 7/8"	1 7/8"
Mechanical Seal Kit	H87A28	H87A28
Impeller, CW (Clockwise)	60D21	60C76
Impeller, CCW (Counter-Clockwise)	60D42	60C75
Maximum Diameter	10 1/8"	10 1/8"
Suction Side - Diameter Eye	4"	4"
Motor Adapter-Also sell S/N NAMEPLATE	60B165A-304	60B165A-304
Suction Piping		
Integral Volute & Front Head, CCW	87B286A-304 - 4" Suc. Piping 87B287A-304 - 6" Suc. Piping	87B286A-304 - 4" Suc. Piping 87B287B-304 - 6" Suc. Piping
Integral Volute & Front Head, CW	87B286B-304 - 4" Suc. Piping 87B287B-304 - 6" Suc. Piping	87B286B-304 - 4" Suc. Piping 87B287B-304 - 6" Suc. Piping
Mounting Adapter	87B239-304 - 4" Suc. Piping 87B241-304 - 6" Suc. Piping	87B239-304 - 4" Suc. Piping 87B241-304 - 6" Suc. Piping
Flange Gasket	11L1AA - 4" Suc. Piping 11L1CA - 6" Suc. Piping	11L1AA - 4" Suc. Piping 11L1CA - 6" Suc. Piping
Socket Head Capscrew	6L178B - 4" Suc. Piping 6L178F - 6" Suc. Piping	6L178B - 4" Suc. Piping 6L178F - 6" Suc. Piping
Discharge Pipe - 4"	28A549BE-304 - 4" piping 28A550BX-304 - 6" piping	28A549BE-304 - 4" piping 28A550BX-304 - 6" piping
Elbow (Between Discharge Pipe & Tee)	2L7A-304 - 4" piping 2L7B-304 - 6" piping	2L7A-304 - 4" piping 2L7B-304 - 6" piping
Tee (Required only on 4" piping)	2L12A-304	2L12A-304
Flange Filler - Use on 4" diameter Wet Well Only	2L28AH-304	2L28AH-304
4" piping with 5/6" diameter Wet Well doesn't use 6" piping with 5/6" diameter Wet Well	2L86B009J-304	2L86B009J-304
Plug Valve	2L104A-304 - 4" piping 2 req'd 2L148M-304 - 6" piping 1 req'd	2L104A-304 - 4" piping 2 req'd 2L148M-304 - 6" piping 1 req'd
Elbow (Between Plug Valve & Check Valve) 4" standard elbow, 6" reducing elbow	87B242-304 & 87B243-304 - 4" 87B244-304 & 87B245-304 - 6"	87B242-304 & 87B243-304 - 4" 87B244-304 & 87B245-304 - 6"
Check Valve Assembly, LH - 4"	2L153S 87A255 (Flange Gasket)	2L153S 87A255 (Flange Gasket)
Check Valve Assembly, LH - 6"	2L153Q-304 87A224 (Flange Gasket)	2L153Q-304 87A224 (Flange Gasket)
Check Valve Assembly, RH - 4"	2L153T 87A255 (Flange Gasket)	2L153T 87A255 (Flange Gasket)
Check Valve Assembly, RH - 6"	2L153R-304 87A224 (Flange Gasket)	2L153R-304 87A224 (Flange Gasket)
Volute Gasket (1/64 & 1/16 thickness available)	60A26 (1/32")	60A26 (1/32")
Impeller Bolt	60A12	60A12
Impeller Washer	60A20	60A20

ENGINEERING DATA



Smith &
Loveless, Inc.®

14040 Santa Fe Trail
Lenexa, KS 66215-1234, USA

After Market
Parts Price Book
Section 4
Rectangular Recessed
WWMPS Parts
Page 24

MECHANICAL, PIPING, & PARTS (CONTINUED)

PUMP PARTS	4B3B	4C2B
<i>VERIFY ALL CASTED PARTS WITH FACTORY</i>	Pump	Pump
Shaft Diameter	1 7/8"	2 1/8"
Mechanical Seal Kit	H87A28	H87A97
Impeller, CW (Clockwise)	60D43	60D63
Impeller, CCW (Counter-Clockwise)	60D1	60D64
Maximum Diameter	12"	10-1/8"
Suction Side - Diameter Eye	4"	4"
Motor Adapter-Also sell S/N NAMEPLATE	60B165D-304	60B165B-304
Suction Piping		
Integral Volute & Front Head, CCW	87D310A-304 – 4" Suc. Piping	87B286A-304 – 4" Suc. Piping
	87D311A-304 – 4" Suc. Piping	87B287A-304 – 6" Suc. Piping
Integral Volute & Front Head, CW	87D310B-304 – 4" Suc. Piping	87B286B-304 - 4" Suc. Piping
	87D311B-304 – 4" Suc. Piping	87B287B-304 – 6" Suc. Piping
Mounting Adapter	87B239-304 - 4" Suc. Piping	87B239-304 - 4" Suc. Piping
	87B241-304 – 6" Suc. Piping	87B241-304 – 6" Suc. Piping
Flange Gasket	11L1AA – 4" Suc. Piping	11L1AA – 4" Suc. Piping
	11L1CA – 6" Suc. Piping	11L1CA – 6" Suc. Piping
Socket Head Capscrew	6L178B – 4" Suc. Piping	6L178B – 4" Suc. Piping
	6L178F – 6" Suc. Piping	6L178F – 6" Suc. Piping
Discharge Pipe	28A549BE-304 – 4" piping	28A549BE-304 – 4" piping
	28A550BX-304 – 6" piping	28A550BX-304 – 6" piping
Elbow (Between Discharge Pipe & Tee)	2L7A-304 – 4" piping	2L7A-304 – 4" piping
	2L7B-304 – 6" piping	2L7B-304 – 6" piping
Tee (Required only on 4" piping)	2L12A-304	2L12A-304
Flange Filler – Use on 4' diameter Wet Well Only 4" piping with 5/6" diameter Wet Well doesn't use 6" piping with 5/6" diameter Wet Well	2L28AJ-304	2L28AH-304
	2L86B014-304	2L86B009J-304
Plug Valve	2L104A-304 – 4" piping 2 req'd	2L104A-304 – 4" piping 2 req'd
	2L148M-304 – 6" piping 1 req'd	2L148M-304 – 6" piping 1 req'd
Elbow (Between Plug Valve & Check Valve) 4" standard elbow, 6" reducing elbow	87B242-304 & 87B243-304 – 4"	87B242-304 & 87B243-304 – 4"
	87B244-304 & 87B245-304 – 6"	87B244-304 & 87B245-304 – 6"
Check Valve Assembly, LH – 4" Check Valve Assembly, LH – 6"	2L153S	2L153S
	87A255 (Flange Gasket)	87A255 (Flange Gasket)
	2L153Q-304	2L153Q-304
Check Valve Assembly, RH – 4" Check Valve Assembly, RH – 6"	87A224 (Flange Gasket)	87A224 (Flange Gasket)
	2L153T	2L153T
	87A255 (Flange Gasket)	87A255 (Flange Gasket)
Volute Gasket (1/64 & 1/16 thickness available)	2L153R-304	2L153R-304
	87A224 (Flange Gasket)	87A224 (Flange Gasket)
	60A28 (1/32")	60A26 (1/32")
Impeller Bolt	60A12	60A12
Impeller Washer	60A20	60A20

ENGINEERING DATA



Smith &
Loveless, Inc.®

14040 Santa Fe Trail
Lenexa, KS 66215-1234, USA

After Market
Parts Price Book
Section 4
Rectangular Recessed
WWMPS Parts
Page 25

MECHANICAL, PIPING, & PARTS (CONTINUED)

PUMP PARTS	4C2D *
<i>VERIFY ALL CASTED PARTS WITH FACTORY</i>	Pump
Shaft Diameter	2 1/8"
Mechanical Seal Kit	H87A97
Impeller, CW (Clockwise)	60C77
Impeller, CCW (Counter-Clockwise)	60C78
Maximum Diameter	10-1/8"
Suction Side - Diameter Eye	4"
Motor Adapter-Also sell S/N NAMEPLATE	60B165B-304
Suction Piping	
Integral Volute & Front Head, CCW	87B286A-304 – 4" Suc. Piping 87B287B-304 – 6" Suc. Piping
Integral Volute & Front Head, CW	87B286B-304 – 4" Suc. Piping 87B287B-304 – 6" Suc. Piping
Mounting Adapter	87B239-304 - 4" Suc. Piping 87B241-304 – 6" Suc. Piping
Flange Gasket	11L1AA – 4" Suc. Piping 11L1CA – 6" Suc. Piping
Socket Head Capscrew	6L178B – 4" Suc. Piping 6L178F – 6" Suc. Piping
Discharge Pipe – 4"	28A549BE-304 – 4" piping 28A550BX-304 – 6" piping
Elbow (Between Discharge Pipe & Tee)	2L7A-304 – 4" piping 2L7B-304 – 6" piping
Tee	2L12A-304
Flange Filler – Use on 4' diameter Wet Well Only 4" piping with 5/6' diameter Wet Well doesn't use 6" piping with 5/6' diameter Wet Well	2L28AH-304 2L86B009J-304
Plug Valve	2L104A-304 – 4" piping 2 req'd 2L148M-304 – 6" piping 1 req'd
Elbow (Between Plug Valve & Check Valve) 4" standard elbow, 6" reducing elbow	87B242-304 & 87B243-304 – 4" 87B244-304 & 87B245-304 – 6"
Check Valve Assembly, LH – 4" Check Valve Assembly, LH – 6"	2L153S 87A255 (Flange Gasket) 2L153Q-304 87A224 (Flange Gasket)
Check Valve Assembly, RH – 4" Check Valve Assembly, RH – 6"	2L153T 87A255 (Flange Gasket) 2L153R-304 87A224 (Flange Gasket)
Volute Gasket (1/64 & 1/16 thickness available)	60A26 (1/32")
Impeller Bolt	60A12
Impeller Washer	60A20

PARTS ORDERING NOTE: Remind customer that gaskets may be needed when ordering casted parts

ENGINEERING DATA



Smith &
Loveless, Inc.®

14040 Santa Fe Trail
Lenexa, KS 66215-1234, USA

After Market
Parts Price Book
Section 4
Rectangular Recessed
WWMPS Parts
Page 26

MECHANICAL, PIPING, & PARTS (CONTINUED)

PUMP PARTS	4C3B	4D3B
<i>VERIFY ALL CASTED PARTS WITH FACTORY</i>	Pump	Pump
Shaft Diameter	2 ¹ / ₈ "	3"
Mechanical Seal Kit	H87A97	H87A182
Impeller, CW (Clockwise)	60D44	60D129
Impeller, CCW (Counter-Clockwise)	60D23	60D193
Maximum Diameter	12"	12"
Suction Side - Diameter Eye	4"	4"
Motor Adapter-Also sell S/N NAMEPLATE	60B165E-304	60B165M-304
Suction Piping		
Integral Volute & Front Head, CCW	87B286A-304 – 4" Suc. Piping 87B287B-304 – 6" Suc. Piping	87B286A-304 – 4" Suc. Piping 87B287B-304 – 6" Suc. Piping
Integral Volute & Front Head, CW	87B286B-304 – 4" Suc. Piping 87B287B-304 – 6" Suc. Piping	87B286B-304 – 4" Suc. Piping 87B287B-304 – 6" Suc. Piping
Mounting Adapter	87B239-304 - 4" Suc. Piping 87B241-304 – 6" Suc. Piping	87B239-304 - 4" Suc. Piping 87B241-304 – 6" Suc. Piping
Flange Gasket	11L1AA – 4" Suc. Piping 11L1CA – 6" Suc. Piping	11L1AA – 4" Suc. Piping 11L1CA – 6" Suc. Piping
Socket Head Capscrew	6L178B – 4" Suc. Piping 6L178F – 6" Suc. Piping	6L178B – 4" Suc. Piping 6L178F – 6" Suc. Piping
Discharge Pipe	28A549BE-304 – 4" piping 28A550BX-304 – 6" piping	28A549BE-304 – 4" piping 28A550BX-304 – 6" piping
Elbow (Between Discharge Pipe & Tee)	2L7A-304 – 4" piping 2L7B-304 – 6" piping	2L7A-304 – 4" piping 2L7B-304 – 6" piping
Tee (Required only on 4" piping)	2L12A-304	2L12A-304
Flange Filler – Use on 4' diameter Wet Well Only	2L28AJ-304	2L28AJ-304
4" piping with 5'/6' diameter Wet Well doesn't use 6" piping with 5'/6' diameter Wet Well	2L86B014-304	2L86B014-304
Plug Valve	2L104A-304 – 4" piping 2 req'd 2L148M-304 – 6" piping 1 req'd	2L104A-304 – 4" piping 2 req'd 2L148M-304 – 6" piping 1 req'd
Elbow (Between Plug Valve & Check Valve)	87B242-304 & 87B243-304 – 4" 87B244-304 & 87B245-304 – 6"	87B242-304 & 87B243-304 – 4" 87B244-304 & 87B245-304 – 6"
Check Valve Assembly, LH – 4"	2L153S 87A255 (Flange Gasket)	2L153S 87A255 (Flange Gasket)
Check Valve Assembly, LH – 6"	2L153Q-304 87A224 (Flange Gasket)	2L153Q-304 87A224 (Flange Gasket)
Check Valve Assembly, RH – 4"	2L153T 87A255 (Flange Gasket)	2L153T 87A255 (Flange Gasket)
Check Valve Assembly, RH – 6"	2L153R-304 87A224 (Flange Gasket)	2L153R-304 87A224 (Flange Gasket)
Volute Gasket (1/64 & 1/16 thickness available)	60A28 (1/32")	60A28 (1/32")
Impeller Bolt	60A12	60A87
Impeller Washer	60A20	60A86

ENGINEERING DATA



Smith &
Loveless, Inc.®

14040 Santa Fe Trail
Lenexa, KS 66215-1234, USA

After Market
Parts Price Book
Section 4
Rectangular Recessed
WWMPs Parts
Page 27

MECHANICAL, PIPING, & PARTS (CONTINUED)

PUMP PARTS	4B2X*1	4C2X
<i>VERIFY ALL CASTED PARTS WITH FACTORY</i>	Pump	Pump
Shaft Diameter	1 7/8"	2 1/8"
Mechanical Seal Kit	H87A28	H87A97
X-PELLER® , CW (Clockwise)	(see table on page 31)	60B252C *
X-PELLER® , CCW (Counter-Clockwise)	(see table on page 31)	60B252D *
Maximum Diameter	10-1/8"	10-1/8"
Suction Side - Diameter Eye	4"	4"
Motor Adapter-Also sell S/N NAMEPLATE	60B165A-304	60B165A-304
Suction Piping		
Integral Volute & Front Head, CCW	87B286A-304 - 4" Suc. Piping 87B287A-304 - 6" Suc. Piping	87B286A-304 - 4" Suc. Piping 87B287B-304 - 6" Suc. Piping
Integral Volute & Front Head, CW	87B286B-304 - 4" Suc. Piping 87B287B-304 - 6" Suc. Piping	87B286B-304 - 4" Suc. Piping 87B287B-304 - 6" Suc. Piping
Mounting Adapter	87B239-304 - 4" Suc. Piping 87B241-304 - 6" Suc. Piping	87B239-304 - 4" Suc. Piping 87B241-304 - 6" Suc. Piping
Flange Gasket	11L1AA - 4" Suc. Piping 11L1CA - 6" Suc. Piping	11L1AA - 4" Suc. Piping 11L1CA - 6" Suc. Piping
Socket Head Capscrew	6L178B - 4" Suc. Piping 6L178F - 6" Suc. Piping	6L178B - 4" Suc. Piping 6L178F - 6" Suc. Piping
Discharge Pipe	28A549BE-304 - 4" piping 28A550BX-304 - 6" piping	28A549BE-304 - 4" piping 28A550BX-304 - 6" piping
Elbow (Between Discharge Pipe & Tee)	2L7A-304 - 4" piping 2L7B-304 - 6" piping	2L7A-304 - 4" piping 2L7B-304 - 6" piping
Tee (Required only on 4" piping)	2L12A-304	2L12A-304
Flange Filler - Use on 4" diameter Wet Well Only	2L28AH-304	2L28AH-304
4" piping with 5/6" diameter Wet Well doesn't use 6" piping with 5/6" diameter Wet Well	2L86B009J-304	2L86B009J-304
Plug Valve	2L104A-304 - 4" piping 2 req'd 2L148M-304 - 6" piping 1 req'd	2L104A-304 - 4" piping 2 req'd 2L148M-304 - 6" piping 1 req'd
Elbow (Between Plug Valve & Check Valve) 4" standard elbow, 6" reducing elbow	87B242-304 & 87B243-304 - 4" 87B244-304 & 87B245-304 - 6"	87B242-304 & 87B243-304 - 4" 87B244-304 & 87B245-304 - 6"
Check Valve Assembly, LH - 4" Check Valve Assembly, LH - 6"	2L153S 87A255 (Flange Gasket) 2L153Q-304 87A224 (Flange Gasket)	2L153S 87A255 (Flange Gasket) 2L153Q-304 87A224 (Flange Gasket)
Check Valve Assembly, RH - 4" Check Valve Assembly, RH - 6"	2L153T 87A255 (Flange Gasket) 2L153R-304 87A224 (Flange Gasket)	2L153T 87A255 (Flange Gasket) 2L153R-304 87A224 (Flange Gasket)
Volute Gasket (1/64 & 1/16 thickness available)	60A26 (1/32")	60A26 (1/32")
Impeller Bolts	60A12	60A12
Impeller Washer	60A20	60A20

PARTS ORDERING NOTE: Remind customer that gaskets may be needed when ordering casted parts

© 2006, 2008, 2009, 2010, 2011, 2012, 2013, 2014, 2015, 2016, 2017 Smith & Loveless, Inc.

ENGINEERING DATA



Smith &
Loveless, Inc.®

14040 Santa Fe Trail
Lenexa, KS 66215-1234, USA

After Market
Parts Price Book
Section 4
Rectangular Recessed
WWMPS Parts
Page 28

MECHANICAL, PIPING, & PARTS (CONTINUED)

PUMP PARTS <i>VERIFY ALL CASTED PARTS WITH FACTORY</i>	6B3B Pump	6C3B Pump	6D3B Pump
Shaft Diameter	1 ⁷ / ₈ "	2 ¹ / ₈ "	3"
Mechanical Seal Kit	H87A28	H87A97	H87A182
Impeller, CW (Clockwise)	60D45	60D47	60D90
Impeller, CCW (Counter-Clockwise)	60D34	60D46	60D192
Maximum Diameter	12"	12"	12"
Suction Side - Diameter Eye	5 ¹ / ₈ "	5 ¹ / ₈ "	5 ¹ / ₈ "
Motor Adapter-Also sell S/N NAMEPLATE	60B165D-304	60B165F-304	60B165M-304
Suction Piping			
Volute	60D35-304	60D35-304	60D35-304
Front Head	60C88-304	60C88-304	60C88-304
Mounting Adapter	87B241-304	87B241-304	87B241-304
Flange Gasket	11L1CA	11L1CA	11L1CA
Socket Head Capscrew	6L17BF	6L17BF	6L17BF
Front Head	60C88-304	60C88-304	60C88-304
Pump Stand	None	None	None
Discharge Pipe 8" needs 2L28013-304 + 2L201B	2L28013-304 – 6"	2L28013-304 – 6"	2L28013-304 – 6"
Elbow (Between Discharge Pipe & Tee)	2L7B	2L7B	2L7B
Tee	None	None	None
Flange Filler	2L86BO12D-304	2L86BO12D-304	2L86BO12D-304
Plug Valve	2L148M-304	2L148M-304	2L148M-304
Elbow (Between Plug Valve & Check Valve)	87B246-304 & 87B247-304	87B246-304 & 87B247-304	87B246-304 & 87B247-304
	2L153Q-304	2L153Q-304	2L153Q-304
Check Valve Assembly, LH – 6"	87A224 (Flange Gasket)	87A224 (Flange Gasket)	87A224 (Flange Gasket)
Check Valve Assembly, RH – 6"	2L153R-304 87A224 (Flange Gasket)	2L153R-304 87A224 (Flange Gasket)	2L153R-304 87A224 (Flange Gasket)
Volute Gasket (1/64 & 1/16 thickness available)	60A28 (1/32")	60A28 (1/32")	60A28 (1/32")
Impeller Bolt	60A12	60A12	60A87
Impeller Washer	60A20	60A20	60A86

PARTS ORDERING NOTE: Remind customer that gaskets may be needed when ordering casted parts

ENGINEERING DATA



Smith &
Loveless, Inc.®

14040 Santa Fe Trail
Lenexa, KS 66215-1234, USA

After Market
Parts Price Book
Section 4
Rectangular Recessed
WWMPS Parts
Page 29

MECHANICAL, PIPING, & PARTS (CONTINUED)

MECHANICAL SEALS

SEAL & SPARE PARTS	B-SHAFT	C-SHAFT	D-SHAFT
	1 7/8"	2 1/8"	3"
Seal Kit, Mechanical Seal	H87A28	H87A97	H87A182
Bronze Seal Housing	87B2	87B19 ***	87B73 ***
Seal Housing – Flat Gasket **	60A11	60A17	60A84
Seal Housing - Quad Ring **	60A110	60A111	60A146
Ceramic Rotating Wear Ring	60A32 *	60A33 *	60A85 *
Carbon Stationary Wear Ring	60A36 *	60A37 *	60A52 *
Rotating O-Ring	60A39 *	60A41 *	60A53 *
Stationary Quad Ring	60A38 *	60A40 *	60A54 *
Spring	60A30 *	60A31 *	60A55 *
Impeller Bolt	60A12	60A12	60A87
Impeller Washer	60A20	60A20	60A86
Volute Gasket	See Volute Gasket Table On Page 31		

* Parts contained in H87A28, H87A97, or H87A182 Mechanical Seal Kits

PARTS ORDERING NOTE: Each time the impeller bolt is removed (required for seal replacement), Smith & Loveless recommends installation of a new impeller bolt that has the embedded Nylock.

PARTS ORDERING NOTE Each time a new seal, ceramic, carbon or spring is installed, a volute gasket, seal housing gasket or quad ring, and impeller bolt are recommended.

** **PARTS TIP:** Seal Housing - Flat Gasket vs. Quad Ring: The older seal housing has a flat surface and uses the flat gasket for both the single and double mechanical seals. The newer seal housing has a groove and it can use either the flat gasket or the quad ring.

*** **SEAL HOUSING:** Call factory for different seal housings for 4-frame pumps.(4B4B, 6C4V)

**** **BOLDED PARTS:** Always quote all bolded parts when quoting a mechanical seal kit.

ENGINEERING DATA



Smith &
Loveless, Inc.®

14040 Santa Fe Trail
Lenexa, KS 66215-1234, USA

After Market
Parts Price Book
Section 4
Rectangular Recessed
WWMPS Parts
Page 30

MECHANICAL, PIPING, & PARTS (CONTINUED)

DOUBLE BALANCED (FOR OVER 200' TDH****) MECHANICAL SEALS

SEAL & SPARE PARTS (HIGH HEAD SEALS – For Over 200' TDH**** or Series P.S.)	C-SHAFT 2-1/8"	D-SHAFT 3"
Seal Kit, Mechanical Seal – Double Balanced (DOES NOT INCLUDE BALANCE SLEEVE)	H60A156	H60A137
Complete Assembly including Bronze Seal Housing & Mechanical Seal (Parts include Upper Housing thru Lower Housing) (Order one extra Seal Housing Quad Ring)	87C425	87C427
Bronze Seal Housing, Upper	87C424	87C428
Bronze Seal Housing, Lower	60C95	60C97
Seal Housing Gasket - Flat ***	60A17	60A84
Seal Housing Gasket - Quad Ring ***	60A111	60A112
Ceramic Rotating Wear Ring (requires 2)	60A155 *	60A85 *
Carbon Stationary Wear Ring (requires 2)	60A153 *	60A136 *
Stationary Quad Ring (requires 2)	11L47E *	60A54 *
Spring	60A154 *	60A135 *
O-Ring-Balance Sleeve, Inner (D-Shaft – new style sleeve 60C112/B requires 2, old style sleeve 60C112/A requires 1)	11L207C *	11L207A *
O-Ring Balance Sleeve, Outer (Both old & new require two out O-Rings)	11L207D *	11L207B *
Balance Sleeve	60C159**	60C112**
Impeller Bolts	60A12	60A87
Impeller Washer	60A20	60A86
Volute Gaskets	See the Volute Gasket Table	

BOLDED PARTS: Always quote all bolded parts when quoting a mechanical seal kit.

* Parts contained in H60A156 or H60A137 Double Balanced Mechanical Seal Kits

** **PARTS ORDERING NOTE:** Each time the balance sleeves are replaced, new Balance Sleeve O-Rings are recommended.

PARTS ORDERING NOTE: Each time the impeller bolt is removed (required for seal replacement), Smith & Loveless recommends installation of a new impeller bolt that has the embedded Nylock.

PARTS ORDERING NOTE: Each time a new seal, ceramic, carbon or spring is installed, a volute gasket, seal housing gasket or quad ring, and impeller bolt are recommended.

*** **PARTS TIP:** Seal Housing – Flat Gasket vs. Quad Ring: The older seal housing has a flat surface and uses the flat gasket for both the single and double mechanical seals. The newer seal housing has a groove and it can use either the flat gasket or the quad ring.

**** **NOTE:** Series 4 Pump C&D Shaft WWMPS-See Factory. High Head Seals on Second Stage Pumps may be required For Over 200'TDH. Add Pump 1 & Pump 2 TDH together to determine if more than 200'TDH. See Factory.

ENGINEERING DATA



Smith &
Loveless, Inc.®

14040 Santa Fe Trail
Lenexa, KS 66215-1234, USA

After Market
Parts Price Book
Section 4
Rectangular Recessed
WWMPs Parts
Page 31

MECHANICAL, PIPING, & PARTS (CONTINUED)

PUMP IMPELLERS & PUMP X-PELLERS® - VACUUM PRIMED

PUMP MODEL	MOTOR RPM	IMPELLER CW PART #	IMPELLER CCW PART #	ADDITIONAL PARTS 1 SET PER IMPELLER PART#
4B2B*1	-	60D21	60D42	60A12, 60A20, 60A26
TURBO 4B2C	-	87D103	87D104	60A12, 60A20, 60A26
4B2D	-	60C76	60C75	60A12, 60A20, 60A26
4B2X*1	-	60B252A	60B252B	60A12, 60A20, 60A26
4B2X*1	-	60B252A	60B252B	60A12, 60A20, 60A26
4B2X*1	-	60B252A	60B252B	60A12, 60A20, 60A26
4B3B	-	60D43	60D1	60A12, 60A20, 60A28
4C2B	-	60D63	60D64	60A12, 60A20, 60A26
4C2D	-	60C77	60C78	60A12, 60A20, 60A26
4C2X	1800	60B252C	60B252D	60A12, 60A20, 60A26
4C3B	-	60B44	60B23	60A12, 60A20, 60A28
4D3B	-	60D129	60D193	60A87, 60A86, 60A28
4D4B	-	60D259	60D258	60A87, 60A86, 60A106B
6B3B (& SERIES)	-	60D45	60D34	60A12, 60A20, 60A28
6B3X	-	60B204	60B209	60A12, 60A20, 60A28
6C3B (& SERIES)	-	60D47	60D46	60A12, 60A20, 60A28
6C3X	-	60B217	60B2118	60A12, 60A20, 60A28
6D3B (& SERIES)	-	60D90	60D192	60A87, 60A86, 60A28
6D3X	-	60B219	60B220	60A87, 60A86, 60A28
8C4D	-	60D178	60D179	60A12, 60A20, 60A106B
8D4D	-	60D150	60D151	60A87, 60A86, 60A106B

GASKETS, VOLUTE PUMP SIZE	STANDARD GASKET PART #	OTHER VOLUTE GASKETS PART # 1/16" THICKNESS
4B2B*1, 4B2C, 4B2D, 4C2B, 4C2D, 4B2X*1, 4C2X	60A26 (1/32")	60A27 (1/16")
4B3B, 4C3B, 4D3B, 6B3B, 6C3B, 6D3B	60A28 (1/32")	60A29 (1/16")

PARTS ORDERING NOTE: New volute gasket is required each time the rotating assembly (motor, impeller, mechanical seals, &/or volute) is disassembled.

ENGINEERING DATA



Smith &
Loveless, Inc.®

14040 Santa Fe Trail
Lenexa, KS 66215-1234, USA

After Market
Parts Price Book
Section 4
Rectangular Recessed
WWMPs Parts
Page 32

OTHER PARTS

ALARMS

PART DESCRIPTION	PART #
Horn, 120 VAC, 60 cycle	4L73A
Horn, 12 VDC.	4L73B
Horn, Weatherproof Box	4L73D
RED ALARM LIGHT ASSEMBLY:	
Light, Red 12 VDC	28B580A
Lamp, 12 VDC, 50 W for 28B580A Light	4L120
Light, Red 120 VAC	28B580B
Lamp, 120 VAC, 50 W for 28B580B Light	4L95A
Light Fixture Body	5L76*
Light Fixture Adapter	5L77*
Red Globe for 5L77	5L78B*
Globe Guard for 5L77	5L79 *
Trickle Charger (CURRENT) Can be used in place of 4L222	4L222C**
Trickle Charger (OLD STYLE)	4L222

* **PARTS ORDERING NOTE:** Must identify as either Appleton or Killark

***Consult the factory.*

BLOWER - VENTILATION

PART DESCRIPTION	PART #
Blower – 265 CFM	7L195
Electrical Cord – 15' - Coiled	4L379B
Cord Connector	5L15A
Air Discharge Seal (seals blower to hood)	87A86
Blower & Cord Assembly (includes blower, cord connector and 15' coiled cord)	87A414B
Air Discharge Seal (seals blower to hood)	87A86
Louver, Adjustable 6 x 6	11L138A
Seal for Louver (Placed between louver & fiberglass)	87A86

FORM-A-GASKET

PART DESCRIPTION	PART #
Form-A-Gasket, 1.5 oz.	12L90A

ENGINEERING DATA



Smith &
Loveless, Inc.®

14040 Santa Fe Trail
Lenexa, KS 66215-1234, USA

After Market
Parts Price Book
Section 4
Rectangular Recessed
WWMPs Parts
Page 33

OTHER PARTS (CONTINUED)

GASKETS	
PART DESCRIPTION	PART #
4" Flange Gasket (check valves & suction/discharge piping)	11L1A
6" Flange Gasket (check valves & suction/discharge piping)	11L1C
Volute/Base Gasket	60A108
Seal Housing Gasket - Quad Ring *	B Shaft: 60A110
	C Shaft: 60A111
	D Shaft: 60A146
Hood Gasket, 64" X 156"	10L122AD
Hood Gasket, 72" X 172"	10L122AD
Baseplate Gasket, 64" X 59"	10L122AB
Baseplate Gasket, 72" X 67"	10L122AB

* **PARTS TIP:** Seal Housing Gasket - Flat vs. Quad Ring. The seal housing has a groove and can use either gasket

* **3-1/2" diameter dial (Customer must verify fit. If smaller dial is needed, contact factory)**
PARTS ORDERING TIP: If no gauge is currently in use, order 1L780C. Otherwise, determine correct PSI

HMI MESSAGE PANEL SCREENS – Requires Engineering Programming

PART DESCRIPTION	PART #
HMI-140 Message Panel – 4 Line Display, 8 Programmable Keys – 4L523D	Retrofit Product
HMI-240 Message Panel – 4 Line Display, 20 Programmable Keys – 4L523B	OBSOLETE
HMI-750 Message Panel – Graphic Color Touch Screen – 4L523C-*	OBSOLETE

*Replaced by the 4L523H

ENGINEERING DATA



Smith &
Loveless, Inc.®

14040 Santa Fe Trail
Lenexa, KS 66215-1234, USA

After Market
Parts Price Book
Section 4
Rectangular Recessed
WWMPS Parts
Page 34

OTHER PARTS (CONTINUED)

HMI MESSAGE PANEL SCREENS – Graphic Color Touch Screen

PART DESCRIPTION	PART #
HMI-8046 Message Panel – Graphic Color Touch Screen – 4L523H The 4L523H replaces the 4L523 B,C,D,E,F,& G. Requires a new cable when replacing with a previous model. 4L523H-1 for PROTRONIX™ I , 4L536C-7 for PROTRONIX® II Controller)	Retrofit Product
Connection Cable-Connect the HMI to PROTRONIX® I -	4L523-1
Connection Cable-Connect the HMI to PROTRONIX® I -	4L536C-7

HOODS

PART DESCRIPTION	NON-GASKET SIDE PART #	GASKET SIDE PART #
Fiberglass Hood 64" X 64" Non-Insulated *	87B186A	87B186B
Fiberglass Hood 64" X 64" Insulated *	87B295A	87B295B
Fiberglass Hood 72" X 72" Non-Insulated *	87B187A	87B187B
Fiberglass Hood 72" X 72" Insulated *	87B296A	87B296B
Hood, Pocket Pull Handle – 2 per hood side, 4 per station - Black		12L216A
Hood, Stainless Steel Lockable Draw Latch		12L233A
Hood Gasket, 64" X 156"		10L122AD
Hood Gasket, 72" X 172"		10L122AD
Louver, Adjustable 6" x 6"		11L138A

* **NOTE: Hardware is not included with the hood - must be requested separately.**

HOODS - MISCELLANEOUS PARTS

PART DESCRIPTION	PART #
Hood Roller Assembly (8 needed per hood)	87A301
S.S. External Retaining Ring	NPN
Roller – 1-1/2" diameter	87A258
Roller Stud	87B259
Roller Washer	87A359
Hood Roller Track – 62" (for 64" X 64" hood)	87B251A
Hood Roller Track – 70" (for 72" X 72" hood)	87B251B
Removable Track Stop – 4 required per station	87A279
Pocket Pull Hood Handle – 2 required per hood side, 4 per station – black	12L216A
Blower & Cord Assembly (includes blower, cord connector and 15' coiled cord)	87A414B
Air Discharge Seal (seals blower to hood)	87A86
Louver, Adjustable 6" x 6"	11L138A
Hood Gasket, 64" X 156"	10L122AD
Hood Gasket, 72" X 172"	10L122AD
Baseplate Gasket, 64" X 59"	10L122AB
Baseplate Gasket, 72" X 67"	10L122AB

ENGINEERING DATA



Smith &
Loveless, Inc.®

14040 Santa Fe Trail
Lenexa, KS 66215-1234, USA

After Market
Parts Price Book
Section 4
Rectangular Recessed
WWMPs Parts
Page 35

OTHER PARTS (CONTINUED)

HOOD (FIBERGLASS) REPAIR KIT

PART DESCRIPTION	PART #
Fiberglass Hood Repair Kit (1 pt. S&L light green gel coat, 1 pt. Polyester resin, 3 sq. ft. fiberglass mat.)	12L360A

KEYSTOCK (MOTOR SHAFT KEY)

PART DESCRIPTION	PART #
B Shaft	95L39-0
C Shaft	95L39-0
D Shaft	95L39-01

LABELS

PART DESCRIPTION	PART #
Label, Blower	12A107A
Label, Rotation	12A152
Label, Motor No 1	12A2
Label, Motor No 2	12A3
Label, Low Level	12A537
Label, Low Water	12A538
Label, Notice Mechanical	12A74
Label, Notice Blower	12A76
Label, "OSHA" Warning	12L150AF
Label, "OSHA" Caution Lift Warning	12L150N
Label, S&L Logo 8" x 3-1/4"	12L154B
Label, S&L Logo 5" x 2"	12L154C
Label, Motor Lift Warning	12L166
Label, Control Panel Nameplate	12L170
Label, FORMULA X ® Logo	12L217A

LATCHES, FOR LOCKS

PART DESCRIPTION	PART #
Pad Lockable Draw Latch & Striker, S.S. (for hood)	12L233A
Pad Lockable Striker Plate & Latch, S.S. (for wet well access plates)	12L222A

ENGINEERING DATA



Smith &
Loveless, Inc.®

14040 Santa Fe Trail
Lenexa, KS 66215-1234, USA

After Market
Parts Price Book
Section 4
Rectangular Recessed
WWMPs Parts
Page 36

OTHER PARTS (CONTINUED)

LEVEL INDICATION CONNECTION PLATE	
PART DESCRIPTION	PART #
Level Indication Connection Plate Complete Assembly (includes all parts listed below)	H87A397
Float Switch Connection Plate Gasket	87B350
Float Switch Connection Plate	87B348
Pipe Plug (2 required for PROTRONIX ® control panels, 3 required per plate for relay logic control panels)	1L69C
Cord Grip for Floats (3 required for PROTRONIX ® control panels, 2 required per plate for relay logic control panels)	5L57C
Cord Grip for Submersible Pressure Transducer (1 required for PROTRONIX ® control panels, 0 required per plate for relay logic control panels)	5L57N
Washer, Stainless Steel (2 required per plate)	6L65F
Lock Washer, Stainless Steel (2 required per plate)	6L94F
Hex Nut, Stainless Steel (2 required per plate)	6L30K
Label, Plastic – LL ALARM/TRANSDUCER/HL ALARM	12A538
Label, Plastic – LL OFF/LL ON/HL ON	12A537
LIFTING STANCHION	
PART DESCRIPTION	PART #
Lifting Stanchion – Top Section – Hemlock	87B39A2-304
Lifting Stanchion – Bottom Section – Hemlock	87B39B2-304
LINE STRAINER	
PART DESCRIPTION	PART #
Vapor Filter 12-Pack Replacement Part Kit Do not use with SONIC START ® STREAMLINE ™	H87A321A
LOUVER, VENT	
PART DESCRIPTION	PART #
Louver, Adjustable – 6" x 6"	11L138A
Seal for Louver (Placed between louver & fiberglass)	87A86

ENGINEERING DATA



Smith &
Loveless, Inc.®

14040 Santa Fe Trail
Lenexa, KS 66215-1234, USA

After Market
Parts Price Book
Section 4
Rectangular Recessed
WWMPs Parts
Page 37

OTHER PARTS (CONTINUED)

PAINT (VERSAPOX®) & TOUCH-UP KITS

PART DESCRIPTION	PART #
Touch-Up Paint Kit – Georgian Hemlock	H87A425
Primer (RED), Part A, Gallon	12L138A *
Primer Catalyst, Part B, Gallon	12L138B

* Order one gallon of Catalyst Part B for each gallon of paint/primer – must be mixed before use.

SHADE AIDE™ (HMI SCREEN SUN BLOCKER)

PART DESCRIPTION	PART #
SHADE AIDE™ Kit, Small (covers HMI Screen 9.5" W x 7" H)	H87A379
SHADE AIDE™ Kit, Small Stainless Steel (covers HMI Screen 9.5" W x 7" H)	H87A379B
SHADE AIDE™ Kit, Large (covers HMI Screen 15" W x 11" H x 2.25" D)	H87A485
SHADE AIDE™ Kit, Large Stainless Steel (covers HMI Screen 15" W x 11" H x 2.25" D)	H87A485A
SHADE AIDE™ Kit, Extra Large (covers HMI Screen 19.875" W x 14" H)	H87A503A
SHADE AIDE™ Kit, Extra Large Stainless Steel (covers HMI Screen 19.875" W x 14" H)	H87A503B

SLINGER RINGS (FOR MOTORS)

PART DESCRIPTION	PART #
B Shaft	95L39-B*
C Shaft	95L39-C*
D Shaft	95L39-D*

VENT LOUVER

PART DESCRIPTION	PART #
Vent Louver, Adjustable – 6" x 6"	11L138A

VIDEOS - TRAINING

PART DESCRIPTION	PART #
How To Replace the Single Mechanical Seal – DVD Format	12L318DVD-1
How To Replace the Single Mechanical Seal – VHS Format	12L318VHS-1

*PARTS ORDERING NOTE: Part # extension varied based on manufacturer. Motor manufacturer needs to be identified prior to sale.

ENGINEERING DATA



Smith &
Loveless, Inc.®

14040 Santa Fe Trail
Lenexa, KS 66215-1234, USA

After Market
Parts Price Book
Section 4
Rectangular Recessed
WWMPS Parts
Page 38

OTHER PARTS (CONTINUED)

4' WET WELL MANWAY ACCESS LIDS (ALUMINUM)	
PART DESCRIPTION	PART #
4' Wet Well Manway Access Lid Half With Slot (aluminum)	87B184A
4' Wet Well Manway Access Lid Half Without Slot (aluminum)	87B184B
4' Wet Well S.S. Continuous Hinge (2 Required)	87B272B
Gasket (installs where two access lids mate up) U-Shaped Neoprene <i>4' required for 4' wet well</i>	10L122AC
Neoprene Gasket (4' Wet Well Hinge) for Under Continuous Hinge (2 required)	87B182-2A
Center Support Angle	87B250C
Button Socket Headscrew (18 required)	6L221CD
SS Lock Washer (18 required)	6L94G
SS Hex Nut (18 required)	6L30A

5' & 6' WET WELL MANWAY ACCESS LIDS (ALUMINUM)	
PART DESCRIPTION	PART #
5' & 6' Wet Well Manway Access Lid Half With Slot (aluminum)	87B184C
5' & 6' Wet Well Manway Access Lid Half Without Slot (aluminum)	87B184D
5' & 6' Wet Well S.S. Continuous Hinge (2 Required)	87B272D
Gasket (installs where two access lids mate up) U-Shaped Neoprene <i>5' required for 5' & 6' Wet Well</i>	10L122AC
Neoprene Gasket for Under Continuous Hinge (2 required)	87B182-2B
Center Support Angle	87B250C
Button Socket Headscrew (23 required)	6L221CD
SS Lock Washer (23 required)	6L94G
SS Hex Nut (23 required)	6L30A

ENGINEERING DATA



Smith &
Loveless, Inc.®

14040 Santa Fe Trail
Lenexa, KS 66215-1234, USA

After Market
Parts Price Book
Section 4
Rectangular Recessed
WWMPs Parts
Page 39

VACUUM PRIMING SYSTEM

FLOAT CHECK VALVES	
PART DESCRIPTION	PART #
Float Check Valve, 3/8" NPT (Complete Assembly) (Replaces 1L443, 1L443G, and 87A76)	1L443H
Adapter Fitting, 3/8" x 1/4"	1L43D
Body (See drawing - not normally replaced)	
Ball Seat (for 1L443H)	1L443HA
Valve Ball 1 1/2" Diameter	1L443B
O-Ring (for 1L443H)	1L443HB
Bowl Only (for 1L443H) (Also includes O-Ring P/N 1L443B)	1L443HC
Drain Valve	1L333
SONIC START® STREAMLINE™ Float Check Valve Piping Assembly (Connects Float Check Valve to vacuum tubing includes gauge port & shut off valve)	87B739

SOLENOID VALVES	
PART DESCRIPTION	PART #
2-Way Solenoid Valve (5/16" orifice)	1L545A
DIN Connector for 1L545A with 8' cord (OLD P/N: 1L545A-1) (Required for initial installation of 1L545A)	87A481-STK
2-Way Solenoid Valve Assembly for the FORMULA X® (Old Style Arrangement with Solenoid piped next to the Float Check Valve)	87B351
SONIC START® STREAMLINE™ Vacuum Dome /2-Way Solenoid Valve Assembly-Newest Current Arrangement	87B728A

SONIC START® STREAMLINE™ KITS	
PART DESCRIPTION	PART #
SONIC START® STREAMLINE™ Upgrade Kit for One Pump	H87A391J
SONIC START® STREAMLINE™ Upgrade Kit for Two Pumps -Must order 2 kits (Old P/N: H87A391B)	H87A391J
SONIC START® STREAMLINE™ Drill & Tap Kit	H87A390A

SONIC START® STREAMLINE™ PROBE	
PART DESCRIPTION	PART #
SONIC START® STREAMLINE™ - 120 VAC (PROBE)	4L628F
SONIC START® STREAMLINE™ - 24 VDC (PROBE)	4L628G

ENGINEERING DATA



Smith &
Loveless, Inc.®

14040 Santa Fe Trail
Lenexa, KS 66215-1234, USA

After Market
Parts Price Book
Section 4
Rectangular Recessed
WWMPS Parts
Page 40

VACUUM PRIMING SYSTEM (CONTINUED)

SONIC START® STREAMLINE™ REPLACEMENT PARTS

These parts come standard in the SONIC START® STREAMLINE™ Kits

PART DESCRIPTION	PART #
SONIC START® STREAMLINE™ Replacement Sensor Probe – 120 VAC	4L628F
SONIC START® STREAMLINE™ Replacement Sensor Probe – 24 VAC	4L628G
Explosion Proof SONIC START® STREAMLINE™ Prime Sensing Probe	4L628H
SONIC START® Operating Module	4L264S
SONIC START® DIN Connector Cable (Old PN: 1L545A-2)	87A481-STK
SONIC START® 8 Pin Socket	5L49B
SONIC START® Cord Grip	5L57L
SONIC START® Cable Ties	5L150A
SONIC START® Brass Bulkhead Adapter	87A384
SONIC START® O-Ring for Bulkhead Adapter	11L4J
SONIC START® Jam Nut	6L222A
SONIC START® Reducer Coupling	1L552A
SONIC START® Male Tubing Connector	1L460D
SONIC START® O-Ring for Cord Grip	5L57L-2
SONIC START® Nut for Cord Grip	5L57L-1

VACUUM DOME

PART DESCRIPTION	PART #
Vacuum Dome (one hole at top)	87B133B*
Compression Ring (holds dome in place)	87A226
SONIC START® STREAMLINE™ Vacuum Dome /2-Way Solenoid Valve Assembly (Current Style)	87B728

***PARTS ORDERING NOTE:** Small O-Ring (P/N 11L4J) & Quad Ring (11L4D) are recommended (not included with dome)

VACUUM DOME ASSEMBLY

PART DESCRIPTION	PART #
Vacuum Dome Complete Assembly (one hole at top) Used with SONIC START® Probe. Old Style.	87B452A
DO NOT USE WITH SONIC START® STREAMLINE™	
Compression Ring (holds dome in place)	87A226
Ferrule Connection Fitting <i>(Optional replacement for Quick Disconnect Fitting on new style electrodes that are includes with these assemblies.)</i>	1L248A
Ferrule Nut & Sleeve	1L786A
SONIC START® STREAMLINE™ Complete Vacuum Dome Assembly Vacuum Dome/ 2-Way Solenoid Valve Dome Assembly. Current Style	87B728

ENGINEERING DATA



Smith &
Loveless, Inc.®

14040 Santa Fe Trail
Lenexa, KS 66215-1234, USA

After Market
Parts Price Book
Section 4
Rectangular Recessed
WWMPs Parts
Page 41

VACUUM PRIMING SYSTEM (CONTINUED)

VACUUM PUMP - HEAVY DUTY - SINGLE PISTON & SPARE PARTS	
PART DESCRIPTION	PART #
Heavy Duty 1/6 HP (For Pumps with 4" Piping) (<i>Complete pump</i>)	8L29
Repair Kit (K264 or K265)	8L29AB
Inlet Filter	8L29A1
Head Gasket	8L29A4
Valve Outlet	8L29A5
Valve Plate	8L29A6
Inlet Valve	8L29A7
Cylinder Gasket	8L29A8
Piston Ring	8L29A10
Piston Seal	8L29A11
Rider Ring	8L29A12
Fan	8L29A20
Shroud	8L29A21
Motor, 1/6 HP 1725	8L29A22
Vibration Isolator (See Section 6)	87A291

VACUUM PUMP - HEAVY DUTY - DUAL PISTON & SPARE PARTS	
PART DESCRIPTION	PART #
Heavy Duty 1/2 HP (For Pumps with 6" Piping) (<i>Complete pump</i>) (replaces 8L40A*)	8L32*
Repair Kit (K262 or K263)	8L32-1
Head Gasket	8L32-2
Outlet Valve	8L32-3
Inlet Valve	8L32-4
Cylinder Gasket	8L32-5
Felt	8L32-6
Piston Ring	8L32-7
Piston Seal	8L32-8
Rider Ring	8L32-9
Valve Plate	8L32-10
Motor 1/2 HP 1725 RPM	8L32-11**
Shroud	8L32-12
Fan	8L32-13
Cylinder Head	8L32-14
Vibration Isolator (See Section 6)	87A291

* SEE SECTION 6 FOR COMBINED EXHAUST CONFIGURATION

**PURCHASE OF NEW 8L32 REQUIRED

ENGINEERING DATA



Smith &
Loveless, Inc.®

14040 Santa Fe Trail
Lenexa, KS 66215-1234, USA

After Market
Parts Price Book
Section 4
Rectangular Recessed
WWMPS Parts
Page 42

VACUUM PRIMING SYSTEM (CONTINUED)

VACUUM PUMP - COMBINED EXHAUST ASSEMBLY	
PART DESCRIPTION	PART #
Vacuum Pump	8L32
Tee	1L37C
Adapter	1L42B
Elbow	1L90H
Tube/NPT Connector	1L248D
Polyethylene Tubing	1L142CA

VACUUM TUBING		
PART DESCRIPTION	PART #	
Vacuum Tubing - 1/4"	Natural:	1L142AA
	Green:	1L142AB
	Red:	1L142AC
Vacuum Tubing - 3/8"	Natural:	1L142BA
	Green:	1L142BB
	Red:	1L142BC

VACUUM TUBING FITTINGS (for vacuum domes, solenoid valves, & float check valves)	
PART DESCRIPTION	PART #
Ferrule (old style) elbow - 3/8" x 1/4" NPT	1L190B
Ferrule (old style) straight - 3/8" x 1/4" NPT	1L248A
Ferrule Nut & Sleeve	1L786A
Quick Disconnect (new style) elbow - 3/8" x 1/4" NPT	1L546C
Quick Disconnect (new style) straight - 3/8" x 1/4" NPT	1L460D

VAPOR FILTER	
PART DESCRIPTION	PART #
Vapor Filter 12-Pack Replacement Part Kit - Recommend H87A391J SONIC START® STREAMLINE™ Upgrade Kit DO NOT USE H87A321A WITH SONIC START® STREAMLINE™	H87A321A

ENGINEERING DATA



Smith &
Loveless, Inc.®

14040 Santa Fe Trail
Lenexa, KS 66215-1234, USA

After Market
Parts Price Book
Section 4
Rectangular Recessed
WWMPS Parts
Page 43

VALVES

PLUG VALVES

PART DESCRIPTION	PART #
4" Plug Valve	2L104A-304 *
Handle/Wrench Only for 4" Plug Valve (Chilean Red)	2L104AA1
4" Flange Gasket	11L1A
6" 3-Way Tapered Plug Valve	2L148M-304 *
6" Flange Gasket	11L1C
Valve Wrench for Plug Valves – (Chilean Red)	2L104AA1
* PARTS ORDERING NOTE: 2 new Flange Gaskets per Plug Valve will be required.	

SOLENOID VALVES

PART DESCRIPTION	PART #
2-Way Solenoid Valve (5/16" orifice)	1L545A
DIN Connector for 1L545A with 8' cord (OLD P/N: 1L545A-1) (Required for initial installation of 1L545A)	87A481-STK
2-Way Solenoid Valve Assembly for the FORMULA X ®	87B351
SONIC START ® STREAMLINE ™ Vacuum Dome /2-Way Solenoid Valve Assembly	87A728

ENGINEERING DATA



Smith &
Loveless, Inc.®

14040 Santa Fe Trail
Lenexa, KS 66215-1234, USA

After Market
Parts Price Book
Section 4
Rectangular Recessed
WWMPS Parts
Page 44

VALVES (CONTINUED)

WAFER CHECK VALVES, SPRING LOADED

PART DESCRIPTION	PART #
4" Left Hand Wafer Check Valve, Extended Body	2L153S *
4" Right Hand Wafer Check Valve, Extended Body	2L153T *
4" Flange Gasket	11L1A
6" Left Hand Wafer Check Valve	2L153Q-304 *
6" Right Hand Wafer Check Valve	2L153R-304 *
6" Flange Gasket	11L1C

* **PARTS ORDERING NOTE:** 2 new Flange Gaskets per Wafer Valve will be required.

WAFER CHECK VALVES – SPRING LOADED, SPARE PARTS

PART DESCRIPTION	4" PART #	6" PART #
	2L153S(-304) (LH) 2L153T(-304) (RH)	2L153Q(-304) (LH) 2L153R(-304) (RH)
Seat Ring	11L207F	11L207G
Brass Arm *	55A32	55A39
Brass Clapper	55B39	55B29
Shoulder Bolt - Stainless Steel	6L184A	6L184B
Roll Pin - Stainless Steel	2L153A6	2L153C-12
Shaft - Stainless Steel *	55B32	55B37
Bronze Bushing (2 required)	55A34	55A35
O-Ring (2 required)	2L153A9	2L153C9
Steel Bar Arm/Handle	55A36	55A37
Pin - Stainless Steel	2L153D11	2L153A11
Eye Bolt (from body to spring)	6L55N	6L55N
Spring - Stainless Steel	11L104N	11L104M
Pipe Plug	1L69C	1L69D
Eye Bolt (from handle to spring)	6L55M	6L55M
Flange Gasket (2 required per valve)	11L1A	11L1C

* **PARTS ORDERING NOTE:** 2 new Flange Gaskets per Plug Valve will be required.

WRENCH, VALVE

PART DESCRIPTION	PART #
Valve Wrench for Plug Valve - Chilean Red	2L104AA1