


Installation and Assembly: Full Service Video Wall Mount

Model: DS-VW765-LAND





A WARNING

- Do not begin to install your Peerless product until you have read and understood the instructions and warnings
 contained in this Installation Sheet. If you have any questions regarding any of the instructions or warnings, for US
 customers please call Peerless customer care at 1-800-865-2112, for all international customers, please contact
 your local distributor.
- This product should only be installed by someone of good mechanical aptitude, has experience with basic building construction, and fully understands these instructions.
- Make sure that the supporting surface will safely support the combined load of the equipment and all attached hardware and components.
- · Never exceed the Maximum UL Load Capacity. See page one.
- If mounting to wood wall studs, make sure that mounting screws are anchored into the center of the studs. Use of an "edge to edge" stud finder is highly recommended.
- · Always use an assistant or mechanical lifting equipment to safely lift and position equipment.
- Tighten screws firmly, but do not overtighten. Overtightening can damage the items, greatly reducing their holding power.
- This product is intended for indoor use only. Use of this product outdoors could lead to product failure and personal injury.
- This product was designed to be installed on the following wall construction only;

WALL CONSTRUCTION HARDWARE REQUIRED

Wood Stud
 Wood Beam
 Solid Concrete
 Cinder Block

Included
Included

Tools Needed for Assembly

- stud finder ("edge to edge" stud finder is recommended)
- · phillips screwdriver
- drill
- 5/16" (8 mm) bit for concrete and cinder block wall
- 5/32" (4 mm) bit for wood stud wall
- level

Accessories


- DS-ACC765 Cable Release Kit
- DS-VWS0## Wall Plate Spacer Kit

Table of Contents

Horizontal and Vertical Video Wall Mount Assembly Formula	3
Parts List	
nstallation to Wood Stud Wall	
nstallation to Solid Concrete or Cinder Block	
nstalling Tilt Brackets	7
Display Adjustment	8 and 9
Mounting and Removing Flat Panel Display	10 and 11

Vertical Spacing Location


If DS-VWS0## Wall Plate Spacer Kit is not available use diagram below to determine vertical spacing. To determine lower mounting slot position of second mount, add display height to **(Y1)** or **(Y2)**



X - 10.00 + (.750 OR 1.580) = (Y1 OR Y2)

Horizontal Spacing Location


If DS-VWS0## Wall Plate Spacer Kit is not available use diagram below to determine horizontal spacing. To determine edge of second mount, add (**Z**) to edge or first mount.




Horizontal Location

DISPLAY WIDTH - (35) = Z (SPACING BETWEEN MOUNTS)

	Parts List		
	Description	Qty.	Part #
Α	pull-out mount assembly	1	145-T1665
В	adapter bracket	2	145-T1669
С	mesh sleeve (not shown)	1	600-1014
D	M5 x 10 mm socket pin type-F screw	2	520-1164
Ε	#14 x 2.5" hex head wood screw	4	5S1-015-C03
F	concrete anchor	4	590-0320
G	fender washer	4	540-1008
Н	nylon shoulder washer	4	590-2233
ı	M6 x 12 mm socket pin screw	4	520-1050
J	M8 x 15 mm socket pin screw	4	520-1068
K	4 mm allen wrench	1	560-9646
L	cable tie (not shown)	2	560-9711






AWARNING

- Installer must verify that the supporting surface will safely support the combined load of the equipment and all attached hardware and components.
- Tighten wood screws so that wall plate is firmly attached, but do not overtighten. Overtightening can damage the screws, greatly reducing their holding power.
- Never tighten in excess of 80 in. lb (9 N.M.).
- Make sure that mounting screws are anchored into the center of the stud. The use of an "edge to edge" stud finder is highly recommended.
- Hardware provided is for attachment of mount through standard thickness drywall or plaster into wood studs. Installers are responsible to provide hardware for other types of mounting situations (not evaluated by UL).
- When installing Peerless wall mounts on a wood stud wall covered with gypsum board (drywall), verify that the woods studs are a minimum of 2"x4" nominal size. When installing to more than one stud, insure the spacing between studs is at least 16" but does not exceed 24". Do not install over gypsum board thicker than 5/8".




Use a stud finder to locate the edges of the stud. Use of an edge-to-edge stud finder is highly recommended. Based on their edges, draw a vertical line down the stud center. Place pull-out mount assembly ($\bf A$) on wall as a template. Level plate, and mark the center of the four mounting holes. Make sure that the mounting holes are on the stud center line. Drill four 5/32" (4 mm) dia. holes 2-1/2" (65 mm) deep. Make sure that the pull-out mount assembly ($\bf A$) is level, secure it using four #14 x 2.5" wood screws ($\bf E$) and fender washers ($\bf G$) as shown below.



Installation to Solid Concrete or Cinder Block


A WARNING

- When installing Peerless wall mounts on a concrete wall, the wall must be at least 8" thick with a minimum compressive strength of 2000 psi.
- When installing Peerless wall mounts on a cinder block wall, the cinder blocks must meet ASTM C-90 specifications
 and have a minimum nominal width of 8". Do not drill into mortar joints! Be sure to mount in a solid part of the block,
 generally 1" (25 mm) minimum from the side of the block. It is suggested that a standard electric drill on slow setting
 is used to drill the hole instead of a hammer drill to avoid breaking out the back of the hole when entering a void or
 cavity.
- Make sure that the wall will safely support four times the combined load of the equipment and all attached hardware and components.
- NOTE: Make sure that there is a minimum of 16" horizontal distance between #14 x 2.5" screws (E). Make sure that pull-out mount assembly (A) is level, use it as a template to mark four mounting holes. Drill four 5/16" (8 mm) dia. holes to a minimum depth of 2.5" (64 mm). Insert anchors (F) in holes flush with wall as shown (right). Place pull-out mount assembly (A) over anchors and secure with four #14 x 2.5" screws (E), and fender washers (G). Level, then tighten all fasteners.



AWARNING


- Tighten screws so that wall plate is firmly attached, but do not <u>overtighten</u>. Overtightening can damage screws, greatly reducing their holding power.
- Never tighten in excess of 80 in. lb (9 N.M.).
- Always attach concrete expansion anchors <u>directly</u> to load-bearing concrete.
- Never attach concrete expansion anchors to concrete covered with plaster, drywall, or other finishing material.



Attaching Adapter Brackets to Display

NOTE: Make sure to use largest hole pattern on back of display.


Attach adapter brackets (**B**) to back of display using four M6 x 12 mm socket pin screws (**I**) with nylon shoulder washer (**H**), or four M8 x 15 mm socket pin screws (**J**) as shown below.



Attaching Adapter Brackets to Pull-Out Mount Assembly

Attach adapter brackets (**B**) to pull-out mount assembly. Slide adapter brackets (**B**) into position. Loosely fasten in place using security screw as shown in detail 1.

NOTE: Once display is located in desired position (± 2 " from center), tighten security screws using 4mm allen wrench (**K**) to lock in place.








NOTE: Each knob can be adjusted independently for fine tuning adjustments.


Turn knob **CLOCKWISE** to raise side

Turn knob COUNTER-CLOCKWISE to lower side









Adapter Bracket Adjustment

Use legend below to determine position of display.


NOTE: Each knob can be adjusted independently for fine tuning adjustments.



Turn knob **CLOCKWISE** to move corner toward the wall



Turn knob COUNTER-CLOCKWISE to move corner away from the wall




Cable Management

6

Display cables can be routed through top or bottom of pull-out mount assembly (A).

NOTE: Use mesh sleeve (M) and cable ties (L) for cable management.


NOTE: Cable ties and cable management slots on pull-out mount assembly (**A**) can be used to secure display cables.



Open and Close Pull Out Mount Assembly



Open pull-out mount assembly (**A**) by releasing locking tab. Push or pull up on locking tab as shown below. **NOTE:** Extended position is for service access only. The mount must be closed during normal use and operation.




PUSH UP

Open Adapter Brackets

8


Open adapter brackets (**B**) by pulling down on front release strap while pulling bottom of display away from wall. **NOTE:** Once front release strap is pulled, adapter brackets (**B**) kick stand will engage.

NOTE: Extended position is for service access only. The mount must be closed during normal use and operation.



Close Adapter Brackets

Slightly pull display away from wall to release kick stand while pulling down on back release straps on adapter brackets (**B**) as shown below. Support the display until the adapter brackets (**B**) are engaged in the closed position. **NOTE:** Once back release strap is pulled, adapter brackets (**B**) kick stand will disengage.



Pull Out Mount Assembly (Optional) Security



To prevent locking tabs from releasing, secure using two M5 x 10 mm socket pin type-F screws (**D**).

