



CAP1750

Guide d'installation rapide

11-2020/v1.1

Edimax Technology Co., Ltd.

No. 278, Xinhu 1st Rd., Neihu Dist., Taipei City, Taiwan

Email: support@edimax.com.tw

Edimax Technology Europe B.V.

Fijenhoef 2, 5652 AE Eindhoven, The Netherlands

Email: support@edimax.nl

Edimax Computer Company


3444 De La Cruz Blvd., Santa Clara, CA 95054, USA

Live Tech Support: 1(800) 652-6776


Email: support@edimax.com

I. Informations sur le produit


I-1. Contenu de l'emballage




1



2



3




4




5




6



7



8




9

1. Point d'accès CAP1750
2. Support de fixation au plafond
3. Kit de fixation Rail en T et vis
4. Kit de fixation pour plafond et vis
5. CD
6. Guide d'installation rapide
7. Câble Ethernet
8. Adaptateur secteur
9. Gabarit de vis pour fixation murale

I-2. Pré-requis système

- Modem et routeur câble/DSL existants
- Ordinateur avec navigateur Internet pour la configuration du point d'accès

I-3. Aperçu du matériel



I-4. État des voyants

Couleur du voyant	État du voyant	Descriptif
Bleu	Allumé	Le point d'accès est allumé.
	Clignotement long	Mise à niveau du microprogramme.
	Clignotement court	Restauration des paramètres usine par défaut
Orange	Allumé	Démarrage.
	Clignotant	Erreur
Éteint	Éteint	Le point d'accès est éteint.

I-5. Réinitialiser




Ce dispositif nécessite une installation professionnelle

Si vous rencontrez des problèmes avec votre point d'accès, vous pouvez réinitialiser les paramètres usine de l'appareil. Cette opération réinitialise **tous** les paramètres aux valeurs par défaut.

1. Maintenez enfoncée la touche de réinitialisation sur le point d'accès pendant au moins 10 secondes.



Vous pourriez avoir besoin d'une épingle ou d'un objet pointu similaire pour appuyer sur le bouton de réinitialisation.




2. Attendez que le point d'accès redémarre. Le point d'accès est prêt pour la configuration lorsque le voyant est **bleu**.

II. Installation rapide

Votre point d'accès peut être prêt à fonctionner en quelques minutes seulement. Il peut fonctionner en tant que point d'accès autonome (Mode PA) ou en tant que partie d'une matrice PA (Mode PA géré ou contrôleur de PA). Ce guide d'installation rapide vous aidera à configurer votre point d'accès et ses paramètres de base.

II-1. Configuration initiale

- 1.** Connectez le point d'accès à un ordinateur à l'aide d'un câble Ethernet.
- 2.** Branchez l'adaptateur secteur au port 12 V CC du point d'accès et branchez l'adaptateur électrique dans une prise de courant à l'aide du câble inclus.



- 3.** Veuillez patienter un instant pour que le point d'accès démarre. Le point d'accès est prêt lorsque le voyant est **bleu**.
- 4.** Configurez l'adresse IP de votre ordinateur sur **192.168.2.x** où **x** est un numéro compris entre **3 et 100**. Si vous ne savez pas comment faire, veuillez consulter le manuel de l'utilisateur pour plus d'informations.




Assurez-vous qu'aucune autre connexion réseau n'est active sur votre PC (déconnectez les connexions Wi-Fi et les câbles Ethernet).

- 5.** Saisissez l'adresse IP par défaut du point d'accès **192.168.2.2** dans la barre d'adresse d'un navigateur Internet.



- 6.** Il vous est demandé de saisir un nom d'utilisateur et un mot de passe.
Saisissez le nom d'utilisateur par défaut "admin" et le mot de passe par défaut "1234".



- 7.** Vous accédez à l'écran « Informations Système » montré ci-dessous.

System	
Model	[REDACTED]
Product Name	AP801F02000000
Uptime	0 day 00:04:15
System Time	2012/01/01 00:04:32
Boot from	Internal memory
Firmware Version	1.3.0
MAC Address	80:1F:02:00:00:00
Management VLAN ID	1
IP Address	192.168.0.108
Default Gateway	192.168.0.1
DNS	192.168.0.1
DHCP Server	192.168.0.1

Wired LAN Port Settings		
Wired LAN Port	Status	VLAN Mode/ID
LAN1	Connected (100 Mbps Full-Duplex)	Untagged Port / 1

- 8.** Merci de suivre les instructions ci-dessous **II-2. Paramètres de base** pour configurer les paramètres de base du point d'accès pour une utilisation en tant que PA autonome en mode PA.

Pour utiliser un PA géré dans un groupe de PA, le point d'accès change automatiquement de mode si un contrôleur de PA est configuré comme décrit au point **III. Edimax Pro NMS**.

Pour utiliser le PA en tant que Contrôleur de PA (maître) dans une matrice PA, consultez la section **III. Edimax Pro NMS**.

II-2. Mode PA : Paramètres de base

Les instructions ci-dessous vous aideront à configurer les paramètres de base suivants du point d'accès :

- **Adresse IP du réseau local**
- **SSID et sécurité 2,4 GHz et 5 GHz**
- **Nom et mot de passe administrateur**
- **Heure et date**



Il vous est recommandé de configurer ces paramètres avant d'utiliser le point d'accès.

1. Pour modifier l'adresse IP du réseau local du point d'accès, allez dans "Paramètres réseau" > "Adresse IP LAN" pour voir apparaître l'écran ci-dessous.

LAN-side IP Address	
IP Address Assignment	DHCP Client ▾
IP Address	192.168.2.2
Subnet Mask	255.255.255.0
Default Gateway	From DHCP ▾
Primary DNS Address	From DHCP ▾ 0.0.0.0
Secondary DNS Address	From DHCP ▾ 0.0.0.0

2. Saisissez les paramètres de l'adresse IP que vous voulez utiliser pour votre point d'accès. Vous pouvez utiliser une adresse IP dynamique (DHCP) ou fixe, selon votre environnement réseau. Cliquez sur "Appliquer" pour enregistrer les modifications et patientez quelques instants que le point d'accès se recharge.



Lorsque vous modifiez l'adresse IP de votre point d'accès, vous devez utiliser la nouvelle adresse IP pour accéder à l'interface de configuration sur navigateur au lieu de l'adresse IP par défaut 192.168.2.2.

- 3.** Pour modifier le SSID des réseaux sans fil 2,4 GHz de votre point d'accès, allez dans « **Paramètres sans fil** » > « **2,4GHz 11bgn** » > « **Général** ». Saisissez le nouvel SSID pour votre réseau sans fil 2,4 GHz dans le champ « **SSID1** » et cliquez sur « **Appliquer** ».



Pour utiliser plusieurs SSID 2,4 GHz, ouvrez le menu déroulant intitulé « Activer nombre SSID » et sélectionner le nombre de SSID dont vous avez besoin. Saisissez ensuite un nouvel SSID dans les champs numérotés correspondants avant de cliquer sur « Appliquer ».

2.4GHz Basic Settings

Wireless	<input checked="" type="radio"/> Enable <input type="radio"/> Disable
Band	11b/g/n
Enable SSID number	1
SSID1	3071F6_G
VLAN ID	1
Auto Channel	<input checked="" type="radio"/> Enable <input type="radio"/> Disable
Auto Channel Range	Ch 1 - 11
Auto Channel Interval	One day <input type="checkbox"/> Change channel even if clients are connected
Channel Bandwidth	Auto
BSS BasicRateSet	1,2,5.5,11 Mbps

- 4.** Pour configurer la sécurité des réseaux sans fil 2,4 GHz de votre point d'accès, allez dans « **Paramètres sans fil** » > « **2,4GHz 11bgn** » > « **Sécurité** ». Sélectionnez une "Méthode d'authentification" et saisissez au choix une "Clé pré-partagée" ou une "Clé de cryptage", puis cliquez sur "Appliquer".



En cas d'utilisation de plusieurs SSID, spécifiez le SSID à configurer en utilisant le menu déroulant "SSID".

2.4GHz Wireless Security Settings

SSID	3071F6_G
Broadcast SSID	Enable
Wireless Client Isolation	Disable
Load Balancing	50 /50
Authentication Method	No Authentication
Additional Authentication	No additional authentication

5. Allez dans "Paramètres sans fil" > "5GHz 11ac 11an" et répétez les étapes **3 et 4** pour le réseau sans fil en 5 GHz du point d'accès.

6. Pour modifier le nom et le mot de passe de l'administrateur de l'interface de configuration sur navigateur, allez dans "**Gestion**" > "**Admin**".

Account to Manage This Device	
Administrator Name	admin
Administrator Password	***** (4-32 Characters)
	***** (Confirm)
<input type="button" value="Apply"/>	

7. Renseignez les champs "Nom Administrateur" et "Mot de passe Administrateur" et cliquez sur "Appliquer".

8. Pour régler l'heure correcte pour votre point d'accès, allez dans « **Gestion** » > « **Date et heure** ».

Date and Time Settings	
Local Time	2012 Year Jan Month 1 Day 0 Hours 00 Minutes 00 Seconds
<input type="button" value="Acquire Current Time from Your PC"/>	
NTP Time Server	
Use NTP	<input checked="" type="checkbox"/> Enable
Server Name	<input type="text"/>
Update Interval	24 hours
Time Zone	
Time Zone	(GMT) Greenwich Mean Time: Dublin, Edinburgh, Lisbon, London

9. Réglez l'heure correcte et le fuseau horaire pour votre point d'accès à l'aide des menus déroulants. Le point d'accès prend également en charge la fonction NTP (Network Time Protocol) et vous pouvez en alternative saisir le nom d'hôte ou l'adresse IP d'un serveur de temps. Cliquez sur « **Appliquer** » lorsque vous avez terminé.




Vous pouvez utiliser le bouton « Obtenir l'heure à partir de votre PC » si vous souhaitez régler le point d'accès à la même heure que celle de votre PC.

- 10.** Les paramètres de base de votre point d'accès sont maintenant configurés. Merci de vous référer à la section **IV. Installation du matériel** pour obtenir des conseils sur la connexion de votre point d'accès à un routeur ou un switch PoE.

III. Edimax Pro NMS

La suite Edimax Pro Network Management Suite (NMS) gère la gestion centrale d'un groupe de points d'accès, autrement connu sous le nom de " PA Array". La suite NMS peut être installée sur un point d'accès et prendre en charge jusqu'à 8 points d'accès Edimax Pro sans qu'aucun autre contrôleur sans fil supplémentaire ne soit nécessaire, ce qui permet de réduire les coûts et de faciliter l'efficacité de la gestion déportée des points d'accès.

Edimax Pro NMS est simple à configurer. Une vue d'ensemble du système est montrée ci-dessous :



Un PA (point d'accès) est désigné comme contrôleur PA (maître) et les autres PA Edimax Pro connectés sont automatiquement désignés en tant que PA gérés (esclaves). En utilisant Edimax Pro NMS vous pouvez surveiller, configurer et gérer tous les PA gérés (jusqu'à 8) depuis un seul contrôleur de PA.




Assurez-vous de disposer de la dernière version de microprogramme pour vos produits Edimax Pro à partir du site Internet de Edimax.


1. Connectez tous vos PA à un switch Ethernet ou PoE qui soit connecté à une passerelle/routeur.




Vous pouvez utiliser votre routeur comme serveur DHCP ou vous pouvez configurer ultérieurement votre contrôleur PA en tant que serveur DHCP.




2. Assurez-vous que tous les PA sont alimentés et vérifiez les voyants.



- 3.** Désignez un PA en tant que contrôleur de PA pour qu'il gère tous les autres PA connectés (jusqu'à 8).



- 4.** Raccordez un ordinateur au contrôleur de PA en utilisant un câble Ethernet.



- 5.** Ouvrez un navigateur Internet et entrez l'adresse IP du contrôleur PA dans le champ adresse. L'adresse IP par défaut est **192.168.2.2**




L'IP adresse de votre ordinateur doit être sur le même sous-réseau que le contrôleur PA. Reportez-vous au manuel d'utilisation pour obtenir plus d'informations.



Si vous modifiez l'adresse IP du contrôleur PA, ou si votre passerelle/routeur utilise un serveur DHCP, assurez-vous de saisir la bonne adresse IP. Consultez les paramètres de votre passerelle/routeur.


- 6.** Entrez le nom d'utilisateur et le mot de passe pour vous connecter. Le nom d'utilisateur et le mot de passe par défaut sont **admin** et **1234**.
- 7.** Vous accédez alors au tableau de bord Edimax Pro NMS. Allez dans "**Mode de fonctionnement**" et sélectionnez "**Mode Contrôleur de PA**" dans le menu déroulant.



8. Cliquez sur “Appliquer” pour sauvegarder les paramètres.



9. La suite NMS de Edimax Pro contient un assistant permettant de rapidement configurer le SSID et la sécurité des PA gérés. Cliquez sur "Assistant" dans le coin supérieur droit pour commencer.



10. Suivez les instructions pour compléter les **étapes 1 à 6** et cliquez sur "Terminer" pour sauvegarder les paramètres. L'assistant vous aide à configurer l'adresse IP LAN, le SSID et la sécurité en 2,4 et 5 GHz, le nom de l'administrateur et son mot de passe, l'heure et la date et les PA gérés.

1

Before start, please power on the managed APs and plug into the same Ethernet network with this AP Controller.

This Setup Wizard will guide you through a basic procedure to configure AP Controller system.

2

IP Address

IP Address Assignment	Static IP Address
IP Address	192.168.8.37
Subnet Mask	255.255.255.0
Default Gateway	192.168.8.1
Primary DNS Address	8.8.8.8
Secondary DNS Address	168.95.1.1

3

Date Settings

Local Time: 2015 Year: Nov Month: 5 Day: 14 Hours: 26 Minutes: 14 Seconds: 14

Acquire Current Time from Your PC

4

Manage This Device

Administrator Name: admin
Administrator Password: **** (4-32 Characters)
Administrator Password (Confirm): ****

5

Managed AP(s)

Search: (x) Match whole words

MAC Address	Device Name	Model	IP Address	Status
74:D4:38:3E:79:10	AP74DA383E7910	CAP1200	192.168.8.102	Online
74:D4:38:3E:78:C0	AP74DA383E78C0	CAP1200	192.168.8.100	Online
74:D4:38:40:E0:E4		CAP1200		Online
74:D4:38:30:71:08		CAP300		Online
74:D4:38:3E:7B:E6		CAP1200		Online
74:D4:38:06:E1:AA		WAP1750		Online
80:1F:02:F1:95:D2		WAP1200		Online

6

2.4GHz Settings

SSID: Edimax 2.4GHz
Security Key: 12345678

Guest Network: Enable Disable

Guest SSID: Guest 2.4GHz
Security Key: 12345678

5GHz Settings

Clone 2.4GHz Settings

SSID: Edimax 5GHz
Security Key: 12345678

Guest Network: Enable Disable

Guest SSID: Guest 5GHz
Security Key: 12345678



**Si l'un de vos PA gérés n'est pas trouvé au cours de l' étape 5
Sélection PA libres, réinitialisez le PA géré avec ses paramètres
usine par défaut. Consultez le manuel d'utilisation du point
d'accès pour obtenir de l'aide.**

- 11.** Votre contrôleur de PA et vos PA gérés doivent maintenant être opérationnels. Utilisez le menu supérieur pour parcourir les paramètres de la suite NMS Edimax Pro.

Utilisez **Tableau de bord**, **Plan de Zone**, **Surveillance NMS** et **Paramètres NMS** pour configurer les PA gérés.


Utilisez **Réseau local & Paramètres locaux** pour configurer votre contrôleur de PA.



Reportez-vous au manuel d'utilisation pour obtenir plus d'informations.

IV. Installation Matérielle


1. Raccordez un routeur ou un switch PoE au port **LAN** du point d'accès à l'aide d'un câble Ethernet.



2. Si vous utilisez un routeur, branchez l'adaptateur secteur au port 12 V cc du point d'accès et branchez l'adaptateur secteur dans une prise de courant.
3. Si vous utilisez un switch PoE (Power over Ethernet), il n'est pas nécessaire d'utiliser l'adaptateur secteur fourni, car le point d'accès sera alimenté par le switch PoE.



N'utilisez pas l'adaptateur secteur si vous utilisez un switch PoE.



COPYRIGHT

Copyright © Edimax Technology Co., Ltd. all rights reserved. No part of this publication may be reproduced, transmitted, transcribed, stored in a retrieval system, or translated into any language or computer language, in any form or by any means, electronic, mechanical, magnetic, optical, chemical, manual or otherwise, without the prior written permission from Edimax Technology Co., Ltd.

Edimax Technology Co., Ltd. makes no representations or warranties, either expressed or implied, with respect to the contents hereof and specifically disclaims any warranties, merchantability, or fitness for any particular purpose. Any software described in this manual is sold or licensed as is. Should the programs prove defective following their purchase, the buyer (and not this company, its distributor, or its dealer) assumes the entire cost of all necessary servicing, repair, and any incidental or consequential damages resulting from any defect in the software. Edimax Technology Co., Ltd. reserves the right to revise this publication and to make changes from time to time in the contents hereof without the obligation to notify any person of such revision or changes.

The product you have purchased and the setup screen may appear slightly different from those shown in this QIG. The software and specifications are subject to change without notice. Please visit our website www.edimax.com for updates. All brand and product names mentioned in this manual are trademarks and/or registered trademarks of their respective holders.

	AT	BE	BG	HR	CY	CZ	DK
	EE	FI	FR	DE	EL	HU	IE
	IT	LV	LT	LU	MT	NL	PL
	PT	RO	SK	SI	ES	SE	UK

The device is restricted to indoor use only when
operating in the 5150 to 5350 MHz frequency range.

Federal Communication Commission Interference Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

1. Reorient or relocate the receiving antenna.
2. Increase the separation between the equipment and receiver.
3. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
4. Consult the dealer or an experienced radio technician for help.

FCC Caution

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

For product available in the USA/Canada market, only channel 1~11 can be operated. Selection of other channels is not possible.

This device is restricted to indoor use.

Federal Radiation Exposure Statement

1. This Transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.
2. This equipment complies with FCC RF radiation exposure limits set forth for an uncontrolled environment.
This equipment should be installed and operated with a minimum distance of 20 centimeters between the radiator and your body or nearby persons.

This device is restricted to indoor use.

RED Compliance Statement

Compliance with 2014/53/EU Radio Equipment Directive (RED)

In accordance with Article 10.8(a) and 10.8(b) of the RED, the following table provides information on the frequency bands used and the maximum RF transmit power of the product for sale in the EU:

Frequency range (MHz)	Max. transmit power (dBm)
2400-2483.5	19.93 dBm
5150-5250	22.88 dBm

A simplified DoC shall be provided as follows: Article 10(9)

Hereby, Edimax Technology Co., Ltd. declares that the radio equipment type **AC1750 Ceiling Mount AP** is in compliance with Directive 2014/53/EU

The full text of the EU declaration of conformity is available at the following internet address: <http://www.edimax.com/edimax/global/>

Safety

This equipment is designed with the utmost care for the safety of those who install and use it. However, special attention must be paid to the dangers of electric shock and static electricity when working with electrical equipment. All guidelines of this and of the computer manufacturer must therefore be followed at all times to ensure the safe use of the equipment.

EU Countries Intended for Use


The ETSI version of this device is intended for home and office use in Austria, Belgium, Bulgaria, Cyprus, Czech, Denmark, Estonia, Finland, France, Germany, Greece, Hungary, Ireland, Italy, Latvia, Lithuania, Luxembourg, Malta, Netherlands, Poland, Portugal, Romania, Slovakia, Slovenia, Spain, Sweden, Turkey, and United Kingdom. The ETSI version of this device is also authorized for use in EFTA member states: Iceland, Liechtenstein, Norway, and Switzerland.

EU Countries Not Intended for Use

None

EU Declaration of Conformity

- English:** This equipment is in compliance with the essential requirements and other relevant provisions of Directive 2014/53/EU, 2014/35/EU.
- Français:** Cet équipement est conforme aux exigences essentielles et autres dispositions de la directive 2014/53/EU, 2014/35/EU.
- Čeština:** Toto zařízení je v souladu se základními požadavky a ostatními příslušnými ustanoveními směrnic 2014/53/EU, 2014/35/EU.
- Polski:** Urządzenie jest zgodne z ogólnymi wymaganiami oraz szczególnymi warunkami określonymi Dyrektywą UE 2014/53/EU, 2014/35/EU.
- Română:** Acest echipament este în conformitate cu cerințele esențiale și alte prevederi relevante ale Directivei 2014/53/UE, 2014/35/UE.
- Русский:** Это оборудование соответствует основным требованиям и положениям Директивы 2014/53/EU, 2014/35/EU.
- Magyar:** Ez a berendezés megfelel az alapvető követelményeknek és más vonatkozó irányelveknek (2014/53/EU, 2014/35/EU).
- Türkçe:** Bu cihaz 2014/53/EU, 2014/35/EU direktifleri zorunlu istekler ve diğer hükümlerle ile uyumludur.
- Українська:** Обладнання відповідає вимогам і умовам директиви 2014/53/EU, 2014/35/EU.
- Slovenčina:** Toto zariadenie spĺňa základné požiadavky a ďalšie príslušné ustanovenia smerníc 2014/53/EU, 2014/35/EU.
- Deutsch:** Dieses Gerät erfüllt die Voraussetzungen gemäß den Richtlinien 2014/53/EU, 2014/35/EU.
- Español:** El presente equipo cumple los requisitos esenciales de la Directiva 2014/53/EU, 2014/35/EU.
- Italiano:** Questo apparecchio è conforme ai requisiti essenziali e alle altre disposizioni applicabili della Direttiva 2014/53/EU, 2014/35/UE.
- Nederlands:** Dit apparaat voldoet aan de essentiële eisen en andere van toepassing zijnde bepalingen van richtlijn 2014/53/EU, 2014/35/EU.
- Português:** Este equipamento cumpre os requisitos essenciais da Directiva 2014/53/EU, 2014/35/EU.
- Norsk:** Dette utstyret er i samsvar med de viktigste kravene og andre relevante regler i Direktiv 2014/53/EU, 2014/35/EU.
- Svenska:** Denna utrustning är i överensstämmelse med de väsentliga kraven och övriga relevanta bestämmelser i direktiv 2014/53/EU, 2014/35/EU.
- Dansk:** Dette udstyr er i overensstemmelse med de væsentligste krav og andre relevante forordninger i direktiv 2014/53/EU, 2014/35/EU.
- suomen kieli:** Tämä laite täyttää direktiivien 2014/53/EU, 2014/35/EU. oleelliset vaatimukset ja muut asiaankuuluvat määäräykset.

FOR USE IN 



WEEE Directive & Product Disposal



At the end of its serviceable life, this product should not be treated as household or general waste. It should be handed over to the applicable collection point for the recycling of electrical and electronic equipment, or returned to the supplier for disposal.

Declaration of Conformity

We, Edimax Technology Co., Ltd., declare under our sole responsibility, that the equipment described below complies with the requirements of the European Radio Equipment Directive.

Equipment: AC1750 Ceiling Mount AP

Model No.: CAP1750

The following European standards for essential requirements have been followed:

Directives 2014/53/EU

Spectrum	: EN 300 328 V2.1.1 (2016-11) EN 301 893 V2.1.1 (2017-05)
EMC	: Draft EN 301 489-1 V2.2.0 (2017-03) Draft EN 301 489-17 V3.2.0 (2017-03)
EMF	: EN 62311:2008
Safety (LVD)	: IEC 62368-1:2014 (2 nd Edition) and/or EN 62368-1:2014+A11:2017

Edimax Technology Europe B.V.
Fijenhof 2,
5652 AE Eindhoven,
The Netherlands

Printed Name: David Huang
Title: Director
Edimax Technology Europe B.V.

a company of:
Edimax Technology Co., Ltd.
No. 278, Xinhua 1st Rd.,
Neihu Dist., Taipei City,
Taiwan



Date of Signature: Nov., 2020

Signature:

Printed Name:
Title:

Albert Chang
Director
Edimax Technology Co., Ltd.

Notice According to GNU General Public License Version 2

This product includes software that is subject to the GNU General Public License version 2. The program is free software and distributed without any warranty of the author. We offer, valid for at least three years, to give you, for a charge no more than the costs of physically performing source distribution, a complete machine-readable copy of the corresponding source code.

Das Produkt beinhaltet Software, die den Bedingungen der GNU/GPL-Version 2 unterliegt. Das Programm ist eine sog. „Free Software“, der Autor stellt das Programm ohne irgendeine Gewährleistungen zur Verfügung. Wir bieten Ihnen für einen Zeitraum von drei Jahren an, eine vollständige maschinenlesbare Kopie des Quelltextes der Programme zur Verfügung zu stellen – zu nicht höheren Kosten als denen, die durch den physikalischen Kopievorgang anfallen.

GNU GENERAL PUBLIC LICENSE

Version 2, June 1991

Copyright (C) 1989, 1991 Free Software Foundation, Inc. 51 Franklin Street, Fifth Floor, Boston, MA 02110-1301, USA
Everyone is permitted to copy and distribute verbatim copies of this license document, but changing it is not allowed.

Preamble

The licenses for most software are designed to take away your freedom to share and change it. By contrast, the GNU General Public License is intended to guarantee your freedom to share and change free software--to make sure the software is free for all its users. This General Public License applies to most of the Free Software Foundation's software and to any other program whose authors commit to using it. (Some other Free Software Foundation software is covered by the GNU Lesser General Public License instead.) You can apply it to your programs, too.

When we speak of free software, we are referring to freedom, not price. Our General Public Licenses are designed to make sure that you have the freedom to distribute copies of free software (and charge for this service if you wish), that you receive source code or can get it if you want it, that you can change the software or use pieces of it in new free programs; and that you know you can do these things.

To protect your rights, we need to make restrictions that forbid anyone to deny you these rights or to ask you to surrender the rights. These restrictions translate to certain responsibilities for you if you distribute copies of the software, or if you modify it.

For example, if you distribute copies of such a program, whether gratis or for a fee, you must give the recipients all the rights that you have. You must make sure that they, too, receive or can get the source code. And you must show them these terms so they know their rights.

We protect your rights with two steps: (1) copyright the software, and (2) offer you this license which gives you legal permission to copy, distribute and/or modify the software.

Also, for each author's protection and ours, we want to make certain that everyone understands that there is no warranty for this free software. If the software is modified by someone else and passed on, we want its recipients to know that what they have is not the original, so that any problems introduced by others will not reflect on the original authors' reputations.

Finally, any free program is threatened constantly by software patents. We wish to avoid the danger that redistributors of a free program will individually obtain patent licenses, in effect making the program proprietary. To prevent this, we have made it clear that any patent must be licensed for everyone's free use or not licensed at all.

The precise terms and conditions for copying, distribution and modification follow.

TERMS AND CONDITIONS FOR COPYING, DISTRIBUTION AND MODIFICATION

0. This License applies to any program or other work which contains a notice placed by the copyright holder saying it may be distributed under the terms of this General Public License. The “Program”, below, refers to any such program or work, and a “work based on the Program” means either the Program or any derivative work under copyright law: that is to say, a work containing the Program or a portion of it, either verbatim or with modifications and/or translated into another language. (Hereinafter, translation is included without limitation in the term “modification”.) Each licensee is addressed as “you”.

Activities other than copying, distribution and modification are not covered by this License; they are outside its scope. The act of running the Program is not restricted, and the output from the Program is covered only if its contents constitute a work based on the Program (independent of having been made by running the Program). Whether that is true depends on what the Program does.

1. You may copy and distribute verbatim copies of the Program's source code as you receive it, in any medium, provided that you conspicuously and appropriately publish on each copy an appropriate copyright notice and disclaimer of warranty; keep

intact all the notices that refer to this License and to the absence of any warranty; and give any other recipients of the Program a copy of this License along with the Program.

You may charge a fee for the physical act of transferring a copy, and you may at your option offer warranty protection in exchange for a fee.

2. You may modify your copy or copies of the Program or any portion of it, thus forming a work based on the Program, and copy and distribute such modifications or work under the terms of Section 1 above, provided that you also meet all of these conditions:

- a) You must cause the modified files to carry prominent notices stating that you changed the files and the date of any change.
- b) You must cause any work that you distribute or publish, that in whole or in part contains or is derived from the Program or any part thereof, to be licensed as a whole at no charge to all third parties under the terms of this License.
- c) If the modified program normally reads commands interactively when run, you must cause it, when started running for such interactive use in the most ordinary way, to print or display an announcement including an appropriate copyright notice and a notice that there is no warranty (or else, saying that you provide a warranty) and that users may redistribute the program under these conditions, and telling the user how to view a copy of this License. (Exception: if the Program itself is interactive but does not normally print such an announcement, your work based on the Program is not required to print an announcement.)

These requirements apply to the modified work as a whole. If identifiable sections of that work are not derived from the Program, and can be reasonably considered independent and separate works in themselves, then this License, and its terms, do not apply to those sections when you distribute them as separate works. But when you distribute the same sections as part of a whole which is a work based on the Program, the distribution of the whole must be on the terms of this License, whose permissions for other licensees extend to the entire whole, and thus to each and every part regardless of who wrote it.

Thus, it is not the intent of this section to claim rights or contest your rights to work written entirely by you; rather, the intent is to exercise the right to control the distribution of derivative or collective works based on the Program.

In addition, mere aggregation of another work not based on the Program with the Program (or with a work based on the Program) on a volume of a storage or distribution medium does not bring the other work under the scope of this License.

3. You may copy and distribute the Program (or a work based on it, under Section 2) in object code or executable form under the terms of Sections 1 and 2 above provided that you also do one of the following:

- a) Accompany it with the complete corresponding machine-readable source code, which must be distributed under the terms of Sections 1 and 2 above on a medium customarily used for software interchange; or,
- b) Accompany it with a written offer, valid for at least three years, to give any third party, for a charge no more than your cost of physically performing source distribution, a complete machine-readable copy of the corresponding source code, to be distributed under the terms of Sections 1 and 2 above on a medium customarily used for software interchange; or,
- c) Accompany it with the information you received as to the offer to distribute corresponding source code. (This alternative is allowed only for noncommercial distribution and only if you received the program in object code or executable form with such an offer, in accord with Subsection b above.)

The source code for a work means the preferred form of the work for making modifications to it. For an executable work, complete source code means all the source code for all modules it contains, plus any associated interface definition files, plus the scripts used to control compilation and installation of the executable. However, as a special exception, the source code distributed need not include anything that is normally distributed (in either source or binary form) with the major components (compiler, kernel, and so on) of the operating system on which the executable runs, unless that component itself accompanies the executable.

If distribution of executable or object code is made by offering access to copy from a designated place, then offering equivalent access to copy the source code from the same place counts as distribution of the source code, even though third parties are not compelled to copy the source along with the object code.

4. You may not copy, modify, sublicense, or distribute the Program except as expressly provided under this License. Any attempt otherwise to copy, modify, sublicense or distribute the Program is void, and will automatically terminate your rights under this License. However, parties who have received copies, or rights, from you under this License will not have their licenses terminated so long as such parties remain in full compliance.

5. You are not required to accept this License, since you have not signed it. However, nothing else grants you permission to modify or distribute the Program or its derivative works. These actions are prohibited by law if you do not accept this License. Therefore, by modifying or distributing the Program (or any work based on the Program), you indicate your acceptance of this License to do so, and all its terms and conditions for copying, distributing or modifying the Program or works based on it.

6. Each time you redistribute the Program (or any work based on the Program), the recipient automatically receives a license from the original licensor to copy, distribute or modify the Program subject to these terms and conditions. You may not impose any further restrictions on the recipients' exercise of the rights granted herein. You are not responsible for enforcing compliance by third parties to this License.

7. If, as a consequence of a court judgment or allegation of patent infringement or for any other reason (not limited to patent issues), conditions are imposed on you (whether by court order, agreement or otherwise) that contradict the conditions of this License, they do not excuse you from the conditions of this License. If you cannot distribute so as to satisfy simultaneously your obligations under this License and any other pertinent obligations, then as a consequence you may not distribute the Program at all. For example, if a patent license would not permit royalty-free redistribution of the Program by all those who receive copies directly or indirectly through you, then the only way you could satisfy both it and this License would be to refrain entirely from distribution of the Program.

If any portion of this section is held invalid or unenforceable under any particular circumstance, the balance of the section is intended to apply and the section as a whole is intended to apply in other circumstances.

It is not the purpose of this section to induce you to infringe any patents or other property right claims or to contest validity of any such claims; this section has the sole purpose of protecting the integrity of the free software distribution system, which is implemented by public license practices. Many people have made generous contributions to the wide range of software distributed through that system in reliance on consistent application of that system; it is up to the author/donor to decide if he or she is willing to distribute software through any other system and a licensee cannot impose that choice.

This section is intended to make thoroughly clear what is believed to be a consequence of the rest of this License.

8. If the distribution and/or use of the Program is restricted in certain countries either by patents or by copyrighted interfaces, the original copyright holder who places the Program under this License may add an explicit geographical distribution limitation excluding those countries, so that distribution is permitted only in or among countries not thus excluded. In such case, this License incorporates the limitation as if written in the body of this License.

9. The Free Software Foundation may publish revised and/or new versions of the General Public License from time to time. Such new versions will be similar in spirit to the present version, but may differ in detail to address new problems or concerns.

Each version is given a distinguishing version number. If the Program specifies a version number of this License which applies to it and "any later version", you have the option of following the terms and conditions either of that version or of any later version published by the Free Software Foundation. If the Program does not specify a version number of this License, you may choose any version ever published by the Free Software Foundation.

10. If you wish to incorporate parts of the Program into other free programs whose distribution conditions are different, write to the author to ask for permission. For software which is copyrighted by the Free Software Foundation, write to the Free Software Foundation; we sometimes make exceptions for this. Our decision will be guided by the two goals of preserving the free status of all derivatives of our free software and of promoting the sharing and reuse of software generally.

NO WARRANTY

11. BECAUSE THE PROGRAM IS LICENSED FREE OF CHARGE, THERE IS NO WARRANTY FOR THE PROGRAM, TO THE EXTENT PERMITTED BY APPLICABLE LAW. EXCEPT WHEN OTHERWISE STATED IN WRITING THE COPYRIGHT HOLDERS AND/OR OTHER PARTIES PROVIDE THE PROGRAM "AS IS" WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESSED OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. THE ENTIRE RISK AS TO THE QUALITY AND PERFORMANCE OF THE PROGRAM IS WITH YOU. SHOULD THE PROGRAM PROVE DEFECTIVE, YOU ASSUME THE COST OF ALL NECESSARY SERVICING, REPAIR OR CORRECTION.

12. IN NO EVENT UNLESS REQUIRED BY APPLICABLE LAW OR AGREED TO IN WRITING WILL ANY COPYRIGHT HOLDER, OR ANY OTHER PARTY WHO MAY MODIFY AND/OR REDISTRIBUTE THE PROGRAM AS PERMITTED ABOVE, BE LIABLE TO YOU FOR DAMAGES, INCLUDING ANY GENERAL, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES ARISING OUT OF THE USE OR INABILITY TO USE THE PROGRAM (INCLUDING BUT NOT LIMITED TO LOSS OF DATA OR DATA BEING RENDERED INACCURATE OR LOSSES SUSTAINED BY YOU OR THIRD PARTIES OR A FAILURE OF THE PROGRAM TO OPERATE WITH ANY OTHER PROGRAMS), EVEN IF SUCH HOLDER OR OTHER PARTY HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.