



HEWLETT
PACKARD

OPERATING AND SERVICE MANUAL

MODEL 654A TEST OSCILLATOR

The main body of this manual applies to

Serial Prefix 0951A

Any changes made in instruments manufactured after this printing will be found in a "Manual Changes" supplement supplied with this manual. Be sure to examine this supplement, if one exists for this manual, for any changes which apply to your instrument and record these changes in the manual. Backdating information for instruments manufactured before this printing will be found in Appendix C for instrument Serial Numbers 0951A02260 and below.

WARNING

To help minimize the possibility of electrical fire or shock hazards, do not expose this instrument to rain or excess moisture.

-hp- Part No. 00654-90003

Microfiche Part No. 00654-90053

©Copyright Hewlett-Packard Company 1969
P.O. Box 301, Loveland, Colorado 80537 U.S.A.

Printed: October 1975



CERTIFICATION

Hewlett-Packard Company certifies that this product met its published specifications at the time of shipment from the factory. Hewlett-Packard further certifies that its calibration measurements are traceable to the United States National Bureau of Standards, to the extent allowed by the Bureau's calibration facility, and to the calibration facilities of other International Standards Organization members.

WARRANTY

This Hewlett-Packard product is warranted against defects in material and workmanship for a period of one year from date of shipment [except that in the case of certain components listed in Section I of this manual, the warranty shall be for the specified period] . During the warranty period, Hewlett-Packard Company will, at its option, either repair or replace products which prove to be defective.

For warranty service or repair, this product must be returned to a service facility designated by -hp-. Buyer shall prepay shipping charges to -hp- and -hp- shall pay shipping charges to return the product to Buyer. However, Buyer shall pay all shipping charges, duties, and taxes for products returned to -hp- from another country.

Hewlett-Packard warrants that its software and firmware designated by -hp- for use with an instrument will execute its programming instructions when properly installed on that instrument. Hewlett-Packard does not warrant that the operation of the instrument, or software, or firmware will be uninterrupted or error free.

LIMITATION OF WARRANTY

The foregoing warranty shall not apply to defects resulting from improper or inadequate maintenance by Buyer, Buyer-supplied software or interfacing, unauthorized modification or misuse, operation outside of the environmental specifications for the product, or improper site preparation or maintenance.

NO OTHER WARRANTY IS EXPRESSED OR IMPLIED. HEWLETT-PACKARD SPECIFICALLY DISCLAIMS THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE.

EXCLUSIVE REMEDIES

THE REMEDIES PROVIDED HEREIN ARE BUYER'S SOLE AND EXCLUSIVE REMEDIES. HEWLETT-PACKARD SHALL NOT BE LIABLE FOR ANY DIRECT, INDIRECT, SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES, WHETHER BASED ON CONTRACT, TORT, OR ANY OTHER LEGAL THEORY.

ASSISTANCE

Product maintenance agreements and other customer assistance agreements are available for Hewlett-Packard products.

For any assistance, contact your nearest Hewlett-Packard Sales and Service Office. Addresses are provided at the back of this manual.

TABLE OF CONTENTS

| Section | Page | Section | Page |
|---|------|--|------|
| I. GENERAL INFORMATION | 1-1 | 5-36. Hum and Noise Check | 5-10 |
| 1-1. Description | 1-1 | 5-37. Counter Output Check. | 5-11 |
| 1-7. Supplied Accessories | 1-1 | 5-38. Adjustment Procedure | 5-12 |
| 1-8. Recommended Accessories | 1-1 | 5-40. Calibration Procedure. | 5-12 |
| 1-9. Instrument and Manual Identification | 1-1 | 5-42. Turn-On | 5-13 |
| | | 5-45. Power Supply Voltage Adjustments | 5-13 |
| | | 5-46. Power Supply Regulation and Ripple Check | 5-13 |
| Section II. INSTALLATION | 2-1 | 5-47. Frequency Calibration Procedures | 5-13 |
| 2-1. Introduction. | 2-1 | 5-58. Meter Tracking and Amplitude Control Adjustments | 5-16 |
| 2-3. Initial Inspection. | 2-1 | 5-61. Amplitude Accuracy Calibration | 5-17 |
| 2-5. Power Requirements | 2-1 | 5-62. Balance Adjustments | 5-18 |
| 2-9. Grounding Requirements | 2-1 | 5-65. Level Flatness Adjustments. | 5-18 |
| 2-11. Installation. | 2-1 | 5-70. Troubleshooting the 654A | 5-19 |
| 2-13. Rack/Bench Installation | 2-1 | 5-74. Front Panel Checks | 5-19 |
| 2-15. Repackaging for Shipment | 2-1 | 5-75. Troubleshooting Tree | 5-19 |
| | | 5-78. Troubleshooting the Power Supply. | 5-22 |
| Section III. OPERATING INSTRUCTIONS | 3-1 | 5-81. Troubleshooting the Oscillator Circuit | 5-22 |
| 3-1. Introduction. | 3-1 | 5-84. Troubleshooting the Buffer Amplifier. | 5-23 |
| 3-3. Controls, Indicators, and Connectors. | 3-1 | 5-86. Troubleshooting the Balanced Amplifier. | 5-23 |
| 3-5. Turn-On Procedure | 3-1 | 5-88. Trouble Isolation in the Remainder of the Leveling Loop | 5-23 |
| 3-6. Output Meter Mechanical Zero Adjustment. | 3-1 | 5-91. Troubleshooting the Amplitude Control Integrator. | 5-24 |
| 3-8. Primary Power Application. | 3-1 | 5-93. Troubleshooting the ALC Loop. | 5-24 |
| 3-9. Operating Instructions | 3-1 | 5-95. Troubleshooting the Meter Differential Amplifier | 5-24 |
| 3-10. Operating Check | 3-1 | 5-97. Troubleshooting the Attenuators | 5-24 |
| | | 5-99. Servicing Etched Circuit Boards. | 5-24 |
| Section IV. THEORY OF OPERATION | 4-1 | 5-101. Servicing Rotary Switches | 5-25 |
| 4-1. General Description | 4-1 | 5-103. Servicing Tuner Assembly. | 5-25 |
| 4-6. Circuit Description | 4-1 | | |
| 4-7. Oscillator Circuit | 4-1 | Section VI. REPLACEABLE PARTS | 6-1 |
| 4-11. Buffer Amplifier. | 4-2 | 6-1. Introduction. | 6-1 |
| 4-13. Counter Emitter Follower | 4-2 | 6-4. Ordering Information. | 6-1 |
| 4-15. Balanced Amplifier | 4-2 | 6-6. Non-Listed Parts | 6-1 |
| 4-19. Amplitude Control and Automatic Leveling Control | 4-3 | | |
| 4-29. Meter Circuits | 4-4 | Section VII. CIRCUIT DIAGRAMS | 7-1 |
| 4-33. Attenuators | 4-4 | 7-1. Introduction. | 7-1 |
| 4-35. Impedance Selector. | 4-4 | | |
| 4-37. Regulated Power Supply. | 4-4 | | |
| Section V. MAINTENANCE. | 5-1 | | |
| 5-1. Introduction. | 5-1 | APPENDICES | |
| 5-4. Performance Checks. | 5-1 | A. CODE LIST OF MANUFACTURERS | |
| 5-6. Frequency Checks. | 5-1 | B. SALES AND SERVICE OFFICES | |
| 5-7. Frequency Range Check | 5-1 | C. BACKDATING | |
| 5-8. Frequency Accuracy Check. | 5-1 | | |
| 5-9. Amplitude Accuracy Checks | 5-1 | | |
| 5-15. Level Flatness Checks | 5-4 | | |
| 5-21. Meter Tracking Accuracy Check | 5-6 | | |
| 5-22. Attenuator Accuracy Checks. | 5-7 | | |
| 5-28. Balance Checks. | 5-8 | | |
| 5-35. Distortion Check | 5-9 | | |

LIST OF TABLES

| Number | Page | Number | Page |
|---|------|---|---------------|
| 1-1. Specifications | 1-2 | 5-2. Frequency Accuracy Check | 5-3 |
| 1-2. General Information | 1-2 | 5-3. Thermal Converters for Level Flatness Checks . . . | 5-5 |
| 3-1. dBm/Voltage Conversion Chart | 3-1 | 5-4. Frequency Adjustments | 5-13 |
| 5-1. Required Test Equipment | 5-2 | 5-5. Front Panel Troubleshooting | 5-21 |
| | | 6-1. Replaceable Parts | 6-2 thru 6-12 |

LIST OF ILLUSTRATIONS

| Number | Page | Number | Page |
|--|------|--|-----------|
| 1-1. Model 654A Test Oscillator | 1-2 | 5-11. Hum and Noise Check | 5-11 |
| 2-1. Power Cords | 2-1 | 5-12. Logarithmic Addition of Harmonic Components | 5-11 |
| 3-1. Location of Controls, Indicators and Connectors | 3-2 | 5-13. 10MHz Low Pass Filter | 5-11 |
| 4-1. RC Network Characteristics | 4-1 | 5-14. Location of Internal Adjustments | 5-12 |
| 4-2. Regulated Power Supply Output Voltage vs Current | 4-5 | 5-15. Frequency Calibration Test Setup | 5-14 |
| 4-3. Simplified Schematic of Current Limiting Circuitry | 4-5 | 5-16. Meter Tracking Adjustment | 5-17 |
| 5-1. Amplitude Accuracy Checks - UNBAL | 5-3 | 5-17. Alignment Access Covers for Models 651B, 2A, 3A, 4A | 5-25 |
| 5-2. Amplitude Accuracy Checks - BAL | 5-4 | 5-18. Troubleshooting Tree | 5-27/5-28 |
| 5-3. Level Flatness Checks | 5-4 | 6-1. Frequency Tuning Mechanism | 6-9 |
| 5-4. Reference Supply | 5-5 | 6-2. Chassis Mechanical Parts | 6-10 |
| 5-5. Meter Tracking Accuracy Check | 5-6 | 7-1. Block Diagram | 7-3 |
| 5-6. Attenuator Accuracy Checks | 5-7 | 7-2. Oscillator and Buffer Amplifier | 7-5 |
| 5-7. Impedance Converter | 5-8 | 7-3. Balanced Amplifier, Meter and Leveling | 7-7/7-8 |
| 5-8. Balance Checks | 5-9 | 7-4. Attenuators and Impedance Selector | 7-9/7-10 |
| 5-9. Balance Box | 5-9 | 7-5. Power Supplies, A1 | 7-11 |
| 5-10. Distortion Check | 5-10 | | |

SAFETY SUMMARY

The following general safety precautions must be observed during all phases of operation, service, and repair of this instrument. Failure to comply with these precautions or with specific warnings elsewhere in this manual violates safety standards of design, manufacture, and intended use of the instrument. Hewlett-Packard Company assumes no liability for the customer's failure to comply with these requirements. This is a Safety Class 1 instrument.

GROUND THE INSTRUMENT

To minimize shock hazard, the instrument chassis and cabinet must be connected to an electrical ground. The instrument is equipped with a three-conductor ac power cable. The power cable must either be plugged into an approved three-contact electrical outlet or used with a three-contact to two-contact adapter with the grounding wire (green) firmly connected to an electrical ground (safety ground) at the power outlet. The power jack and mating plug of the power cable meet International Electrotechnical Commission (IEC) safety standards.

DO NOT OPERATE IN AN EXPLOSIVE ATMOSPHERE

Do not operate the instrument in the presence of flammable gases or fumes. Operation of any electrical instrument in such an environment constitutes a definite safety hazard.

KEEP AWAY FROM LIVE CIRCUITS

Operating personnel must not remove instrument covers. Component replacement and internal adjustments must be made by qualified maintenance personnel. Do not replace components with power cable connected. Under certain conditions, dangerous voltages may exist even with the power cable removed. To avoid injuries, always disconnect power and discharge circuits before touching them.

DO NOT SERVICE OR ADJUST ALONE

Do not attempt internal service or adjustment unless another person, capable of rendering first aid and resuscitation, is present.

DO NOT SUBSTITUTE PARTS OR MODIFY INSTRUMENT

Because of the danger of introducing additional hazards, do not install substitute parts or perform any unauthorized modification to the instrument. Return the instrument to a Hewlett-Packard Sales and Service Office for service and repair to ensure that safety features are maintained.

DANGEROUS PROCEDURE WARNINGS

Warnings, such as the example below, precede potentially dangerous procedures throughout this manual. Instructions contained in the warnings must be followed.

WARNING

Dangerous voltages, capable of causing death, are present in this instrument. Use extreme caution when handling, testing, and adjusting.

SAFETY SYMBOLS


General Definitions of Safety Symbols Used On Equipment or In Manuals.



Instruction manual symbol: the product will be marked with this symbol when it is necessary for the user to refer to the instruction manual in order to protect against damage to the instrument.



Indicates dangerous voltage (terminals fed from the interior by voltage exceeding 1000 volts must be so marked).



Protective conductor terminal. For protection against electrical shock in case of a fault. Used with field wiring terminals to indicate the terminal which must be connected to ground before operating equipment.



Low-noise or noiseless, clean ground (earth) terminal. Used for a signal common, as well as providing protection against electrical shock in case of a fault. A terminal marked with this symbol must be connected to ground in the manner described in the installation (operating) manual, and before operating the equipment.



Frame or chassis terminal. A connection to the frame (chassis) of the equipment which normally includes all exposed metal structures.



Alternating current (power line).



Direct current (power line).



Alternating or direct current (power line).

WARNING

The **WARNING** sign denotes a hazard. It calls attention to a procedure, practice, condition or the like, which, if not correctly performed or adhered to, could result in injury or death to personnel.

CAUTION

The **CAUTION** sign denotes a hazard. It calls attention to an operating procedure, practice, condition or the like, which, if not correctly performed or adhered to, could result in damage to or destruction of part or all of the product.

NOTE :

The **NOTE** sign denotes important information. It calls attention to procedure, practice, condition or the like, which is essential to highlight.

SECTION I

GENERAL INFORMATION

1-1. DESCRIPTION.

1-2. The Hewlett-Packard Model 654A Test Oscillator is an ideal general purpose signal source whenever a flat balanced or unbalanced test signal is required. Balanced outputs of 135 ohms, 150 ohms and 600 ohms have many uses in the communications industry. Automatic leveling, together with the expanded meter, make the 654A ideally suited to voltmeter calibration or to test frequency response of components during manufacture. The instrument is shown in Figure 1-1 and the specifications are listed in Table 1-1.

General information relating to the instrument is listed in Table 1-2. The information in Table 1-2 should not be considered specifications.

1-3. The Model 654A is a stable, low distortion sine-wave signal source with a flat frequency response of $\pm 0.5\%$ over the frequency range of 10 Hz to 10 MHz. The attenuators allow the signal to be adjusted in 1 dB and 10 dB steps from +10 dBm to -89 dBm, and the front panel AMPLITUDE control allows a continuous adjustment in level of ± 1 dB from the settings shown on the OUTPUT LEVEL attenuators. The flat frequency response is achieved by automatic leveling circuits within the 654A.

1-4. Five output impedances are available, selected by a front panel push-button control: these are 50 and 75 ohms unbalanced and 135, 150 and 600 ohms balanced. Balance is greater than 50 dB up to 1 MHz and greater than 40 dB up to 5 MHz.

1-5. The meter scale is expanded to indicate 0 dBm at center scale, with a total range of ± 1 dBm. The metering circuit monitors the signal level before the attenuators so that the meter indication is independent of the attenuator

settings; the meter indicates the signal level set by the front panel AMPLITUDE control. The output signal level into the load is the algebraic sum of the meter indication and the OUTPUT LEVEL attenuator settings.

1-6. An additional feature is the COUNTER OUTPUT rear panel BNC connector. This allows the Model 654A frequency to be continuously monitored by an electronic counter without interrupting measurements or affecting terminal balance.

1-7. SUPPLIED ACCESSORIES.

Rack mount kit: -hp- Part No. 5060-0775.

1-8. RECOMMENDED ACCESSORIES.

| | |
|-------------|--------------------------------------|
| -hp- 11048C | 50 ohm Feedthrough Termination |
| -hp- 11094A | 75 ohm Feedthrough Termination |
| -hp- 11095A | 600 ohm Feedthrough Termination |
| -hp- 11143A | Balanced BNC to Alligator clip cable |

1-9. INSTRUMENT AND MANUAL IDENTIFICATION.

1-10. Hewlett-Packard uses a two-section serial number. The first section (prefix) identifies a series of instruments. The last section (suffix) identifies a particular instrument within the series. If a letter is included with the serial number, it identifies the country in which the instrument was manufactured. If the serial prefix of your instrument differs from the one on the title page of this manual, a change sheet will be supplied to make this manual compatible with newer instruments or the backdating information in Appendix C will adapt this manual to earlier instruments. All correspondence with Hewlett-Packard should include the complete serial number.




Figure 1-1. Model 654A Test Oscillator

Table 1-1. Specifications

| | |
|---|---|
| <p>Frequency range: 10 Hz to 10 MHz in 6 bands.</p> <p>Frequency accuracy: 100 Hz (on X100 RANGE) to 5 MHz: +/-2% 10 Hz to 100 Hz: +/-3% 5 MHz to 10 MHz: +/-4%</p> <p>Level flatness(+10 dBm and 0 dBm): +/-0.5% referenced to level at 1 kHz from 10 Hz to 10 MHz for unbalanced outputs, 10 Hz to 5 MHz for 135 ohm and 150 ohm outputs, and 10 Hz to 1 MHz for 600 ohm output.</p> <p>Attenuator</p> <p>Range: 99 dB in 10 dB and 1 dB steps.</p> <p>Accuracy: +/-1.5% (0.15 dB) except +/-10% (1 dB) at output levels below 60 dBm at frequencies greater than 300 kHz.</p> | <p>Amplitude control: greater than 2 dB.</p> <p>Amplitude accuracy: +/-1% for 90 days (at 1 kHz, +10 dBm level with meter centered).</p> <p>Meter tracking: +/-0.05 dB.</p> <p>Balance (on balanced impedances) when measured by the procedure given in Paragraph 5-28: greater than 50 dB for frequencies from 10 Hz to 1 MHz, greater than 40 dB to 5 MHz.</p> <p>Distortion (THD) 10 Hz to 1 MHz: greater than 40 dB below fundamental. 1 MHz to 10 MHz: greater than 34 dB below fundamental.</p> <p>Hum and noise: greater than 70 dB down at full output.</p> |
|---|---|

Table 1-2. General Information

| | |
|--|---|
| <p>Output impedance: 50 ohm unbalanced, 75 ohm unbalanced, 135 ohm balanced, 150 ohm balanced and 600 ohm balanced.</p> <p>Output level: +11 dBm to -90 dBm, 10 dB and 1 dB steps with adjustable +/-1 dB meter range; calibrated for each impedance.</p> <p>Meter resolution: 0.02 dB.</p> | <p>Output connectors: BNC. Maximum voltage which can be applied to the output: less than +/-3 V peak.</p> <p>Counter output: greater than 0.1 V rms into 50 ohm, BNC connector.</p> <p>Operating temperature: 0°C to +55°C (32°F to 130°F).</p> <p>Power: 115 V or 230 V +/- 10%, 48 Hz to 66 Hz, 30 W nominal, 35 W max.</p> |
|--|---|

SECTION II INSTALLATION

2-1. INTRODUCTION.

2-2. This section contains information and instructions necessary for installing and shipping the Model 654A Test Oscillator. Included are initial inspection procedures, power and grounding requirements, environmental information, installation instructions and instructions for repackaging for shipment.

2-3. INITIAL INSPECTION.

2-4. This instrument was carefully inspected both mechanically and electrically before shipment. It should be physically free of marks or scratches and in perfect electrical order upon receipt. To confirm this, the instrument should be inspected for physical damage in transit. Also, check for supplied accessories, and test the electrical performance of the instrument using the procedure outlined in Section V of this manual. If there is damage or deficiency, see the warranty on Page ii of this manual.

2-5. POWER REQUIREMENTS.

2-6. This instrument will operate from either 115 or 230 V ac, 48 Hz to 66 Hz. The instrument can easily be in the position of the slide switch located on the rear panel, so that the designation appearing on the switch matches the nominal voltage of the power source.



Before applying primary power to the 654A be sure it is set for the proper line voltage as outlined in Paragraph 3-8.

2-7. Power Cords.

2-8. Figure 2-1 illustrates the standard power plug configurations that are used throughout the United States and in other countries. The -hp- part number directly below each drawing is the part number for a 654A power cord equipped with a power plug of that configuration. If the appropriate power cord is not included with the instrument, notify the nearest -hp- Sales and Service Office and a replacement cord will be provided.

2-9. GROUNDING REQUIREMENTS.

2-10. To protect operating personnel, the National Electrical Manufacturer's Association (NEMA) recommends that the instrument panel and cabinet be grounded. The Model 654A is equipped with a three-conductor power cord which, when plugged into an appropriate receptacle, grounds the instrument. The offset pin on the power plug is the ground connection.




Figure 2-1. Power Cords.

2-11. INSTALLATION.

2-12. This instrument is fully transistorized; therefore no special cooling is required. However, the instrument should not be operated where the ambient temperature is outside the limits specified in Table 1-2.

2-13. RACK/BENCH INSTALLATION.

2-14. This instrument is initially shipped as a bench-type instrument (unless ordered specifically as a rack-type) with plastic feet and tilt stand in place. Conversion to a rack-mounted instrument can be accomplished by using the rack-mounting kit and instruction furnished with your instrument.

2-15. REPACKAGING FOR SHIPMENT.

2-16. The following is a general guide for repackaging for shipment. If you have any question, contact your local -hp- Sales and Service Office. (See Appendix at the back of this manual for office location.)

NOTE

If the instrument is to be shipped to Hewlett-Packard for service or repair, attach a tag to the instrument identifying the owner and indicating the service or repair to be accomplished; include the model number and full serial number of the instrument. In any correspondence, identify the instrument by model number and serial number.

- a. Place instrument in original container if available. If original container is not available, a suitable one can be purchased from your nearest -hp- Sales and Service Office.

If original container is not used.

- b. Wrap instrument in heavy paper or plastic before placing in an inner container.
- c. Use plenty of packing material around all sides of instrument and protect panel faces with cardboard strips.
- d. Place instrument and inner container in a heavy carton or wooden box and seal with strong tape or metal bands.
- e. Mark shipping container with "DELICATE INSTRUMENT," "FRAGILE" etc.

SECTION III

OPERATING INSTRUCTIONS

3-1. INTRODUCTION.

3-2. This section contains instructions and information necessary for the operation of the 654A Test Oscillator. Included in this section are identification of controls, indicators and connectors, turn-on procedure, meter mechanical zero adjustment and operating instructions.

3-3. CONTROLS, INDICATORS, AND CONNECTORS.

3-4. All operating controls, indicators and connectors of the 654A are identified and described in Figure 3-1.

3-5. TURN-ON PROCEDURE.

3-6. OUTPUT METER MECHANICAL ZERO ADJUSTMENT.

3-7. The Model 654A output meter is properly mechanically zero-set when the meter pointer rests over the -1 dBm mark. Zero-set the output meter to obtain maximum accuracy and mechanical stability in the following manner. With LINE switch turned off, insert pointed object (such as tip of ball point pen) into recess on adjustment wheel, and rotate wheel until meter pointer rests exactly over -1 dBm mark.

3-8. PRIMARY POWER APPLICATION.

- a. Before applying primary power to instrument, set 115 or 230 volt slide switch (S3) to position which indicates primary voltage to be used.
- b. Connect primary power to connector J1. Switch LINE switch (S1) to ON position; pilot lamp (DS1) will glow.

3-9. OPERATING INSTRUCTIONS.

- a. Zero-set meter (Paragraph 3-7) and turn instrument on (Paragraph 3-8).
- b. Set the FREQUENCY RANGE switch and FREQUENCY dial (with VERNIER) to the desired frequency. (Dial reading multiplied by range setting gives the frequency in Hz.)
- c. Connect a frequency counter to the rear panel COUNTER OUTPUT, if desired.
- d. Select the required output impedance by pressing the appropriate IMPEDANCE pushbutton.

- e. Adjust the OUTPUT LEVEL attenuators and the AMPLITUDE control for the desired signal output level. The algebraic sum of the meter indication and the attenuator setting gives the power level, in dBm, into a load equal to the impedance selected by the IMPEDANCE pushbutton. In Table 3-1, the 0 dBm and +10 dBm levels are converted to voltage for each impedance.

CAUTION

SWITCH THE 10 DBM STEP ATTENUATOR DOWN BEFORE CONNECTING TO SENSITIVE EQUIPMENT, SUCH AS THERMAL CONVERTERS, SO AS TO PREVENT DAMAGE FROM OVERLOADING.

Table 3-1. dBm/Voltage Conversion Chart


| 0 dBm = 1 m watt into rated load. | | |
|-----------------------------------|-------------|-------------|
| Impedance | 0 dBm | +10 dBm |
| 50 ohm | 0.224 V rms | 0.707 V rms |
| 75 ohm | 0.274 V rms | 0.866 V rms |
| 135 ohm | 0.367 V rms | 1.162 V rms |
| 150 ohm | 0.387 V rms | 1.225 V rms |
| 600 ohm | 0.775 V rms | 2.449 V rms |

- f. Connect the load to the output connectors. Use the UNBAL connector for 50 ohm and 75 ohm loads and both connectors (BAL) for 135 ohm, 150 ohm and 600 ohm loads.

3-10. OPERATING CHECK.

3-11. Before making measurements using the 654A, perform the following front panel checks to ensure that your instrument is operating correctly.

- a. Turn AMPLITUDE control until white arrow on knob is pointing up; meter should indicate approximately 0 dBm.
- b. Turn AMPLITUDE control extreme counterclockwise; meter should indicate -1 dBm or less.
- c. Turn AMPLITUDE control extreme clockwise; meter should indicate +1 dBm or greater.



- | | |
|---|---|
| <p>① FREQUENCY dial (C1A/B/C): Varies test frequency continuously within each frequency range. Dial reading multiplied by range setting gives the output frequency in Hz of the 654A.</p> <p>② FREQUENCY RANGE switch (S2): Selects one of six frequency multipliers from X10 to X1M.</p> <p>③ Output Meter (M1): Monitors amplitude of 654A output prior to OUTPUT LEVEL attenuators. Algebraic sum of meter indication and OUTPUT LEVEL attenuator setting gives output power into rated load.</p> <p>④ Mechanical Zero Adjust: Allows meter to be mechanically zeroed, when instrument is off.</p> <p>⑤ OUTPUT LEVEL (S4): Attenuates 654A output signal in nine steps of 1 dBm each.</p> <p>⑥ OUTPUT LEVEL (S4): Attenuates 654A output signal in nine steps of 10 dBm each.</p> <p>⑦ UNBAL output (J4): BNC connector provides an unbalanced output signal, at impedances of 50 ohms and 75 ohms.</p> <p>⑧ BAL output (J3 and J4): BNC connectors provide a balanced output signal at impedances of 135 ohms, 150 ohms and 600 ohms.</p> | <p>⑨ IMPEDANCE switch (A4S1): Selects required output impedance of instrument; pushbuttons are interlocked so that when one is pressed the others spring out.</p> <p>⑩ AMPLITUDE control (R3): Allows adjustment of +/- 1 dBm of output signal amplitude.</p> <p>⑪ FREQUENCY VERNIER: Provides a fine frequency adjustment for FREQUENCY dial.</p> <p>⑫ LINE ON switch (S1) and Pilot Lamp (DS1): Switch applies primary power to instrument; pilot lamp glows to indicate application of primary power.</p> <p>⑬ 115 V or 230 V Slide Switch (S3): Sets instrument to operate from a primary power source of either 115 V ac or 230 V ac, 48 Hz to 66 Hz.</p> <p>⑭ FUSE (F1): 0.4 amp slow blow fuse protects instrument from overloads.</p> <p>⑮ COUNTER OUTPUT (J2): BNC connector provides signal output of greater than 0.1 V rms into a 50 ohm load, at same frequency as front panel outputs.</p> <p>⑯ Primary Power Connector (J1): Connects primary power to instrument.</p> |
|---|---|

Figure 3-1. Location of Controls, Indicators and Connectors

SECTION IV THEORY OF OPERATION

4-1. GENERAL DESCRIPTION.

4-2. The Model 654A Test Oscillator (see Block Diagram, Figure 7-1) contains a Wien Bridge Frequency Adjustable Oscillator (10 Hz to 10 MHz) followed by a Buffer Amplifier and a Balanced Amplifier with a single ended input and balanced output. The output of the Balanced Amplifier is a leveled, sinusoidal signal; this signal passes through Balanced Attenuators and a Balance and Unbalance Impedance Switch (output impedance switching network) to the front panel output connectors.

4-3. An Average Responding Detector monitors the output from the Balanced Amplifier to provide two dc currents (proportional to the signal level); one current flows to the meter circuits and the other to the Amplitude Control Integrator. Automatic leveling of the 654A signal is achieved by means of the Amplitude Control Integrator which compares the current from the Average Detector with the current from an Amplitude Current Reference to regulate the current through the lamp of a photosensitive control device (A2DSV1). The lamp controls the impedance of a resistive divider at the input of the Buffer Amplifier so as to maintain a constant output level from the Balanced Amplifier. The output level attenuators provide attenuation in 10 dB and 1 dB steps at the output connectors and a front panel AMPLITUDE control gives 2 dB of continuous output level adjustment by varying the current from the Amplitude Current Reference.

4-4. The current from the Average Detector which flows to the meter circuits is divided into two parts: a fixed amount of current (approximately 1.25 ma) flows into the Meter Offset Current Reference and the remainder flows to the meter. In this way the meter is offset so that it indicates only over the range of -1 dBm to +1 dBm. The current flowing into the Meter Offset Current Reference is held constant by the Meter Differential Amplifier which clamps the input of the current reference to a virtual ground.

4-5. A Counter Emitter Follower provides isolation between the oscillator circuit and the rear panel COUNTER OUTPUT. Regulated Power Supplies provide the +31 V and -26 V required to operate the 654A.

4-6. CIRCUIT DESCRIPTION.

4-7. OSCILLATOR CIRCUIT (Schematic No. 1, Figure 7-2)

4-8. The frequency adjustable Oscillator drives the Buffer

Amplifier with a stable sine wave at a frequency determined by the setting of the FREQUENCY RANGE switch and the FREQUENCY dial. The circuit is a Wien Bridge Oscillator which has a standard, frequency selective, RC leg and a resistance leg modified by the addition of a variable impedance (A2CR1 and A2CR2). A2Q26 and A2Q1 through A2Q6 comprises the amplifier section and A2Q7 is a peak detector which provides negative feedback to the bridge for leveling. Two types of feedback are used; positive feedback from the frequency selective network drives the base of A2Q3 through the source follower A2Q1, and negative feedback from the resistive side of the bridge drives the base of A2Q2. A2Q2 and A2Q3 form a differential amplifier. Only at the selected frequency does the positive feedback overcome the negative feedback to sustain oscillations.

4-9. The six frequency ranges are selected by means of the RC networks mounted on the FREQUENCY RANGE switch (S2); continuous adjustment of the frequency on each range is accomplished by rotating the FREQUENCY dial, which controls the setting of the tuner capacitors C1A, C1B and C1C. The signal from the amplifier output (from A2Q5 and A2Q6) is developed across the RC network of the bridge; at the selected frequency, where $X_C = R$ (Figure 4-1), the positive feedback to the base of A2Q3 has the correct phase and sufficient amplitude to sustain oscillations. The high input impedance of the field effect transistor (A2Q1) prevents the amplifier from loading the frequency determining leg of the bridge; the feedback provided by A2Q26 prevents any changes in the parameters of A2Q1 from affecting the frequency response of the amplifier. The difference between the positive and negative




Figure 4-1. RC Network Characteristics

feedback signals is amplified by the differential amplifier (A2Q2 and A2Q3) and applied, through emitter follower A2Q4, to the complementary symmetry pair A2Q5 and A2Q6. The very low output impedance of the complementary pair acts as a constant voltage source for the Buffer Amplifier and also allows feedback to be applied to the bridge without loading the output of the oscillator. A2Q5 and A2Q6 are forward biased through A2CR7 and A2CR8 so as to conduct slightly when no signal is applied; this eliminates crossover distortion of the output signal.

4-10. A2Q7 acts as a peak detector. Part of the oscillator signal is superimposed on a negative bias at the base of A2Q7; A2Q7 conducts only when the positive peaks of the signal overcome the negative bias. The negative dc output of A2Q7 is filtered by A2C2, A2C3 and A2C4 and used to bias the diodes A2CR1 and A2CR2 so as to vary the impedance of the negative feedback side of the bridge to control the amplitude of oscillations. A2R8 is switched into the circuit on the X100 through X1M ranges and A2C5 on the X10 through X1K ranges for extra filtering. A2CR3 limits any reverse voltage transients across the polarized capacitors A2C3, A2C4 and A2C5. A2R9* is selected to draw current from the bridge so as to balance the current through A2CR1 and A2CR2 and improve distortion in the output signal.

4-11. BUFFER AMPLIFIER. (Schematic 1)

4-12. The Buffer Amplifier (A2Q8 through A2Q10) provides isolation between the oscillator and the Balanced Amplifier and is also used as the point at which the 654A signal is leveled. A2Q8 and A2Q9 form a differential amplifier whose output, from the collector of A2Q9, is amplified by A2Q10 and fed to the Balanced Amplifier. Part of the signal output from A2Q10 is applied as negative feedback through A2R39 to the base of A2Q8 to stabilize the amplifier gain over its 10 Hz to 10 MHz frequency range. The signal from the oscillator is divided down at the input to the Buffer Amplifier by a resistive divider consisting of A2R33 and the resistive element of the photosensitive resistor (A2DSV1). The resistance of the resistive element is determined by the current through the lamp, which is controlled by the Automatic Leveling Circuits (Paragraph 4-19 and following). The signal level at the input of the Buffer Amplifier varies with changes in the resistance of the photosensitive resistor to control the level of the 654A output signal.

4-13. COUNTER EMITTER FOLLOWER. (Schematic 1)

4-14. The Counter Emitter Follower (A3Q1) serves as isolation between the Oscillator circuit, and the rear panel COUNTER OUTPUT (J2). The output frequency is the same as the Variable Test Oscillator frequency. Signal amplitude at the COUNTER OUTPUT is approximately 0.1 V rms into a 50 ohm load.

4-15. BALANCED AMPLIFIER. (Schematic 2, Figure 7-3)

4-16. The single-ended sinusoidal output from the Buffer Amplifier is amplified and converted into a balanced signal in the Balanced Amplifier. The Amplifier consists of three cascaded differential amplifiers (A2Q11 through A2Q16) and two complementary symmetry pairs (A2Q18, A2Q19 and A2Q20, A2Q21). The balanced output signal from the complementary symmetry pairs is developed across summing resistors A2R74 and A2R75 and then applied through A2R76 and C9, and through A2R77 and C10 to the attenuators (S4). The input sinusoidal signal at the base of A2Q11 is converted into two signals of equal amplitude, but 180° out of phase, taken from the collectors of A2Q11 and A2Q12. The two signals then follow parallel paths, while maintaining the 180° phase relationship, through the Balanced Amplifier. One signal path is through A2Q11, A2Q13 and A2Q15 to the complementary symmetry pair A2Q18 and A2Q19; the other signal path is through A2Q12, A2Q14 and A2Q16 to complementary symmetry pair A2Q20 and A2Q21. The complementary pairs are biased through diodes A2CR15, A2CR16 and A2CR17, A2CR18 so that the transistors conduct slightly when no signal is applied; this eliminates crossover distortion of the signal at the output of the Balanced Amplifier.

4-17. The gain of the Balanced Amplifier is stabilized by means of negative feedback. A2R51 couples the output signal from the top of A2R74 back to the base of A2Q11 and A2R53 couples the opposite signal from the bottom end of A2R75 back to the base of A2Q12. Note that the application of feedback together with the high gain of the Amplifier and the very low signal source impedance (from the Buffer Amplifier) causes the Balanced Amplifier to function as an operational amplifier with differential input and output; as a result, the overall gain of the Balanced Amplifier is determined by the ratio of A2R51 to A2R44 and A2R53 to A2R54. Capacitors A2C15 and A2C18 improve the high frequency response of the feedback paths.

4-18. To maintain proper balance of the output signal, the junction of summing resistors A2R74 and A2R75 is held at virtual ground by means of negative feedback to the third differential amplifier (A2Q15, A2Q16). The differential pair A2Q22 and A2Q23 compares the voltage at the junction of A2R74 and A2R75 with ground (the base of A2Q23 is connected directly to ground). Any signal unbalance or common mode signal across the two resistors moves their junction away from ground; this voltage at the junction is amplified by A2Q22 and A2Q23 and applied to the base of A2Q17 to change its collector current. A2Q17 is the source of current for A2Q15 and A2Q16 so that the change in current through them will be such as to restore the balance between the two sinusoidal signals and return the junction of A2R74 and A2R75 back to ground. A2C32 is adjusted for equal signal voltage across A2R74 and A2R75. A2R47, A2C16, A2C23, A2C26, A2C27, A2C28 and A2C29 all serve as frequency shaping elements to improve the frequency response and to insure stability of the Balanced Amplifier over its frequency range of 10 Hz to 10 MHz.

4-19. AMPLITUDE CONTROL AND AUTOMATIC LEVELING CONTROL.

4-20. The amplitude of the balanced sine wave signal from the Balanced Amplifier is independent of the Attenuator settings but can be varied over a 2 dB range by the front panel AMPLITUDE control (Schematic 2). The Automatic Leveling Circuit (ALC) consists of the Average Detector, the Amplitude Control Integrator, and the Amplitude Current Reference (varied by the AMPLITUDE control). The Average Detector monitors the output of the Balanced Amplifier and produces a dc current proportional to the amplitude of the Balanced Amplifier signal. The Amplitude Control Integrator compares this dc current with a current of opposite polarity from the Amplitude Current Reference; any difference in magnitude between the current from the Average Detector and the reference current is used to apply negative feedback to the photosensitive resistor at the input of the Buffer Amplifier until the output of the Balanced Amplifier is at the level where the two currents are equal. The output of the Balanced Amplifier is at the required level when the current from the Average Detector is equal to the reference current.

4-21. AVERAGE DETECTOR. (Schematic 2)

4-22. The detector monitors the output of the Balanced Amplifier. A2Q24 and A2Q25 form a high gain amplifier which is a current source for the detector (A2CR21 and A2CR22). A2CR21 supplies the metering circuits with a positive dc current and A2CR22 supplies the ALC circuits with a negative dc current. These currents are equal in amplitude to each other and proportional to the amplitude of the Balanced Amplifier output signal. A2Q24 and A2Q25 (together with the components connected to the base of A2Q25) form essentially one transistor with high gain, high output impedance and very low output capacitance; these factors together with the 'bootstrap' capacitor A2C42 account for the amplifier's effectiveness as a current source over a wide frequency and temperature range. A2C43 (Freq. Response) is adjusted for flat frequency response of the detector circuit.

4-23. AMPLITUDE CURRENT REFERENCE.

(Schematic 2)

4-24. Zener Diode A1CR8 maintains a constant voltage across R3 (front-panel AMPLITUDE control) and A2R91 in series, the Amplitude Control Integrator maintains essentially 0 Vdc at the output of the current reference (at the base of A3Q6): thus, for any given setting of R3, there is a fixed voltage drop across A3R19 and A3R20 and a fixed amount of current flows from the Amplitude Current Reference. When the setting of the AMPLITUDE control (R3) is changed, the voltage drop across A3R19 and A3R20 is changed; this sets a new fixed value of current flowing towards the base of A3Q6.

4-25. AMPLITUDE CONTROL INTEGRATOR.

(Schematic 2)

4-26. The circuit consists of A3Q6 through A3Q9 and

associated circuitry, including the lamp of the photosensitive resistor A2DSV1 (Schematic 1). A3Q6 and A3Q7 form a differential amplifier; any change in output from the collector of A3Q7 is amplified by A3Q8 and applied to the base of A3Q9 to change the current through the lamp of the photosensitive resistor (A2DSV1). Changes in lamp current change the impedance of the voltage divider at the input of the Buffer Amplifier (Paragraph 4-12), thus changing the sine wave signal level through the Buffer Amplifier and the Balanced Amplifier. The dc current from the Average Detector is compared, at the base of A3Q6, with the current from the Amplitude Current Reference. In the differential pair (A3Q6, A3Q7) the base of A3Q7 is connected directly to ground; therefore, as long as the base of A3Q6 is held at 0 Vdc, there will be no change in output from the collector of A3Q7. The amplitude of the positive current flowing from the Amplitude Current Reference is fixed; the amplitude of the negative current flowing from the Average Detector depends on the level of signal at the output of the Balanced Amplifier. These currents are summed at the base of A3Q6. The difference current flows into the base of A3Q6. The amplitude of the base current is set by the AMPLITUDE CAL. adjustment and the AMPLITUDE control. As long as this current level is not changed by a variation in the Average Detector output, there will be no change in current through the lamp of the photosensitive resistor; thus the ac signal level at the output of the Balanced Amplifier will be constant. In this condition, the ALC loop is in the "quiescent" state and the output of the 654A is at the required level.

4-27. Suppose that the output level of the Balanced Amplifier now changes for some reason (e. g. the frequency of the Wien Bridge Oscillator is changed); then the Amplitude Control Integrator will act to return the signal back to its original level in the following manner:

- a. The negative current from the Average Detector (A2CR22) will change proportionally with the change in ac signal level. This current flowing into the summing node at the base of A3Q6 diminishes the positive current amplitude thus decreasing the base current to A3Q6. This, in turn, begins to shut off the transistor.
- b. The output of the Amplitude Control Integrator changes in response to the new input so as to change the ac signal level into the Buffer Amplifier. This will be in such a direction as to return the Balanced Amplifier ac output back to the level where the negative dc current from the Average Detector is again equal to its quiescent value. In this way the 654A output signal is maintained at a constant level.

4-28. To manually control the 654A output level over the 2 dBm range, the AMPLITUDE control setting is changed; this changes the current from the Amplitude Current Reference thus changing the base current to A3Q6. The Amplitude Control Integrator now acts as before to change the Balanced Amplifier ac output level until the current

differential at the base of A3Q6 is equal to its quiescent value. The ALC circuit contains an integrator for fast response without overshoot and without sacrificing the ability to reject ripple superimposed on the current from the Average Detector. S2C14 is switched in parallel with A3C10 on the X10 RANGE for required response of the Amplitude Control Integrator at low frequencies.

4-29. METER CIRCUITS. (Schematic 2)

4-30. The meter circuits consist of the Meter Differential Amplifier, the Meter Offset Current Reference and the Meter. As explained in Paragraph 4-22, the Average Detector (A2CR21 and A2CR22) monitors the Balanced Amplifier output and produces two dc currents, equal in amplitude but opposite in polarity, proportional to the Balanced Amplifier output. The positive output of the Average Detector (from A2CR21) flows to the meter circuits. A fixed part of this current flows into the Meter Offset Current Reference and the remainder flows through the Meter and its shunt resistors A3R17 and A3R18. The Meter (M1) is calibrated to indicate center scale when the 654A output into rated load (the attenuators set at 0 dBm) is 0 dBm. The total range of the meter scale is +/-1 dBm so that when the Meter indicates -1 dBm, no current is flowing through the Meter and all of the current from the Average Detector is flowing through the Meter Offset Current Reference circuit.

4-31. The action of the Meter Offset Current Reference and the Meter Differential Amplifier is very similar to the action of the Amplitude Current Reference and the Amplitude Control Integrator (described in Paragraphs 4-22 through 4-25). Apart from a few minor differences the circuits are identical.

4-32. The Meter Offset Current Reference consists of A3R6, A3R7, A3R8, A3R9 and A3CR2. A3CR2 is a special temperature compensated Zener diode which maintains a constant voltage across A3R7 and A3R8 in series. Thus, the current flowing into the circuit is determined essentially by the voltage across A3R9. This current must always be a fixed amount so as to offset the Meter scale correctly; therefore, the voltage across A3R9 must always be fixed; this is achieved by means of the Meter Differential Amplifier. The Meter Differential Amplifier consists of A3Q2 through A3Q5. A3Q2 and A3Q3 form a differential pair; since the base of A3Q3 is connected directly to ground, the base of A3Q2 will be held at a virtual ground. Any difference between the two bases causes an output change from the collector of A3Q3 which is amplified by A3Q4 and applied to A3Q5 so as to return the base of A3Q2 back to virtual ground. One side of A3R9 is connected to the base of A3Q2, which is clamped to a virtual ground; the other side of A3R9 is connected to a constant voltage point (set by A3R7); thus the voltage across A3R9 is held constant as required, and the Meter Offset Current Reference always takes a fixed amount of the current from the Average Detector to offset the Meter. A3C5 serves to improve the frequency stability of the

Meter Differential Amplifier. A3C6 is connected across the Meter to damp the meter movement, and A3C7 is switched in parallel with A3C6 on the X10 RANGE so as to further improve damping of the Meter at very low frequencies.

4-33. ATTENUATORS. (Schematic 3)

4-34. The balanced sine wave signal, developed across A2R74 and A2R75 in the Balanced Amplifier, is fed through A2R76 and C9, and through A2R77 and C10 to the Attenuators (S4). The attenuator assembly (S4) consists of four attenuators; a 1 dB step and a 10 dB step attenuator connected in series for each of the two halves of the balanced signal. Each attenuator consists of four resistive networks which are switched in various combinations to give the required attenuation. The front panel controls consist of two concentric rotary knobs labelled OUTPUT LEVEL dBm; the outer control, marked in 10 dB steps, controls both of the 10 dB step attenuators simultaneously; the inner control, marked in 1 dB steps, controls both of the 1 dB step attenuators simultaneously.

4-35. IMPEDANCE SELECTOR. (Schematic 3)

4-36. The front panel IMPEDANCE switch (A4S1) selects the required output impedance of the 654A. The impedance networks and the switching connections are shown on schematic 3; the switch connections are shown with the 50 ohm UNBAL button pushed. In the BAL mode, both front panel output connectors, J3 and J4, are used; in the UNBAL mode, only J4 is used.

4-37. REGULATED POWER SUPPLY.

4-38. The regulated power supply provides all dc voltaged required by the 654A Test Oscillator circuits. The power supply consists of a +31 V and - 26 V series regulated supply. Each power supply is protected by current limiting and foldback current limiting.

4-39. The +31 V and - 26 V power supplies are functionally identical. Both use operational amplifiers for output voltage error amplification. A1R40 adjusts the +31 V supply voltage and A1R41 adjusts the - 26 V supply voltage.

4-40. Conventional current limiting is used in both supplies to limit the output current to approximately 300 mA. Foldback current limiting further limits the output current if the output voltage is pulled below approximately 16 V by a malfunction in the 654A circuitry. A direct short to ground of either supply will result in an output current of approximately 10 mA as shown in Figure 4-2.

4-41. Figure 4-3 is a simplified schematic of the current limiting circuitry used in the 654A power supplies. The Current Limiting Transistor A1Q4(+) or A1Q7(-) is a variable shunt to the series regulator drive current. It is first switched on by the voltage drop across the Current Limit Sensing Resistor when the power supply output current reaches approximately 300 mA. The power supply will remain in this Conventional Current Limit condition until the output current decreases allowing the supply to return to normal operation, or until the power supply output voltage drops below the Foldback Reference (16.2V).




Figure 4-2. Regulated Power Supply Output Voltage vs Current.

If the latter occurs, the Diode Switch is effectively closed and the power supply goes into a Foldback Current Limit condition. In this condition the Current Limiting Transistor is controlled by the power supply output voltage. As the output voltage decreases, the shunt current is increased.




Figure 4-3. Simplified Schematic of Current Limiting Circuitry

WARNING

Maintenance described herein is performed with power supplied to the instrument, and protective covers removed. Such maintenance should be performed only by service-trained personnel who are aware of the hazards involved (for example, fire and electrical shock). Where maintenance can be performed without power applied, the power should be removed.

SECTION V MAINTENANCE

5-1. INTRODUCTION.

5-2. This section contains maintenance and service information for the -hp- Model 654A Test Oscillator. Included are performance checks and adjustment and calibration procedures.

5-3. Table 5-1 lists the equipment required to properly maintain the Model 654A. If the recommended model is not available, any instrument that has specifications equal to, or better than, the required specifications may be used.

5-4. PERFORMANCE CHECKS.

5-5. The performance checks are in-cabinet tests (except where noted) to compare the performance of the Model 654A with the specifications given in Table 1-1. These checks may be used for incoming inspection, periodic maintenance and for performance checks after a repair. The Performance Check Test card at the end of Section V may be cut out and used as a permanent record of the instrument's performance during incoming inspection. It is recommended that performance checks and, if necessary, calibration be performed every 90 days.

5-6. FREQUENCY CHECKS.

5-7. FREQUENCY RANGE CHECK.

- a. Connect an electronic counter to the 654A rear panel COUNTER OUTPUT.
- b. Set the 654A controls as follows:

 FREQUENCY RANGE X10
 FREQUENCY dial Extreme clockwise
- c. The counter should indicate a period average of 100ms or greater, verifying a frequency of 10Hz, or less, at the lower end of the frequency range.
- d. Set the FREQUENCY RANGE switch to X1M and FREQUENCY dial to its extreme counter-clockwise position. The counter should indicate a frequency of 10MHz, or greater, verifying a frequency of at least 10MHz at the upper end of the frequency range.
- e. Perform the Frequency Adjustments (Paragraphs 5-47 through 5-57) if the tolerances are not met.

5-8. FREQUENCY ACCURACY CHECK.

- a. Connect an electronic counter to the 654A rear panel COUNTER OUTPUT.
- b. Set the 654A controls as follows:

 FREQUENCY RANGE X10
 FREQUENCY dial 1
- c. Verify frequency accuracy using the settings and tolerances given in Table 5-2. Use the period average setting on the counter for frequencies below 1kHz and use the frequency setting for frequencies above 1kHz.
- d. Perform the frequency adjustments (Paragraphs 5-47 through 5-57) if the tolerances are not met.

5-9. AMPLITUDE ACCURACY CHECKS.

(See also Table 3-1, Page 3-1).

5-10. 50 UNBAL AMPLITUDE ACCURACY.

- a. Connect the equipment as shown in Figure 5-1. Use the 50 ohm Feedthrough termination which should be connected directly to the 654A output connector.
- b. Set the 654A controls as follows:

 FREQUENCY dial 1
 FREQUENCY RANGE X1K
 OUTPUT LEVEL dBm +10,0
 IMPEDANCE 50 UNBAL
 AMPLITUDE Adjust for 0dBm
 on 654A meter.
- c. The ac voltmeter indication should be between .7000 V rms and .7142 V rms verifying an absolute level of + 10 dBm, +/-1%.
- d. If the tolerances are not met perform the Meter Tracking and Amplitude Control Adjustments of Paragraphs 5-58 through 5-60.

5-11. 75 UNBAL AMPLITUDE ACCURACY.

- a. Perform the procedure of Paragraph 5-10 except: in step a. Use the 75 ohm feedthrough termination;

Table 5-1. Required Test Equipment

| INSTRUMENT TYPE | REQUIRED CHARACTERISTICS | RECOMMENDED MODEL |
|--|--|--|
| Electronic Counter | Frequency: 10.00Hz to 10.00MHz. Period: 1.000ms to 100.0ms. | -hp- Model 5245L Electronic Counter. |
| AC Digital Voltmeter | Range: .9999V rms and 9.999V rms full scale. Accuracy: at least .1% of reading at 1kHz. | -hp- Model 3450B Multifunction Meter with OPT 001 |
| Wave Analyzer | Frequency Range: 1MHz to 22MHz. Must be compatible with Tracking Oscillator. (Note: the H05-312A is required only for distortion checks, otherwise a standard -hp- 312A can be used.) | -hp- Model H05-312A Wave Analyzer. |
| Tracking Oscillator | Must be capable of expanding wave analyzer meter indication to resolve 0.05dB. | -hp- Model 313A Tracking Oscillator. |
| Distortion Analyzer | Distortion Sensitivity: greater than 46dB. Frequency range: 10Hz to 600kHz. | -hp- Model 333A Distortion Analyzer. |
| Amplifier | Gain: 40dB. Frequency range: 1kHz to 10MHz. | -hp- Model 461A General Purpose Amplifier. |
| AC Voltmeter | Frequency range: 10Hz to 10MHz. Voltage range: 1.00mV rms to 1.00V rms (dB scales referenced to 1mW into 600 ohms). | -hp- Model 400E AC Voltmeter. |
| DC Null Voltmeter | Range: 10uV to 10mV. Accuracy: +/-2% of full scale. | -hp- Model 419A DC Null Voltmeter. |
| DC Voltmeter | Range: 0.1V to 100V. Input Impedance: 10 megohms. | -hp- Model 427A Multi-Function Meter. |
| Oscilloscope | Sensitivity: 5mV/cm. Bandwidth: dc to 50MHz. | -hp- Model 180A Oscilloscope with 1801A and 1820A plug-ins. |
| Feedthrough Terminating Resistance | Resistance: (a) 50 ohms +/- .25% (b) 75 ohms +/- .25% | Feed-Thru (a) -hp- Model 11048C (b) -hp- Model 11094A |
| Attenuators | Frequency range: 10Hz to 10MHz (with known accuracy at 10kHz, 300kHz and 10MHz). Attenuation range: (a) 9dB in 1dB steps. (b) 90dB in 10dB steps. | VHF Attenuators (a) -hp- Model 355C (b) -hp- Model 355D |
| Thermal Converters | Frequency range: 10Hz to 10MHz. Input: at least +10dBm into rated input impedance. Input impedance: (a) 50 ohms, unbalanced. (b) 75 ohms, unbalanced. (c) 135 ohms, balanced. (d) 150 ohms, balanced. (e) 600 ohms, balanced. | Thermal Converters (a) -hp- Model 11050A (b) -hp- Model H01-11050A (c) -hp- Model H11-11050A (d) -hp- Model H12-11050A (e) -hp- Model H10-11050A |
| BNC to Binding Post Adapter | | -hp- Model 10110A (2 required) |
| Resistors. | 1/8 W, metal film. (a) 75 ohms, .25% (two required). (b) 135 ohms, .1% (four required). (c) 300 ohms, .1% (two required). | -hp- Part No: 0698-6262 0698-7364 0698-6295 |
| <p>Note. The following items are not commercially available but can be easily constructed. refer to the figures listed for schematics and parts lists.</p> <p>DC Reference Supply Figure 5-4</p> <p>75 ohm to 50 ohm Impedance Converter Figure 5-7</p> <p>Balance Box Figure 5-9</p> <p>10MHz Low-Pass Filter Figure 5-12</p> | | <p>Note: The following are useful optional items.</p> <p>1) Jumper cable, 8 in., -hp- Part No. 10502-6001 (2 required, see Paragraph 5-30a)</p> <p>2) Sine-Wave Signal Generator: may be required for troubleshooting (Refer to Paragraphs 5-79 and 5-83.)</p> |

Table 5-2. Frequency Accuracy Check

| FREQUENCY DIAL | RANGE | ACCURACY | COUNTER INDICATION |
|----------------|-------|----------|-------------------------------|
| | | | Counter set to Period Average |
| 1 | X10 | ± 3% | 100ms ± 3ms |
| 2.5 | X10 | ± 3% | 40ms ± 1.2ms |
| 5 | X10 | ± 3% | 20.0ms ± 0.6ms |
| 8 | X10 | ± 3% | 12.5ms ± .375ms |
| 10 | X10 | ± 3% | 10.0ms ± 0.3ms |
| | | | Counter set to Frequency |
| 1 | X100 | ± 2% | 10.0ms ± 0.2ms |
| 2.5 | X100 | ± 2% | 4.00ms ± .08ms |
| 5 | X100 | ± 2% | 2.00ms ± 0.04ms |
| 8 | X100 | ± 2% | 1.25ms ± .025ms |
| 10 | X100 | ± 2% | 1.00ms ± 0.02ms |
| 1 | X1K | ± 2% | 1,000Hz ± 20Hz |
| 2.5 | X1K | ± 2% | 2500Hz ± 50Hz |
| 5 | X1K | ± 2% | 5,000Hz ± 100Hz |
| 8 | X1K | ± 2% | 8,000Hz ± 160Hz |
| 10 | X1K | ± 2% | 10,000Hz ± 200Hz |
| 1 | X10K | ± 2% | 10.0kHz ± 0.2kHz |
| 2.5 | X10K | ± 2% | 25kHz ± .5kHz |
| 5 | X10K | ± 2% | 50.0kHz ± 1.0kHz |
| 8 | X10K | ± 2% | 80kHz ± 1.6kHz |
| 10 | X10K | ± 2% | 100kHz ± 2kHz |
| 1 | X100K | ± 2% | 100kHz ± 2kHz |
| 2.5 | X100K | ± 2% | 250kHz ± 5kHz |
| 5 | X100K | ± 2% | 500kHz ± 10kHz |
| 8 | X100K | ± 2% | 800kHz ± 16kHz |
| 10 | X100K | ± 2% | 1,000kHz ± 20kHz |
| 1 | X1M | ± 2% | 1,000kHz ± 20kHz |
| 2.5 | X1M | ± 2% | 2,500kHz ± 50kHz |
| 5 | X1M | ± 2% | 5,000kHz ± 100kHz |
| 8 | X1M | ± 4% | 8,000kHz ± 320kHz |
| 10 | X1M | ± 4% | 10,000kHz ± 400kHz |

in step b. Set IMPEDANCE to 75 UNBAL;
in step c. The ac differential voltmeter indication should be between .8573V rms and .8747V rms.

- b. If the tolerances are not met, first assure that the 50 ohm output is correct (Paragraph 5-10) then troubleshoot the instrument. The trouble will most probably be in either the 50 ohm or 75 ohm impedance networks on the A4 board.

5-12. 135 BAL AMPLITUDE ACCURACY.

- a. Connect the equipment (shown in Figure 5-2), in the following manner:
 - 1) Connect a 67.5 ohm resistor (use two 135 ohm resistors in parallel, R1 and R2) across two BNC to Binding Post Adapters as shown in Figure 5-2.
 - 2) Connect the adapters to the two output terminals of the 654A.
 - 3) Connect the ac voltmeter across the resistor which is connected to the 654A UNBAL terminal.
- b. Set the 654A controls as in Paragraph 5-10b except set IMPEDANCE to 135 BAL.
- c. Record the ac differential voltmeter indication.
- d. Disconnect the voltmeter from the one resistor and record the voltage across the other resistor (connect the ground lead as before).
- e. Add the two voltages recorded in steps c and d. The total voltage should fall between 1.150V rms and 1.174V rms, verifying an absolute level of +10dBm, +/-1%.
- f. If the tolerances are not met troubleshoot the instrument; the most likely problem would be the 135 ohm impedance network on the A4 board.




Figure 5-1. Amplitude Accuracy Checks - UNBAL




Figure 5-2. Amplitude Accuracy Checks - BAL

5-13. 150 BAL AMPLITUDE ACCURACY.

- a. Connect the equipment as in Paragraph 5-12a except use 75 ohm resistors in place of the 67.5 ohms.
- b. Set the 654A controls as in Paragraph 5-10b except set IMPEDANCE to 150 BAL.
- c. Perform steps c and d of Paragraph 5-12.
- d. Add the two voltages; the total voltage should fall between 1.213V rms and 1.237V rms verifying an absolute level of +10dBm, +/-1%.
- e. If the tolerances are not met troubleshoot the instrument; the most likely problem would be the 150 ohm impedance network on the A4 Board.

- d. Add the two voltages; the total voltage should fall between 2.424V rms and 2.474V rms verifying an absolute accuracy of +10dBm +/-1%.
- e. If the tolerances are not met troubleshoot the instrument; the most likely problem would be the 600 ohm impedance network on the A4 Board.

5-15. LEVEL FLATNESS CHECKS.

5-16. 50 UNBAL FLATNESS CHECK.

5-14. 600 BAL AMPLITUDE ACCURACY.

- a. Connect the equipment as in Paragraph 5-12a except use 300 ohm resistors in place of the 67.5 ohms.
- b. Set the 654A controls as in Paragraph 5-10b except set IMPEDANCE to 600 BAL.
- c. Perform steps c and d of Paragraph 5-12.

- a. Set the 654A controls as follows:

FREQUENCY dial 1
 FREQUENCY RANGE X1K
 OUTPUT LEVEL dBm +10.0
 IMPEDANCE 50 UNBAL
 AMPLITUDE Adjust for 0dBm on 654A meter.

- b. Connect the equipment shown in Figure 5-3; use the 50 ohm thermal converter (Table 5-3) which should be connected directly to the 654A UNBAL output connector. (The parts required to build the Reference Supply are shown in Figure 5-4).




Figure 5-3. Level Flatness Checks

Table 5-3. Thermal Converters for Level Flatness Checks.
(See Paragraph 5-16 for explanation)

| INPUT IMPEDANCE | -hp- Part No. | Input Level | Output Voltage (dc) | +/-0.5% deviation |
|-----------------|---------------|----------------|---------------------|-------------------|
| 50 UNBAL | 11050A | +10dBm 0dBm | mV mV | +/- uV +/- uV |
| 75 UNBAL | H01-11050A | +10dBm 0dBm | mV mV | +/- uV +/- uV |
| 135 BAL | H11-11050A | +10dBm 0dBm | mV mV | +/- uV +/- uV |
| 150 BAL | H12-11050A | +10dBm 0dBm | mV mV | +/- uV +/- uV |
| 600 BAL | H10-11050A | +10dBm 0dBm | mV mV | +/- uV +/- uV |

- c. Set the reference supply for minimum output voltage and record, in Table 5-3, the thermal converter output voltage indicated on the dc null voltmeter.
- d. Using the formula given below, calculate the voltage deviation which represents a change of +/-0.5%; record this in the last column of Table 5-3.

$$\pm \Delta E = \frac{2E (\% \text{ change})}{100}$$

ΔE = maximum allowable deviation from E
 E = thermal converter output voltage
 % change = (+/-) 0.5%

Example: If E = 7mV

$$\text{Then } \pm \Delta E = \frac{2 \times 7 \times 10^{-3} \times (\pm)0.5}{100} = \pm 70\mu\text{V}$$

NOTE

The factor 2 is included in the formula as the thermal converter is a square law device.

- e. Adjust the reference supply for null indication on the dc null meter.
- f. Sweep the 654A slowly over the frequency range of 10Hz to 10MHz; the dc null meter indication should not vary more than +/- ΔE (calculated in step d of this Paragraph) from null. This verifies a level flatness, referenced to 1kHz, of +/-0.5% at an output level of +10dBm.
- g. Reset the 654A frequency to 1kHz and the 10dBm step attenuator to 0 position and repeat

steps c through f of this paragraph to verify a flatness of +/-0.5% at an output level of 0dBm.

- h. If the tolerances are not met, first check the 75 UNBAL flatness (Paragraph 5-17) before performing the calibration of Paragraph 5-67.

5-17. 75 UNBAL FLATNESS CHECK.

- a. Perform the procedure of Paragraph 5-16 steps a through g with the following changes: in step a. Set IMPEDANCE to 75 UNBAL; in step b. Use the 75 ohm thermal converter (Table 5-3).
- b. If the tolerances are not met, perform the calibration of Paragraph 5-66.




Figure 5-4. Reference Supply

5-18. 135 BAL FLATNESS CHECK.

- a. Perform the procedure of Paragraph 5-16 steps a through g with the following changes:
In step a. Set IMPEDANCE to 135 BAL;
In step b. Use the 135 ohm thermal converter (Table 5-3) which should be connected directly to both output connectors of the 654A;
In step f. Sweep the 654A over the frequency range of 10Hz to 5MHz.
- b. If the tolerances are not met, first assure that the 75 UNBAL flatness is within tolerance before troubleshooting the 654A.

5-19. 150 BAL FLATNESS CHECK.

- a. Perform the procedure of Paragraph 5-16 steps a through g with the following changes:
In step a. Set IMPEDANCE to 150 BAL;
In step b. Use the 150 ohm thermal converter (Table 5-3) which should be connected directly to both output connectors of the 654A;
In step f. Sweep the 654A over the frequency range of 10Hz to 5MHz.
- b. If the tolerances are not met, first assure that the 75 UNBAL flatness is within tolerance before troubleshooting the 654A.

5-20. 600 BAL FLATNESS CHECK.

- a. Perform the procedure of Paragraph 5-16 steps a through g with the following changes:
In step a. Set IMPEDANCE to 600 BAL;
In step b. Use the 600 ohm thermal converter (Table 5-3) which should be connected directly to both output connectors of the 654A.
In step f. Sweep the 654A over the frequency range of 10Hz to 1MHz.
- b. If the tolerances are not met, first assure that the 75 UNBAL flatness is within tolerance before troubleshooting the 654A.

5-21. METER TRACKING ACCURACY CHECK.

- a. Connect the equipment as shown in Figure 5-5. Use an attenuator with known accuracy at 10kHz, and 10MHz.
- b. Set the 654A controls as follows:

| | |
|------------------------|-------------------------------|
| FREQUENCY RANGE | X1K |
| FREQUENCY dial | .10 |
| OUTPUT LEVEL dBm | +10.0 |
| IMPEDANCE | 50 UNBAL |
| AMPLITUDE | Adjust for 0dBm on 654A meter |
- c. On the rear panels of the instruments, connect the 312A Wave Analyzer RECORDER OUTPUT to the 313A Tracking Oscillator RECORDER INPUT. Set the tracking oscillator METER MODE switch to EXPAND 312A.
- d. Set the external attenuator to -1dB position.
- e. Adjust the wave analyzer to the same frequency as the 654A and for a meter indication of between -7dB and +3dB.
- f. Adjust the tracking oscillator SCALE OFFSET control for a 0dB reference indication on the oscillator meter.
- g. Set the external attenuator for 0dB attenuation.
- h. Adjust the 654A AMPLITUDE control to return the tracking oscillator meter indication to 0dB reference; 654A meter should indicate -1dBm, +/-0.05dBm.
- i. Set the external attenuator to -2dB position.
- j. Adjust the 654A AMPLITUDE control to return the tracking oscillator meter indication to 0dB reference; 654A meter should indicate +1dBm, +/-0.05dBm.




Figure 5-5. Meter Tracking Accuracy Check

- k. Adjust the 654A to 10MHz and reset the AMPLITUDE control for 0dBm indication on the 654A meter.
- l. Repeat steps d through j of this paragraph to check tracking at 10MHz.
- m. These checks verify meter tracking accuracy of +/-0.05dB; perform the adjustments of Paragraphs 5-58 through 5-60 if the limits are not met.

5-22. ATTENUATOR ACCURACY CHECKS.

5-23. MEASUREMENT PROBLEMS.

5-24. The test set up for the attenuator checks is critical. Improper grounding can give attenuator measurement errors of greater than 1dB. Ground loops can be eliminated by using an adequate Isolation Transformer connected between the power line source and the 654A as shown in Figure 5-6.

5-25. If the 654A attenuators do not appear to be within the limits given in the following checks, carefully check the test setup before troubleshooting the attenuators; the placement of the shield around the 654A attenuators is extremely critical and, if disturbed, can adversely affect the high frequency response of the attenuators (see Paragraph 5-97).

5-26. 10dB-STEP ATTENUATOR CHECK.

NOTE

See Paragraphs 5-24 and 5-25 before making this check.

- a. Connect the equipment shown in Figure 5-6. (Figure 5-7 shows the parts required to build the 75 ohm to 50 ohm impedance converter). Use the 10dB/step external attenuator (with known accuracy at 300kHz and 10MHz), do not connect the 1dB/step attenuator at this time.
- b. On the rear panels of the instruments connect the 312A Wave Analyzer RECORDER OUTPUT to the 313A Tracking Oscillator RECORDER INPUT. Set the tracking oscillator METER MODE switch to EXPAND 312A.
- c. Set the 654A controls as follows:
 FREQUENCY dial 3
 FREQUENCY RANGE X100K
 OUTPUT LEVEL dBm +10,0
 IMPEDANCE 150 BAL
 AMPLITUDE Adjust for 0dBm on 654A meter.
- d. Set the external attenuator to -90dB position and the external amplifier gain to +40dB.




Figure 5-6. Attenuator Accuracy Checks

- e. Adjust the wave analyzer to the same frequency as the 654A and for a meter indication of between -7dB and +3dB.
- f. Adjust the tracking oscillator SCALE OFFSET control for a meter indication of 0dB reference level.
- g. Check the 654A 10dB attenuator at each position by decreasing attenuation on the external attenuator as attenuation is increased on the 654A attenuator. at each position the tracking oscillator meter indication should be 0dB, +/-0.15dB.
- h. Check the 654A 10dB attenuator at 10MHz using the following procedure.
 - 1) Set the 654A to 10MHz.
 - 2) Repeat steps d, e and f of this paragraph.
 - 3) Repeat step g of this paragraph for the +10 through -60dB position of the 654A attenuator.
 - 4) Repeat step g for the -70 and -80 positions of the 654A attenuators except that the tracking oscillator meter indication for these two positions should be 0dB, +/-1dB.

————— NOTE —————

This procedure, so far, has checked only one side of the attenuator, the following step describes how to check the other side.

- i. Check the other side of the 654A 10dB attenuator at 300kHz and 10MHz by interchanging the two cables connected to the 654A output connectors (i.e. as viewed in Figure 5-6, the cable terminated in 75 ohms is moved with the termination to the right-hand connector and the cable connected to the 75 ohm to 50 ohm impedance converter is moved with the converter to the left-hand connector); then repeat steps c through h of this paragraph.

5-27. 1dB-STEP ATTENUATOR CHECK.

————— NOTE —————

See Paragraphs 5-24 and 5-25 before making this check.

- a. Connect the equipment as in Figure 5-6 with the 1dB/step external attenuator connected directly between the 75 ohm to 50 ohm impedance converter and 312A Wave Analyzer.
- b. Perform steps b and c of Paragraph 5-26.
- c. Set the external attenuator to the -9dB position.
- d. Perform steps e and f of Paragraph 5-26.
- e. Check the 654A 1dB step attenuator at each position by decreasing attenuation on the external attenuator as attenuation is increased on the 654A attenuator; at each position the tracking oscillator meter indication should be 0dB, +/-0.15dB.
- f. Repeat the check with the 654A and wave analyzer set to 10MHz to verify the attenuator accuracy at high frequency.

————— NOTE —————

This procedure, so far, has checked only one side of the attenuator, the following step describes how to check the remaining half.

- g. Check the other side of the 654A 1dB step attenuator at 300kHz and 10MHz by interchanging the cables (as described in Paragraph 5-26, step i) and repeating steps b through f of this paragraph (5-27).

5-28. BALANCE CHECKS.

- 5-29. If the tolerances given in the following procedures




Figure 5-7. Impedance Converter




Figure 5-8. Balance Checks

(Paragraphs 5-30 through 5-34) are not met, perform the Balance Adjustments (Paragraph 5-62 through 5-64).

in step d. ac voltmeter indication should be below 12.25mV rms.

5-30. 135 BAL CHECK.

5-33. 600 BAL CHECK.

- a. Connect the equipment, as shown in Figure 5-8, using the 135 ohm Balance Box: (the parts required to build the Balance Box are shown in Figure 5-9) the cables from the 654A should be as short as possible and of equal length (jumper cables, -hp- 10502-6001, which are made from 8 in. lengths of coaxial cable, are suitable for this application).

5-34. Repeat the procedure of Paragraph 5-30 with the following changes:

- in step a. Use the 600 ohm Balance Box (See Figure 5-9);
- in step b. Set IMPEDANCE to 600 BAL;
- in step c. ac voltmeter indication should be below 7.75mV rms;
- in step d. ac voltmeter indication should be below 24.5mV rms.

- b. Set the 654A controls as follows:

FREQUENCY dial 1
 FREQUENCY RANGE X10
 OUTPUT LEVEL dBm +10,0
 IMPEDANCE 135 BAL
 AMPLITUDE Adjust for 0dBm on 654A meter.

5-35. DISTORTION CHECK.

- a. Connect a distortion analyzer to the 654A 50 ohm output as shown in Figure 5-10.


- c. Sweep the 654A slowly over the frequency range of 10Hz to 1MHz; the ac voltmeter indication should remain below 3.68mV rms, verifying balance of greater than 50dB from 10Hz to 1MHz.

- d. Sweep the 654A slowly over the frequency range of 1MHz to 5MHz; the ac voltmeter indication should remain below 11.6mV rms, verifying balance of greater than 40dB from 1MHz to 5MHz.

5-31. 150 BAL CHECK.

5-32. Repeat the procedure of Paragraph 5-30 with the following changes:

- in step a. use the 150 ohm Balance Box (See Figure 5-9);
- in step b. set IMPEDANCE to 150 BAL;
- in step c. ac voltmeter indication should be below 3.87mV rms;



Parts List: (All resistors 1/8 watt metal film.)

- R1, R2 300 ohms +/- .1% -hp- 0698-6295
- R3 150 ohms +/- .1% -hp- 0757-0284

Rp:

| Input Impedance | Rp, +/-1% |
|-----------------|--------------------------|
| 135 ohms | 174 ohms, -hp- 0698-4417 |
| 150 ohms | 200 ohms, -hp- 0757-0407 |
| 600 ohms | open |

Figure 5-9. Balance Box




Figure 5-10. Distortion Check

b. Set the 654A controls as follows:

- FREQUENCY dial 1
- FREQUENCY RANGE X10
- OUTPUT LEVEL dBm +10,0
- IMPEDANCE 50 UNBAL
- AMPLITUDE Adjust for +1dBm on 654A meter.

c. Verify distortion of greater than 40dB below the fundamental frequency by checking the distortion at the following frequency settings of the 654A:

- 1) FREQUENCY dial at 1, 2, 5, 8 and 10 for each FREQUENCY RANGE switch setting, X10, X100, X1K, and X10K.
- 2) FREQUENCY dial at 1, 2 and 5 for X100K setting of FREQUENCY RANGE switch.

d. Disconnect the 654A from the distortion analyzer and connect the 654A to the wave analyzer (remove 50 ohm feedthru termination).

e. Set the 654A FREQUENCY RANGE switch to X1M and the FREQUENCY dial to 1.

f. Tune the wave analyzer to 1MHz and note the level (in dB) of the 654A fundamental frequency as indicated on the wave analyzer meter.

g. Tune the wave analyzer to the second and third harmonics of the 654A frequency and record the difference (in dB) between the level of each harmonic and the level of the fundamental. Calculate the total harmonic distortion (calculation below) which should be at least 40dB below the fundamental frequency level.

NOTE

If both harmonics are more than 43dB below the fundamental, the total harmonic distortion will be more than 40dB down and it will not be necessary to make the following calculation.

- 1) Ascertain the difference between the two harmonic levels (in dB).

2) Using the chart below (Figure 5-12), determine the dB to be added to the largest harmonic level.

3) Add this amount to the largest harmonic level. This total should be ≥ 40 dB below the level in step f.

Example:

If two harmonics with levels of -42dB and -48dB are measured, the difference is $-48 - (-42) = -6$. Observing the chart this corresponds to an added level of 1.0dB. Adding this to the largest harmonic level (-42dB) gives $-42 + 1.0 = -41$ dB.

h. Set the 654A frequency to 5MHz; tune the wave analyzer to 5MHz and repeat steps f and g to measure the total harmonic distortion at 5MHz, which should be greater than 34dB below the fundamental.

i. Set the 654A frequency to 10MHz; tune the wave analyzer to 10MHz and record the level indicated (in dB) on the wave analyzer meter.

j. Tune the wave analyzer to 20MHz and measure the distortion which should be at least 34dB below the level recorded in step i.

k. Perform the adjustment of Paragraph 5-51 if the tolerances are not met.

5-36. HUM AND NOISE CHECK.

a. Connect the equipment shown in Figure 5-11. Figure 5-13 shows the parts required to build the 10MHz Low-Pass Filter.

b. Set the 654A controls as follows:

- FREQUENCY dial Extreme Clockwise
- FREQUENCY RANGE X1K
- OUTPUT LEVEL dBm +10,0
- IMPEDANCE 50 UNBAL




Figure 5-11. Hum and Noise Check

c. Adjust the 654A AMPLITUDE control for an ac voltmeter indication of 0dB on the 0dB range.

d. Remove the 654A top cover: insert a screwdriver between the tuner capacitor (point X on Figure 5-14) and chassis ground. The residual hum and noise indicated on the ac voltmeter should be greater than 70dB below the 0dB reference.

CAUTION

IN THE FOLLOWING STEP THE 654A TUNER CAPACITOR IS SHORTED TO GROUND. CARE SHOULD BE TAKEN NOT TO TOUCH OR DAMAGE THE PLATES OF THE TUNER CAPACITOR OTHERWISE THE INSTRUMENT WILL HAVE TO BE RECALIBRATED.

CAUTION

DO NOT MOVE THE TWO WIRES BETWEEN TUNER AND RANGE SWITCH (95 AND 8); THEIR POSITION WILL EFFECT FREQUENCY. ALL WIRES ON OR AROUND THE FREQUENCY RANGE SWITCH CAN EFFECT FREQUENCY RESPONSE.




Figure 5-13. 10MHz Low Pass Filter

e. If the tolerance is not met ensure that a good ground connection was made in step d before troubleshooting the instrument.




Figure 5-12. Logarithmic Addition of Harmonic Components

5-37. COUNTER OUTPUT CHECK.

a. Set the 654A controls as follows:

FREQUENCY dial 1
 FREQUENCY RANGE X10

b. Connect an ac voltmeter to the 654A rear panel COUNTER OUTPUT; terminate the the cable to the ac voltmeter with a 50 ohm feedthrough termination.

c. Sweep the FREQUENCY dial slowly from 1 to 10 for all positions of the FREQUENCY RANGE switch.

- d. The ac voltmeter indication should be 0.1V rms or greater, verifying an output of at least 0.1V rms into 50 ohms.
- e. If the limits are not met troubleshoot the instrument.

5-38. ADJUSTMENT PROCEDURE.

5-39. The following is a complete calibration procedure for the Model 654A Test Oscillator. These adjustments should

be performed only if it has been determined by the Performance Checks that the 654A is not meeting its specifications. Figure 5-14 shows the location of all internal adjustments.

5-40. CALIBRATION PROCEDURE.

5-41. To remove the top or bottom cover, remove the two retaining screws, slide the cover about 1/2 inch to the rear and lift off. To remove the side covers, remove the two retaining screws and lift off. To replace the covers, reverse the procedure.

CAUTION

THE 654A CONTAINS HIGH IMPEDANCE, HIGH FREQUENCY CIRCUITS. CONTAMINATION OF THE SWITCHES, CIRCUIT BOARDS OR TUNING CAPACITOR WILL CAUSE HIGH IMPEDANCE LEAKAGE PATHS AND SUBSEQUENT DETERIORATION OF THE PERFORMANCE OF THE INSTRUMENT. AVOID TOUCHING ANY OF THESE CIRCUITS WITH THE BARE FINGERS, AS SKIN OILS ARE EXTREMELY CONTAMINATING. IF HANDLING IS NECESSARY, WEAR CLEAN COTTON OR RUBBER GLOVES. DO NOT USE A PENCIL TO TRACE CIRCUITS IN THE INSTRUMENT. GRAPHITE PENCIL LEAD IS AN EXTREMELY GOOD CONDUCTOR AND AN ACCIDENTALLY INTRODUCED PATH OF THIS TYPE IS SOMETIMES DIFFICULT TO LOCATE. TO AVOID SURFACE CONTAMINATION OF A PRINTED CIRCUIT OR SWITCH, CLEAN WITH A WEAK SOLUTION OF WARM WATER AND MILD DETERGENT AFTER REPAIR. RINSE THOROUGHLY WITH CLEAN WATER AND ALLOW IT TO DRY COMPLETELY BEFORE OPERATING. DO NOT APPLY ANY COMMERCIAL MOISTURE SEALING SPRAY TO THE BOARDS; APPLICATION OF THESE AGENTS MAY CAUSE LEAKAGE PATHS.




Figure 5-14. Location of Internal Adjustments

ed by the meeting its all internal

ove the two to the rear ve the two ers, reverse

OF CE HE IN AN HE AN TO AK LY OT OF

5-42. TURN-ON.

5-43. Connect the 654A to a variable power line supply (set for 115V or 230V as appropriate).

5-44. Zero set the meter (Paragraph 3-7), turn the instrument on (Paragraph 3-8), and allow 30 minutes warm-up time.

5-45. POWER SUPPLY VOLTAGE ADJUSTMENTS.

- a. Connect a dc voltmeter to the power supply positive output (A1 Pin 12).
- b. Adjust A1R40 (+31 V ADJUST) for a dc voltmeter indication of +31 V +/- 0.2 V.
- c. Connect the dc voltmeter to the negative power supply output (A1 Pin 13).
- d. Adjust A1R41 (- 26 V Adjust) for a dc voltmeter indication of - 26 V +/- 0.2 V.

5-46. POWER SUPPLY REGULATION AND RIPPLE CHECK.

- a. Connect the dc voltmeter to the power supply negative output (A1 Pin 13); switch the FREQUENCY RANGE switch to X100 and note the voltmeter indication.
- b. Vary the power line voltage from 103.5V to 126.5V (207V to 253V for a 230V power line); the dc voltmeter indication should remain within +/-0.5V of the reading noted in step a.
- c. Adjust the line voltage to 103.5V (207V for a 230V power line) and disconnect the dc voltmeter.

- d. Connect an oscilloscope to the power supply positive output (A1 Pin 12) and short out the tuner capacitor (C1) by clipping a lead from the solder lug (green/white lead) on the tuner frame to the chassis. The oscilloscope ripple indication should be less than 15mV peak-to-peak.



DO NOT MOVE THE TWO WIRES BETWEEN TUNER AND RANGE SWITCH; THEIR POSITION WILL AFFECT FREQ. CAL.

- e. Connect the oscilloscope to the power supply negative output (A1 Pin 13); the ripple indication should be less than 15mV peak-to-peak.
- f. Disconnect the clip lead from the tuner.

5-47. FREQUENCY CALIBRATION PROCEDURES.



DO NOT MOVE THE TWO WIRES BETWEEN TUNER AND RANGE SWITCH AFTER CALIBRATION IS STARTED; THEIR POSITION WILL AFFECT FREQ. CAL.

5-48. The frequency calibration set-up is shown in Figure 5-14 (do not make the set-up at this time); the frequency should be continuously monitored at the rear panel COUNTER OUTPUT. Table 5-2 lists the accuracy required at each check frequency; adjustments for each range are listed in Table 5-4. Components located on the FREQUENCY RANGE switch (S2) are identified on the switch drawing of Figure 7-2.

Table 5-4. Frequency Adjustments

| Increasing value of these components decreases frequency and changes A2TP2 voltage as shown. Adjust variable capacitors clockwise to increase capacitance, counter-clockwise to decrease capacitance. | | | | |
|---|-------------------------|-------------------------|-----------------------------|-------------------------|
| FREQUENCY RANGE | FREQUENCY Dial = 1 | | FREQUENCY Dial = 10 | |
| | Increases A2TP2 Voltage | Decreases A2TP2 Voltage | Increases A2TP2 Voltage | Decreases A2TP2 Voltage |
| X10 | S2R2* | S2R10* | --- | --- |
| X100 | --- | --- | S2C17* | --- |
| X1K | --- | --- | S2C8, S2C9*, S2C13*, S2C16* | S2C2, S2C3* |
| X10K | --- | --- | S2C1*, S2C18* | --- |
| X100K | --- | --- | S2C10, S2C11* | S2C4, S2C5* |
| X1M | S2R8* | S2R16* | A2C1, S2C12, S2C15* | S2C6, S2C7* |

5-49. During calibration, the instrument bottom cover is removed; the top cover is removed to make adjustments and replaced while making frequency measurements (not necessary to replace retaining screws), all internal shields must be in place and held firmly by retaining screws. If desired Figure 5-17 gives a scaled drawing of top and bottom alignment access covers with cut-outs that will allow adjustments while the covers are in place. The dimensions are given in inches.

5-50. FEEDBACK LEVEL ADJUSTMENT.

- a. Connect the equipment shown in Figure 5-15.
- b. Set the 654A controls as follows:
 FREQUENCY dial extreme clockwise
 FREQUENCY RANGE X1K
 OUTPUT LEVEL dBm +10,0
 AMPLITUDE extreme counter-clockwise
 IMPEDANCE 50 UNBAL

————— NOTE —————
 Adjust A2C1, S2C2, and S2C8, if necessary, to start oscillations.

- c. Adjust A2R3 (Feedback Level Adj.) for an indication on the dc voltmeter of -350mV, +/-10mV.
- d. For oscillator troubleshooting, refer to Paragraph 5-81.

5-51. DISTORTION ADJUSTMENT.

- a. Connect the 654A to the distortion analyzer as shown in Figure 5-10. Set the 654A controls for a frequency of 1 X 100.
- b. Adjust A2R4 (Distortion Adj.) for minimum distortion, which should be at least -46dB. If the tolerance cannot be met, change the value of A2R9*

- c. Check distortion at other dial and range settings.

————— NOTE —————
 You can adjust A1R4 at other frequency to get them into specification providing that you still are in specification at 1 X 100.

- d. Disconnect the distortion analyzer.

5-52. Frequency Dial and 1 K Range Adjustment.

- a. Preliminary mechanical adjustments (perform only if necessary).
 - 1) To prevent gear backlash problems during alignment, make sure that there is no movement between MP1 and MP2. See Figure 6-1. (They must be pressed tightly together.) Also MP3, 4, and MP5 spring gear assembly must be under tension.
 - 2) Check to make sure that the stop MP6 prevents the tuning capacitor from being completely closed. MP6 should hold the capacitor at least 1/16 inch open. Adjust if necessary.
 - 3) With the dial set to maximum clockwise position, slip the dial face such that the first mark left of 1 is 1/16 inch to the right of the fixed indicator. To slip dial, remove Frequency dial knob and loosen 4 dial retaining screws. After slipping dial, retighten the screws.
- b. Connect equipment as shown in Figure 5-15 and set the 654A controls as in Paragraph 5-50b. Record output frequency.
- c. Record frequency at dial settings 1, 2, 5, 8 and 10. If some readings are high and some are low, proceed to step e. If all readings are high or all




Figure 5-15. Frequency Calibration Test Setup

nge settings.

readings are low, proceed to step d. If all the readings are within tolerances, proceed to step f.

- d. Check readings at 1, 5 and 10 on the dial. If readings are close to proper value, proceed to step e. If they are not, perform the following:

- 1) Place dial to clockwise position.
- 2) Remove the frequency dial knob and loosen the four dial retaining screws.
- 3) Slip the dial to read 1 with a counter indication of 1 kHz (Frequency Range 1 K).
- 4) Tighten the retaining screws and replace the knob.

- e. Set the FREQUENCY dial to 10. Adjust S2C2 and S2C8 alternately until the counter indicates a frequency of 10 kHz and A2TP2 voltage is -370 ± 10 mV. Then recheck at 1 on the dial. Work back and forth between 1 and 10 on the dial until both are near or within the allowed limits. Recheck step c.

- 1) If S2C2 does not have sufficient range, change the value of S2C3* (refer to Table 5-5). If S2C8 does not have sufficient range, change S2C9*.

- 2) If A2TP2 should not remain -370 mV ± 20 mV over the entire dial range, change value of S2C16* or S2C13* to bring frequency and A2TP2 voltage within limits.

- f. Check all frequencies on the X1K range according to Table 5-2. The voltage at 1 and 10 on the dial should read the same ± 10 mV. If voltage is not within limits, proceed to step e(2).

————— NOTE —————

Steps d, e and f interact with each other.

5-53. X100, X1K and X10K RANGE TRACKING.

- a. Connect the equipment as shown in Figure 5-15. Set the 654A controls as in Paragraph 5-50b.
- b. Check frequency tracking of the FREQUENCY dial using the settings and tolerances given in Table 5-2 for the X100, X1K and X10K ranges. Also monitor A2TP2 voltage which should remain within -0.3 to -0.4 V over the entire range. If necessary, pad S2C17* for X100 RANGE and S2C1* and S2C18* for X10K RANGE for correct frequency and A2TP2 voltage when the dial is set to 10.

5-54. X10 RANGE ADJUSTMENTS.

- a. Connect the equipment as shown in Figure 5-15.
- b. Set the 654A FREQUENCY RANGE switch to X10 and FREQUENCY dial to 1, other controls as in Paragraph 5-50b. The counter (set to read period average) should indicate 100 ± 3 msec (10 ± 0.3 Hz) and A2TP2 voltage should be -370 ± 40 mV; if either frequency or A2TP2 voltage is not within tolerance, change the value of S2R2* and S2R10* simultaneously (see Table 5-4) until the tolerances are met.
- c. Check frequency tracking using the settings and tolerances given in Table 5-2 for the X10 range. Monitor A2TP2 voltage which should remain at -370 ± 40 mV over the entire range. If necessary, to make dial track, repeat step b but set the frequency towards the upper or lower tolerance.

5-55. X1M RANGE ADJUSTMENTS.

- a. Connect the equipment as shown in Figure 5-15.
- b. Set the 654A FREQUENCY RANGE switch to X1M and the FREQUENCY dial to 10, other controls as in Paragraph 5-50b.

————— NOTE —————

Adjust A2C1, S2C6 and S2C12, if necessary, to start oscillation.

- c. Adjust S2C6 and S2C12 (see Table 5-4) for a counter indication between 10.1 and 10.2 MHz (1 to 2% high) and A2TP2 voltage between -0.38 V and -0.40 V.
- d. Set the FREQUENCY dial to 5; counter should indicate 5,000 ± 65 kHz. If not, perform the following.

- 1) Note whether the counter indication is higher or lower than 5,000 kHz.

- 2) Set the FREQUENCY dial to 10; if the frequency of step 1) was high, adjust A2C1 to increase the counter indication slightly; if the frequency of step 1) was low, adjust A2C1 to slightly lower the counter indication.

————— NOTE —————

While making this adjustment to A2C1, the oscillator may stop oscillating; however, the adjustment to be made in step 3) will start oscillations again.

- 3) Readjust S2C6 and S2C12 as in step 5-55c.

- 4) Repeat step 5-55d as often as necessary until tolerances are met at both 5 and 10 settings of the FREQUENCY dial. If S2C6 does not have sufficient range, change the value of S2C7* in accordance with Table 5-4; similarly, for S2C12 change S2C15*.
- e. Set the 654A FREQUENCY dial to 1; the counter should indicate 1000 ± 20 kHz and A2TP2 voltage should be between -0.3 V to -0.4 V; if frequency or A2TP2 voltage is not within tolerance, pad range resistors S2R8* and S2R16* simultaneously in accordance with Table 5-4.

————— NOTE —————

It may be necessary to set the frequency high at 10 on dial in order for the dial to track.

- f. Set the dial to 10 and repeat steps c and d if necessary.
- g. Check frequency tracking of the dial at the settings given in Table 5-2 for the X1M range; if any of these are not within tolerance, repeat steps c through g of this paragraph. A2TP2 voltage should be within -0.25 to -0.42 volts over the entire range.

5-56. X100K RANGE ADJUSTMENTS.

- a. Connect the equipment as shown in Figure 5-15. Set the 654A controls as in Paragraph 5-50b except set FREQUENCY RANGE to X100K and FREQUENCY dial to 1.
- b. Note the A2TP2 voltage which should be between -0.3 V to -0.4 V; set the FREQUENCY dial to 10 and adjust S2C4 and S2C10 for a counter indication of 1 MHz \pm 20 kHz and an A2TP2 voltage as noted above. If S2C4 does not have sufficient range, change the value of S2C5* in accordance with Table 5-4; similarly, for S2C10, change the value of S2C11*.
- c. Check the FREQUENCY dial tracking using the settings and tolerances given in Table 5-2 for the X100K range. If not in tolerance, repeat step b but set the frequency (with dial at 10) towards the lower or upper limit of the tolerance given in Table 5-2 so that the dial will track as required.

5-57. OUTPUT WAVEFORM CHECK.

- a. Connect the 654A 50 ohm output to the oscilloscope; terminate the cable from the 654A with a 50 ohm feedthru.

- b. Set the 654A controls as follows:

AMPLITUDE extreme counter-clockwise
 OUTPUT LEVEL dBm extreme
clockwise
 IMPEDANCE 50 UNBAL

- c. Check the 654A output waveform for spurious oscillations or visible distortion; check all frequencies by sweeping the FREQUENCY dial across the whole range at each FREQUENCY RANGE setting. If distortion or spurious oscillations occur, eliminate by changing the value of A2C8*.

————— NOTE —————

If A2C8* is changed it may be necessary to recalibrate the X1M and X100K ranges.

5-58. METER TRACKING AND AMPLITUDE CONTROL ADJUSTMENTS.

5-59. METER RANGE ADJUSTMENT.

- a. Set the 654A controls as follows:

FREQUENCY dial 1
 FREQUENCY RANGE X1K
 OUTPUT LEVEL dBm +10.0
 IMPEDANCE 50 UNBAL

- b. Adjust A3R18 (Meter Cal) to its extreme clockwise position.
- c. Adjust A3R7 (Meter Offset Cal) so that the AMPLITUDE control has sufficient range to exceed the maximum meter deflection at both ends of the meter scale.
- d. Adjust the 654A AMPLITUDE control for a meter indication of -1dBm.
- e. Connect the equipment shown in Figure 5-16 and set the external attenuator for 0dB attenuation.
- f. Adjust the reference supply for null indication on the dc null voltmeter (which should be set to either the 30uV or 100uV range).
- g. Set the external attenuator to -2dB position and adjust the 654A AMPLITUDE control to return the dc null voltmeter indication to null.
- h. Adjust A3R18 (Meter Cal) until the 654A meter indicates +1dBm.




Figure 5-16. Meter Tracking Adjustment

- i. Check the 654A meter tracking as follows:
 - 1) Set the external attenuator to -1dB position and adjust the 654A AMPLITUDE control for null indication on the dc null voltmeter; the 654A meter should indicate $0 \pm 0.05\text{dBm}$.
 - 2) Set the external attenuator to 0 dB position and adjust the 654A AMPLITUDE control for null indication on the dc null voltmeter; the 654A meter should indicate $-1 \pm 0.01\text{dBm}$.
 - 3) If the tolerances in steps 1) and 2) are not met then readjust A3R7 (Meter Offset Cal) as in step c and repeat steps d through i of this paragraph.
- j. The meter tracking adjustment is completed by performing Paragraph 5-60.
- k. For troubleshooting information refer to Paragraph 5-94.
- c. Adjust the 654A AMPLITUDE control for an indication on the ac differential voltmeter of .7071V rms (+10dBm); adjust A3R7 (Meter Offset Cal) for a 654A meter indication of 0dBm.
- d. Set the 654A AMPLITUDE control to the extreme clockwise position and adjust A3R20 (Amplitude Cal) for an ac differential voltmeter indication of 0.80V rms (approximately +11.05dBm).
- e. For troubleshooting information refer to Paragraph 5-95.

5-61. AMPLITUDE ACCURACY CALIBRATION.

- a. Perform the Amplitude Accuracy checks of Paragraphs 5-9 through 5-14 but do not make any adjustments except as outlined below. If the +/-1% limits are met for all impedances do not perform the remaining steps of this Paragraph.
- b. If the +/-1% limits are not met for any impedance:

5-60. AMPLITUDE CONTROL AND METER CALIBRATION.

NOTE
Perform adjustments of Paragraph 5-59 before making the following adjustments.

- a. Connect the equipment shown in Figure 5-1 using the 50 ohm termination.
- b. Set the 654A controls as follows:

FREQUENCY dial1
 FREQUENCY RANGEX1K
 OUTPUT LEVEL dBm+10.0
 IMPEDANCE50 UNBAL

- 1) Verify that the impedance networks on the Impedance Selector board (A4) have the correct impedance and if necessary replace any faulty resistors. The impedance can be checked by measuring the open circuit voltage (for each impedance) which should be twice the terminated voltage; alternatively set the attenuator to -80dB position and measure the output impedance with an ohmmeter.
- 2) Perform procedure of Paragraph 5-60 except, in step c (of 5-60) adjust the 654A AMPLITUDE control for an ac differential voltmeter indication slightly higher or lower than 0.707V rms (see example below) so as to correct any error noted in step a of this Paragraph (5-61): the offset from 0.707V rms should be as small as possible, but in any case, must remain within the limits of 0.700 to 0.714V rms.

EXAMPLE: Suppose that, in step a of this paragraph, the amplitude is found to be too high for one of the impedances; then set the 654A **AMPLITUDE** control for an ac voltmeter indication below 0.707V rms, and vice versa.

- c. Repeat the steps of this paragraph as necessary to ensure that the level is correct for all impedances.

5-62. BALANCE ADJUSTMENTS.

5-63. 135 BAL.

- a. Perform steps a and b of the Balance Check of Paragraph 5-30.
- b. Set the 654A frequency to 10MHz and adjust A2C32 (High Freq. Balance) for optimum balance (lowest indication on the ac voltmeter.)
- c. Set the 654A frequency to 5MHz; the ac voltmeter indication should be below 11.6mV rms indicating a balance of greater than 40dB. If it is not then select a value for A2C21* or A2C36* (but not both) to give the required balance at 5MHz. (Typically, balance of at least 46dB, 5.8mV rms, can be achieved).

NOTE

There is no way of predetermining which side of the balanced amplifier is unbalanced or what value of capacitance is required; A2C21* or A2C36* must be selected by trial and error. Select the lowest value of capacitance possible.

- d. Perform steps c and d of Paragraph 5-30 (135 BAL CHECK) to ensure that limits are met at all frequencies of the 654A.

5-64. 150 AND 600 BAL CHECK.

- a. Perform the checks of Paragraphs 5-31 through 5-34 to ensure that balance is within specifications for the 150 ohm and 600 ohm impedances.
- b. If it is not, repeat the procedure of Paragraph 5-63 but slightly degrade the balance for the 135 ohm impedance (be careful to remain within the requirements of 40dB from 1MHz to 5MHz and 50dB from 10Hz to 1MHz) then repeat step a of this paragraph (5-64) until balance specifications are met for all three impedances.

5-18

NOTE

This situation is not likely to arise; however, if it does, then it is recommended that careful notes be made during the procedure as there is no way, other than by trial and error, of determining if the 135 ohm balance is being degraded in a direction which will improve the balance for the other impedances, or if it is being degraded in a direction which will worsen the balance for the other impedances.

5-65. LEVEL FLATNESS ADJUSTMENTS.

5-66. 75 UNBAL FLATNESS.

- a. Perform steps a through e of Paragraph 5-16 (50 UNBAL FLATNESS CHECK) with the following exceptions:
in step a. Set **IMPEDANCE** to 75 UNBAL;
in step b. Use the 75 ohm thermal converter (see Table 5-3).
- b. Set the 654A frequency to 10MHz and adjust A2C43 (Frequency Response) for null indication, $\pm\Delta E$ (calculated in step a of Paragraph 5-16) on the dc null voltmeter.
- c. Sweep the 654A frequency slowly down to 1MHz; the null voltmeter indication should remain within $\pm\Delta E$ of null over the whole frequency range.

NOTE

It may be necessary to slightly offset the adjustment of A2C43 at 10MHz so that the flatness is within tolerance across the XIM range.

- d. Set the 654A frequency to 10Hz; if the dc null voltmeter indication is not within $\pm\Delta E$ of null change the value of A2C40*. (Increase the value of A2C40* if the 654A level is too low at 10Hz, and vice-versa.)
- e. Sweep the 654A **FREQUENCY** dial slowly from 1 to 10 for all settings of the **FREQUENCY RANGE** switch to ensure that the 75 ohm output is flat over the entire frequency range of the instrument.

5-67. 50 UNBAL FLATNESS.

NOTE

The adjustments of Paragraph 5-66 should be completed before making these adjustments.

- a. Perform steps a through e of Paragraph 5-16.
- b. Set the 654A frequency to 10MHz; the dc null voltmeter indication should be within $\pm\Delta E$ of

null. If it is not change the value of A4C1* to bring the 654A level within tolerance (decrease A4C1* to increase the output level and vice-versa).

c. Sweep the 654A frequency slowly down to 1MHz and observe the dc null voltmeter indication which should remain within +/-ΔE of null. If it does not repeat step b of this paragraph but select a value for A4C1* which allows the flatness to be met across the 1MHz to 10MHz frequency range.

d. Check the 654A flatness over the 10Hz to 1MHz ranges as before.

5-68. 135, 150 and 600 BAL FLATNESS.

5-69. Check the flatness for the balanced impedances by performing Paragraphs 5-18, 5-19 and 5-20. There are no adjustments to be made for these ranges.

5-70. TROUBLESHOOTING THE 654A.

5-71. This section contains information and procedures designed to aid in the process of isolating malfunctions. Troubleshooting should be undertaken only after it has been determined that the malfunction cannot be corrected by performing the adjustment and calibration procedures.

5-72. When a malfunction occurs first ensure that the trouble is not caused by conditions external to the instrument; then make the front panel checks described in Paragraph 5-74 before proceeding to the Troubleshooting Tree.

5-73. The Troubleshooting Tree (Figure 5-18) illustrates a systematic method of locating a faulty circuit. Additional checks (including visual) and measurements will be required to isolate the faulty component.

5-74. FRONT PANEL CHECKS.

- a. Check that the LINE ON lamp is lit; if it is not, check the setting of the 115/230V slide switch, check the fuse (F1) and if necessary check the primary circuit of the power transformer (T1) on schematic No. 4, Figure 7-5).
- b. In this procedure the 654A will be swept across its frequency range while the following points are monitored:
 - A. the COUNTER OUTPUT
 - B. the 654A meter indication
 - C. the front panel output connectors.

By applying the observation made to Table 5-5 it should be possible to localize any problems to a particular area in the instrument (refer also to the Block Diagram, Figure 7-1).

1) Set the 654A controls as follows:

AMPLITUDE fully clockwise
 OUTPUT LEVEL dBm +10,0
 IMPEDANCE 50 UNBAL

2) Connect an oscilloscope or ac voltmeter, through a 50 ohm feedthrough termination, to the 654A rear panel COUNTER OUTPUT.

3) Connect an oscilloscope or ac voltmeter, through a 50 ohm feedthrough termination, to the front panel UNBAL output connection.

4) Sweep the 654A FREQUENCY dial slowly from 1 to 10 (for all positions of the FREQUENCY RANGE switch) while observing the three monitoring points A, B and C.

5) Select from the left hand column of Table 5-5 the ABC combination which corresponds with the observations made in step 4). The center column of Table 5-5 gives the most likely trouble area for each combination and the right hand column indicates the next step to make in troubleshooting.

5-75. TROUBLESHOOTING TREE.

5-76. To use the tree start at ①, read step ① of Paragraph 5-77 and make the required check; the next step then depends upon whether the first check was a PASS or FAIL. Several of the FAIL branches split into sub-branches, take the sub-branch which best fits the observations made. At each step of the tree it is important to read the appropriate step of Paragraph 5-77 as the tree itself does not give sufficiently detailed information, in most cases, for the check to be made. Refer also to the Block Diagram and Schematics of Section VII when using the troubleshooting tree. If you complete the tree and still have failed to localize the problem area then refer to Paragraph 5-78 for additional information.

5-77. This paragraph provides information for each step of the troubleshooting tree.

NOTE

Make the Front panel checks, described in Paragraph 5-74, if you have not already done so.

① Check with an oscilloscope at A2 Pin 4: there should be a sine wave of between 5.5V and 7V p-p. Sweep the FREQUENCY dial from 1 to 10 for all positions of the range switch. If the signal appears, even momentarily, then the problem is probably frequency calibration.

② Check the dc voltage at the output of the Buffer Amplifier (junction of A2CR24 and A2R44), this should be 0 +/- .1V dc.

③ Check the dc power supply voltages on the A2 board:

+31 +/- .5V dc at A2 Pin 1.

-26 +/- .5V dc at A2 Pin 2.

④ Check the ac voltage at the output of the Buffer Amplifier (junction of A2CR24 and A2R44) with an oscilloscope; this should be a sine wave of 3V +/- 1V peak-to-peak. Notice that for the FAIL situation there are three possible branches (NO SIGNAL, LESS SIGNAL, GREATER SIGNAL). Take the appropriate branch to the next check point.

————— NOTE —————

If the output from the Buffer Amplifier is not correct then the problem is probably in the ALC loop; following the tree should be the fastest way of localizing the problem. If after completing the tree you still have not localized the problem, then refer to Paragraph 5-79 which gives a method for opening the ALC loop.

⑤ A procedure for checking the oscillator circuit is given in Paragraph 5-81.

⑥ FAIL if either (or both) supply is not present.

⑦ Check the dc voltage on the lamp (A2DSV1) at A2 Pin 5. With a larger than normal signal level in the Buffer Amplifier the voltage at A2 Pin 5 should be low, from 0 to +5V dc.

⑧ Check the dc voltage on the lamp (A2DSV1) at A2 Pin 5, normally this is +4 to +6V dc. If the voltage is less, then the lamp voltage is trying to increase the Buffer Amplifier signal level and the problem is in the Buffer Amplifier. If the voltage is greater, the lamp is causing the low signal in the Buffer Amplifier. The lamp is probably open if the voltage is higher than +15V dc.

————— NOTE —————

Momentary shorting of the +31 +31 V or - 26 V power supply may cause a Locked Current Limit condition if the power supplies are still loaded by the 654A circuitry. In the Locked Current Limit condition the dc output drops to less than 2 V and does not return to normal when the short is removed. This does not damage the power supplies. Proper power supply voltage can be restored by switching the instrument off and then on again.

⑨ If the positive power supply cannot be adjusted to +31 V, proceed as follows:

- a. Verify that the positive power supply is not in a current limit condition by disconnecting the power supply load A1 Pin 12 (+) and A1 Pin 13 (-).

————— NOTE —————

Turn AC power off while disconnecting the power supplies. A3 circuitry may be damaged if only one power supply is connected to it.

- b. If the +31 V power supply is restored by disconnecting the load circuitry, troubleshoot the load circuitry (Oscillator, Buffer Amplifier, Balanced Amplifier, Average Detector, Amplitude Control Integrator, and Meter Amplifier).
- c. If the +31 V power supply is not restored by disconnecting the load circuitry, troubleshoot the positive supply. Refer to schematic 4.

⑩ If the negative power supply cannot be adjusted to - 26 V, use the procedure given in step 10 to isolate the problem area.

⑪ Check T1 and the line filter components; also check A1Cr1 thru A1CR4, A1C14 and A1C15.

⑫ Check the dc voltages at the Balanced Amplifier output which should be 0 +/- .1V dc at the top of A2R74 and the bottom of A2R75 ('top' and 'bottom' are as viewed on Schematic No. 2).

⑬ Check for open lamp or resistor in the photo-resistor A2DSV1.

⑭ Troubleshoot the Amplitude Control Integrator (A3Q6 through A3Q9) including the Amplitude Current Reference and the lamp of the photo-resistor (A2DSV1).

⑮ Troubleshoot the Buffer Amplifier (A2Q8 thru A2Q10) also include the resistor of the photo-resistor, A2DSV1.

⑯ Check the ac signal level at the Balanced Amplifier output with an oscilloscope. The signal should be a sine-wave of 4 +/- .5V peak-to-peak at the top of A2R74 and at the bottom of A2R75, the two signals should be 180% out of phase with each other. Note that in the FAIL condition there are two possible paths.

⑰ Check the ac signal with an oscilloscope between the attenuators (S4) and C9 and C10, the signal at both points should be 3 +/- 1V peak-to-peak. If signal is not present, check C9, C10, A2R76 and A2R77.

Table 5-5. Front Panel Troubleshooting (See Paragraph 5-74)

| MONITOR † POINT INDICATIONS | MOST LIKELY TROUBLE AREAS | ACTION REQUIRED | | | | | | | | | |
|---|--|--|-----------------|----------------------------|---------------------------------------|-----------------------|-----------------------|-----------------------------|-------------------------------|--|---------------------------------------|
| $\bar{A} \bar{B} \bar{C}$ | Oscillator circuit or Power Supplies | Go to ① on troubleshooting tree. | | | | | | | | | |
| $\bar{A} \bar{B} C$ | Multiple troubles 1) Counter Emitter Follower 2) Meter circuits Average Detector | 1) Troubleshoot 2) Go to ⑱ on troubleshooting tree. | | | | | | | | | |
| $\bar{A} B \bar{C}$ | Multiple troubles 1) Counter Emitter Follower 2) Attenuators (S4) and/or Impedance switch (A4) | 1) Troubleshoot 2) Check all positions of attenuators and impedance switch. | | | | | | | | | |
| $\bar{A} B C$ | Counter Emitter Follower | Troubleshoot. | | | | | | | | | |
| $A \bar{B} \bar{C}$ | ALC Loop - consisting of Buffer and Balanced Amplifiers, Average Detector and ALC circuits | Go to ② on troubleshooting tree. | | | | | | | | | |
| $A \bar{B} C$ | Metering circuits (and Average Detector) | Go to ⑱ on troubleshooting tree. | | | | | | | | | |
| $A B \bar{C}$ | Attenuators (S4) and/or Impedance Switch (A4) | Check all positions of attenuator and impedance switch. | | | | | | | | | |
| OTHER TROUBLES | | | | | | | | | | | |
| Incorrect flatness or level | ALC Loop - consisting of Buffer and Balanced Amplifiers, Average Detector and ALC circuits | Go to ② on troubleshooting tree. | | | | | | | | | |
| No output only at certain frequencies | Oscillator calibration | Calibrate | | | | | | | | | |
| Incorrect frequency | Oscillator calibration | Calibrate | | | | | | | | | |
| <table border="0" style="width: 100%;"> <tr> <td style="width: 33%;">†COUNTER OUTPUT</td> <td style="width: 33%;">A = 0.1V rms into 50 ohms;</td> <td style="width: 33%;">\bar{A} = intermittent or no signal</td> </tr> <tr> <td>654A meter indication</td> <td>B = +1dBm or greater;</td> <td>\bar{B} = less than +1dBm</td> </tr> <tr> <td>Front panel output connectors</td> <td>C = approximately 0.8V rms into 50 ohms;</td> <td>\bar{C} = intermittent or no signal</td> </tr> </table> | | | †COUNTER OUTPUT | A = 0.1V rms into 50 ohms; | \bar{A} = intermittent or no signal | 654A meter indication | B = +1dBm or greater; | \bar{B} = less than +1dBm | Front panel output connectors | C = approximately 0.8V rms into 50 ohms; | \bar{C} = intermittent or no signal |
| †COUNTER OUTPUT | A = 0.1V rms into 50 ohms; | \bar{A} = intermittent or no signal | | | | | | | | | |
| 654A meter indication | B = +1dBm or greater; | \bar{B} = less than +1dBm | | | | | | | | | |
| Front panel output connectors | C = approximately 0.8V rms into 50 ohms; | \bar{C} = intermittent or no signal | | | | | | | | | |

- ⑱ Check the input signal to the Impedance networks A4 Pin 1 and A4 Pin 2, this should be 3 +/- 1V peak-to-peak when the attenuators are set at +10dBm. If the signal is not present, try all positions of the attenuators and the impedance switch.
- ⑲ Check the dc voltage at the collector of A2Q25 which should be from +6 to +8 volts.
- ⑳ Troubleshoot the Balanced Amplifier, A2Q11 through A2Q23 and associated components. If in

- step ⑫ the dc voltages were incorrect and were equal and opposite then the problem is probably in the differential amplifiers A2Q11 through A2Q16. If the dc voltages are incorrect but of the same polarity then the problem is probably in the feedback amplifier A2Q22, A2Q23 and A2Q17.
- ㉑ If the output signal is not present on A4 Pin 3 and (in the BAL modes of the IMPEDANCE switch) A4 Pin 4 then check the resistive networks on the A4 board. If it is present, check the cables to the output connectors J3 and J4.

- 22) Ensure that the problem is not in the cables before attempting to troubleshoot the attenuators.
- 23) Check with an oscilloscope, the ac signal from the detector amplifier at the collector of A2Q25. This should be a flattened sine-wave (see schematic 2) of about .8V peak-to-peak. Note that there are two possible paths for the FAIL mode.
- 24) Check the dc voltages at the outputs of the detector (A2 Pin 6 and A2 Pin 7), these should be 0 +/- .05V dc.
- 25) Troubleshoot the Meter Differential Amplifier (A3Q2 through A3Q5), the Meter (M1) and the Meter Offset Current Reference.
- 26) Check the detector diodes (A2CR21, A2CR22) and capacitors A2C40*, A2C41 and A2C44.
- 27) Check the Detector Amplifier A2Q24, A2Q25 and associated components.

5-78. TROUBLESHOOTING THE POWER SUPPLY.

NOTE

To protect the output capacitors C9 and C10 (rated 3 V), pull connectors off of pins 15 and 16 of the A2 board. Ensure that the dc voltages on pins 15 and 16 are near zero (<500 mV) before reconnecting the wires to C9 and C10. Available test points for power supply voltage:

+ 31 V at A1 pin 12, A2 pin 1, A3 pin 5;
- 26 V at A1 pin 13, A2 pin 2, A3 pin 4

WARNING

TURN OFF POWER BEFORE CONNECTING OR DISCONNECTING POWER SUPPLY LEADS.

5-79. Disconnect the power supply from the A2 and A3 boards. The pins are given in the preceding note. If the power supply voltages are still incorrect and cannot be adjusted, troubleshoot the power supply.

- a. After the power supply has proper voltages, turn off power and reconnect the power supply leads to A3, one at a time while monitoring the - 26 V. If the negative voltage loads down, then troubleshoot that specific board.
- b. Last, connect the power supply to the A2 board while monitoring the - 26 V. If - 26 V loads down,

turn off the power and lift one end of A2R20 and A2R25. If the - 26 V supply is satisfactory, troubleshoot the Oscillator. If the negative voltage is still loaded, troubleshoot the Buffer Amplifier, Balance Amplifier and Average Detector.

5-80. PROCEDURE.

- a. Lift one side of A2R33 to isolate the Wien Bridge Oscillator from the circuit.
- b. Lift the side of A2R38 which is connected to A2DSV1.
- c. Connect the signal generator with a large (at least 10 microfarad) non-polar capacitor in series to A2R38. The capacitor blocks any dc present on the signal generator output.

NOTE

If a large non-polar capacitor is not available, use two polarized capacitors in series, with their + ends connected together.

- d. Set the signal generator frequency to 1kHz and the output level to about .25V rms (monitor with an ac voltmeter).
- e. Signal trace the ALC loop. Signal levels, and voltages should correspond with those shown on the schematics.

5-81. TROUBLESHOOTING THE OSCILLATOR CIRCUIT.

NOTE

This procedure assumes that the front panel checks (Table 5-6) have been made and that the Troubleshooting Tree has been followed (together with the information in Paragraph 5-77) to branch ⑤

- a. If the signal at the junction of A2R22 and A2R23 is twice the normal amplitude then the Peak Detector is not operating. In particular check A2Q7 and A2C11.
- b. If A2C12 is close to the A2Q1 FET the oscillator could break into spurious oscillations above 100 kHz.
- c. If there is no signal at A2 Pin 4 isolate the Peak Detector by lifting one side of A2C11 and the emitter of A2Q7. If the oscillator comes on, check the Peak Detector components. If there is no apparent fault in the Peak Detector it is possible that A2R3 may be out of adjustment. To check this reconnect the peak detector, and perform the adjustment outlined in Paragraph 5-50.

- d. If the oscillator still cannot be made to operate perform the procedure of the following paragraphs.

5-82. In the following procedure the oscillator circuit is driven by an external signal generator and the Wien Bridge is disabled. This allows the circuit to be checked out using the normal troubleshooting techniques for an amplifier.

5-83. The recommended signal generator is a 652A or 651B (which has 50 ohms output impedance and a frequency range of 10Hz to 10MHz). If this is not available any oscillator with low output impedance and capable of driving up to 3V rms open circuit will suffice. In most cases it will not be essential to use the generator at frequencies over 1kHz.

- a. Turn off the power to the 654A.
- b. Disconnect the Buffer Amplifier and Counter Emitter-Follower by lifting the negative side of A2C12.
- c. Disconnect the Peak Detector by lifting one side of A2C11 and the emitter lead of A2Q7.
- d. Disable the RC tuning network of the Wien Bridge by disconnecting A2 Pins 8, 10 and 11.

- e. Connect the signal generator through a large capacitor (as described in Paragraph 5-80c and the note) to A2 Pin 10. Connect the ground side of the generator to A2 Pin 8.
- f. Turn the 654A power on. Set the signal generator frequency to 1kHz and the output to approximately 1V rms (monitor with an ac voltmeter on A2 Pin 10). Monitor the output signal with an oscilloscope on A2C12.

1) The amplifier has a voltage gain of approximately 2, therefore the output should be a sine wave of between 5 and 6V peak-to-peak.

2) If the signal does not appear at the output then troubleshoot the amplifier (A2Q1 through A2Q6 and associated circuitry) using normal troubleshooting techniques for an amplifier. A2Q5 and A2Q6 should be replaced as a pair if either has to be replaced.

3) When the amplifier is operating correctly check the frequency response, which should remain essentially flat between 10Hz and 10MHz, by sweeping the signal generator over that range while maintaining a constant input voltage on the green lead.

4) Reconnect A2C11 and A2Q7 to ensure that the Peak Detector does not disable the amplifier (if it does troubleshoot the Peak Detector). If the signal is still present at A2 Pin 5 then the

probable cause of trouble in the oscillator circuit is the FREQUENCY RANGE switch or associated components.

5-84. TROUBLESHOOTING THE BUFFER AMPLIFIER.

NOTE

AC output will be erroneous if the control voltage to DSV1 is the wrong value. This should be approximately 5 to 7 V dc.

5-85. The ac gain of the Buffer Amplifier should be 0.6 or less than 1. The dc voltage at A2R44 should be 0V \pm 150 mV and the ac voltage should be between 3 and 4 V p-p.

5-86. TROUBLESHOOTING THE BALANCED AMPLIFIER.

5-87. The balanced amplifier should have an ac gain of approximately two. The dc voltage at both sides of A2C32 should be near zero (\pm 300 mV) with one side positive and the other negative. The ac waveforms at each side of A2C32 should be equal in amplitude but 180° out of phase. The amplitude should be 6 to 7 V p-p.

- a. If the ac voltages are near equal and the dc voltages are of opposite polarity but not near zero and the amplitude control has little effect, then the trouble is probably in the feedback loop A2Q17, Q22 or Q23. This circuit holds A2C32 near zero.
- b. If the balanced amplifier output is clipped or distorted, replace A2Q17 with approximately 500 Ω resistor between emitter and collector, using pc board holes. If the balanced amplifier's output becomes a good sine wave, this indicates the Q17, Q22, Q23 loop is faulty. If not, the balanced amplifier differential pairs (Q11 thru Q21) are at fault.
- c. If A2C32 ac voltages are not approximately equal, the fault is probably in the differential pairs Q11 thru Q21.
- d. If the instrument will not pass its balance specifications check to see that A2R74 and R75 are the same value.

5-88. TROUBLE ISOLATION IN THE REMAINDER OF THE LEVELING LOOP.

5-89. The following check will determine if the trouble is in the Average Detector.

- a. The input of A2C40 should be 4 to 5.5 V dc and the ac signal should be 0.8 V p-p to 1.0 V p-p.

- b. AC waveshape should have the same wave shape as shown on Schematic No. 2. If you have a flatness problem, check the wave shape for symmetry and see if output capacitor C9 or C10 are leaking.

5-90. The following checks will determine if the trouble is in the Control Integrator or in the Meter Differential Amplifier.

NOTE

Disconnecting the outputs of A2CR21 and CR22 will cause the voltage readings to be incorrect.

- a. If A2CR21 is not zero \pm 20 mV, the trouble is in the Meter Differential Amplifier.
- b. If A2CR22 is not zero \pm 20 mV, the trouble is in the Control Integrator.

5-91. TROUBLESHOOTING THE AMPLITUDE CONTROL INTEGRATOR.

5-92. The Amplitude Control Integrator consists of A3Q6 thru A3Q9. The output is +5 V to +7 V dc. The output feeds back into the Photocell Module of the Buffer Amplifier. Check the resistance of the filament in the lamp. It should be approximately 40 Ω . The photocell should have approximately 1 k Ω to 2 k Ω resistance when a +5 V to +7 V dc is applied to the filament.

5-93. TROUBLESHOOTING THE ALC LOOP.

5-94. If the trouble is known to be in the ALC loop (Buffer and Balanced Amplifier and the Automatic Leveling Circuits) and cannot be isolated to a unit by the preceding paragraphs, then this method can be used to break open the loop. The Buffer Amplifier is then driven by an external signal generator (0.25 V rms at 1 kHz into 2.5 k Ω) and it can be checked as any amplifier.

- a. Lift one side of A2R33 to isolate the Wien Bridge Oscillator from the circuit.
- b. Lift the side of A2R38 which is connected to A2DSV1.
- c. Connect the signal generator with a large (at least 10 μ F) non-polar capacitor in series to A2R38. The capacitor blocks any dc present on the signal generator output.

NOTE

If a large non-polar capacitor is not available, use two polarized capacitors in series, with their + ends connected together.

- d. Set the signal generator frequency to 1 kHz and the output level to about .25 V rms (monitor with an ac voltmeter).

- e. Signal trace the ALC loop. Signal levels, and voltages should correspond with those shown on the schematics.

5-95. TROUBLESHOOTING THE METER DIFFERENTIAL AMPLIFIER.

5-96. The Meter Differential Amplifier is used for the meter in all functions. Use voltages on the schematic for locating the trouble. If the base of A3Q2 is not zero, the trouble could be in the offset current reference circuit.

5-97. TROUBLESHOOTING THE ATTENUATORS.

5-98. If either side of the attenuator is shorted to ground, remove the cover and make a physical check. The signal path is probably touching the metal case or cover. The contacts of the switches should be kept clean and lubricated (refer to CAUTION on Page 5-13 and Service Note M45B). For proper lubricant, use Electrolube 2A or Electrical Contact Lubricant, -hp- Part No. 6040-0300.

NOTE

In order for the attenuator to make specifications and ensure proper grounding, all mechanical connections must be *very* tight.

5-99. SERVICING ETCHED CIRCUIT BOARDS.

5-100. The Model 654A contains four plated-through, double-sided, etched circuit boards. When working on these boards, observe the following rules to prevent damage to the circuit board or components:

- a. Use a low-heat (25 to 50 watts) soldering iron with a small tip.
- b. To remove a component, clip a heat sink (long nose pliers, commercial heat sink tweezers, etc.) on the component lead as close to the component as possible. Place the soldering iron directly on the component lead, and pull up on the lead. If a component is obviously damaged or faulty, clip the leads close to the component, and remove the leads from the board.



EXCESSIVE OR PROLONGED HEAT CAN LIFT THE CIRCUIT FOIL FROM THE BOARD OR CAUSE DAMAGE TO COMPONENTS.

- c. Clean the component lead holes by heating the solder in the hole, quickly removing the soldering iron, and inserting a pointed, non-metallic object such as a toothpick.

levels, and
se shown on

DIFFEREN-

sed for the
chematic for
ot zero, the
circuit.

TORS.

d to ground,
.. The signal
cover. The
n and lubri-
Service Note
ube 2A or
0-0300.

ake
nd-
be

IS.

ed-through,
ing on these
damage to

ng iron with

t sink (long
ezers, etc.)
component
ectly on the
lead. If a
faulty, clip
remove the

AT
M
O

reating the
e soldering
allic object

- d. To mount a new component, shape the leads and insert them in the holes. Clip a heat sink on the component, heat with the soldering iron, and add solder as necessary to obtain a good electrical connection.

5-101. SERVICING ROTARY SWITCHES.

5-102. The Model 654A contains two rotary type switches: FREQUENCY RANGE and the ATTENUATOR. When working on these switches, observe the following rules:

- a. Use a low heat (25 to 50 watts) soldering iron with a small tip.
- b. When replacing components, attempt to dress them as nearly to their original alignment as possible.
- c. Clean excessive flux from the connection and adjoining area.
- d. After cleaning the switch, apply a light coat of lubricate to the switch detent balls. DO NOT apply lubricant to switch contacts or allow lubricant to contaminate components.

- e. To eliminate excessive contact wear and oxidation, the contacts may be lubricated with Electrolube 2G, -hp- Part No. 5060-6086. Only a very small amount of lubricant is necessary. Note: Electrolube 2G will change to a reddish brown color with time; however, the lubricating properties are not affected. A more detailed description on how to apply Electrolube 2G is available at no cost from your local Sales and Service Office. Ask for Service Note M45B.

5-103. SERVICING TUNER ASSEMBLY.

5-104. When replacing the tuning capacitor, C1, make certain that the tuner coupler and the frequency dial shaft are aligned to prevent binding of the FREQUENCY Dial or VERNIER control. If necessary, remove the frequency dial knob, frequency dial, and loosen the tuner drive assembly (casting and spur gears) retaining screws; then align tuner coupler and frequency dial shaft. Tighten retaining screws after tuner coupler and dial shaft are aligned.

NOTE

For correct alignment, refer to Frequency Dial Calibration, Paragraph 5-52.




Figure 5-17. Alignment Access Covers for Models 651B, 2A, 3A, 4A

PERFORMANCE CHECK TEST CARD

Hewlett-Packard Model 654A

Test Oscillator

Serial No. _____

Tests Performed By _____

Date _____

| DESCRIPTION | CHECK | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|--|--|-----------------------------|-------------------------------------|-----------------|-----------------|-----------------|----------------|--|---------------|--|---------------|--|---------------|--|---------------|--|-------------|--|-------------------------------------|--|----------------|--|---------|--|---------------|--|-------------|--|---------|--|---------------|--|-------------|--|-------------------------------------|--|----------------|--|---------|--|---------------|--|-------------|
| 1. FREQUENCY RANGE (Paragraph 5-7) | <table style="width: 100%; border: none;"> <tr> <td style="width: 50%; text-align: center;">10 Hz or less _____</td> <td style="width: 50%; text-align: center;">10 MHz or greater _____</td> </tr> </table> | 10 Hz or less _____ | 10 MHz or greater _____ | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 10 Hz or less _____ | 10 MHz or greater _____ | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 2. FREQUENCY ACCURACY (Paragraph 5-8) | <table style="width: 100%; border: none;"> <tr> <td style="width: 50%;">10 Hz to 100 Hz (X10 RANGE)</td> <td style="width: 50%; text-align: right;">+/-3% _____</td> </tr> <tr> <td>100 Hz to 5 MHz</td> <td style="text-align: right;">+/-2% _____</td> </tr> <tr> <td>5 MHz to 10 MHz</td> <td style="text-align: right;">+/-4% _____</td> </tr> </table> | 10 Hz to 100 Hz (X10 RANGE) | +/-3% _____ | 100 Hz to 5 MHz | +/-2% _____ | 5 MHz to 10 MHz | +/-4% _____ | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 10 Hz to 100 Hz (X10 RANGE) | +/-3% _____ | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 100 Hz to 5 MHz | +/-2% _____ | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 5 MHz to 10 MHz | +/-4% _____ | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 3. AMPLITUDE ACCURACY (Paragraphs 5-9 through 5-14) | <table style="width: 100%; border: none;"> <tr> <td style="width: 50%;"></td> <td style="width: 50%; text-align: center;">+10 dBm, +/-1% at 1 KHz</td> </tr> <tr> <td></td> <td style="text-align: right;">50 UNBAL _____</td> </tr> <tr> <td></td> <td style="text-align: right;">75 UNBAL _____</td> </tr> <tr> <td></td> <td style="text-align: right;">135 BAL _____</td> </tr> <tr> <td></td> <td style="text-align: right;">150 BAL _____</td> </tr> <tr> <td></td> <td style="text-align: right;">600 BAL _____</td> </tr> </table> | | +10 dBm, +/-1% at 1 KHz | | 50 UNBAL _____ | | 75 UNBAL _____ | | 135 BAL _____ | | 150 BAL _____ | | 600 BAL _____ | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | +10 dBm, +/-1% at 1 KHz | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | 50 UNBAL _____ | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | 75 UNBAL _____ | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | 135 BAL _____ | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | 150 BAL _____ | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | 600 BAL _____ | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 4. LEVEL FLATNESS (Paragraphs 5-15 through 5-20) | <table style="width: 100%; border: none;"> <tr> <td style="width: 50%;"></td> <td style="width: 50%; text-align: center;">+/-0.5% (referenced to 1 KHz level)</td> </tr> <tr> <td></td> <td style="text-align: center;">10 Hz to 10 MHz</td> </tr> <tr> <td></td> <td style="text-align: right;">50 UNBAL</td> </tr> <tr> <td></td> <td style="text-align: right;">+10 dBm _____</td> </tr> <tr> <td></td> <td style="text-align: right;">0 dBm _____</td> </tr> <tr> <td></td> <td style="text-align: right;">75 UNBAL</td> </tr> <tr> <td></td> <td style="text-align: right;">+10 dBm _____</td> </tr> <tr> <td></td> <td style="text-align: right;">0 dBm _____</td> </tr> <tr> <td></td> <td style="text-align: center;">+/-0.5% (referenced to 1 KHz level)</td> </tr> <tr> <td></td> <td style="text-align: center;">10 Hz to 5 MHz</td> </tr> <tr> <td></td> <td style="text-align: right;">135 BAL</td> </tr> <tr> <td></td> <td style="text-align: right;">+10 dBm _____</td> </tr> <tr> <td></td> <td style="text-align: right;">0 dBm _____</td> </tr> <tr> <td></td> <td style="text-align: right;">150 BAL</td> </tr> <tr> <td></td> <td style="text-align: right;">+10 dBm _____</td> </tr> <tr> <td></td> <td style="text-align: right;">0 dBm _____</td> </tr> <tr> <td></td> <td style="text-align: center;">+/-0.5% (referenced to 1 KHz level)</td> </tr> <tr> <td></td> <td style="text-align: center;">10 Hz to 1 MHz</td> </tr> <tr> <td></td> <td style="text-align: right;">600 BAL</td> </tr> <tr> <td></td> <td style="text-align: right;">+10 dBm _____</td> </tr> <tr> <td></td> <td style="text-align: right;">0 dBm _____</td> </tr> </table> | | +/-0.5% (referenced to 1 KHz level) | | 10 Hz to 10 MHz | | 50 UNBAL | | +10 dBm _____ | | 0 dBm _____ | | 75 UNBAL | | +10 dBm _____ | | 0 dBm _____ | | +/-0.5% (referenced to 1 KHz level) | | 10 Hz to 5 MHz | | 135 BAL | | +10 dBm _____ | | 0 dBm _____ | | 150 BAL | | +10 dBm _____ | | 0 dBm _____ | | +/-0.5% (referenced to 1 KHz level) | | 10 Hz to 1 MHz | | 600 BAL | | +10 dBm _____ | | 0 dBm _____ |
| | +/-0.5% (referenced to 1 KHz level) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | 10 Hz to 10 MHz | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | 50 UNBAL | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | +10 dBm _____ | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | 0 dBm _____ | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | 75 UNBAL | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | +10 dBm _____ | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | 0 dBm _____ | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | +/-0.5% (referenced to 1 KHz level) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | 10 Hz to 5 MHz | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | 135 BAL | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | +10 dBm _____ | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | 0 dBm _____ | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | 150 BAL | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | +10 dBm _____ | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | 0 dBm _____ | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | +/-0.5% (referenced to 1 KHz level) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | 10 Hz to 1 MHz | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | 600 BAL | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | +10 dBm _____ | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | 0 dBm _____ | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 5. METER TRACKING ACCURACY (Paragraph 5-21) | <table style="width: 100%; border: none;"> <tr> <td style="width: 50%;"></td> <td style="width: 50%; text-align: right;">+/-0.05 dB _____</td> </tr> </table> | | +/-0.05 dB _____ | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | +/-0.05 dB _____ | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |

PERFORMANCE CHECK TEST CARD (CONT'D)

| | | 1st HALF | 2nd HALF |
|--|--|---|---|
| <p>6. ATTENUATOR ACCURACY (Paragraphs 5-22 through 5-27)</p> | <p>10 dB/STEP 300 KHz +/-0.15 dB, all positions</p> <p>10 MHz +/-0.15 dB, +10 through -60 dB +/-1 dB, -70 and -80 dB</p> <p>1 dB/STEP 300 KHz +/-0.15 dB, all positions</p> <p>10 MHz +/-0.15 dB all positions</p> | <p>_____</p> <p>_____</p> <p>_____</p> <p>_____</p> | <p>_____</p> <p>_____</p> <p>_____</p> <p>_____</p> |
| <p>7. BALANCE (Paragraphs 5-28 through 5-34)</p> | <p>Greater than 50 dB 10 Hz to 1 MHz</p> <p>135 BAL 150 BAL 600 BAL</p> <p>Greater than 40 dB 1 MHz to 5 MHz</p> <p>135 BAL 150 BAL 600 BAL</p> | <p>_____</p> <p>_____</p> <p>_____</p> | <p>_____</p> <p>_____</p> <p>_____</p> |
| <p>8. DISTORTION (Paragraph 5-35)</p> | <p>Greater than 40 dB below fundamental 10 Hz to 1 MHz</p> <p>Greater than 34 dB below fundamental 1 MHz to 10 MHz</p> | <p>_____</p> <p>_____</p> | <p>_____</p> <p>_____</p> |
| <p>9. HUM AND NOISE (Paragraph 5-36)</p> | <p>Greater than 70 dB below full output (+11 dBm)</p> | <p>_____</p> | <p>_____</p> |
| <p>10. COUNTER OUTPUT (Paragraph 5-37)</p> | <p>Greater than 0.1V rms into 50 ohms, 10 Hz to 10 MHz</p> | <p>_____</p> | <p>_____</p> |

SECTION VI REPLACEABLE PARTS

6-1. INTRODUCTION.

6-2. This section contains information for ordering replacement parts. Table 6-1 lists parts in alphameric order of their reference designators and indicates the description, -hp- part number of each part, together with any applicable notes, and provides the following:

- a. Total quantity used in the instrument (TQ column). The total quantity of a part is given the first time the part number appears.
- b. Description of the part. (See list of abbreviations below.)
- c. Typical manufacturer of the part in a five-digit code. (See Appendix A for list of manufacturers.)
- d. Manufacturer's part number.

6-3. Figures 6-1 and 6-2 illustrate the replaceable mechanical parts used in the 654A. Miscellaneous parts are listed at the end of Table 6-1.

6-4. ORDERING INFORMATION.

6-5. To obtain replacement parts, address order or inquiry to your local Hewlett-Packard Field Office. (See Appendix B for list of office locations.) Identify parts by their Hewlett-Packard part numbers.

6-6. NON-LISTED PARTS.

6-7. To obtain a part that is not listed, include:

- a. Instrument model number.
- b. Instrument serial number.
- c. Description of the part.
- d. Function and location of the part.

| Abbreviations | | Prefix | | Multiplier | | | |
|------------------|---|--------|----------|------------------|-------|---|-------------------|
| Ag | silver | tera | T | 10 ¹² | centi | c | 10 ⁻² |
| Al | aluminum | giga | G | 10 ⁹ | milli | m | 10 ⁻³ |
| A | ampere(s) | mega | M or Meg | 10 ⁶ | micro | μ | 10 ⁻⁶ |
| Au | gold | kilo | K or k | 10 ³ | nano | n | 10 ⁻⁹ |
| C | capacitor | hecto | h | 10 ² | pico | p | 10 ⁻¹² |
| cer | ceramic | deka | da | 10 | femto | f | 10 ⁻¹⁵ |
| coef | coefficient | deci | d | 10 ⁻¹ | atto | a | 10 ⁻¹⁸ |
| com | common | | | | | | |
| comp | composition | | | | | | |
| conn | connection | | | | | | |
| dep | deposited | | | | | | |
| DPDT | double pole double-throw | | | | | | |
| DPST | double pole single-throw | | | | | | |
| elect | electrolytic | | | | | | |
| encap | encapsulated | | | | | | |
| F | farad(s) | | | | | | |
| FET | field effect transistor | | | | | | |
| fxd | fixed | | | | | | |
| GaAs | gallium arsenide | | | | | | |
| GHz | gigahertz = 10 ⁹ hertz | | | | | | |
| gd | guarded | | | | | | |
| Ge | germanium | | | | | | |
| gnd | grounded | | | | | | |
| H | henry (ies) | | | | | | |
| Hg | mercury | | | | | | |
| Hz | hertz (cycle(s) per second) | | | | | | |
| ID | inside diameter | | | | | | |
| impq | impregnated | | | | | | |
| incd | incandescent | | | | | | |
| ins | insulation(ies) | | | | | | |
| kΩ | kilohm(s) = 10 ³ ohms | | | | | | |
| kHz | kilohertz = 10 ³ hertz | | | | | | |
| L | inductor | | | | | | |
| lin | linear taper | | | | | | |
| log | logarithmic taper | | | | | | |
| mA | milliampere(s) = 10 ⁻³ amperes | | | | | | |
| MHz | megahertz = 10 ⁶ hertz | | | | | | |
| MΩ | megohm(s) = 10 ⁶ ohms | | | | | | |
| met flm | metal film | | | | | | |
| mfr | manufacturer | | | | | | |
| ms | millisecond | | | | | | |
| mtg | mounting | | | | | | |
| mV | millivolt(s) = 10 ⁻³ volts | | | | | | |
| μF | microfarad(s) | | | | | | |
| μs | microsecond(s) | | | | | | |
| μV | microvolt(s) = 10 ⁻⁶ volts | | | | | | |
| my | Mylar® | | | | | | |
| nA | nanampere(s) = 10 ⁻⁹ amperes | | | | | | |
| NC | normally closed | | | | | | |
| Ne | neon | | | | | | |
| NO | normally open | | | | | | |
| NPO | negative positive zero (zero temperature coefficient) | | | | | | |
| ns | nanosecond(s) = 10 ⁻⁹ seconds | | | | | | |
| nsr | not separately replaceable | | | | | | |
| Ω | ohm(s) | | | | | | |
| obd | order by description | | | | | | |
| OD | outside diameter | | | | | | |
| p | peak | | | | | | |
| pA | picoampere(s) | | | | | | |
| pc | printed circuit | | | | | | |
| pF | picofarad(s) = 10 ⁻¹² farads | | | | | | |
| piv | peak inverse voltage | | | | | | |
| p/o | part of | | | | | | |
| pos | position(s) | | | | | | |
| poly | polystyrene | | | | | | |
| pot | potentiometer | | | | | | |
| p-p | peak-to-peak | | | | | | |
| ppm | parts per million | | | | | | |
| prec | precision (temperature coefficient, long term stability and/or tolerance) | | | | | | |
| R | resistor | | | | | | |
| Rh | rhodium | | | | | | |
| rms | root mean square | | | | | | |
| rot | rotary | | | | | | |
| Se | selenium | | | | | | |
| sct | section(s) | | | | | | |
| Si | silicon | | | | | | |
| sl | slide | | | | | | |
| SPDT | single pole double throw | | | | | | |
| SPST | single pole single throw | | | | | | |
| Ta | tantalum | | | | | | |
| TC | temperature coefficient | | | | | | |
| TiO ₂ | titanium dioxide | | | | | | |
| tog | toggle | | | | | | |
| tol | tolerance | | | | | | |
| trim | trimmer | | | | | | |
| TSTR | transistor | | | | | | |
| V | volt(s) | | | | | | |
| vacw | alternating current working voltage | | | | | | |
| var | variable | | | | | | |
| vdcw | direct current working voltage | | | | | | |
| W | watt(s) | | | | | | |
| w/ | with | | | | | | |
| wiv | working inverse voltage | | | | | | |
| w/o | without | | | | | | |
| ww | wirewound | | | | | | |

| Prefix | Symbols | Multiplier | Prefix | Symbols | Multiplier |
|--------|----------|------------------|--------|---------|-------------------|
| tera | T | 10 ¹² | centi | c | 10 ⁻² |
| giga | G | 10 ⁹ | milli | m | 10 ⁻³ |
| mega | M or Meg | 10 ⁶ | micro | μ | 10 ⁻⁶ |
| kilo | K or k | 10 ³ | nano | n | 10 ⁻⁹ |
| hecto | h | 10 ² | pico | p | 10 ⁻¹² |
| deka | da | 10 | femto | f | 10 ⁻¹⁵ |
| deci | d | 10 ⁻¹ | atto | a | 10 ⁻¹⁸ |

| Designators | | Prefix | Symbols | Multiplier |
|-------------|---|--------|---|------------|
| A | assembly | FL | filter | |
| B | motor | HR | heater | |
| BT | battery | IC | integrated circuit | |
| C | capacitor | J | jack | |
| CR | capacitor | K | relay | |
| DL | diode | L | inductor | |
| DS | delay line | M | meter | |
| E | misc electronic part | MP | mechanical part | |
| F | fuse | P | plug | |
| Q | transistor | Q | transistor | |
| QCR | transistor-diode | QCR | transistor-diode | |
| R | resistor | R | resistor | |
| RT | thermistor | RT | thermistor | |
| S | switch | S | switch | |
| T | transformer | T | transformer | |
| TB | terminal board | TB | terminal board | |
| TC | thermocouple | TC | thermocouple | |
| TP | test point | TP | test point | |
| TS | terminal strip | TS | terminal strip | |
| U | microcircuit | U | microcircuit | |
| V | vacuum tube, neon bulb, photocell, etc. | V | vacuum tube, neon bulb, photocell, etc. | |
| W | cable | W | cable | |
| X | socket | X | socket | |
| XDS | larepholder | XDS | larepholder | |
| XF | fuseholder | XF | fuseholder | |
| Y | crystal | Y | crystal | |
| Z | network | Z | network | |

STD-B 2734

Table 6-1. Replaceable Parts (Cont'd)

| REFERENCE DESIGNATOR | -hp- PART NO. | TQ | DESCRIPTION | MFR. | MFR. PART NO. |
|----------------------|---------------|----|---|-------|--------------------|
| A1 | 00653-66507 | | PC BOARD: POWER SUPPLY | 28480 | 00653-66507 |
| A1C3 | 0140-0177 | | C: fxd 400 pF \pm 1% 300 vdcw | 72136 | DM15F401F0300WV1CR |
| A1C6 | 0180-0230 | | C: fxd 1 μ F \pm 20% 50 vdcw | 56289 | 150D105X0050A2 |
| A1C14, 15 | 0150-0052 | | C: fxd A1 elect .05 μ F +75% - 10% 400 vdcw | 28480 | 0150-0052 |
| A1C17 | 0180-0230 | | C: fxd 1 μ F \pm 20% 50 vdcw | 56289 | 150D105X0050A2 |
| A1C18 | 0140-0149 | | C: fxd 470 pF \pm 5% 300 vdcw | 72136 | DM15F471J0300WV1CR |
| A1C19 | 0180-0161 | | C: fxd 3.3 μ F \pm 20% 35 vdcw | 56289 | 150D335X003582 |
| A1C20 | 0180-1746 | | C: fxd 15 μ F \pm 10% 20 vdcw | 56289 | 150D156X902082 |
| A1C21 | 0180-0161 | | C: fxd 3.3 μ F \pm 20% 35 vdcw | 56289 | 150D335X003582 |
| A1C23, A1C24 | 0150-0084 | | C: fxd .1 μ F +80%, - 20% 100 vdcw | 28480 | 0150-0084 |
| A1CR1 thru A1CR4 | 1901-0158 | | Diode: Si | 04713 | SR1258-3 obd |
| A1CR5, CR6 | 1901-0040 | | Diode: Si 50 mA 30 V | 28480 | 1901-0040 |
| A1CR11 | 1902-0777 | | Diode: TC REF | 04713 | 1N825 |
| A1CR12, CR13 | 1901-0040 | | Diode: Si 50 mA 30 V | 28480 | 1901-0040 |
| A1CR14 | 1902-0184 | | Diode: bkdn 16.2 V | 28480 | 1902-0184 |
| A1CR15 | 1901-0040 | | Diode: Si 50 mA 30 V | 28480 | 1901-0040 |
| A1CR16 | 1902-0777 | | Diode: TC REF | 04713 | 1N825 |
| A1CR17-A1CR19 | 1901-0040 | | Diode: Si 50 mA 30 V | 28480 | 1901-0040 |
| A1CR20 | 1902-0777 | | Diode: TC REF | 04713 | 1N825 |
| A1CR22 | 1902-0184 | | Diode: Bkdn 16.2 V | 28480 | 1902-0184 |
| A1CR23 | 1901-0040 | | Diode: Si 50 mA 30 V | 28480 | 1901-0050 |
| A1CR24 | 1902-0184 | | Diode: Bkdn 16.2 V | 28480 | 1902-0184 |
| A1CR25 | 1901-0040 | | Diode: Si 50 mA 30 V | 28480 | 1901-0040 |
| A1CR26 | 1902-3190 | | Diode: Bkdn 13 V | 04713 | SZ10939-215 |
| A1Q1 | | | Not assigned | | |
| A1Q2 | 1853-0037 | 3 | Tstr: NPN | 28480 | 1853-0037 |
| A1Q3 thru Q5 | 1854-0474 | 3 | Tstr: Si PNP | 28480 | 1854-0474 |
| A1Q6, Q7 | 1853-0037 | | Tstr: Si PNP | 28480 | 1853-0037 |
| A1R1 | 0757-0403 | 2 | R: fxd comp 121 Ω \pm 1% 1/8W | 24546 | C4-1/8-To-121-R-F |
| A1R3 | 0683-3035 | 2 | R: fxd comp 30K \pm 5% 1/4W | 01121 | CB3035 |
| A1R4 | 0757-0440 | 2 | R: fxd comp 7.5K \pm 1% 1/8W | 24546 | C4-1/8-To-7501-F |
| A1R5 | 0698-4450 | 2 | R: fxd comp 324 Ω \pm 1% 1/8 W | 24546 | C4-1/8-To-324R-F |
| A1R6 | 0683-0395 | 4 | R: fxd comp 3.9 Ω \pm 5% 1/4W | 01121 | CB0395 |
| A1R7 | 0683-4715 | 2 | R: fxd comp 470 Ω \pm 5% 1/4W | 01121 | CB4715 |
| A1R8 | 0683-1835 | 1 | R: fxd comp 18K \pm 5% 1/4W | 01121 | CB1835 |
| A1R9 | 0757-0436 | 2 | R: fxd comp 4.32K \pm 1% 1/8W | 24546 | C4-1/8-To-4321-F |
| A1R10 | 0757-0279 | 1 | R: fxd comp 3.16K \pm 1% 1/8W | 24546 | C4-1/8-To-3161-F |
| A1R11 | 0757-0451 | 2 | R: fxd comp 24.3 k Ω \pm 1% 1/8W | 24546 | C4-1/8-To-2432-F |
| A1R12 | 0698-4445 | 2 | R: fxd 5.76K \pm 1% 1/8W | 16299 | C4-1/8-To-5761-F |
| A1R13 | 0757-0403 | | R: fxd comp 121 Ω \pm 1% 1/8W | 24546 | C4-1/8-To-121R-F |
| A1R18 | 0698-4888 | | R: fxd 1180 Ω \pm 1% 1/8W | 24546 | NA6 |
| A1R19 | 0698 4405 | | R: 107 Ω 1% 1/8W | 16299 | C4-1/8-To-107R-F |
| A1R20 | 0757-0280 | | R: 1K 1% 1/8W | 24546 | C4-1/8-To-1001-F |
| A1R29 | 0698-4484 | 1 | R: fxd comp 19.1K \pm 1% 1/8W | 24546 | C4-1/8-To-1912-F |
| A1R30 | 0698-4445 | | R: fxd 5.76K \pm 1% 1/8W | 16299 | C4-1/8-To-5761-F |
| A1R31 | 0698-4435 | 1 | R: fxd comp 2.49K \pm 1% 1/8W | 16299 | C4-1/8-To-2491-F |
| A1R32 | 0757-0436 | | R: fxd comp 4.32 K \pm 1% 1/8W | 24546 | C4-1/8-To-4321-F |
| A1R33 | 0683-0395 | | R: fxd comp 3.9 Ω \pm 5% 1/4W | 01121 | CB0395 |
| A1R34 | 0683-4715 | | R: fxd comp 470 Ω \pm 5% 1/4W | 01121 | CB4715 |
| A1R35 | 0698-4450 | | R: fxd comp 324 Ω \pm 1% 1/8W | 24546 | C4-1/8-To-324R-F |
| A1R36 | 0757-0440 | | R: fxd comp 7.5K \pm 1% 1/8W | 24546 | C4-1/8-To-7501-F |
| A1R37 | 0683-1535 | | R: fxd comp 15 k Ω \pm 5% 1/4W | 01121 | CB1535 |
| A1R38 | 0683-3035 | | R: fxd comp 30K \pm 5% 1/4W | 01121 | CB3035 |
| A1R39 | 0761-0024 | | R: fxd comp 2.4K \pm 5% 1 W | 24546 | FP32-1-To-2401-J |
| A1R40, R41 | 2100-3211 | 2 | R: var 1K \pm 10% | 28480 | 2100-3211 |
| A1R42, R43 | 0683-0395 | | R: fxd comp 3.9 Ω \pm 5% 1/4W | 01121 | CB0395 |
| A1U1, U2 | 1826-0043 | 2 | IC: OP AMP | 27014 | LM307H |
| | 1200-0437 | 2 | Socket: IC | 17117 | 7009-265-5 |

Table 6-1. Replaceable Parts

| NO. | REFERENCE DESIGNATOR | -hp- PART NO. | TQ | DESCRIPTION | MFR | MFR. PART NO. |
|------------|----------------------|---------------|----|--|-------|--------------------|
| WV1CR 2 | | | | | | |
| 2 | | | | | | |
| WV1CR | | | | | | |
| 2 | | | | | | |
| 2 | | | | | | |
| 2 | | | | | | |
| | A2 | 00654-66502 | 1 | PC board: main, oscillator and output | -hp- | |
| | C1 | 0121-0421 | 2 | C: var 2 10 pF | 000LC | 5640/10-PC |
| | C2 | 0150-0084 | 8 | C: fxd cer 0.1 uF +80% -20% 100 vdcw | 72982 | 8131-100-651-104Z |
| | C3 | 0180-1792 | 1 | C: fxd Al 2900 uF +75% -10% 3 vdcw | 56289 | 39D298G003G14-DSB |
| | C4 | 0180-0228 | 1 | C: fxd Ta 22 uF +/-10% 15 vdcw | 56289 | 150D226X9015B2-DYS |
| | C5 | 0180-0063 | 2 | C: fxd Al 500 uF +75% -10% 3 vdcw | 56289 | 30D507G003DF2-DSM |
| | C6,C7 | | | Not assigned | | |
| | C8* | 0140-0202 | 1 | C: fxd mica 15 pF +/-5% | 72136 | RDM15C150J5C |
| | C9,C10 | 0150-0084 | 1 | C: fxd cer 0.1 uF +80% -20% 100 vdcw | 72982 | 8131-100-651-104Z |
| | C11,C12 | 0180-0039 | 2 | C: fxd Al 100 uF +75% -10% 12 vdcw | 56289 | 30D107G012CC2-DSM |
| | C13 | 0180-0101 | 1 | C: fxd Ta 1.8 uF +/-10% 35 vdcw | 56289 | 150D185X9035B2-DYS |
| | C14 | | | Not assigned | | |
| | C15 | 0150-0022 | 2 | C: fxd TiO ₂ 3.3 pF +/-10% 500 vdcw | 78488 | Type GA obd |
| | C16 | 0160-2206 | 1 | C: fxd mica 160 pF +/-5% | 72136 | RDM15F161J3C |
| | C17 | 0150-0093 | 12 | C: fxd cer 0.01 uF +80% -20% 100 vdcw | 91418 | TA obd |
| | C18 | 0150-0022 | 1 | C: fxd TiO ₂ 3.3 pF +/-5% | 78488 | Type GA obd |
| | C19 | 0150-0093 | 1 | C: fxd cer 0.01 uF +80% -20% 100 vdcw | 91418 | TA obd |
| | C20 | 0150-0084 | 2 | C: fxd cer 0.1 uF +80% -20% 100 vdcw | 72982 | 8131 100 651 104Z |
| | C21* | 0150-0046 | 1 | C: fxd TiO ₂ 0.68 pF +/-5% 500 vdcw | 78488 | Type GA obd |
| | C22 | 0160-2197 | 1 | C: fxd mica 10 pF +/-5% | 72136 | RDM15C100J3C |
| | C23 | 0140-0145 | 1 | C: fxd mica 22pF +/-5% | 72136 | RDM15C220J5C |
| | C24 | 0160-2204 | 2 | C: fxd mica 100 pF +/-5% | 72136 | RDM15F101J3C |
| | C25 | 0150-0084 | 1 | C: fxd cer 0.1 uF +80% -20% 100 vdcw | 72982 | 8131 100-651-104Z |
| | C26 thru C29 | 0160-2605 | 4 | C: fxd cer 0.02 uF +80% -20% 25 vdcw | 72982 | 5835Y5U203Z |
| | C30,C31 | 0150-0093 | 1 | C: fxd cer 0.01 uF +80% -20% 100 vdcw | 91418 | TA obd |
| | C32 | 0121-0162 | 1 | C: var 1.2-3.5 pF | 74970 | 189 351-5 |
| | C33 thru C35 | 0150-0093 | 1 | C: fxd cer 0.01 uF +80% -20% 100 vdcw | 91418 | TA obd |
| | C36* | 0150-0046 | 1 | C: fxd TiO ₂ 0.68 pF +/-5% 500 vdcw | 78488 | Type GA obd |
| | C37 | | | Not assigned | | |
| | C38 | 0160-3431 | 1 | C: fxd cer 6.8 pF +/-5% 500 vdcw | 72982 | 301-000-S380689D |
| | C39 | | | Not assigned | | |
| | C40* | 0180-2176 | 1 | C: fxd Ta 180 uF +/-20% 10 vdcw | 56289 | 109D187X0010F2-DYP |
| | C41 | 0180-0137 | 2 | C: fxd Ta 100 uF +/-20% 10 vdcw | 37942 | TAS107M010P1F |
| | C42 | 0180-0689 | 1 | C: fxd Ta 270 uF +/-20% 30 vdcw | | 109D277X0015T2 |
| | C43 | 0121-0421 | | C: var 2-10 pF | 000LC | 5640/10/PC |
| | C44 | 0180-0137 | | C: fxd Ta 100 uF +/-20% 10 vdcw | 37942 | TAS107M010P1F |
| | C45,C46 | 0150-0084 | | C: fxd cer 0.1 uF +80% -20% 100 vdcw | 72982 | 8131-100-651-104Z |

Table 6-1. Replaceable Parts (Cont'd)

| REFERENCE DESIGNATOR | -hp- PART NO. | TQ | DESCRIPTION | MFR. | MFR PART NO | |
|----------------------|---------------|----|---|-------|----------------|-----|
| A2 (Cont'd) | | | | | | |
| CR1, CR2 | 1910-0016 | 2 | Diode. Ge 60 wiv 1 ms | 93332 | Q2361 | |
| CR3 | 1901-0025 | | Diode. Si 100 mA at +1V 100 piv 12 pF | 07933 | RD1526 | |
| CR4 | 1902-3182 | 2 | Diode: breakdown 12.1V +/-5% 400 mW | 04713 | SZ10939-206 | |
| CR5 | 1902-0045 | 2 | Diode: breakdown 7.32V +/-2% 400 mW | 04713 | SZ10939-144 | |
| CR6 | 1902-3237 | 2 | Diode: breakdown 20V +/-5% 400 mW | 04713 | SZ10939-269 | |
| CR7 thru CR11 | 1901-0025 | | Diode. Si 100 mA at +1V 100 piv 12 pF | 07933 | RD1526 | |
| CR12 | 1902-0057 | 3 | Diode: breakdown 6.49V +/-5% 400 mW | 04713 | SZ10939-128 | |
| CR13 | 1902-3259 | 1 | Diode: breakdown 24.3V +/-5% 400 mW | 04713 | SZ10939-293 | |
| CR14 | 1902-0025 | 1 | Diode: breakdown 10V +/-5% 400 mW | 04713 | SZ10930-182 | |
| CR15 thru CR18 | 1901-0025 | | Diode. Si 100 mA at +1V 100 piv 12 pF | 07933 | RD1526 | |
| CR19 | 1902-0766 | 1 | Diode: breakdown 18.2V +/-5% 400 mW | 04713 | SZ10939-257 | |
| CR20 | 1902-0045 | | Diode: breakdown 7.32V +/-2% 400 mW | 04713 | SZ10939-144 | |
| CR21, CR22 | 1901-0347 | 3 | Diode: Si hot carrier 20 mA 1.5 pF 8 vdcw | hp | | |
| CR23 | 1902-0041 | 1 | Diode: breakdown 5.11V +/-5% 400 mW | 04713 | SZ10939-98 | |
| CR24 | 1902-3182 | | Diode: breakdown 12.1V +/-5% 400 mW | 04713 | SZ10939-206 | |
| CR25 | 1902-0222 | | Diode: Zener 14V 5% | 04713 | SZ1521-98 | |
| CR26 | 1902-0554 | | Diode: Zener 10V 5% | -hp- | | |
| DSV1 | 1990-0082 | 1 | Lamp: photocell module | 03911 | CLM5012 | |
| L1 thru L3 | 9170-0016 | 4 | Bead: ferrite | 02114 | 56-590 65A1/3B | |
| Q1 | 1855-0081 | 1 | TSTR. FET N-channel type A 2N5245 | 01295 | | obd |
| Q2 | 1854-0215 | 10 | TSTR: Si NPN 2N3904 | 04713 | SPS3611 | |
| Q3 | 1853-0036 | | TSTR: Si PNP 2N3906 | 04713 | SPS3612 | |
| Q4 | 1854-0233 | 2 | TSTR: Si NPN 2N3866 | 02735 | | obd |
| Q5 | 1854-0053 | 3 | TSTR: Si NPN 2N2218 | 04713 | 2N2218 | |
| Q6 | 1853-0012 | 3 | TSTR: Si PNP 2N2904A | 04713 | 2N2904A | |
| Q7 thru Q9 | 1854-0215 | | TSTR: Si NPN 2N3904 | 04713 | SPS3611 | |
| Q10 | 1853-0036 | | TSTR: Si PNP 2N3906 | 04713 | SPS3612 | |
| Q11, Q12 | 1854-0092 | 2 | TSTR: Si NPN 2N3563 | 04713 | MPS3563 | |
| Q13, Q14 | 1853-0034 | 2 | TSTR: Si PNP | 04713 | SM3197 | |
| Q15, Q16 | 1854-0215 | | TSTR: Si NPN 2N3904 | 04713 | SPS3611 | |
| Q17 | 1854-0233 | | TSTR: Si NPN 2N3866 | 02735 | | obd |
| Q18 | 1854-0053 | | TSTR: Si NPN 2N2218 | 04713 | 2N2218 | |
| Q19 | 1853-0012 | | TSTR: Si PNP 2N2904A | 04713 | 2N2904A | |
| Q20 | 1854-0053 | | TSTR: Si NPN 2N2218 | 04713 | 2N2218 | |
| Q21 | 1853-0012 | | TSTR: Si PNP 2N2904A | 04713 | 2N2904A | |
| Q22, Q23 | 1853-0015 | | TSTR: Si PNP 2N3640 | 04713 | MPS3460-5 | |
| Q24 | 1854-0215 | | TSTR: Si NPN 2N3904 | 04713 | SPS3611 | |
| Q25 | 1854-0296 | 1 | TSTR: Si NPN | 04713 | MPS6543 | |
| Q26 | 1853-0036 | | TSTR: Si PNP 2N3906 | 04713 | SPS3612 | |
| R1 | 0757-0430 | 1 | R: fxd met flm 2210 ohms +/-1% 1/8 W | 91637 | MF-1/10-32 | obd |
| R2 * | 0698-4430 | 1 | R: fxd met flm 1910 ohms +/-1% 1/8 W | 91637 | MF-1/10-32 | obd |
| R3 | 2100-1984 | 2 | R: var 100 ohm +/-10% 1/2 W | 73138 | 62PR100 | |
| R4 | 2100-2604 | 1 | R: var 50 ohms +/-10% 1/2 W | 01121 | Type SV5001 | |
| R5 | 0757-0401 | 6 | R: fxd met flm 100 ohms +/-1% 1/8 W | 91637 | MF-1/10-32 | obd |
| R6, R7 | 0683-0275 | 4 | R: fxd comp 2.7 ohms +/-5% 1/4 W | 01121 | CB27C5 | |
| R8 | 0683-0035 | 1 | R: fxd comp 10 kilohms +/-5% 1/4 W | 01121 | CB1035 | |
| R9 * | 0698-3158 | 1 | R: fxd met flm 23.7 kilohms +/-1% 1/8 W | 91637 | MF-1/10-32 | obd |
| R10 | 0757-0280 | 7 | R: fxd met flm 1000 ohms +/-1% 1/8 W | 91637 | MF-1/10-32 | obd |
| R11 | 0698-3279 | 3 | R: fxd met flm 4.99 kilohms +/-1% 1/8 W | 91637 | MF-1/10-32 | obd |
| R12 | 0698-3558 | 3 | R: fxd met flm 4020 ohms +/-1% 1/8 W | 91637 | MF-1/10-32 | obd |
| R13 | 0757-0449 | 1 | R: fxd met flm 20 kilohms +/-1% 1/8 W | 91637 | MF-1/10-32 | obd |
| R14 | 0698-4453 | 1 | R: fxd met flm 402 ohms +/-1% 1/8 W | 35009 | CEA | obd |
| R15 | 0757-0283 | 6 | R: fxd met flm 2000 ohms +/-1% 1/8 W | 14674 | C4 | obd |
| R16 | | | Not assigned | | | |
| R17 | 0757-0384 | 3 | R: fxd met flm 20 ohms +/-1% 1/8 W | 91637 | MF-1/10-32 | obd |
| R18 | 0683-9105 | 1 | R: fxd comp 91 ohms +/-5% 1/4 W | 01121 | CB9105 | |
| R19 | 0698-3639 | 1 | R: fxd met oxide 1200 ohms +/-5% 2 W | 14674 | C42S | |
| R20 | 0683-1005 | 2 | R: fxd comp 10 ohms +/-5% 1/4 W | 01121 | CB1005 | |
| R21 | 0683-3005 | 1 | R: fxd comp 30 ohms +/-5% 1/4 W | 01121 | CB3005 | |
| R22, R23 | 0757-0346 | 6 | R: fxd met flm 10 ohms +/-1% 1/8 W | 91637 | MF-1/10-32 | obd |
| R24 | 0683-0275 | | R: fxd comp 2.7 ohms +/-5% 1/4 W | 01121 | CB27G5 | |
| R25 | 0683-1005 | | R: fxd comp 10 ohms +/-5% 1/4 W | 01121 | CB1005 | |
| R26 | 0757-0280 | | R: fxd met flm 1000 ohms +/-1% 1/8 W | 91637 | MF-1/10-32 | obd |

Table 6-1. Replaceable Parts (Cont'd)

| NO. | REFERENCE DESIGNATOR | -hp- PART NO. | TQ | DESCRIPTION | MFR. | MFR. PART NO. |
|-----|----------------------|--------------------|----|---|-------|-------------------|
| | A2 (Cont'd) | | | | | |
| | R27 | 0683-4705 | 1 | R: fxd comp 47 ohms +/-5% 1/4 W | 01121 | CB4705 |
| | R28 | 0757-0444 | 1 | R: fxd met flm 12.1 kilohms +/-1% 1/8 W | 91637 | MF-1/10-32 |
| | R29 | | | Not assigned | | obd |
| | R30 | 0757-0401 | | R: fxd met flm 100 ohms +/-1% 1/8 W | 91637 | MF-1/10-32 |
| | | | | | | obd |
| | R31 | 0683-5115 | 1 | R: fxd comp 510 ohms +/-5% 1/4 W | 01121 | CB5115 |
| | R32 | | | Not assigned | | |
| | R33 | 0698-4428 | 2 | R: fxd met flm 1690 ohms +/-1% 1/8 W | 91637 | MF-1/10-32 |
| | | | | | | obd |
| | R34 | 0698-3558 | | R: fxd met flm 4020 ohms +/-1% 1/8 W | 91637 | MF-1/10-32 |
| | R35, R36 | 0757-0401 | | R: fxd met flm 100 ohms +/-1% 1/8 W | 91637 | MF-1/10-32 |
| | R37 | 0757-0290 | 2 | R: fxd met flm 6190 ohms +/-1% 1/8 W | 91637 | MF-1/10-32 |
| | | | | | | obd |
| | R38 | 0698-4123 | 4 | R: fxd met flm 499 ohms +/-1% 1/8 W | 91637 | MF-10-32 |
| | R39 | 0757-0283 | | R: fxd met flm 2000 ohms +/-1% 1/8 W | 14674 | C4 |
| | R40 | 0757-0277 | 2 | R: fxd met flm 49.9 ohms +/-1% 1/8 W | 91637 | MF-1/10-32 |
| | R41, R42 | | | Not assigned | | obd |
| | R43 | 0757-0826 | 1 | R: fxd met flm 2430 ohms +/-1% 1/2 W | 75042 | CEC T-0 |
| | R44 | 0698-4123 | | R: fxd met flm 499 ohms +/-1% 1/8 W | 91637 | MF-1/10-32 |
| | R45 | 0757-0280 | | R: fxd met flm 1000 ohms +/-1% 1/8 W | 91637 | MF-1/10-32 |
| | R46, R47 | 0757-0407 | 4 | R: fxd met flm 200 ohms +/-1% 1/8 W | 91637 | MF-1/10-32 |
| | | | | | | obd |
| obd | R48 | 0698-3558 | 1 | R: fxd met flm 4020 ohms +/-1% 1/8 W | 28480 | 0698-3558 |
| | R49 | 0757-0280 | | R: fxd met flm 1000 ohms +/-1% 1/8 W | 91637 | MF-1/10-32 |
| | R50 | 0757-0407 | | R: fxd met flm 200 ohms +/-1% 1/8 W | 91637 | MF-1/10-32 |
| | R51 | 0757-0283 | | R: fxd met flm 2000 ohms +/-1% 1/8 W | 14674 | C4 |
| obd | | | | | | obd |
| | R52 | | | Not assigned | | |
| | R53 | 0757-0283 | | R: fxd met flm 2000 ohms +/-1% 1/8 W | 14674 | C4 |
| | R54 | 0698-4123 | | R: fxd met flm 499 ohms +/-1% 1/8 W | 91637 | MF-1/10-32 |
| | R55 | 0757-0403 | 2 | R: fxd met flm 121 ohms +/-1% 1/8 W | 91637 | MF-1/10-32 |
| | | | | | | obd |
| | R56 | 0757-0283 | | R: fxd met flm 2000 ohms +/-1% 1/8 W | 14674 | C4 |
| | R57 | 0757-0434 | 1 | R: fxd met flm 3650 ohms +/-1% 1/8 W | 35009 | CEA |
| | R58 | 0757-0403 | | R: fxd met flm 121 ohms +/-1% 1/8 W | 91637 | MF-1/10-32 |
| | R59 | 0757-0283 | | R: fxd met flm 2000 ohms +/-1% 1/8 W | 14674 | C4 |
| obd | | | | | | obd |
| | R60 | 0757-0828 | 2 | R: fxd met flm 3010 ohms +/-1% 1/2 W | 91637 | MFF 1/2 T-1 |
| | R61, R62* | 0698-3262 | | R: fxd met flm 40 2 ohms 1% | 16299 | C4-1/8-Tn-4022-F |
| | R63 | 0757-0410 | 3 | R: fxd met flm 301 ohms +/-1% 1/8 W | 91637 | MF-1/10-32 |
| | | | | | | obd |
| | R64 | 0698-4864 | 1 | R: fxd met flm 499 ohms +/-1% 1/2 W | 91637 | MFF 1/2 T-1 |
| | R65 | 0757-0407 | | R: fxd met flm 200 ohms +/-1% 1/8 W | 91637 | MF-1/10-32 |
| | R66 | 0757-0828 | | R: fxd met flm 3010 ohms +/-1% 1/2 W | 91637 | MFF 1/2 T-1 |
| | R67 | 0757-0410 | | R: fxd met flm 301 ohms +/-1% 1/8 W | 91637 | MF-1/10-32 |
| | | | | | | obd |
| | R68, R69 | 0757-0346 | | R: fxd met flm 10 ohms +/-1% 1/8 W | 91637 | MF-1/10-32 |
| | | | | | | obd |
| | R71, R72 | 0757-0346 | | R: fxd met flm 10 ohms +/-1% 1/8 W | 91637 | MF-1/10-32 |
| | | | | | | obd |
| obd | R74, R75 | 0698-6362 | 2 | R: fxd met flm 1000 ohms +/-0.1% 1/8 W | 91637 | MF-1/10-32 |
| obd | R76, R77 | 0698-6800 | 2 | R: fxd met flm 62 ohms +/-0.1% 1/8 W | 91637 | MF-1/10-32 |
| | R78 | 0698-3208 | 1 | R: fxd met flm 4990 ohms +/-1% 1/4 W | 91637 | MF-1/8-44 |
| | R79 | 0698-3558 | | R: fxd met flm 4020 ohms +/-1% 1/8 W | 91637 | MF-1/10-32 |
| obd | | | | | | obd |
| | R80 | | | Not assigned | | |
| | R81 | 0698-4123 | | R: fxd met flm 499 ohms +/-1% 1/8 W | 91637 | MF-1/10-32 |
| obd | R82 | 0698-4428 | | R: fxd met flm 1690 ohms +/-1% 1/8 W | 91637 | MF-1/10-32 |
| | R83 | 0757-0401 | | R: fxd met flm 100 ohms +/-1% 1/8 W | 91637 | MF-1/10-32 |
| obd | | | | | | obd |
| obd | R84 | 0757-0290 | | R: fxd met flm 6190 ohms +/-1% 1/8 W | 91637 | MF-1/10-32 |
| obd | R85 | 0757-0401 | | R: fxd met flm 100 ohms +/-1% 1/8 W | 91637 | MF-1/10-32 |
| obd | R86 | 0698-4423 | 1 | R: fxd met flm 1370 ohms +/-1% 1/8 W | 35009 | CEA |
| obd | R87 | 0757-0420 | 1 | R: fxd met flm 750 ohms +/-1% 1/8 W | 91637 | MF-1/10-32 |
| obd | | | | | | obd |
| obd | R88 | 0757-0084 | 1 | R: fxd met flm 2100 ohms +/-1% 1/2 W | 91637 | MFF 1/2 T-J |
| obd | R89 | 0757-0427 | 2 | R: fxd met flm 1500 ohms +/-1% 1/8 W | 91637 | MF-1/10-32 |
| obd | R90 | 0683-0275 | | R: fxd comp 2.7 ohms +/-5% 1/4 W | 01121 | CB27G5 |
| | R91 | 0757-0280 | | R: fxd met flm 1000 ohms +/-1% 1/8 W | 91637 | MF-1/10-32 |
| | | | | | | obd |
| | | 0340-0060 | 2 | Insulator. feed thru | 98291 | FT-E-15 |
| | A3 | 00654-86503 | 1 | PC board: meter leveling | -hp- | |
| obd | C1 | 0150-0093 | | C: fxd cer 0.01 uF +80% -20% 100 vdcw | 91418 | TA |
| | C2 | 0180-1942 | 1 | C: fxd AI 150 uF +75% -10% 15 vdcw | 56289 | 30D157G015DD2-DSM |
| | C3 | 0150-0084 | | C: fxd cer 0.1 uF +80% -20% 100 vdcw | 72982 | 8131-100-651-104Z |
| obd | C4 | 0150-0093 | | C: fxd cer 0.01 uF +80% -20% 100 vdcw | 91418 | TA |
| | | | | | | obd |

Table 6-1. Replaceable Parts (Cont'd)

| REFERENCE DESIGNATOR | -hp- PART NO. | TQ | DESCRIPTION | MFR | MFR. PART NO |
|----------------------|--------------------|----------|---|-------------|-------------------|
| A3 (Cont'd) | | | | | |
| C5 | 0140-0200 | 1 | C: fxd mica 390 pF +/-5% | 72136 | RDM15F391J3C |
| C6 | 0180-0033 | 1 | C: fxd Al 50 uF +100% -10% 6 vdcw | 56289 | 30D506G006CB2 DSM |
| C7 | 0180-0063 | | C: fxd Al 500 uF +75% -10% 3 vdcw | 56289 | 30D507G003DF2 DSM |
| C8 | 0150-0093 | | C: fxd cer 0.01 uF +80% -20% 100 vdcw | 91418 | TA obd |
| C9 | 0160-2204 | | C: fxd mica 100 pF +/-5% 300 vdcw | 72136 | RDM15F101J3C |
| C10 | 0180-1719 | 1 | C: fxd Ta 22 uF +/-10% 25 vdcw | 56289 | 109D226X9025C2 |
| C11,C12 | 0150-0093 | | C: fxd cer 0.01 uF +80% -20% 100 vdcw | 91418 | TA obd |
| CR1 | 1902-3237 | | Diode: breakdown 20V +/-5% 400 mW | 04713 | SZ10939 269 |
| CR2 | 1902-0777 | | Diode: zener 6.2V +/-5% 1N825 400 mW | 12954 | |
| CR3 | 1902-0057 | | Diode: breakdown 6.49V +/-5% 400 mW | 04713 | SZ10939 128 |
| CR4 | 1901-0347 | | Diode: Si hot carrier 8 vdcw 20 mA 1.5 pF | -hp- | |
| CR5 | 1901-0025 | | Diode: Si 100 mA at +1V 100 piv 12 pF | 07933 | RD1526 |
| CR6 | 1902-0057 | | Diode: breakdown 6.49V +/-5% 400 mW | 04713 | SZ10939-128 |
| Q1 thru Q3 | 1854-0215 | | TSTR: Si NPN 2N3904 | 04713 | SPS3611 |
| Q4 | 1853-0036 | | TSTR: Si PNP 2N3906 | 04713 | SPS3612 |
| Q5 thru Q7 | 1854-0215 | | TSTR: Si NPN 2N3904 | 04713 | SPS3611 |
| Q8 | 1853-0036 | | TSTR: Si PNP 2N3906 | 04713 | SPS3612 |
| Q9 | 1854-0039 | 1 | TSTR: Si NPN 2N3053 | 04713 | 2N3053 |
| R1 | 0698-3279 | 2 | R: fxd met flm 4990 ohms +/-1% 1/8 W | 91637 | MF-1/10-32 obd |
| R2 | 0757-0427 | | R: fxd met flm 1.5 kilohms +/-1% 1/8 W | 91637 | MF-1/10-32 obd |
| R3 | 0757-0743 | 1 | R: fxd met flm 3320 ohms +/-1% 1/4 W | 91637 | MF 1/8-44 obd |
| R4 | 0757-0410 | | R: fxd met flm 301 ohms +/-1% 1/8 W | 91637 | MF 1/10-32 obd |
| R5 | 0757-0277 | | R: fxd met flm 49.9 ohms +/-1% 1/8 W | 91637 | MF 1/10-32 obd |
| R6 | 0698-3406 | 1 | R: fxd met flm 1.33 kilohms +/-1% 1/2 W | 91637 | MFF-1-2-T-1 obd |
| R7 | 2100-1984 | | R: var 100 ohms +/-10% 1/2 W | 73138 | 62PR100 |
| R8 | 0757-0280 | | R: fxd met flm 1000 ohms +/-1% 1/8 W | 91637 | MF 1/10-32 obd |
| R9 | 0698-6799 | 1 | R: fxd met flm 4530 ohms +/-1% 1/8 W | 91637 | MF-1/10-32 obd |
| R10 | 0757-0271 | 2 | R: fxd met flm 124 kilohms +/-1% 1/8 W | 35009 | CEA obd |
| R11 | 0698-4504 | 2 | R: fxd met flm 69.8 kilohms +/-1% 1/8 W | 35009 | CEA obd |
| R12,R13 | | | Not assigned | | |
| R14 | 0757-0442 | | R: fxd met flm 10.0 kilohms +/-1% 1/8 W | 91637 | MF-1/10-32 obd |
| R15 | 0698-4486 | 2 | R: fxd met flm 24.9 kilohms +/-1% 1/8 W | 91637 | MF-1/10-32 obd |
| R16 | 0757-0442 | | R: fxd met flm 10.0 kilohms +/-1% 1/8 W | 91637 | MF 1/10-32 obd |
| R17 | 0698-3279 | | R: fxd met flm 4.99 kilohms +/-1% 1/8 W | 91637 | MF 1/10-32 obd |
| R18 | 2100-2030 | 1 | R: var 20 kilohms +/-20% 1/2 W | 73138 | 62PR20K |
| R19 | 0698-6801 | 1 | R: fxd met flm 3480 ohms +/-1% 1/8 W | 91637 | MF 1/10-32 obd |
| R20 | 2100-1772 | 1 | R: var 500 ohms +/-10% 1/2 W | 75042 | Type 500 obd |
| R21 | 0757-0271 | | R: fxd met flm 124 kilohms +/-1% 1/8 W | 35009 | CEA obd |
| R22 | 0698-4504 | | R: fxd met flm 69.8 kilohms +/-1% 1/8 W | 35009 | CEA obd |
| R23 | 0683-1825 | 1 | R: fxd comp 1.8 kilohms +/-5% 1/4 W | 01121 | CB1825 |
| R24 | 0698-4486 | | R: fxd met flm 24.9 kilohms +/-1% 1/8 W | 91637 | MF-1/10-32 obd |
| R25 | 0812-0049 | 1 | R: fxd w.w. 500 ohms +/-5% 2W | 91637 | CW2B-3 |
| A4 | | | | | |
| | 00654-66504 | 1 | PC board: impedance | -hp- | |
| C1* | 0160-0196 | 1 | C: fxd mica 24 pF +/-5% | 72136 | RDM15C240J3S |
| R1 | 0757-0276 | 2 | R: fxd met flm 61.9 ohms +/-1% 1/8 W | 19701 | MF4C obd |
| R2 | 0698-7160 | 1 | R: fxd met flm 113.65 ohms +/-0.1% 1/8 W | 91637 | MF 1/10-32 obd |
| R3 | 0698-7166 | 1 | R: fxd met flm 27.276 ohms +/-0.1% 1/8 W | 91637 | MF 1/10-32 obd |
| R4 | 0757-0276 | | R: fxd met flm 61.9 ohms +/-1% 1/8 W | 19701 | MF4C obd |
| R5 | 0698-7161 | 1 | R: fxd met flm 139.19 ohms +/-0.1% 1/8 W | 91637 | MF 1/10-32 obd |
| R6 | 0698-7171 | | R: fxd met flm 1.73 ohms +/-1% 1/4 W | 75042 | TF07 obd |
| R7 | 0698-7168 | 1 | R: fxd met flm 31.283 ohms +/-0.1% 1/8 W | 91637 | MF 1/10-32 obd |
| R8 | 0698-7165 | 2 | R: fxd met flm 21.105 ohms +/-0.1% 1/8 W | 91637 | MFF 1/8-T-2 obd |
| R9 | 0698-7167 | 2 | R: fxd met flm 29.261 ohms +/-0.1% 1/8 W | 91637 | MF-1/10-32 obd |
| R10,R11 | 0698-7170 | 2 | R: fxd met flm 70.832 ohms +/-0.1% 1/8 W | 91637 | MF 1/10-32 obd |
| R12 | 0698-7165 | | R: fxd met flm 21.105 ohms +/-0.1% 1/8 W | 91637 | MFF 1/8-T-2 obd |
| R13 | 0698-7167 | | R: fxd met flm 29.261 ohms +/-0.1% 1/8 W | 91637 | MF-1/10-32 obd |
| R14 | 0698-7164 | 2 | R: fxd met flm 17.273 ohms +/-0.25% 1/8 W | 01295 | MC55D |
| R15 | 0698-7169 | 2 | R: fxd met flm 36.550 ohms +/-0.1% 1/8 W | 91637 | MF 1/10-32 obd |
| R16,R17 | 0698-7159 | 2 | R: fxd met flm 74.663 ohms +/-0.1% 1/8 W | 91637 | MF 1/10-32 obd |
| R18 | 0698-7164 | | R: fxd met flm 17.273 ohms +/-0.25% 1/8 W | 01295 | MC55D |


Table 6-1 Replaceable Parts (Cont'd)

| REFERENCE DESIGNATOR | -hp- PART NO. | TQ | DESCRIPTION | MFR | MFR PART NO. |
|--|--------------------|----|--|-------|-------------------|
| A4 (Cont'd) | | | | | |
| R19 | 0698-7169 | | R: fxd met flm 36.550 ohms +/-0.1% 1/8 W | 91637 | MF-1/10-32 obd |
| R20 | 0698-7162 | 2 | R: fxd met flm 239.86 ohms +/-0.1% 1/8 W | 91637 | MF-1/10-32 obd |
| R21, R22 | 0698-7163 | 2 | R: fxd met flm 2008 1 ohms +/-0.1% 1/8 W | 91637 | MF-1/10-32 obd |
| R23 | 0698-7162 | | R: fxd met flm 239.86 ohms +/-0.1% 1/8 W | 91637 | MF-1/10-32 obd |
| S1 | 3101-0837 | 1 | Switch: pushbutton | 71590 | Series PB15 |
| CHASSIS MOUNTED COMPONENTS AND ASSEMBLIES | | | | | |
| C1A, B, C | 5061-0735 | 3 | Tuner assembly | -hp- | |
| C2 thru C5 | 0160-3333 | 4 | C: fxd cer 5000 pF +/-20% 3000 vdcw | -hp- | |
| C6, C7 | 0180-0047 | 2 | C: fxd Al 500 uF 75 vdcw | 56289 | D32443 DFP |
| C8 | | | Not assigned | | |
| C9, C10 | 0180 2117 | 2 | C: fxd Al 4000 uF +75% -10% 3 vdcw | 56289 | (39D)D46446-DSB |
| DS1 | 2140-0015 | 1 | Neon. NE-2H | 24455 | BuIb T-2 |
| | 5040-0234 | 1 | Pilot light: jewel | -hp- | |
| | 5040-0235 | 1 | Pilot light: base | -hp- | |
| F1 | 2110-0340 | 1 | Fuse. 0.4 amp S.B. 250 V | 71400 | MDL 4/10 |
| J1 | 1251-2357 | 1 | Receptacle: power 3 pin | 82389 | EAC-301 |
| J2 thru J4 | 1250-0083 | 3 | Jack: BNC | 000L8 | 28JR-130-1 |
| L1, L3 | | | Not assigned | | |
| L2, L4 | 9140-0029 | 2 | Coil: 100 uH 2.6 ohms | 99848 | 3100-15-101 |
| M1 | 1120-0945 | 1 | m. meter | 55026 | 07760 |
| | 1460-0256 | 4 | Spring: compression | 83909 | |
| MP16 | 0340-0580 | 2 | Insul. Xstr Mtg. | -hp- | |
| Q1 | 1854-0053 | | Tstr: Si NPN, 2N3055 | -hp- | |
| Q2 | 1853-0305 | | Tstr: Si PNP, 2N5875 | 04713 | 2N5875 |
| R1 | 0684-3331 | 1 | R: fxd comp 33 kilohms +/-10% 1/4 W | 01121 | CB3331 |
| R2 | 0766-0029 | 1 | R: fxd met oxide 10 ohms +/-2% 3 W | 14674 | FP-3 obd |
| R3 | 2100-0079 | 1 | R: var 250 ohms +/-10% 2.25 W | 01121 | Type J obd |
| S1 | 3101-0036 | 1 | Switch: power | 88140 | 8928D61 |
| S2 | 00653-61901 | 1 | Switch assembly: range | -hp- | |
| C1* | 0150-0011 | 3 | C: fxd TiO ₂ 1.5 pF +/-20% 500 vdcw | 78488 | Type GA obd |
| C2 | 0121-0420 | 6 | C: var 2-10 pF Teflon dielectric | 000LC | 5640/10 |
| C3* | 0140-0146 | 2 | C: fxd mica 82 pF +/-5% | 72136 | RDM15D820J3S |
| C4 | 0120-0420 | | C: var 2-10 pF | 000LC | 5640/10 |
| C5* | 0140-0146 | | C: fxd mica 82 pF +/-5% | 72136 | RDM15E820J3S |
| C6 | 0121-0420 | | C: var 2-10 pF | 000LC | 5640/10 |
| C7* | 0160-2322 | 2 | C: fxd mica 18 pF +/-5% | 72136 | RDM15C180J1S |
| C8 | 0121-0420 | | C: var 2-10 pF | 000LC | 5640/10 |
| C9* | 0160-0763 | 2 | C: fxd mica 5 pF +/-10% | 72136 | RDM15C050K5S |
| C10 | 0121-0420 | | C: var 2-10 pF | 000LC | 5640/10 |
| C11* | 0160-0763 | | C: fxd mica 5 pF +/-10% | 72136 | RDM15C050K5S |
| C12 | 0121-0420 | | C: var 2-10 pF | 000LC | 5640/10 |
| C13* | 0150-0011 | | C: fxd TiO ₂ 1.5 pF +/-20% 500 vdcw | 78488 | Type GA obd |
| C14 | 0180-0294 | 1 | C: fxd Ta 390 uF +/-20% 10 vdcw | 56289 | 109D397X0010T2DYP |
| C15* | 0160-2322 | | C: fxd mica 18 pF +/-5% | 72136 | RDM15C180J1S |
| C16* | 0150-0029 | 2 | C: fxd TiO ₂ 1 pF +/-10% 500 vdcw | 78488 | Type GA obd |
| C17* | 0150-0011 | | C: fxd TiO ₂ 1.5 pF +/-20% 500 vdcw | 78488 | Type GA obd |
| C18* | 0150-0029 | | C: fxd TiO ₂ 1 pF +/-10% 500 vdcw | 78488 | Type GA obd |
| R1 | 0698-6711 | 1 | R: fxd met flm 12 megohms +/-1% 1/2 W | 00327 | M12 obd |
| R2* | 0686-1545 | 1 | R: fxd comp 150 kilohms +/-5% 1/2 W | 01121 | EB1545 |
| R3 | 0698-6702 | 1 | R: fxd met flm 1.24 megohms +/-0.25% 1/2 W | 91637 | MFF 1/2 T-O obd |
| R4 | 0698-6722 | 1 | R: fxd met flm 124 kilohms +/-0.1% 1/8 W | 91637 | MF-1/10-32 obd |
| R5 | 0698-6707 | 1 | R: fxd met flm 12.4 kilohms +/-0.25% 1/8 W | 91637 | MF-1/10-32 obd |
| R6 | 0698-6706 | 1 | R: fxd met flm 1.24 kilohms +/-0.25% 1/8 W | 91637 | MF-1/10-32 obd |
| R7 | 0698-4408 | 1 | R: fxd met flm 124 ohms +/-1% 1/8 W | 91637 | MF-1/10-32 obd |
| R8 | | | Not assigned | | |
| R9 | 0698-6713 | 1 | R: fxd met flm 24.3 megohms +/-1% 1/2 W | 00327 | M12 obd |
| R10* | 0686-1855 | 1 | R: fxd comp 1.8 megohms +/-5% 1/2 W | 01121 | EB1855 |

Table 6-1. Replacable Parts (Cont'd)

| REFERENCE DESIGNATOR | -hp- PART NO. | TQ | DESCRIPTION | MFR | MFR. PART NO |
|----------------------|--------------------|----------|--|------------|----------------|
| S2 (Cont'd) | | | | | |
| R11 | 0698 6857 | 1 | R: fxd met flm 2.61 megohms $\pm 0.25\%$ 1/2 W | 00327 | M12D obd |
| R12 | 0698-6821 | 1 | R: fxd met flm 261 kilohms $\pm 0.25\%$ 1/8 W | 91637 | MF-1/10-32 obd |
| R13 | 0698-6822 | 1 | R: fxd met flm 26.1 kilohms $\pm 0.25\%$ 1/8 W | 91637 | MF-1/10-32 obd |
| R14 | 0698-6823 | 1 | R: fxd met flm 2.61 kilohms $\pm 0.25\%$ 1/8 W | 91637 | MF-1/10-32 obd |
| R15 | 0757-0409 | 1 | R: fxd met flm 274 ohms $\pm 1\%$ 1/8 W | 91637 | MF-1/10-32 obd |
| R16 | | | Not assigned | | |
| R17 | 0575-0280 | | R: fxd met flm 1000 ohms $\pm 1\%$ 1/8 W | 91637 | MF-1/10-32 obd |
| | 00653-01202 | 1 | Bracket switch | -hp- | |
| S3 | 3101 1234 | 1 | Switch slide 115/230V | 82389 | 11A-1242A |
| S4 | 00654-63401 | 1 | Assembly: attenuator | -hp | |
| R1 | 0698 6812 | 8 | R: fxd met flm 362.6 ohms $\pm 0.25\%$ 1/8 W | 91637 | MF-1/10-32 obd |
| R2 | 0698-6813 | 4 | R: fxd met flm 21.84 ohms $\pm 0.25\%$ 1/8 W | 35009 | CEA obd |
| R3,R4 | 0698-6812 | | R: fxd met flm 362.6 ohms $\pm 0.25\%$ 1/8 W | 91637 | MF-1/10-32 obd |
| R5 | 0698-6813 | | R: fxd met flm 21.84 ohms $\pm 0.25\%$ 1/8 W | 35009 | CEA obd |
| R6 | 0698-6812 | | R: fxd met flm 362.6 ohms $\pm 0.25\%$ 1/8 W | 91637 | MF-1/10-32 obd |
| R7 | 0698-6804 | 4 | R: fxd met flm 540.9 ohms $\pm 0.25\%$ 1/8 W | 91637 | MF-1/10-32 obd |
| R8 | 0698-6803 | 2 | R: fxd met flm 14.40 ohms $\pm 0.25\%$ 1/8 W | 91637 | MF-1/10-32 obd |
| R9 | 0698-6804 | | R: fxd met flm 540.9 ohms $\pm 0.25\%$ 1/8 W | 91637 | MF-1/10-32 obd |
| R10 | 0698-6805 | 4 | R: fxd met flm 1078 ohms $\pm 0.25\%$ 1/8 W | 91637 | MF-1/10-32 obd |
| R11 | 0698-6827 | 2 | R: fxd met flm 7.154 ohms $\pm 0.5\%$ 1/8 W | 00327 | M11D obd |
| R12 | 0698-6805 | | R: fxd met flm 1078 ohms $\pm 0.25\%$ 1/8 W | 91637 | MF-1/10-32 obd |
| R13 | 0698-6810 | 8 | R: fxd met flm 66.05 ohms $\pm 0.25\%$ 1/8 W | 91637 | MF-1/10-32 obd |
| R14 | 0698-6811 | 4 | R: fxd met flm 979.3 ohms $\pm 0.25\%$ 1/8 W | 91637 | MF-1/10-32 obd |
| R15,R16 | 0698-6810 | | R: fxd met flm 66.05 ohms $\pm 0.25\%$ 1/8 W | 91637 | MF-1/10-32 obd |
| R17 | 0698-6811 | | R: fxd met flm 979.3 ohms $\pm 0.25\%$ 1/8 W | 91637 | MF-1/10-32 obd |
| R18 | 0698-6810 | | R: fxd met flm 66.05 ohms $\pm 0.25\%$ 1/8 W | 91637 | MF-1/10-32 obd |
| R19 | 0698-6808 | 4 | R: fxd met flm 75.78 ohms $\pm 0.25\%$ 1/8 W | 91637 | MF-1/10-32 obd |
| R20 | 0698-6809 | 2 | R: fxd met flm 306.9 ohms $\pm 0.25\%$ 1/8 W | 91637 | MF-1/10-32 obd |
| R21 | 0698-6808 | | R: fxd met flm 75.78 ohms $\pm 0.25\%$ 1/8 W | 91637 | MF-1/10-32 obd |
| R22 | 0698-6806 | 4 | R: fxd met flm 119.3 ohms $\pm 0.25\%$ 1/8 W | 91637 | MF-1/10-32 obd |
| R23 | 0698-6807 | 2 | R: fxd met flm 88.23 ohms $\pm 0.25\%$ 1/8 W | 91637 | MF-1/10-32 obd |
| R24 | 0698-6806 | | R: fxd met flm 119.3 ohms $\pm 0.25\%$ 1/8 W | 91637 | MF-1/10-32 obd |
| R25 | 0698-6812 | | R: fxd met flm 362.6 ohms $\pm 0.25\%$ 1/8 W | 91637 | MF-1/10-32 obd |
| R26 | 0698-6813 | | R: fxd met flm 21.84 ohms $\pm 0.25\%$ 1/8 W | 35009 | CEA obd |
| R27,R28 | 0698-6812 | | R: fxd met flm 362.6 ohms $\pm 0.25\%$ 1/8 W | 91637 | MF-1/10-32 obd |
| R29 | 0698-6813 | | R: fxd met flm 21.84 ohms $\pm 0.25\%$ 1/8 W | 35009 | CEA obd |
| R30 | 0698-6812 | | R: fxd met flm 362.6 ohms $\pm 0.25\%$ 1/8 W | 91637 | MF-1/10-32 obd |
| R31 | 0698-6804 | | R: fxd met flm 540.9 ohms $\pm 0.25\%$ 1/8 W | 91637 | MF-1/10-32 obd |
| R32 | 0698-6803 | | R: fxd met flm 14.40 ohms $\pm 0.25\%$ 1/8 W | 91637 | MF-1/10-32 obd |
| R33 | 0698-6804 | | R: fxd met flm 540.9 ohms $\pm 0.25\%$ 1/8 W | 91637 | MF-1/10-32 obd |
| R34 | 0698-6805 | | R: fxd met flm 1078 ohms $\pm 0.25\%$ 1/8 W | 91637 | MF-1/10-32 obd |
| R35 | 0698-6827 | | R: fxd met flm 7.154 ohms $\pm 0.5\%$ 1/8 W | 00327 | M11D obd |
| R36 | 0698-6805 | | R: fxd met flm 1078 ohms $\pm 0.25\%$ 1/8 W | 91637 | MF-1/10-32 obd |
| R37 | 0698-6810 | | R: fxd met flm 66.05 ohms $\pm 0.25\%$ 1/8 W | 91637 | MF-1/10-32 obd |
| R38 | 0698-6811 | | R: fxd met flm 979.3 ohms $\pm 0.25\%$ 1/8 W | 91637 | MF-1/10-32 obd |
| R39,R40 | 0698-6810 | | R: fxd met flm 66.05 ohms $\pm 0.25\%$ 1/8 W | 91637 | MF-1/10-32 obd |
| R41 | 0698 6811 | | R: fxd met flm 979.3 ohms $\pm 0.25\%$ 1/8 W | 91637 | MF-1/10-32 obd |
| R42 | 0698-6810 | | R: fxd met flm 66.05 ohms $\pm 0.25\%$ 1/8 W | 91637 | MF-1/10-32 obd |
| R43 | 0698-6808 | | R: fxd met flm 75.78 ohms $\pm 0.25\%$ 1/8 W | 91637 | MF-1/10-32 obd |
| R44 | 0698-6809 | | R: fxd met flm 306.9 ohms $\pm 0.25\%$ 1/8 W | 91637 | MF-1/10-32 obd |
| R45 | 0698-6808 | | R: fxd met flm 75.78 ohms $\pm 0.25\%$ 1/8 W | 91637 | MF-1/10-32 obd |
| R46 | 0698-6806 | | R: fxd met flm 119.3 ohms $\pm 0.25\%$ 1/8 W | 91637 | MF-1/10-32 obd |
| R47 | 0698-6807 | | R: fxd met flm 88.23 ohms $\pm 0.25\%$ 1/8 W | 91637 | MF-1/10-32 obd |
| R48 | 0698-6806 | | R: fxd met flm 119.3 ohms $\pm 0.25\%$ 1/8 W | 91637 | MF-1/10-32 obd |
| T1 | 9100-3239 | 1 | Transformer | -hp- | |
| W1 | 8120-1348 | 1 | Cord. power | 70903 | KH-4147 |

UNCIRCLED
NUMBERS COORDINATE WITH
MP NUMBERS ON PAGE 6-11



654A - B-1867

ATTACHING HARDWARE

| ITEM | -hp- PART NO. | DESCRIPTION |
|------|---------------|----------------------------------|
| ① | 3030-0022 | Screw: Set, 6-32 x 1/8 in. long |
| ② | 3030-0001 | Screw: Set, 8-32 x 3/16 in. long |
| ③ | 3030-0004 | Screw: Set, 8-32 x 1 in. long |
| ④ | 3050-0180 | Washer: .270 ID x .375 OD |
| ⑤ | 0510-0054 | Ring Retaining: .25 OD SHAFT |

Figure 6-1. Frequency Tuning Mechanism




Figure 6-2. Chassis Mechanical Parts

Table 6-1. Replaceable Parts (Cont'd)

| REFERENCE DESIGNATOR | -hp- PART NO. | T | Q | DESCRIPTION | MFR. | MFR. PART NO |
|-------------------------|---------------|---|---|--------------------------------------|-------|--------------|
| MECHANICAL PARTS | | | | | | |
| MP1 | 1500-0253 | 2 | | Yoke-Flex: coupler | 76489 | 39006 |
| MP2 | 1500-0004 | 1 | | Yoke | -hp- | |
| MP3 | 5060-0021 | 1 | | Gear: ass'y | -hp- | |
| MP4 | 1460-0114 | 1 | | Wireform | 91260 | obd |
| MP5 | 5060-0020 | 1 | | Gear: ass'y | -hp- | |
| MP6 | 5020-0233 | 1 | | Collar | -hp- | |
| MP7 | 5020-0348 | 1 | | Shaft | -hp- | |
| MP8 | 5020-0641 | 1 | | Gear: spur ass'y shaft | -hp- | |
| MP9 | 5020-0639 | 1 | | Casting: Cap drive ass'y | -hp- | |
| MP10 | 5000-0637 | 1 | | Spring: thrust | -hp- | |
| MP11 | 5020-0630 | 1 | | Dial: hub | -hp- | |
| MP12 | 5040-0607 | 1 | | Disc: vernier drive | -hp- | |
| MP13 | 00653-00102 | 1 | | Deck: capacitor | -hp- | |
| MP15 | 00653-00101 | 1 | | Deck: main | -hp- | |
| MP16 | 0340-0580 | 2 | | Insulator: TSTR | 76530 | 293011 |
| MP17 | 00653-01205 | 1 | | Bracket: attenuator mount | -hp- | |
| MP18 | 00653-05502 | 1 | | Shield attenuator | -hp- | |
| MP19 | 0360-1507 | 2 | | Insulator: feedthrough | 12284 | 4242-1-0119 |
| MP20 | 1400-0084 | 1 | | Holder: fuse | 75915 | 342014 |
| MP21 | 00651-05503 | 1 | | Shield filter | -hp- | |
| MP22 | 00653-04101 | 1 | | Cover: plate | -hp- | |
| MP23 | 00651-05501 | 1 | | Shield: power | -hp- | |
| MP24 | 00651-04001 | 1 | | Dial | -hp- | |
| MP25 | 0370-0160 | 1 | | Knob: dial | -hp- | |
| MP26 | 61B-400-4 | 1 | | Plate: freq. dial | -hp- | |
| MP27 | 5040-5158 | 1 | | Indicator: dial | -hp- | |
| MP28 | 0370-0025 | 1 | | Knob-Freq: vernier | -hp- | |
| MP29 | 0370-0112 | 1 | | Knob-Bar: black | -hp- | |
| MP30 | 0370-0026 | 1 | | Knob: amp | -hp- | |
| MP31 | 4040-0297 | 1 | | Bezel: meter | -hp- | |
| MP32 | 0370-0440 | 5 | | Knob: pushbutton | -hp- | |
| MP33 | 00653-47401 | 1 | | Knob: attenuator outer | -hp- | |
| MP34 | 00653-67401 | 1 | | Knob: attenuator inner | -hp- | |
| MP35 | 1250-0901 | 2 | | Connector: RF | 74163 | 1104/D |
| MP36 | 00654-05501 | 1 | | Shield: output | -hp- | |
| MP37 | 00653-05501 | 1 | | Shield: S. W | -hp- | |
| MP38 | 5060-8587 | 1 | | Cover ass'y: top | -hp- | |
| | 2370-0013 | 8 | | Attaching hardware: screw, machine | 83385 | obd |
| | 0150-0075 | 8 | | Attaching hardware: nut, sheet metal | -hp- | |
| MP39 | 00653-00204 | 1 | | Panel: rear | -hp- | |
| MP40 | 5060-0731 | 2 | | Frame ass'y | -hp- | |
| MP41 | 5060-8737 | 2 | | Retainer: 5H handle ass'y | -hp- | |
| MP42 | 00654-00202 | 1 | | Panel: front | -hp- | |
| MP43 | 5060-0767 | 5 | | Foot ass'y: FM | -hp- | |
| MP44 | 1490-0030 | 1 | | Stand: tilt | 91260 | obd |
| MP45 | 5000-0051 | 2 | | Trim: fluted Al plate | -hp- | |
| MP46 | 5060-0222 | 2 | | Handle ass'y: 5H side | -hp- | |
| MP47 | 5060-8711 | 1 | | Cover ass'y: bottom | -hp- | |
| | 2370-0013 | | | Attaching hardware: screw, machine | 83385 | obd |
| | 0150-0075 | | | Attaching hardware: nut, sheet metal | -hp- | |
| MP48 | 5000-8599 | 2 | | Cover: side front | -hp- | |
| | 2370-0016 | 4 | | Attaching hardware: screw, machine | 80120 | obd |
| MP49 | 5000-8597 | 2 | | Cover: side rear | -hp- | |
| | 2370-0016 | | | Attaching hardware: screw, machine | 80120 | obd |
| MP50 | 00653-01206 | 1 | | Bracket: attenuator | -hp- | |

Table 6-1. Replaceable Parts (Cont'd)

| REFERENCE DESIGNATOR | -hp- PART NO. | T Q | DESCRIPTION | MFR. | MFR PART NO. |
|----------------------|---------------|-----|---|-------|--------------|
| | | | MISCELLANEOUS | | |
| | 00653-61602 | 2 | Cable: attenuator input | -hp- | |
| | 00653-61601 | 2 | Cable: attenuator output | -hp- | |
| | 00651-61604 | 1 | Cable: power | -hp- | |
| | 5060-8740 | 1 | Kit: rack mount, 5H | -hp- | |
| | 5000-7133 | 1 | Label: pushbutton 50 ohms | -hp- | |
| | 5000-7126 | 1 | Label: pushbutton 75 ohms | -hp- | |
| | 5000-7134 | 1 | Label: pushbutton 135 ohms | -hp- | |
| | 5000-7135 | 1 | Label: pushbutton 150 ohms | -hp- | |
| | 5000-7136 | 1 | Label: pushbutton 600 ohms | -hp- | |
| | 00654-90003 | 1 | Manual: operating and service | -hp- | |
| | 1205-0033 | 8 | Heat sink semiconductor for A204-06, A2018-021 and A309 | 05820 | 207-CB |
| | 5040-0234 | 1 | Holder: lamp | | |
| | 5040-0235 | 1 | Base: lampholder | | |

SECTION VII CIRCUIT DIAGRAMS


7-1. INTRODUCTION.

7-2. This section contains circuit diagrams to aid in the operation and maintenance of the Model 654A. Figure 7-1 is a functional circuit diagram which shows the overall relationship between the basic circuits of the instrument. Figures 7-2 through 7-5 contain the detailed schematic diagrams as well as component location drawings of each















printed circuit board and the rotary switches.


7-3. General schematic notes, which apply to all the schematic diagrams, are listed on Page 7-2.

7-4. An explanation of terms and symbols used on the schematic diagrams is given below.




SCHEMATIC NOTES

1. PARTIAL REFERENCE DESIGNATIONS ARE SHOWN, PREFIX WITH ASSEMBLY OR SUBASSEMBLY DESIGNATION(S) OR BOTH FOR COMPLETE DESIGNATION.
2. COMPONENT VALUES ARE SHOWN AS FOLLOWS UNLESS OTHERWISE NOTED.
 RESISTANCE IN OHMS
 CAPACITANCE IN MICROFARADS
 INDUCTANCE IN MICROHENRYS
3.  DENOTES ASSEMBLY.
4.  DENOTES MAIN SIGNAL PATH
5.  DENOTES DC FEEDBACK PATH.
6.  DENOTES AC FEEDBACK PATH.
7.  DENOTES FRONT PANEL MARKING.
8.  DENOTES REAR PANEL MARKING.
9.  DENOTES SCREWDRIVER ADJUST.
10.  DENOTES FRONT PANEL CONTROL.
11.  DENOTES POWER LINE GROUND
12.  DENOTES FRAME GROUND.
13.  DENOTES ASSEMBLY GROUND.
14. * AVERAGE VALUE SHOWN, OPTIMUM VALUE SELECTED AT FACTORY. COMPONENT MAY OR MAY NOT BE PRESENT
15.  DENOTES GROUND CONNECTION MADE WITH ASSEMBLY MOUNTING SCREWS IN PLACE
16.  DENOTES SIGNAL CONNECTION
17. **2** DENOTES SCHEMATIC ON WHICH SIGNAL CONNECTION IS MADE.
18.  DENOTES COMPONENTS NOT MOUNTED ON ASSEMBLY.



- NOTES-
1. Numbers in the Block indicates Schematic on which the circuit appears
 2. See Paragraph 5-70 for Troubleshooting information



654A-B-1820A


SHADED AREA SHOWN ON SCHEMATIC NO. 2

A2
 hp Part No. 00654-66502
 Rev. A

A2 ASSEMBLY COMPONENT LOCATIONS

| | Q | C | CR | | C | | R | C | | R | | R | | R |
|----|----|----|----|----|-----|----|-----|----|----|----|----|-----|----|----|
| 11 | A7 | | | 26 | C7 | 41 | | C5 | 56 | B7 | 71 | C8 | 86 | D5 |
| 12 | A8 | | | 27 | D7 | 42 | | B5 | 57 | A8 | 72 | D8 | 87 | D5 |
| 13 | B7 | | A8 | 28 | C8 | 43 | | C6 | 58 | B8 | 73 | D8 | 88 | D5 |
| 14 | B8 | | B7 | 29 | D8 | 44 | A6 | C5 | 59 | B8 | 74 | D7 | 89 | D5 |
| 15 | B7 | A6 | B6 | 30 | D9 | 45 | A7 | C4 | 60 | C7 | 75 | D8 | 90 | D5 |
| 16 | B8 | A8 | B6 | 31 | D9 | 46 | A7 | D4 | 61 | B6 | 76 | D7 | 91 | A1 |
| 17 | B8 | A7 | B9 | 32 | D8 | 47 | A7 | | 62 | B9 | 77 | D8 | | |
| 18 | C7 | A9 | B9 | 33 | D9 | 48 | A7 | | 63 | B7 | 78 | C9 | | |
| 19 | D7 | B8 | D9 | 34 | A8 | 49 | A8 | | 64 | C7 | 79 | C7 | | |
| 20 | C8 | C6 | C8 | 35 | A7 | 50 | A8 | | 65 | B7 | 80 | ... | | |
| 21 | D8 | B6 | C5 | 36 | B9 | 51 | A6 | | 66 | C8 | 81 | D6 | | |
| 22 | C9 | C8 | C5 | 37 | ... | 52 | ... | | 67 | B8 | 82 | D6 | | |
| 23 | C9 | B7 | C6 | 38 | D6 | 53 | A9 | | 68 | C7 | 83 | D5 | | |
| 24 | D5 | B7 | | 39 | ... | 54 | A9 | | 69 | D7 | 84 | D6 | | |
| 25 | D5 | B9 | | 40 | C5 | 55 | B7 | | 70 | C8 | 85 | D6 | | |


P/O Figure 7-2. Oscillator and Buffer Amplifier



RANGE SWITCH
S2
hp Part No. 00653-61901

A2 SCHEMATIC
COMPONENT LOCATIONS

| | R | Q | C | CR | L | DSV | | R | Q | CR | | R |
|----|-----|-----|-----|-----|-----|-----|----|-----|-----|-----|----|-----|
| 1 | B13 | E14 | D13 | J14 | B17 | C22 | 16 | --- | | | 31 | E20 |
| 2 | D13 | C16 | J15 | H14 | C18 | | 17 | D16 | | | 32 | --- |
| 3 | D13 | E16 | J16 | J14 | F18 | | 18 | F16 | | | 33 | C22 |
| 4 | J13 | C17 | J15 | F16 | | | 19 | F17 | | | 34 | B25 |
| 5 | J14 | D18 | J16 | C17 | | | 20 | B20 | | | 35 | C24 |
| 6 | H14 | E18 | --- | C15 | | | 21 | B18 | | | 36 | C24 |
| 7 | H15 | E20 | --- | D17 | | | 22 | D18 | | | 37 | D24 |
| 8 | J16 | C23 | B17 | E17 | | | 23 | E18 | | | 38 | C23 |
| 9 | F13 | C25 | H15 | F19 | | | 24 | F18 | | C26 | 39 | D24 |
| 10 | E14 | C26 | E18 | F19 | | | 25 | F14 | | | 40 | B26 |
| 11 | D15 | | E19 | E20 | | | 26 | F19 | D15 | | 41 | --- |
| 12 | F15 | | E20 | B26 | | | 27 | E19 | | | 42 | --- |
| 13 | H14 | | B19 | | | | 28 | F18 | | | 43 | D26 |
| 14 | E15 | | --- | | | | 29 | --- | | | 44 | |
| 15 | B16 | | | | | | 30 | E19 | | | 45 | |



654A-B-1820A


SHADED AREA SHOWN ON SCHEMATIC NO. 1

A2
hp Part No. 00654-66502
Rev. A

A2 ASSEMBLY
COMPONENT LOCATIONS

| | R | Q | C | CR | L | DSV | | R | Q | CR | | R |
|----|----|----|-----|----|----|-----|----|-----|----|----|----|-----|
| 1 | C2 | B1 | B2 | A3 | D1 | B4 | 16 | ... | | | 31 | D3 |
| 2 | B2 | C1 | D3 | A3 | D1 | | 17 | C1 | | | 32 | ... |
| 3 | C2 | C1 | C4 | C3 | A2 | | 18 | B1 | | | 33 | A5 |
| 4 | B2 | D1 | C3 | B1 | | | 19 | A3 | | | 34 | A5 |
| 5 | A2 | D1 | B3 | C2 | | | 20 | D3 | | | 35 | A5 |
| 6 | C3 | A2 | ... | C1 | | | 21 | D2 | | | 36 | A5 |
| 7 | C3 | D3 | ... | C2 | | | 22 | C2 | | | 37 | A5 |
| 8 | D4 | A5 | C1 | B2 | | | 23 | A2 | | | 38 | A6 |
| 9 | A3 | A5 | A4 | C3 | | | 24 | A3 | | A5 | 39 | A6 |
| 10 | B1 | B5 | C2 | C3 | | | 25 | A4 | | C8 | 40 | B5 |
| 11 | C1 | | D2 | C2 | | | 26 | D2 | B1 | D8 | 41 | ... |
| 12 | B1 | | A2 | B5 | | | 27 | C2 | | | 42 | ... |
| 13 | B3 | | D3 | | | | 28 | B3 | | | 43 | B5 |
| 14 | B1 | | ... | | | | 29 | ... | | | | |
| 15 | D1 | | | | | | 30 | A1 | | | | |

P/O Figure 7-3. Balanced Amplifier, Meter and Leveling




A3
 hp Part No. 00654-66503

NOTES


- DC LEVELS WERE OBSERVED UNDER THE FOLLOWING CONDITIONS:
- A. 654A.
 RANGE - X10K
 DIAL - 1
 IMPEDANCE -75 UNBAL
 OUTPUT LEVEL -+ 10 dBm
 AMPLITUDE -SET FOR 0 DN METER.
 - B. ALL VOLTAGES +/-10%.
 - C. VOLTAGES WERE TAKEN WITH AN -HP- MODEL 3440A DIGITAL VOLTMETER HAVING A 3443A PLUG-IN. HOWEVER, ANY DC VOLTMETER WITH APPROXIMATELY 10 MEGOHMS INPUT IMPEDANCE WILL YIELD ABOUT THE SAME RESULTS.

**A2 SCHEMATIC
 COMPONENT LOCATIONS**


| | Q | C | CR | | C | | R | C | | R | | R | | R |
|----|-----|----|-----|----|-------|----|-------|-----|----|-----|----|-------|----|-----|
| 11 | F3 | | | 26 | D10 | 41 | | B17 | 56 | H5 | 71 | D11 | 86 | A15 |
| 12 | F4 | | | 27 | E10 | 42 | | B16 | 57 | F6 | 72 | F11 | 87 | B15 |
| 13 | F5 | | E4 | 28 | D12 | 43 | | C14 | 58 | F6 | 73 | H11 | 88 | C15 |
| 14 | F6 | | H5 | 29 | F12 | 44 | F2 | C17 | 59 | H6 | 74 | E13 | 89 | C16 |
| 15 | F7 | C6 | D7 | 30 | F12 | 45 | E3 | A15 | 60 | D7 | 75 | E13 | 90 | A15 |
| 16 | F9 | E4 | E7 | 31 | C12 | 46 | H3 | C15 | 61 | E7 | 76 | D14 | 91 | L14 |
| 17 | K8 | E4 | D9 | 32 | E12 | 47 | E3 | | 62 | E9 | 77 | E14 | | |
| 18 | D10 | L6 | E9 | 33 | J11 | 48 | H3 | | 63 | H7 | 78 | H10 | | |
| 19 | F10 | H6 | J10 | 34 | J1 | 49 | E4 | | 64 | K8 | 79 | K9 | | |
| 20 | C11 | E8 | J9 | 35 | K1 | 50 | H4 | | 65 | K9 | 80 | - - - | | |
| 21 | F11 | F8 | B17 | 36 | F10 | 51 | C6 | | 66 | C9 | 81 | C13 | | |
| 22 | J10 | K8 | C17 | 37 | - - - | 52 | - - - | | 67 | H9 | 82 | C14 | | |
| 23 | J9 | H8 | B14 | 38 | C16 | 53 | L6 | | 68 | D10 | 83 | C15 | | |
| 24 | C15 | K9 | | 39 | - - - | 54 | J4 | | 69 | E10 | 84 | B14 | | |
| 25 | B15 | E9 | | 40 | B16 | 55 | F5 | | 70 | C11 | 85 | B15 | | |



V U T S R P N M L K J H F E D C B A



ATTENUATOR
S4
hp Part No. 00654-63401



654A-B-1784

A4
hp Part No. 00654-66504


NOTES

DC LEVELS WERE OBSERVED UNDER THE FOLLOWING CONDITIONS:

A. 654A.
RANGE - X10K
DIAL - 1
IMPEDANCE - 75 UNBAL
OUTPUT LEVEL - + 10 dBm
AMPLITUDE - SET FOR 0 ON METER.

B. ALL VOLTAGES +/-10%.

C. VOLTAGES WERE TAKEN WITH AN HP MODEL 3440A DIGITAL VOLTMETER HAVING A 3443A PLUG-IN. HOWEVER, ANY DC VOLTMETER WITH APPROXIMATELY 10 MEGOHMS INPUT IMPEDANCE WILL YIELD ABOUT THE SAME RESULTS.




AI
 hp Part No. 00653-66507
 Rev. A

NOTES

DC LEVELS WERE OBSERVED UNDER THE FOLLOWING CONDITIONS:

- A. 654A.
 RANGE - X10K
 DIAL - 1
 IMPEDANCE -75 UNBAL
 OUTPUT LEVEL --+ 10 dBm
 AMPLITUDE-SET FOR 0 ON METER.
- B. ALL VOLTAGES +/-10%.
- C. VOLTAGES WERE TAKEN WITH AN HP. MODEL 3440A DIGITAL VOLTMETER HAVING A 3443A PLUG-IN. HOWEVER, ANY DC VOLTMETER WITH APPROXIMATELY 10 MEGOHMS INPUT IMPEDANCE WILL YIELD ABOUT THE SAME RESULTS.



COPYRIGHT 1975 BY HEWLETT-PACKARD COMPANY 653-0-4423

NOTES

DC LEVELS WERE OBSERVED UNDER THE FOLLOWING CONDITIONS:

- A. 654A.
- RANGE - X10K
- DIAL - 1
- IMPEDANCE - 75 UNBAL
- OUTPUT LEVEL - +10 dBm

CODE LIST OF MANUFACTURERS

The following code numbers are from the Federal Supply Code for Manufacturers Cataloging Handbooks H4-1 (Name to Code) and H4-2 (Code to Name) and their latest supplements. The date of revision and the date of the supplements used appear at the bottom of each page. Alphabetical codes have been arbitrarily assigned to suppliers not appearing in the H4 Handbooks.

| Code No. | Manufacturer | Address | Code No. | Manufacturer | Address | Code No. | Manufacturer | Address |
|----------|--|--------------------------|----------|--|------------------------------------|----------|---|---------------------------------|
| 00000 | U. S. A Common | Any supplier of U. S. | 05347 | Ultronix, Inc. | San Mateo, Cal. | 11236 | CTS of Berne, Inc. | Berne, Ind. |
| 00136 | McCoy Electronics | Mount Holly Springs, Pa. | 05397 | Union Carbine Corp., Elect. | Div. New York, N. Y. | 11237 | Chicago Telephone of California, Inc. | So. Pasadena, Cal. |
| 00213 | Sage Electronics Corp | Rochester, N. Y. | 05574 | Viking Ind Inc | Canoga Park, Cal. | 11242 | Bay State Electronics Corp. | Waltham, Mass |
| 00287 | Cemco, Inc. | Danielson, Conn. | 05593 | Icore Electro-Plastics Inc. | Sunnyvale, Cal. | 11312 | Teledyne Inc., Microwave Div. | Palo Alto, Cal. |
| 00334 | Humidial | Colton, Calif. | 05616 | Cosmo Plastic (c o Electrical Spec. Co.) | Cleveland, Ohio | 11314 | National Seal | Downey, Cal. |
| 00348 | Mictron, Co., Inc. | Valley Stream, N. Y. | 05624 | Barber Colman Co. | Rockford, Ill. | 11453 | Precision Connector Corp. | Jamaica, N. Y. |
| 00373 | Garlock Inc. | Cherry Hill, N. J. | 05728 | Tiffen Optical Co. | Roslyn Heights, Long Island, N. Y. | 11534 | Duncan Electronics Inc. | Costa Mesa, Cal. |
| 00656 | Aerovox Corp. | New Bedford, Mass. | 05729 | Metro-Tel Corp. | Westbury, N. Y. | 11711 | General Instrument Corp., Semiconductor Division Products Group | Newark, N. J. |
| 00779 | Amp. Inc. | Harrisburg, Pa | 05783 | Stewart Engineering Co | Santa Cruz, Cal. | 11717 | Imperial Electronic, Inc. | Buena Park, Cal. |
| 00781 | Aircraft Radio Corp. | Boonton, N. J. | 05820 | Wakefield Engineering Inc. | Wakefield, Mass. | 11870 | Melabs, Inc. | Palo Alto, Cal. |
| 00809 | Croven, Ltd. | Whitby, Ontario, Canada | 06004 | Bassick Co., Div. of Stewart Warner Corp. | Bridgeport, Conn. | 12136 | Philadelphia Handle Co. | Camden, N. J. |
| 00815 | Northern Engineering Laboratories, Inc. | Burlington, Wis. | 06090 | Raychem Corp. | Redwood City, Cal. | 12361 | Grove Mfg. Co., Inc. | Shady Grove, Pa. |
| 00853 | Sangamo Electric Co., Pickens Div. | Pickens, S. C | 06175 | Bausch and Lomb Optical Co. | Rochester, N. Y. | 12574 | Gulton Ind. Co., Data System Div. | Albuquerque, N. M. |
| 00866 | Goe Engineering Co. | City of Industry, Cal. | 06402 | E. T. A. Products Co. of America | Chicago, Ill. | 12697 | ClaroStat Mfg. Co. | Dover, N. H. |
| 00891 | Carl E. Holmes Corp. | Los Angeles, Cal. | 06540 | Amatom Electronic Hardware Co., Inc. | New Rochelle, N. Y. | 12728 | Elmar Filter Corp. | W. Haven, Conn. |
| 00929 | MicroLab Inc. | Livingston, N. J. | 06555 | Beede Electrical Instrument Co., Inc. | Penacook, N. H. | 12859 | Nippon Electric Co., Ltd | Tokyo, Japan |
| 01002 | General Electric Co., Capacitor Dept. | Hudson Falls, N. Y. | 06666 | General Devices Co., Inc | Indianapolis, Ind | 12881 | Metex Electronics Corp. | Clark, N. J. |
| 01009 | Alden Products Co. | Brockton, Mass. | 06751 | Components Inc., Ariz. Div. | Phoenix, Arizona | 12930 | Delta Semiconductor Inc. | Newport Beach, Cal. |
| 01121 | Allen Bradley Co. | Milwaukee, Wis | 06751 | Torrington Mfg. Co., West Div. | Van Nuys, Cal | 12954 | Dickson Electronics Corp. | Scottsdale, Arizona |
| 01255 | Liton Industries, Inc. | Beverly Hills, Cal. | 06812 | Varian Assoc. Etmac Div. | San Carlos, Cal. | 13019 | Aircro Supply Co., Inc. | Wichita, Kansas |
| 01281 | TRW Semiconductors, Inc. | Lawndale, Cal. | 06980 | Kelvin Electric Co. | Van Nuys, Cal | 13061 | Wilco Products | Detroit, Mich. |
| 01295 | Texas Instruments, Inc., Transistor Products Div. | Dallas, Texas | 07088 | Digitran Co. | Pasadena, Cal. | 13103 | Thermolloy | Dallas, Texas |
| 01349 | The Alliance Mfg. Co. | Alliance, Ohio | 07126 | Transistor Electronics Corp. | Minneapolis, Minn. | 13327 | Solitron Devices Inc. | Tappan, N. Y. |
| 01538 | Small Parts Inc. | Los Angeles, Cal. | 07137 | Westinghouse Electric Corp., Electronic Tube Div. | Elmira, N. Y. | 13396 | Telefunken (GmbH) | Hanover, Germany |
| 01589 | Pacific Relays, Inc. | Van Nuys, Cal. | 07138 | Westinghouse Electric Corp., Electronic Tube Div. | Elmira, N. Y. | 13835 | Midland-Wright Div of Pacific Industries, Inc. | Kansas City, Kansas |
| 01670 | Gudebrod Bros. Silk Co. | New York, N. Y. | 07149 | Filmohm Corp. | New York, N. Y. | 14099 | Sem-Tech | Newbury Park, Cal. |
| 01930 | Amerock Corp. | Rockford, Ill. | 07233 | Cinch-Graphix Co. | City of Industry, Cal. | 14193 | Calif. Resistor Corp. | Sanita Monica, Cal. |
| 01960 | Pulse Engineering Co. | Santa Clara, Cal | 07256 | Silicon Transistor Corp. | Carle Place, N. Y. | 14298 | American Components, Inc. | Conshohocken, Pa. |
| 02114 | Ferrocube Corp. of America | Saugerties, N. Y. | 07261 | Avnet Corp. | Culver City, Cal. | 14433 | ITT Semiconductor, a Div. of Int. Telephone and Telegraph Corporation | West Palm Beach, Fla. |
| 02116 | Wheelock Signals, Inc. | Long Branch, N. J. | 07263 | Fairchild Camera & Inst. Corp. Semiconductor Div. | Mountain View, Cal. | 14493 | Hewlett-Packard Company | Loveland, Colo. |
| 02286 | Cole Rubber and Plastics Inc. | Sunnyvale, Cal. | 07322 | Minnesota Rubber Co. | Minneapolis, Minn. | 14655 | Cornell Dublier Electric Corp. | Newark, N. J. |
| 02660 | Amphenol-Borg Electronics Corp. | Broadview, Ill | 07387 | Birtcher Corp. The | Monterey Park, Cal. | 14674 | Corning Glass Works | Corning, N. Y. |
| 02735 | Radio Corp. of America, Semiconductor and Materials Division | Somerville, N. J. | 07397 | Sylvania Elect. Prod. Inc., Mt. View Operations | Mountain View, Cal. | 14752 | Electro Cube Inc. | San Gabriel, Cal. |
| 02771 | Vocaline Co. of America, Inc. | Old Saybrook, Conn. | 07700 | Technical Wire Products Inc. | Cranford, N. J. | 14960 | Williams Mfg. Co. | San Jose, Cal. |
| 02777 | Hopkins Engineering Co. | San Fernando, Cal. | 07829 | Bodine Elect. Co. | Chicago, Ill. | 15106 | The Sphere Co., Inc. | Little Falls, N. Y. |
| 02875 | Hudson Tool & Die | Newark, N. J. | 07910 | Continental Device Corp. | Hawthorne, Cal. | 15203 | Webster Electronics Co. | New York, N. Y. |
| 03296 | Nylon Molding Corp. | Springfield, N. J. | 07933 | Raytheon Mfg. Co., Semiconductor Div. | Mountain View, Cal. | 15287 | Scionics Corp. | Northridge, Cal. |
| 03508 | G. E. Semiconductor Prod. Dept. | Syracuse, N. Y. | 07980 | Hewlett-Packard Co., New Jersey Division | Rockaway, N. J. | 15291 | Adjustable Bushing Co. | N. Hollywood, Cal. |
| 03705 | Apex Machine & Tool Co. | Dayton, Ohio | 08145 | U. S. Engineering Co. | Los Angeles, Cal. | 15558 | Micron Electronics | Garden City, Long Island, N. Y. |
| 03797 | Eldema Corp. | Compton, Calif | 08289 | Blinn, Delbert Co. | Pomona, Cal | 15566 | Amprobe Inst. Corp. | Lynbrook, N. Y. |
| 03818 | Parker Seal Co. | Los Angeles, Cal. | 08358 | Burgess Battery Co. | Niagara Falls, Ontario, Canada | 15631 | Cabletronics | Costa Mesa, Cal. |
| 03877 | Transitron Electric Corp. | Wakefield, Mass. | 08524 | Deutsch Fastener Corp. | Los Angeles, Cal. | 15772 | Twentieth Century Coil Spring Co. | Santa Clara, Cal. |
| 03888 | Pyrofilm Resistor Co., Inc. | Cedar Knolls, N. J. | 08664 | Bristol Co., The | Waterbury, Conn | 15801 | Fenwal Elect. Inc. | Framingham, Mass. |
| 03954 | Singer Co., Diehl Div., Finderne Plant | Sumerville, N. J. | 08717 | ITT Cannon Electric Inc., Phoenix Div. | Phoenix, Arizona | 15818 | Amelco Inc. | Mountain View, Cal. |
| 04009 | Arrow, Hart and Hegeman Elect. Co. | Hartford, Conn | 08772 | National Radio Lab Inc. | Paramus, N. J. | 16037 | Spruce Pine Mica Co. | Spruce Pine, N. C. |
| 04013 | Taruus Corp. | Lambertville, N. J. | 08792 | CBS Electronics Semiconductor Operations, Div. of CBS Inc. | Lowell, Mass | 16179 | Omni-Spectra Inc. | Detroit, Ill. |
| 04062 | Arco Electronic Inc. | Great Neck, N. Y. | 08806 | General Electric Co., M. n.ature Lamp Dept. | Cleveland, Ohio | 16352 | Computer Diode Corp. | Lodi, N. J. |
| 04217 | Essex Wire | Los Angeles, Cal. | 08984 | Mel-Rain | Indianapolis, Ind | 16554 | Electroid Co. | Union, N. J. |
| 04222 | Hi-Q Division of Aerovox | Myrtle Beach, S. C. | 09026 | Babcock Relays Div. | Costa Mesa, Calif. | 16585 | Boots Aircraft Nut Corp. | Pasadena, Cal. |
| 04354 | Precision Paper Tube Co. | Wheeling, Ill | 09097 | Electronic Enclosures Inc. | Los Angeles, Calif. | 16688 | Ideal Prec. Meter Co., Inc. | Brooklyn, N. Y. |
| 04404 | Palo Alto Division of Hewlett-Packard Co. | Palo Alto, Cal | 09134 | Texas Capacitor Co. | Houston, Texas | 16758 | Delco Radio Div. of G. M. Corp. | Kokomo, Ind. |
| 04651 | Sylvania Electric Products, Microwave Device Div. | Mountain View, Cal | 09145 | Tech. Ind. Inc. Atohm Elect. | Burbank, Cal. | 17109 | Thermometrics Inc. | Canoga Park, Cal. |
| 04673 | Dakota Engr. Inc. | Culver City, Cal | 09250 | Electro Assemblies, Inc. | Chicago, Ill. | 17474 | Trane Company | Mountain View, Cal. |
| 04713 | Motorola Inc. Semiconductor Prod. Div. | Phoenix, Arizona | 09353 | C & K Components Inc. | Newton, Mass. | 17875 | Hamilton Metal Products Corp. | Akron, Ohio |
| 04732 | Filttron Co., Inc. Western Div. | Culver City, Cal. | 09569 | Mallory Battery Co. of Canada, Ltd. | Toronto, Ontario, Canada | 17745 | Angstrom Prec. Inc. | No. Hollywood, Cal. |
| 04773 | Automatic Electric Co. | Northlake, Ill. | 09795 | Pennsylvania Fluorocarbon | Clifton Heights, Penn. | 17856 | Silconix Inc. | Sunnyvale, Cal. |
| 04796 | Sequoia Wire Co. | Redwood City, Cal. | 09922 | Burdny Corp. | Norwalk, Conn | 17870 | McGraw-Edison Co. | Manchester, N. H. |
| 04811 | Precision Coil Spring Co. | El Monte, Cal. | 10214 | General Transistor Western Corp. | Los Angeles, Cal. | 18042 | Power Design Pacific Inc. | Palo Alto, Cal. |
| 04870 | P. M. Motor Company | Westchester, Ill | 10411 | Ti-Tal, Inc. | Berkeley, Cal. | 18083 | Clevite Corp. Semiconductor Div. | Palo Alto, Cal. |
| 04919 | Component Mfg. Service Co. | W. Bridgewater, Mass. | 10646 | Carborandum Co. | Niagara Falls, N. Y. | 18324 | Signotics Corp. | Sunnyvale, Cal. |
| 05006 | Twentieth Century Plastics, Inc. | Los Angeles, Cal | | | | 18476 | Ty-Car Mfg. Co., Inc. | Holliston, Mass. |
| 05277 | Westinghouse Electric Corp. Semiconductor Dept. | Youngwood, Pa. | | | | 18486 | TRW Elect. Comp Div | Des Plaines, Ill. |

CODE LIST OF MANUFACTURERS (Continued)

| Code No. | Manufacturer | Address | Code No. | Manufacturer | Address | Code No. | Manufacturer | Address |
|----------|--|-----------------------------|----------|---|---|----------|--|--|
| 19644 | LRC Electronics | Horseheads, N. Y. | 71482 | C. P. Clare & Co. | Chicago, Ill. | 78452 | Thompson-Dremer & Co. | Chicago, Ill. |
| 19701 | Electra Mfg. Co. | Independence, Kansas | 71590 | Centralab Div. of Globe Union Inc. | Milwaukee, Wis. | 78471 | Tilley Mfg. Co. | San Francisco, Cal. |
| 20183 | General Atomics Corp. | Philadelphia, Pa. | 71616 | Commercial Plastics Co. | Chicago, Ill. | 78488 | Stackpole Carbon Co. | St. Marys, Pa. |
| 21226 | Executone, Inc. | Long Island City, N. Y. | 71700 | Cornish Wire Co., The | New York, N. Y. | 78493 | Standard Thomson Corp. | Waltham, Mass. |
| 21355 | Fafnir Bearing Co., The | New Britain, Conn. | 71707 | Coto Coal Co., Inc. | Providence, R. I. | 78553 | Timmerman Products, Inc. | Cleveland, Ohio |
| 21520 | Fansteel Metallurgical Corp. | N. Chicago, Ill. | 71744 | Chicago Miniature Lamp Works | Chicago, Ill. | 78790 | Transformer Engineers | San Gabriel, Cal. |
| 23020 | General Reed Co. | Metuchen, N. J. | 71785 | Cinch Mfg. Co. | Chicago, Ill. | 78947 | Uemite Co. | Newtonville, Mass. |
| 23042 | Texscan Corp. | Indianapolis, Ind. | 71984 | Howard B. Jones Div. | Chicago, Ill. | 79136 | Waldes Kohinor Inc. | Long Island City, N. Y. |
| 23783 | British Radio Electronics Ltd. | Washington, D.C. | 72136 | Dow Corning Corp. | Midland, Mich. | 79142 | Veeder Root, Inc. | Hartford, Conn. |
| 24455 | G. E. Lamp Division | Nela Park, Cleveland, Ohio | 72619 | Diallight Corp. | Willimantic, Conn. | 79251 | Wenco Mfg. Co. | Chicago, Ill. |
| 24655 | General Radio Co. | West Concord, Mass. | 72656 | Indiana General Corp | Brooklyn, N. Y. | 79727 | Continental-Wirt Electronics Corp. | Philadelphia, Pa. |
| 24681 | Memcor Inc., Comp. Div. | Huntington, Ind. | 72699 | General Instrument Corp. | Keasby, N. J. | 79963 | Zierick Mfg. Corp. | New Rochelle, N. Y. |
| 26365 | Gries Reproducer Corp. | New Rochelle, N. Y. | 72765 | Drake Mfg. Co. | Newark, N. J. | 80031 | Mepco Division of Sessions Clock Co. | Morrisstown, N. J. |
| 26462 | Grobart File Co. of America, Inc. | Carlstadt, N. J. | 72782 | Hughes Aircraft Co. | Newport Beach, Cal. | 80033 | Prestole Corp. | Toledo, Ohio |
| 26851 | Compac Hollister Co. | Hollister, Cal. | 72825 | Drake H. Eby Inc. | Harwood Heights, Ill. | 80120 | Schnitzer Alloy Products Co. | Elizabeth, N. J. |
| 26992 | Hamilton Watch Co. | Lanaster, Pa. | 72928 | Godeman Co. | Chicago, Ill. | 80131 | Electronic Industries Association. | Standard tube or semi-conductor device, any manufacturer |
| 28480 | Hewlett-Packard Co. | Palo Alto, Cal. | 72962 | Elastic Stop Nut Corp | Union, N. J. | 80207 | Unimax Switch, Div. Maxon Electronics Corp. | Wallingford, Conn. |
| 28520 | Heyman Mfg. Co. | Kenilworth, N. J. | 72964 | Robert M. Hadley Co. | Los Angeles, Cal. | 80223 | United Transformer Corp. | New York, N. Y. |
| 30817 | Instrument Specialties Co., Inc. | Little Falls, N. J. | 72982 | Ernie Technological Products, Inc. | Erie, Pa. | 80248 | Oxford Electric Corp. | Chicago, Ill. |
| 33173 | G. E. Receiving Tube Dept | Owensboro, Ky. | 73061 | Hansen Mfg. Co., Inc. | Princeton, Ind. | 80294 | Bourns Inc. | Riverside, Cal. |
| 35434 | Lectrohm Inc. | Chicago, Ill. | 73076 | H. M. Harper Co. | Chicago, Ill. | 80411 | Arco Div. of Robertshaw Controls Co. | Columbus, Ohio |
| 35196 | Stanwyck Coil Products Ltd. | Hawkesbury, Ontario, Canada | 73138 | Helipot Div. of Beckman Inst., Inc. | Fullerton, Cal. | 80486 | All Star Products Inc. | Defiance, Ohio |
| 36287 | Cunningham, W. H. & Hill Ltd. | Toronto, Ontario, Canada | 73293 | Hughes Products Division of Hughes Aircraft Co. | Newport Beach, Cal. | 80509 | Avery Label Co. | Monrovia, Cal. |
| 37942 | P. R. Mallory & Co., Inc. | Indianapolis, Ind. | 73445 | Amplex Electric Co. | Hicksville, L. I., N. Y. | 80583 | Hammarlund Co., Inc. | Mars Hill, N. C. |
| 39543 | Mechanical Industries Prod. Co. | Akron, Ohio | 73506 | Bardley Semiconductor Corp | New Haven, Conn. | 80640 | Stevens, Arnold, Co., Inc. | Boston, Mass. |
| 40920 | Miniature Precision Bearings, Inc. | Keene, N. H. | 73559 | Carling Electric, Inc. | Hartford, Conn. | 80813 | Dumco Gray Co. | Dayton, Ohio |
| 40931 | Honeywell Inc. | Minneapolis, Minn. | 73586 | Circle F Mfg. Co. | Trenton, N. J. | 81030 | International Inst. Inc. | Orange, Conn. |
| 42190 | Muter Co. | Chicago, Ill. | 73872 | George K. Garrett Co., Div. MSL Industries, Inc. | Philadelphia, Pa. | 81073 | Grayhill Co. | LaGrange, Ill. |
| 43990 | C. A. Norgren Co. | Englewood, Colo. | 73734 | Federal Screw Products, Inc. | Chicago, Ill. | 81095 | Triud Transformer Corp. | Venice, Cal. |
| 44655 | Ohmite Mfg. Co. | Skokie, Ill. | 73743 | Fischer Special Mfg. Co. | Cincinnati, Ohio | 81312 | Winchester Elec. Div. Litton Ind., Inc. | Oakville, Conn. |
| 46384 | Penn Eng. & Mfg. Corp. | Doylestown, Pa. | 73793 | General Industries Co., The | Elyria, Ohio | 81349 | Military Specification | |
| 47680 | Polaroid Corp. | Cambridge, Mass. | 73846 | Goshen Stamping & Tool Co. | Goshen, Ind. | 81483 | International Rectifier Corp. | El Segundo, Cal. |
| 48620 | Precision Thermometer & Inst. Co. | Southampton, Pa. | 73899 | JFD Electronics Corp. | Brooklyn, N. Y. | 81541 | Airpax Electronics, Inc. | Cambridge, Maryland |
| 49956 | Microwave & Power Tube Div. | Waltham, Mass. | 73905 | Jennings Radio Mfg. Corp. | San Jose, Cal. | 81860 | Barry Controls, Div. Barry Wright Corp. | Watertown, Mass. |
| 52090 | Rowan Controller Co. | Westminster, Md. | 73957 | Groove-Pin Corp. | Ridgely, N. J. | 82042 | Carter Precision Electric Co. | Skokie, Ill. |
| 52983 | HP Co., Med. Elec. Div. | Waltham, Mass. | 74276 | Signalite Inc. | Neptune, N. J. | 82047 | Sporti Faraday Inc., Copper Hewitt Electric Div. | Hoboken, N. J. |
| 54294 | Shallcross Mfg. Co. | Selma, N. C. | 74455 | J. H. Wynn, and Sons | Winchester, Mass. | 82116 | Electric Regulator Corp. | Norwalk, Conn. |
| 55026 | Simpson Electric Co. | Chicago, Ill. | 74861 | Industrial Condenser Corp. | Chicago, Ill. | 82142 | Jeffers Electronics Division of Speer Carbon Co. | Du Bois, Pa. |
| 55933 | Sonotone Corp. | Elmsford, N. Y. | 74868 | R. F. Products Division of Amphemul-Borg Electronic Corp. | Danbury, Conn. | 82170 | Fairchild Camera & Inst. Corp. | Paramus, N. J. |
| 55938 | Raytheon Co. Commercial Apparatus & System Div. | So. Norwalk, Conn. | 74970 | E. F. Johnson Co. | Waseca, Minn. | 82209 | Maguire Industries, Inc. | Greenwich, Conn. |
| 56137 | Spaulding Fibre Co., Inc. | Tonawanda, N. Y. | 75042 | International Resistance Co. | Philadelphia, Pa. | 82219 | Sylvania Electric Prod., Inc. | Electronic Tube Division Emporium, N. J. |
| 56289 | Sprague Electric Co. | North Adams, Mass. | 75263 | Keystone Carbon Co., Inc. | St. Marys, Pa. | 82376 | Astron Corp. | East Newark, Harrison, N. J. |
| 58474 | Superior Elect. Co. | Bristol, Conn. | 75382 | CTS Knights, Inc. | Sandwich, Ill. | 82389 | Switchcraft, Inc. | Chicago, Ill. |
| 59446 | Telex Corp. | Tulsa, Okla. | 75382 | Kulka Electric Corp. | Mt. Vernon, N. Y. | 82647 | Metals & Controls Inc. | Spencer Products Attleboro, Mass. |
| 59730 | Thomas & Betts Co. | Elizabeth, N. J. | 75818 | Lenz Electric Mfg. Co. | Chicago, Ill. | 82768 | Phillips-Advance Control Co. | Joliet, Ill. |
| 60741 | Triplett Electrical Inst. Co. | Bluffton, Ohio | 75915 | Littlefuse, Inc. | Des Plaines, Ill. | 82866 | Research Products Corp. | Madison, Wis. |
| 61775 | Union Switch and Signal Div. of Westinghouse Air Brake Co. | Pittsburgh, Pa. | 76005 | Lord Mfg. Co. | Erie, Pa. | 82877 | Rolton Mfg. Co., Inc. | Woodstock, N. Y. |
| 62119 | Universal Electric Co. | Owosso, Mich. | 76210 | C. W. Marwedel | San Francisco, Cal. | 82893 | Vector Electronic Co. | Glendale, Cal. |
| 63743 | Ward-Leonard Electric Co. | Mt. Vernon, N. Y. | 76433 | General Instrument Corp. | Micanoid Division Newark, N. J. | 83058 | Carr Fastener Co. | Cambridge, Mass. |
| 64959 | Western Electric Co., Inc. | New York, N. Y. | 76487 | James Millen Mfg. Co., Inc. | Malden, Mass. | 83085 | New Hampshire Ball Bearing, Inc. | Peterborough, N. H. |
| 65092 | Weston Inst. Inc. Weston-Newark | Newark, N. J. | 76493 | J. W. Miller Co. | Los Angeles, Cal. | 83125 | General Instrument Corp. | Capacitor Div. Darlington, S. C. |
| 66295 | Witteck Mfg. Co. | Chicago, Ill. | 76530 | Cinch-Monadnock, Div. of United Carr Fastener Corp. | San Leandro, Cal. | 83148 | ITT Wire and Cable Div. | Los Angeles, Cal. |
| 66346 | Minnesota Mining & Mfg. Co. Reverse Mincom Div. | St. Paul, Minn. | 76545 | Mueller Electric Co. | Cleveland, Ohio | 83186 | Victory Eng. Corp. | Springfield, N. J. |
| 70276 | Allen Mfg. Co. | Hartford, Conn. | 76703 | National Union | Newark, N. J. | 83298 | Bendix Corp., Red Bank Div. | Red Bank, N. J. |
| 70309 | Allied Control | New York, N. Y. | 76854 | Oak Manufacturing Co. | Crystal Lake, Ill. | 83315 | Hubbell Corp. | Mundelein, Ill. |
| 70318 | Allmetal Screw Product Co., Inc. | Garden City, N. Y. | 77068 | The Bendix Corp. | Electrodynamics Div. N. Hollywood, Cal. | 83324 | Rosan Inc. | Newport Beach, Cal. |
| 70417 | Amplex, Div. of Chrysler Corp. | Detroit, Mich. | 77075 | Pacific Metals Co. | San Francisco, Cal. | 83330 | Smith, Herman H., Inc. | Brooklyn, N. Y. |
| 70485 | Atlantic India Rubber Works, Inc. | Chicago, Ill. | 77221 | Phostran Instrument and Electronic Co. | So. Pasadena, Cal. | 83332 | Tech Labs | Palisades Park, N. J. |
| 70563 | Amperite Co., Inc. | Union City, N. J. | 77252 | Philadelphia Steel and Wire Corp. | Philadelphia, Pa. | 83385 | Central Screw Co. | Chicago, Ill. |
| 70674 | ADC Products Inc. | Minneapolis, Minn. | 77342 | American Machine & Foundry Co. | Potter & Brumfield Div. Princeton, Ind. | 83501 | Gavitt Wire and Cable Co., Div. of Amerace Corp. | Brookfield, Mass. |
| 70903 | Belden Mfg. Co. | Chicago, Ill. | 77630 | TRW Electronic Components Div. | Camden, N. J. | 83594 | Burroughs Corp., Electronic Tube Div. | Plainfield, N. J. |
| 70998 | Bird Electric Corp. | Cleveland, Ohio | 77638 | General Instrument Corp. | Rectifier Division Brooklyn, N. Y. | 83740 | Union Carbide Corp., Consumer Prod. Div. | New York, N. Y. |
| 71002 | Birnbach Radio Co. | New York, N. Y. | 77764 | Resistance Products Co. | Harrisburg, Pa. | 83777 | Model Eng. and Mfg., Inc. | Huntington, Ind. |
| 71034 | Bihley Electric Co., Inc. | Erie, Pa. | 77969 | Rubbercraft Corp. of Calif. | Torrance, Cal. | 83821 | Lloyd Scruggs Co. | Festus, Mo. |
| 71041 | Boston Gear Works Div. of Murray Co. of Texas | Quincy, Mass. | 78189 | Shakespeare Division of Illinois Tool Works | Elgin, Ill. | 83942 | Aeronautical Inst. & Radio Co. | Lodi, N. J. |
| 71218 | Bud Radio, Inc. | Willoughby, Ohio | 78277 | Sigma | So. Braintree, Mass. | 84171 | Arco Electronics Inc. | Great Neck, N. Y. |
| 71279 | Cambridge Thermionics Corp. | Cambridge, Mass. | 78283 | Signal Indicator Corp. | New York, N. Y. | 84396 | A. J. Giesener Co., Inc. | San Francisco, Cal. |
| 71286 | Canloc Fastener Corp. | Paramus, N. J. | 78290 | Struthers-Dunn Inc. | Pitman, N. J. | 84411 | TRW Capacitor Div. | Ogallala, Neb. |
| 71313 | Cardwell Condenser Corp. | Lindenhurst, L. I., N. Y. | | | | | | |
| 71400 | Bussmann Mfg. Div. of McGraw-Edison Co. | St. Louis, Mo. | | | | | | |
| 71436 | Chicago Condenser Corp. | Chicago, Ill. | | | | | | |
| 71447 | Calif. Spring Co., Inc. | Pico-Rivera, Cal. | | | | | | |
| 71450 | CTS Corp. | Elkhart, Ind. | | | | | | |
| 71468 | ITT Cannon Electric Inc. | Los Angeles, Cal. | | | | | | |
| 71471 | Cinema, Div. Acrovox Corp. | Burbank, Cal. | | | | | | |

00015-49
Revised May, 1970

From Handbook Supplements
H4-J Dated January 1970

CODE LIST OF MANUFACTURERS (Continued)

| Code No. | Manufacturer | Address | Code No. | Manufacturer | Address | Code No. | Manufacturer | Address |
|----------|---|----------------------|----------|--|------------------------|----------|---|---------------------|
| 94870 | Sarkes Tarzian, Inc. | Bloomington, Ind. | 91929 | Honeywell Inc., Micro Switch Division | Freeport, Ill. | 96095 | Hi-Q Div. of Aerovox Corp. | Olean, N. Y. |
| 85454 | Boonton Molding Company | Boonton, N. J. | | | | 96256 | Thordarson-Meissner Inc. | Mt. Carmel, Ill. |
| 85471 | A. B. Boyd Co. | San Francisco, Cal. | 91961 | Nahm-Bros. Spring Co. | Oakland, Cal. | 96296 | Solar Mfg. Co. | Los Angeles, Cal. |
| 85474 | R. M. Bracamonte & Co. | San Francisco, Cal. | 92180 | Tru-Connector Corp. | Peabody, Mass. | 96396 | Microswitch, Div. of | |
| 85660 | Koiled Kords, Inc. | Hamden, Conn. | 92367 | Elgeet Optical Co., Inc. | Rochester, N. Y. | | Minn.-Honeywell | Freeport, Ill. |
| 85911 | Seamless Rubber Co. | Chicago, Ill. | 92607 | Tensolite Insulated Wire Co., Inc. | | 96330 | Carlton Screw Co. | Chicago, Ill. |
| 86174 | Fafnir Bearing Co. | Los Angeles, Calif. | | | | 96341 | Microwave Associates, Inc. | Burlington, Mass. |
| 86197 | Clifton Precision Products Co., Inc. | Clifton Heights, Pa. | 92702 | IMC Magnetics Corp. | Westbury, L.I., N. Y. | 96501 | Excel Transformer Co. | Oakland, Cal. |
| | | | 92966 | Hudson Lamp Co. | Kearney, N. J. | 96508 | Xcelite, Inc. | Orchard Park, N. Y. |
| 86579 | Precision Rubber Products Corp. | Dayton, Ohio | 93332 | Sylvania Electric Prod. Inc., Semiconductor Div. | Woburn, Mass. | 96733 | San Fernando Elec. Mfg. Co. | San Fernando, Cal. |
| 86684 | Radio Corp. of America, Electronic Comp. & Devices Division | Harrison, N. J. | 93369 | Robbins & Myera Inc. | Pallisades Park, N. J. | 96881 | Thomson Ind. Inc. | Long Island, N. Y. |
| 86928 | Seastrom Mfg. Co. | Glendale, Cal. | 93410 | Stemco Controls, Div. of Essex Wire Corp. | Manassas, Ohio | 97464 | Industrial Retaining Ring Co. | Irvington, N. J. |
| 87034 | Marco Industries | Anaheim, Cal. | 93632 | Waters Mfg. Co. | Culver City, Cal. | 97539 | Automatic & Precision Mfg. | Englewood, N. J. |
| 87216 | Philco Corporation (Lansdale Division) | Lansdale, Pa. | 93929 | G. V. Controls | Livingston, N. J. | 97979 | Reon Resistor Corp. | Yonkers, N. Y. |
| 87473 | Western Fibrous Glass Products Co. | San Francisco, Cal. | 94137 | General Cable Corp. | Bayonne, N. J. | 97983 | Litton System Inc., Adler-Westrex Commun. Div. | New Rochelle, N. Y. |
| 87664 | Van Waters & Rogers Inc. | San Francisco, Cal. | 94144 | Raytheon Co., Comp. Div., Ind. Comp. Operations | Quincy, Mass. | 98141 | R-Tronics, Inc. | Jamaica, N. Y. |
| 87930 | Tower Mfg. Corp. | Providence, R. I. | 94148 | Scientific Electronics Products, Inc. | Loveland, Colo. | 98159 | Rubber Teck, Inc. | Gardena, Cal. |
| 88140 | Cutler-Hammer, Inc. | Lincoln, Ill. | 94154 | Wagner Elect. Corp., Tung-Sol Div. | Newark, N. J. | 98220 | Hewlett-Packard Co., Medical Elec. Div. | Pasadena, Cal. |
| 88220 | Gould-National Batteries, Inc. | St. Paul, Minn. | 94197 | Curtiss-Wright Corp., Electronics Div. | East Patterson, N. J. | 98278 | Microdot, Inc. | So. Pasadena, Cal. |
| 88698 | General Mills, Inc. | Buffalo, N. Y. | 94222 | South Chester Corp. | Chester, Pa. | 98291 | Seal Electro Corp. | Mamaroneck, N. Y. |
| 89231 | Graybar Electric Co. | Oakland, Cal. | 94330 | Wire Cloth Products, Inc. | Bellwood, Ill. | 98376 | Zero Mfg. Co. | Burbank, Cal. |
| 89473 | G. E. Distributing Corp. | Schenectady, N. Y. | 94375 | Automatic Metal Products Co. | Brooklyn, N. Y. | 98410 | Etc Inc. | Cleveland, Ohio |
| 89479 | Security Co. | Detroit, Mich. | 94682 | Worcester Pressed Aluminum Corp. | Worcester, Mass. | 98731 | General Mills Inc., Electronics Div. | Minneapolis, Minn. |
| 89665 | United Transformer Co. | Chicago, Ill. | 94696 | Magnecraft Electric Co. | Chicago, Ill. | 98734 | Paeco Division of Hewlett-Packard Co. | Palo Alto, Cal. |
| 90030 | United Shoe Machinery Corp. | Beverly, Mass. | 95023 | George A. Philbrick Researchers, Inc. | Boston, Mass. | 98821 | North Hills Electronics, Inc. | Glen Cove, N. Y. |
| 90179 | U. S. Rubber Co., Consumer Ind. & Plastics Prod. Div. | Passaic, N. J. | 95146 | Alco Elect. Mfg. Co. | Lawrence, Mass. | 98978 | International Electronic Research Corp. | Burbank, Cal. |
| 90365 | Belleville Speciality Tool Mfg., Inc. | Belleville, Ill. | 95236 | Allies Products Corp. | Dania, Fla. | 99109 | Columbia Technical Corp. | New York, N. Y. |
| 90763 | United Carr Fastener Corp. | Chicago, Ill. | 95238 | Continental Connector Corp. | Woodside, N. Y. | 99313 | Varian Associates | Palo Alto, Cal. |
| 90970 | Bearing Engineering Co. | San Francisco, Cal. | 95263 | Leecraft Mfg. Co., Inc. | Long Island, N. Y. | 99378 | Atlee Corp. | Winchester, Mass. |
| 91146 | ITT Cannon Elect. Inc., Salem Div. | Salem, Mass. | 95265 | National Coil Co. | Sheridan, Wyo. | 99515 | Marshall Ind., Capacitor Div. | Monrovia, Cal. |
| 91260 | Connor Spring Mfg. Co. | San Francisco, Cal. | 95275 | Vitramon, Inc. | Bridgeport, Conn. | 99707 | Control Switch Division, Controls Co. of America | El Segundo, Cal. |
| 91345 | Miller Dial & Nameplate Co. | El Monte, Cal. | 95348 | Gordos Corp. | Bloomfield, N. J. | 99800 | Delevan Electronics Corp. | East Aurora, N. Y. |
| 91418 | Radio Materials Co. | Chicago, Ill. | 95354 | Methodie Mfg. Co. | Rolling Meadows, Ill. | 99848 | Wilco Corporation | Indianapolis, Ind. |
| 91506 | Augat Inc. | Attleboro, Mass. | 95566 | Arnold Engineering Co. | Marengo, Ill. | 99928 | Branson Corp. | Whippany, N. J. |
| 91637 | Dale Electronics, Inc. | Columbus, Nebr. | 95712 | Dage Electric Co., Inc. | Franklin, Ind. | 99934 | Rembrandt, Inc. | Boston, Mass. |
| 91662 | Elco Corp. | Willow Grove, Pa. | 95984 | Siemon Mfg. Co. | Wayne, Ill. | 99942 | Hoffman Electronics Corp., Semiconductor Division | El Monte, Cal. |
| 91673 | Epiphone Inc. | New York, N. Y. | 95987 | Wekesser Co. | Chicago, Ill. | 99957 | Technology-Instrument Corp. of California | Newbury Park, Cal. |
| 91737 | Gremer Mfg. Co., Inc. | Wakefield, Mass. | 96067 | Microwave Assoc., West, Inc. | Sunnyvale, Cal. | | | |
| 91827 | K F Development Co. | Redwood City, Cal. | | | | | | |
| 91886 | Malco Mfg., Inc. | Chicago, Ill. | | | | | | |

The following HP Vendors have no number assigned in the latest supplement to the Federal Supply Code for Manufacturers Handbook.

| | | | | | | | | |
|-------|--------------------------------|--------------------|-------|--|----------------------------|-------|------------------------|-------------------|
| 0000F | Malco Tool and Die | Los Angeles, Calif | 000CS | Hewlett-Packard Co., Colorado Springs Div. | Colorado Springs, Colorado | 000QQ | Cooltron | Oakland, Cal |
| 0000Z | Willow Leather Products Corp. | Newark, N. J. | 000MM | Rubber Eng. & Development | Hayward, Cal. | 000WW | California Eastern Lab | Burlington, Cal. |
| 000AB | ETA | England | 000NN | A "N" D Mfg. Co. | San Jose, Cal. | 000YY | S. K. Smith Co. | Los Angeles, Cal. |
| 000BB | Precision Instrument Comp. Co. | Van Nuys, Cal. | | | | | | |

hp MANUAL BACKDATING CHANGES

Model 654A

TEST OSCILLATOR

Serials Prefixed: 0951 A-

This manual backdating sheet makes this manual applicable to earlier instruments. Instrument-component values that differ from those in the manual, yet are not listed in the backdating sheet, should be replaced using the part number given in the manual.

| Instrument Serial Prefix | Make Manual Changes | Instrument Serial Prefix | Make Manual Changes |
|--------------------------|---------------------|--------------------------|---------------------|
| 907-00200 and below | 1 | | |
| 951-00340 and below | 1, 2 | | |
| 0951 A00755 and below | 1, 2, 3 | | |
| 0951 A01700 and below | 1, 2, 3, 4 | | |
| 0951 A02260 and below | 1, 2, 3, 4, 5 | | |
| | | | |

CHANGE NO. 1

Table 6-1: Change A2R11 to R: fxd, 10 kΩ ± 1%, 1/8 W, -hp- Part No. 0757-0442.
 Change A2R12 to R: fxd, 4.02 kΩ ± 1%, 1/8 W, -hp- Part No. 0698-3558.

Figure 7-2: Change the value of A2R11 to 10 kΩ and the value of A2R12 to 4.02 kΩ.

CHANGE NO. 2

Table 6-1: Change the -hp- Part No. of J1 to 1251-0148
 Change the -hp- Part No. of W1 to 8120-0078.
 Change the -hp- Part No. of Panel: rear to 00653-00202 (Mechanical Parts).
 Change the -hp- Part No. of MP17 to 00653-01204.
 Delete MP50, Bracket: Attenuator -hp- Part No. 00653-01206.

CHANGE NO. 3

Change the -hp- Part No. of T1 to 9100-0294.

CHANGE NO. 4

Page 6-3, Table 6-1. Delete A2CR25 and A2CR26

Page 6-4, Table 6-1. Change A2 R61, 62 to A2R61, 62; 0757-0384; 20 ohms.
 Add A2R70 and A2R73, 0686-2015, 200 ohms ½ W.

Page 7-6. Change the A2 Component Locator as in Figure C-1.




Figure C-1. P/O A2 Component Locator

Page 7-7/7-8. Change A2 Schematic Diagram as in Figure C-2
Change A2R61 and 62 to 20 ohms.




Figure C-2. P/O A2 Schematic Diagram.

CHANGE NO. 5

Page 4-4, Replace Paragraphs 4-37 thru 4-41 with the following:

4-37. REGULATED POWER SUPPLIES.

4-38. The regulated power supplies provide all voltages required by the 654A circuits. The power supplies consist of a (nominally) + 31 volt series regulated supply and a (nominally) - 26 volt series regulated supply. The - 26 volt supply is referenced to the +31 volt supply.

4-39. The +31 volt regulated supply is of the conventional series regulator type. Q1 and A1Q1 are connected in the Darlington Configuration to increase loop gain of the circuit, thus improving voltage regulation. A1R14 allows the voltage to be adjusted to +31 volts (± 0.5); it also affects the - 26 volt supply (making the plus supply more positive, makes the negative supply more negative).

4-40. The - 26 volt regulated supply operates in a manner similar to the +31 volt supply. A1Q5 is a current limiter which conducts only when the load current exceeds the set value. Conduction of A1Q5 causes the series regulator Q2 to reduce the output voltage until the load causing the excessive current is

removed. Diodes A1CR6 and A1CR7 protect the control transistor A1Q4 from short circuits between the two supplies and short circuits at the output of the - 26 volt supply.

Delete Figure 4-2 and 4-3

Page 5-13, Paragraph 5-45 with the following:

5-45. POWER SUPPLY VOLTAGE ADJUSTMENTS.

- a. Connect a dc voltmeter to the power supply positive output (A1 Pin 12).
- b. Adjust A1R14 (+30 V Adjust) for 31, ± 0.2 V.
- c. Connect the dc voltmeter to the power supply negative output (A1 Pin 13). The voltage should be - 26, ± 0.5 V; if not, change the value of A1R15* to obtain the required voltage (increasing the value of A1R15* makes the power supply voltage less negative, and vice-versa).
- d. For power supply troubleshooting, refer to Paragraph 5-78.

Page 5-20, Paragraph 5-77. Replace Steps 9 thru 11 with the following:

- a. If only the - 26 V supply is inoperative proceed to branch (11).
- b. Check if the external circuits are loading the power supply by lifting A1 Pin 12 and A1R18 (Schematic No. 2). If the supply operates the trouble is in the external circuits. If the supply does not operate proceed to step c of this Paragraph.
- c. The - 26 V supply is referenced to the +31 V. To check if the - 26 V supply is loading the +31 V supply first lift A1 pin 13; if the supplies now operate the trouble is in the external circuits; if the supplies still do not operate, lift A1R15*, A1R6 and A1R7 to isolate the - 26 V supply from the +31 V supply. If the +31 V supply now operates the trouble is in the - 26 V does not operate troubleshoot the +31 V supply.

Check T1 and the line filter components; also check A2CR1 thru A1CR4, A1C9 and A1C10.

- a. Troubleshoot the - 26 V supply if you have arrived here from branch (9)c.
- b. Lift A1 Pin 13 to isolate the - 26 V supply from external circuits. If the supply now operates the trouble is in the external circuits; if the -26 V supply does not operate troubleshoot.

Page 5-27/5-28, Figure 18. Change Step 10 to Step 11 and Change Step 11 to Step 10.

Page 6-2, Table 6-1. Change the A1 Replaceable Parts list as in Table C1.

Table C-1. A1 Replaceable Parts.

| REFERENCE DESIGNATOR | -hp- PART NO. | TQ | DESCRIPTION | MFR | MFR. PART NO. |
|----------------------|---------------|----|--|-------|----------------------|
| A1 | 00654 66501 | 1 | PC board: power supply | -hp- | |
| C1,C2 | 0180-0149 | 4 | C: fxd Al elect 65 uF +100% -10% 60 vdcw | 56289 | D36978-DSM |
| C3,C4 | 0150-0059 | 2 | C: fxd cer 0.001 uF +100% -20% 500 vdcw | 72982 | S01-010X5G0102Z |
| C5,C6 | 0180-0045 | 2 | C: fxd Al 20 uF +75% -10% 25 vdcw | 56289 | 30D206G025C82-DSM |
| C7,C8 | 0180-0149 | 2 | C: fxd Al elect 65 uF +100% -10% 60 vdcw | 56289 | (type 30D)036978-DSM |
| C9,C10 | 0150-0052 | 2 | C: fxd cer 0.05 uF +/-20% 400 vdcw | 56289 | 33C17A-CDH |
| CR1 thru CR4 | 1901-0158 | 4 | Diode: Si 200 piv | 04713 | SR13583 |
| CR5 | 1902-0049 | 1 | Diode: breakdown 6.19V +/-5% 400 mW | 04713 | SZ10939-122 |
| CR6,CR7 | 1901-0025 | 14 | Diode: Si 100 mA at +1V 100 piv 12 pF | 07333 | RD1526 |
| CR8 | 1902-0777 | 2 | Diode: zener 1N825 6.2V +/-5% 400 mW | 12354 | obd |
| CR9 | 1901-0025 | 2 | Diode: Si 100 mA at +1V 100 piv 12 pF | 07333 | RD1526 |
| Q1 | 1853-0037 | 2 | TSTR: Si PNP 2N4036 | 04713 | SS2109 |
| Q2 | 1853-0036 | 8 | TSTR: Si PNP 2N3906 | 04713 | SPS-3612 |
| Q3 | 1853-0037 | 2 | TSTR: Si PNP 2N4036 | 04713 | SS2109 |
| Q4,Q5 | 1853-0036 | 8 | TSTR: Si PNP 2N3906 | 01713 | SPS-3612 |
| R1 thru R4 | 0683-3925 | 4 | R: fxd comp 3900 ohms +/-5% 1/4 W | 01121 | C83925 |
| R5 | 0686-7525 | 1 | R: fxd comp 7500 ohms +/-5% 1/2 W | 01121 | E87525 |
| R6 | 0687-1531 | 1 | R: fxd comp 15 kilohms +/-10% 1/2 W | 01121 | E81531 |
| R7 | 0683-4335 | 1 | R: fxd comp 43 kilohms +/-5% 1/4 W | 01121 | C84335 |
| R8 | 0687-3921 | 1 | R: fxd comp 3900 ohms +/-10% 1/2 W | 01121 | E83921 |
| R9 | 0683-8215 | 1 | R: fxd comp 820 ohms +/-5% 1/4 W | 01121 | C83215 |
| R10,R11 | 0689-0915 | 2 | R: fxd carbon comp 9.1 ohms +/-5% 1 W | 01121 | G8-91G5 |
| R12 | 0757-0273 | 1 | R: fxd met flm 3010 ohms +/-1% 1/8 W | 91637 | MF-1/10-32 |
| R13 | 0698-4020 | 1 | R: fxd met flm 9.53 kilohms +/-1% 1/8 W | 91637 | MF-1/10-32 |
| R14 | 2100-0090 | 1 | R: var comp lin 2000 ohms +/-30% 0.15 W | 71450 | UPM-70RE(hp) |
| R15* | 0683-2715 | 1 | R: fxd comp 270 ohms +/-5% 1/4 W | 01121 | C82715 |
| R16 | 0757-1013 | 1 | R: fxd met flm 6000 ohms +/-1% 1/2 W | 75242 | CEC T O |
| R17 | 0757-0039 | 1 | R: fxd met flm 5030 ohms +/-1% 1/2 W | 91637 | MFF 1/2 T-1 |
| R18 | 0698-4988 | 1 | R: fxd met flm 1180 ohms +/-1% 1/2 W | 91637 | MFF 1/2 T-1 |

Page 6-6, Table 6-1. Change the -hp- Part Number of Q1, and Q2 to 1850-0098, TSTR: GE PNP (SELECTED).

Page 7-7/7-8. Change A1 Schematic Diagram as in Figure C-3.





Figure C-3. Amplitude Reference Supply.

Page 7-11, Figure 7-5. Change the A1 Power Supply Component Locator and Schematic Diagram as in Figure C-4 and C-5.



654A-B-1819

A1
hp Part No. 00654-66501

Figure C-4. A1 Component Locator.




Figure C-5. A1 Schematic Diagram.



hp MANUAL CHANGES

MODEL 654A

TEST OSCILLATOR

-hp- Part Number 00654-90003

► New or Revised Item

CHANGE NO. 1 for serial numbers 0951A02608 and greater.

Page 6-3, Change A2C24 to -hp- part number 0160-0362 (C:Fxd 510 pF 300 V).

Page 6-4, Change A2CR20 -hp- part number 1902-0025 (Diode-Bkdn 10 V).

Change A2Q25 to -hp- part number 1854-0092 (Xstr-2N3563).
Change A2R26 to -hp- part number 0698-4014 (R:Fxd 787 ohm 1%).

Page 6-5, Change A2R64 to -hp- part number 0686-4315 (R:Fxd 430 ohm 5%).

Change A2R65 to -hp- part number 0757-0284 (R:Fxd 150 ohm 1%).

Change A2R82 to -hp- part number 0698-4424 (R:Fxd 1400 ohm 1%).

Change A2R79 to -hp- part number 0757-0273 (R:Fxd 3010 ohm 1%).

Add A2R29 -hp- part number 0757-0442 (R:Fxd 10 ohm 1% 1/8 W).

Add A2R94, R95 -hp- part number 0683-0475 (R:Fxd 4.7 ohm 5%).

Figure 7-2, Page 7-5. Add A2R29 as follows:





Figure 7-3, Page 7-7, 7-8. Add A2R94, R95 as follows:



CHANGE NO. 2 for serial numbers 0951A02491 and greater.

19 November 1979

Page 1-1, Paragraph 1-7. Delete Paragraph 1-7.

Add new Paragraph 1-7: Options: Option 908 Rack Mount Kit, -hp- part number 5060-8740, Option 910: Additional Manual -hp- part number 00654-90003.

Page 2-1, Paragraph 2-14. Change last sentence to read as follows:

Conversion to a Rack MOUNTed instrument can be accomplished by using the Rack Mount Kit Option 908.

CHANGE NO. 3 for all serial numbers.

Page 5-2, Table 5-1. Change thermal converter (e) 600 ohms, balanced. Part number to -hp- part number H13-11049A.

Page 5-5, Table 5-3. Change thermal converter part number for 600 BAL to -hp- part number H13-11049A.

Page 5-19. Add Table 5-4A. Padding List A4C1.

| Value | -hp- Part No. |
|-------|---------------|
| 24 pF | 0160-0196 |
| 30 pF | 0160-2199 |
| 33 pF | 0160-2150 |
| 39 pF | 0140-0190 |

CHANGE NO. 4 for serial numbers 0951A02691 and greater.

Page 6-3, Table 6-1. Change A2C43 to -hp- part number 0121-0127 (C:Var 1. 7/14.1 pF 350 V).

Page 7-7/7-8, Figure 7-3. Change value of A2C43 to 1.7 – 14.1 pF.

CHANGE NO. 5 for serial numbers 0951A02926 and greater.

Page 6-12, Table 6-1. Add the following:

| | | |
|---------|-------------|----------------|
| Holder: | Fuse | -hp- 2110-0470 |
| Cap: | Fuse | -hp- 2110-0465 |
| Nut: | Fuse Holder | -hp- 2110-0467 |
| Washer: | Lock | -hp- 2190-0054 |
| Washer: | Rubber | -hp- 1400-0090 |

CHANGE NO. 6 for all serial numbers.

Page 1-2, Table 1-2. General information. Change power supply specification to 115 V ± 10%, 48 Hz to 440 Hz, 230 V ± 10%, 48 Hz to 66 Hz, 30 W nominal, 35 W maximum.

CHANGE NO. 7 for serial numbers 0951A02771 and greater.

Page 6-3, Table 6-1. Replaceable Parts. Add the following padding list to A2C21*.

| | |
|-----------|----------------|
| 0150-0029 | Cap-Fxd 1 pF |
| 0150-0011 | Cap-Fxd 1.5 pF |
| 0150-0031 | Cap-Fxd 2.0 pF |

Add the following padding list to A2C36*.

| | |
|-----------|----------------|
| 0150-0029 | Cap-Fxd 1 pF |
| 0150-0011 | Cap-Fxd 1.5 pF |
| 0150-0031 | Cap-Fxd 2.0 pF |

Supplement A for 00654-90003

Page 6-5, Table 6-1. **Replaceable Parts.** Add the following padding list to A2R61*, R62*:

| | |
|-----------|-------------------------|
| 0698-3432 | Res - Fxd 26.1 Ω |
| 0698-0078 | Res - Fxd 28.0 Ω |
| 0757-0388 | Res - Fxd 30.1 Ω |
| 0698-4376 | Res - Fxd 32.4 Ω |
| 0757-0368 | Res - Fxd 34.0 Ω |
| 0757-0390 | Res - Fxd 36.5 Ω |
| 0698-3435 | Res - Fxd 38.3 Ω |

CHANGE NO. 8 Serial Numbers 0951A03056 and Greater.

Page 6-4, Table 6-1. **Replaceable Parts.** Change A2CR15 thru A2CR18 from 1901-0025, Diode:Si to 1901-0033, Diode:Si .1 A 180 V.

CHANGE NO. 9 applies to all Serial Numbers.

Page 7-5. Delete the asterisk (*), which denotes a component that may be padded, on the following components:

| | |
|-----------------|-----------|
| C3*, C5* | 0140-0146 |
| C1*, C13*, C17* | 0150-0011 |
| C16*, C18* | 0150-0029 |
| C9*, C11* | 0160-0763 |
| C15*, C7* | 0160-2322 |
| R2* | 0686-1545 |
| R10* | 0686-1855 |

Page 6-7. Add the following part to the S2 (00653-61901) Range Switch Assembly list:

| -hp- Part No. | TQ | Description |
|---------------|----|-------------|
| 2260-0001 | 2 | Hex-Nut |

Page 6-6. Delete CR4 (-hp- Part Number 1901-0347).

Page 7-9/7-10. A4, C1* may consist of any of the following parts:

| | |
|-------|-----------|
| 24 pF | 0160-0196 |
| 30 pF | 0160-2199 |
| 33 pF | 0160-2150 |

Page 6-6. Add the following part to the A4 (00654-66504) Impedance PC board list:

| -hp- Part No. | TQ | Description |
|---------------|----|------------------|
| 0380-0959 | 1 | Standoff-Captive |

Page 6-7. Change Power Switch S1 to 3101-2147.