

User's Guide for the NREL Force and Loads Analysis Program (FLAP)

Version 2.2

Alan D. Wright



National Renewable Energy Laboratory
(formerly the Solar Energy Research Institute)
1617 Cole Boulevard
Golden, Colorado 80401-3393
A Division of Midwest Research Institute
Operated for the U.S. Department of Energy
under Contract No. DE-AC02-83CH10093

August 1992

NOTICE

This report was prepared as an account of work sponsored by an agency of the United States government. Neither the United States government nor any agency thereof, nor any of their employees, makes any warranty, express or implied, or assumes any legal liability or responsibility for the accuracy, completeness, or usefulness of any information, apparatus, product, or process disclosed, or represents that its use would not infringe privately owned rights. Reference herein to any specific commercial product, process, or service by trade name, trademark, manufacturer, or otherwise does not necessarily constitute or imply its endorsement, recommendation, or favoring by the United States government or any agency thereof. The views and opinions of authors expressed herein do not necessarily state or reflect those of the United States government or any agency thereof.

Printed in the United States of America
Available from:
National Technical Information Service
U.S. Department of Commerce
5285 Port Royal Road
Springfield, VA 22161

Price: Microfiche A01
Printed Copy A11

Codes are used for pricing all publications. The code is determined by the number of pages in the publication. Information pertaining to the pricing codes can be found in the current issue of the following publications which are generally available in most libraries: *Energy Research Abstracts (ERA)*; *Government Reports Announcements and Index (GRA and I)*; *Scientific and Technical Abstract Reports (STAR)*; and publication NTIS-PR-360 available from NTIS at the above address.

Summary

The following report gives the reader an overview of and instructions on the proper use of the National Renewable Energy Laboratory Force and Loads Analysis Program (FLAP, version 2.2). It is intended as a tool for prediction of rotor and blade loads and response for two- or three-bladed rigid hub wind turbines. The effects of turbulence are accounted for.

The objectives of the report are to give an overview of the code and also show the methods of data input and correct code execution steps in order to model an example two-bladed rigid hub turbine. A large portion of the discussion (Sections 6.0, 7.0, and 8.0) is devoted to the subject of inputting and running the code for wind turbulence effects. The ability to include turbulent wind effects is perhaps the biggest change in the code since the release of FLAP version 2.01 in 1988.

This report is intended to be a user's guide. It does not contain a theoretical discussion on equations of motion, assumptions, underlying theory, etc. It is intended to be used in conjunction with Wright, Buhl, and Thresher (1988).

Hopefully, this report will assist new users in the understanding of code input preparation and correct code execution.

Table of Contents

	<u>Page</u>
Summary	iii
Nomenclature	vii
1.0 Introduction	1
2.0 Code Overview	2
3.0 New Code Inputs	4
4.0 Example Turbine Description	5
5.0 Preparation of Input Data	9
6.0 Preparation of Turbulent Wind Input Data	14
7.0 Input of Turbulence Data to FLAP	15
8.0 Example Interactive Run	17
8.1 Module 1—FLAP1	17
8.2 Module 2—FLAP2	17
9.0 Conclusions	19
10.0 References	20
11.0 Acknowledgments	21
Appendix A: Module 1 Input File, Interactive Run Listing, and Output Files	A-1
Appendix B: Module 2 Interactive Run Listing and Output Files	B-1
Appendix C: Module 1 Listing	C-1
Appendix D: Module 2 Listing	D-1
Appendix E: Modules 1 and 2 Flowcharts	E-1

List of Figures

	<u>Page</u>
4-1 Illustration of example turbine	5
4-2 Turbine blade planform, thickness, and twist	6
4-3 Turbine blade stiffness distribution	6
4-4 Turbine blade weight distribution	7
4-5 Lift profile for the LS(1) airfoil	7
5-1 Illustration of rotor geometry	10

List of Tables

	<u>Page</u>
4-1 Example Turbine Specifications	8

Nomenclature

C_D	Drag coefficient
C_L	Lift coefficient
deg	Degrees
ft	Feet
m	Meters
rad	Radians
Ω	Rotor rotation rate (RPM)

1.0 Introduction

The following report is intended to be a guide for the correct use of the National Renewable Energy Laboratory (NREL) Force and Loads Analysis Program (FLAP, Version 2.2). The original equations of motion that formed the basis for FLAP (version 2.01) have been retained. The main change is the ability to calculate blade response and loads caused by turbulence.

Degrees of freedom include four-blade elastic flap modes. A prescribed time-dependent sinusoidal yaw function can be input to the code.

The report gives a general overview of the code. A description of new input variables (compared to FLAP version 2.01 of 1988) is given. Then, an example of a two-bladed, rigid hub wind turbine is described. Preparation of the basic data input file for this two-bladed turbine is described. Then, the methods of turbulent wind input preparation and input of turbulence to FLAP are explained. Finally, an interactive run session for both modules is illustrated. Code listings and output results are contained in the appendices.

2.0 Code Overview

FLAP (Force and Loads Analysis Program) analyzes two- or three-bladed rigid hub rotors. It predicts blade loads that result from such effects as gravity, windshear, tower shadow, and turbulent wind fluctuations. It also predicts shaft loads caused by gravity, windshear, and tower shadow.

Degrees of freedom included in this model are four elastic flap modes for the blade. Blade torsion and edgewise degrees of freedom are not included. The tower top is assumed to be fixed in space. The model assumes constant rotor speed. Although machine yaw is not considered to be a degree of freedom, a prescribed time-dependent yaw motion can be input to the code.

FLAP is basically a derivative of the Force and Loads Analysis Program (FLAP; Version 2.01) (Wright, Buhl, and Thresher, 1988).

This version of FLAP is similar to FLAP 2.01 in that a quasi-steady linear aerodynamic model is used to compute blade aerodynamic forces. The lift is modeled as a linear function of angle of attack up to stall. Past stall, lift is set equal to a constant. The drag is modeled as a quadratic function involving lift coefficient. For more details, see Section 5.0 of Wright, Buhl, and Thresher (1988).

FLAP is composed of two modules (FLAP1 and FLAP2). The first module is a preprocessor that reads blade and machine property data. It computes such items as blade flapwise frequencies and modeshapes as well as stiffness, mass, coriolis, and other matrices. These quantities are variables that do not generally change from one run to the next and, thus, are computed once.

Distributed blade properties such as the blade's stiffness, weight, twist, and chord may be read into Module 1 at unevenly spaced points. The input data is then interpolated to form sets of evenly spaced data. Another capability of this module is calculation of the blade's flapwise frequencies and modeshapes. This information is written to a file for examination by the user. From this information, the user can check the effects of mass and stiffness on blade frequencies and modeshapes.

We assume in this version of FLAP that both blades have identical mass, stiffness, twist, and chord distributions. In Module 1, mass, stiffness, and other matrices are calculated for only one blade. The effects of mass, pitch, and twist imbalances are not accounted for in this model.

The second module (FLAP2) calculates the blade equations of motion and computes blade and low-speed shaft loads. The code calculates the rotor response to such input as gravity, windshear, tower shadow, yaw misalignment, and yaw rate. The response to these inputs is generally a steady-state one. The code is run with initial values for the blade deflection and velocity. Once the blade reaches a steady-state trim solution, the blade deflection and loads are calculated and written to a file. The shaft loads are also calculated and written to a separate file.

The rotor response and load calculations resulting from time-dependent yaw motion or turbulent wind input is handled differently than the trim case. In those cases, a steady-state trim solution is calculated first, before the code enters the transient portion of the solution process. The results of this trim solution are then used as initial conditions for the transient analysis. After this trim solution is completed, the time clock is started, and the model is run, with the yaw function evaluated at each azimuth position. The yaw-function values for the initial yaw-angle displacement, yaw-angle amplitude, and maximum yaw velocity are set by the user during the model-run setup. Because the yaw function is given independently of the rotor model, the model solution from one rotor revolution to the next will not be steady state.

The number of revolutions to be run in the yaw solution is set by the user during run setup. After each rotor-revolution solution in the yaw routine, loads are computed and printed out.

The procedure for calculating rotor response and loads resulting from turbulent wind fluctuations is similar to the yaw solution procedure described above. The code first calculates rotor response for a trim (steady-state) solution. The computed values for blade deflection and velocity at zero azimuth (blade straight up) are then used as initial conditions for the transient analysis.

In order to run a turbulence analysis with FLAP, a file of turbulent, rotationally sampled wind data is needed. Such a file of data can be generated by such codes as the VEERS Three-Dimensional Wind Simulation (Veers, 1988). Additional details of this file generation and code execution with turbulence will be given in Sections 6.0 and 7.0. Example input to Module 1 are described next, including preparation of blade property data for an example turbine. First, some new code input parameters are described.

3.0 New Code Inputs

New code inputs include NUMSCN, TIMINC, MSTAT, and STA. All these variables are related to the input of turbulent windspeed fluctuations from a separate file. This file of windspeed data must be produced using a separate code, such as the VEERS model (Veers, 1988).

NUMSCN is the number of lines of windspeed data in the turbulent wind input file. For example, a windspeed file may have 8,192 lines of data. TIMINC is the time increment between each line of wind data. An example file might be sampled in the VEERS model at 24 Hz so that $TIMINC = 1/24$ sec (.041667 sec). MSTAT is the number of blade stations at which turbulent wind data are input. At the present time, only a value of $MSTAT = 2$ is input. STA represents the actual points on the rotor at which wind data are input, in this case, at 20 and 40 ft. These stations correspond to the 50% and 100% blade radial stations. It is important to note that STA represents the distance from the rotor center of rotation and not the distance from the blade root. More details will be given in Sections 6.0 and 7.0 on turbulence input.

4.0 Example Turbine Description

We will show the data input file preparation for an example two-bladed, rigid-hub turbine. Before showing code input, the turbine will be described. This is a fictitious two-bladed, rigid-hub wind turbine.

The example wind turbine, shown in Figure 4-1, is a two-bladed, fixed-pitch, free-yaw, downwind, stall-controlled rotor turbine. It has a rotor diameter of 24 m (80 ft) and features wood epoxy composite rotor blades. These blades use LS(1)-04XX airfoils with thickness distribution and planform shown in Figure 4-2. This blade has a chord taper ratio of 2.2 beginning at the 30% blade radial station. Figure 4-2 also describes the linear trailing-edge-drop twist distribution of 4.0 deg. Blade stiffness and mass distributions are shown in Figures 4-3 and 4-4. The lift and drag profiles for the LS(1) are shown in Figure 4-5. The blade pitch is set to zero degrees measured at the 75% blade span. The rotor has a solidity of 0.035 and a coning angle of 7.0 deg angled away from the tower. The teetered rotor has a delta-3 angle of zero degrees and rotates at a constant rotational speed of 60 RPM. Aerodynamically shaped tip vanes mounted at the blade tip perpendicular to the spanwise axis provide overspeed protection and assist in high-wind stops. Table 4-1 summarizes the major turbine specifications for the test turbine.

The distance from the yaw axis to the center of the hub is 6.79 ft.

Figure 4-1. Illustration of example turbine




Figure 4-2. Turbine blade planform, thickness, and twist




Figure 4-3. Turbine blade stiffness distribution





Figure 4-4. Turbine blade weight distribution



BA-G0245801

Figure 4-5. Lift profile for the LS(1) airfoil

Table 4-1. Example Turbine Specifications.

Rated Power	250 kW
Rated Windspeed	20.3 m/s (45 mph) Rotor
Diameter	24.5 m (80 ft)
Rotor Type	Two-Bladed Rigid Hub
Rotor Orientation	Downwind
Blade Construction	Wood Epoxy Composite
Rotor Airfoil	NASA LS(1) 0417
Tip Speed	77.9 m/s (173 mph)
Cut-in Windspeed	5.9 m/s (13 mph)
Rotor RPM	60 RPM
Generator RPM	1,800 RPM
Generator Type	300-kW Induction, 3 Phase
Gearbox	Planetary
Hub Height	24.9 m (81.5 ft)
Tower	Open - Truss
Pitch Control	None
Yaw	Passive
Overspeed Control	Tip Vanes
Total System Weight	9,750 Kg (21,500 lbs)
Coning	7 deg
Rotating Natural Frequencies	
First Flapwise	2 Hz
Second Flapwise	7.8 Hz

5.0 Preparation of Input Data

Appendix A, page A-2, shows the basic input file to Module 1 for the turbine. We will now describe the basis for assigning values to these inputs.

ALENTH (ft)

The distance from the tower centerline or yaw axis to the center of the hub (point where the two blades intersect) is 6.79 ft.

ALPHA ϕ (deg)

This variable represents the angle from the chord line to the zero lift line. This angle can be found from examination of the lift curve for the LS(1) airfoil shown in Figure 4-5 and represents the angle of attack at which C_L is equal to zero. It is equal to -4 deg for this airfoil. We assume a constant ALPHA ϕ for the entire blade span. Provisions for changing ALPHA ϕ with blade span are not provided in this version of FLAP.

CHI (deg)

The angle CHI is the rotor shaft tilt, set equal to zero for this turbine. See Wright, Buhl, and Thresher (1988) for more details.

CSUBMA

This variable represents the airfoil pitching moment coefficient, set equal to 0.015 for this airfoil. For more details, see Wright, Buhl, and Thresher (1988), page 13. This input is not very important for calculation of flap-bending moments.

DRGFRM

This input variable is used in the calculation of airfoil drag coefficient, as given in Wright, Buhl, and Thresher (1988), equation 4-7, page 85. It can be found by fitting a second-order equation of the form given in Wright, Buhl, and Thresher (1988) to the airfoil C_D versus C_L curve. For this airfoil, the value for DRGFRM was calculated as 0.0032.

HUBHT (ft)


The hub height of this turbine is 80 ft.

BETA ϕ (deg)

The precone angle for this rotor is 7 deg.

BLSHNK (ft)

BLSHNK is defined as the length of blade shank measured from the blade root to the point where the airfoil section begins. A nonzero value for BLSHNK must always be input to this code. If the particular rotor being analyzed has a zero blade shank, set BLSHNK to some small number (.01). Figure 5-1 clarifies the definition of this variable. The main purpose of this variable is to identify the portion of the blade



BA 00046403

Figure 5-1. Illustration of rotor geometry

not producing aerodynamic lift. For this case, $BLSHNK = 0.8$ ft. Input of a zero for $BLSHNK$ will cause an error in code execution.

BLTIP (ft)

This variable is the blade length, as measured from the blade root to the tip. This value will not, in general, be equal to the rotor radius (see Figure 5-1). For this turbine, $BLTIP$ is set equal to 38 ft because we have a hub radius of 2 ft. The hub is not considered as part of the blade.

HUBRAD (ft)

$HUBRAD$ is the distance from the axis of rotation to the blade root. For this rotor, $HUBRAD$ is set equal to 2 ft. Figure 5-1 clarifies this input variable.

KSHADW

This variable is used in the tower shadow model (see Wright, Buhl, and Thresher, 1988, pages 7, 88). It represents the number of oscillations in the tower shadow region. For this turbine, it is set to 3 because we have a three-legged truss tower.

NBLADS

The number of blades is set to 2.

NPANEL

This variable represents the number of points on the blade, beginning at the root and ending at the tip, in which distributed blade properties are input. We input properties at 11 points along the blade. The maximum value for $NPANEL$ is 11.

OMEGA (RPM)

The rotor speed is 60 RPM.

PHIAMP (deg)

This variable is set to zero because we are not performing a yaw motion solution. See Ref. 2 for more details. This variable defines the yaw-motion amplitude in the time-dependent yaw solution.

PHIOMG (deg/sec)

This variable is also set to zero. This variable defines the steady yaw rate in the trim solution or the maximum yaw rate in a yaw-motion, time-dependent solution. (See Wright, Buhl, and Thresher, 1988).

PHI ϕ (deg)

This variable is set to +13 deg because the steady yaw error for this data case was 13 deg (see Wright, Buhl, and Thresher, 1988). See Wright and Butterfield (1992) for yaw error definition.

PSIZER

This variable represents the tower shadow half-width. The tower shadow is modeled as a pie-shaped sector centered about the tower centerline. The value of PSIZER was arbitrarily selected as 20 deg for this machine. For more details, see Wright, Buhl, and Thresher (1988), page 7.

SHERXP

The power law windshear relation given in Wright, Buhl, and Thresher (1988), page 7, had an exponent equal to 0.164 for this case. This value was determined from analysis of anemometer data at three heights, as described in Wright and Butterfield (1992).

THETAP

This variable represents the angle between the principal flapwise bending plane and the cone of rotor rotation. If the blade elastic flapping motion is considered to occur perpendicular to the rotor plane, then THETAP should be set to zero. If flapping motion is considered to occur about the section chord line at the blade root, then THETAP should be set to the angle between this chord line and the rotor cone of rotation.

For a single code run, the orientation of flapping is constant; it does not change from blade station to station because of changes in pretwist. To change the flapping direction for other stations, the code must be rerun with appropriate values of THETAP. All load and deflection results are referenced to this one axis system (the X_p , Y_p , Z_p axes [Wright, Buhl, and Thresher, 1988]). For this case, we set THETAP to 2 deg to reflect flapping about the root chord line. For more details, see Wright, Buhl, and Thresher (1988), pages 13 and 86.

THETAT

This variable represents the difference in twist between the reference station and the tip. Because the reference station was selected at the root, this twist difference is 4 deg.

TSUBP and TSUB ϕ

For formal definitions of these variables, see Wright, Buhl, and Thresher (1988), equation 3-3. These two parameters are used to set the shape and magnitude of the velocity profile in the tower shadow region.

Setting both these inputs equal to .05 gives us a cosine squared velocity deficit. The magnitude of the deficit is 10% of the hub height windspeed. If we set $TSUB\phi = 0.1$ and $TSUBP = 0$, then we have a square wave-shaped velocity profile with a deficit of 10% of the free-stream windspeed. For more information, see Wright, Buhl, and Thresher (1988).

VHUB (ft/s)

The hub height free-stream windspeed for this case was 33.64 ft/sec.

XLEFT

We used 11 points to input distributed property data. The first point XLEFT(1) is located at the blade root. The last point XLEFT(11) is located at the blade tip. The other points are chosen to help approximate the blade's mass, stiffness, twist, and chord distributions.

WEIGHT

We wanted to include the 42-lb tip weight in the blade's distributed weight input (provisions for inputting a concentrated tip weight are not included). We placed points at 36.0, 36.2, and 38.0 ft.

Distributed property data are interpolated in Module 1 to form a set of evenly spaced data. Between each value of XLEFT, the property data are being linearly interpolated. The point 36.2 was chosen to allow the weight to change rapidly in order to model the tip weight.

The other values chosen for WEIGHT were based on the blade's weight distribution, shown in Figure 4-4.

AEIARE ($\times 10^6$ lb-ft²)

Figure 4-3 shows the stiffness distributions for this airfoil. Input of values from this plot result in overprediction of the blade's flapwise bending frequencies. We deliberately reduced these values uniformly along the blade so that the predicted flapwise frequencies will agree with test data. It is known that the first symmetric flapwise frequency is approximately 2 Hz. Values taken directly from Figure 4-3 result in overprediction of the frequencies. The user can now try different mass and stiffness distributions, run Module 1, and see what effect these changes have on predicted frequencies. We deliberately reduced the blade's stiffness distribution.

We did not adjust the blade's weight distribution because this parameter is so important for correct calculation of blade centrifugal and gravitational loads.

AIEMASS, AIFMASS, AOFFST, AESBAC

These input variables are set to zero. We did not perform a thorough investigation of the effects of these parameters on blade loads and response. The variables AOFFST and AESBAC may have some effect on the torsional moments predicted by FLAP. We do not think these input parameters have a big effect on flapwise bending moments, however.

ACHORD

This variable is input directly from the information given in Figure 4-2.

ATWIST

This variable represents the blade's built-in twist distribution. It is input from the information given in Figure 4-2. It is important to note that these values must be adjusted in order to obtain zero twist at the tip; i.e., $ATWIST(11) = 0$. The input variable ATWIST has the blade tip as its zero reference point instead of the 75% span, as seen in Figure 4-2.

ACLALF, ACDZER

ACLALF is the lift curve slope. It is allowed to vary along the span. These values were input from information on the LS(1) airfoil.

ACDZER is the drag coefficient at zero lift. It is used in the calculation of drag coefficient (Wright, Buhl, and Thresher, 1988). It is also allowed to vary along the span.

NUMSCN, TIMINC, MSTAT, STA

These four variables provide information necessary for input of turbulent wind fluctuations to FLAP. NUMSCN was input as 8,192 to reflect 8,192 lines of data in the turbulent windspeed file. TIMINC is set to .041667 because the wind data are sampled at 24 Hz. The number of blade stations at which windspeed data are input is two. Note: The hub center windspeed data will be read in also. MSTAT represents the number of blade stations outboard of the hub center at which turbulent wind input are to be read. STA gives the positions (as measured from the center of rotor rotation) of these points, here set to 20 and 40 ft., which is 50% and 100% of the rotor radius. These inputs are seen in the input file of Appendix A.

6.0 Preparation of Turbulent Wind Input Data

If the user is not interested in running a case with turbulent windspeed input, then this section can be skipped. The FLAP code can be run for deterministic cases only by simply choosing the (Q) option after the trim solution.

In order to run a turbulent windspeed case, a separate file of turbulent windspeed data is needed for input to FLAP. It is assumed that the user must run a separate turbulence wind simulation model such as Veers (1988). Some specific details on the VEERS model will now be given as well as the structure of the turbulence input file to FLAP.

We recommend the use of Veers (1988) for generation of turbulent windspeed input for this rotor. We will henceforth refer to Veers (1988) as the VEERS Three-Dimensional Wind Simulation or, simply, the VEERS model. The reason we recommend this code is that it can be used to generate turbulent windspeed data needed for several points on a blade. With this model, a full three-component field of turbulence is not calculated, only the longitudinal, "along wind," component (in spite of the name "Three-Dimensional . . .").

This simulation method is used to obtain rotationally sampled windspeeds (Veers, 1988). We simulate the windspeed at three points of the rotating blade: the 50% rotor radius location on the blade, the 100% rotor radius on the blade, and the windspeed for the center of rotor rotation.

In the VEERS code, various spectral models for the fixed-point power spectral density calculations can be chosen (Veers, 1988). We usually choose the Solari model. The coherence model is the exponential model with some modifications (Veers, 1988). Input to the model include mean windspeed, rotor speed, number of blades, turbulence intensity, terrain surface roughness, and coherence decrement. For more information, see Veers (1988).

Another input to this model is the number of equally spaced azimuth points in which windspeed data are to be simulated. This parameter will dictate the sampling rate of the generated, rotationally sampled windspeed data. From information that we have obtained from Winkelaar (1991), we usually set this parameter to a high value, in our case, 24 points around the azimuth. This will result in a turbulent windspeed file consisting of four columns of data generated at 24 Hz. The time increment between digitized data is, thus, approximately 0.0417 sec.

In the output file from the VEERS model, the first column is rotor azimuth angle (deg), the second is windspeed at 50% rotor radius, the third is windspeed at 100% rotor radius, and the fourth is the center of hub windspeed. The file contains 8,192 lines of data sampled at 24 Hz. This file represents 341 seconds of real-time wind data. The number of lines of data in the file can be set in the VEERS model input file. We usually want this number to be some power of two (2^{13} in this case) so that we can later perform power spectral density calculations on the computed loads and response output. The FLAP code will generate corresponding loads and response output corresponding to each line of windspeed data. An example output file from VEERS is shown in Appendix F.

7.0 Input of Turbulence Data to FLAP

At this time, we will describe how these turbulent windspeed data are read into FLAP and how they are used.

In order to run a turbulent windspeed case, the FLAP code must first be run in order to determine a trim solution. The code then uses the computed values of blade deflection and velocity at zero azimuth (blade at 12 o'clock) as initial conditions for this process. An example interactive execution will be shown in the next section.

One major change included in FLAP, Version 2.20, and not included in version 2.01, is a subroutine named TRBCLC. After the code finishes with its trim solution calculations, it enters this subroutine, if so chosen by the user. It is in this subroutine that the turbulent windspeed data generated by VEERS is read into FLAP.

We must now describe the two types of interpolation of this windspeed data that are occurring in FLAP. One type is with respect to rotor azimuth, and the other is along the blade radial station locations.

To describe the first type, we must remember that the FLAP code does not increment the rotor azimuth angle in equal azimuth steps. They can vary from point to point because of the use of the Euler Predictor Corrector numeric integration procedure (Wright, Buhl, and Thresher, 1988). The windspeed data generated from VEERS (Veers, 1988) is generated at equal time steps. The main purpose of subroutine TRBCLC is to interpolate the data in order to provide approximate wind input at intermediate rotor azimuth locations. Linear interpolation is used in this subroutine.

Appendix D gives a listing of FLAP2. Subroutine TRBCLC is on page D-112. Upon entering this subroutine, the user will be prompted for the name of the windspeed input file and asked whether the windspeed data are in English (ft/sec) or metric (m/sec) units. He or she is then asked for a file name that contains load and response predictions. These predictions are not written in the RESULTS.DAT file formed previously.

The code then reads one line of wind input data at a time. For the first pass through this subroutine, before the first line of windspeed data is read, the initial azimuth angle is set to zero degrees, and the initial values for the two windspeeds on each blade and the hub center windspeed are set equal to VHUB. The first line of data is then read. The azimuth angle is then incremented, and wind input are then determined by linear interpolation for this intermediate azimuth angle. The values calculated at this intermediate azimuth are stored in the variables VYNOW1(1), VYNOW1(2), and VYNOWH. These variables represent the interpolated values of the two velocities on the blade and the hub center wind velocity at the present azimuth angle. The two end-point values, used in the linear interpolation process, represent the last and most recent values of windspeed read from the input file. These values are represented by the variables VYSAV1(I,J) and VYSAVH(I). The integer I can be either 0 or 1, corresponding to old or new. The integer J is equal to 1 or 2, corresponding to windspeed at the 50% or 100% radial location. The variable VYSAVH(I) is the hub center windspeed.

The three interpolated windspeeds are ultimately passed to a subroutine name WINDVL. In this subroutine, values of turbulent windspeed are calculated for intermediate blade radial stations.

The FLAP code calculates blade aerodynamic forces at 21 equally spaced blade stations, beginning at the root and ending at the tip. In this subroutine, we take the three values of windspeed passed from subroutine TRBCLC and calculate interpolated values for intermediate blade radial stations. We then have

an array containing 21 equally spaced windspeed inputs for a blade. These values are saved in the array DELTVY(I); see Appendix D, page D-108 for Subroutine WINDVL.

This process of azimuth interpolation in subroutine TRBCLC and blade radial station interpolation in WINDVL is continued for each iteration in the numeric process. The code will calculate elastic flap deflections, velocity, and accelerations at every single iteration point. The code calculates and saves loads only at those azimuth positions corresponding to the azimuth values read in from the turbulent windspeed file.

Results written to the user-designated output file include azimuth angle, blade loads, and deflection information. The user can modify the write statement in subroutine TRBCLC to write out all or part of these results. This file will contain the same number of lines of output results as the number of lines of data in the windspeed input file.

Some remarks should be made on proper execution of the trim solution portion of this process. The file produced by the VEERS model contains windspeed data derived from three parts: (1) the mean hub height windspeed, (2) the variation of windspeed as a result of windshear, and (3) the variation as a result of stochastic effects. The second part may be zero if the VEERS model is run with a zero windshear exponent.

Care must be taken to run the trim solution in FLAP using the correct values of VHUB and SHERXP. The variable VHUB, in Module 2 of FLAP, should be set to the value of hub height windspeed as calculated in the VEERS model. The mean windspeed input to the VEERS model is the mean windspeed at a 10-m height (Veers, 1988). This will not necessarily be equal to the hub height windspeed. Hub height may be at a different level. The equivalent hub height windspeed from the VEERS model can be calculated from a knowledge of the windspeed input at 10 m and the power law shear exponent. Once this value is known, FLAP SHOULD BE RUN WITH VHUB SET TO THIS VALUE IN FEET/SECOND.

If the VEERS model is run with a nonzero shear exponent, then the FLAP code should be run with SHERXP set to zero. The wind data generated by the VEERS model already contain the effect of windshear. Input of a nonzero SHERXP in FLAP will result in windshear overprediction. To be safe, we set SHERXP, at the beginning of subroutine TRBCLC, to zero.

An example interactive run of Modules 1 and 2 will now be given.

8.0 Example Interactive Run

8.1 Module 1—FLAP1

Please see Appendix A for a printout of this interactive run. Upon code execution, the user is first prompted for the input file name, here referred to as TURBN.DAT. Upon typing in the input file name, the user is prompted for the name of the run-data file name. This file is written by FLAP1 and contains the data to be read by FLAP2.

All the input data are echoed out to allow the user to check all inputs. At this point, the user is not able to change input during execution of Module 1. The changes must be made to the input file and then rerun.

After all the input data have been echoed out, the user is prompted for the name of a file for writing the blade's modeshape and natural frequency data. This file is different than the run-data file. The purpose of this modeshape file is to allow the user to examine resulting flapwise natural frequencies and modeshapes. It is not read by FLAP2, and its only purpose is to examine frequency results.

Finally, the user is asked if he or she wants to process another data file; in which case, he or she answers yes or no. The code then responds by repeating the previous steps or stating "FLAP Terminated Normally." This signals the end of FLAP1 execution. A listing of this interactive session is shown in Appendix A. A listing of the run-data file and the modeshape file is also shown.

8.2 Module 2—FLAP2

Upon executing FLAP2, the user is presented with a menu of options shown in the interactive run listing in Appendix B. The options include (R)ead in a data file, (S)et up and run the model, (D)agnostic run, (T)urbulence run, and (Q)uit.

The user first chooses the (R) option and reads in the run-data file produced by Module 1 (FLAP1). After this step, the user selects option (S). Upon selecting (S), a list of free variables will be given. The user is free to change any of these variables. At this stage, the user selects the number of degrees of freedom to be included in the analysis. The variable NSHAPS sets the number of modes (from 1 to 4) to be used in the analysis. We suggest that NSHAPS be set to 1 so that the first mode is used. For the example turbine described earlier, final code runs should use a value of 2 for NSHAPS because the second bending mode at a frequency of 8 Hz (8 times the rotor rotation speed) gets highly excited by windshear, tower shadow, and turbulence (Wright and Butterfield, 1992).

After changing any of the free variables, the user is given the option of changing the run parameters. We suggest changing the variables STEPMX and EUERR under certain conditions. See Wright, et al. (1988) for the definition of these two variables. The default parameters (STEPMX = 10, EUERR = 10) can be used for initial runs, when only one or two modes are used, at low windspeeds in nonstalled conditions. When more modes are used or in cases involving high angles of attack (stalled flow) or severe tower shadow input, these parameters should be set to 1. Although the code will take longer to run, decreasing these input parameters will help the code to converge to a solution. The small step size is necessary when the blade is encountering highly nonlinear operating conditions, such as stalled flow, and abrupt changes because of tower shadow.

For high-windspeed cases, the code may take 20 to 30 trim iterations before a solution is reached. This occurs because of the decrease in blade aerodynamic damping that result from high angle-of-attack conditions.

We also suggest setting the Trace Flag in the set of run parameters to TRUE. This allows printout of blade deflection, velocity, acceleration, and other items in the RESULTS.DAT file. From this information, the user can monitor problems that may be occurring during code execution.

Another variable in this list of parameters is NYAW. If the user wants to run a time-dependent yaw solution, NYAW should be set to some integer number greater than zero. The variable PHIAMP in the free variable list must also be greater than zero (see Wright, Buhl, and Thresher, 1988).

NYAW represents the number of rotor revolutions to be performed during the yaw solution. The code will first compute a trim solution and then perform a transient analysis using the time-dependent yaw solution. The solution is completed at the end of NYAW revolutions.

After reviewing and/or changing the set of run parameters, the user is prompted for the name of the RESULTS.DAT file. This file will contain blade deflection, slope, and velocity results as well as all the blade's force and moment values. These results are given as a function of blade azimuth angle as well as blade radial station.

Once the code obtains a satisfied trim condition, the code prompts the user for a Fourier analysis of result data. The nine result items are then listed, and the user chooses which item (one at a time) to be Fourier analyzed. The code then determines Fourier cosine and sine coefficients and writes them in table form to the RESULTS.DAT file. A RESULTS.DAT file corresponding to the interactive run is shown in Appendix B.

After this, the name of a shaft load output file is asked for. The shaft loads for the trim runs are written to a separate file. A printout of this file for this interactive run is also shown in Appendix B.

After this, the user is asked if he or she wants to make another run with these data. If the answer is yes, the previous steps are repeated. If the answer is no, the user is returned to the operations menu.

One option that has not been described is (D). This option can only be performed after a trim solution has been performed. Upon execution of this option, items such as angle of attack, lift, and drag will be written to a file named DIAGNOS.DAT. This information is presented for various blade stations as well as rotor azimuth positions.

The other option to be described is (T). This option must also be chosen only after a trim solution has been performed. In this case, we can see that a turbulence analysis was performed. The turbulent windspeed input file was named WIND-2.DAT. These windspeed data were in metric units (meters/seconds). The turbulence load output file was named LOADS-2.DAT. If the user wants to bypass the turbulence analysis, then the (Q) option should be chosen before the (T) option. This will halt code execution.

9.0 Conclusions

An overview of the NREL Force and Loads Analysis Program (FLAP, Version 2.2) has been given. New input to the code have been described. An example two-bladed rigid-hub wind turbine was described. Preparation of code input and an example code interactive run for this turbine were shown. Code and interactive run listings are given in the appendices.

10.0 References

- Veers, P. S., 1988, *Three-Dimensional Wind Simulation*, SAND 88-0152, Sandia National Laboratories, Albuquerque, New Mexico.
- Winkelaar, D., 1991, *First Three-Dimensional Wind Simulation and the Predictions of Stochastic Blade Loads*, presented at the Tenth ASME Wind Energy Symposium, Houston, Texas.
- Wright, A. D., and Butterfield, C. P., 1992, *The NREL Teetering Hub Rotor Code: Final Results and Conclusions*, presented at the Eleventh ASME Wind Symposium, Houston, Texas.
- Wright, A. D., Buhl, M. L., and Thresher, R. W., 1988, *FLAP Code Development and Validation*, SERI/TR-217-3125, National Renewable Energy Laboratory, Golden, Colorado.

11.0 Acknowledgments

The author would like to thank C. P. Butterfield of the National Renewable Energy Laboratory for assisting in analysis and interpretation of test results from the example turbine discussed in this report. Thanks also goes to Dr. Paul Veers of Sandia National Laboratories for many helpful suggestions on the correct use of the turbulence model. Thanks go to Lynn Starr and Rick Clyne for preparation and editing of this manuscript, respectively.

Appendix A

Module 1 Input File, Interactive Run Listing, and Output Files

```

TURBN.DAT
DATA INPUT FOR THE EXAMPLE TWO BLADED, DOWNWIND
80 FT DIAM. RIGID HUB ROTOR
ALENTH      6.79
ALPHA0     -4.0
BETA0      7.0
BLSHNK     0.80
BLTIP      38.00
CHI        0.
CSBMAC     0.015
DRGFRM     0.0032
HUBHT      80.
HUBRAD     2.0
KSHADW     1
NBLADS     2
NPANEL     11
OMEGA      60.
PHIAMP     0.0
PHIOMG     0.0
PHIO       13.0
PSIZER     20.
SHERXP     0.164
THETAP     2.00
THETAT     4.0
TSUBP      0.05
TSUBO      0.05
VHUB       33.64
XLEFT      0.0      0.80      1.00      4.00      10.00      18.00      22.00      26.00      36.00      36.20
WEIGHT     50.0     50.00     50.00     43.3      31.6      19.3      14.0      9.35      5.39      28.30
AEIARE     38.90     38.90     38.89     22.50     13.33     4.22      2.48      1.45      0.289     0.280
AIEMAS     0.0      0.0      0.0      0.0      0.0      0.0      0.0      0.0      0.0      0.0
AIFMAS     0.0      0.0      0.0      0.0      0.0      0.0      0.0      0.0      0.0      0.0
AOFFST     0.      0.      0.      0.      0.      0.      0.      0.      0.      0.
ACHORD     1.00     1.00     2.083     2.333     2.916     2.464     2.238     2.012     1.560     1.549
ATWIST     0.0      0.0      4.0      3.9      3.8      3.2      2.8      2.1      0.20      0.10
ACLALF     0.0      0.0      4.55     4.75     4.85     4.95     4.95     5.20     5.18     5.18
ACLMAX     0.0      0.0      1.0      1.1      1.2      1.3      1.5      1.6      1.6      1.6
ACDZER     0.0      0.0      0.0083   0.0083   0.0083   0.0083   0.0083   0.0083   0.0083   0.0083
AESBAC     0.0      0.0      0.0      0.0      0.0      0.0      0.0      0.0      0.0      0.0
NUMSCN    100
TIMINC     0.041667
MSTAT     2
STA       20.      40.

```

THIS IS THE INTERACTIVE RUN LISTING FOR MODULE 1:

Program For Analysis Of Horizontal Axis Wind Turbine
Response To Dynamic Loads

- MODULE 1

Subroutine INPUT: Input and process new blade
and turbine data.

Enter name of input data file >

Enter name of output data file >

TURBN.DAT

DATA INPUT FOR THE EXAMPLE TWO BLADED, DOWNWIND
80 FT DIAM. RIGID HUB ROTOR

Parameter values:

ALENTH =	6.79000	NPANEL =	11
ALPHA0 =	-4.00000	OMEGA =	60.00000
BETA0 =	7.00000	PHIO =	13.00000
BLSHNK =	0.80000	PHIAMP =	0.00000
BLTIP =	38.00000	PHIOMG =	0.00000
CHI =	0.00000	PSIZER =	20.00000
CSUBMA =	0.01500	SHERXP =	0.16400
DRGFRM =	0.00320	THETAP =	2.00000
HUBHT =	80.00000	THETAT =	4.00000
HUBRAD =	2.00000	TSUBO =	0.05000
KSHADW =	1	TSUBP =	0.05000
NBLADS =	2	VHUB =	33.64000
NUMSCN =	100		
TIMINC =	0.04166		
MSTAT =	2		

Hit <Enter> to continue...

XLEFT	WEIGHT	AEIARE	AIEMAS	AIFMAS	AOFFST
0.00000	50.00000	38.90000	0.00000	0.00000	0.00000
0.80000	50.00000	38.90000	0.00000	0.00000	0.00000
1.00000	50.00000	38.89000	0.00000	0.00000	0.00000
4.00000	43.30000	22.50000	0.00000	0.00000	0.00000
10.00000	31.60000	13.33000	0.00000	0.00000	0.00000
18.00000	19.30000	4.22000	0.00000	0.00000	0.00000
22.00000	14.00000	2.48000	0.00000	0.00000	0.00000
26.00000	9.35000	1.45000	0.00000	0.00000	0.00000
36.00000	5.39000	0.28900	0.00000	0.00000	0.00000
36.20000	28.30000	0.28000	0.00000	0.00000	0.00000
38.00000	28.20000	0.13500	0.00000	0.00000	0.00000

Hit <Enter> to continue...

ACHORD	ATWIST	ALCALF	ACLMAX	ACDZER	AESBAC
--------	--------	--------	--------	--------	--------

1.00000	0.00000	0.00000	0.00000	0.00000	0.00000
1.00000	0.00000	0.00000	0.00000	0.00000	0.00000
2.08300	4.00000	4.55000	1.00000	0.00830	0.00000
2.33300	3.90000	4.75000	1.10000	0.00830	0.00000
2.91600	3.80000	4.85000	1.20000	0.00830	0.00000
2.46400	3.20000	4.95000	1.30000	0.00830	0.00000
2.23800	2.80000	4.95000	1.50000	0.00830	0.00000
2.01200	2.10000	5.20000	1.60000	0.00830	0.00000
1.56000	0.20000	5.18000	1.60000	0.00830	0.00000
1.54900	0.10000	5.18000	1.60000	0.00830	0.00000
1.33300	0.00000	5.24000	1.60000	0.00830	0.00000

Hit <Enter> to continue...

STA-
20.000
40.000

Hit <Enter> to continue...

Enter name of modeshape and frequency output file done.

Data for MODULE 2 have been written to RUNB.DAT.

Do you want to process another data file? (Y,=N) >

FLAP terminated normally.

THIS IS THE MODESHAPE AND FREQUENCY FILE

FREQUENCIES =				
	15.4516	50.6140	147.366	473.919
Modeshapes:				
1	0.000000	0.000000	0.000000	0.000000
11	0.479990E-03	-0.470760E-03	0.152273E-03	-0.453987E-03
21	0.226373E-02	-0.172893E-02	0.811213E-03	-0.116018E-02
31	0.560398E-02	-0.376290E-02	0.195616E-02	-0.155346E-02
41	0.105679E-01	-0.668386E-02	0.330836E-02	-0.146922E-02
51	0.171897E-01	-0.105695E-01	0.450120E-02	-0.981423E-03
61	0.255666E-01	-0.153675E-01	0.519992E-02	-0.279214E-03
71	0.359055E-01	-0.208500E-01	0.517710E-02	0.422401E-03
81	0.485312E-01	-0.266104E-01	0.435051E-02	0.942064E-03
91	0.638611E-01	-0.320938E-01	0.278973E-02	0.116603E-02
101	0.823587E-01	-0.366515E-01	0.698037E-03	0.106098E-02
111	0.104471	-0.396127E-01	-0.162388E-02	0.669985E-03
121	0.130561	-0.403623E-01	-0.382617E-02	0.957751E-04
131	0.160841	-0.384173E-01	-0.556326E-02	-0.524056E-03
141	0.195319	-0.334936E-01	-0.654618E-02	-0.104599E-02
151	0.233762	-0.255528E-01	-0.658726E-02	-0.134900E-02
161	0.275687	-0.148218E-01	-0.563072E-02	-0.135829E-02
171	0.320391	-0.177524E-02	-0.376279E-02	-0.106016E-02
181	0.367023	0.129271E-01	-0.119463E-02	-0.503351E-03
191	0.414711	0.285568E-01	0.178793E-02	0.216767E-03
201	0.462746	0.444972E-01	0.491525E-02	0.996658E-03

THIS IS THE RUN DATA FILE PRODUCED BY MODULE 1 AND READ
BY MODULE 2:

TURBN.DAT
DATA INPUT FOR THE EXAMPLE TWO BLADED, DOWNWIND
80 FT DIAM. RIGID HUB ROTOR

ALENTH	ALPHA0	BETA0	
6.790000000E+00	-4.000000000E+00	7.000000000E+00	
BLSHNK	BLTIP	CHI	
8.000000000E-01	3.800000000E+01	0.000000000E+00	
CSUBMA	DRGFRM	HUBHT	
1.500000000E-02	3.200000000E-03	8.000000000E+01	
HUBRAD	OMEGA	PHIO	
2.000000000E+00	6.000000000E+01	1.300000000E+01	
PHIAMP	PHIOMG	PSIZER	
0.000000000E+00	0.000000000E+00	2.000000000E+01	
SHERXP	THETAP	THETAT	
1.640000000E-01	2.000000000E+00	4.000000000E+00	
TSUB0	TSUBP	VHUB	
5.000000000E-02	5.000000000E-02	3.364000000E+01	
KSHADW	NBLADS	NSHAPS	NPTS
1	2	2	21
NUMSCN= 100			
TIMINC= 0.04166			
MSTAT = 2			

STA(I)-
2.000E+01 4.000E+01

CLALFA-			
0.000000E+00	4.610000E+00	4.736667E+00	4.778330E+00
4.810000E+00	4.841667E+00	4.867500E+00	4.891250E+00
4.915000E+00	4.938750E+00	4.950000E+00	4.950000E+00
5.000000E+00	5.118750E+00	5.198800E+00	5.195000E+00
5.191200E+00	5.187400E+00	5.183600E+00	5.180000E+00
5.240000E+00			

CLMAX -			
0.000000E+00	1.030000E+00	1.093333E+00	1.128330E+00
1.160000E+00	1.191667E+00	1.217500E+00	1.241250E+00
1.265000E+00	1.288750E+00	1.350000E+00	1.445000E+00
1.520000E+00	1.567500E+00	1.600000E+00	1.600000E+00
1.600000E+00	1.600000E+00	1.600000E+00	1.600000E+00
1.600000E+00			

CDZERO-			
0.000000E+00	8.300000E-03	8.300000E-03	8.300000E-03
8.300000E-03	8.300000E-03	8.300000E-03	8.300000E-03
8.300000E-03	8.300000E-03	8.300000E-03	8.300000E-03
8.300000E-03	8.300000E-03	8.300000E-03	8.300000E-03
8.300000E-03	8.300000E-03	8.300000E-03	8.300000E-03
8.300000E-03			

CHORD-			
1.000000E+00	2.158000E+00	2.316333E+00	2.498183E+00
2.682800E+00	2.867416E+00	2.836900E+00	2.729550E+00
2.622201E+00	2.514851E+00	2.407501E+00	2.300150E+00
2.192800E+00	2.085449E+00	1.984879E+00	1.898999E+00
1.813119E+00	1.727239E+00	1.641359E+00	1.554500E+00
1.333000E+00			

ECNTFN-			
0.000000E+00	0.000000E+00	0.000000E+00	0.000000E+00
0.000000E+00	0.000000E+00	0.000000E+00	0.000000E+00
0.000000E+00	0.000000E+00	0.000000E+00	0.000000E+00

0.0000000E+00	0.0000000E+00	0.0000000E+00	0.0000000E+00
0.0000000E+00	0.0000000E+00	0.0000000E+00	0.0000000E+00
0.0000000E+00	0.0000000E+00	0.0000000E+00	0.0000000E+00
ESUBAC-			
0.0000000E+00	0.0000000E+00	0.0000000E+00	0.0000000E+00
0.0000000E+00	0.0000000E+00	0.0000000E+00	0.0000000E+00
0.0000000E+00	0.0000000E+00	0.0000000E+00	0.0000000E+00
0.0000000E+00	0.0000000E+00	0.0000000E+00	0.0000000E+00
0.0000000E+00	0.0000000E+00	0.0000000E+00	0.0000000E+00
0.0000000E+00	0.0000000E+00	0.0000000E+00	0.0000000E+00
THETA0-			
1.3962630E-01	7.0336770E-02	7.1442140E-02	7.2053010E-02
7.2605690E-02	7.3158380E-02	7.5136420E-02	7.7623500E-02
8.0110590E-02	8.2597690E-02	8.5521120E-02	8.8837260E-02
9.3200590E-02	9.9003830E-02	1.0496420E-01	1.1126480E-01
1.1756550E-01	1.2386610E-01	1.3016670E-01	-1.3700830E-01
1.3962630E-01			
CKBEND-			
1.0083390E+02	-4.0322250E+00	9.9915050E-02	-4.0335320E-02
-4.0322250E+00	2.8433650E+01	-2.5780500E-01	3.1327550E-02
9.9915050E-02	-2.5780500E-01	6.7112550E+00	-1.9452040E-02
-4.0335320E-02	3.1327550E-02	-1.9452040E-02	5.5040870E+00
CKTOMG-			
9.4809340E-01	1.0213810E-01	-2.5309020E-03	1.0220290E-03
1.0213810E-01	7.1425090E-02	6.5302360E-03	-7.9456660E-04
-2.5309020E-03	6.5302360E-03	4.4022620E-03	4.9147420E-04
1.0220290E-03	-7.9456660E-04	4.9147420E-04	6.0389170E-04
CKTGRV-			
2.7604020E-02	1.9881190E-03	-1.2441410E-04	4.4409070E-05
1.9881190E-03	2.2382840E-03	1.3956390E-04	-4.0216200E-05
-1.2441410E-04	1.3956390E-04	1.5335550E-04	1.1202700E-05
4.4409070E-05	-4.0216200E-05	1.1202700E-05	2.5997140E-05
CKQLCD-			
0.0000000E+00	0.0000000E+00	0.0000000E+00	0.0000000E+00
0.0000000E+00	0.0000000E+00	0.0000000E+00	0.0000000E+00
0.0000000E+00	0.0000000E+00	0.0000000E+00	0.0000000E+00
0.0000000E+00	0.0000000E+00	0.0000000E+00	0.0000000E+00
CMMASS-			
5.7911190E-01	4.1807690E-07	5.0681800E-07	6.3668550E-07
4.1807690E-07	1.2199980E-02	2.1859380E-07	2.5996100E-07
5.0681800E-07	2.1859380E-07	3.1734160E-04	3.0884490E-07
6.3668550E-07	2.5996100E-07	3.0884490E-07	2.4889670E-05
CKTCRL(1,K,L)-			
9.3012170E-03	1.3157830E-03	1.3310280E-05	7.8709800E-06
1.3157830E-03	6.7067570E-04	7.5045650E-05	-1.5799920E-06
1.3310280E-05	7.5045650E-05	3.7128080E-05	5.1852320E-06
7.8709800E-06	-1.5799920E-06	5.1852320E-06	4.2657200E-06
CKTCRL(2,K,L)-			
2.8308130E-04	1.4827730E-04	1.9014220E-05	6.6901930E-07
1.4827730E-04	1.5741480E-05	5.2289370E-06	2.0837360E-06
1.9014220E-05	5.2289370E-06	-5.9275360E-07	2.0192700E-07
6.6901930E-07	2.0837360E-06	2.0192700E-07	-2.7655570E-07
CKTCRL(3,K,L)-			
3.3599220E-06	6.4080110E-06	3.0212620E-06	6.1850270E-07
6.4080110E-06	2.3025510E-06	4.3411470E-08	7.3307340E-08
3.0212620E-06	4.3411470E-08	2.3791120E-08	-1.0719060E-08
6.1850270E-07	7.3307340E-08	-1.0719060E-08	2.2584170E-08
CKTCRL(4,K,L)-			
5.6055080E-07	4.5585320E-07	2.9808030E-07	1.4599310E-07
4.5585320E-07	4.1657040E-07	8.5431540E-08	-8.5354440E-09
2.9808030E-07	8.5431540E-08	-2.9392540E-09	3.6502860E-09
1.4599310E-07	-8.5354440E-09	3.6502860E-09	-2.2649680E-09
CMRIGO-			
6.4966190E+01	-4.2173530E+00	3.2205240E-01	-5.5928610E-02
CMBLNC-			

0.000000E+00	0.000000E+00	0.000000E+00	0.000000E+00
CMGRAV-			
2.112808E+00	-2.839586E-01	3.679537E-02	-1.003211E-02
TCORLS(1,1)-			
2.112827E+00	2.112390E+00	2.109043E+00	2.099713E+00
2.081900E+00	2.054090E+00	2.015440E+00	1.965079E+00
1.903075E+00	1.830128E+00	1.747460E+00	1.655836E+00
1.557707E+00	1.455335E+00	1.352473E+00	1.242096E+00
1.122282E+00	9.952594E-01	8.639767E-01	7.179174E-01
0.000000E+00			
TCORLS(2,1)-			
-2.839564E-01	-2.834853E-01	-2.806986E-01	-2.741201E-01
-2.625872E-01	-2.452832E-01	-2.217901E-01	-1.920114E-01
-1.569729E-01	-1.186056E-01	-7.941478E-02	-4.165334E-02
-7.896016E-03	2.012678E-02	4.119116E-02	5.657803E-02
6.623729E-02	6.990127E-02	6.786418E-02	5.995573E-02
0.000000E+00			
TCORLS(3,1)-			
3.679599E-02	3.666853E-02	3.550334E-02	3.218265E-02
2.628547E-02	1.831184E-02	9.365865E-03	6.824709E-04
-6.478380E-03	-1.124059E-02	-1.329151E-02	-1.286880E-02
-1.058539E-02	-7.250928E-03	-3.703694E-03	-2.736572E-04
2.648312E-03	4.690167E-03	5.666096E-03	5.523812E-03
0.000000E+00			
TCORLS(4,1)-			
-1.003195E-02	-9.543358E-03	-7.345412E-03	-3.908103E-03
-4.155433E-04	2.138550E-03	3.316753E-03	3.194923E-03
2.161797E-03	7.513885E-04	-5.478787E-04	-1.427048E-03
-1.763852E-03	-1.617821E-03	-1.159107E-03	-5.311044E-04
1.192244E-04	6.470822E-04	9.551492E-04	1.002002E-03
0.000000E+00			
TGRAV-			
2.671312E+01	2.378878E+01	2.108008E+01	1.860922E+01
1.635735E+01	1.432427E+01	1.249737E+01	1.084464E+01
9.364412E+00	8.056700E+00	6.918170E+00	5.931010E+00
5.090887E+00	4.384272E+00	3.803745E+00	3.287839E+00
2.816365E+00	2.389323E+00	2.006714E+00	1.634597E+00
0.000000E+00			
TOMGA-			
4.074944E+02	3.988864E+02	3.857896E+02	3.691469E+02
3.497035E+02	3.282899E+02	3.055742E+02	2.818853E+02
2.578596E+02	2.341524E+02	2.113507E+02	1.897065E+02
1.696925E+02	1.515182E+02	1.354844E+02	1.202465E+02
1.054258E+02	9.119117E+01	7.771135E+01	6.386213E+01
0.000000E+00			
CIFMOM(1,1)-			
0.000000E+00	0.000000E+00	0.000000E+00	0.000000E+00
0.000000E+00	0.000000E+00	0.000000E+00	0.000000E+00
0.000000E+00	0.000000E+00	0.000000E+00	0.000000E+00
0.000000E+00	0.000000E+00	0.000000E+00	0.000000E+00
0.000000E+00	0.000000E+00	0.000000E+00	0.000000E+00
0.000000E+00	0.000000E+00	0.000000E+00	0.000000E+00
0.000000E+00	0.000000E+00	0.000000E+00	0.000000E+00
CIFMOM(2,1)-			
0.000000E+00	0.000000E+00	0.000000E+00	0.000000E+00
0.000000E+00	0.000000E+00	0.000000E+00	0.000000E+00
0.000000E+00	0.000000E+00	0.000000E+00	0.000000E+00
0.000000E+00	0.000000E+00	0.000000E+00	0.000000E+00
0.000000E+00	0.000000E+00	0.000000E+00	0.000000E+00
0.000000E+00	0.000000E+00	0.000000E+00	0.000000E+00
0.000000E+00	0.000000E+00	0.000000E+00	0.000000E+00
CIFMOM(3,1)-			
0.000000E+00	0.000000E+00	0.000000E+00	0.000000E+00
0.000000E+00	0.000000E+00	0.000000E+00	0.000000E+00
0.000000E+00	0.000000E+00	0.000000E+00	0.000000E+00
0.000000E+00	0.000000E+00	0.000000E+00	0.000000E+00
0.000000E+00	0.000000E+00	0.000000E+00	0.000000E+00
0.000000E+00	0.000000E+00	0.000000E+00	0.000000E+00
0.000000E+00	0.000000E+00	0.000000E+00	0.000000E+00
CIFMOM(4,1)-			

0.000000E+00	0.000000E+00	0.000000E+00	0.000000E+00
0.000000E+00	0.000000E+00	0.000000E+00	0.000000E+00
0.000000E+00	0.000000E+00	0.000000E+00	0.000000E+00
0.000000E+00	0.000000E+00	0.000000E+00	0.000000E+00
0.000000E+00	0.000000E+00	0.000000E+00	0.000000E+00
0.000000E+00	0.000000E+00	0.000000E+00	0.000000E+00

DELTIM-

0.000000E+00	0.000000E+00	0.000000E+00	0.000000E+00
0.000000E+00	0.000000E+00	0.000000E+00	0.000000E+00
0.000000E+00	0.000000E+00	0.000000E+00	0.000000E+00
0.000000E+00	0.000000E+00	0.000000E+00	0.000000E+00
0.000000E+00	0.000000E+00	0.000000E+00	0.000000E+00
0.000000E+00	0.000000E+00	0.000000E+00	0.000000E+00

OFFMAS-

0.000000E+00	0.000000E+00	0.000000E+00	0.000000E+00
0.000000E+00	0.000000E+00	0.000000E+00	0.000000E+00
0.000000E+00	0.000000E+00	0.000000E+00	0.000000E+00
0.000000E+00	0.000000E+00	0.000000E+00	0.000000E+00
0.000000E+00	0.000000E+00	0.000000E+00	0.000000E+00
0.000000E+00	0.000000E+00	0.000000E+00	0.000000E+00
0.000000E+00	0.000000E+00	0.000000E+00	0.000000E+00
0.704375E-01	-0.109351	0.105763E-01	-0.135159
0.396756	0.195642	0.313000	0.557743
-0.649376	-0.709698	-0.811690	-0.750139
0.644929	0.667904	0.493030	0.328551

Appendix B

Module 2 Interactive Run Listing and Output Files

THIS IS THE INTERACTIVE RUN LISTING FOR MODULE 2:

Program For Analysis Of Horizontal Axis Wind Turbine
Response To Dynamic Loads

MODULE 2

Operations Menu

- (R)ead in a data file
- (S)et up and run the model
- (D)iagnostic run
- (T)urbulence analysis
- (Q)uit

Enter Option (R,S,D,T,Q) >

Enter the name of the file that contains run-data >
Reading in new data...done.

Operations Menu

- (R)ead in a data file
- (S)et up and run the model
- (D)iagnostic run
- (T)urbulence analysis
- (Q)uit

Enter Option (R,S,D,T,Q) >

Current values for the 'free' variables:

- | | | | | | |
|----|----------|--------------------|----|----------|---------------------|
| 1 | ALENTH = | 6.7900 feet | 12 | PHIAMP = | 0.0000 degrees |
| 2 | ALPHA0 = | -4.0000 degrees | 13 | PHIOMG = | 0.0000 degrees/sec |
| 3 | BETA0 = | 7.0000 degrees | 14 | PSISHD = | 180.0000 degrees |
| 4 | CHI = | 0.0000 degrees | 15 | PSIZER = | 20.0000 degrees |
| 5 | GRAV = | 32.1740 feet/sec^2 | 16 | RHOAIR = | 0.0020 Slugs/feet^3 |
| 6 | HUBHT = | 80.0000 feet | 17 | SHERXP = | 0.1640 |
| 7 | KSHADW = | 1 | 18 | THETAP = | 2.0000 degrees |
| 8 | NBLADS = | 2 | 19 | THETAT = | 4.0000 degrees |
| 9 | NSHAPS = | 2 | 20 | TSUBO = | 0.0500 |
| 10 | OMEGA = | 60.0000 RPM | 21 | TSUBP = | 0.0500 |
| 11 | PHIO = | 13.0000 degrees | 22 | VHUB = | 33.6400 feet/second |
| 23 | TIMINC = | 0.041660 seconds | 24 | NUMSCN = | 100 |

Would you like to change any values? (Y,=N) >

The current values of the run parameters are:

- 1 STEPMX = 10.000 degrees Maximum Step Size
- 2 STEPMN = 0.001 degrees Minimum Step Size
- 3 PRINT1 = 10.000 degrees Printout Interval in Region 1
- 4 PRINT2 = 10.000 degrees Printout Interval in Region 2
- 5 BEGIN2 = 180.000 degrees Beginning of Print Region 2
- 6 END2 = 270.000 degrees End of Print Region 2
- 7 EUERR = 10.000 percent Max value of Euler error function
- 8 TRMERR = 10.000 percent Convergence Criterion for Trim Solution

9 NYAW = 0 No. of Disk Revolutions for Yawing Soln.
10 TRACEF = .FALSE. Trace Flag

Do you want to change any of these values? (Y,=N) >

Enter number of variable you wish to change >
Enter new REAL value for STEPMX >

The current values of the run parameters are:

1 STEPMX = 5.000 degrees Maximum Step Size
2 STEPMM = 0.001 degrees Minimum Step Size
3 PRINT1 = 10.000 degrees Printout Interval in Region 1
4 PRINT2 = 10.000 degrees Printout Interval in Region 2
5 BEGIN2 = 180.000 degrees Beginning of Print Region 2
6 END2 = 270.000 degrees End of Print Region 2
7 EUERR = 10.000 percent Max value of Euler error function
8 TRMERR = 10.000 percent Convergence Criterion for Trim Solution
9 NYAW = 0 No. of Disk Revolutions for Yawing Soln.
10 TRACEF = .FALSE. Trace Flag

Do you want to change any of these values? (Y,=N) >

Enter number of variable you wish to change >
Enter new REAL value for EUERR >

The current values of the run parameters are:

1 STEPMX = 5.000 degrees Maximum Step Size
2 STEPMM = 0.001 degrees Minimum Step Size
3 PRINT1 = 10.000 degrees Printout Interval in Region 1
4 PRINT2 = 10.000 degrees Printout Interval in Region 2
5 BEGIN2 = 180.000 degrees Beginning of Print Region 2
6 END2 = 270.000 degrees End of Print Region 2
7 EUERR = 5.000 percent Max value of Euler error function
8 TRMERR = 10.000 percent Convergence Criterion for Trim Solution
9 NYAW = 0 No. of Disk Revolutions for Yawing Soln.
10 TRACEF = .FALSE. Trace Flag

Do you want to change any of these values? (Y,=N) >

Enter number of variable you wish to change >
Enter new REAL value for TRMERR >

The current values of the run parameters are:

1 STEPMX = 5.000 degrees Maximum Step Size
2 STEPMM = 0.001 degrees Minimum Step Size
3 PRINT1 = 10.000 degrees Printout Interval in Region 1
4 PRINT2 = 10.000 degrees Printout Interval in Region 2
5 BEGIN2 = 180.000 degrees Beginning of Print Region 2
6 END2 = 270.000 degrees End of Print Region 2
7 EUERR = 5.000 percent Max value of Euler error function
8 TRMERR = 5.000 percent Convergence Criterion for Trim Solution
9 NYAW = 0 No. of Disk Revolutions for Yawing Soln.
10 TRACEF = .FALSE. Trace Flag

Do you want to change any of these values? (Y,=N) >

Product of CMMASS premultiplied by its inverse:

1.0000000	0.0000000
0.0000000	1.0000000

Are you ready to run the model? (=Y,N) >

Enter name of results file [=RESULTS.DAT] >

>>> File already exists <<<

Do you want to overwrite the old data? (Y,N) >

Trim test #01 completed. The trim condition was not satisfied.

Trim test #02 completed. The trim condition was not satisfied.

Trim test #03 completed. The trim condition was satisfied.

Do you want to perform fourier analysis of any of the results data?

note: shaft loads harmonics will appear in the shaft loads file.

Read in the result data item # that you want analyzed

- 1 = flapwise displacement
- 2 = flapwise slope
- 3 = flapwise segment velocity
- 4 = blade tension
- 5 = blade edgewise shear
- 6 = blade flapwise shear
- 7 = blade flapwise moment
- 8 = blade edgewise moment
- 9 = blade torsional moment

Read in the highest order harmonic desired
Do you want to perform fourier analysis of any of the results data?

note: shaft loads harmonics will appear in the shaft loads file.

Read in name of shaft loads output file <
SHAFTB.DAT

Do you want to do another run with this data? (Y,=N) >

Operations Menu

- (R)ead in a data file
- (S)et up and run the model
- (D)iagnostic run
- (T)urbulence analysis
- (Q)uit

Enter Option (R,S,D,T,Q) >

Turbulence Analysis Run Set-up

Read in the name of the wind residual time series file
WIND-2B.DAT

Is the wind data in metric units (meters/sec)?
Y

Read in the name of the file for loads output
turblobd.dat

Operations Menu

- (R)ead in a data file
- (S)et up and run the model
- (D)iagnostic run
- (T)urbulence analysis
- (Q)uit

Enter Option (R,S,D,T,Q) >

Invalid response. Please try again.

Enter Option (R,S,D,T,Q) >

FLAP terminated normally.

Analysis of Wind Turbine Blade Loads
National Renewable Energy Lab

TURBN.DAT

DATA INPUT FOR THE EXAMPLE TWO BLADED, DOWNWIND

80 FT DIAM. RIGID HUB ROTOR

ALENTH = 6.790 feet	HUBHT = 80.000 feet	STEPMX = 5.000 degrees
ALPHA0 = -4.000 degrees	HUBRAD = 2.000 feet	STEPMN = 0.001 degrees
BETA0 = 7.000 degrees	OMEGA = 60.000 RPM	TSUBP = 0.050
BLSHNK = 0.800 feet	PHIAMP = 0.000 degrees	TSUB0 = 0.050
BLTIP = 38.000 feet	PHIOMG = 0.000 degrees/sec	THETAP = 2.000 degrees
CHI = 0.000 degrees	PHIO = 13.000 degrees	THETAT = 4.000 degrees
CSUBMA = 0.015	PSIZER = 20.000 degrees	TRMERR = 5.000 percent
DRGFRM = 0.003	RHOAIR = 0.002 slugs/ft ³	VHUB = 33.640 feet/second
EUERR = 5.000 percent	SHERXP = 0.164	

KSHADW = 1 NBLADS = 2 NSHAPS = 2 NYAW = 0

Blade section flap displacement (feet)

Trim Solution

Psi	Time	Phi	Phi-D	Phi-DD	X / R										
deg	sec	deg	deg/s	deg/s^2	.0	.1	.2	.3	.4	.5	.6	.7	.8	.9	1.0
0	0.00	13.0	0.00	0.00	0.00	1.86E-3	8.52E-3	2.05E-2	3.87E-2	6.48E-2	0.10	0.15	0.21	0.27	0.34
10	0.00	13.0	0.00	0.00	0.00	1.85E-3	8.52E-3	2.05E-2	3.88E-2	6.49E-2	0.10	0.15	0.21	0.27	0.34
20	0.00	13.0	0.00	0.00	0.00	2.04E-3	9.26E-3	2.22E-2	4.18E-2	6.93E-2	0.11	0.15	0.21	0.28	0.34
30	0.00	13.0	0.00	0.00	0.00	2.14E-3	9.68E-3	2.32E-2	4.36E-2	7.21E-2	0.11	0.16	0.22	0.28	0.35
40	0.00	13.0	0.00	0.00	0.00	2.06E-3	9.41E-3	2.26E-2	4.26E-2	7.11E-2	0.11	0.16	0.22	0.29	0.36
50	0.00	13.0	0.00	0.00	0.00	2.01E-3	9.25E-3	2.23E-2	4.21E-2	7.06E-2	0.11	0.16	0.23	0.30	0.37
60	0.00	13.0	0.00	0.00	0.00	2.12E-3	9.71E-3	2.34E-2	4.40E-2	7.33E-2	0.11	0.17	0.23	0.30	0.37
70	0.00	13.0	0.00	0.00	0.00	2.23E-3	1.01E-2	2.43E-2	4.56E-2	7.55E-2	0.12	0.17	0.23	0.30	0.37
80	0.00	13.0	0.00	0.00	0.00	2.14E-3	9.75E-3	2.34E-2	4.40E-2	7.32E-2	0.11	0.16	0.23	0.30	0.37
90	0.00	13.0	0.00	0.00	0.00	1.97E-3	9.05E-3	2.18E-2	4.11E-2	6.88E-2	0.11	0.16	0.22	0.29	0.36
100	0.00	13.0	0.00	0.00	0.00	1.92E-3	8.78E-3	2.11E-2	3.98E-2	6.66E-2	0.10	0.15	0.21	0.28	0.34
110	0.00	13.0	0.00	0.00	0.00	1.93E-3	8.77E-3	2.11E-2	3.96E-2	6.56E-2	0.10	0.15	0.20	0.26	0.32
120	0.00	13.0	0.00	0.00	0.00	1.83E-3	8.30E-3	1.99E-2	3.74E-2	6.20E-2	9.51E-2	0.14	0.19	0.24	0.30
130	0.00	13.0	0.00	0.00	0.00	1.62E-3	7.41E-3	1.78E-2	3.36E-2	5.60E-2	8.68E-2	0.13	0.18	0.23	0.29
140	0.00	13.0	0.00	0.00	0.00	1.49E-3	6.84E-3	1.65E-2	3.10E-2	5.19E-2	8.07E-2	0.12	0.16	0.22	0.27
150	0.00	13.0	0.00	0.00	0.00	1.49E-3	6.77E-3	1.63E-2	3.05E-2	5.06E-2	7.79E-2	0.11	0.15	0.20	0.25
160	0.00	13.0	0.00	0.00	0.00	1.47E-3	6.63E-3	1.59E-2	2.98E-2	4.92E-2	7.51E-2	0.11	0.15	0.19	0.24
170	0.00	13.0	0.00	0.00	0.00	1.33E-3	6.05E-3	1.45E-2	2.73E-2	4.54E-2	7.01E-2	0.10	0.14	0.18	0.23
180	0.00	13.0	0.00	0.00	0.00	1.06E-3	4.95E-3	1.20E-2	2.27E-2	3.85E-2	6.10E-2	9.12E-2	0.13	0.17	0.22
190	0.00	13.0	0.00	0.00	0.00	8.53E-4	4.03E-3	9.79E-3	1.87E-2	3.20E-2	5.13E-2	7.78E-2	0.11	0.15	0.19
200	0.00	13.0	0.00	0.00	0.00	9.74E-4	4.40E-3	1.06E-2	1.98E-2	3.27E-2	4.99E-2	7.19E-2	9.81E-2	0.13	0.16
210	0.00	13.0	0.00	0.00	0.00	1.17E-3	5.14E-3	1.22E-2	2.26E-2	3.63E-2	5.33E-2	7.32E-2	9.54E-2	0.12	0.14
220	0.00	13.0	0.00	0.00	0.00	1.08E-3	4.82E-3	1.15E-2	2.15E-2	3.51E-2	5.28E-2	7.48E-2	0.10	0.13	0.16
230	0.00	13.0	0.00	0.00	0.00	9.47E-4	4.41E-3	1.07E-2	2.02E-2	3.43E-2	5.42E-2	8.09E-2	0.11	0.15	0.19
240	0.00	13.0	0.00	0.00	0.00	1.20E-3	5.52E-3	1.33E-2	2.52E-2	4.23E-2	6.63E-2	9.79E-2	0.14	0.18	0.23
250	0.00	13.0	0.00	0.00	0.00	1.66E-3	7.49E-3	1.80E-2	3.36E-2	5.53E-2	8.42E-2	0.12	0.16	0.21	0.26
260	0.00	13.0	0.00	0.00	0.00	1.89E-3	8.51E-3	2.04E-2	3.82E-2	6.30E-2	9.62E-2	0.14	0.19	0.24	0.30
270	0.00	13.0	0.00	0.00	0.00	1.83E-3	8.45E-3	2.04E-2	3.84E-2	6.45E-2	0.10	0.15	0.21	0.27	0.34
280	0.00	13.0	0.00	0.00	0.00	1.89E-3	8.75E-3	2.11E-2	4.00E-2	6.75E-2	0.11	0.16	0.22	0.29	0.37
290	0.00	13.0	0.00	0.00	0.00	2.15E-3	9.83E-3	2.37E-2	4.45E-2	7.42E-2	0.11	0.17	0.23	0.30	0.38
300	0.00	13.0	0.00	0.00	0.00	2.30E-3	1.04E-2	2.50E-2	4.70E-2	7.77E-2	0.12	0.17	0.24	0.31	0.38
310	0.00	13.0	0.00	0.00	0.00	2.15E-3	9.81E-3	2.36E-2	4.45E-2	7.41E-2	0.11	0.17	0.23	0.30	0.38
320	0.00	13.0	0.00	0.00	0.00	1.95E-3	9.01E-3	2.17E-2	4.11E-2	6.92E-2	0.11	0.16	0.22	0.30	0.37
330	0.00	13.0	0.00	0.00	0.00	1.98E-3	9.08E-3	2.19E-2	4.12E-2	6.90E-2	0.11	0.16	0.22	0.29	0.36
340	0.00	13.0	0.00	0.00	0.00	2.10E-3	9.50E-3	2.28E-2	4.28E-2	7.07E-2	0.11	0.16	0.21	0.28	0.34
350	0.00	13.0	0.00	0.00	0.00	2.03E-3	9.22E-3	2.21E-2	4.15E-2	6.88E-2	0.11	0.15	0.21	0.27	0.34
360	0.00	13.0	0.00	0.00	0.00	1.86E-3	8.52E-3	2.05E-2	3.87E-2	6.48E-2	0.10	0.15	0.21	0.27	0.34

Blade section flapwise slope (feet/foot)

Trim Solution

Psi	Time	Phi	Phi-D	Phi-DD	X / R										
deg	sec	deg	deg/s	deg/s^2	.0	.1	.2	.3	.4	.5	.6	.7	.8	.9	1.0
0	0.00	13.0	0.00	0.00	0.00	1.08E-3	2.44E-3	3.91E-3	5.73E-3	8.10E-3	1.10E-2	1.39E-2	1.63E-2	1.76E-2	1.79E-2
10	0.00	13.0	0.00	0.00	0.00	1.08E-3	2.44E-3	3.92E-3	5.75E-3	8.14E-3	1.10E-2	1.40E-2	1.65E-2	1.78E-2	1.81E-2
20	0.00	13.0	0.00	0.00	0.00	1.17E-3	2.64E-3	4.23E-3	6.11E-3	8.46E-3	1.12E-2	1.40E-2	1.62E-2	1.74E-2	1.77E-2
30	0.00	13.0	0.00	0.00	0.00	1.23E-3	2.76E-3	4.41E-3	6.35E-3	8.73E-3	1.15E-2	1.42E-2	1.64E-2	1.76E-2	1.79E-2
40	0.00	13.0	0.00	0.00	0.00	1.19E-3	2.69E-3	4.31E-3	6.28E-3	8.80E-3	1.18E-2	1.48E-2	1.73E-2	1.87E-2	1.90E-2
50	0.00	13.0	0.00	0.00	0.00	1.17E-3	2.65E-3	4.26E-3	6.25E-3	8.87E-3	1.21E-2	1.53E-2	1.80E-2	1.95E-2	1.98E-2
60	0.00	13.0	0.00	0.00	0.00	1.23E-3	2.78E-3	4.45E-3	6.48E-3	9.08E-3	1.22E-2	1.53E-2	1.79E-2	1.93E-2	1.96E-2
70	0.00	13.0	0.00	0.00	0.00	1.28E-3	2.88E-3	4.61E-3	6.66E-3	9.19E-3	1.21E-2	1.51E-2	1.75E-2	1.88E-2	1.90E-2
80	0.00	13.0	0.00	0.00	0.00	1.24E-3	2.78E-3	4.46E-3	6.46E-3	8.99E-3	1.20E-2	1.50E-2	1.74E-2	1.88E-2	1.90E-2
90	0.00	13.0	0.00	0.00	0.00	1.15E-3	2.59E-3	4.16E-3	6.09E-3	8.61E-3	1.16E-2	1.48E-2	1.73E-2	1.87E-2	1.90E-2
100	0.00	13.0	0.00	0.00	0.00	1.11E-3	2.51E-3	4.03E-3	5.89E-3	8.29E-3	1.12E-2	1.41E-2	1.65E-2	1.78E-2	1.81E-2
110	0.00	13.0	0.00	0.00	0.00	1.11E-3	2.50E-3	4.00E-3	5.78E-3	8.00E-3	1.06E-2	1.32E-2	1.52E-2	1.64E-2	1.66E-2
120	0.00	13.0	0.00	0.00	0.00	1.05E-3	2.37E-3	3.79E-3	5.46E-3	7.53E-3	9.93E-3	1.23E-2	1.43E-2	1.53E-2	1.55E-2
130	0.00	13.0	0.00	0.00	0.00	9.39E-4	2.12E-3	3.40E-3	4.95E-3	6.94E-3	9.31E-3	1.17E-2	1.37E-2	1.48E-2	1.50E-2
140	0.00	13.0	0.00	0.00	0.00	8.67E-4	1.96E-3	3.14E-3	4.59E-3	6.47E-3	8.72E-3	1.10E-2	1.29E-2	1.40E-2	1.42E-2
150	0.00	13.0	0.00	0.00	0.00	8.58E-4	1.93E-3	3.09E-3	4.47E-3	6.18E-3	8.18E-3	1.02E-2	1.18E-2	1.27E-2	1.29E-2
160	0.00	13.0	0.00	0.00	0.00	8.41E-4	1.89E-3	3.01E-3	4.33E-3	5.93E-3	7.75E-3	9.56E-3	1.10E-2	1.18E-2	1.20E-2
170	0.00	13.0	0.00	0.00	0.00	7.67E-4	1.73E-3	2.76E-3	4.01E-3	5.58E-3	7.42E-3	9.30E-3	1.08E-2	1.16E-2	1.18E-2
180	0.00	13.0	0.00	0.00	0.00	6.27E-4	1.43E-3	2.30E-3	3.42E-3	4.97E-3	6.91E-3	8.95E-3	1.06E-2	1.16E-2	1.18E-2
190	0.00	13.0	0.00	0.00	0.00	5.10E-4	1.17E-3	1.88E-3	2.85E-3	4.23E-3	6.00E-3	7.89E-3	9.47E-3	1.04E-2	1.05E-2
200	0.00	13.0	0.00	0.00	0.00	5.58E-4	1.25E-3	2.00E-3	2.88E-3	3.94E-3	5.16E-3	6.37E-3	7.34E-3	7.87E-3	7.97E-3
210	0.00	13.0	0.00	0.00	0.00	6.54E-4	1.45E-3	2.29E-3	3.17E-3	4.04E-3	4.87E-3	5.58E-3	6.09E-3	6.35E-3	6.39E-3
220	0.00	13.0	0.00	0.00	0.00	6.11E-4	1.37E-3	2.18E-3	3.08E-3	4.11E-3	5.23E-3	6.31E-3	7.15E-3	7.60E-3	7.68E-3
230	0.00	13.0	0.00	0.00	0.00	5.59E-4	1.27E-3	2.04E-3	3.04E-3	4.41E-3	6.12E-3	7.92E-3	9.40E-3	1.02E-2	1.04E-2
240	0.00	13.0	0.00	0.00	0.00	7.00E-4	1.58E-3	2.55E-3	3.75E-3	5.35E-3	7.30E-3	9.33E-3	1.10E-2	1.19E-2	1.21E-2
250	0.00	13.0	0.00	0.00	0.00	9.51E-4	2.13E-3	3.40E-3	4.87E-3	6.62E-3	8.60E-3	1.06E-2	1.21E-2	1.29E-2	1.31E-2
260	0.00	13.0	0.00	0.00	0.00	1.08E-3	2.42E-3	3.87E-3	5.55E-3	7.58E-3	9.90E-3	1.22E-2	1.40E-2	1.50E-2	1.52E-2
270	0.00	13.0	0.00	0.00	0.00	1.07E-3	2.42E-3	3.89E-3	5.71E-3	8.12E-3	1.10E-2	1.41E-2	1.65E-2	1.79E-2	1.82E-2
280	0.00	13.0	0.00	0.00	0.00	1.11E-3	2.51E-3	4.04E-3	5.99E-3	8.62E-3	1.19E-2	1.53E-2	1.81E-2	1.96E-2	1.99E-2
290	0.00	13.0	0.00	0.00	0.00	1.25E-3	2.81E-3	4.50E-3	6.56E-3	9.19E-3	1.23E-2	1.55E-2	1.81E-2	1.95E-2	1.98E-2
300	0.00	13.0	0.00	0.00	0.00	1.32E-3	2.97E-3	4.75E-3	6.85E-3	9.43E-3	1.24E-2	1.54E-2	1.78E-2	1.91E-2	1.94E-2
310	0.00	13.0	0.00	0.00	0.00	1.24E-3	2.81E-3	4.50E-3	6.55E-3	9.18E-3	1.23E-2	1.55E-2	1.81E-2	1.95E-2	1.98E-2
320	0.00	13.0	0.00	0.00	0.00	1.14E-3	2.59E-3	4.15E-3	6.13E-3	8.78E-3	1.20E-2	1.54E-2	1.82E-2	1.97E-2	2.00E-2
330	0.00	13.0	0.00	0.00	0.00	1.15E-3	2.60E-3	4.17E-3	6.10E-3	8.61E-3	1.16E-2	1.47E-2	1.73E-2	1.87E-2	1.89E-2
340	0.00	13.0	0.00	0.00	0.00	1.21E-3	2.71E-3	4.33E-3	6.23E-3	8.57E-3	1.13E-2	1.39E-2	1.61E-2	1.73E-2	1.75E-2
350	0.00	13.0	0.00	0.00	0.00	1.17E-3	2.63E-3	4.20E-3	6.06E-3	8.36E-3	1.10E-2	1.37E-2	1.58E-2	1.70E-2	1.72E-2
360	0.00	13.0	0.00	0.00	0.00	1.08E-3	2.44E-3	3.91E-3	5.73E-3	8.10E-3	1.10E-2	1.39E-2	1.63E-2	1.76E-2	1.79E-2

Blade section flap velocity (feet/second)

Trim Solution

Psi	Time	Phi	Phi-D	Phi-DD	X / R										
deg	sec	deg	deg/s	deg/s^2	.0	.1	.2	.3	.4	.5	.6	.7	.8	.9	1.0
0	0.00	13.0	0.00	0.00	0.00	-4.54E-3	-1.76E-2	-4.04E-2	-7.00E-2	-9.67E-2	-0.11	-9.03E-2	-4.29E-2	2.79E-2	0.11
10	0.00	13.0	0.00	0.00	0.00	4.45E-3	1.78E-2	4.15E-2	7.33E-2	0.11	0.13	0.14	0.13	0.10	6.67E-2
20	0.00	13.0	0.00	0.00	0.00	6.69E-3	2.70E-2	6.28E-2	0.11	0.16	0.20	0.22	0.21	0.18	0.14
30	0.00	13.0	0.00	0.00	0.00	-2.04E-4	5.25E-4	2.13E-3	6.76E-3	2.05E-2	5.15E-2	0.11	0.18	0.28	0.38
40	0.00	13.0	0.00	0.00	0.00	-3.86E-3	-1.37E-2	-3.06E-2	-5.01E-2	-5.85E-2	-3.72E-2	2.83E-2	0.14	0.29	0.45
50	0.00	13.0	0.00	0.00	0.00	1.38E-3	6.20E-3	1.49E-2	2.78E-2	4.58E-2	6.97E-2	0.10	0.14	0.18	0.22
60	0.00	13.0	0.00	0.00	0.00	5.52E-3	2.16E-2	4.99E-2	8.71E-2	0.12	0.14	0.13	8.81E-2	1.99E-2	-5.90E-2
70	0.00	13.0	0.00	0.00	0.00	5.85E-4	1.83E-3	3.91E-3	5.77E-3	4.29E-3	-4.69E-3	-2.44E-2	-5.55E-2	-9.50E-2	-0.14
80	0.00	13.0	0.00	0.00	0.00	-6.01E-3	-2.44E-2	-5.69E-2	-0.10	-0.15	-0.19	-0.21	-0.22	-0.20	-0.18
90	0.00	13.0	0.00	0.00	0.00	-4.68E-3	-1.99E-2	-4.71E-2	-8.59E-2	-0.13	-0.19	-0.24	-0.30	-0.35	-0.41
100	0.00	13.0	0.00	0.00	0.00	3.94E-4	-8.36E-4	-3.57E-3	-1.17E-2	-3.63E-2	-9.18E-2	-0.19	-0.33	-0.50	-0.69
110	0.00	13.0	0.00	0.00	0.00	-6.87E-4	-5.37E-3	-1.42E-2	-3.10E-2	-6.59E-2	-0.13	-0.24	-0.39	-0.57	-0.76
120	0.00	13.0	0.00	0.00	0.00	-6.58E-3	-2.83E-2	-6.70E-2	-0.12	-0.19	-0.28	-0.37	-0.46	-0.55	-0.65
130	0.00	13.0	0.00	0.00	0.00	-7.12E-3	-3.03E-2	-7.16E-2	-0.13	-0.20	-0.28	-0.37	-0.45	-0.53	-0.61
140	0.00	13.0	0.00	0.00	0.00	-1.83E-3	-9.58E-3	-2.38E-2	-4.70E-2	-8.62E-2	-0.15	-0.24	-0.37	-0.52	-0.67
150	0.00	13.0	0.00	0.00	0.00	5.66E-4	7.79E-5	-1.30E-3	-7.19E-3	-2.79E-2	-7.71E-2	-0.17	-0.29	-0.45	-0.62
160	0.00	13.0	0.00	0.00	0.00	-2.84E-3	-1.26E-2	-3.01E-2	-5.59E-2	-9.08E-2	-0.14	-0.19	-0.25	-0.32	-0.39
170	0.00	13.0	0.00	0.00	0.00	-7.40E-3	-3.02E-2	-7.07E-2	-0.13	-0.19	-0.24	-0.28	-0.29	-0.29	-0.28
180	0.00	13.0	0.00	0.00	0.00	-1.06E-2	-4.42E-2	-0.10	-0.19	-0.29	-0.39	-0.49	-0.57	-0.63	-0.69
190	0.00	13.0	0.00	0.00	0.00	-2.17E-3	-1.27E-2	-3.21E-2	-6.56E-2	-0.13	-0.23	-0.40	-0.62	-0.89	-1.2
200	0.00	13.0	0.00	0.00	0.00	9.03E-3	3.25E-2	7.30E-2	0.12	0.15	0.11	-2.89E-2	-0.27	-0.58	-0.93
210	0.00	13.0	0.00	0.00	0.00	2.32E-3	9.21E-3	2.13E-2	3.75E-2	5.35E-2	6.40E-2	6.40E-2	5.21E-2	3.08E-2	5.57E-3
220	0.00	13.0	0.00	0.00	0.00	-7.17E-3	-2.50E-2	-5.56E-2	-9.00E-2	-0.10	-5.19E-2	8.63E-2	0.32	0.62	0.96
230	0.00	13.0	0.00	0.00	0.00	1.11E-3	8.94E-3	2.38E-2	5.21E-2	0.11	0.22	0.41	0.66	0.97	1.3
240	0.00	13.0	0.00	0.00	0.00	1.57E-2	6.62E-2	0.16	0.28	0.44	0.61	0.78	0.94	1.1	1.2
250	0.00	13.0	0.00	0.00	0.00	1.45E-2	6.18E-2	0.15	0.27	0.42	0.59	0.78	0.96	1.1	1.3
260	0.00	13.0	0.00	0.00	0.00	1.37E-3	1.07E-2	2.84E-2	6.20E-2	0.13	0.26	0.48	0.78	1.1	1.5
270	0.00	13.0	0.00	0.00	0.00	-2.21E-3	-4.25E-3	-6.76E-3	-1.61E-3	3.46E-2	0.13	0.32	0.59	0.93	1.3
280	0.00	13.0	0.00	0.00	0.00	6.78E-3	2.90E-2	6.88E-2	0.13	0.20	0.28	0.37	0.46	0.55	0.64
290	0.00	13.0	0.00	0.00	0.00	9.83E-3	3.93E-2	9.13E-2	0.16	0.23	0.28	0.30	0.27	0.20	0.12
300	0.00	13.0	0.00	0.00	0.00	-4.23E-4	-1.71E-3	-3.97E-3	-7.04E-3	-1.03E-2	-1.29E-2	-1.40E-2	-1.35E-2	-1.17E-2	-9.23E-3
310	0.00	13.0	0.00	0.00	0.00	-8.76E-3	-3.49E-2	-8.10E-2	-0.14	-0.21	-0.25	-0.26	-0.22	-0.16	-7.80E-2
320	0.00	13.0	0.00	0.00	0.00	-3.50E-3	-1.51E-2	-3.59E-2	-6.58E-2	-0.10	-0.15	-0.20	-0.25	-0.31	-0.37
330	0.00	13.0	0.00	0.00	0.00	4.64E-3	1.63E-2	3.63E-2	5.89E-2	6.69E-2	3.71E-2	-4.89E-2	-0.20	-0.39	-0.60
340	0.00	13.0	0.00	0.00	0.00	1.84E-3	5.78E-3	1.24E-2	1.82E-2	1.36E-2	-1.46E-2	-7.66E-2	-0.17	-0.30	-0.43
350	0.00	13.0	0.00	0.00	0.00	-6.01E-3	-2.40E-2	-5.57E-2	-9.82E-2	-0.14	-0.17	-0.18	-0.16	-0.11	-6.09E-2
360	0.00	13.0	0.00	0.00	0.00	-4.58E-3	-1.77E-2	-4.08E-2	-7.07E-2	-9.76E-2	-0.11	-9.14E-2	-4.39E-2	2.72E-2	0.11

Blade tension (Lb)

Trim Solution

Psi	Time	Phi	Phi-D	Phi-DD	X / R										
deg	sec	deg	deg/s	deg/s^2	.0	.1	.2	.3	.4	.5	.6	.7	.8	.9	1.0
0	0.00	13.0	0.00	0.00	1.52E+4	1.46E+4	1.33E+4	1.17E+4	9.88E+3	8.12E+3	6.54E+3	5.23E+3	4.07E+3	3.00E+3	0.00
10	0.00	13.0	0.00	0.00	1.52E+4	1.46E+4	1.33E+4	1.17E+4	9.88E+3	8.12E+3	6.54E+3	5.23E+3	4.07E+3	3.00E+3	0.00
20	0.00	13.0	0.00	0.00	1.53E+4	1.46E+4	1.33E+4	1.17E+4	9.90E+3	8.14E+3	6.55E+3	5.23E+3	4.08E+3	3.01E+3	0.00
30	0.00	13.0	0.00	0.00	1.53E+4	1.46E+4	1.34E+4	1.17E+4	9.92E+3	8.15E+3	6.56E+3	5.24E+3	4.08E+3	3.01E+3	0.00
40	0.00	13.0	0.00	0.00	1.54E+4	1.47E+4	1.34E+4	1.18E+4	9.95E+3	8.17E+3	6.57E+3	5.26E+3	4.09E+3	3.02E+3	0.00
50	0.00	13.0	0.00	0.00	1.55E+4	1.48E+4	1.35E+4	1.18E+4	9.99E+3	8.20E+3	6.59E+3	5.27E+3	4.10E+3	3.03E+3	0.00
60	0.00	13.0	0.00	0.00	1.57E+4	1.49E+4	1.35E+4	1.19E+4	1.00E+4	8.23E+3	6.62E+3	5.29E+3	4.12E+3	3.04E+3	0.00
70	0.00	13.0	0.00	0.00	1.58E+4	1.50E+4	1.36E+4	1.19E+4	1.01E+4	8.27E+3	6.64E+3	5.31E+3	4.13E+3	3.05E+3	0.00
80	0.00	13.0	0.00	0.00	1.59E+4	1.51E+4	1.37E+4	1.20E+4	1.01E+4	8.30E+3	6.67E+3	5.33E+3	4.15E+3	3.06E+3	0.00
90	0.00	13.0	0.00	0.00	1.61E+4	1.52E+4	1.38E+4	1.21E+4	1.02E+4	8.34E+3	6.70E+3	5.35E+3	4.16E+3	3.07E+3	0.00
100	0.00	13.0	0.00	0.00	1.62E+4	1.53E+4	1.39E+4	1.21E+4	1.02E+4	8.38E+3	6.73E+3	5.37E+3	4.18E+3	3.08E+3	0.00
110	0.00	13.0	0.00	0.00	1.64E+4	1.55E+4	1.40E+4	1.22E+4	1.03E+4	8.42E+3	6.75E+3	5.39E+3	4.19E+3	3.09E+3	0.00
120	0.00	13.0	0.00	0.00	1.65E+4	1.56E+4	1.41E+4	1.23E+4	1.03E+4	8.45E+3	6.78E+3	5.41E+3	4.21E+3	3.10E+3	0.00
130	0.00	13.0	0.00	0.00	1.66E+4	1.57E+4	1.41E+4	1.23E+4	1.04E+4	8.49E+3	6.80E+3	5.43E+3	4.22E+3	3.11E+3	0.00
140	0.00	13.0	0.00	0.00	1.67E+4	1.57E+4	1.42E+4	1.24E+4	1.04E+4	8.51E+3	6.82E+3	5.44E+3	4.23E+3	3.12E+3	0.00
150	0.00	13.0	0.00	0.00	1.68E+4	1.58E+4	1.43E+4	1.24E+4	1.04E+4	8.54E+3	6.84E+3	5.45E+3	4.24E+3	3.12E+3	0.00
160	0.00	13.0	0.00	0.00	1.69E+4	1.59E+4	1.43E+4	1.24E+4	1.05E+4	8.55E+3	6.85E+3	5.46E+3	4.25E+3	3.13E+3	0.00
170	0.00	13.0	0.00	0.00	1.69E+4	1.59E+4	1.43E+4	1.25E+4	1.05E+4	8.56E+3	6.86E+3	5.47E+3	4.25E+3	3.13E+3	0.00
180	0.00	13.0	0.00	0.00	1.69E+4	1.59E+4	1.43E+4	1.25E+4	1.05E+4	8.56E+3	6.86E+3	5.47E+3	4.25E+3	3.13E+3	0.00
190	0.00	13.0	0.00	0.00	1.69E+4	1.59E+4	1.43E+4	1.25E+4	1.05E+4	8.56E+3	6.86E+3	5.47E+3	4.25E+3	3.13E+3	0.00
200	0.00	13.0	0.00	0.00	1.69E+4	1.59E+4	1.43E+4	1.24E+4	1.05E+4	8.55E+3	6.85E+3	5.46E+3	4.25E+3	3.13E+3	0.00
210	0.00	13.0	0.00	0.00	1.68E+4	1.58E+4	1.43E+4	1.24E+4	1.04E+4	8.54E+3	6.84E+3	5.45E+3	4.24E+3	3.12E+3	0.00
220	0.00	13.0	0.00	0.00	1.67E+4	1.58E+4	1.42E+4	1.24E+4	1.04E+4	8.52E+3	6.83E+3	5.44E+3	4.23E+3	3.12E+3	0.00
230	0.00	13.0	0.00	0.00	1.66E+4	1.57E+4	1.41E+4	1.23E+4	1.04E+4	8.49E+3	6.81E+3	5.43E+3	4.22E+3	3.11E+3	0.00
240	0.00	13.0	0.00	0.00	1.65E+4	1.56E+4	1.41E+4	1.23E+4	1.03E+4	8.46E+3	6.78E+3	5.41E+3	4.21E+3	3.10E+3	0.00
250	0.00	13.0	0.00	0.00	1.64E+4	1.55E+4	1.40E+4	1.22E+4	1.03E+4	8.42E+3	6.76E+3	5.39E+3	4.19E+3	3.09E+3	0.00
260	0.00	13.0	0.00	0.00	1.62E+4	1.54E+4	1.39E+4	1.21E+4	1.02E+4	8.38E+3	6.73E+3	5.37E+3	4.18E+3	3.08E+3	0.00
270	0.00	13.0	0.00	0.00	1.61E+4	1.52E+4	1.38E+4	1.21E+4	1.02E+4	8.35E+3	6.70E+3	5.35E+3	4.16E+3	3.07E+3	0.00
280	0.00	13.0	0.00	0.00	1.59E+4	1.51E+4	1.37E+4	1.20E+4	1.01E+4	8.31E+3	6.67E+3	5.33E+3	4.15E+3	3.06E+3	0.00
290	0.00	13.0	0.00	0.00	1.58E+4	1.50E+4	1.36E+4	1.19E+4	1.01E+4	8.27E+3	6.64E+3	5.31E+3	4.13E+3	3.05E+3	0.00
300	0.00	13.0	0.00	0.00	1.57E+4	1.49E+4	1.35E+4	1.19E+4	1.00E+4	8.23E+3	6.62E+3	5.29E+3	4.12E+3	3.04E+3	0.00
310	0.00	13.0	0.00	0.00	1.55E+4	1.48E+4	1.35E+4	1.18E+4	9.99E+3	8.20E+3	6.59E+3	5.27E+3	4.10E+3	3.03E+3	0.00
320	0.00	13.0	0.00	0.00	1.54E+4	1.47E+4	1.34E+4	1.18E+4	9.95E+3	8.17E+3	6.57E+3	5.25E+3	4.09E+3	3.02E+3	0.00
330	0.00	13.0	0.00	0.00	1.53E+4	1.46E+4	1.33E+4	1.17E+4	9.92E+3	8.15E+3	6.56E+3	5.24E+3	4.08E+3	3.01E+3	0.00
340	0.00	13.0	0.00	0.00	1.53E+4	1.46E+4	1.33E+4	1.17E+4	9.90E+3	8.13E+3	6.54E+3	5.23E+3	4.08E+3	3.01E+3	0.00
350	0.00	13.0	0.00	0.00	1.52E+4	1.46E+4	1.33E+4	1.17E+4	9.88E+3	8.12E+3	6.54E+3	5.23E+3	4.07E+3	3.00E+3	0.00
360	0.00	13.0	0.00	0.00	1.52E+4	1.46E+4	1.33E+4	1.17E+4	9.88E+3	8.12E+3	6.54E+3	5.23E+3	4.07E+3	3.00E+3	0.00

Blade edgewise shear (Lb)

Trim Solution

Psi	Time	Phi	Phi-D	Phi-DD	X / R										
					.0	.1	.2	.3	.4	.5	.6	.7	.8	.9	1.0
0	0.00	13.0	0.00	0.00	3.29E+2	3.19E+2	2.99E+2	2.70E+2	2.34E+2	1.93E+2	1.52E+2	1.14E+2	77.	42.	0.00
10	0.00	13.0	0.00	0.00	4.76E+2	4.34E+2	3.88E+2	3.37E+2	2.84E+2	2.30E+2	1.79E+2	1.34E+2	92.	53.	0.00
20	0.00	13.0	0.00	0.00	6.18E+2	5.46E+2	4.74E+2	4.03E+2	3.32E+2	2.65E+2	2.05E+2	1.53E+2	1.07E+2	64.	0.00
30	0.00	13.0	0.00	0.00	7.53E+2	6.53E+2	5.57E+2	4.65E+2	3.79E+2	2.99E+2	2.30E+2	1.71E+2	1.20E+2	73.	0.00
40	0.00	13.0	0.00	0.00	8.75E+2	7.48E+2	6.30E+2	5.21E+2	4.20E+2	3.29E+2	2.52E+2	1.88E+2	1.32E+2	82.	0.00
50	0.00	13.0	0.00	0.00	9.77E+2	8.28E+2	6.91E+2	5.67E+2	4.54E+2	3.54E+2	2.70E+2	2.01E+2	1.42E+2	89.	0.00
60	0.00	13.0	0.00	0.00	1.06E+3	8.92E+2	7.40E+2	6.03E+2	4.80E+2	3.73E+2	2.84E+2	2.12E+2	1.50E+2	96.	0.00
70	0.00	13.0	0.00	0.00	1.12E+3	9.40E+2	7.77E+2	6.30E+2	5.00E+2	3.87E+2	2.93E+2	2.19E+2	1.56E+2	9.97E+1	0.00
80	0.00	13.0	0.00	0.00	1.16E+3	9.68E+2	7.97E+2	6.45E+2	5.10E+2	3.94E+2	2.98E+2	2.23E+2	1.58E+2	1.02E+2	0.00
90	0.00	13.0	0.00	0.00	1.17E+3	9.74E+2	8.01E+2	6.47E+2	5.10E+2	3.93E+2	2.97E+2	2.22E+2	1.58E+2	1.02E+2	0.00
100	0.00	13.0	0.00	0.00	1.15E+3	9.58E+2	7.87E+2	6.35E+2	5.00E+2	3.85E+2	2.91E+2	2.17E+2	1.55E+2	1.00E+2	0.00
110	0.00	13.0	0.00	0.00	1.10E+3	9.22E+2	7.58E+2	6.11E+2	4.81E+2	3.70E+2	2.80E+2	2.09E+2	1.49E+2	96.	0.00
120	0.00	13.0	0.00	0.00	1.04E+3	8.67E+2	7.14E+2	5.77E+2	4.54E+2	3.49E+2	2.64E+2	1.97E+2	1.40E+2	90.	0.00
130	0.00	13.0	0.00	0.00	9.45E+2	7.94E+2	6.57E+2	5.32E+2	4.19E+2	3.22E+2	2.44E+2	1.81E+2	1.28E+2	83.	0.00
140	0.00	13.0	0.00	0.00	8.33E+2	7.05E+2	5.86E+2	4.76E+2	3.76E+2	2.90E+2	2.19E+2	1.63E+2	1.15E+2	74.	0.00
150	0.00	13.0	0.00	0.00	7.06E+2	6.04E+2	5.06E+2	4.14E+2	3.29E+2	2.54E+2	1.92E+2	1.43E+2	1.01E+2	63.	0.00
160	0.00	13.0	0.00	0.00	5.67E+2	4.94E+2	4.20E+2	3.47E+2	2.78E+2	2.16E+2	1.64E+2	1.21E+2	85.	52.	0.00
170	0.00	13.0	0.00	0.00	3.93E+2	3.51E+2	3.04E+2	2.54E+2	2.04E+2	1.60E+2	1.21E+2	89.	62.	38.	0.00
180	0.00	13.0	0.00	0.00	2.18E+2	2.08E+2	1.89E+2	1.63E+2	1.33E+2	1.06E+2	81.	60.	40.	24.	0.00
190	0.00	13.0	0.00	0.00	97.	1.17E+2	1.23E+2	1.16E+2	1.02E+2	85.	67.	49.	32.	16.	0.00
200	0.00	13.0	0.00	0.00	-22.	28.	58.	71.	71.	63.	52.	38.	23.	8.7	0.00
210	0.00	13.0	0.00	0.00	-1.57E+2	-78.	-24.	8.3	24.	28.	26.	18.	7.9	-2.3	0.00
220	0.00	13.0	0.00	0.00	-2.78E+2	-1.73E+2	-97.	-47.	-17.	-2.5	2.6	2.08E-2	-5.7	-12.	0.00
230	0.00	13.0	0.00	0.00	-3.83E+2	-2.55E+2	-1.61E+2	-95.	-53.	-29.	-17.	-14.	-16.	-20.	0.00
240	0.00	13.0	0.00	0.00	-4.67E+2	-3.22E+2	-2.12E+2	-1.34E+2	-82.	-49.	-31.	-25.	-24.	-25.	0.00
250	0.00	13.0	0.00	0.00	-5.25E+2	-3.66E+2	-2.45E+2	-1.58E+2	-98.	-61.	-39.	-31.	-28.	-29.	0.00
260	0.00	13.0	0.00	0.00	-5.56E+2	-3.88E+2	-2.60E+2	-1.67E+2	-1.04E+2	-64.	-41.	-32.	-30.	-31.	0.00
270	0.00	13.0	0.00	0.00	-5.61E+2	-3.91E+2	-2.60E+2	-1.66E+2	-1.01E+2	-60.	-38.	-30.	-28.	-30.	0.00
280	0.00	13.0	0.00	0.00	-5.42E+2	-3.75E+2	-2.46E+2	-1.54E+2	-90.	-51.	-30.	-23.	-23.	-27.	0.00
290	0.00	13.0	0.00	0.00	-4.97E+2	-3.38E+2	-2.16E+2	-1.29E+2	-70.	-35.	-17.	-13.	-16.	-22.	0.00
300	0.00	13.0	0.00	0.00	-4.26E+2	-2.80E+2	-1.69E+2	-91.	-40.	-11.	0.90	0.53	-6.2	-16.	0.00
310	0.00	13.0	0.00	0.00	-3.34E+2	-2.06E+2	-1.10E+2	-44.	-3.3	17.	22.	16.	5.0	-8.7	0.00
320	0.00	13.0	0.00	0.00	-2.26E+2	-1.19E+2	-42.	8.1	37.	47.	45.	34.	18.	0.31	0.00
330	0.00	13.0	0.00	0.00	-1.02E+2	-22.	34.	67.	81.	81.	70.	53.	32.	10.	0.00
340	0.00	13.0	0.00	0.00	35.	87.	1.19E+2	1.32E+2	1.31E+2	1.17E+2	97.	73.	47.	21.	0.00
350	0.00	13.0	0.00	0.00	1.81E+2	2.03E+2	2.09E+2	2.01E+2	1.83E+2	1.56E+2	1.25E+2	93.	62.	31.	0.00
360	0.00	13.0	0.00	0.00	3.29E+2	3.19E+2	2.99E+2	2.70E+2	2.34E+2	1.93E+2	1.52E+2	1.14E+2	77.	42.	0.00

Blade flapwise shear (Lb)

Trim Solution

Psi	Time	Phi	Phi-D	Phi-DD	X / R										
deg	sec	deg	deg/s	deg/s^2	.0	.1	.2	.3	.4	.5	.6	.7	.8	.9	1.0
0	0.00	13.0	0.00	0.00	-73.	3.5	1.37E+2	2.78E+2	3.94E+2	4.54E+2	4.43E+2	3.55E+2	2.03E+2	-1.2	0.00
10	0.00	13.0	0.00	0.00	-70.	5.7	1.38E+2	2.78E+2	3.94E+2	4.54E+2	4.44E+2	3.57E+2	2.06E+2	1.8	0.00
20	0.00	13.0	0.00	0.00	2.8	78.	2.06E+2	3.36E+2	4.36E+2	4.77E+2	4.50E+2	3.52E+2	1.95E+2	-10.	0.00
30	0.00	13.0	0.00	0.00	35.	1.11E+2	2.37E+2	3.64E+2	4.58E+2	4.92E+2	4.58E+2	3.55E+2	1.94E+2	-12.	0.00
40	0.00	13.0	0.00	0.00	-8.0	69.	2.00E+2	3.34E+2	4.39E+2	4.85E+2	4.64E+2	3.69E+2	2.12E+2	4.8	0.00
50	0.00	13.0	0.00	0.00	-38.	41.	1.75E+2	3.14E+2	4.26E+2	4.81E+2	4.69E+2	3.80E+2	2.26E+2	18.	0.00
60	0.00	13.0	0.00	0.00	4.9	86.	2.18E+2	3.51E+2	4.52E+2	4.95E+2	4.73E+2	3.77E+2	2.19E+2	10.	0.00
70	0.00	13.0	0.00	0.00	47.	1.30E+2	2.61E+2	3.88E+2	4.78E+2	5.07E+2	4.74E+2	3.70E+2	2.09E+2	-0.17	0.00
80	0.00	13.0	0.00	0.00	10.	97.	2.31E+2	3.62E+2	4.59E+2	4.95E+2	4.69E+2	3.70E+2	2.12E+2	3.7	0.00
90	0.00	13.0	0.00	0.00	-56.	34.	1.74E+2	3.13E+2	4.21E+2	4.70E+2	4.58E+2	3.70E+2	2.17E+2	11.	0.00
100	0.00	13.0	0.00	0.00	-68.	26.	1.67E+2	3.06E+2	4.11E+2	4.58E+2	4.46E+2	3.58E+2	2.08E+2	4.0	0.00
110	0.00	13.0	0.00	0.00	-44.	53.	1.93E+2	3.26E+2	4.19E+2	4.55E+2	4.33E+2	3.39E+2	1.86E+2	-14.	0.00
120	0.00	13.0	0.00	0.00	-75.	26.	1.69E+2	3.03E+2	3.98E+2	4.35E+2	4.16E+2	3.25E+2	1.75E+2	-22.	0.00
130	0.00	13.0	0.00	0.00	-1.48E+2	-44.	1.04E+2	2.46E+2	3.52E+2	4.03E+2	3.98E+2	3.17E+2	1.75E+2	-19.	0.00
140	0.00	13.0	0.00	0.00	-1.86E+2	-79.	72.	2.17E+2	3.25E+2	3.81E+2	3.81E+2	3.05E+2	1.67E+2	-22.	0.00
150	0.00	13.0	0.00	0.00	-1.73E+2	-63.	87.	2.28E+2	3.28E+2	3.75E+2	3.68E+2	2.88E+2	1.50E+2	-37.	0.00
160	0.00	13.0	0.00	0.00	-1.73E+2	-61.	90.	2.29E+2	3.25E+2	3.68E+2	3.58E+2	2.76E+2	1.37E+2	-47.	0.00
170	0.00	13.0	0.00	0.00	-2.11E+2	-96.	56.	1.95E+2	2.93E+2	3.45E+2	3.43E+2	2.69E+2	1.39E+2	-37.	0.00
180	0.00	13.0	0.00	0.00	-2.98E+2	-1.81E+2	-25.	1.21E+2	2.33E+2	3.05E+2	3.21E+2	2.64E+2	1.46E+2	-22.	0.00
190	0.00	13.0	0.00	0.00	-3.73E+2	-2.55E+2	-94.	63.	1.89E+2	2.74E+2	3.03E+2	2.53E+2	1.38E+2	-33.	0.00
200	0.00	13.0	0.00	0.00	-3.12E+2	-1.95E+2	-37.	1.12E+2	2.22E+2	2.83E+2	2.90E+2	2.25E+2	9.97E+1	-74.	0.00
210	0.00	13.0	0.00	0.00	-2.20E+2	-1.04E+2	47.	1.82E+2	2.71E+2	3.05E+2	2.87E+2	2.04E+2	71.	-1.01E+2	0.00
220	0.00	13.0	0.00	0.00	-2.72E+2	-1.56E+2	-1.3	1.43E+2	2.48E+2	2.98E+2	2.94E+2	2.20E+2	91.	-81.	0.00
230	0.00	13.0	0.00	0.00	-3.51E+2	-2.36E+2	-75.	85.	2.13E+2	2.91E+2	3.12E+2	2.54E+2	1.32E+2	-43.	0.00
240	0.00	13.0	0.00	0.00	-2.76E+2	-1.64E+2	-6.5	1.47E+2	2.66E+2	3.32E+2	3.43E+2	2.76E+2	1.47E+2	-33.	0.00
250	0.00	13.0	0.00	0.00	-1.19E+2	-10.	1.38E+2	2.74E+2	3.68E+2	4.02E+2	3.80E+2	2.90E+2	1.46E+2	-41.	0.00
260	0.00	13.0	0.00	0.00	-65.	40.	1.86E+2	3.21E+2	4.14E+2	4.43E+2	4.15E+2	3.18E+2	1.67E+2	-27.	0.00
270	0.00	13.0	0.00	0.00	-1.19E+2	-16.	1.34E+2	2.82E+2	3.96E+2	4.50E+2	4.42E+2	3.57E+2	2.09E+2	9.7	0.00
280	0.00	13.0	0.00	0.00	-1.17E+2	-17.	1.32E+2	2.83E+2	4.03E+2	4.64E+2	4.62E+2	3.80E+2	2.31E+2	27.	0.00
290	0.00	13.0	0.00	0.00	-15.	80.	2.22E+2	3.60E+2	4.61E+2	5.01E+2	4.77E+2	3.79E+2	2.21E+2	12.	0.00
300	0.00	13.0	0.00	0.00	47.	1.38E+2	2.75E+2	4.04E+2	4.95E+2	5.22E+2	4.83E+2	3.75E+2	2.10E+2	-0.77	0.00
310	0.00	13.0	0.00	0.00	-12.	77.	2.15E+2	3.53E+2	4.59E+2	5.03E+2	4.79E+2	3.81E+2	2.20E+2	9.5	0.00
320	0.00	13.0	0.00	0.00	-81.	4.5	1.45E+2	2.92E+2	4.13E+2	4.76E+2	4.70E+2	3.83E+2	2.30E+2	20.	0.00
330	0.00	13.0	0.00	0.00	-51.	32.	1.68E+2	3.08E+2	4.21E+2	4.75E+2	4.61E+2	3.70E+2	2.15E+2	6.0	0.00
340	0.00	13.0	0.00	0.00	16.	95.	2.25E+2	3.55E+2	4.51E+2	4.87E+2	4.54E+2	3.51E+2	1.91E+2	-17.	0.00
350	0.00	13.0	0.00	0.00	-2.6	75.	2.05E+2	3.36E+2	4.37E+2	4.77E+2	4.48E+2	3.47E+2	1.89E+2	-17.	0.00
360	0.00	13.0	0.00	0.00	-73.	3.9	1.37E+2	2.78E+2	3.94E+2	4.54E+2	4.43E+2	3.55E+2	2.03E+2	-1.3	0.00

Blade flapwise moment (ft-Lbs

Trim Solution

Psi	Time	Phi	Phi-D	Phi-DD	X / R										
deg	sec	deg	deg/s	deg/s^2	.0	.1	.2	.3	.4	.5	.6	.7	.8	.9	1.0
0	0.00	13.0	0.00	0.00	-6.45E+3	-6.63E+3	-6.46E+3	-5.82E+3	-4.73E+3	-3.33E+3	-1.88E+3	-6.16E+2	1.91E+2	3.61E+2	0.00
10	0.00	13.0	0.00	0.00	-6.50E+3	-6.67E+3	-6.49E+3	-5.85E+3	-4.76E+3	-3.36E+3	-1.90E+3	-6.38E+2	1.76E+2	3.54E+2	0.00
20	0.00	13.0	0.00	0.00	-7.49E+3	-7.39E+3	-6.95E+3	-6.08E+3	-4.81E+3	-3.30E+3	-1.80E+3	-5.37E+2	2.46E+2	3.83E+2	0.00
30	0.00	13.0	0.00	0.00	-8.02E+3	-7.79E+3	-7.24E+3	-6.26E+3	-4.91E+3	-3.34E+3	-1.80E+3	-5.22E+2	2.60E+2	3.89E+2	0.00
40	0.00	13.0	0.00	0.00	-7.60E+3	-7.53E+3	-7.13E+3	-6.28E+3	-5.02E+3	-3.50E+3	-1.96E+3	-6.58E+2	1.72E+2	3.53E+2	0.00
50	0.00	13.0	0.00	0.00	-7.33E+3	-7.37E+3	-7.07E+3	-6.30E+3	-5.10E+3	-3.62E+3	-2.09E+3	-7.61E+2	1.05E+2	3.27E+2	0.00
60	0.00	13.0	0.00	0.00	-7.94E+3	-7.82E+3	-7.35E+3	-6.44E+3	-5.13E+3	-3.58E+3	-2.02E+3	-6.99E+2	1.49E+2	3.45E+2	0.00
70	0.00	13.0	0.00	0.00	-8.52E+3	-8.23E+3	-7.61E+3	-6.55E+3	-5.13E+3	-3.51E+3	-1.93E+3	-6.11E+2	2.08E+2	3.69E+2	0.00
80	0.00	13.0	0.00	0.00	-8.03E+3	-7.88E+3	-7.37E+3	-6.41E+3	-5.06E+3	-3.50E+3	-1.95E+3	-6.41E+2	1.85E+2	3.59E+2	0.00
90	0.00	13.0	0.00	0.00	-7.10E+3	-7.19E+3	-6.90E+3	-6.13E+3	-4.94E+3	-3.49E+3	-1.99E+3	-7.00E+2	1.38E+2	3.38E+2	0.00
100	0.00	13.0	0.00	0.00	-6.81E+3	-6.94E+3	-6.68E+3	-5.94E+3	-4.77E+3	-3.35E+3	-1.90E+3	-6.38E+2	1.72E+2	3.50E+2	0.00
110	0.00	13.0	0.00	0.00	-6.95E+3	-6.98E+3	-6.62E+3	-5.79E+3	-4.57E+3	-3.13E+3	-1.70E+3	-4.85E+2	2.66E+2	3.86E+2	0.00
120	0.00	13.0	0.00	0.00	-6.37E+3	-6.51E+3	-6.24E+3	-5.49E+3	-4.34E+3	-2.97E+3	-1.59E+3	-4.19E+2	2.98E+2	3.96E+2	0.00
130	0.00	13.0	0.00	0.00	-5.25E+3	-5.65E+3	-5.63E+3	-5.09E+3	-4.12E+3	-2.88E+3	-1.58E+3	-4.43E+2	2.70E+2	3.81E+2	0.00
140	0.00	13.0	0.00	0.00	-4.57E+3	-5.12E+3	-5.21E+3	-4.79E+3	-3.91E+3	-2.75E+3	-1.51E+3	-4.10E+2	2.81E+2	3.82E+2	0.00
150	0.00	13.0	0.00	0.00	-4.58E+3	-5.07E+3	-5.11E+3	-4.63E+3	-3.72E+3	-2.56E+3	-1.34E+3	-2.88E+2	3.53E+2	4.08E+2	0.00
160	0.00	13.0	0.00	0.00	-4.46E+3	-4.94E+3	-4.97E+3	-4.48E+3	-3.57E+3	-2.42E+3	-1.23E+3	-2.06E+2	4.00E+2	4.25E+2	0.00
170	0.00	13.0	0.00	0.00	-3.84E+3	-4.45E+3	-4.60E+3	-4.23E+3	-3.44E+3	-2.38E+3	-1.25E+3	-2.62E+2	3.39E+2	3.88E+2	0.00
180	0.00	13.0	0.00	0.00	-2.48E+3	-3.43E+3	-3.88E+3	-3.78E+3	-3.23E+3	-2.34E+3	-1.31E+3	-3.62E+2	2.48E+2	3.41E+2	0.00
190	0.00	13.0	0.00	0.00	-1.26E+3	-2.49E+3	-3.21E+3	-3.33E+3	-2.95E+3	-2.18E+3	-1.22E+3	-3.00E+2	2.96E+2	3.70E+2	0.00
200	0.00	13.0	0.00	0.00	-1.80E+3	-2.79E+3	-3.29E+3	-3.22E+3	-2.68E+3	-1.83E+3	-8.57E+2	7.5	5.08E+2	4.63E+2	0.00
210	0.00	13.0	0.00	0.00	-2.87E+3	-3.52E+3	-3.69E+3	-3.34E+3	-2.59E+3	-1.61E+3	-6.01E+2	2.29E+2	6.53E+2	5.19E+2	0.00
220	0.00	13.0	0.00	0.00	-2.34E+3	-3.18E+3	-3.54E+3	-3.35E+3	-2.71E+3	-1.79E+3	-7.86E+2	75.	5.51E+2	4.77E+2	0.00
230	0.00	13.0	0.00	0.00	-1.64E+3	-2.78E+3	-3.43E+3	-3.49E+3	-3.02E+3	-2.18E+3	-1.17E+3	-2.36E+2	3.51E+2	3.97E+2	0.00
240	0.00	13.0	0.00	0.00	-3.00E+3	-3.87E+3	-4.26E+3	-4.09E+3	-3.43E+3	-2.44E+3	-1.32E+3	-3.17E+2	3.14E+2	3.86E+2	0.00
250	0.00	13.0	0.00	0.00	-5.46E+3	-5.75E+3	-5.59E+3	-4.94E+3	-3.88E+3	-2.60E+3	-1.32E+3	-2.49E+2	3.83E+2	4.19E+2	0.00
260	0.00	13.0	0.00	0.00	-6.60E+3	-6.70E+3	-6.37E+3	-5.55E+3	-4.34E+3	-2.92E+3	-1.53E+3	-3.69E+2	3.24E+2	4.00E+2	0.00
270	0.00	13.0	0.00	0.00	-6.32E+3	-6.62E+3	-6.49E+3	-5.85E+3	-4.75E+3	-3.37E+3	-1.93E+3	-6.75E+2	1.37E+2	3.30E+2	0.00
280	0.00	13.0	0.00	0.00	-6.58E+3	-6.89E+3	-6.77E+3	-6.14E+3	-5.03E+3	-3.62E+3	-2.13E+3	-8.18E+2	56.	3.02E+2	0.00
290	0.00	13.0	0.00	0.00	-8.00E+3	-7.92E+3	-7.46E+3	-6.53E+3	-5.18E+3	-3.61E+3	-2.04E+3	-7.07E+2	1.43E+2	3.42E+2	0.00
300	0.00	13.0	0.00	0.00	-8.80E+3	-8.50E+3	-7.83E+3	-6.72E+3	-5.24E+3	-3.57E+3	-1.95E+3	-6.10E+2	2.15E+2	3.74E+2	0.00
310	0.00	13.0	0.00	0.00	-7.96E+3	-7.88E+3	-7.44E+3	-6.53E+3	-5.20E+3	-3.63E+3	-2.04E+3	-6.99E+2	1.56E+2	3.50E+2	0.00
320	0.00	13.0	0.00	0.00	-6.91E+3	-7.10E+3	-6.92E+3	-6.25E+3	-5.11E+3	-3.66E+3	-2.13E+3	-7.92E+2	89.	3.24E+2	0.00
330	0.00	13.0	0.00	0.00	-7.10E+3	-7.18E+3	-6.91E+3	-6.16E+3	-4.97E+3	-3.50E+3	-1.98E+3	-6.77E+2	1.62E+2	3.53E+2	0.00
340	0.00	13.0	0.00	0.00	-7.77E+3	-7.61E+3	-7.11E+3	-6.17E+3	-4.84E+3	-3.29E+3	-1.76E+3	-4.92E+2	2.83E+2	4.01E+2	0.00
350	0.00	13.0	0.00	0.00	-7.42E+3	-7.33E+3	-6.90E+3	-6.03E+3	-4.76E+3	-3.25E+3	-1.75E+3	-4.89E+2	2.80E+2	3.98E+2	0.00
360	0.00	13.0	0.00	0.00	-6.45E+3	-6.63E+3	-6.46E+3	-5.82E+3	-4.73E+3	-3.33E+3	-1.88E+3	-6.15E+2	1.92E+2	3.61E+2	0.00

Average Flapwise Moment = -6020.8 (ft-Lbs) at the 20% station

Blade edgewise moment (ft-Lbs)

Trim Solution

Psi	Time	Phi	Phi-D	Phi-DD	X / R										
deg	sec	deg	deg/s	deg/s^2	.0	.1	.2	.3	.4	.5	.6	.7	.8	.9	1.0
0	0.00	13.0	0.00	0.00	7.10E+3	5.87E+3	4.69E+3	3.61E+3	2.65E+3	1.84E+3	1.18E+3	6.74E+2	3.13E+2	87.	0.00
10	0.00	13.0	0.00	0.00	9.01E+3	7.28E+3	5.72E+3	4.34E+3	3.16E+3	2.19E+3	1.41E+3	8.19E+2	3.90E+2	1.15E+2	0.00
20	0.00	13.0	0.00	0.00	1.09E+4	8.66E+3	6.72E+3	5.06E+3	3.66E+3	2.53E+3	1.64E+3	9.57E+2	4.64E+2	1.42E+2	0.00
30	0.00	13.0	0.00	0.00	1.26E+4	9.97E+3	7.67E+3	5.73E+3	4.13E+3	2.85E+3	1.84E+3	1.08E+3	5.31E+2	1.66E+2	0.00
40	0.00	13.0	0.00	0.00	1.42E+4	1.11E+4	8.52E+3	6.34E+3	4.55E+3	3.13E+3	2.03E+3	1.20E+3	5.92E+2	1.88E+2	0.00
50	0.00	13.0	0.00	0.00	1.55E+4	1.21E+4	9.22E+3	6.84E+3	4.90E+3	3.37E+3	2.19E+3	1.30E+3	6.46E+2	2.07E+2	0.00
60	0.00	13.0	0.00	0.00	1.66E+4	1.29E+4	9.78E+3	7.23E+3	5.17E+3	3.56E+3	2.31E+3	1.38E+3	6.89E+2	2.23E+2	0.00
70	0.00	13.0	0.00	0.00	1.73E+4	1.34E+4	1.02E+4	7.51E+3	5.36E+3	3.69E+3	2.40E+3	1.43E+3	7.17E+2	2.34E+2	0.00
80	0.00	13.0	0.00	0.00	1.78E+4	1.37E+4	1.04E+4	7.65E+3	5.46E+3	3.75E+3	2.44E+3	1.45E+3	7.31E+2	2.39E+2	0.00
90	0.00	13.0	0.00	0.00	1.78E+4	1.38E+4	1.04E+4	7.65E+3	5.45E+3	3.74E+3	2.44E+3	1.45E+3	7.33E+2	2.40E+2	0.00
100	0.00	13.0	0.00	0.00	1.75E+4	1.35E+4	1.02E+4	7.49E+3	5.34E+3	3.67E+3	2.39E+3	1.43E+3	7.20E+2	2.36E+2	0.00
110	0.00	13.0	0.00	0.00	1.68E+4	1.30E+4	9.80E+3	7.21E+3	5.13E+3	3.52E+3	2.29E+3	1.37E+3	6.91E+2	2.27E+2	0.00
120	0.00	13.0	0.00	0.00	1.59E+4	1.22E+4	9.24E+3	6.79E+3	4.84E+3	3.32E+3	2.16E+3	1.29E+3	6.48E+2	2.13E+2	0.00
130	0.00	13.0	0.00	0.00	1.46E+4	1.13E+4	8.52E+3	6.26E+3	4.46E+3	3.05E+3	1.98E+3	1.18E+3	5.94E+2	1.94E+2	0.00
140	0.00	13.0	0.00	0.00	1.30E+4	1.01E+4	7.64E+3	5.62E+3	4.01E+3	2.74E+3	1.78E+3	1.06E+3	5.30E+2	1.73E+2	0.00
150	0.00	13.0	0.00	0.00	1.13E+4	8.77E+3	6.66E+3	4.91E+3	3.50E+3	2.40E+3	1.55E+3	9.20E+2	4.58E+2	1.48E+2	0.00
160	0.00	13.0	0.00	0.00	9.36E+3	7.35E+3	5.61E+3	4.15E+3	2.97E+3	2.03E+3	1.31E+3	7.70E+2	3.80E+2	1.21E+2	0.00
170	0.00	13.0	0.00	0.00	6.77E+3	5.35E+3	4.11E+3	3.05E+3	2.18E+3	1.49E+3	9.59E+2	5.60E+2	2.74E+2	86.	0.00
180	0.00	13.0	0.00	0.00	4.24E+3	3.43E+3	2.67E+3	2.00E+3	1.44E+3	9.85E+2	6.30E+2	3.64E+2	1.75E+2	53.	0.00
190	0.00	13.0	0.00	0.00	2.88E+3	2.47E+3	2.01E+3	1.56E+3	1.14E+3	7.87E+2	4.99E+2	2.79E+2	1.24E+2	32.	0.00
200	0.00	13.0	0.00	0.00	1.55E+3	1.53E+3	1.36E+3	1.11E+3	8.37E+2	5.81E+2	3.61E+2	1.89E+2	72.	11.	0.00
210	0.00	13.0	0.00	0.00	-2.58E+2	1.82E+2	3.70E+2	3.95E+2	3.31E+2	2.30E+2	1.27E+2	44.	-5.3	-16.	0.00
220	0.00	13.0	0.00	0.00	-1.85E+3	-1.00E+3	-4.95E+2	-2.28E+2	-1.11E+2	-76.	-78.	-85.	-74.	-40.	0.00
230	0.00	13.0	0.00	0.00	-3.23E+3	-2.02E+3	-1.24E+3	-7.58E+2	-4.80E+2	-3.27E+2	-2.42E+2	-1.85E+2	-1.27E+2	-59.	0.00
240	0.00	13.0	0.00	0.00	-4.31E+3	-2.82E+3	-1.81E+3	-1.16E+3	-7.56E+2	-5.11E+2	-3.61E+2	-2.57E+2	-1.66E+2	-73.	0.00
250	0.00	13.0	0.00	0.00	-4.99E+3	-3.31E+3	-2.16E+3	-1.40E+3	-9.18E+2	-6.20E+2	-4.33E+2	-3.02E+2	-1.91E+2	-83.	0.00
260	0.00	13.0	0.00	0.00	-5.28E+3	-3.50E+3	-2.28E+3	-1.48E+3	-9.66E+2	-6.53E+2	-4.57E+2	-3.21E+2	-2.03E+2	-88.	0.00
270	0.00	13.0	0.00	0.00	-5.24E+3	-3.44E+3	-2.22E+3	-1.41E+3	-9.15E+2	-6.14E+2	-4.32E+2	-3.07E+2	-1.98E+2	-88.	0.00
280	0.00	13.0	0.00	0.00	-4.88E+3	-3.15E+3	-1.98E+3	-1.23E+3	-7.72E+2	-5.09E+2	-3.59E+2	-2.62E+2	-1.76E+2	-81.	0.00
290	0.00	13.0	0.00	0.00	-4.17E+3	-2.60E+3	-1.55E+3	-9.06E+2	-5.35E+2	-3.41E+2	-2.47E+2	-1.94E+2	-1.41E+2	-70.	0.00
300	0.00	13.0	0.00	0.00	-3.12E+3	-1.79E+3	-9.41E+2	-4.54E+2	-2.11E+2	-1.19E+2	-1.03E+2	-1.08E+2	-98.	-56.	0.00
310	0.00	13.0	0.00	0.00	-1.80E+3	-7.87E+2	-1.95E+2	92.	1.78E+2	1.47E+2	71.	-4.0	-45.	-38.	0.00
320	0.00	13.0	0.00	0.00	-3.06E+2	3.42E+2	6.42E+2	7.01E+2	6.11E+2	4.47E+2	2.69E+2	1.18E+2	19.	-16.	0.00
330	0.00	13.0	0.00	0.00	1.37E+3	1.59E+3	1.57E+3	1.37E+3	1.08E+3	7.73E+2	4.85E+2	2.51E+2	89.	8.2	0.00
340	0.00	13.0	0.00	0.00	3.21E+3	2.97E+3	2.57E+3	2.09E+3	1.59E+3	1.12E+3	7.11E+2	3.89E+2	1.62E+2	34.	0.00
350	0.00	13.0	0.00	0.00	5.15E+3	4.42E+3	3.63E+3	2.85E+3	2.12E+3	1.48E+3	9.43E+2	5.29E+2	2.36E+2	60.	0.00
360	0.00	13.0	0.00	0.00	7.10E+3	5.87E+3	4.69E+3	3.61E+3	2.65E+3	1.84E+3	1.18E+3	6.74E+2	3.13E+2	87.	0.00

Blade torsion (ft-Lbs)

Trim Solution

Psi	Time	Phi	Phi-D	Phi-DD												
deg	sec	deg	deg/s	deg/s^2	.0	.1	.2	.3	.4	.5	.6	.7	.8	.9	1.0	
0	0.00	13.0	0.00	0.00	-16.	-15.	-14.	-11.	-8.0	-4.4	-0.82	2.2	3.8	3.2	0.00	
10	0.00	13.0	0.00	0.00	-25.	-24.	-22.	-18.	-14.	-9.2	-4.4	-0.27	2.4	2.7	0.00	
20	0.00	13.0	0.00	0.00	-35.	-34.	-30.	-26.	-20.	-14.	-7.6	-2.3	1.3	2.3	0.00	
30	0.00	13.0	0.00	0.00	-44.	-43.	-39.	-33.	-26.	-18.	-11.	-4.5	7.61E-2	1.9	0.00	
40	0.00	13.0	0.00	0.00	-53.	-51.	-47.	-40.	-32.	-24.	-15.	-7.4	-1.5	1.3	0.00	
50	0.00	13.0	0.00	0.00	-60.	-58.	-53.	-46.	-38.	-28.	-19.	-9.9	-3.0	0.78	0.00	
60	0.00	13.0	0.00	0.00	-66.	-65.	-59.	-51.	-41.	-31.	-21.	-11.	-3.6	0.56	0.00	
70	0.00	13.0	0.00	0.00	-71.	-68.	-62.	-53.	-43.	-32.	-21.	-11.	-3.7	0.51	0.00	
80	0.00	13.0	0.00	0.00	-70.	-68.	-62.	-53.	-43.	-32.	-21.	-12.	-3.9	0.45	0.00	
90	0.00	13.0	0.00	0.00	-66.	-65.	-59.	-51.	-41.	-31.	-21.	-11.	-3.8	0.47	0.00	
100	0.00	13.0	0.00	0.00	-61.	-59.	-54.	-46.	-37.	-28.	-18.	-9.5	-2.8	0.80	0.00	
110	0.00	13.0	0.00	0.00	-54.	-52.	-47.	-40.	-31.	-23.	-14.	-6.8	-1.3	1.3	0.00	
120	0.00	13.0	0.00	0.00	-45.	-43.	-39.	-32.	-25.	-17.	-10.	-4.2	0.14	1.8	0.00	
130	0.00	13.0	0.00	0.00	-34.	-33.	-29.	-24.	-18.	-12.	-6.7	-1.9	1.4	2.3	0.00	
140	0.00	13.0	0.00	0.00	-24.	-23.	-20.	-16.	-12.	-7.0	-2.8	0.70	2.8	2.8	0.00	
150	0.00	13.0	0.00	0.00	-15.	-14.	-12.	-8.7	-5.1	-1.6	1.4	3.5	4.3	3.3	0.00	
160	0.00	13.0	0.00	0.00	-6.7	-6.1	-4.3	-1.9	0.69	3.1	4.9	6.0	5.7	3.8	0.00	
170	0.00	13.0	0.00	0.00	3.6	3.9	4.9	6.2	7.4	8.3	8.7	8.4	7.0	4.2	0.00	
180	0.00	13.0	0.00	0.00	13.	13.	13.	14.	13.	13.	12.	11.	8.1	4.6	0.00	
190	0.00	13.0	0.00	0.00	18.	18.	18.	17.	17.	15.	14.	12.	8.8	4.9	0.00	
200	0.00	13.0	0.00	0.00	21.	21.	21.	20.	19.	18.	16.	13.	9.5	5.1	0.00	
210	0.00	13.0	0.00	0.00	25.	25.	24.	23.	22.	20.	17.	14.	10.	5.3	0.00	
220	0.00	13.0	0.00	0.00	29.	28.	27.	26.	24.	21.	18.	15.	11.	5.5	0.00	
230	0.00	13.0	0.00	0.00	32.	31.	30.	28.	26.	23.	20.	16.	11.	5.8	0.00	
240	0.00	13.0	0.00	0.00	36.	35.	34.	31.	28.	25.	21.	17.	12.	6.0	0.00	
250	0.00	13.0	0.00	0.00	40.	39.	37.	34.	31.	27.	22.	18.	12.	6.2	0.00	
260	0.00	13.0	0.00	0.00	43.	42.	39.	36.	32.	28.	23.	18.	13.	6.4	0.00	
270	0.00	13.0	0.00	0.00	43.	42.	40.	36.	33.	28.	24.	19.	13.	6.6	0.00	
280	0.00	13.0	0.00	0.00	42.	41.	38.	35.	31.	27.	23.	18.	13.	6.6	0.00	
290	0.00	13.0	0.00	0.00	39.	38.	35.	32.	28.	25.	21.	17.	12.	6.3	0.00	
300	0.00	13.0	0.00	0.00	33.	32.	30.	27.	24.	21.	19.	15.	11.	6.0	0.00	
310	0.00	13.0	0.00	0.00	25.	25.	23.	21.	19.	18.	16.	13.	10.	5.6	0.00	
320	0.00	13.0	0.00	0.00	17.	17.	16.	15.	14.	13.	12.	11.	9.0	5.2	0.00	
330	0.00	13.0	0.00	0.00	9.2	9.0	8.7	8.5	8.6	8.8	9.1	8.9	7.6	4.7	0.00	
340	0.00	13.0	0.00	0.00	0.72	0.75	1.2	2.0	3.2	4.7	6.1	6.9	6.5	4.2	0.00	
350	0.00	13.0	0.00	0.00	-7.7	-7.4	-6.3	-4.5	-2.2	0.41	2.9	4.8	5.3	3.8	0.00	
360	0.00	13.0	0.00	0.00	-16.	-15.	-14.	-11.	-8.0	-4.4	-0.81	2.2	3.8	3.2	0.00	

Blade flapwise moment expansion coefficients

Trim Solution

	X / R										
	.0	.1	.2	.3	.4	.5	.6	.7	.8	.9	1.
A0=	-5.89E+3	-6.16E+3	-6.02E+3	-5.39E+3	-4.33E+3	-3.01E+3	-1.65E+3	-4.73E+2	2.60E+2	3.79E+2	0.00
B0=	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
A1=	-2.46E+3	-2.00E+3	-1.62E+3	-1.29E+3	-9.83E+2	-6.88E+2	-4.41E+2	-2.50E+2	-1.13E+2	-29.	0.00
B1=	-7.25E+2	-5.68E+2	-4.37E+2	-3.29E+2	-2.40E+2	-1.67E+2	-1.09E+2	-63.	-29.	-7.8	0.00
A2=	1.14E+3	9.54E+2	7.77E+2	6.09E+2	4.51E+2	3.16E+2	2.08E+2	1.23E+2	61.	19.	0.00
B2=	7.40E+2	6.26E+2	5.17E+2	4.15E+2	3.20E+2	2.34E+2	1.59E+2	98.	49.	15.	0.00
A3=	3.60E+2	3.11E+2	2.64E+2	2.21E+2	1.82E+2	1.45E+2	1.10E+2	77.	46.	18.	0.00
B3=	-3.51E+2	-2.94E+2	-2.40E+2	-1.90E+2	-1.45E+2	-1.06E+2	-75.	-50.	-30.	-12.	0.00
A4=	-1.03E+2	-93.	-84.	-77.	-70.	-63.	-54.	-43.	-29.	-13.	0.00
B4=	59.	49.	39.	31.	23.	17.	12.	9.1	6.3	3.2	0.00
A5=	-3.3	7.2	17.	27.	36.	41.	40.	35.	25.	12.	0.00
B5=	-24.	-19.	-15.	-10.	-7.0	-4.5	-3.0	-2.3	-2.0	-1.3	0.00
A6=	76.	49.	24.	0.80	-19.	-32.	-36.	-33.	-24.	-11.	0.00
B6=	18.	14.	9.8	6.0	2.8	0.66	-0.29	-0.29	0.18	0.44	0.00
A7=	-1.65E+2	-1.14E+2	-66.	-23.	12.	35.	43.	40.	29.	13.	0.00
B7=	-42.	-31.	-20.	-10.	-2.5	2.7	5.0	4.8	3.0	0.92	0.00
A8=	4.35E+2	3.05E+2	1.81E+2	72.	-12.	-63.	-81.	-75.	-53.	-23.	0.00
B8=	5.58E+2	3.94E+2	2.39E+2	1.02E+2	-3.1	-69.	-94.	-86.	-59.	-24.	0.00
A9=	2.01E+2	1.41E+2	85.	36.	0.32	-21.	-27.	-23.	-14.	-4.7	0.00
B9=	-42.	-29.	-17.	-5.8	1.9	5.8	6.6	5.4	3.4	1.3	0.00
A*=	-95.	-66.	-39.	-16.	-0.50	8.4	11.	8.5	4.4	0.96	0.00
B*=	14.	10.	5.8	2.3	-7.40E-2	-1.2	-1.4	-1.1	-0.58	-0.18	0.00

Mean Rotor Torque =	13993.57 ft-Lbs
Mean Rotor Power =	119.21 kW
No. of Data Points =	36

Low-Speed Shaft Loads in Rotor coordinates

Azimuth Angle	Fxr	Fyr	Fzr	Mxr	Myr	Mzr
0.000	118.669	3533.737	-1731.120	-3878.388	12628.680	-394.485
10.000	389.462	3460.918	-1712.961	-5178.290	13183.030	-811.221
20.000	650.965	3594.173	-1637.488	-5548.472	13814.660	-1216.224
30.000	918.805	3717.303	-1504.489	-4769.990	13839.520	-1662.392
40.000	1160.662	3622.955	-1334.563	-4817.126	13784.990	-2060.046
50.000	1370.130	3515.534	-1130.519	-5286.656	13678.690	-2400.547
60.000	1536.050	3632.255	-883.760	-4450.380	13718.360	-2666.971
70.000	1650.852	3829.759	-600.329	-2344.472	13919.000	-2843.988
80.000	1714.129	3845.875	-301.410	-575.671	14090.920	-2926.976
90.000	1727.833	3726.644	-3.021	23.525	14136.820	-2921.154
100.000	1690.108	3717.043	294.845	498.060	14165.760	-2828.482
110.000	1598.671	3841.529	591.435	1799.442	14282.210	-2646.024
120.000	1456.907	3872.376	872.473	3216.859	14378.260	-2378.178
130.000	1273.284	3741.077	1118.143	3372.287	14329.000	-2041.760
140.000	1054.319	3634.080	1324.006	2757.436	14193.750	-1652.779
150.000	803.006	3677.928	1495.436	2797.454	14112.910	-1217.490
160.000	524.975	3743.789	1628.063	3540.189	14086.620	-742.866
170.000	204.368	3689.524	1705.965	3651.546	13348.490	-170.365
180.000	-118.669	3533.737	1731.120	3878.388	12628.680	394.485
190.000	-389.462	3460.918	1712.961	5178.290	13183.030	811.221
200.000	-650.965	3594.173	1637.488	5548.472	13814.660	1216.224
210.000	-918.805	3717.303	1504.489	4769.990	13839.520	1662.392
220.000	-1160.662	3622.955	1334.563	4817.126	13784.990	2060.046
230.000	-1370.130	3515.534	1130.519	5286.656	13678.690	2400.547
240.000	-1536.050	3632.255	883.760	4450.380	13718.360	2666.971
250.000	-1650.852	3829.759	600.329	2344.472	13919.000	2843.988
260.000	-1714.129	3845.875	301.410	575.671	14090.920	2926.976
270.000	-1727.833	3726.644	3.021	-23.525	14136.820	2921.154

280.000	-1690.108	3717.043	-294.845	-498.060	14165.760	2828.482
290.000	-1598.671	3841.529	-591.435	-1799.442	14282.210	2646.024
300.000	-1456.907	3872.376	-872.473	-3216.859	14378.260	2378.178
310.000	-1273.284	3741.077	-1118.143	-3372.287	14329.000	2041.760
320.000	-1054.319	3634.080	-1324.006	-2757.436	14193.750	1652.779
330.000	-803.006	3677.928	-1495.436	-2797.454	14112.910	1217.490
340.000	-524.975	3743.789	-1628.063	-3540.189	14086.620	742.866
350.000	-204.368	3689.524	-1705.965	-3651.546	13348.490	170.365
360.000	118.669	3533.737	-1731.120	-3878.388	12628.680	-394.485

Hub loads in fixed frame hub coordinates

Azimuth Angle	Fxh	Fyh	Fzh	Mxh	Myh	Mzh
0.000	118.669	3533.737	-1731.120	-3878.388	12628.680	-394.485
10.000	86.093	3460.918	-1754.567	-5240.487	13183.030	100.304
20.000	51.653	3594.173	-1761.379	-5629.832	13814.660	754.813
30.000	43.464	3717.303	-1762.328	-4962.129	13839.520	945.321
40.000	31.278	3622.955	-1768.393	-5014.305	13784.990	1518.302
50.000	14.675	3515.534	-1776.264	-5237.123	13678.690	2506.772
60.000	2.666	3632.255	-1772.138	-4534.854	13718.360	2520.657
70.000	0.500	3829.759	-1756.618	-3474.331	13919.000	1230.382
80.000	0.824	3845.875	-1740.426	-2982.472	14090.920	58.661
90.000	-3.022	3726.644	-1727.833	-2921.154	14136.820	-23.525
100.000	-3.119	3717.043	-1715.630	-2871.998	14165.760	0.668
110.000	8.989	3841.529	-1704.542	-3101.895	14282.210	-785.929
120.000	27.130	3872.376	-1697.955	-3667.992	14378.260	-1596.792
130.000	38.095	3741.077	-1694.121	-3731.744	14329.000	-1270.904
140.000	43.399	3634.080	-1691.951	-3174.704	14193.750	-506.344
150.000	52.295	3677.928	-1696.588	-3031.411	14112.910	-344.350
160.000	63.515	3743.789	-1709.430	-3580.765	14086.620	-512.750
170.000	94.974	3689.524	-1715.536	-3625.655	13348.490	-466.308

180.000	118.669	3533.737	-1731.120	-3878.388	12628.680	-394.485
190.000	86.093	3460.918	-1754.567	-5240.487	13183.030	100.304
200.000	51.653	3594.173	-1761.379	-5629.832	13814.660	754.813
210.000	43.464	3717.303	-1762.328	-4962.129	13839.520	945.321
220.000	31.278	3622.955	-1768.393	-5014.305	13784.990	1518.302
230.000	14.675	3515.534	-1776.264	-5237.123	13678.690	2506.772
240.000	2.666	3632.255	-1772.138	-4534.854	13718.360	2520.657
250.000	0.500	3829.759	-1756.618	-3474.331	13919.000	1230.382
260.000	0.824	3845.875	-1740.426	-2982.472	14090.920	58.661
270.000	-3.022	3726.644	-1727.833	-2921.154	14136.820	-23.525
280.000	-3.119	3717.043	-1715.630	-2871.998	14165.760	0.668
290.000	8.989	3841.529	-1704.542	-3101.895	14282.210	-785.929
300.000	27.130	3872.376	-1697.955	-3667.992	14378.260	-1596.793
310.000	38.096	3741.077	-1694.120	-3731.743	14329.000	-1270.904
320.000	43.399	3634.080	-1691.951	-3174.704	14193.750	-506.344
330.000	52.295	3677.928	-1696.588	-3031.411	14112.910	-344.351
340.000	63.516	3743.789	-1709.430	-3580.765	14086.620	-512.751
350.000	94.974	3689.524	-1715.536	-3625.655	13348.490	-466.309
360.000	118.669	3533.737	-1731.120	-3878.388	12628.680	-394.484

Harmonics of Rotor Shaft Loads

	Fxr	Fyr	Fzr	Mxr	Myr	Mzr
cos(0*PSI)	0.000	3688.695	0.000	0.000	13871.760	0.000
sin(0.*PSI)	0.000	0.000	0.000	0.000	0.000	0.000
cos(PSI)	80.548	0.000	-1737.332	-4941.545	0.000	-291.948
sin(PSI)	1726.760	0.000	-5.872	-706.891	0.000	-2909.703
cos(2.*PSI)	0.000	-98.942	0.000	0.000	-381.793	0.000
sin(2.*PSI)	0.000	-60.532	0.000	0.000	-260.192	0.000
cos(3.*PSI)	7.620	0.000	4.263	778.822	0.000	-18.037
sin(3.*PSI)	-2.633	0.000	-2.543	-766.651	0.001	16.298

cos(4.*PSI)	0.000	5.500	0.000	0.000	-239.641	0.000
sin(4.*PSI)	0.000	-5.569	0.000	0.000	49.886	0.000
cos(5.*PSI)	10.199	0.000	-0.545	-8.898	0.000	-27.590
sin(5.*PSI)	-0.878	0.000	0.016	-54.854	0.000	2.769

Harmonics of Hub loads in Fixed Coordinates

	F _{xh}	F _{yh}	F _{zh}	M _{xh}	M _{yh}	M _{zh}
cos(0*PSI)	37.338	3688.695	-1732.046	-3925.625	13871.760	207.472
sin(0*PSI)	0.000	0.000	0.000	0.000	0.000	0.000
cos(PSI)	0.000	0.000	0.000	0.000	0.000	0.000
sin(PSI)	0.000	0.000	0.000	0.000	0.000	0.000
cos(2.*PSI)	45.748	-98.942	-1.838	-618.361	-381.794	-125.112
sin(2.*PSI)	-8.734	-60.532	-40.672	-873.727	-260.192	1413.482
cos(3.*PSI)	0.000	0.000	0.000	0.000	-0.001	0.000
sin(3.*PSI)	0.000	0.000	0.000	0.000	0.001	0.000
cos(4.*PSI)	10.189	5.500	0.982	378.198	-239.642	-378.712
sin(4.*PSI)	0.649	-5.569	0.026	-405.975	49.886	-384.327
cos(5.*PSI)	0.000	0.000	0.000	0.000	-0.001	0.000
sin(5.*PSI)	0.000	0.000	0.000	0.000	0.000	0.000

THIS IS THE FILE OF TURBULENT WINDSPEED DATA AS READ
 BY MODULE 2 DURING A TURBULENT LOAD CALCULATION (Meters/sec).

15.0000	11.4375	12.1721	9.8636
30.0000	11.2795	11.4703	9.6749
45.0000	10.5139	10.3868	9.5616
60.0000	10.6547	10.4691	9.2097
75.0000	10.1082	10.4514	9.2604
90.0000	9.8202	10.5176	9.7193
105.0000	9.8885	9.7964	9.6447
120.0000	10.1578	8.9342	9.3867
135.0000	9.9126	8.5892	9.2205
150.0000	9.8776	8.2925	9.3452
165.0000	9.1952	9.3958	9.8515
180.0000	9.4681	8.5594	9.9078
195.0000	8.5003	9.1422	9.9595
210.0000	9.3399	8.3813	9.5617
225.0000	9.0926	7.1986	9.5399
240.0000	7.9973	7.8164	9.5954
255.0000	8.1461	9.0605	9.4897
270.0000	8.6887	9.2447	8.9503
285.0000	9.0807	9.1259	8.9510
300.0000	9.3613	10.0571	8.8075
315.0000	10.4193	11.3491	8.4452
330.0000	10.4663	12.0937	8.4692
345.0000	10.2636	12.1379	8.8571
360.0000	10.4984	12.1172	9.0080
15.0000	11.3167	11.9926	9.1126
30.0000	11.7563	11.1521	8.9411
45.0000	11.8934	10.6483	8.7469
60.0000	10.8782	10.9209	8.8334
75.0000	9.7996	10.4784	8.8542
90.0000	10.0067	9.8132	9.0214
105.0000	9.9229	9.7753	8.9829
120.0000	9.7480	9.1833	9.0527
135.0000	10.2449	9.4676	8.9647
150.0000	9.2852	9.5491	8.4993
165.0000	9.0427	8.0110	9.1352
180.0000	8.8864	8.0518	9.1892
195.0000	9.0984	7.4229	9.4032
210.0000	8.2008	7.6567	9.2803
225.0000	7.9738	7.2738	8.7864
240.0000	8.0416	6.9329	8.5786
255.0000	8.3663	8.6349	8.7668
270.0000	8.5202	8.2866	9.2442
285.0000	9.2680	8.9515	9.0515
300.0000	9.5274	9.8538	9.6445
315.0000	9.8669	10.5504	9.5061
330.0000	9.8349	11.3884	9.3152
345.0000	9.7656	11.8374	9.7763
360.0000	10.2332	11.0562	9.8647
15.0000	10.6885	10.3335	9.8093
30.0000	11.1781	10.5074	9.5484
45.0000	10.9226	10.4468	9.7127
60.0000	10.4891	10.6511	9.6241
75.0000	9.3743	10.1225	9.4663
90.0000	9.0496	9.5442	9.2864
105.0000	9.2474	9.1924	9.2707
120.0000	9.0530	9.4338	9.6475
135.0000	9.1471	8.8096	9.5353

150.0000	8.5220	8.6550	9.5515
165.0000	7.8419	7.8843	9.7655
180.0000	8.5828	6.9766	9.3817
195.0000	8.3854	7.8903	9.5150
210.0000	8.1869	7.0015	9.2821
225.0000	7.8609	6.2604	9.1465
240.0000	8.9282	7.9758	9.2703
255.0000	8.8671	8.3891	9.3725
270.0000	8.9678	8.0585	9.2055
285.0000	10.1328	9.4557	9.3929
300.0000	9.9143	9.9891	9.3575
315.0000	9.7722	9.9394	9.3916
330.0000	10.4391	10.6427	9.1462
345.0000	10.0804	10.3252	8.8188
360.0000	10.7110	10.1753	8.7808
15.0000	11.0008	10.9421	8.5497
30.0000	10.2920	10.8820	8.5737
45.0000	10.0779	10.7198	8.4824
60.0000	8.9733	10.2688	8.5000
75.0000	8.4847	10.0147	8.5795
90.0000	8.2959	8.8401	8.9199
105.0000	8.0646	10.2595	8.8030
120.0000	8.4317	9.1840	8.6205
135.0000	8.7602	9.2067	8.7841
150.0000	9.1933	8.6731	9.1407
165.0000	8.4096	8.7849	9.3633
180.0000	7.7077	8.3820	9.4672
195.0000	7.8242	7.6489	9.7056
210.0000	8.4655	7.3910	9.7025
225.0000	8.2551	7.3215	9.4254
240.0000	9.1701	8.0362	9.3822
255.0000	9.0610	9.0985	9.5409
270.0000	9.2662	9.6007	9.1374
285.0000	10.0148	10.3568	9.1824
300.0000	10.1570	9.6240	8.7583
315.0000	9.9560	10.5797	8.4523
330.0000	10.0334	10.3203	8.7834
345.0000	9.8394	9.7610	8.7382
360.0000	9.5330	10.2365	8.6937
15.0000	10.3205	9.6960	9.0034
30.0000	10.0801	10.2417	9.0482
45.0000	9.4649	9.7643	9.0773
60.0000	9.3237	10.1505	9.5303

THIS IS THE TURBULENCE BLADE LOD FILE PRODUCED
 BY MODULE 1 UPON EXECUTION OF TURBULENT WIND INPUTS:

15.0000	-6870.64	-1754.82
30.0000	-9219.37	-1513.41
45.0000	-6966.43	-2087.61
60.0000	-6965.40	-2078.88
75.0000	-8878.00	-1603.94
90.0000	-5958.20	-1899.76
105.0000	-5835.08	-1796.18
120.0000	-6500.60	-1539.25
135.0000	-3568.18	-1804.07
150.0000	-3562.13	-1538.94
165.0000	-3891.07	-1219.88
180.0000	-1950.84	-1462.31
195.0000	-224.362	-1411.70
210.0000	-3380.40	-822.724
225.0000	-910.911	-1392.49
240.0000	370.476	-1678.88
255.0000	-3879.93	-994.851
270.0000	-2914.81	-1338.81
285.0000	-2345.39	-1721.53
300.0000	-5984.54	-1331.77
315.0000	-6167.66	-1539.08
330.0000	-6710.77	-1834.00
345.0000	-9804.19	-1786.35
0.000000	-9460.19	-2218.77
15.0000	-9683.75	-2352.34
30.0000	-10878.6	-2078.04
45.0000	-8127.20	-2187.45
60.0000	-7040.91	-1853.10
75.0000	-7240.04	-1404.34
90.0000	-4382.79	-1657.15
105.0000	-4599.84	-1539.14
120.0000	-5929.41	-1372.80
135.0000	-3912.39	-1784.05
150.0000	-5587.50	-1613.26
165.0000	-5637.56	-1700.58
180.0000	-1280.76	-2121.36
195.0000	-1169.14	-1313.54
210.0000	-562.606	-629.670
225.0000	3470.42	-987.674
240.0000	1992.93	-829.895
255.0000	-445.353	-728.751
270.0000	-1215.53	-1255.45
285.0000	-3013.93	-1601.81
300.0000	-6249.89	-1548.91
315.0000	-6474.73	-1847.32
330.0000	-7150.70	-1936.11
345.0000	-8995.94	-1761.92
0.000000	-8066.10	-2031.38
15.0000	-7321.76	-2101.23
30.0000	-7809.90	-1735.84
45.0000	-6444.73	-1644.52
60.0000	-5397.44	-1599.95
75.0000	-6274.38	-1436.30
90.0000	-5018.62	-1725.02
105.0000	-4844.32	-1799.77
120.0000	-5818.93	-1574.23
135.0000	-4550.95	-1719.95

150.000	-3557.26	-1735.71
165.000	-3540.32	-1526.01
180.000	-218.966	-1665.92
195.000	2086.84	-1190.38
210.000	-166.088	-308.557
225.000	4137.32	-956.682
240.000	3164.02	-992.530
255.000	-3591.60	-430.915
270.000	-931.020	-1641.58
285.000	-2849.34	-1915.06
300.000	-9527.41	-1215.55
315.000	-5190.82	-2179.24
330.000	-5425.48	-2136.38
345.000	-9951.77	-1247.07
0.000000	-4289.08	-1994.31
15.0000	-4724.21	-1726.38
30.0000	-9099.45	-968.104
45.0000	-4231.59	-1943.99
60.0000	-5840.88	-1919.43
75.0000	-9037.01	-1499.94
90.0000	-4323.04	-2258.23
105.000	-4454.21	-1909.52
120.000	-7586.31	-1144.96
135.000	-1855.49	-1896.87
150.000	-3237.65	-1572.22
165.000	-5433.71	-1120.20
180.000	61.2371	-1909.10
195.000	486.885	-1520.81
210.000	-2290.40	-606.445
225.000	2505.84	-1206.53
240.000	1283.89	-1079.95
255.000	-3723.65	-588.338
270.000	-1946.85	-1525.89
285.000	-4781.84	-1768.85
300.000	-9408.44	-1608.74
315.000	-5918.70	-2400.94
330.000	-7728.17	-2032.73
345.000	-8395.31	-1592.44
0.000000	-3438.64	-1938.45
15.0000	-5061.17	-1297.51
30.0000	-5187.46	-1055.51
45.0000	-2739.37	-1570.89
60.0000	-5200.60	-1416.06

Appendix C

Module 1 Listing

PROGRAM FLAP1

```
C          *****
C          *
C          * 0000000 0          00  000000  *
C          * 0      0          0 0  0  0  *
C          * 0000  0          000000 000000  *
C          * 0      0          0  0  0  *
C          * 0      0000000 0          0  0  *
C          *
C          * Forces & Loads  Analysis  Program *
C          *
C          *          Module 1
C          *
C          *          Version 2.2
C          *
C          *****
```

```
C *****
C * CHANGES MADE IN FLAP SINCE THE MARCH 1988 VERSION *
C * 2.01 RELEASE. FOR MORE DETAILS SEE THE USER'S MANUAL. *
C *****
```

This version of FLAP is for analysis of three bladed or two bladed rigid hub rotors only. The teetering option has been removed from this version and reformulated in the new teetering rotor analysis: STRAP (SERI TEETERING ROTOR ANALYSIS PROGRAM). User's wishing to run analyses for 2-bladed teetering hub rotors should consult that code and user's manual.

This version of FLAP has been modified from version 2.01 in several ways. First, in Module1 modifications have been made in order to calculate blade flap-wise frequencies and modeshapes directly in the code and to output these to a user designated file. This file is designated during execution of Module1. The user can examine results in this file in order to gain knowledge about the blade's frequencies

C and modeshapes. The user no longer needs to
C calculate these frequencies by hand. In addi-
C tion these calculated modeshapes get passed
C to module2 (via the RESULTS.DAT file) in order
C to calculate generalized forces. They also get
C used in calculation of the blade's mass, stiffness
C and other matrices.

C The second major change, contained in the second
C module is the ability to read in turbulent wind-
C speed fluctuations (in subroutine TRBCLC) and
C calculate loads and response on a single blade
C due to turbulence (note: the shaft loads are not
C calculated during the turbulence execution because
C only one blade is being analyzed).

C Another change is the ability to calculate the rotor
C shaft loads during a trim (steady state) solution.
C The code does this either for a three-bladed or a
C two bladed rigid hub rotor.

```
C *****  
C *                               *  
C *           DISCLAIMER          *  
C *                               *  
C * Neither the United States Department of Energy, the *  
C * National Renewable Energy Laboratory,                *  
C * the Midwest Research Institute nor anyone           *  
C * else who has been involved in the                   *  
C * creation, production or delivery of this program shall *  
C * be liable for any direct, indirect, consequential, or *  
C * incidental damages arising out of the use, the results *  
C * of use, or inability to use this program even if the *  
C * United States Department of Energy has been advised of *  
C * the possibility of such damages or claim. Some states *  
C * do not allow the exclusion or limitation of liability *  
C * for consequential or incidental damages, so the above *  
C * limitation may not apply to you.                    *  
C *                                                     *  
C *****
```

```
C *****  
C *                               *  
C *           The FLAP Code       *  
C *                               *  
C * FLAP calculates the forces and moments on a wind tur- *  
C * bine blade due to aerodynamic, inertial and gravita- *  
C * tional forces. The aerodynamic effects include wind *  
C * shear, tower shadow and the induced velocity due to the *  
C * change in momentum of the air stream as it passes over *  
C * the blade. In addition, this version includes the *  
C * ability to input and calculate response                *  
C * and loads due to turbulence.                            *  
C *****  
C *****
```

```

C      *
C      *           Module 1           *
C      *
C      * This program is the first of two modules that consti- *
C      * tute the FLAP code. This first module interpolates the *
C      * input data into a form usable by the second module *
C      * which does the actual modeling. This module also com- *
C      * putes the coefficient matrix used for solving the blade *
C      * flaps equation of motion. It also calculated the blade's *
C      * frequency and modeshapes. *
C      * *****
C
C      *****
C      *
C      * Questions about the original formulation, theory, meth- *
C      * od of solution and programming should be addressed to: *
C      *
C      *           Alan D. Wright
C      *           National Renewable Energy Laboratory *
C      *           1617 Cole Blvd. *
C      *           Golden, CO 80401 *
C      *           303-231-7651 *
C      * *****
C
C      *****
C      *
C      * I/O Conventions: *
C      *
C      * Unit 1 - Input data file
C      * Unit 2 - Output data file
C      * Unit 5 - Keyboard *
C      * Unit * - Monitor or keyboard *
C      *
C      * *****
C
C      *****
C      *
C      * External references in this routine: *
C      *
C      * COEFFS - Subroutine that computes the K and M coef- *
C      * ficients used in solving the equations of *
C      * blade motion. *
C      *
C      * INPUT - Subroutine that reads in a set of blade and *
C      * machine data and converts them to a form *
C      * needed by the COEFFS subroutine. *
C      *
C      * PRNCOE - Subroutine that creates the input data file *
C      * for the second module. *
C      *
C      * *****
C
C      *****
C      *
C      * Local and dummy variables used in this routine: *
C      *
C      * ANS - Used to store input responses from the key- *
C      * board. *
C      *
C      * FILOUT - String that contains the name of the out- *
C      * put file. It is defined in INPUT. *

```

```

C      *      NP      - Number of blade property values used in *
C      *      performing composite Simpson's integration *
C      *      for the K and M coefficient arrays. This *
C      *      number is approximately 10 times the NPTS *
C      *      value. *
C      *      NPTS    - Number of points along the blade used to *
C      *      perform Simpson's integration for calcula *
C      *      ting the moments and forces at the blade *
C      *      root *
C      *      NSIMP   - Order of the composite Simpson's integra *
C      *      tion used in the run. Parameter is set to *
C      *      10 in order to make 21 blade property sta *
C      *      tions. *
C      *      *
C      *****

```

```

INTEGER      NP
INTEGER      NPTS
INTEGER      NSIMP

```

```

CHARACTER*1  ANS
CHARACTER*50 FILOUT

```

```

PARAMETER   ( NSIMP = 10 )

```

```

100 FORMAT (
& // ' Program For Analysis Of Horizontal Axis Wind Turbine'
& / ' Response To Dynamic Loads'
& // ' MODULE 1' )
110 FORMAT ( / )
120 FORMAT ( A )
130 FORMAT ( / ' FLAP terminated normally.' / )

```

```

C      Calculate the number of blade property stations and interpola-
C      tion points.

```

```

NPTS = 2*NSIMP + 1
NP    = 20*NSIMP + 1

```

```

C      Print title.

```

```

PRINT 100.

```

```

C      Get input responses, generate coefficients, and write to output
C      file.

```

```

10 PRINT 110

```

```

CALL INPUT ( NP , NPTS , FILOUT )
CALL MODES ( NP )
CALL COEFFS ( NP , NPTS )
CALL PRNCOE ( FILOUT , NPTS )

```

```

C      Check to see if user wants to process another data file.

```

```

20 PRINT *, ' '
PRINT *, 'Do you want to process another data file? (Y,N) > '
READ 120, ANS

IF ( ( ANS .EQ. 'Y' ) .OR. ( ANS .EQ. 'y' ) ) GO TO 10

IF ( ( ANS .NE. 'N' ) .AND. ( ANS .NE. 'n' )
& .AND. ( ANS .NE. ' ' ) ) THEN
PRINT *, 'Invalid response. Please try again...'
GO TO 20
END IF

```

C Processing complete.

PRINT 130

999 STOP

END

BLOCK DATA

```

C *****
C *
C * This module is used to initialize the COMMON blocks. *
C *
C *****

C *****
C *
C * Named COMMON blocks used in this routine: *
C *
C * AERO - Aerodynamic blade properties derived from *
C * input aerodynamic data. *
C * BLADE - Blade position dependent values that are *
C * computed by linear interpolation of the in- *
C * put property data. *
C * LITERL - Data file titles used for printed output. *
C * LODVAL - Holds components used in calculating blade *
C * loads and deflections. *
C * MATRIX1 - Holds some of the coefficient matrices of *
C * the governing equation of motion. *
C * MATRIX2 - Holds some of the coefficient matrices of *
C * the governing equation of motion. *
C * PANELS - Used to communicate with the interpolation *
C * subroutine INTERP. *
C * TENSIN - Holds tension components of the stiffness *
C * functions. *
C * TURBN - Turbine related variables. *
C * WIND - Wind related variables. *
C *
C *****

C *****
C *
C * External references in this routine: *
C *
C * none *

```

```

C      *
C      *****
C
C      *****
C      *
C      * COMMON variables used in Module 1 of FLAP:
C      *
C      * ALENTH - Distance from the tower axis to the rotor
C      *          hub. (feet)
C      * ALPHA0 - The angle from the zero-lift line to the
C      *          section-chord line. (Generally negative)
C      * BETA0 - Blade coning angle. The value is input in
C      *          degrees and converted to radians. (radians)
C      * BLSHNK - Length of blade shank measured from the
C      *          blade root to the start of the airfoil sec-
C      *          tion. If airfoil begins at the root, then
C      *          BLSHNK=0. (feet)
C      * BLTIP - Blade length measured from the blade root
C      *          to the blade tip. Note - rotor radius is
C      *          HUBRAD + BLTIP. (feet)
C      * CDZERO - Drag coefficient values at equidistant
C      *          points along the blade. Derived from
C      *          ACDZER values. (dimensionless)
C      * CHI - Rotor tilt angle. Input in degrees and
C      *          converted to radians. (radians)
C      * CHORD - Blade chord at equidistant points along the
C      *          blade. Derived from ACHORD. (feet)
C      * CIFMOM - Integral of DIFMOM.
C      * CKBEND - Bending stiffness matrix.
C      * CKQLOD - Inertial moment stiffening matrix.
C      * CKTCRL - Coriolis stiffening matrix.
C      * CKTGRV - Gravity stiffening matrix.
C      * CKTOMG - Centrifugal stiffening matrix.
C      * CLALFA - Slope of the lift curve at equidistant
C      *          points along the blade. Derived from ACLALF
C      *          values. (radians^-1)
C      * CLMAX - The maximum or stall value of the lift co-
C      *          efficient. Derived from ACLMAX values.
C      * CMBLNC - Coefficient associated with the blade mass
C      *          imbalance (OFFSET).
C      * CMGRAV - Mass coefficients associated with gravita-
C      *          tional loads.
C      * CMMASS - Blade mass matrix. It is also used in the
C      *          inertia force stiffening term.
C      * CMRIGD - Mass coefficients associated with rigid bo-
C      *          dy motion.
C      * CSUBMA - Pitching moment coefficient.
C      * DELTIM - Integral of DDELT I.
C      * DRGFRM - Drag coefficient form constant.
C      * ECNTFN - Complicated term.
C      * EIAREA - Moment of inertia values at equidistant
C      *          points along the blade. Derived from
C      *          AEIARE data values. (Lb-Ft**2)
C      * ESUBAC - Distance from the blade elastic axis to the
C      *          aerodynamic center. Positive if elastic
C      *          axis is forward (toward leading edge) of
C      *          aerodynamic center. Derived from AESBAC
C      *          values. (feet)
C      * HUBHT - Hub reference height above the ground.
C      *          (feet)

```

```

C * HUBRAD - Radius of rotor hub. (feet) *
C * IEMASS - Edgewise mass moment of inertia at equidis- *
C * tant points along the blade section. Der- *
C * ived from AIEMAS values. (Lb-sec^2) *
C * IFMASS - Flapwise mass moment of inertia at equidis- *
C * tant points along the blade section. Der- *
C * ived from AIFMAS values. (Lb-sec^2) *
C * KSHADW - Number of tower shadow peaks within the *
C * tower shadow zone. *
C * MASS - Blade mass per unit length at equidistant *
C * points along the blade. Input in Lbf/ft, *
C * via the input variable WEIGHT, and convert- *
C * ed to slugs/ft. (slugs/ft) *
C * NBLADS - Number of turbine blades. *
C * NSHAPS - Number of blade shape functions, 4 maximum. *
C * *
C * OFFMAS - Integral of DOFFMS. *
C * OFFSET - Distance from the elastic axis to the mass *
C * axes of blade section. Positive towards *
C * the leading edge. Derived from AOFFST val- *
C * ues. Called E-sub-eta in the formulation. *
C * (feet) *
C * OMEGA - Rotor speed. Input in RPM and converted to *
C * radians/second. (rad/sec) *
C * PHI0 - Rotor mean yaw angle. (radians) *
C * PHIAMP - Amplitude of periodic yaw motion about mean *
C * yaw angle. Input as degrees and converted *
C * to radians. (radians) *
C * PHIOMG - Maximum yaw rate. Used internally to com- *
C * pute the yaw period. It can be used to in- *
C * put a turbine steady yaw rate. Input as *
C * degrees/sec and converted to radians/sec- *
C * ond. (radians/sec) *
C * PSIZER - Half angle width of the tower shadow re- *
C * gion. (degrees) *
C * SHERXP - Wind shear power exponent. *
C * STEP - Distance between the equidistant data *
C * points along the blade. (feet) *
C * TCORLS - Blade tension coefficient due to coriolis *
C * effects. *
C * TGRAV - Blade tension coefficient due to gravity *
C * effects. *
C * THETA0 - Orientation of the zero lift line with re- *
C * spect to the blade principal bending axis. *
C * THETAP - The blade pitch angle. That is, the angle *
C * from the bending axis, XP, to the cone of *
C * rotation, X-axis, for the reference sta- *
C * tion. THETAP establishes the orientation *
C * of the flapping displacements. Positive *
C * angles are toward feather. Generally, the *
C * reference station section-chord line is *
C * taken as the bending (flapping) axis. *
C * (radians) *
C * THETAT - The built-in blade twist angle from the *
C * section-chord line at the reference station *
C * to the section-chord line at the tip of the *
C * rotor. Positive towards feather. *
C * *
C * TITLE1 - First line of the data file title. *
C * TITLE2 - Second line of the data file title. *
C * TITLE3 - Third line of the data file title. *

```

```

C      *      TOMGA - Blade tension coefficient associated with *
C      *      centrifugal force effects. *
C      *      TSUBO - Tower shadow wind speed offset component. *
C      *      TSUBP - Tower shadow sinusoidal component. *
C      *      VHUB - Air speed at the height of the hub. *
C      *      (ft/sec) *
C      *      XLEFT - Radial positions of the blade property data *
C      *      points. These are monotonically increasing *
C      *      values from 0.0 at the root to R at the *
C      *      tip. (feet) *
C      *      *
C      *****

```

```

INCLUDE      'C:\INCLUDE\AERO.INC'

```

```

INCLUDE      'C:\INCLUDE\BLADE.INC'

```

```

INCLUDE      'C:\INCLUDE\LITERL.INC'

```

```

INCLUDE      'C:\INCLUDE\LODVAL.INC'

```

```

INCLUDE      'C:\INCLUDE\MATRX1.INC'

```

```

INCLUDE      'C:\INCLUDE\MATRX2.INC'

```

```

INCLUDE      'C:\INCLUDE\PANELS.INC'

```

```

INCLUDE      'C:\INCLUDE\TENSIN.INC'

```

```

INCLUDE      'C:\INCLUDE\TURBN.INC'

```

```

INCLUDE      'C:\INCLUDE\WIND.INC'

```

```

END
SUBROUTINE CAPS ( STRING )

```

```

C      *****
C      *
C      *      Subroutine CAPS is used to convert alphabetic charac- *
C      *      ters into upper case. It assumes that all the lower *
C      *      case letters are in one contiguous block and all the *
C      *      upper case letters are in another contiguous block. *
C      *      This routine will need to be changed to work with a *
C      *      noncontiguous character set like IBM's EBCDIC. It is *
C      *      not needed for an upper case only character set like *
C      *      CDC's Display Code. *
C      *
C      *****

```

```

C      *****
C      *
C      *      Named COMMON blocks used in this routine: *
C      *
C      *      none *
C      *
C      *****

```

```

C *****
C *
C * External references in this routine: *
C * *
C * none *
C * *
C *****

```

```

C *****
C *
C * Local and dummy variables used in this routine: *
C * *
C * DIFF - Numerical difference between 'A' and 'a'. *
C * I - Generic index. *
C * LENGTH - The declared length of the given string. *
C * STRING - The string needing to be converted to upper *
C * case. *
C * *
C *****

```

```

INTEGER    DIFF
INTEGER    I
INTEGER    LENGTH

CHARACTER*(*) STRING

```

```

C Compute the numerical difference between 'A' and 'a'.

```

```

DIFF = ICHAR( 'a' ) - ICHAR( 'A' )

```

```

C Get the length of the string.

```

```

LENGTH = LEN( STRING )

```

```

C Look for lower case letters. Convert them to upper case.

```

```

DO 100 I=1,LENGTH

```

```

IF ( ( STRING(I:I) .GE. 'a' ) .AND.
& ( STRING(I:I) .LE. 'z' ) ) THEN

```

```

STRING(I:I) = CHAR( ICHAR( STRING(I:I) ) - DIFF )

```

```

END IF

```

```

100 CONTINUE

```

```

RETURN
END
SUBROUTINE COEFFS ( NP , NPTS )

```

```

C *****
C *
C * This subroutine computes the coefficient matrices used *

```



```

C      * in the solution of the blade equations of motion. *
C      * Since these coefficients are independent of the posi- *
C      * tion or state of the blade, and are only dependent upon *
C      * the blade properties, they are calculated independently *
C      * of the solution to the equations of motion and are made *
C      * available to the rest of the program through the COMMON *
C      * blocks MATRX1 and MATRX2. *
C      * *
C      *****

```

```

C      *****
C      * *
C      * Named COMMON blocks used in this routine: *
C      * *
C      * AERO - Aerodynamic blade properties derived from *
C      * input aerodynamic data. *
C      * BLADE - Blade position dependent values that are *
C      * computed by linear interpolation of the input *
C      * property data. *
C      * LODVAL - Holds components used in calculating blade *
C      * loads and deflections. *
C      * MATRX1 - Holds some of the coefficient matrices of *
C      * the governing equation of motion. *
C      * MATRX2 - Holds some of the coefficient matrices of *
C      * the governing equation of motion. *
C      * TENSIN - Holds tension components of the stiffness *
C      * functions. *
C      * *
C      *****

```

```

C      *****
C      * *
C      * External references in this routine: *
C      * *
C      * SIMPSN - Function that performs the composite Simp- *
C      * son's integration on the input data arrays. *
C      * TRPZOD - Function that performs composite trapezoi- *
C      * dal integration. *
C      * *
C      *****

```

```

C      *****
C      * *
C      * Local and dummy variables used in this routine: *
C      * *
C      * BLTBLT - Square of BLTIP. (feet**2) *
C      * DDELTI - IEMASS - IFMASS. *
C      * DIFMOM - Complicated term. *
C      * DKBEND - Used to compute the integrals associated *
C      * with the coefficient matrices. *
C      * DKMASS - Used to compute the integrals associated *
C      * with the coefficient matrices. *
C      * DKQLD - Used to compute the integrals associated *
C      * with the coefficient matrices. *
C      * DKTCRL - Used to compute the integrals associated *
C      * with the coefficient matrices. *
C      * DKTGRA - Used to compute the integrals associated *
C      * with the coefficient matrices. *
C      * DKTOMG - Used to compute the integrals associated *
C      * with the coefficient matrices. *

```

```

C      *      DMBALN - Used to compute the integrals associated *
C      *      with the coefficient matrices. *
C      *      DMGRAV - Used to compute the integrals associated *
C      *      with the coefficient matrices. *
C      *      DMRIGD - Used to compute the integrals associated *
C      *      with the coefficient matrices. *
C      *      DOFFMS - OFFSET*MASS. *
C      *      DTCOR1 - Used to compute the integrals associated *
C      *      with the tension components. *
C      *      DTCOR2 - Used to compute the integrals associated *
C      *      with the tension components. *
C      *      DTCOR3 - Used to compute the integrals associated *
C      *      with the tension components. *
C      *      DTCOR4 - Used to compute the integrals associated *
C      *      with the tension components. *
C      *      DTOMGA - Used to compute the integrals associated *
C      *      with the tension components. *
C      *      I      - Generic index. *
C      *      IPT      - Array index used for trapezoidal integra- *
C      *      tion. *
C      *      K      - Generic index. *
C      *      L      - Generic index. *
C      *      N      - Generic index. *
C      *      NP      - Number of blade property values used in *
C      *      performing composite Simpson's integration *
C      *      for the M and K coefficient arrays. This *
C      *      number is approximately 10 times the NPTS *
C      *      value. (passed from FLAP1) *
C      *      NPTS    - Number of points along the blade used to *
C      *      perform Simpson's integration for calculat- *
C      *      ing the moments and forces at the blade *
C      *      root. (passed from FLAP1) *
C      *      SHP      - Array containing shape functions evaluated *
C      *      at regular intervals. *
C      *      SHPDD    - First derivative of SHP with respect to *
C      *      location along the blade. *
C      *      SHPDDOT  - Second derivative of SHP with respect to *
C      *      location along the blade. *
C      *      X      - Dummy variable used to indicate location *
C      *      along the blade for use by the internal *
C      *      shape functions. *
C      *
C      *****

```

```

REAL      DDELT1 (201)
REAL      DIFMOM (201)
REAL      DKBEND (201)
REAL      DKMASS (201)
REAL      DKQLD  (201)
REAL      DKTCLR (201)
REAL      DKTGRA (201)
REAL      DKTOMG (201)
REAL      DMBALN (201)
REAL      DMGRAV (201)
REAL      DMRIGD (201)
REAL      DOFFMS (201)
REAL      DTCOR1 (201)
REAL      DTCOR2 (201)
REAL      DTCOR3 (201)
REAL      DTCOR4 (201)

```

```

REAL      DTOMGA (201)
REAL      SIMPSN
REAL      STEP
REAL      TRPZOD

```

```

INTEGER   I
INTEGER   IPT
INTEGER   K
INTEGER   L
INTEGER   N
INTEGER   NP
INTEGER   NPTS

```

```

INCLUDE   'C:\INCLUDE\AERO.INC'

```

```

INCLUDE   'C:\INCLUDE\BLADE.INC'

```

```

INCLUDE   'C:\INCLUDE\LODVAL.INC'

```

```

INCLUDE   'C:\INCLUDE\MATRX1.INC'

```

```

INCLUDE   'C:\INCLUDE\MATRX2.INC'

```

```

INCLUDE   'C:\INCLUDE\TENSIN.INC'

```

```

INCLUDE   'C:\INCLUDE\MODAL.INC'

```

```

1000 FORMAT ( / ' Generating coefficient matrices and property'
&           , ' arrays...' )
8000,FORMAT ( '&done.' )

```

```

C      *****
C      *
C      * Fill the intermediate function arrays which are used to *
C      * compute the tension component integrals.                *
C      *
C      *****

```

```

STEP = BLTIP/( NP - 1.0)

```

```

DO 200 I=1,NP

```

```

    DTOMGA(I) = MASS(I)*( HUBRAD + STEP*( I - 1 ) )
    DTCOR1(I) = MASS(I)*SHP(1,I)
    DTCOR2(I) = MASS(I)*SHP(2,I)
    DTCOR3(I) = MASS(I)*SHP(3,I)
    DTCOR4(I) = MASS(I)*SHP(4,I)

```

```

200 CONTINUE

```

```

C      *****
C      *
C      * Compute the tension component integrals. Each tension *
C      * component is calculated by integrating from a specific *
C      * position on the blade out to the blade tip.            *
C      *
C      *****

```

```

C *****
DO 300 I=1,NP

TOMGA(1) = TRPZOD( DTOMGA , I , NP , BLTIP )
TGRAV(1) = TRPZOD( MASS , I , NP , BLTIP )

TCORLS(1,I) = TRPZOD( DTCOR1 , I , NP , BLTIP )
TCORLS(2,I) = TRPZOD( DTCOR2 , I , NP , BLTIP )
TCORLS(3,I) = TRPZOD( DTCOR3 , I , NP , BLTIP )
TCORLS(4,I) = TRPZOD( DTCOR4 , I , NP , BLTIP )

300 CONTINUE

```

```

C *****
C *
C * Compute the coefficient matrices. Please note that *
C * only the upper triangle elements are computed. *
C *
C *****

```

```

DO 470 K=1,4
DO 440 L=K,4

```

```

C Fill the intermediate function arrays which are used
C to compute the stiffness and loading coefficient ma-
C trices.

```

```

DO 400 I=1,NP

DKBEND(I) = EIAREA(I)*SHPDD (K,I)*SHPDD (L,I)
DKMASS(I) = MASS (I)*SHP (K,I)*SHP (L,I)
DKQLD (I) = IFMASS(I)*SHPDOT(K,I)*SHPDOT(L,I)
DKTOMG(I) = TOMGA (I)*SHPDOT(K,I)*SHPDOT(L,I)

```

```

400 CONTINUE

```

```

C Compute the K,Lth element of the coefficient matrices.

```

```

CKBEND(K,L) = SIMPSN( 0.0 , BLTIP , NP , DKBEND )
CKTOMG(K,L) = SIMPSN( 0.0 , BLTIP , NP , DKTOMG )
CKQLD(K,L) = IFMASS(NP)*SHPDOT(K,NP)*SHP(L,NP)
& - SIMPSN( 0.0 , BLTIP , NP , DKQLD )
CMMASS(K,L) = SIMPSN( 0.0 , BLTIP , NP , DKMASS )

```

```

DO 410 I=1,NP
410 DKTGRA(I) = TGRAV(I)*SHPDOT(K,I)*SHPDOT(L,I)

```

```

CKTGRV(K,L) = SIMPSN( 0.0 , BLTIP , NP , DKTGRA )

```

```

C Index into coefficient matrix for coriolis stiffening.

```

```

DO 430 N=1,4

```

```

DO 420 I=1,NP
420   DKTCTRL(I) = TCORLS(N,I)*SHPDOT(K,I)*SHPDOT(L,I)

      CKTCTRL(N,K,L) = SIMPSN( 0.0 , BLTIP , NP , DKTCTRL )

430   CONTINUE

440.  CONTINUE

C      Compute elements of coefficient matrices which use only a
C      single index. Fill intermediate function arrays first, then
C      compute the elements of the matrices.

DO 450 I=1,NP

      DMRIGD(I) = MASS(I)*( HUBRAD + STEP*( I-1 ) )*SHP(K,I)
      DMBALN(I) = MASS(I)*SHP(K,I)*OFFSET(I)
      DMGRAV(I) = MASS(I)*SHP(K,I)

450   CONTINUE

      CMRIGD(K) = SIMPSN( 0.0 , BLTIP , NP , DMRIGD )
      CMBLNC(K) = SIMPSN( 0.0 , BLTIP , NP , DMBALN )
      CMGRAV(K) = SIMPSN( 0.0 , BLTIP , NP , DMGRAV )

DO 460 I=1,NP

      DMRIGD(I) = MASS(I)*( HUBRAD + STEP*( I-1 ) )*SHP(K,I)
      DMBALN(I) = MASS(I)*SHP(K,I)*OFFSET(I)
      DMGRAV(I) = MASS(I)*SHP(K,I)

460   CONTINUE

470 CONTINUE

C      *****
C      *
C      * Once the diagonal and upper triangular elements are *
C      * computed, reflect the upper triangle onto the lower *
C      * one.
C      *
C      *
C      *****

DO 520 K=1,3

DO 510 L=K+1,4

      CKBEND(L,K) = CKBEND(K,L)
      CKQLOD(L,K) = CKQLOD(K,L)
      CKTGRV(L,K) = CKTGRV(K,L)
      CKTOMG(L,K) = CKTOMG(K,L)
      CMMASS(L,K) = CMMASS(K,L)

```

```
DO 500 N=1,4
500   CKTCRL(N,L,K) = CKTCRL(N,K,L)
```

```
510   CONTINUE
```

```
520 CONTINUE
```

```
C *****
C *
C * The following arrays are used to compute the loads and *
C * moments for completion of MODULE 2. *
C *
C *****
```

```
DO 600 I=1,NP
```

```
DDELT(I) = IEMASS(I) - IFMASS(I)
DOFFMS(I) = OFFSET(I)*MASS(I)
```

```
600 CONTINUE
```

```
DO 610 I=1,NPTS
```

```
IPT = 10*( I - 1 ) + 1
```

```
DELTIM(I) = TRPZOD( DDELT , IPT , NP , BLTIP )
OFFMAS(I) = TRPZOD( DOFFMS , IPT , NP , BLTIP )
```

```
610 CONTINUE
```

```
DO 640 N=1,4
```

```
DO 620 I=1,NP
```

```
620   DIFMOM(I) = IFMASS(I)*SHPDOT(N,I)
```

```
DO 630 I=1,NPTS
```

```
IPT = 10*( I - 1 ) + 1
```

```
CIFMOM(N,I) = TRPZOD( DIFMOM , IPT , NP , BLTIP )
```

```
630 CONTINUE
```

```
640 CONTINUE
```

```
C *****
C *
C * These tension and property arrays will be used in *
C * MODULE 2 to compute the loads and moments. *
C *
C *****
```

```
DO 700 I=1,NPTS
```

```
IPT = 10*( I - 1 ) + 1
```

```
CHORD (I) = CHORD(IPT)
```

```

      ECNTFN(I) = OFFSET(IPT)*MASS(IPT)*( HUBRAD
&      + BLTIP*( I-1 )/( NPTS-1 ) )
      TGRAV (I) = TGRAV(IPT)
      THETAO(I) = THETAO(IPT)
      TOMGA (I) = TOMGA(IPT)

      TCORLS(1,I) = TCORLS(1,IPT)
      TCORLS(2,I) = TCORLS(2,IPT)
      TCORLS(3,I) = TCORLS(3,IPT)
      TCORLS(4,I) = TCORLS(4,IPT)

```

700 CONTINUE

```

C      *****
C      *
C      *   Generation of coefficient matrices and property arrays   *
C      *   is complete.
C      *
C      *****

```

PRINT 8000

RETURN
END

SUBROUTINE MODES(NP)

```

REAL ASUM(4,4)
REAL BSUM(4,4)
REAL CSUM(4,4)
REAL DSUM(4,4)
REAL BLTBLT
REAL CF1
REAL CF1DOT
REAL CF1DD
REAL CF2
REAL CF2DOT
REAL CF2DD
REAL CF3
REAL CF3DOT
REAL CF3DD
REAL CF4
REAL CF4DOT
REAL CF4DD
REAL EKBEND(201)
REAL EKMMASS(201)
REAL EKTOMG(201)
REAL ETOMGA(201)
REAL MAG(4)
REAL OMGA2
REAL SIMPSN
REAL STEP
REAL POLY(4,201)
REAL POLYDT(4,201)
REAL POLYDD(4,201)
REAL TTOMGA(201)
REAL TRPZOD
REAL X

```

```

REAL QPRIME(4,4)
REAL QTRANS(4,4)
REAL PRDCT1(4,4)
REAL PRDCT2(4,4)
REAL VALU(4)
REAL VECTR1(4,4)
REAL VECTR2(4,4)
REAL VECTR3(4,4)

```

```

INTEGER I
INTEGER K
INTEGER L
INTEGER NP
INTEGER NDIM
INTEGER NDP

```

```

INCLUDE 'C:INCLUDE\BLADE.INC'
INCLUDE 'C:INCLUDE\MODAL.INC'
INCLUDE 'C:INCLUDE\TURBN.INC'

```

```

CHARACTER*20 MODOUT

```

```

C   Coordinate shape functions and their derivatives.
C   These functions are polynomials that satisfy the
C   boundary conditions for a cantilever blade, namely
C   zero displacement and zero slope at the root.
C   These functions will be used in linear combinations
C   using a Rayleigh Ritz type procedure to determine the
C   natural frequencies and modeshapes of the blade.

```

```

C   First shape function and it's derivatives:

```

```

CF1 (X) = X**2*( X*(X-4.0) + 6.)/3.
CF1DOT(X) = 4.*X*(X*(X-3.)+3.)/3.
CF1DD(X) = 4.*(X*(X-2.)+1.)

```

```

C   Second shape function and it's derivatives:

```

```

CF2 (X) = X**3*(X*(3.*X-10.)+10.)/3.
CF2DOT(X) = 5.*X**2*(X*(3.*X-8.)+6.)/3.
CF2DD(X) = 20.*X*(X*(3.*X-6.)+3.)/3.

```

```

C   Third shape function and it's derivatives:

```

```

CF3 (X) = X**4*(X*(2.*X - 6.) + 5.)
CF3DOT(X) = 2.*X**3*(X*(6.*X-15.) + 10.)
CF3DD(X) = 60.*X**2*( X*( X-2.) + 1.)

```

```

C   Fourth shape function and it's derivatives:

```

```

CF4 (X) = X**5*( X*( 10.*X - 28.) + 21.)/3.
CF4DOT(X) = 7.*X**4*( X*( 10.*X - 24.) + 15.)/3.
CF4DD(X) = 14.*X**3*(X*(10.*X - 20. ) + 10.)

```

```

STEP = 1./(NP-1.)
BLTBLT = BLTIP**2
X      = 0.

```

```

DO 110 I = 1,NP

```



```
POLY(1,I) = CF1 ( X)
POLYDT(1,I) = CF1DOT(X)/BLTIP
POLYDD(1,I) = CF1DD(X)/BLTBLT
```

```
POLY(2,I) = CF2 ( X)
POLYDT(2,I) = CF2DOT(X)/BLTIP
POLYDD(2,I) = CF2DD(X)/BLTBLT
```

```
POLY(3,I) = CF3(X)
POLYDT(3,I) = CF3DOT(X)/BLTIP
POLYDD(3,I) = CF3DD(X)/BLTBLT
```

```
POLY(4,I) = CF4(X)
POLYDT(4,I) = CF4DOT(X)/BLTIP
POLYDD(4,I) = CF4DD(X)/BLTBLT
```

```
X = X + STEP
```

```
110 CONTINUE
```

```
C      Fill the intermediate function arrays which are used to
C      compute the tension component integral for the
C      centrifugal stiffening matrix.
```

```
X = 0.
```

```
STEP = BLTIP/(NP - 1.)
```

```
DO 200 I = 1, NP
```

```
ETOMGA(I) = MASS(I)*( HUBRAD + STEP*( I-1 ))
```

```
200 CONTINUE
```

```
C      Compute the tension component integral.
```

```
DO 300 I = 1, NP
```

```
TTOMGA(I) = TRPZOD( ETOMGA, I, NP, BLTIP)
```

```
300 CONTINUE
```

```
C      Compute the coefficient matrices: ASUM, BSUM, CSUM.
```

```
C      ASUM is the bending stiffness matrix, BSUM is the
```

```
C      centrifugal stiffening matrix, and CSUM is the
```

```
C      mass matrix.
```

```
DO 470 K = 1, 4
```

```
DO 440 L = K, 4
```

```
DO 400 I = 1, NP
```

```
EKBEND(I) = EIAREA(I)*POLYDD(K,I)*POLYDD(L,I)
```

```
EKMASS(I) = MASS(I)*POLY(K,I)*POLY(L,I)
```

```
EKTOMG(I) = TTOMGA(I)*POLYDT(K,I)*POLYDT(L,I)
```

```
400 CONTINUE
```

```
C      Compute the K,L th element of the coefficient matrices.
```

```
ASUM(K,L) = SIMPSN(0., BLTIP, NP, EKBEND)
```

```
BSUM(K,L) = SIMPSN(0., BLTIP, NP, EKTOMG)
```

```
CSUM(K,L) = SIMPSN(0., BLTIP, NP, EKMASS)
```

```

440     CONTINUE
470     CONTINUE

C       Once the diagonal and upper triangular elements are
C       computed, reflect the upper triangle onto the lower
C       one.

      DO 520 K = 1,3

          DO 510 L = K+1,4

              ASUM(L,K) = ASUM(K,L)
              BSUM(L,K) = BSUM(K,L)
              CSUM(L,K) = CSUM(K,L)
510     CONTINUE
520     CONTINUE

      NDIM = 4
      NDP  = 4

C       Add the Centrifugal stiffening term to
C       the bending stiffness terms.
C       Form the new matrix DSUM

      OMGA2 = OMEGA * OMEGA * .0109662271124

      DO 1820 I = 1,NDIM
      DO 1830 J = 1,NDIM
          DSUM(I,J) = ASUM(I,J) + OMGA2* BSUM(I,J)
1830 CONTINUE
1820 CONTINUE

      CALL JACOBI(CSUM,NDIM,NDP,VALU,VECTR1)
      CALL EIGSRT(VALU,VECTR1,NDIM,NDP)

      DO 880 I = 1, NDIM
      DO 870 J = 1, NDIM
          SVALU = SQRT(VALU(J))
          QPRIME(I,J) = VECTR1(I,J)/SVALU
870 CONTINUE
880 CONTINUE

      DO 900 I = 1,NDIM
      DO 890 J = 1,NDIM
          QTRANS(J,I) = QPRIME(I,J)
890 CONTINUE
900 CONTINUE

      CALL MULT(QPRIME,DSUM,PRDCT1,NDIM,NDIM)
      CALL MULT(PRDCT1,QTRANS,PRDCT2,NDIM,NDIM)

      CALL JACOBI(PRDCT2,NDIM,NDP,VALU,VECTR2)
      CALL EIGSRT(VALU,VECTR2,NDIM,NDP)
      CALL MULT(VECTR2,QPRIME,VECTR3,NDIM,NDIM)

C       The frequencies of interest are actually the square roots
C       of the calculated eigenvalues.

```

```

DO 915 J = 1,NDIM
  SUMSQ = 0.
  DO 910 I = 1,NDIM
    SUMSQ = SUMSQ + VECTR3(I,J)**2
910  CONTINUE
    MAG(J) = SQRT(SUMSQ)
915  CONTINUE

DO 920 I = 1, NDIM
  FREQ(I) = SQRT( VALU(NDIM+1-I))
920  CONTINUE

DO 960 I = 1,NDIM
DO 940 J = 1,NDIM
  LAMDA(I,J) = VECTR3(I,NDIM+1-J)/MAG(NDIM+1-J)
940  CONTINUE
960  CONTINUE

PRINT*, 'Enter name of modeshape and frequency output file'
READ*, MODOUT

OPEN(8, FILE = MODOUT, STATUS = 'UNKNOWN')

WRITE(8,*) 'FREQUENCIES = '
WRITE(8,*) (FREQ(I), I=1,NDIM)

DO 670 I = 1,4
  DO 660 J = 1,NP
    SHP(I,J) = 0.
    SHPDOT(I,J) = 0.
    SHPDD(I,J) = 0.
660  CONTINUE
670  CONTINUE

DO 700 I = 1,NP
  DO 690 J = 1,NDIM
    DO 680 K = 1,NDIM
      SHP(J,I) = SHP(J,I) + LAMDA(K,J)*POLY(K,I)
      SHPDOT(J,I) = SHPDOT(J,I) + LAMDA(K,J)*POLYDT(K,I)
      SHPDD(J,I) = SHPDD(J,I) + LAMDA(K,J)*POLYDD(K,I)
680  CONTINUE
690  CONTINUE
700  CONTINUE

DO 1400 I = 1,NDIM
TIPDFL = 1.
DO 1390 J = 1,NP
  SHP(I,J) = SHP(I,J)/TIPDFL
  SHPDOT(I,J) = SHPDOT(I,J)/TIPDFL
  SHPDD(I,J) = SHPDD(I,J)/TIPDFL
1390  CONTINUE
1400  CONTINUE

WRITE(8,*) 'Modeshapes:'
DO 720 I = 1,NP,10
  WRITE(8,*) I, (SHP(J,I), J = 1,NDIM)
720  CONTINUE

```

```

RETURN
END

SUBROUTINE JACOBI(A,N,NP,D,V)
PARAMETER (NMAX=100)
DIMENSION A(NP,NP),D(NP),V(NP,NP),B(NMAX),Z(NMAX)
DO 12 IP = 1,N
  DO 11 IQ = 1,N
    V(IP,IQ) = 0.
11  CONTINUE
  V(IP,IP) = 1.
12 CONTINUE

  DO 13 IP = 1,N
    B(IP) = A(IP,IP)
    D(IP) = B(IP)
    Z(IP) = 0.
13 CONTINUE

  NROT = 0

  DO 24 I = 1,50
    SM = 0.
    DO 15 IP = 1,N-1
      DO 14 IQ = IP+1, N
        SM = SM + ABS(A(IP,IQ))
14  CONTINUE
15  CONTINUE

    IF(SM .EQ. 0.) RETURN
    IF(I .LT. 4) THEN
      TRESH = 0.2*SM/N**2
    ELSE
      TRESH = 0.
    ENDIF

    DO 22 IP = 1,N-1
      DO 21 IQ = IP+1,N
        G = 100.*ABS(A(IP,IQ))
        IF( G .LT. 1.0E-08)THEN
          A(IP,IQ)=0.

          ELSEIF( ABS(A(IP,IQ)) .GT. TRESH)THEN
            H = D(IQ)-D(IP)
            IF(ABS(H) + G .EQ. ABS(H))THEN
              T = A(IP,IQ)/H
            ELSE
              THETA = 0.5*H/A(IP,IQ)
              T = 1./((ABS(THETA) + SQRT(1.+ THETA**2))
              IF(THETA .LT. 0.) T = -1.* T
            ENDIF

            C = 1./SQRT(1+T**2)
            S = T*C
            TAU = S/(1.+C)
            H = T*A(IP,IQ)
            Z(IP) = Z(IP) - H
            Z(IQ) = Z(IQ) + H
            D(IP) = D(IP) - H

```

```

D(IQ) = D(IQ) + H
A(IP,IQ) = 0.
DO 16 J=1, IP-1
  G = A(J,IP)
  H = A(J,IQ)
  A(J,IP) = G-S*(H+G*TAU)
  A(J,IQ) = H+S*(G-H*TAU)
16 CONTINUE

```

```

DO 17 J = IP+1, IQ-1
  G = A(IP,J)
  H = A(J,IQ)
  A(IP,J) = G-S*(H+G*TAU)
  A(J,IQ) = H+S*(G-H*TAU)
17 CONTINUE

```

```

DO 18 J = IQ+1, N
  G = A(IP,J)
  H = A(IQ,J)
  A(IP,J) = G-S*(H+G*TAU)
  A(IQ,J) = H+S*(G-H*TAU)
18 CONTINUE

```

```

DO 19 J = 1,N
  G = V(J,IP)
  H = V(J,IQ)
  V(J,IP) = G-S*(H+G*TAU)
  V(J,IQ) = H+S*(G-H*TAU)
19 CONTINUE

```

```

  NROT = NROT + 1
ENDIF
21 CONTINUE
22 CONTINUE

```

```

DO 23 IP = 1,N
  B(IP) = B(IP) + Z(IP)
  D(IP) = B(IP)
  Z(IP) = 0.
23 CONTINUE
24 CONTINUE

```

```

RETURN
END

```

```

SUBROUTINE EIGSRT(D,V,N,NP)

```

```

DIMENSION D(NP), V(NP,NP)
DO 13 I = 1, N-1
  K=I
  P=D(I)
DO 11 J=I+1,N
  IF(D(J) .GE. P)THEN
    K=J
    P=D(J)
  ENDIF
11 CONTINUE

```

```

IF(K .NE. I) THEN
  D(K) = D(I)

```

```

D(I) = P
DO 12 J = 1,N
  P = V(J,I)
  V(J,I) = V(J,K)
  V(J,K) = P
12 CONTINUE
ENDIF
13 CONTINUE
RETURN
END

```

SUBROUTINE INPUT (NP , NPTS , FILOUT)

```

C *****
C *
C * Subroutine INPUT performs the following tasks: *
C *
C * 1 - Opens input and output data files. *
C * 2 - Reads in blade property and wind turbine data. *
C * 3 - Checks validity of input data. *
C * 4 - Performs a linear interpolation between data *
C * points to provide data at the proper points for *
C * the COEFFS subroutine. *
C * 5 - Performs unit conversions. *
C *
C *****
C
C *****
C *
C * External references in this routine: *
C *
C * CAPS - Converts strings to upper case. *
C * INTERP - Subroutine that performs a linear interpo- *
C * lation of the input data. *
C *
C *****
C
C *****
C *
C * Named COMMON blocks used in this routine: *
C *
C * AERO - Aerodynamic blade properties derived from *
C * input aerodynamic data. *
C * BLADE - Blade position dependent values that are *
C * computed by linear interpolation of the in- *
C * put property data. *
C * LITERL - Data file titles used for printed output. *
C * PANELS - Used to communicate with the interpolation *
C * subroutine INTERP. *
C * TURBN - Turbine related variables. *
C * WIND - Wind related variables. *
C *
C *****
C
C *****
C *
C * Local and dummy variables used in this routine: *
C *
C *

```

```

C * ACDZER Drag coefficient at each blade station. *
C * (dimensionless) *
C * ACHORD - Blade chord at each data station. (feet) *
C * ACLALF - Slope of lift curve at each blade station. *
C * (radians**-1) *
C * ACLMAX - The maximum or stall value of the lift co- *
C * efficient. *
C * AEIARE - Moment of inertia of blade at data station. *
C * (10**6 Lb-Ft**2) *
C * AESBAC - Distance from elastic axis to aerodynamic *
C * center. Origin is at the elastic axis; It *
C * is positive if the elastic axis is forward *
C * (toward the leading edge) of the aerodynam- *
C * ic center. (feet) *
C * AIEMAS Second mass moment of the blade cross sec- *
C * tion in the edgewise direction. (Lb-sec^2) *
C * AIFMAS - Second mass moment of the blade cross sec- *
C * tion in the flapwise direction. (Lb-sec^2) *
C * ANS - Literal containing the answer to a ques- *
C * tion. *
C * AOFFST - Distance from the elastic axis to the mass *
C * axes of blade section. Positive towards *
C * the leading edge. Called E-sub-eta in the *
C * formulation. (feet) *
C * ATWIST - The blade built-in twist angle as a func- *
C * tion of position along the blade span. The *
C * built-in twist at each of I stations. *
C * ATWIST is the angle from the section-chord *
C * line at the Ith station to the section- *
C * chord line at the tip. Generally speaking, *
C * ATWIST(Reference Station) = THETAT. *
C * ERROR - Error flag indicating an invalid XLEFT ar- *
C * ray. *
C * FILEIN - Literal containing the name of the input *
C * data file. *
C * FILOUT - Literal containing the name of the output *
C * data file. *
C * GRAV - Constant of gravitational acceleration as *
C * measured at sea level. (feet/second**2) *
C * - Generic index. *
C * NP Number of blade property values used in *
C * performing composite Simpson's integration *
C * for the M and K coefficient arrays. This *
C * number is approximately 10 times the NPTS *
C * value. *
C * NPANEL - Number of blade property values to be read *
C * in from the input data file. *
C * NPTS - Number of points along the blade used to *
C * perform Simpson's integration for calculat- *
C * ing the moments and forces at the blade *
C * root. *
C * RAD2DG - Degrees to radians conversion factor. *
C * RTWIST - The blade twist angle relative to the zero- *
C * lift line. (radians) *
C * WEIGHT - Blade section weight per unit length. In- *
C * put as blade station data. (Lbf/ft) *
C * *
C *****

```

```

REAL      ACDZER (11)
REAL      ACHORD (11)
REAL      ACLALF (11)
REAL      ACLMAX (11)
REAL      AEIARE (11)
REAL      AESBAC (11)
REAL      AIEMAS (11)
REAL      AIFMAS (11)
REAL      AOFFST (11)
REAL      ATWIST (11)
REAL      GRAV
REAL      RAD2DG
REAL      RTWIST (11)
REAL      WEIGHT (11)

```

```

INTEGER   I
INTEGER   NP
INTEGER   NPANEL
INTEGER   NPTS

```

```

LOGICAL   ERROR

```

```

CHARACTER*50 FILEIN
CHARACTER*50 FILOUT

```

```

INCLUDE   'C:\INCLUDE\AERO.INC'

```

```

INCLUDE   'C:\INCLUDE\BLADE.INC'

```

```

INCLUDE   'C:\INCLUDE\LITERL.INC'

```

```

INCLUDE   'C:\INCLUDE\PANELS.INC'

```

```

INCLUDE   'C:\INCLUDE\TRBINF.INC'

```

```

INCLUDE   'C:\INCLUDE\TURBN.INC'

```

```

INCLUDE   'C:\INCLUDE\WIND.INC'

```

```

DATA      GRAV      / 32.1740 /
DATA      RAD2DG    / 57.29577951308233 /

```

```

1000 FORMAT ( / ' Subroutine INPUT: Input and process new blade'
&          / '                and turbine data.' / )
1100 FORMAT ( A )
1200 FORMAT ( / ' *** Invalid response ***' / )
1300 FORMAT ( BN , 6X , F16.5 )
1400 FORMAT ( BN , 6X , I10 )
1500 FORMAT ( BN , 12X , 11( F10.5 , : ) )
2000 FORMAT ( // 3( 1X , A / ) / ' Parameter values:' / )
2100 FORMAT ( 1X , A , F12.5 , 10X , A , I6 )
2200 FORMAT ( 1X , A , F12.5 , 10X , A , F12.5 )
2300 FORMAT ( 1X , A , I6 , 16X , A , F12.5 )
2400 FORMAT ( ' XLEFT      WEIGHT      AEIARE '
&          , ' AIEMAS      AIFMAS      AOFFST' / )
2500 FORMAT ( 11( F11.5 , 5F13.5 / : ) )
2600 FORMAT ( / ' ACHORD      ATWIST      ALCALF '
&          , ' ACLMAX      ACDZER      AESBAC' / )
2700 FORMAT ( / ' STA-' )

```



```

2750 FORMAT ( 11( F10.3/:))
3000 FORMAT ( / ' >>> Error: Blade data do not start at blade root:'
&      , ' <<<'
&      / ' >>>' , 50X , ' <<<'
&      / ' >>>      XLEFT(1) = ' , F8.3 , ' , but should be'
&      , ' zero. <<<' )
3100 FORMAT ( / ' >>> Error: Blade data do not end at blade tip:'
&      , ' <<<'
&      / ' >>>' , 46X , ' <<<'
&      / ' >>>      XLEFT(' , I2.2 , ' ) = ' F8.3
&      , ' , but should be <<<'
&      / ' >>>      equal to BLTIP = ' , F8.3
&      , ' <<<' / )
3200 FORMAT ( / ' >>> Please correct input file and rerun job <<<'
&      /// ' FLAP terminated abnormally due to the error listed'
&      , ' above.' / )

```

C Initialize the number of shape functions.

```
NSHAPS = 4
```

C Get input and output data file names. Open the input file.

C Determine rotor type. Read data from input file.

```

PRINT 1000
PRINT *, 'Enter name of input data file > '
READ 1100, FILEIN

```

```
OPEN ( 1 , FILE=FILEIN , STATUS='OLD' )
```

```

PRINT *, ' '
PRINT *, 'Enter name of output data file > '
READ 1100, FILOUT

```

```
CALL CAPS ( FILOUT )
```

```

110 READ (1,1100) TITLE1
   READ (1,1100) TITLE2
   READ (1,1100) TITLE3

```

```

READ (1,1300) ALENTH
READ (1,1300) ALPHAO
READ (1,1300) BETAO
READ (1,1300) BLSHNK
READ (1,1300) BLTIP
READ (1,1300) CHI
READ (1,1300) CSUBMA
READ (1,1300) DRGFRM
READ (1,1300) HUBHT
READ (1,1300) HUBRAD
READ (1,1400) KSHADW
READ (1,1400) NBLADS
READ (1,1400) NPANEL
READ (1,1300) OMEGA
READ (1,1300) PHIAMP
READ (1,1300) PHIOMG
READ (1,1300) PHIO

```

```

READ (1,1300) PSIZER
READ (1,1300) SHERXP
READ (1,1300) THETAP
READ (1,1300) THETAT
READ (1,1300) TSUBP
READ (1,1300) TSUBO
READ (1,1300) VHUB

```

```

READ (1,1500) ( XLEFT ( I) , I=1,NPANEL )
READ (1,1500) ( WEIGHT(I) , I=1,NPANEL )
READ (1,1500) ( AEIARE(I) , I=1,NPANEL )
READ (1,1500) ( AIEMAS(I) , I=1,NPANEL )
READ (1,1500) ( AIFMAS(I) , I=1,NPANEL )
READ (1,1500) ( AOFFST(I) , I=1,NPANEL )
READ (1,1500) ( ACHORD(I) , I=1,NPANEL )
READ (1,1500) ( ATWIST(I) , I=1,NPANEL )
READ (1,1500) ( ACLALF(I) , I=1,NPANEL )
READ (1,1500) ( ACLMAX(I) , I=1,NPANEL )
READ (1,1500) ( ACDZER(I) , I=1,NPANEL )
READ (1,1500) ( AESBAC(I) , I=1,NPANEL )

```

```

READ (1,1400) NUMSCN
READ (1,1300) TIMINC
READ (1,1400) MSTAT
READ (1,1500) ( STA(I), I=1,MSTAT)

```

C Close input file.

```
CLOSE(1)
```

C Echo input data.

```
PRINT 2000, TITLE1 , TITLE2 , TITLE3
```

```

PRINT 2100, 'ALENTH = ' , ALENTH , 'NPANEL = ' , NPANEL
PRINT 2200, 'ALPHAO = ' , ALPHAO , 'OMEGA = ' , OMEGA
PRINT 2200, 'BETAO = ' , BETAO , 'PHIO = ' , PHIO
PRINT 2200, 'BLSHNK = ' , BLSHNK , 'PHIAMP = ' , PHIAMP
PRINT 2200, 'BLTIP = ' , BLTIP , 'PHIOMG = ' , PHIOMG
PRINT 2200, 'CHI = ' , CHI , 'PSIZER = ' , PSIZER
PRINT 2200, 'CSUBMA = ' , CSUBMA , 'SHERXP = ' , SHERXP
PRINT 2200, 'DRGFRM = ' , DRGFRM , 'THETAP = ' , THETAP
PRINT 2200, 'HUBHT = ' , HUBHT , 'THETAT = ' , THETAT
PRINT 2200, 'HUBRAD = ' , HUBRAD , 'TSUBO = ' , TSUBO
PRINT 2300, 'KSHADW = ' , KSHADW , 'TSUBP = ' , TSUBP
PRINT 2300, 'NBLADS = ' , NBLADS , 'VHUB = ' , VHUB
PRINT 2300, 'NUMSCN = ' , NUMSCN
PRINT 2200, 'TIMINC = ' , TIMINC
PRINT 2300, 'MSTAT = ' , MSTAT

```

```

PRINT *, ' '
PRINT *, 'Hit <Enter> to continue...'

```

```

200 PRINT 2400
PRINT 2500, ( XLEFT(I) , WEIGHT(I) , AEIARE(I) , AIEMAS(I)
& , AIFMAS(I) , AOFFST(I) , I=1,NPANEL )

```

```
PRINT *, ' '
PRINT *, 'Hit <Enter> to continue...'
```

```
READ (*,1100,END=210) ANS
```

```
210 PRINT 2600
```

```
PRINT 2500, ( ACHORD(I) , ATWIST(I) , ACLALF(I) , ACLMAX(I)
&           , ACDZER(I) , AESBAC(I) , I=1, NPANEL )
```

```
PRINT *, ' '
PRINT *, 'Hit <Enter> to continue...'
```

```
220 PRINT 2700
```

```
PRINT 2750, ( STA(I), I=1,MSTAT)
```

```
PRINT *, ' '
PRINT *, 'Hit <Enter> to continue...'
```

```
READ (*,1100,END=300) ANS
```

```
C      Check validity of XLEFT array. XLEFT must start at blade root
C      and end at blade tip.
```

```
300 ERROR = .FALSE.
```

```
IF ( XLEFT(1) .NE. 0.0 ) THEN
PRINT 3000, XLEFT(1)
ERROR = .TRUE.
END IF
```

```
IF ( XLEFT(NPANEL) .NE. BLTIP ) THEN
PRINT 3100, NPANEL , XLEFT(NPANEL) , BLTIP
ERROR = .TRUE.
END IF
```

```
IF ( ERROR ) THEN
PRINT 3200
STOP
END IF
```

```
C      Perform unit conversions - Lbm to slugs, degrees to radians.
```

```
DO 400 I=1, NPANEL
WEIGHT(I) = WEIGHT(I)/GRAV
AEIARE(I) = AEIARE(I)*1.E06
AIEMAS(I) = AIEMAS(I)
AIFMAS(I) = AIFMAS(I)
RTWIST(I) = ( THETAT - ATWIST(I) - ALPHAO )/RAD2DG
```

```
400 CONTINUE
```

```
C      Perform linear interpolation of blade properties to set up
C      arrays of blade property data at equidistant points along the
C      blade. The arrays are used by the COEFFS subroutine to produce
C      the coefficient matrices.
```

```
STEP = BLTIP/( NP - 1 )
```

```
CALL INTERP ( WEIGHT , MASS , NPANEL , NP )  
CALL INTERP ( AIEMAS , IEMASS , NPANEL , NP )  
CALL INTERP ( AIFMAS , IFMASS , NPANEL , NP )  
CALL INTERP ( AEIARE , EIAREA , NPANEL , NP )  
CALL INTERP ( AOFFST , OFFSET , NPANEL , NP )  
CALL INTERP ( ACHORD , CHORD , NPANEL , NP )  
CALL INTERP ( RTWIST , THETAO , NPANEL , NP )
```

```
C These property arrays will be used by the RUN subroutine for  
C solving the governing equations and for calculation of the  
C loads and moments.
```

```
STEP = BLTIP/( NPTS - 1 )
```

```
CALL INTERP ( ACLALF , CLALFA , NPANEL , NPTS )  
CALL INTERP ( ACDZER , CDZERO , NPANEL , NPTS )  
CALL INTERP ( AESBAC , ESUBAC , NPANEL , NPTS )  
CALL INTERP ( ACLMAX , CLMAX , NPANEL , NPTS )
```

```
RETURN
```

```
END
```

```
SUBROUTINE INTERP ( GIVEN , CMPUTD , NPANEL , NP )
```

```
C *****  
C *  
C * This subroutine performs a linear interpolation of the *  
C * input data set. The input blade data contains NPANEL *  
C * data points. The data are interpolated to provide data *  
C * at NP evenly spaced points. *  
C * *  
C *****
```

```
C *****  
C *  
C * Local and dummy variables used in this routine: *  
C * *  
C * CMPUTD - Regularly spaced interpolated data. *  
C * GIVEN - Unevenly spaced input data. *  
C * IPNL - Index into the GIVEN array. *  
C * JPT - Index into the CMPUTD array. *  
C * MOVE - Flag to see if we've moved to the next pan- *  
C * el. *  
C * NP - Number of evenly spaced data points. *  
C * NPANEL - Number of unevenly spaced data points. *  
C * PTR - Blade position pointer. It is the location *  
C * of the next interpolated value. *  
C * SLOPE - Slope of the line between two GIVEN data *  
C * points. *  
C * *  
C *****
```

```
INTEGER NP  
INTEGER NPANEL  
  
REAL CMPUTD (NP)
```

```

REAL      GIVEN (NPANEL)
REAL      PTR
REAL      SLOPE

INTEGER   IPNL
INTEGER   JPT

LOGICAL   MOVE

INCLUDE   'C:INCLUDE\PANELS.INC'

```

C Initialize GIVEN index and pointer.

```

IPNL = 1
PTR = 0.0

```

C Compute slope between first two data points.

```

SLOPE = ( GIVEN(2) - GIVEN(1) )/XLEFT(2)

```

C Compute property at each of the NP evenly spaced points.

```

DO 20 JPT=1, NP-1

```

```

    CMPUTD(JPT) = GIVEN(IPNL) + SLOPE*( PTR - XLEFT(IPNL) )

```

```

    PTR = PTR + STEP

```

C Make sure that the new data point is inside the current
C panel. Otherwise, move over one step.

```

    IF ( JPT .LT. NP-1 ) THEN

```

```

        MOVE = .FALSE.

```

```

10    IF ( PTR .GT. XLEFT(IPNL+1) ) THEN

```

```

        IPNL = IPNL + 1

```

```

        MOVE = .TRUE.

```

```

        GO TO 10

```

```

    END IF

```

```

        IF ( MOVE ) SLOPE = ( GIVEN(IPNL+1) - GIVEN(IPNL) )/
&          ( XLEFT(IPNL+1) - XLEFT(IPNL) )

```

```

    END IF

```

```

20 CONTINUE

```

```

    CMPUTD(NP) = GIVEN(NPANEL)

```

```

    RETURN

```

```

    END

```

```

    FUNCTION LNTH ( STRING )

```

```

C *****
C *
C * Function LNTH returns the length of a character string. *
C * When using the Lahey F77L compiler, the intrinsic func- *
C * tion NBLANK can be used as we do here. This function *
C * was supplied to make conversion to other compilers eas- *
C * ier. *
C *
C *****

```

```

C *****
C *
C * Named COMMON blocks used in this routine: *
C *
C * none *
C *
C *****

```

```

C *****
C *
C * Variables used in this routine: *
C *
C * IC - Generic index. *
C * LENGTH - The declared length of STRING. *
C * LNTH - The location of the last nonblank character *
C * in STRING. *
C * STRING - A character string. *
C *
C *****

```

```

INTEGER IC
INTEGER LENGTH
INTEGER LNTH

CHARACTER*(*) STRING

```

```

C Get the declared length of STRING using the FORTRAN 77 intrinsic
C function LEN.

```

```

LENGTH = LEN( STRING )

```

```

C Find the location of the last nonblank character in STRING.

```

```

DO 100 IC=LENGTH,1,-1

```

```

LNTH = IC

```

```

IF ( STRING(IC:IC) .NE. ' ' ) GO TO 200

```

```

100 CONTINUE

```

```

C STRING is all blanks.

```

```

LNTH = 0

```

200 RETURN

END

SUBROUTINE PRNCOE (FILEOUT , NPTS)

```
C *****
C *
C * This subroutine writes the data required to run MODULE *
C * 2 into the run data file. Variable names are included *
C * in the file for informational purposes only. All vari- *
C * ables written into the run data file have been defined *
C * previously. Named common blocks AERO, BLADE, TURBN and *
C * WIND first appear in subroutine INPUT. Named common *
C * blocks MATRX1 and MATRX2 are computed in subroutine *
C * COEFFS. *
C * *
C *****

C *****
C *
C * Named COMMON blocks used in this routine: *
C * *
C * AERO - Aerodynamic blade properties derived from *
C * input aerodynamic data. *
C * BLADE - Blade position dependent values that are *
C * computed by linear interpolation of the in- *
C * put property data. *
C * HUBTYP - Holds flag indicating the type of hub (ri- *
C * gid or teetering). *
C * LITERL - Data file titles used for printed output. *
C * LODVAL - *
C * MATRX1 - Holds some of the coefficient matrices of *
C * the governing equation of motion. *
C * MATRX2 - Holds some of the coefficient matrices of *
C * the governing equation of motion. *
C * TENSIN - Holds tension components of the stiffness *
C * functions. *
C * TURBN - Turbine related variables. *
C * WIND - Wind related variables. *
C * *
C *****

C *****
C *
C * Local and dummy variables used in this routine: *
C * *
C * COL - Column index into matrices. *
C * FILEOUT - Literal containing the name of the output *
C * data file. *
C * I - Generic index. *
C * N - Generic index. *
C * NPTS - Number of points along the blade used to *
C * perform Simpson's integration for calculat- *
C * ing the moments and forces at the blade *
C * root. (passed from FLAP1) *
C * NSHPS - Number of blade shape functions. Set to 1 *
C * for use by MODULE 2. *
C * ROW - Row index into matrices. *
C * *
```

C *****

INTEGER COL
INTEGER I
INTEGER LNTH
INTEGER N
INTEGER NPTS
INTEGER NSHPS
INTEGER ROW

CHARACTER*50 FILOUT

INCLUDE 'C:INCLUDE\AERO.INC'
INCLUDE 'C:INCLUDE\BLADE.INC'
INCLUDE 'C:INCLUDE\LITERL.INC'
INCLUDE 'C:INCLUDE\LODVAL.INC'
INCLUDE 'C:INCLUDE\MATRX1.INC'
INCLUDE 'C:INCLUDE\MATRX2.INC'
INCLUDE 'C:INCLUDE\TENSIN.INC'
INCLUDE 'C:INCLUDE\TRBINF.INC'
INCLUDE 'C:INCLUDE\TURBN.INC'
INCLUDE 'C:INCLUDE\WIND.INC'
INCLUDE 'C:INCLUDE\MODAL.INC'

2000 FORMAT (3(A /) /)
2100 FORMAT (A)
3000 FORMAT (/ 13X , 'ALENTH' , 18X , 'ALPHA0' , 18X , ' BETA0'
& / 3(1PE24.10))
3100 FORMAT (/ 13X , 'BLSHNK' , 18X , ' BLTIP' , 18X , ' CHI '
& / 3(1PE24.10))
3200 FORMAT (/ 13X , 'CSUBMA' , 18X , 'DRGFRM' , 18X , ' HUBHT'
& / 3(1PE24.10))
3300 FORMAT (/ 13X , 'HUBRAD' , 18X , ' OMEGA' , 18X , ' PH10 '
& / 3(1PE24.10))
3400 FORMAT (/ 13X , 'PHIAMP' , 18X , 'PHIOMG' , 18X , 'PSIZER'
& / 3(1PE24.10))
3500 FORMAT (/ 13X , 'SHERXP' , 18X , 'THETAP' , 18X , 'THETAT'
& / 3(1PE24.10))
3600 FORMAT (/ 13X , ' TSUB0' , 18X , ' TSBP' , 18X , ' VHUB '
& / 3(1PE24.10))
3700 FORMAT (/ 10X , 'KSHADW' , 12X , 'NBLADS'
& , 12X , 'NSHAPS' , 12X , ' NPTS ' / 114 , 3(I18))
3860 FORMAT (/ 10X , 'NUMSCN=' , I6)
3870 FORMAT (/ 10X , 'TIMINC=' , F10.5)
3880 FORMAT (/ 10X , 'MSTAT =' , I3)
4000 FORMAT (/ A , 26(/ 4(1PE18.7 , :)))
5000 FORMAT (/ ' CKTCRL(' , I2 , ',K,L)-' , 4(/ 4(1PE18.7)))
6000 FORMAT (/ A / 4(1PE18.7))
6100 FORMAT (/ ' TCORLS(' , I1 , ',I)-' , 26(/ 4(1PE18.7 , :)))


```

6050 FORMAT ( / ' STA(1)-' , 26( / 5( 1PE14.3 , : )))
7000 FORMAT ( / ' CIFMOM(' , I1 , ',I)-' , 26( / 4( 1PE18.7 , : ) ) )
8000 FORMAT ( / ' Data for MODULE 2 have been written to ' , A , '.'
&          / )

```

C Open output data file.

```
OPEN ( 2 , FILE=FILOUT , STATUS='UNKNOWN' )
```

C Put titles in run data file.

```
WRITE (2,2000) TITLE1 , TITLE2 , TITLE3
```

C Put scalar values into run data file.

```

WRITE (2,3000) ALENTN , ALPHA0 , BETA0
WRITE (2,3100) BLSHKN , BLTIP , CHI
WRITE (2,3200) CSUBMA , DRGFRM , HUBHT
WRITE (2,3300) HUBRAD , OMEGA , PHIO
WRITE (2,3400) PHIAMP , PHIOMG , PSIZER
WRITE (2,3500) SHERXP , THETAP , THETAT
WRITE (2,3600) TSUBO , TSUBP , VHUB

```

C Use the value 2 for NSHAPS, which is the preferred value for
C MODULE 2. Use the variable name NSHPS to avoid overwriting

C NSHAPS.

```
NSHPS = 2
```

```
WRITE (2,3700) KSHADW , NBLADS , NSHPS , NPTS
```

```
WRITE (2,3860) NUMSCN
```

```
WRITE (2,3870) TIMINC
```

```
WRITE (2,3880) MSTAT
```

```
WRITE (2,6050) ( STA(I) , I=1 , MSTAT)
```

C Put vector values into run data file.

```
WRITE (2,4000) ' CLALFA-' , ( CLALFA(I) , I=1,NPTS )
```

```
WRITE (2,4000) ' CLMAX -' , ( CLMAX (I) , I=1,NPTS )
```

```
WRITE (2,4000) ' CDZERO-' , ( CDZERO(I) , I=1,NPTS )
```

```
WRITE (2,4000) ' CHORD-' , ( CHORD (I) , I=1,NPTS )
```

```
WRITE (2,4000) ' ECNTFN-' , ( ECNTFN(I) , I=1,NPTS )
```

```
WRITE (2,4000) ' ESUBAC-' , ( ESUBAC(I) , I=1,NPTS )
```

```
WRITE (2,4000) ' THETA0-' , ( THETA0(I) , I=1,NPTS )
```

C Put matrix coefficient values into run data file.

```
WRITE (2,4000) ' CKBEND-'
```

```
&          , ( ( CKBEND(ROW,COL) , COL=1,4 ) , ROW=1,4 )
```

```
WRITE (2,4000) ' CKTOMG-'
```

```
&          , ( ( CKTOMG(ROW,COL) , COL=1,4 ) , ROW=1,4 )
```

```
WRITE (2,4000) ' CKTGRV-'
```

```
&          , ( ( CKTGRV(ROW,COL) , COL=1,4 ) , ROW=1,4 )
```

```
WRITE (2,4000) ' CKQLDD-'
```

```

&          , ( ( CKQLD(ROW,COL) , COL=1,4 ) , ROW=1,4 )
WRITE (2,4000) ' CMMASS-'
&          , ( ( CMMASS(ROW,COL) , COL=1,4 ) , ROW=1,4 )

DO 500 N=1,4
500 WRITE (2,5000) N , ( ( CKTCRL(N,ROW,COL), COL=1,4 ) , ROW=1,4 )

C      Put vector coefficient values into run data file.

WRITE (2,6000) ' CMRIGD-' , ( CMRIGD(I) , I=1,4 )
WRITE (2,6000) ' CMBLNC-' , ( CMBLNC(I) , I=1,4 )
WRITE (2,6000) ' CMGRAV-' , ( CMGRAV(I) , I=1,4 )

C      Put matrix tension values into run data file.

DO 600 N=1,4
600 WRITE (2,6100) N , ( TCORLS(N,I) , I=1,NPTS )

C      Put vector gravity and centrifugal stiffening values into run
C      data file.

WRITE (2,4000) ' TGRAV-' , ( TGRAV(I) , I=1,NPTS )
WRITE (2,4000) ' TOMGA-' , ( TOMGA(I) , I=1,NPTS )

C      Put property values into run data file.

DO 700 N=1,4
700 WRITE (2,7000) N , ( CIFMOM(N,I) , I=1,NPTS )

WRITE (2,4000) ' DELTIM-' , ( DELTIM(I) , I=1,NPTS )
WRITE (2,4000) ' OFFMAS-' , ( OFFMAS(I) , I=1,NPTS )

DO 710 I = 1,4
    WRITE(2,*) (LAMDA(I,J),J=1,4)
710 CONTINUE

C      Run file generation complete. Print message and close file.

WRITE (*,8000) 'FILOUT(1:LNGTH(FILOUT))

CLOSE ( 2 )

RETURN
END
FUNCTION SIMPSN ( LOWLIM , UPLIM , NPTS , FOFX )

C      *****
C      *
C      * This function performs composite Simpson's integration *
C      * on a given set of data points. The formulation appears *
C      * in:

```

```

C      *      Carnahan, et al, Applied Numerical Methods, John      *
C      *      Wiley and Sons, NY, pp. 78-79.                        *
C      *                                                              *
C      *-----*
C      *-----*
C      *
C      *      Local and dummy variables used in this routine:      *
C      *
C      *      FOFX  - Array of data points to be integrated. They   *
C      *              are treated as the value of a function eval-   *
C      *              uated at a specific point.                     *
C      *      H      Subinterval size..                             *
C      *      I      - Generic index.                               *
C      *      LOWLIM - Lower limit of integration.                 *
C      *      UPLIM  - Upper limit of integration.                 *
C      *      NPTS   - Number of base points given by 2*N+1, where  *
C      *              N is the number of applications of Simpson's   *
C      *              rule. See NSIMP in the main program. Note:    *
C      *              When calling from subroutine COEFFS, the      *
C      *              value of NP is used instead of NPTS.         *
C      *      SIMPSN - Value of the integral from LOWLIM to UPLIM.  *
C      *
C      *-----*

```

```

REAL      FOFX  (201)
REAL      H
REAL      LOWLIM
REAL      SIMPSN
REAL      UPLIM

```

```

INTEGER   I
INTEGER   NPTS

```

```

C      Compute the subinterval size and initialize the integral.

```

```

H      = ( UPLIM - LOWLIM )/( NPTS - 1 )
SIMPSN = 0.0

```

```

C      Add in the intermediate points. In the formulation, all even
C      numbered points have coefficient of 4. In this case, the index
C      must be shifted to form the proper coefficient.

```

```

DO 10 I=2,NPTS-1,2
10 SIMPSN = SIMPSN + 4.0*FOFX(I) + 2.0*FOFX(I+1)

```

```

SIMPSN = SIMPSN + FOFX(1) - FOFX(NPTS)

```

```

SIMPSN = H*SIMPSN/3.0

```

```

RETURN

```

```

END

```

```

FUNCTION TRPZOD ( FOF , LOWLIM , NP , BLTIP )

```

```

C *****
C *
C * Function TRPZOD performs composite trapezoidal integra- *
C * tion on a set of data points transmitted from the *
C * calling routine. For derivation of the formula and *
C * limitations, see Carnahan, p. 78 (see full reference in *
C * comments for function SIMPSN). For computational effi- *
C * ciency, the interval width is not used in the formula- *
C * tion until the end when it is multiplied by the sum. *
C *
C *****
C
C *****
C *
C * Local and dummy variables used in this routine: *
C *
C * FOF - Array of data points to be integrated. They *
C * are treated by this function as the value *
C * of a function evaluated at specific points. *
C * (dummy argument) *
C * H - Subinterval length given by  $H=(B-A)/N$ . *
C * I - Index into the FOF array. *
C * LOWLIM - Index of the lower integration limit. The *
C * blade position indexed by LOWLIM is given *
C * by  $BLTIP*(LOWLIM-1)/(NP-1)$ . (dummy argu- *
C * ment) *
C * NP - Number of evenly spaced data points. (dummy *
C * argument) *
C * TRPZOD - Value of the integral from the blade posi- *
C * tion indexed by LOWLIM to BLTIP. *
C *
C *****

```

```

REAL      BLTIP
REAL      FOF      (201)
REAL      H
REAL      TRPZOD

INTEGER   I
INTEGER   LOWLIM
INTEGER   NP

```

```

C Check to see if the lower and upper limits of integration are
C the same. If so, the integral is zero.

```

```

IF ( LOWLIM .EQ. NP ) THEN

```

```

    TRPZOD = 0.0
    RETURN

```

```

END IF

```

```

C Compute the distance between data points.

```

```

H = BLTIP/( NP - 1 )

```

```

C      Initialize integral to the contribution of the end points.

TRPZOD = 0.5*( FOF(LOWLIM) + FOF(NP) )

C      If there are only two data points, then we are done.

IF ( LOWLIM+1 .EQ. NP ) GO TO 20

C      Add in the contribution of the intermediate points.

DO 10 I=LOWLIM+1,NP-1
10 TRPZOD = TRPZOD + FOF(I)

C      Multiply by the interval width and return.

20 TRPZOD = H*TRPZOD

RETURN
END

SUBROUTINE MULT ( AMATRX , BMATRX, RESULT, M , N )

C      *****
C      *
C      * Subroutine MULT premultiplies two incoming matrices *
C      * together. The result is stored in the RESULT matrix. *
C      * All matrices are considered to be square matrices up to *
C      * up to order 4. The matrix AMATRX gets multiplied *
C      * by the matrix BMATRX. *
C      *****

C      *****
C      *
C      * External references in this routine: *
C      *
C      * none *
C      *
C      *****

C      *****
C      *
C      * Named COMMON blocks used in this routine: *
C      *
C      * NONE *
C      *
C      *****

C      *****
C      *
C      * Local and dummy variables used in this routine: *
C      *
C      * AMATRX - The incoming matrix to be premultiplied by *
C      * the inverse CMMASS matrix. *

```

```

C      *      BMATRIX - The other incoming matrix which does the      *
C      *      multiplying.                                          *
C      *      RESULT - The result matrix of the multiplications      *
C      *      I       - Generic index.                               *
C      *      J       - Generic index.                               *
C      *      K       - Generic index.                               *
C      *      M       - Number of rows in the incoming matrix.      *
C      *      N       - Number of columns in the incoming matrix.    *
C      *
C      *****

```

```

REAL      AMATRIX (4,4)
REAL      BMATRIX(4,4)
REAL      RESULT(4,4)

```

```

INTEGER   I
INTEGER   J
INTEGER   K
INTEGER   M
INTEGER   N

```

```

C      Multiply AMATRIX by BMATRIX putting the result into RESULT.

```

```

DO 30 I=1,M
    DO 20 J=1,N
        RESULT(I,J) = 0.
        DO 10 K=1,M
10      RESULT(I,J) = RESULT(I,J) + BMATRIX(I,K) * AMATRIX(K,J)
20      CONTINUE
30      CONTINUE
    RETURN
END

```

Appendix D

Module 2 Listing

PROGRAM FLAP2

```
C      *****
C      *
C      * 0000000 0      00      000000 *
C      * 0      0      0 0      0 0 *
C      * 0000      0      000000 000000 *
C      * 0      0      0      0 0      *
C      * 0      0000000 0      0 0      *
C      *
C      * Forces & Loads Analysis Program *
C      *
C      *           Module 2              *
C      *
C      *           Version 2.01          *
C      *
C      *****
```

```
C      *****
C      *
C      *           DISCLAIMER             *
C      *
C      * Neither the United States Department of Energy, the *
C      * National Renewable Energy Laboratory,                *
C      * the Midwest Research Institute nor anyone            *
C      * else who has been involved in the                    *
C      * creation, production or delivery of this program shall *
C      * be liable for any direct, indirect, consequential, or *
C      * incidental damages arising out of the use, the results *
C      * of use, or inability to use this program even if the *
C      * United States Department of Energy has been advised of *
C      * the possibility of such damages or claim. Some states *
C      * do not allow the exclusion or limitation of liability *
C      *
```


C * for consequential or incidental damages, so the above *
C * limitation may not apply to you. *
C * *
C *****

C *****
C * *
C * The FLAP Code *
C * *
C * FLAP calculates the forces and moments on a wind tur- *
C * bine blade due to aerodynamic, inertial and gravita- *
C * tional forces. The aerodynamic effects include wind *
C * shear, tower shadow and the induced velocity due to the *
C * change in momentum of the air stream as it passes over *
C * the blade. A dynamic stall model can be added without *
C * substantial revision of the code. *
C * *
C *****

C *****
C * *
C * Module 2 *
C * *
C * This program is the second of two modules that consti- *
C * tute the FLAP code. This second module performs the *
C * actual model run, computes the loads and prints the re- *
C * sults to an external data file. *
C * *
C *****

C *****
C * *
C * Questions about the original formulation, theory, meth- *
C * od of solution and programming should be addressed to: *
C * *
C * Alan D. Wright *
C * Wind Research Branch *
C * Solar Energy Research Institute *
C * 1617 Cole Blvd. *
C * Golden, CO 80401 *
C * (303)231-7651 *
C * *
C *****

C *****

```

C      *                   *
C      * I/O Conventions:   *
C      *                   *
C      *   Unit 2 - Diagnostics file   *
C      *   Unit 3 - Input run data     *
C      *   Unit 4 - Results file       *
C      *   Unit * - Monitor or keyboard *
C      *                   *
C      * *****
C      * *****
C      *   External references in this routine:   *
C      *   *                   *
C      *   *                   *
C      *   *   DATAIN - Reads in a data generated by MODULE 1.   *
C      *   *   DIAG - Performs a test run of the aerodynamic rou- *
C      *   *   tines.                                           *
C      *   *   RUN - Models the rotor blade motion.             *
C      *   *                   *
C      * *****
C      * *****
C      *   Local and dummy variables used in this routine:   *
C      *   *                   *
C      *   *   ANS - Used to store input responses from key- *
C      *   *   board.                                         *
C      *   *   HAVDAT - Flag that indicates that some data has been *
C      *   *   read in.                                       *
C      *   *   HAVRUN - Flag that indicates that the model has been *
C      *   *   run. Used for diagnostic runs.                 *
C      *   *   NEWSET - Flag that indicates that a new data set has *
C      *   *   been read in.                                   *
C      *   *   NPTS - Number of points along the blade used to *
C      *   *   perform Simpson's integration for calculat- *
C      *   *   ing the moments and forces at the blade *
C      *   *   root.                                          *
C      *   *   NSIMP - Order of the composite Simpson's integra- *
C      *   *   tion used in the run. Parameter is set to *
C      *   *   10 in order to make 21 blade property sta- *
C      *   *   tions.                                        *
C      *   *   TODEGS - Logical variable that indicates the direc- *
C      *   *   tion of conversion between degrees and ra- *
C      *   *   dians.                                         *
C      *   *                   *
C      * *****

```

```

INTEGER      NPTS
INTEGER      NSIMP

```

```

INCLUDE      'C:\INCLUDE\TRBINF.INC'

```

```

LOGICAL      HAVDAT
LOGICAL      HAVRUN
LOGICAL      NEWSET
LOGICAL      TODEGS

```

```

CHARACTER*1  ANS

```

```

DATA      HAVDAT / .FALSE. /
DATA      HAVRUN / .FALSE. /
DATA      NSIMP  / 10 /
DATA      TODEGS / .TRUE. /

```

```

100 FORMAT (
& // ' Program For Analysis Of Horizontal Axis Wind Turbine'
& / '           Response To Dynamic Loads'
& // '           MODULE 2' )
110 FORMAT ( / ' Operations Menu'
& / ' -----'
& // ' (R)ead in a data file'
& / ' (S)et up and run the model'
& / ' (D)iagnostic run'
& / ' (T)urbulence analysis'
& / ' (Q)uit' )
120 FORMAT ( / ' Enter Option (R,S,D,T,Q) > ' )
130 FORMAT ( A )
140 FORMAT ( / ' You must select option (R) at least once before'
& / ' invoking this option.' )
150 FORMAT ( / ' You must select option (S) at least once before'
& / ' invoking this option.' )
160 FORMAT ( / ' Invalid response. Please try again.' )
170 FORMAT ( / ' FLAP terminated normally.' / )

```

C Calculate the number of blade property stations.

```
NPTS = 2*NSIMP + 1
```

C Print title.

```
PRINT 100
```

C Print menu of options. Ask for choice.

```
10 PRINT 110
```

```
20 PRINT 120
```

```
READ 130, ANS
```

C Which option was chosen?

```
IF ( ( ANS .EQ. 'R' ) .OR. ( ANS .EQ. 'r' ) ) THEN
```

C Read in a data file. Convert limits values back to degrees
C if this isn't the first time we've read in data.

```

IF ( HAVDAT ) CALL CONVRT ( TODEGS )
CALL DATAIN
HAVDAT = .TRUE.
NEWSET = .TRUE.
GO TO 10

```

```
ELSE IF ( ( ANS .EQ. 'S' ) .OR. ( ANS .EQ. 's' ) ) THEN
```

C Set up and run the model. Option (R) must have been
C previously selected.

```
IF ( HAVDAT ) THEN
  CALL RUN ( NPTS , NEWSET , HAVRUN )
  GO TO 10
ELSE
  PRINT 140
  GO TO 20
END IF
```

ELSE IF ((ANS .EQ. 'D') .OR. (ANS .EQ. 'd')) THEN

C Run diagnostics. Option (S) must have been previously
C selected.

```
IF ( HAVRUN ) THEN
  CALL DIAG ( NPTS )
  GO TO 10
ELSE
  PRINT 150
  GO TO 20
END IF
```

ELSE IF ((ANS .EQ. 'T') .OR. (ANS .EQ. 't')) THEN

C Run turbulence case. Option S must have been
C previously invoked.

```
IF ( HAVRUN ) THEN
  ITURB = 1
  CALL TRBCLC( NPTS )
  GO TO 10
ELSE
  PRINT 150
  GO TO 20
ENDIF
```

ELSE IF ((ANS .NE. 'Q') .AND. (ANS .NE. 'q')) THEN

C Invalid response.

```
PRINT 160
GO TO 20
```

END IF

C Processing complete.

```
PRINT 170
```

```
STOP
END
```

```
BLOCK DATA
```

```

C *****
C *
C * This module is used to initialize the COMMON blocks. *
C *
C *****

C *****
C *
C * Named COMMON blocks used in this routine: *
C *
C * AERO1 - Holds coefficients related to aerodynamic *
C * loads calculations such as ClAlpha, CdZero, *
C * etc. *
C * AIRFRC - Holds values used in aerodynamic calcula- *
C * tions. *
C * BLADE Holds blade property values such as stiff- *
C * ness and mass distributions. *
C * CONST - Turbine and other constants used in load *
C * calculations. *
C * DELTV - Holds turbine inputs for possible future *
C * use. Not currently used. *
C * FORMS - Holds blade deflections. *
C * INV - Holds the inverse of the mass matrix. *
C * LIMITC - Holds values used in the LIMITS routine. *
C * LITERL - Holds data set titles. *
C * LODVAL - Holds values used to compute blade loads. *
C * MATRIX1 - Holds stiffness coefficient matrices. *
C * MATRIX2 - Holds some of the coefficient matrices of *
C * the governing equation of motion. *
C * POSITN - Holds parameters related to blade position *
C * such as PHI, PSI, etc. *
C * SARAYS - Holds new and old values for the general- *
C * ized coordinates. *
C * SHAPE - Holds blade coordinate shape functions. *
C * START - Holds initial blade deflection. *
C * TENSIN - Holds tension components of the stiffness *
C * functions. *
C * TURBN - Holds turbine parameters such as number of *
C * blades, rotor speed, etc. *
C * VINDUC - Holds induced velocity components. *
C * VREL1 - Holds blade section velocity components. *
C * WIND - Holds wind shear and tower shadow parame- *
C * ters. *
C * WNDVEL - Holds values used in wind shear and tower *
C * shadow computations. *
C *
C *****

C *****
C *
C * COMMON variables used in Module 2 of FLAP: *
C *
C * ABAR - Dimensionless form of ALENTN ( ALENTN di- *
C * vided by the rotor radius, RR ). *
C * AINVRS - The inverse CMMASS matrix. *
C * ALENTN - Distance from the tower axis to the rotor *
C * hub. (feet) *
C * ALPHA - The angle from the zero-lift line to the *

```

```

C      *      section-chord line. (Generally negative)      *
C      *      BEGIN2 - Azimuth position corresponding to the beginning of print region 2. (degrees)      *
C      *      BETA0  Blade coning angle. The value is input in degrees and converted to radians. (radians)      *
C      *      (input data)      *
C      *      BLSHNK - Length of blade shank measured from the blade root to the start of the airfoil section. If airfoil begins at the root, then BLSHNK=0. (feet)      *
C      *      BLTIP  - Blade length measured from the blade root to the blade tip. Note - rotor radius is HUBRAD + BLTIP. (feet)      *
C      *      CDZERO - Drag coefficient values at equidistant points along the blade. Derived from ACDZER values. (dimensionless)      *
C      *      CHI   - Rotor pitch angle. Input in degrees and converted to radians. (radians) (input data)      *
C      *      CHORD - Blade chord at equidistant points along the blade. Derived from ACHORD. (feet)      *
C      *      CIFMOM - Integral of DIFMOM.      *
C      *      CKBEND - Bending stiffness matrix.      *
C      *      CKQLOD - Inertial moment stiffening matrix.      *
C      *      CKTCRL - Coriolis stiffening matrix.      *
C      *      CKTGRV - Gravity stiffening matrix.      *
C      *      CKTOMG - Centrifugal stiffening matrix.      *
C      *      CLALFA - Slope of the lift curve at equidistant points along the blade. Derived from ACLALF values. (radians^-1)      *
C      *      CLMAX  - The maximum or stall value of the lift coefficient. Derived from ACLMAX values.      *
C      *      CMBLNC - Coefficient associated with the blade mass imbalance (OFFSET).      *
C      *      CMGRAV - Mass coefficients associated with gravitational loads.      *
C      *      CMMASS - Blade mass matrix. It is also used in the inertia force stiffening term.      *
C      *      CMRIGD - Mass coefficients associated with rigid body motion.      *
C      *      CSUBMA - Pitching moment coefficient.      *
C      *      CTHP   - Cosine of the pitch angle, THETAP.      *
C      *      DAETA  - Differential aerodynamic forces on a blade section in the chordwise direction.      *
C      *      DAZETA - Differential aerodynamic forces on a blade section in the flapwise direction.      *
C      *      DELPSI - Delta-Psi. The amount Psi will change from this step to the next. Used in Euler predictor/corrector routine.      *
C      *      DELTAT The incremental time change from one step to the next in the yaw solution (ITRIM=0).      *
C      *      DELTIM - Integral of DDELTI.      *
C      *      DELTVX - Turbulent wind velocity fluctuations. Not currently in use. (feet/second)      *
C      *      DELTVY - Turbulent wind velocity fluctuations. Not currently in use. (feet/second)      *
C      *      DELTVZ - Turbulent wind velocity fluctuations. Not currently in use. (feet/second)      *
C      *      DRGFRM - Drag coefficient form constant.      *
C      *      DVIND  - The delta-V-induced velocity components.      *

```

```

C      *      Components are of order epsilon.      *
C      *      ECNTFN - Complicated term.            *
C      *      EIAREA - Moment of inertia values at equidistant *
C      *      points along the blade. Derived from *
C      *      AEIARE data values. (Lb-Ft**2)        *
C      *      END2  - Azimuth position corresponding to the end *
C      *      of print region 2. (degrees)          *
C      *      ERROR - Difference between corrected and predicted *
C      *      value of the blade tip displacements in the *
C      *      Euler predictor/corrector routine.    *
C      *      ESUBAC - Distance from the blade elastic axis to the *
C      *      aerodynamic center. Positive towards the *
C      *      leading edge. Derived from AESBAC values. *
C      *      (feet)                                *
C      *      EUERR  - Convergence criterion for computing blade *
C      *      tip deflections via the Euler predictor/ *
C      *      corrector routine. (percent)          *
C      *      FAERO  - Aerodynamic force on the rotor.      *
C      *      GRAV  - Constant of gravitational acceleration as *
C      *      measured at sea level. (feet/second**2) *
C      *      HUBHT - Hub reference height above the ground. *
C      *      (feet)                                *
C      *      HUBRAD - Radius of rotor hub. (feet) (input data) *
C      *      HUBVEL - Wind velocity at rotor hub. Currently *
C      *      equal to Vhub. (feet/second)          *
C      *      IEMASS - Edgewise mass moment of inertia at equidis- *
C      *      tant points along the blade section. Der- *
C      *      ived from AIEMAS values. (10^6 Lb-sec^2) *
C      *      IFMASS - Flapwise mass moment of inertia at equidis- *
C      *      tant points along the blade section. Der- *
C      *      ived from AIFMAS values. (10^6 Lb-sec^2) *
C      *      ITRIM  - Flag indicating run status:      *
C      *      0 - Run to find yawing solution.        *
C      *      1 - Run to find trim solution.          *
C      *      2 - Trim startup run.                  *
C      *      KSHADW - Number of tower shadow peaks within the *
C      *      tower shadow zone. (input data)        *
C      *      MASS  - Blade mass per unit length at equidistant *
C      *      points along the blade. Input in Lbf/ft, *
C      *      via the input variable WEIGHT, and convert- *
C      *      ed to slugs/ft. (slugs/ft) (input data) *
C      *      NBLADS - Number of turbine blades. (input data) *
C      *      NSHAPS - Number of blade shape functions, 4 maximum. *
C      *      (input data)                            *
C      *      NYAW  - Number of rotor revolutions to be run for *
C      *      a yawing solution.                      *
C      *      OFFMAS - Integral of DOFFMS.            *
C      *      OFFSET - Distance from the elastic axis to the mass *
C      *      axes of blade section. Positive towards *
C      *      the leading edge. Derived from AOFFST val- *
C      *      ues. Called E-sub-eta in the formulation. *
C      *      (feet) (input data)                    *
C      *      OMEGA - Rotor speed. Input in RPM and converted to *
C      *      radians/second. (rad/sec) (input data) *
C      *      PHI   - Rotor yaw error angle. Angle between the *
C      *      hub axis and the mean wind. Subscript in- *
C      *      dicates which time derivative.          *
C      *      PHIO  - Rotor yaw reference angle. Measured as the *
C      *      angle between a horizontal reference line *
C      *      passing through the tower axis and the hor- *

```

```

C      *           izontal projection of the line between the *
C      *           tower axis and the rotor hub. Input as de- *
C      *           grees and converted to radians. (radians) *
C      *           (input data) *
C      *   PHIAMP - Amplitude of periodic yaw motion about yaw *
C      *           reference angle. Input as degrees and con- *
C      *           verted to radians. (radians) (input data) *
C      *   PHIOMG - Maximum yaw rate. Used internally to com- *
C      *           pute the yaw period. It can be used to in- *
C      *           put a turbine steady yaw rate. Input as *
C      *           degrees/sec and converted to radians/sec- *
C      *           ond. (radians/sec) (input data) *
C      *   PI      - The constant 3.141592653589793... *
C      *   PRINT1 - Printout interval in print region 1. *
C      *   PRINT2 - Printout interval in print region 2. *
C      *   PSI     - Blade azimuth angle. The zeroth element is *
C      *           the past value of Psi and the first element *
C      *           contains the present value. A value of ze- *
C      *           ro indicates the blade is straight up. *
C      *   PSISHD - Azimuth position of the center line of the *
C      *           tower shadow. When it is 180 degrees, the *
C      *           tower shadow center line is oriented verti- *
C      *           cally downward from the hub. *
C      *   PSIZER - Half angle width of the tower shadow re- *
C      *           gion. (degrees) (input data) *
C      *   RAD2DG - Radians to degrees conversion factor. *
C      *   RHOAIR - Air density. Currently set to sea level. *
C      *           (Lb-sec^2/feet^4 or slugs/feet^3) *
C      *   RR      - Rotor radius (BLTIP+HUBRAD). (feet) *
C      *   RROMGA - A constant used throughout the FLAP code. *
C      *           (RR*OMEGA*PI/30) *
C      *   SO      - Initial static blade deflection at the tip. *
C      *           It is set in subroutine STARTUP. *
C      *   SHAPE - Array containing shape functions evaluated *
C      *           at regular intervals. The second subscript *
C      *           corresponds to Nth spatial derivative. *
C      *   SHERXP - Wind shear power exponent. (input data) *
C      *   SNEW - An array of tip displacement function val- *
C      *           ues for each of the STEPMX stations around *
C      *           the disk. These are the results of the *
C      *           current computation. The zeroth element *
C      *           has the same value as the 360th element of *
C      *           SOLD. *
C      *   SOLD - An array of tip displacement function val- *
C      *           ues for each of the STEPMX stations around *
C      *           the disk. These are the results of the *
C      *           previous computation. The 360th element *
C      *           has the same value as the zeroth element of *
C      *           SNEW. *
C      *   STEPMN - Minimum allowable azimuth angle step size. *
C      *           (degrees) *
C      *   STEPMX - Maximum allowable azimuth angle step size. *
C      *           (degrees) *
C      *   STHP - Sine of the pitch angle THETAP. *
C      *   TCORLS - Blade tension coefficient due to coriolis *
C      *           effects. *
C      *   TGRAV - Blade tension coefficient due to gravity *
C      *           effects. *
C      *   THETA0 - Orientation of the zero lift line with re- *
C      *           spect to the blade principal bending axis. *

```



```

C      *      THETAP - Blade pitch angle. The angle from the flap *
C      *      bending axis (assumed to be the chord line) *
C      *      at the 3/4 spanwise location. The assump- *
C      *      tion has been made that the bending axis *
C      *      does not vary with spanwise location. In *
C      *      effect, THETAP sets the blade pitch angle *
C      *      and the direction of the flapping displace- *
C      *      ments. Input in degrees and converted to *
C      *      radians. (radians) (input data) *
C      *      THETAT - The built-in blade twist angle from the *
C      *      section-chord line at the reference station *
C      *      to the section-chord line at the tip of the *
C      *      rotor. Positive towards feather. *
C      *      TIME - Total elapsed time from the beginning of *
C      *      the yaw solution run. The zeroth element *
C      *      holds the past value of time, and the first *
C      *      element holds the current value. (seconds) *
C      *      TITLE1 - First line of the data file title. *
C      *      TITLE2 - Second line of the data file title. *
C      *      TITLE3 - Third line of the data file title. *
C      *      TOMGA - Blade tension coefficient associated with *
C      *      centrifugal force effects. *
C      *      TRACEF - Flag that causes subroutine TRACE to print *
C      *      the values of various variables around the *
C      *      rotor disk. *
C      *      TRMERR - Convergence criterion for computing the *
C      *      trim solution. (percent) *
C      *      TSHADW - The tower shadow velocity deficit. *
C      *      TSUBO - Tower shadow wind speed offset component. *
C      *      TSUBP - Tower shadow sinusoidal component. *
C      *      VETA - Relative fluid velocity over the blade in *
C      *      the edgewise direction. *
C      *      VHUB - Air speed at the height of the hub. *
C      *      (ft/sec) (input data) *
C      *      VINDO - An induced velocity rotor term. It is uni- *
C      *      form over the rotor disk. *
C      *      VINDC - An induced velocity component associated *
C      *      with the Cosine(Psi) term. *
C      *      VINDR - Inflow minus uniform induced velocity. *
C      *      WV - The actual tip displacements computed from *
*      *      the relation in subroutine FORM1: *
*      *      
$$V = \text{Sum of } S(I)*\text{GAMMA}(I)$$
 *
*      *      and *
*      *      
$$\text{VDOT} = \text{Sum of } \text{SDOT}(I)*\text{GAMMA}(I),$$
 *
*      *      where V is a function of position along the *
*      *      blade and time, S is a function of time and *
*      *      GAMMA is the blade coordinate shape func- *
*      *      tion. The index I denotes summation over *
*      *      the coordinate function shapes, DOT is the *
*      *      first derivative w.r.t. time. Thus: *
*      *      
$$\text{WV}(0,I) = V = \text{displacement}$$
 *
*      *      and 
$$\text{WV}(1,I) = V\text{-DOT} = \text{velocity.}$$
 *
*      *      VWIND - Resultant wind velocity at the rotor disk. *
*      *      VZETA - Relative fluid velocity over the blade in *
*      *      the flapwise direction. *
*      *      WSHEAR - The harmonic or unsteady component of the *
*      *      wind shear. *
*      *      WSHR - Individual harmonic components of the total *
*      *      unsteady wind shear component. *
*      *      WW - Resultant windspeed at a blade element. *

```

```
C      *
C      *****
```

```
INCLUDE      'C:INCLUDE\AERO1.INC'
INCLUDE      'C:INCLUDE\AIRFRC.INC'
INCLUDE      'C:INCLUDE\BLADE2.INC'
INCLUDE      'C:INCLUDE\CONST2.INC'
INCLUDE      'C:INCLUDE\DELT.V.INC'
INCLUDE      'C:INCLUDE\FORMS.INC'
INCLUDE      'C:INCLUDE\INV.INC'
INCLUDE      'C:INCLUDE\LIMITC.INC'
INCLUDE      'C:INCLUDE\LITERL.INC'
INCLUDE      'C:INCLUDE\LODVAL.INC'
INCLUDE      'C:INCLUDE\MATRX1.INC'
INCLUDE      'C:INCLUDE\MATRX2.INC'
INCLUDE      'C:INCLUDE\POSITN.INC'
INCLUDE      'C:INCLUDE\SARAYS.INC'
INCLUDE      'C:INCLUDE\SHAPE.INC'
INCLUDE      'C:INCLUDE\START.INC'
INCLUDE      'C:INCLUDE\TENSIN2.INC'
INCLUDE      'C:INCLUDE\TURBN.INC'
INCLUDE      'C:INCLUDE\VINDUC.INC'
INCLUDE      'C:INCLUDE\VREL1.INC'
INCLUDE      'C:INCLUDE\WIND2.INC'
INCLUDE      'C:INCLUDE\WINDVEL.INC'
```

```
C      Initialize COMMON blocks.
```

```
DATA      BEGIN2 / 180.0 /
DATA      DELPSI / 2* 0.0 /
DATA      DELTAT / 2* 0.0 /
DATA      DELTVX / 21* 0.0 /
DATA      DELTVY / 21* 0.0 /
DATA      DELTVZ / 21* 0.0 /
DATA      END2 / 270.0 /
DATA      EUERR / 10.0 /
DATA      GRAV / 32.1740 /
DATA      KSHADW / 1 /
```

```

DATA      NSHAPS /           /
DATA      NYAW  /           /
DATA      PHI   / 3* 0.0    /
DATA      PHIO  /           /
DATA      PI    / 3.141592653589793 /
DATA      PRINT1 / 10.0     /
DATA      PRINT2 / 10.0     /
DATA      PSI   / 2* 0.0    /
DATA      PSISHD / 180.0    /
DATA      PSIZER / 15.0     /
DATA      RAD2DG / 57.29577951308233 /
DATA      RHOAIR / 0.002    /
DATA      SHERXP / 0.14286  /
DATA      STEPMN / 0.001    /
DATA      STEPMX / 10.0     /
DATA      TIME  / 2* 0.0    /
DATA      TRACEF / .FALSE.  /
DATA      TRMERR / 10.0     /
DATA      TSUBO / 10.0     /
DATA      TSUBP / 10.0     /
DATA      VHUB  / 27.1     /

```

END

SUBROUTINE ACCEL (DEFLTN , VELCTY , ACCELN , NPTS , STEMP)

```

C      *****
C      *
C      * Subroutine ACCEL computes the solution to the blade *
C      * equation of motion. The coefficient matrices are *
C      * available for all four coordinate shape functions, but *
C      * the solution is only calculated for the number of func- *
C      * tions specified by the value of NSHAPS. *
C      *
C      *****
C
C      *****
C      *
C      * External references in this routine: *
C      *
C      *   AFORCE - Calculates the value of the aerodynamic *
C      *             force integral. *
C      *   FORM1  - Calculates the values of the blade dis- *
C      *             placement function. *
C      *
C      *****
C
C      *****
C      *
C      * Named COMMON blocks used in this routine: *
C      *
C      *   AIRFRC - Holds values used in aerodynamic calcula- *
C      *             tions. *
C      *   CONST  - Turbine and other constants used in load *
C      *             calculations. *
C      *   MATRX1 - Holds stiffness coefficient matrices. *
C      *   MATRX2 - Holds some of the coefficient matrices of *
C      *             the governing equation of motion. *
C      *   POSITN - Holds parameters related to blade position *

```

```

C      *      such as PHI, PSI, etc.      *
C      *      TENSIN - Holds tension components of the stiffness *
C      *      functions.                  *
C      *      TURBN  - Holds turbine parameters such as number of *
C      *      blades, rotor speed, etc.   *
C      *      *      *      *      *      *
C      *****

```

```

C      *****
C      *      *      *      *      *      *
C      *      Local and dummy variables used in this routine:  *
C      *      *      *      *      *      *
C      *      AA      - 2.0*Omega*Sine( ThetaP ).                *
C      *      ACCELN - The solution to the equation of motion. It *
C      *      corresponds to the S-double dot value in          *
C      *      the formulation, and is the current solution      *
C      *      for the blade tip acceleration.                    *
C      *      (feet/second^2)                                    *
C      *      BB      - Gravity times cosine of the blade azimuth. *
C      *      BLDANG - Blade azimuth position used in the teeter- *
C      *      ing rotor option.                                  *
C      *      C1      - BetaD*Omega^2.                            *
C      *      C2      - Omega*Phi*Cosine( Psi ).                  *
C      *      C3      - dPhi/dt*Sine( Psi ).                      *
C      *      C4      - -Chi*Cosine( ThetaP ).                   *
C      *      C5      - Sine( ThetaP )*Sine( Psi ).              *
C      *      C6      - Beta0*Cosine( ThetaP )*Cosine( Psi ).   *
C      *      C7      - Omega^2.                                  *
C      *      CC      - QUANT1^2.                                  *
C      *      CPSI   - Cosine of the blade angle.                *
C      *      DD      - Complicated term.                        *
C      *      DEFLTN - The current value of the tip deflection, *
C      *      corresponding to the S variable in the formu-     *
C      *      lation of the equation of motion.                  *
C      *      EE      - QUANT1^2.                                  *
C      *      FF      - Omega*QUANT1*Cosine( ThetaP )            *
C      *      GG      - Complicated term.                        *
C      *      K       - Generic DO index.                        *
C      *      M       - Generic DO index.                        *
C      *      N       - Generic DO index.                        *
C      *      NPTS   - Number of points along the blade used to *
C      *      perform Simpson's integration for calculat-       *
C      *      ing the moments and forces at the blade          *
C      *      root. (passed from FLAP1)                          *
C      *      P1      - Array used in computing acceleration.    *
C      *      P2      - Array used in computing acceleration.    *
C      *      P3      - Array used in computing acceleration.    *
C      *      Q       - Matrix used in computing acceleration.   *
C      *      QUANT1 - Omega*Sine( ThetaP ).                      *
C      *      SPSI   - Sine of the blade angle.                  *
C      *      STEMP  - Temporary array holding the tip displace- *
C      *      ment values. The third dimension repre-          *
C      *      sents the order of the time derivative.           *
C      *      VELCTY - The tip velocity corresponding to the S-dot *
C      *      value in the formulation of the equation of      *
C      *      motion.                                           *
C      *      *      *      *      *      *
C      *****

```

```

REAL      AA
REAL      ACCELN (4)
REAL      BB
REAL      BLDANG
REAL      C7
REAL      CC
REAL      CPSI
REAL      DD
REAL      DEFLTN (4)
REAL      EE
REAL      FF
REAL      GG
REAL      P1   (4)
REAL      P2   (4)
REAL      P3   (4)
REAL      Q    (4,4)
REAL      QUANT1
REAL      SPSI
REAL      STEMP (4,0:1,0:2)
REAL      VELCTY (4)

```

```

INTEGER   K
INTEGER   M
INTEGER   N
INTEGER   NPTS

```

```
INCLUDE 'C:\INCLUDE\AIRFRC.INC'
```

```
INCLUDE 'C:\INCLUDE\CONST2.INC'
```

```
INCLUDE 'C:\INCLUDE\MATRX1.INC'
```

```
INCLUDE 'C:\INCLUDE\MATRX2.INC'
```

```
INCLUDE 'C:\INCLUDE\POSITN.INC'
```

```
INCLUDE 'C:\INCLUDE\TURBN.INC'
```

```
BLDANG = PSI(1)
```

```
CALL FORM1 ( STEMP , NPTS , NSHAPS )
```

```
CALL AFORCE ( NPTS , BLDANG )
```

C Calculate constant coefficients.

```

SPSI = SIN( BLDANG )
CPSI = COS( BLDANG )
QUANT1 = OMEGA*STHP
AA = 2.0*QUANT1
BB = GRAV*CPSI
CC = QUANT1*QUANT1
DD = CTHP*( OMEGA*OMEGA*BETA0 + 2.0*OMEGA*PHI(1)*CPSI
&          + PHI(2)*SPSI )
EE = CC
FF = OMEGA*QUANT1*CTHP

```

```

GG      = GRAV*( -1.0*CHI*CTHP + STHP*SPSI + BETAO*CTHP*CPSI )
C7      = OMEGA*OMEGA

```

C Compute P1 (see formulation notes).

```

DO 10 M=1,NSHAPS
10  P1(M) = FAERO(M) + FF*CMBLNC(M) + GG*CMGRAV(M) - DD*CMRIGD(M)

```

C Compute P2 - S(M) product (see formulation notes).

```

DO 20 M = 1, NSHAPS
20  P2(M) = EE*DEFLT(M)

```

C Compute Q(M,K) - S(K) products (see formulation notes).

```

DO 50 M=1,NSHAPS

```

```

P3(M) = 0.0

```

```

DO 40 K=1,NSHAPS

```

```

&      Q(M,K) = CC*CKQLOD(M,K) - CKBEND(M,K)
&      - C7*CKTOMG(M,K) + BB*CKTGRV(M,K)

```

```

DO 30 N=1,NSHAPS

```

```

30  Q(M,K) = Q(M,K) - AA*VELCTY(N)*CKTCRL(N,M,K)

```

```

P3(M) = P3(M) + Q(M,K)*DEFLT(K)

```

```

40  CONTINUE

```

```

50  CONTINUE

```

C Compute new value for tip acceleration.

```

DO 60 M=1,NSHAPS
60  ACCELN(M) = P1(M) + P2(M) + P3(M)

```

```

RETURN

```

```

END

```

```

SUBROUTINE AERO ( NPTS , BLDANG )

```

```

C      *****
C      *
C      * Subroutine AERO computes the aerodynamic forces on the *
C      * blade as a function of position along the blade. The *
C      * result is an array of values for D-A(ETA) and D-A(ZETA) *
C      * for each NPTS station down the blade. *
C      *
C      *
C      *****

```

```

C      *****
C      *
C      *

```

```

C      * External references in this routine:      *
C      *                                           *
C      *   VREL  - Calculates the relative velocity components *
C      *             for each blade station.         *
C      *                                           *
C      ******
C
C      ******
C      * Named COMMON blocks used in this routine: *
C      *                                           *
C      *   AERO1 - Holds coefficients related to aerodynamic *
C      *             loads calculations such as ClAlpha, CdZero, *
C      *             etc.                                     *
C      *   AIRFRC - Holds values used in aerodynamic calcula- *
C      *             tions.                                  *
C      *   BLADE  Holds blade property values such as stiff- *
C      *             ness and mass distributions.           *
C      *   CONST  -- Turbine and other constants used in load *
C      *             calculations.                          *
C      *   TURBN  - Holds turbine parameters such as number of *
C      *             blades, rotor speed, etc.             *
C      *   VREL1  - Holds blade section velocity components. *
C      *                                           *
C      ******
C
C      ******
C      * Local and dummy variables used in this routine: *
C      *                                           *
C      *   ALPHA - Angle of attack. Includes blade twist con- *
C      *             tribution. (radians)                 *
C      *   BLDANG - Blade azimuth position.                *
C      *   CD2   - 0.5*AirDensity*ChordLength.            *
C      *   CDLAG - Drag coefficient.                      *
C      *   CLIFT - Coefficient of lift. Equal to angle of at- *
C      *             tack times the lift curve slope.      *
C      *   I     - Generic index.                         *
C      *   INBORD - The number of blade stations that are not *
C      *             on the airfoil section. INBORD is used in *
C      *             other routines to differentiate between *
C      *             sections of the blade with and without an *
C      *             airfoil section.                      *
C      *   NPTS  - Number of points along the blade used to *
C      *             perform Simpson's integration for calculat- *
C      *             ing the moments and forces at the blade *
C      *             root. (passed from FLAP1)             *
C      *                                           *
C      ******

```

```

REAL      ALPHA
REAL      BLDANG
REAL      CD2
REAL      CDLAG
REAL      CLIFT

```

```

INTEGER   I
INTEGER   INBORD
INTEGER   NPTS

```

```

INCLUDE      'C:INCLUDE\AERO1.INC'
INCLUDE      'C:INCLUDE\AIRFRC.INC'
INCLUDE      'C:INCLUDE\BLADE2.INC'
INCLUDE      'C:INCLUDE\CONST2.INC'
INCLUDE      'C:INCLUDE\TURBN.INC'
INCLUDE      'C:INCLUDE\VREL1.INC'

```

C Get the relative fluid velocities from each blade section.

```
CALL VREL ( INBORD , NPTS , BLDANG )
```

C Clear out the aerodynamic load values for the inboard portion
C of the blade - that is, the portion of the blade without any
C airfoil section. This is related to BLSHNK.

```
DO 10 I=1,NPTS
```

```
  IF ( I .LT. INBORD ) THEN
```

```
    DAETA(I) = 0.0
    DAZETA(I) = 0.0
    WW(I)    = 0.0
```

```
  ELSE
```

C See the formulation notes for the derivation of the
C equations for DAETA, DAZETA and the other values.

```

CD2      = 0.5*RHOAIR*CHORD(I)
WW(I)    = SQRT( VETA(I)*VETA(I) + VZETA(I)*VZETA(I) )
ALPHA    = ATAN( VZETA(I)/VETA(I) ) + THETA0(I)
CLIFT    = ALPHA*CLALFA(I)
CLIFT    = SIGN( AMIN1( ABS( CLIFT ) , CLMAX(I) ) , CLIFT )
CDRAG    = CDZERO(I) + DRGFRM*CLIFT**2
DAETA(I) = CD2*WW(I)*( CLIFT*VZETA(I) - CDRAG*VETA(I) )
DAZETA(I)= CD2*WW(I)*( CLIFT*VETA(I) + CDRAG*VZETA(I) )

```

```
  END IF
```

```
10 CONTINUE
```

```
RETURN
```

```
END
```

```
SUBROUTINE AFORCE ( NPTS , BLDANG )
```

```

C        *****
C        *
C        * Subroutine AFORCE calculates the value of the aerody- *

```



```

C      * namic force integral used in solving the blade equation *
C      * of motion. The aerodynamic force, D-A(ZETA), is inte- *
C      * grated along the blade from the root of the airfoil *
C      * section to the blade tip, and then multiplied by the *
C      * inverse of the CMMASS matrix that was input in the *
C      * DATAIN routine. There is one AFORCE value for each of *
C      * the coordinate shape functions specified by the value *
C      * of NSHAPS. *
C      * *
C      *****

```

```

C      *****
C      * *
C      * External references in this routine: *
C      * *
C      * AERO - Calculates the aerodynamic forces on the *
C      * blade. *
C      * SIMPSN - Composite Simpson's integration. *
C      * *
C      *****

```

```

C      *****
C      * *
C      * Named COMMON blocks used in this routine: *
C      * *
C      * AIRFRC - Holds values used in aerodynamic calcula- *
C      * tions. *
C      * BLADE - Holds blade property values such as stiff- *
C      * ness and mass distributions. *
C      * MATRX1 - Holds stiffness coefficient matrices. *
C      * TURBN - Holds turbine parameters such as number of *
C      * blades, rotor speed, etc. *
C      * *
C      *****

```

```

C      *****
C      * *
C      * Local and dummy variables used in this routine: *
C      * *
C      * BLDANG - Blade azimuth position. *
C      * FOFZET - Product of the dA(Zeta) and the shape *
C      * function. *
C      * FTEMP - Temporary array. *
C      * I - Generic index. *
C      * L - Generic index. *
C      * M - Generic index. *
C      * NPTS - Number of points along the blade used to *
C      * perform Simpson's integration for calculat- *
C      * ing the moments and forces at the blade *
C      * root. (passed from FLAP1) *
C      * *
C      *****

```

```

REAL      BLDANG
REAL      FOFZET (21)
REAL      FTEMP (4)
REAL      SIMPSN

```

```

INTEGER   I

```

```

INTEGER      L
INTEGER      M
INTEGER      NPTS

INCLUDE      'C:INCLUDE\AIRFRG.INC'

INCLUDE      'C:INCLUDE\BLADE2.INC'

INCLUDE      'C:INCLUDE\MATRX1.INC'

INCLUDE      'C:INCLUDE\SHAPE.INC'

INCLUDE      'C:INCLUDE\TURBN.INC'

C           Compute aerodynamic forces.

CALL AERO ( NPTS , BLDANG )

C           Compute the product of the DAZETA value and the shape
C           function at each blade station for each specified shape
C           function.

DO 20 M=1,NSHAPS

    DO 10 I=1,NPTS
10    FOFZET(I) = DAZETA(I)*SHAPE(M,0,I)

C           Compute the integral of dF(Aero) along the blade.

FAERO(M) = SIMPSN( 0.0 , BLTIP , NPTS , FOFZET )

20 CONTINUE

C           Multiply the F-AERO integrals by the inverse of the CMMASS
C           coefficient matrix. This is done for the specified number
C           of shape functions.

DO 50 M=1,NSHAPS

    FTEMP(M) = 0.0

    DO 40 L=1,NSHAPS
40    FTEMP(M) = FTEMP(M) + CMMASS(M,L)*FAERO(L)

50 CONTINUE

C           Replace the F-AERO values by their corresponding values
C           multiplied by the CMMASS inverse coefficient matrix.

DO 60 M=1,NSHAPS
60 FAERO(M) = FTEMP(M)

```

```

RETURN
END
SUBROUTINE CAPS ( STRING )

```

```

C *****
C *
C * Subroutine CAPS is used to convert alphabetic charac- *
C * ters into upper case. It assumes that all the lower *
C * case letters are in one contiguous block and all the *
C * upper case letters are in another contiguous block. *
C * This routine will need to be changed to work with a *
C * noncontiguous character set like IBM's EBCDIC. It is *
C * not needed for an upper case only character set like *
C * CDC's Display Code. *
C *
C *****

```

```

C *****
C *
C * 'Named COMMON blocks used in this routine: *
C *
C * none *
C *
C *****

```

```

C *****
C *
C * External references in this routine: *
C *
C * none *
C *
C *****

```

```

C *****
C *
C * Local and dummy variables used in this routine: *
C *
C * DIFF - Numerical difference between 'A' and 'a'. *
C * I - Generic index. *
C * LENGTH - The declared length of the given string. *
C * STRING - The string needing to be converted to upper *
C * case. *
C *
C *****

```

```

INTEGER DIFF
INTEGER I
INTEGER LENGTH

CHARACTER*(*) STRING

```

```

C Compute the numerical difference between 'A' and 'a'.

```

```

DIFF = ICHAR( 'a' ) - ICHAR( 'A' )

```

```

C Get the length of the string.

```

```

LENGTH = LEN( STRING )

C   Look for lower case letters.  Convert them to upper case.

DO 100 I=1,LENGTH

    IF ( ( STRING(I:I) .GE. 'a' ) .AND.
&      ( STRING(I:I) .LE. 'z' ) ) THEN

        STRING(I:I) = CHAR( ICHAR( STRING(I:I) ) - DIFF )

    END IF

100 CONTINUE

RETURN
END
SUBROUTINE CONVRT ( TODEGS )

C   *****
C   *
C   * Subroutine CONVRT performs the units conversion speci- *
C   * fied by the logical value of TODEGS.  The calling rou- *
C   * tine sends a value of .TRUE. to indicate conversion to *
C   * degrees or .FALSE. to indicate conversion to radians. *
C   * This conversion back and forth between radians and de- *
C   * grees is to make the interactive portions of the SETUP *
C   * and LIMITS routines more 'User Friendly'. *
C   *
C   *****

C   *****
C   *
C   * External references in this routine: *
C   *
C   *   none *
C   *
C   *****

C   *****
C   *
C   * Named COMMON blocks used in this routine: *
C   *
C   *   CONST - Turbine and other constants used in load *
C   *           calculations. *
C   *   LIMITC - Holds values used in the LIMITS routine. *
C   *   TURBN - Holds turbine parameters such as number of *
C   *           blades, rotor speed, etc. *
C   *   WIND - Holds wind shear and tower shadow parame- *
C   *          ters. *
C   *
C   *****

C   *****
C   *
C   * Local and dummy variables used in this routine: *

```

```

C      *           *
C      *   FACT1 - Conversion factor.           *
C      *   FACT2 - Conversion factor.           *
C      *   TODEGS - Logical variable that indicates the direc- *
C      *               tion of conversion between degrees and ra- *
C      *               dians.                               *
C      *           *
C      *           *
C      *           *
C      *           *
C      *           *
C      *           *
C      *****

```

```

REAL      FACT1
REAL      FACT2

LOGICAL   TODEGS

INCLUDE   'C:\INCLUDE\CONST2.INC'

INCLUDE   'C:\INCLUDE\LIMITC.INC'

INCLUDE   'C:\INCLUDE\TURBN.INC'

INCLUDE   'C:\INCLUDE\WIND2.INC'

```

```

C      For all calls to this routine, set the conversion factors
C      specific to the unit conversion required. Then perform the
C      conversions and return to calling routine.

```

```

IF ( TODEGS ) THEN

```

```

C      Convert from radians and radians/second to degrees and RPM.

```

```

FACT1 = RAD2DG
FACT2 = 30.0/PI

```

```

ELSE

```

```

C      Convert from degrees and RPM to radians and radians/second.

```

```

FACT1 = 1.0/RAD2DG
FACT2 = PI/30.0

```

```

END IF

```

```

C      Convert 'free' variables from the SETUP routine.

```

```

BETA0 = FACT1*BETA0
ALPHA0 = FACT1*ALPHA0
CHI = FACT1*CHI
PHIAMP = FACT1*PHIAMP
PHIOMG = FACT1*PHIOMG
PHIO = FACT1*PHIO
PSISHD = FACT1*PSISHD
PSIZER = FACT1*PSIZER
THETAP = FACT1*THETAP
THETAT = FACT1*THETAT

```

OMEGA = FACT2*OMEGA

C Convert 'limits' variables from the LIMITS routine.

BEGIN2 = FACT1*BEGIN2
END2 = FACT1*END2
PRINT1 = FACT1*PRINT1
PRINT2 = FACT1*PRINT2
STEPMX = FACT1*STEPMX
STEPMN = FACT1*STEPMN

RETURN
END
SUBROUTINE DATAIN

C *****
C * *
C * Subroutine DATAIN reads the data file produced by the *
C * PRNCOE routine of Module 1. The name of the run-data *
C * file is specified interactively. DATAIN opens the spe- *
C * cified file, reads the data and then closes the file. *
C * *
C * Note: If any changes have been made to the format of *
C * the run-data file in PRNCOE of Module 1, then the *
C * same changes MUST be made to DATAIN. *
C * *
C *****

C *****
C * *
C * External references in this routine: *
C * *
C * CONVRT - Performs units conversions. *
C * *
C *****

C *****
C * *
C * Named COMMON blocks used in this routine: *
C * *
C * AERO1 - Holds coefficients related to aerodynamic *
C * loads calculations such as ClAlpha, CdZero, *
C * etc. *
C * BLADE - Holds blade property values such as stiff- *
C * ness and mass distributions. *
C * *
C * LITERL - Holds data set titles. *
C * LODVAL - Holds values used to compute blade loads. *
C * MATRX1 - Holds stiffness coefficient matrices. *
C * MATRX2 - Holds other matrices related to coriolis *
C * stiffening, gravity, etc. *
C * *
C * TENSIN - Holds tension component integrals. *
C * TURBN - Holds turbine parameters such as number of *
C * blades, rotor speed, etc. *
C * *
C * WIND - Holds wind shear and tower shadow parame- *
C * ters. *
C * *

```

C *****
C *****
C *
C * Local and dummy variables used in this routine: *
C *
C * COL - Column index into matrices. *
C * I - Generic index. *
C * N - Generic index. *
C * NPTS - Number of points along the blade used to *
C * perform Simpson's integration for calculat- *
C * ing the moments and forces at the blade *
C * root. (passed from FLAP1) *
C * ROW - Row index into matrices. *
C * RUNDAT - Name of file containing run data. *
C * TORADS - Flag used to tell CONVRT to convert 'free' *
C * variables to radians. *
C *
C *****

```

```

INTEGER COL
INTEGER I
INTEGER N
INTEGER NPTS
INTEGER ROW

CHARACTER*50 RUNDAT

LOGICAL TORADS

INCLUDE 'C:INCLUDE\AERO1.INC'
INCLUDE 'C:INCLUDE\BLADE2.INC'
INCLUDE 'C:INCLUDE\LITERL.INC'
INCLUDE 'C:INCLUDE\LODVAL.INC'
INCLUDE 'C:INCLUDE\MATRX1.INC'
INCLUDE 'C:INCLUDE\MATRX2.INC'
INCLUDE 'C:INCLUDE\TENSIN2.INC'
INCLUDE 'C:INCLUDE\TRBINF.INC'
INCLUDE 'C:INCLUDE\TURBN.INC'
INCLUDE 'C:INCLUDE\WINO2.INC'
INCLUDE 'C:INCLUDE\MODAL.INC'

SAVE TORADS

DATA TORADS / .FALSE. /

```

```

2000 FORMAT ( 3( A / ) / )
2100 FORMAT ( 9X , L7 )
3000 FORMAT ( // 3( 1PE24.7 ) )

```

```

3100 FORMAT ( // I14 , 3( I18 ) )
3400 FORMAT ( / 18X, 16)
3500 FORMAT ( / 18X, F10.5)
3600 FORMAT ( / 18X, I3)
3700 FORMAT ( / 2( / 5( 1PE14.3 , : ) ) )
4000 FORMAT ( / 6( / 4( 1PE18.7 , : ) ) )
4100 FORMAT ( '&done.' )

```

C Get name of run-data file. Open it.

```

100 PRINT *, ' '
    PRINT *, 'Enter the name of the file that contains run-data > '
    READ (*,'(A)') RUNDAT

    OPEN ( 3 , FILE=RUNDAT , STATUS='OLD' , ERR=110 )

    PRINT *, 'Reading in new data...'

    GO TO 200

```

C Error opening data file.

```

110 PRINT *, ' >>> Run-data file not found. Try again. <<<'
    GO TO 100

```

C Read titles .

```

200 READ (3,2000) TITLE1 , TITLE2 , TITLE3

```

C Read scalar data.

```

READ (3,3000) ALENTH , ALPHA0 , BETA0
READ (3,3000) BLSHNK , BLTIP , CHI
READ (3,3000) CSUBMA , DRGFRM , HUBHT
READ (3,3000) HUBRAD , OMEGA , PHIO
READ (3,3000) PHIAMP , PHICMG , PSIZER
READ (3,3000) SHERXP , THETAP , THETAT
READ (3,3000) TSUBO , TSUBP , VHUB
READ (3,3100) KSHADW , NBLADS , NSHAPS , NPTS
READ (3,3400) NUMSCN
READ (3,3500) TIMINC
READ (3,3600) MSTAT
READ (3,3700) ( STA(I), I=1,MSTAT)

```

C Read in vector values.

```

READ (3,4000) ( CLALFA(I) , I=1,NPTS )
READ (3,4000) ( CLMAX ( I) , I=1,NPTS )
READ (3,4000) ( CDZERO(I) , I=1,NPTS )
READ (3,4000) ( CHORD ( I) , I=1,NPTS )
READ (3,4000) ( ECNTFN(I) , I=1,NPTS )
READ (3,4000) ( ESUBAC(I) , I=1,NPTS )
READ (3,4000) ( THETA0(I) , I=1,NPTS )

```


C Read in coefficient matrices.

```
READ (3,4000) ( ( CKBEND(ROW,COL) , COL=1,4 ) , ROW=1,4 )
READ (3,4000) ( ( CKTOMG(ROW,COL) , COL=1,4 ) , ROW=1,4 )
READ (3,4000) ( ( CKTGRV(ROW,COL) , COL=1,4 ) , ROW=1,4 )
READ (3,4000) ( ( CKQLD(ROW,COL) , COL=1,4 ) , ROW=1,4 )
READ (3,4000) ( ( CMMASS(ROW,COL) , COL=1,4 ) , ROW=1,4 )
```

```
DO 300 N=1,4
```

```
300 READ (3,4000) ( ( CKTCRL(N,ROW,COL) , COL=1,4 ) , ROW=1,4 )
```

C Read in vector coefficients.

```
READ (3,4000) ( CMRIGD(I) , I=1,4 )
READ (3,4000) ( CMBLNC(I) , I=1,4 )
READ (3,4000) ( CMGRAV(I) , I=1,4 )
```

C Read tension arrays.

```
DO 400 N=1,4
```

```
400 READ (3,4000) ( TCORLS(N,I) , I=1,NPTS )
```

```
READ (3,4000) ( TGRAV(I) , I=1,NPTS )
```

```
READ (3,4000) ( TOMGA(I) , I=1,NPTS )
```

```
DO 410 N=1,4
```

```
410 READ (3,4000) ( CIFMOM(N,I) , I=1,NPTS )
```

C Read arrays of special load computation functions.

```
READ (3,4000) ( DELTIM(I) , I=1,NPTS )
```

```
READ (3,4000) ( OFFMAS(I) , I=1,NPTS )
```

```
DO 500 I = 1,4
```

```
READ(3,*) (LAMDA(I,J),J=1,4)
```

```
510 CONTINUE
```

```
500 CONTINUE
```

C Processing complete. Close data file.

```
PRINT 4100
```

```
CLOSE ( 3 )
```

C The units are converted to radians and radians/second to permit
C compatibility between newly input data and data being used for
C consecutive model runs. Thus the DIAG and RUN routines do not
C need to know if the data they are using is new or old.

```
CALL CONVRT ( TORADS )
```

```
RETURN
```

```
END
```

```
SUBROUTINE DIAG ( NPTS )
```

```

C *****
C *
C * Subroutine DIAG performs a test run of the aerodynamic *
C * routines for diagnostic purposes. It steps around the *
C * rotor disk in specified increments and calculates the *
C * aerodynamic forces along the blade, the relative veloc- *
C * ity components, the induced velocity components and the *
C * windspeeds. These are printed out in chart form for *
C * each specified azimuth printout interval around the *
C * disk. DIAG can be run repetitively for sensitivity *
C * analyses. *
C *
C * The following parameters are printed for each of the *
C * specified positions around the disk: *
C *
C *      DAETA      DAZETA      VETA      VZETA      VWIND *
C *      WSHEAR    VINDR      VINDO    DVIND      ALPHA *
C *      CDZERO    CLLIFT      WV *
C *
C *****

C *****
C *
C * External references in this routine: *
C *
C *      AERO - Calculates the aerodynamic forces on the *
C *            blade. *
C *      CONVRT - Performs units conversions. *
C *      SETUP - Interactive modification of free variables. *
C *
C *****

C *****
C *
C * Named COMMON blocks used in this routine: *
C *
C *      AERO1 - Holds coefficients related to aerodynamic *
C *            loads calculations such as ClAlpha, CdZero, *
C *            etc. *
C *      AIRFRC - Holds values used in aerodynamic calcula- *
C *            tions. *
C *      BLADE - Holds blade property values such as stiff- *
C *            ness and mass distributions. *
C *      CONST - Turbine and other constants used in load *
C *            calculations. *
C *      DELTV - Holds turbine inputs for possible future *
C *            use. Not currently used. *
C *      FORMS - Holds blade deflections. *
C *      POSITN - Holds parameters related to blade position *
C *            such as PHI, PSI, etc. *
C *      SARAYS - Holds new and old values for the general- *
C *            ized coordinates. *
C *      SHAPE - Holds blade coordinate shape functions. *
C *      TURBN - Holds turbine parameters such as number of *
C *            blades, rotor speed, etc. *
C *      VINDUC - Holds induced velocity components. *
C *      VREL1 - Holds blade section velocity components. *
C *      WNDVEL - Holds values used in wind shear and tower *
C *            shadow computations. *
C *
C *****

```

```

C *****
C *****
C *
C * Local and dummy variables used in this routine: *
C *
C * ALPHA - Angle of attack. Includes blade twist con- *
C * tribution. (radians) *
C * ANS - Used to store input responses from key- *
C * board. *
C * BLDANG - Blade azimuth position. *
C * CLLIFT - Coefficient of lift. Equal to angle of at- *
C * tack times the lift curve slope. *
C * I - Generic index. *
C * ICALL - Counter to save the number of calls to sub- *
C * routine DIAG. Used to open output file. *
C * IDPSI - Printout interval in whole degrees around *
C * the rotor disk. *
C * IPSI - Do loop counter for azimuth position. *
C * IPT - Array index used for trapezoidal integra- *
C * tion. *
C * NPTS - Number of points along the blade used to *
C * perform Simpson's integration for calculat- *
C * ing the moments and forces at the blade *
C * root. (passed from FLAP1) *
C * NSHP - Counter on DO loops for the coordinate *
C * shape function. *
C * TODEGS - Flag used to tell CONVRT to convert 'free' *
C * variables to degrees. *
C * TORADS - Flag used to tell CONVRT to convert 'free' *
C * variables to radians. *
C *
C *****

```

```

REAL      ALPHA (21)
REAL      BLDANG
REAL      CLLIFT (21)

INTEGER   I
INTEGER   ICALL
INTEGER   IDPSI
INTEGER   IPSI
INTEGER   IPT
INTEGER   NPTS
INTEGER   NSHP

CHARACTER*1 ANS

LOGICAL   TODEGS
LOGICAL   TORADS

INCLUDE   'C:INCLUDE\AERO1.INC'

INCLUDE   'C:INCLUDE\AIRFRC.INC'

INCLUDE   'C:INCLUDE\BLADE2.INC'

INCLUDE   'C:INCLUDE\CONST2.INC'

```

```

INCLUDE      'C:INCLUDE\DELTV.INC'

INCLUDE      'C:INCLUDE\FORMS.INC'

INCLUDE      'C:INCLUDE\POSITN.INC'

INCLUDE      'C:INCLUDE\SARAYS.INC'

INCLUDE      'C:INCLUDE\SHAPE.INC'

INCLUDE      'C:INCLUDE\TURBN.INC'

INCLUDE      'C:INCLUDE\VINDUC.INC'

INCLUDE      'C:INCLUDE\VREL1.INC'

INCLUDE      'C:INCLUDE\WINDVEL.INC'

SAVE         ICALL
SAVE         TODEGS
SAVE         TORADS

DATA         ICALL / 0 /
DATA         TODEGS / .TRUE. /
DATA         TORADS / .FALSE. /

```

```
CHARACTER *20 WRTAIR
```

```

1000 FORMAT ( '1' /// 10X , 'Test Run of Aerodynamic Routines' /// )
2000 FORMAT ( /// 10X , 'Azimuth position: PSI = ' , I3
&           , 10X , 'Hub velocity = ' , F10.3
&           / 48X , 'TSHADW = ' , F10.3 )
2100 FORMAT ( /// ' I DAETA(I) DAZETA(I) VETA(I) VZETA(I)'
&           , ' VWIND(I) WSHEAR(I) VINDR(I) VINDO(I)'
&           , ' DVIND(I) ALPHA(I) CDZERO(I)
&           , ' CLLIFT(I) VV(1,I)' / )
2200 FORMAT ( I4 , 13( 1PE10.3 ) )
3000 FORMAT ( A )

```

C If this is the first time DIAG is called, open the output file.

```

100 IF ( ICALL .EQ. 0 ) THEN
   OPEN ( 2 , FILE='DIAGNOS.DAT' , STATUS='UNKNOWN'
&       , CARRIAGECONTROL='FORTRAN' )
   ICALL = 1
END IF

PRINT *, 'Read in name of airloads output file'
READ*, WRTAIR
OPEN( 20, FILE = WRTAIR, STATUS = 'UNKNOWN')

```

C Print heading in diagnostic file.

```

WRITE (2,1000)

PRINT *, ' '
PRINT *, 'Subroutine DIAG: Diagnostic run and output'
PRINT *, ' '

```

```

C      Convert values into degrees.

      CALL CONVRT ( TODEGS )

C      Run setup routine.

      CALL SETUP

C      Convert values back into radians for internal use.

      CALL CONVRT ( TORADS )

C      Ask for printout interval.

      PRINT *, ' '
      PRINT *, 'Enter printout interval around rotor disk in whole '
&      , 'degrees > '
      READ *, IDPSI

      DELPSI(1) = IDPSI/RAD2DG
      DELTAT(1) = DELPSI(1)/OMEGA

C      NOTE: DIAG assumes that time is frozen at time=0.

      PHI(0) = PHI0
      PHI(1) = PHIOMG
      PHI(2) = 0.0

C      Go around the disk in IDPSI increments.

      DO 250 IPSI=0,360,IDPSI

C      Clear the forms array.

      DO 200 I=1,NPTS
         VV(0,I) = 0.0
         VV(1,I) = 0.0
200    CONTINUE

      PSI(1) = IPSI/RAD2DG
      BLDANG = PSI(1)

C      Set up the forms array.

      DO 220 IPT=1,NPTS

         DO 210 NSHP=1,NSHAPS

            VV(0,IPT) = VV(0,IPT)
&            + SHAPE(NSHP,0,IPT)*SNEW(NSHP,0,IPSI)
            VV(1,IPT) = VV(1,IPT)
&            + SHAPE(NSHP,0,IPT)*SNEW(NSHP,1,IPSI)

```

```

210     CONTINUE

220     CONTINUE

C         Compute the aerodynamic forces on the blade.

        CALL AERO ( NPTS , BLDANG )

        DO 230 I=1,NPTS

            IF ( DAETA(I) .EQ. 0.0 ) THEN
                ALPHA(I) = 0.0
            ELSE
                ALPHA(I) = ATAN( VZETA(I)/VETA(I) ) + THETA0(I)
            END IF

            CLLIFT(I) = AMIN1( CLALFA(I)*ABS( ALPHA(I) ) , CLMAX(I) )
            CLLIFT(I) = SIGN( CLLIFT(I) , ALPHA(I) )

230     CONTINUE

C         Print out results.

        WRITE (2,2000) IPSI , HUBVEL , TSHADW

        WRITE (2,2100)

        DO 240 I=1,21
240     WRITE (2,2200) I, DAETA(I), DAZETA(I), VETA(I), VZETA(I)
        &           , VWIND(I), WSHEAR(I), VINDR(I), VINDO(I)
        &           , DVIND(I), ALPHA(I), CDZERO(I), CLLIFT(I)
        &           , VV(1,I)

        WRITE(20,*) IPSI, VZETA(17)/12.

250     CONTINUE

C         Test run completed. See if user wants more.

        PRINT *, ' '
        PRINT *, 'Test run completed. Results written onto file '
        &       , 'DIAGNOS.DAT'

300     PRINT *, ' '
        PRINT *, 'Do you want to perform another test run? (Y,=N) > '
        READ 3000, ANS

        IF ( ( ANS .EQ. 'Y' ) .OR. ( ANS .EQ. 'y' ) ) GO TO 100

        IF ( ( ANS .NE. 'N' ) .AND. ( ANS .NE. 'n' )
        &       .AND. ( ANS .NE. ' ' ) ) THEN

            PRINT *, ' >>> Invalid response. Please try again. <<<'
            GO TO 300

```

END IF

RETURN

END

SUBROUTINE DSKREV (NPTS)

```
C *****
C *
C * Subroutine DSMREV performs a full disk revolution solu- *
C * tion to the blade equations of motion and saves the re- *
C * sulting values. *
C *
C *****

C *****
C *
C * External references in this routine: *
C *
C * EULER - Self starting modified Euler predictor/cor- *
C * rector integration. *
C * NXXPHI - Calculates the next values of the yaw vari- *
C * ables. *
C * NXXPSI - Calculates the next value of the azimuth *
C * angle, Psi. *
C * SAVE1 - Saves tip displacement variables. *
C * STRTUP - Calculates the static deflection of the *
C * blade at the startup position. *
C * TRACE - Traces certain variables. *
C *
C *****

C *****
C *
C * Named COMMON blocks used in this routine: *
C *
C * CONST - Turbine and other constants used in load *
C * calculations. *
C * LIMITC - Holds values used in the LIMITS routine. *
C * POSITN - Holds parameters related to blade position *
C * such as PHI, PSI, etc. *
C * SARAYS - Holds new and old values for the general- *
C * ized coordinates. *
C * TURBN - Holds turbine parameters such as number of *
C * blades, rotor speed, etc. *
C *
C *****

C *****
C *
C * Local and dummy variables used in this routine: *
C *
C * I - Generic index. *
C * IPSIST - The next STEPMX station in integer degrees. *
C * ISTEP - STEPMX in integer degrees. *
C * J - Generic index. *
C * NEW - Array index for new data. *
C * NPTS - Number of points along the blade used to *
```

```

C      *          perform Simpson's integration for calculat- *
C      *          ing the moments and forces at the blade *
C      *          root. (passed from FLAP1) *
C      *      NSHP - Counter on DO loops for the coordinate *
C      *          shape function. *
C      *      OLD  - Array index for old data. *
C      *      STEMP - Temporary array holding the tip displace- *
C      *          ment values. The third dimension repre- *
C      *          sents the order of the time derivative. *
C      *      TIMNOW - Current time. *
C      * *
C      *****

```

```

REAL      STEMP (4,0:1,0:2)
REAL      TIMNOW

```

```

INTEGER   I
INTEGER   IPSIST
INTEGER   ISTEP
INTEGER   J
INTEGER   NEW
INTEGER   NPTS
INTEGER   NSHP
INTEGER   OLD

```

```

INCLUDE   'C:INCLUDE\CONST2.INC'

```

```

INCLUDE   'C:INCLUDE\LIMITC.INC'

```

```

INCLUDE   'C:INCLUDE\POSITN.INC'

```

```

INCLUDE   'C:INCLUDE\SARAYS.INC'

```

```

INCLUDE   'C:INCLUDE\TURBN.INC'

```

```

SAVE     NEW
SAVE     OLD
SAVE     STEMP

```

```

DATA     NEW    / 1 /
DATA     OLD    / 0 /

```

```

1000 FORMAT ( ' Static deflection at startup (MODE' , I2.2 , ') = '
&          , F8.4 / )

```

```

C      Initialize some variables.

```

```

ISTEP = RAD2DG*STEPMX + .001

```

```

C      IPSIST is the next STEPMX station. That is, then next azimuth
C      location at which the deflection, velocity and acceleration
C      values will be saved and the loads will be computed. Values
C      for azimuth positions intermediate to the loads will not be
C      saved.

```

```

IPSIST = RAD2DG*( PSI(1) + STEPMX ) + 0.001

```



```

C      When the ITRIM flag is set to 2, then this is the first pass
C      through DSKREV for this analysis.  If it is, then compute the
C      static deflection of the blade tip for the startup condition.

      IF ( ITRIM .EQ. 2 ) THEN

          CALL STARTUP ( STEMP , NPTS )

C      This section prints the computed static starting deflection
C      when the program is running in the trace mode.

          IF ( TRACEF ) THEN

              DO 100 I=1,NSHAPS
100          WRITE (4,1000) I , STEMP(I,1,0)

              END IF

          END IF

C      Push current values of S, SDOT and SDD onto old values.

          DO 220 NSHP=1,NSHAPS

              DO 200 J=0,360,ISTEP
200          SOLD(NSHP,J) = SNEW(NSHP,0,J)

              DO 210 I=0,2
210          SNEW(NSHP,I,0) = SNEW(NSHP,I,360)

              220 CONTINUE

C      Save old values of position variables and error.

          300 DELPSI(0) = DELPSI(1)
              DELTAT(0) = DELTAT(1)
              PSI (0) = PSI (1)
              TIME (0) = TIME (1)

C      Get next PSI, delta PSI, etc. and next yaw values PHI, PHI dot
C      and PHI dot-dot.

          400 CALL NXTPSI ( IPSIST )

              TIMNOW = TIME(1)

              CALL NXTPHI ( TIMNOW )

C      Solve the equation of motion and compute tip displacements and
C      velocities.  Check error of Euler predictor-corrector solution.
C      If the error condition is satisfied, check for disk station and
C      save the new values if this azimuth is a STEPMX disk station.

          CALL EULER ( STEMP , NSHAPS , NPTS )

```

```

IF ( (ERROR .GT. EUERR) .AND. (DELPSI(1) .GT. STEPMM) ) GO TO 400

C      The following tests check for the current azimuth location
C      between the STEPMX stations.  If the current position is very
C      close to a STEPMX station, then the deflection, velocity and
C      acceleration values are saved.

IF ( ABS( PSI(1) - IPSIST/RAD2DG ) .LT. 0.1*STEPMM ) THEN

    CALL SAVE1 ( IPSIST , NSHAPS , STEMP )

C      When the TRACEF flag is set, print out the prescribed
C      values.  See subroutine TRACE for a full description.

    IF ( TRACEF ) CALL TRACE ( STEMP , NPTS )

END IF

C      Move new temporary values to old.

DO 510 NSHP=1,NSHAPS

    DO 500 I=0,2
500    STEMP(NSHP,OLD,I) = STEMP(NSHP,NEW,I)

510 CONTINUE

C      If we haven't gone all the way around, solve the equation of
C      motion for the next step.

IF ( IPSIST .LE. 360 ) GO TO 300

RETURN
END
SUBROUTINE EULER ( STEMP , NSHAPS , NPTS )

C      *****
C      *
C      * Subroutine EULER uses the self starting modified pre- *
C      * dictor-corrector method to compute the values of the *
C      * blade tip displacement and velocity, given the previous *
C      * values and the solution to the blade equation of mo- *
C      * tion. The solution is not iterated for a specified de- *
C      * sired accuracy, but is instead run through one computa- *
C      * tion of the predictor-corrector. The error function *
C      * compares the percentage change in tip deflection be- *
C      * tween two consecutive azimuth locations against the *
C      * static tip deflection computed by the startup routine. *
C      * This error value is sent back to the calling routine *
C      * (ie. DSKREV). If the error is too large, a smaller az- *
C      * imuth angle step size will be used and another call *
C      * will be made to this routine. *
C      *
C      *

```

```

C *****
C *****
C *
C * External references in this routine: *
C *
C * ACCEL - Solves the blade equation of motion. *
C *
C *****
C *****
C *
C * Named COMMON blocks used in this routine: *
C *
C * POSITN - Holds parameters related to blade position *
C * such as PHI, PSI, etc. *
C * START - Holds initial blade deflection. *
C *
C *****
C *****
C *
C * Local and dummy variables used in this routine: *
C *
C * ACCELN - Tip acceleration. *
C * DEFLTN - Tip displacement. *
C * NEW - Array index for new data. *
C * NPTS - Number of points along the blade used to *
C * perform Simpson's integration for calculat- *
C * ing the moments and forces at the blade *
C * root. (passed from FLAP1) *
C * NSHAPS - Number of blade shape functions, 4 maximum. *
C * NSHP - Counter on DO loops for the coordinate *
C * shape function. *
C * OLD - Array index for old data. *
C * SCORCT - Corrected values for blade tip accelera- *
C * tion. *
C * SPRDCT - Predicted values for blade tip accelera- *
C * tion. *
C * STEMP - Temporary array holding the tip displace- *
C * ment values. The third dimension repre- *
C * sents the order of the time derivative. *
C *
C * VELCTY - Tip velocity. *
C *
C *****

```

```

REAL ACCELN (4)
REAL DEFLTN (4)
REAL SCORCT (4)
REAL SPRDCT (4)
REAL STEMP (4,0:1,0:2)
REAL VELCTY (4)

```

```

INTEGER NEW
INTEGER NPTS
INTEGER NSHAPS
INTEGER NSHP
INTEGER OLD

```

```

INCLUDE 'C:\INCLUDE\POSITN.INC'

```

```

INCLUDE      'C:\INCLUDE\START.INC'

SAVE        NEW
SAVE        OLD

DATA        NEW    / 1 /
DATA        OLD    / 0 /

```

C Calculate predictor values.

```

DO 100 NSHP=1,NSHAPS

    STEMP(NSHP,NEW,1) = STEMP(NSHP,OLD,1)
&    + STEMP(NSHP,OLD,2)*DELTAT(NEW)
    STEMP(NSHP,NEW,0) = STEMP(NSHP,OLD,0)
&    + STEMP(NSHP,OLD,1)*DELTAT(NEW)

    SPRDCT(NSHP) = STEMP(NSHP,NEW,0)

```

100 CONTINUE

C Calculate predicted acceleration values by solving the blade
C equation of motion with the predicted values of the tip
C velocity and displacement.

```

DO 200 NSHP=1,NSHAPS

    DEFLTN(NSHP) = STEMP(NSHP,NEW,0)
    VELCTY(NSHP) = STEMP(NSHP,NEW,1)

```

200 CONTINUE

C Subroutine ACCEL performs the actual solution of the blade
C equation of motion. It uses the previous values of the tip
C deflection and velocity and the current values of the forces.
C It returns the new blade tip acceleration values.

```

CALL ACCEL ( DEFLTN , VELCTY , ACCELN , NPTS, STEMP )

```

C Calculate corrector values.

```

DO 300 NSHP=1,NSHAPS

    STEMP(NSHP,NEW,2) = ACCELN(NSHP)

    STEMP(NSHP,NEW,0) = STEMP(NSHP,OLD,0)
&    + 0.5*DELTAT(1)*( STEMP(NSHP,OLD,1)
&    + STEMP(NSHP,NEW,1) )
    STEMP(NSHP,NEW,1) = STEMP(NSHP,OLD,1)
&    + 0.5*DELTAT(1)*( STEMP(NSHP,OLD,2)
&    + STEMP(NSHP,NEW,2) )

    SCORCT(NSHP) = STEMP(NSHP,NEW,0)

```

300 CONTINUE

C The error is computed from the sum of the ratios of the tip
C displacement change from the predicted to the corrected values
C relative to the initial static blade deflection computed at
C startup. Summation is over the number of coordinate shape
C functions specified in the run.

· ERROR = 0.0

DO 400 NSHP=1,NSHAPS

400 ERROR = ERROR + (SCORCT(NSHP) - SPRDCT(NSHP))/SO(NSHP)

C The error value is converted into percent for use in the
C DSKREV routine.

ERROR = 100.0*ABS(ERROR)

RETURN

END

SUBROUTINE FORM1 (STEMP , NPTS , NSHAPS)

C *****
C *
C * Subroutine FORM1 computes the values of the blade dis- *
C * placement function for each of the NPTS stations along *
C * the blade. The values are produced solely for use in *
C * computing the blade relative velocity values that are *
C * in turn used to compute the blade aerodynamic forces *
C * and ultimately the aerodynamic force function used in *
C * the blade equation of motion. *
C * *
C *****

C *****
C *
C * External references in this routine: *
C * *
C * none *
C * *
C *****

C *****
C *
C * Named COMMON blocks used in this routine: *
C * *
C * FORMS - Holds blade deflections. *
C * POSITN - Holds parameters related to blade position *
C * such as PHI, PSI, etc. *
C * SHAPE - Holds blade coordinate shape functions. *
C * *
C *****

C *****
C *
C * Local and dummy variables used in this routine: *
C * *

```

C      *
C      *      BLDANG - Blade azimuth position.
C      *      I      - Generic index.
C      *      NPTS  - Number of points along the blade used to
C      *                perform Simpson's integration for calculat-
C      *                ing the moments and forces at the blade
C      *                root. (passed from FLAP1)
C      *      NSHAPS - Number of blade shape functions, 4 maximum.
C      *      NSHP  - Counter on DO loops for the coordinate
C      *                shape function.
C      *      OLD   - Array index for old data.
C      *      STEMP - Temporary array holding the tip displace-
C      *                ment values. The third dimension repre-
C      *                sents the order of the time derivative.
C      *
C      *****

```

```

REAL      STEMP (4,0:1,0:2)

```

```

INTEGER   I
INTEGER   NPTS
INTEGER   NSHAPS
INTEGER   NSHP
INTEGER   OLD

```

```

INCLUDE   'C:INCLUDE\CONST2.INC'

```

```

INCLUDE   'C:INCLUDE\FORMS.INC'

```

```

INCLUDE   'C:INCLUDE\POSITN.INC'

```

```

INCLUDE   'C:INCLUDE\SHAPE.INC'

```

```

SAVE     OLD

```

```

DATA     OLD / 0 /

```

```

C      Initialize the VV array.

```

```

DO 100 I=1,NPTS
  VV(0,I) = 0.0
  VV(1,I) = 0.0
100 CONTINUE

```

```

C      Compute the VV values down the blade for each of the specified
C      shape functions.

```

```

DO 210 NSHP=1,NSHAPS

  DO 200 I=1,NPTS
    VV(0,I)=VV(0,I)+SHAPE(NSHP,0,I)*STEMP(NSHP,OLD,0)
    VV(1,I)=VV(1,I)+SHAPE(NSHP,0,I)*STEMP(NSHP,OLD,1)
200   CONTINUE

210 CONTINUE

```

```

RETURN
END
SUBROUTINE GAUSSJ ( A , N )

```

```

C *****
C *
C * Subroutine GAUSSJ is used to solve linear equations by *
C * Gauss-Jordan elimination with full pivoting. It was *
C * transcribed from the book "Numerical Recipes" by Wil- *
C * liam H. Press, et al. Code for right-hand-side vectors *
C * was not implemented in this routine. This routine was *
C * hard-wired for matrices of maximum order 4. *
C *
C *****

```

```

C *****
C *
C * External references in this routine: *
C *
C * none *
C *
C *****

```

```

C *****
C *
C * Named COMMON blocks used in this routine: *
C *
C * none *
C *
C *****

```

```

C *****
C *
C * Local and dummy variables used in this routine: *
C *
C * A - Input matrix with NP by NP elements. After *
C * processing it is replaced with its inverse. *
C * BIG - The biggest element in the A matrix. *
C * DUM - Temporary storage. *
C * I - Generic index. *
C * ICOL - Column. *
C * INDXC - Used for bookkeeping on pivoting. *
C * INDXR - Used for bookkeeping on pivoting. *
C * IPIV - Used for bookkeeping on pivoting. *
C * J - Generic index. *
C * IROW - Row. *
C * K - Generic index. *
C * L - Generic index. *
C * LL - Generic index. *
C * N - Order of the square A matrix. *
C * NMAX - Dimension of bookkeeping arrays. *
C * PIVINV - Inverse of the current pivot element. *
C *
C *****

```

```

REAL      A      (4,4)
REAL      BIG
REAL      DUM
REAL      PIVINV

```

```

INTEGER      I
INTEGER      ICOL
INTEGER      INDXC (4)
INTEGER      INDXR (4)
INTEGER      IPIV (4)
INTEGER      J
INTEGER      IROW
INTEGER      K
INTEGER      L
INTEGER      LL
INTEGER      N

```

Initialize the pivot matrix.

```

DO 100 J=1,N
) IPIV(J) = 0

```

This is the main loop over the columns to be reduced.

```

DO 260 I=1,N

```

```

    BIG = 0.0

```

This is the outer loop of the search for a pivot element.

```

DO 210 J=1,N

```

```

    IF ( IPIV(J) .NE. 1 ) THEN

```

```

        DO 200 K=1,N

```

```

            IF ( IPIV(K) .EQ. 0 ) THEN

```

```

                IF ( ABS( A(J,K) ) .GE. BIG ) THEN

```

```

                    BIG = ABS( A(J,K) )

```

```

                    IROW = J

```

```

                    ICOL = K

```

```

                END IF

```

```

            ELSE IF ( IPIV(K) .GT. 1 ) THEN

```

```

                PRINT *, ' '

```

```

                PRINT *, ' >>> The input matrix to GAUSSJ is '

```

```

                PRINT *, 'singular. <<<'

```

```

                PRINT *, ' '

```

```

                PRINT *, 'FLAP terminated abnormally due to the '

```

```

                PRINT *, 'the error listed above.'

```

```

            STOP

```

```

        END IF

```

```

    CONTINUE

```



```

        END IF

210  CONTINUE

        IPIV(ICOL)  IPIV(ICOL) + 1

C      We now have the pivot element; so we interchange rows.  If
C      needed, to put the pivot element on the diagonal.  The col-
C      umns are not physically interchanged, only relabeled:
C      INDXC(I), the column of the Ith pivotal element, is the Ith
C      column that is reduced, while INDXR(I) is the row in which
C      that pivot element was originally located.  If INDXR(I) is
C      not equal to INDXC(I), there is an implied column inter-
C      change.  With this form of bookkeeping, the solution Bs will
C      end up in the correct order, and the inverse matrix will be
C      scrambled by columns.

        IF ( IROW .NE. ICOL ) THEN

            DO 220 L=1,N

                DUM      = A(IROW,L)
                A(IROW,L) = A(ICOL,L)
                A(ICOL,L) = DUM

220    CONTINUE

        END IF

C      We are now ready to divide the pivot row by the pivot
C      element, located at (IROW,ICOL).

        INDXR(I) = IROW
        INDXC(I) = ICOL

        IF ( A(ICOL,ICOL) .EQ. 0.0 ) THEN

            PRINT *, ' '
            PRINT *, ' >>> The input matrix to GAUSSJ is '
            &      , 'singular. <<<'
            PRINT *, ' '
            PRINT *, ' FLAP terminated abnormally due to the '
            &      , 'the error listed above.'

            STOP

        END IF

        PIVINV = 1.0/A(ICOL,ICOL)

        A(ICOL,ICOL) = 1.0

        DO 230 L=1,N
230    A(ICOL,L) = PIVINV*A(ICOL,L)

C      Reduce all the rows except the pivot one.

```

```

C *****
C *
C *   Named COMMON blocks used in this routine:
C *
C *   none
C *
C *****

```

```

C *****
C *
C *   Local and dummy variables used in this routine:
C *
C *   ANS   - Answer to user question.
C *   EXISTS - Flag that indicates whether or not a file
C *           already exists.
C *   ISOPEN - Flag that indicates whether or not unit 4
C *           is already active.
C *   NEDOPN - Flag that indicates whether or not we need
C *           to open the results file.
C *   RESFIL - Name of file to store results.
C *   TEMP  - Temporary variable used to store the name
C *           of the results file.
C *
C *****

```

```

INTEGER      LNTH

LOGICAL      EXISTS
LOGICAL      ISOPEN
LOGICAL      NEDOPN

CHARACTER*1  ANS
CHARACTER*(*) RESFIL
CHARACTER*50 TEMP

```

```

1000 FORMAT ( ' Enter name of results file [=', A , ']' > ' )
1100 FORMAT ( A )
1200 FORMAT ( '1' )

```

```

C      Get name of results file.

```

```

100 PRINT 1000, RESFIL(1:LNTH(RESFIL))
READ 1100, TEMP

```

```

IF ( TEMP .EQ. ' ' ) THEN

```

```

C      The user hit just an <Enter>. Use the old name.

```

```

TEMP = RESFIL

```

```

ELSE

```

```

C      Convert file name to upper case if a name was typed in.

```

```

CALL CAPS ( TEMP )

```

```

DO 250 LL=1,N

  IF ( LL .NE. ICOL ) THEN

    DUM      = A(LL,ICOL)
    A(LL,ICOL) = 0.0

    DO 240 L=1,N
240      A(LL,L) = A(LL,L) - DUM*A(ICOL,L)

    END IF

250  CONTINUE

260 CONTINUE

C      Unscramble the solution in view of the column interchanges.
C      We do this by interchanging pairs of columns in the reverse
C      order that the permutation was built up.

DO 310 L=N,1,-1

  IF ( INDXR(L) .NE. INDXC(L) ) THEN

    DO 300 K=1,N

      DUM      = A(K,INDXR(L))
      A(K,INDXR(L)) = A(K,INDXC(L))
      A(K,INDXC(L)) = DUM

300    CONTINUE

    END IF

310 CONTINUE

RETURN
END
SUBROUTINE GETFIL ( RESFIL )

C      *****
C      *
C      * Subroutine GETFIL gets the name of the results file and *
C      * opens it.  If the file already exists, the user is *
C      * asked if it should be overwritten. *
C      *
C      *****

C      *****
C      *
C      * External references in this routine: *
C      *
C      * LNTH - Returns the length of a string. *
C      *
C      *****

```

```

END IF

C      Check to see if unit 4 is already attached.

INQUIRE (4, OPENED=ISOPEN )

IF ( ISOPEN ) THEN

    IF ( TEMP .EQ. RESFIL ) THEN

C          Use the same file that's already open.  Eject a page.

        WRITE (4,1200)
        NEDOPN = .FALSE.

    ELSE

C          Use a different file.  Close old one.

        CLOSE ( 4 )
        NEDOPN = .TRUE.

    END IF

ELSE

C          No open file yet.  We need to open one.

        NEDOPN = .TRUE.

    END IF

    IF ( NEDOPN ) THEN

C          We need to open the new results file.  Does it already
C          exist?

        INQUIRE ( FILE=TEMP , EXIST=EXISTS )

        IF ( EXISTS ) THEN

C          File already exists.  Write over it?

110      PRINT *, ' >>> File already exists <<<'
          PRINT *, ' '
          PRINT *, 'Do you want to overwrite the old data?'
          &      ' (Y,N) > '
          READ 1100, ANS

          IF ( ( ANS .EQ. 'N' ) .OR. ( ANS .EQ. 'n' ) ) GO TO 100

          IF ( ( ANS .NE. 'Y' ) .AND. ( ANS .NE. 'y' ) ) GO TO 110

```

```

END IF

C      Open the results file.

      OPEN ( 4 , FILE=TEMP , STATUS='UNKNOWN'
&          , CARRIAGECONTROL='FORTRAN' )

END IF

C      Save name of results file.

RESFIL = TEMP

RETURN
END

SUBROUTINE INDUCD ( INBORD , NPTS , BLDANG )

C      *****
C      *
C      * Subroutine INDUCD computes the induced velocities along *
C      * the blade. These are then used to compute the aerody- *
C      * namic forces. The values computed and returned by this *
C      * routine are all in non-dimensional form. That is, they *
C      * are divided by R, OMEGA or R*OMEGA where necessary. *
C      *
C      *****

C      *****
C      *
C      * External references in this routine:
C      *
C      *     none
C      *
C      *****

C      *****
C      *
C      * Named COMMON blocks used in this routine:
C      *
C      *     AERD1 - Holds coefficients related to aerodynamic *
C      *             loads calculations such as ClAlpha, CdZero, *
C      *             etc.
C      *     BLADE - Holds blade property values such as stiff- *
C      *             ness and mass distributions.
C      *     CONST - Turbine and other constants used in load *
C      *             calculations.
C      *     POSITN - Holds parameters related to blade position *
C      *             such as PHI, PSI, etc.
C      *     TURBN - Holds turbine parameters such as number of *
C      *             blades, rotor speed, etc.
C      *     VINDUC - Holds induced velocity components.
C      *     WIND - Holds wind shear and tower shadow param- *
C      *            eters.
C      *     WNDVEL - Holds values used in wind shear and tower *
C      *            shadow computations.
C      *
C      *****

```

```
*
* Local and dummy variables used in this routine:
*
*   A2BVL - Temporary storage.
*   AA    - Temporary storage.
*   ALMP  - Temporary storage.
*   AM2BV - Temporary storage.
*   AMBV  - Temporary storage.
*   APR   - Temporary storage.
*   APRIME - Temporary storage.
*   ASTAR - Temporary storage.
*   BB    - Temporary storage.
*   BLDANG - Blade azimuth position.
*   BPRIME - Temporary storage.
*   BVALUE - Temporary storage.
*   CC    - Temporary storage.
*   CPRIME - Temporary storage.
*   CSS   - Temporary storage.
*   DELVSH - Temporary storage.
*   F1    - Temporary storage.
*   F2    - Temporary storage.
*   F3    - Temporary storage.
*   F4    - Temporary storage.
*   I     - Generic index.
*   INBORD - The number of blade stations that are not
*             on the airfoil section. INBORD is used in
*             other routines to differentiate between
*             sections of the blade with and without an
*             airfoil section.
*   ISUBP - Temporary storage.
*   ISUBW - Temporary storage.
*   J     - Generic index.
*   LAMDAH - Inflow ratio.
*   MPRIME - Temporary storage.
*   NPTS  - Number of points along the blade used to
*             perform Simpson's integration for calculat-
*             ing the moments and forces at the blade
*             root. (passed from FLAP1)
*   P     - Temporary storage.
*   RBAR  - Temporary storage.
*   RDCL1 - Temporary storage.
*   RDCL2 - Temporary storage.
*   STEADY - Flag to indicate steady flow.
*   STEP  - Distance between points along the blade.
*   TAU   - Temporary storage.
*   TAU4  - Temporary storage.
*   TAUTZL - Temporary storage.
*   THETZL - Temporary storage.
*   TLAM  - Temporary storage.
*   TSUBZR - Temporary storage.
*   VINDPC - Temporary storage.
*   VINDS - Temporary storage.
*   Z     - Blade position pointer.
```

REAL A2BVL

```

REAL      AA
REAL      ALMP
REAL      AM2BV
REAL      AMBV
REAL      APR
REAL      APRIME
REAL      ASTAR
REAL      BB
REAL      BLDANG
REAL      BPRIME
REAL      BVALUE
REAL      CC
REAL      CPRIME
REAL      CSS      (5)
REAL      DELVSH
REAL      F1
REAL      F2
REAL      F3
REAL      F4
REAL      ISUBP
REAL      ISUBW
REAL      LAMDAH
REAL      MPRIME
REAL      P
REAL      RBAR
REAL      RDCL1
REAL      RDCL2
REAL      STEP
REAL      TAU
REAL      TAU4
REAL      TAUTZL
REAL      THETZL
REAL      TLAM
REAL      TSUBZR
REAL      VINDPC
REAL      VINDS
REAL      Z

INTEGER   I
INTEGER   INBRD
INTEGER   J
INTEGER   NPTS

LOGICAL   STEADY

INCLUDE   'C:\INCLUDE\AERO1.INC'

INCLUDE   'C:\INCLUDE\BLADE2.INC'

INCLUDE   'C:\INCLUDE\CONST2.INC'

INCLUDE   'C:\INCLUDE\POSITN.INC'

INCLUDE   'C:\INCLUDE\TURBN.INC'

INCLUDE   'C:\INCLUDE\VINDUC.INC'

INCLUDE   'C:\INCLUDE\WIND2.INC'

INCLUDE   'C:\INCLUDE\WINDVEL.INC'

```

```

2000 FORMAT ( / ' >>> Error in steady induced velocity. <<<'
&          / ' >>> Negative value in SQRT was set to 0. <<<'
&          / ' >>> Blade angle = ' , F6.2
&
&          / ' >>> Blade station = ' , 13.2
&
&          / )

```

C Initialize constants.

```

INBORD = 1
LAMDAH = HUBVEL/( RR*OMEGA )
STEP = BLTIP/( NPTS - 1 )

IF ( TSHADW .EQ. 0.0 ) THEN
  TSUBZR = 0.0
ELSE
  TSUBZR = TSUBO
END IF

DO 100 I=1,5
100 CSS(I) = COS( I*BLDANG )

```

C Move blade station pointer to inboard start of airfoil section
C on blade.

```

Z = 0.0

110 IF ( Z .LT. BLSHNK ) THEN

  Z = Z + STEP
  INBORD = INBORD + 1

  GO TO 110

END IF

```

C Initialize internal values.

```

ASTAR = 0.20
MPRIME = 2.40
BVALUE = 0.16
Z = 0.0

ALMP = LAMDAH*MPRIME
AMBV = MPRIME + BVALUE
AM2BV = LAMDAH*( MPRIME + 2.0*BVALUE )
APR = 1.0/( 8.0*PI*RR )
A2BVL = 2.0*BVALUE*LAMDAH
TLAM = LAMDAH*LAMDAH

```

Loop through blade stations.

```

DO 220 I=1,NPTS

```



```
IF ( I .LT. INBORD ) THEN
```

```
VINDR(I) = 0.0  
VINDO(I) = 0.0  
DVIND(I) = 0.0
```

```
ELSE
```

```
STEADY = .TRUE.  
RBAR = ( Z + HUBRAD )/RR  
THETZL = THETAP - THETAO(I)  
TAU = APR*( CLALFA(I)*CHORD(I)*NBLADS )  
TAUTZL = TAU*THETZL
```

```
AA = RBAR - 0.5*TAUTZL  
BB = RBAR*TAU - LAMDAH*( RBAR  
& - ( WSHR(0,I) - TSUBZR )*( RBAR - TAUTZL ) )  
CC = -RBAR*( RBAR*TAUTZL  
& + LAMDAH*( WSHR(0,I) - TSUBZR )*( LAMDAH - TAU ) )
```

```
C Compute the induced velocity. First check to see if the  
C coefficient of the squared term is zero. If it is, then  
C the equation is linear. If the radical of the root is  
C less than zero, then the momentum solution is invalid,  
C set the radical to zero and go on.
```

```
IF ( AA .NE. 0.0 ) THEN
```

```
RDCL1 = BB**2 - 4.0*AA*CC  
  
IF ( RDCL1 .LT. 0.0 ) RDCL1 = 0.0  
  
VINDR(I) = 0.5*( -BB + SQRT( RDCL1 ) )/AA
```

```
ELSE
```

```
VINDR(I) = -CC/BB
```

```
END IF
```

```
C Check to see if the induced condition is steady or  
C turbulent. If it is turbulent, compute turbulent  
C intermediate values and recompute the induced velocity.
```

```
IF ( ( 1.0-VINDR(I)/LAMDAH .GT. ASTAR ) .OR.  
& ( RDCL1 .EQ. 0.0 ) ) THEN
```

```
STEADY = .FALSE.  
TAU4 = 4.0*TAU
```

```
APRIME = 2.0*TAUTZL  
BPRIME = -RBAR*( ALMP + TAU4 )  
& - LAMDAH*( WSHR(0,I) - TSUBZR ) .  
& *( RBAR*APRIME - 4*TAUTZL )  
CPRIME = RBAR*( 4*RBAR*TAUTZL + AMBV*TLAM  
& + LAMDAH*( WSHR(0,I) - TSUBZR )  
& *( AM2BV - TAU4 ) )
```

```

C          Compute the induced velocity. Use same logic as
C          for steady flow.

          IF ( APRIME .NE. 0.0 ) THEN

              RDCL2 = BPRIME**2 - 4*APRIME*CPRIME

              IF ( RDCL2 .LT. 0.0 ) THEN

                  PRINT 2000, BLDANG , I

                  RDCL2 = 0.0

              END IF

              VINDR(I) = -0.5*( BPRIME + SQRT( RDCL2 ) )/APRIME

          ELSE

              VINDR(I) = -CPRIME/BPRIME

          END IF

          END IF

          VINDO(I) = LAMDAH - VINDR(I)

C          Calculate the intermediate components for forming induced
C          velocity terms.

          F1 = TAU*VINDR(I)*( VINDR(I) - 2*RBAR*THETZL )
          F2 = TAU*( RBAR - THETZL*VINDR(I) )
          F3 = RBAR*( VINDR(I) - VINDO(I) ) + F2

          IF ( STEADY ) THEN

              ISUBP = F1/F3
              ISUBW = LAMDAH*( F2 - RBAR*VINDO(I) )/F3

          ELSE

              F4 = RBAR*ALMP + 4*F2
              ISUBP = 4*F1/F4
              ISUBW = LAMDAH*( 4*F2 - RBAR*( A2BVL
&                                     + MPRIME*VINDO(I) ) )/F4

          END IF

C          Form induced velocity components of order epsilon, etc.

          VINDC(1) = -PHI(0)*ISUBP + WSHR(1,I)*ISUBW
          VINDS = -CHI*ISUBP

          DO 200 J=2,5
200      VINDC(J) = WSHR(J,I)*ISUBW

```

```
C      Compute the tower shadow effect if in the tower shadow
C      region.
```

```
IF ( TSHADW .NE. 0.0 ) THEN
```

```
VINDPC = TSUBP*ISUBW
P      = KSHADW*PI/PSIZER
DELVSH = VINDPC*COS( P*( BLDANG - PSISHD ) )
```

```
ELSE
```

```
VINDPC = 0.0
DELVSH = 0.0
```

```
END IF
```

```
C      Compute the delta-V-induced term. i.e., the sum of the
C      order epsilon components.
```

```
DVIND(I) = VINDS*SIN( BLDANG ) - DELVSH
```

```
DO 210 J=1,5
```

```
210 DVIND(I) = DVIND(I) + VINDC(J) * CSS( J )
```

```
END IF
```

```
C      Increment the blade position pointer and repeat the induced
C      velocity procedure out to the blade tip.
```

```
Z = Z + STEP
```

```
220 CONTINUE
```

```
RETURN
```

```
END
```

```
SUBROUTINE INVERT ( AMAT , AINV , N )
```

```
C      *-----*
C      *
C      * Subroutine INVERT is a transparent interface between *
C      * the calling routine, SOLVE, and GAUSSJ, the routine *
C      * that performs the actual inversion. The incoming ma- *
C      * trix is unaffected by the inversion process. *
C      *
C      *-----*
```

```
C      *-----*
C      *
C      * External references in this routine: *
C      *
C      * GAUSSJ - Matrix inversion using Gauss-Jordan elimi- *
C      * nation with full pivoting. *
C      *
C      *-----*
```

```

C *****
C *
C *   Named COMMON blocks used in this routine:   *
C *
C *   none
C *
C *****

```

```

C *****
C *
C *   Local and dummy variables used in this routine:   *
C *
C *   AINV  - The resulting inverse matrix.
C *   AMAT  - The incoming matrix to be inverted.
C *   I     - Generic index.
C *   J     - Generic index.
C *   N     - The order of the incoming square matrix.
C *
C *****

```

```

REAL      AINV  (4,4)
REAL      AMAT  (4,4)

```

```

INTEGER   I
INTEGER   J
INTEGER   N

```

```

C   Load the incoming matrix into the inverse matrix AINV.

```

```

DO 20 I=1,N
  DO 10 J=1,N
    AINV(I,J) = AMAT(I,J)
10  CONTINUE
20  CONTINUE

```

```

      Invert the matrix.

```

```

CALL GAUSSJ ( AINV , N )

```

```

RETURN
END
SUBROUTINE LIMITS

```

```

; *****
; *
; *   Subroutine LIMITS inputs the run limit values through *
; *   interactive dialog.  A set of default values are init- *
; *   ialized in the BLOCK DATA subprogram.
; *
; *****
;
; *****
; *
; *

```

```

C      * External references in this routine:      *
C      *                                          *
C      *      none                                *
C      *                                          *
C      *****
C      *****
C      *                                          *
C      * Named COMMON blocks used in this routine: *
C      *                                          *
C      *      LIMITC - Holds values used in the LIMITS routine. *
C      *                                          *
C      *****
C      *****
C      * Local and dummy variables used in this routine: *
C      *                                          *
C      *      ANS - Answer to user question. *
C      *      ERROR - IOSTAT error value on OPEN statement. Used *
C      *              to check for existing files. *
C      *      ICASE - Number of variable to change. *
C      *      P1 - Temporary variable used for testing to see *
C      *              if PRINT1 is a multiple of STEPMX. *
C      *      P2 - Temporary variable used for testing to see *
C      *              if PRINT2 is a multiple of STEPMX. *
C      *      TEMP - Temporary variable used to store the name *
C      *              of the results file. *
C      *                                          *
C      *****

```

```

REAL      P1
REAL      P2

INTEGER   ICASE

CHARACTER*1 ANS

INCLUDE   'C:INCLUDE\LIMITC.INC'

```

```

1000 FORMAT ( // ' The current values of the run parameters are: ' / )
1100 FORMAT ( 1X , A , F8.3 ,      A )
1200 FORMAT ( 1X , A , I4 , 4X , A )
2000 FORMAT ( A )

```

```

C      Print out the current limit values.

```

```

100 PRINT 1000

PRINT 1100, ' 1 STEPMX = ', STEPMX
&          , ' degrees Maximum Step Size'

PRINT 1100, ' 2 STEPMM = ', STEPMM
&          , ' degrees Minimum Step Size'

PRINT 1100, ' 3 PRINT1 = ', PRINT1
&          , ' degrees Printout Interval in Region 1'

```

```

PRINT 1100, ' 4 PRINT2 = ' , PRINT2
&          , ' degrees Printout Interval in Region 2'

PRINT 1100, ' 5 BEGIN2 = ' , BEGIN2
&          , ' degrees Beginning of Print Region 2'

PRINT 1100, ' 6 END2 = ' , END2
&          , ' degrees End of Print Region 2'

PRINT 1100, ' 7 EUERR = ' , EUERR
&          , ' percent Max value of Euler error function'

PRINT 1100, ' 8 TRMERR = ' , TRMERR
&          , ' percent Convergence Criterion for Trim Solution'

PRINT 1200, ' 9 NYAW = ' , NYAW
&          , ' No. of Disk Revolutions for Yawing Soln.'

IF ( TRACEF ) THEN
  PRINT *, '10 TRACEF = .TRUE.          Trace Flag'
ELSE
  PRINT *, '10 TRACEF = .FALSE.        Trace Flag'
END IF

```

C Ask user for changes to present values.

```

200 PRINT *, ' '
PRINT *, 'Do you want to change any of these values? (Y,=N) > '
READ 2000, ANS

IF ( ( ANS .EQ. 'Y' ) .OR. ( ANS .EQ. 'y' ) ) THEN

210 PRINT *, ' '
PRINT *, 'Enter number of variable you wish to change > '
READ *, ICASE

IF ( ( ICASE .LE. 0 ) .OR. ( ICASE .GT. 10 ) ) THEN

  PRINT *, ' >>> Invalid response. Please try again. <<<'
  GO TO 210

ELSE

```

C Change one of the variables.

```

GO TO (300,310,320,330,340,350,360,370,380,390), ICASE

300 PRINT *, 'Enter new REAL value for STEPMX > '
READ *, STEPMX
GO TO 100

310 PRINT *, 'Enter new REAL value for STEPMM > '
READ *, STEPMM
GO TO 100

320 PRINT *, 'Enter new REAL value for PRINT1 > '

```

```

        READ *, PRINT1
        GO TO 100

330    PRINT *, 'Enter new REAL value for PRINT2 > '
        READ *, PRINT2
        GO TO 100

340    PRINT *, 'Enter new REAL value for BEGIN2 > '
        READ *, BEGIN2
        GO TO 100

350    PRINT *, 'Enter new REAL value for END2 > '
        READ *, END2
        GO TO 100

360    PRINT *, 'Enter new REAL value for EUERR > '
        READ *, EUERR
        GO TO 100

370    PRINT *, 'Enter new REAL value for TRMERR > '
        READ *, TRMERR
        GO TO 100

380    PRINT *, 'Enter new INTEGER value for NYAW > '
        READ *, NYAW
        GO TO 100

390    PRINT *, 'Enter new LOGICAL value for TRACEF (T,F) > '
        READ *, TRACEF
        GO TO 100

    END IF

ELSE IF ( ( ANS .NE. 'N') .AND. ( ANS .NE. 'n' )
&          .AND. ( ANS .NE. ' ' ) ) THEN

    PRINT *, ' >>> Invalid response. Please try again. <<<'

    GO TO 200

END IF

C      Check to make sure the values of PRINT1 and PRINT2 are integer
C      multiples of STEPMX. If they are not, print error message and
C      go back to the change values section.

P1 = STEPMX*INT( PRINT1/STEPSMX + 0.00001 )
P2 = STEPMX*INT( PRINT2/STEPSMX + 0.00001 )

IF ( ABS( P1 - PRINT1 ) .GT. 0.001 ) THEN

    PRINT *, ' '
    PRINT *, ' >>> PRINT1 must be a multiple of STEPMX <<<'

    GO TO 100

END IF

IF ( ABS( P2 - PRINT2 ) .GT. 0.001 ) THEN

```

```
PRINT *, ' '
PRINT *, '>>> PRINT2 must be a multiple of STEPMX <<<'
```

```
GO TO 100
```

```
END IF
```

```
RETURN
```

```
END
```

```
FUNCTION LNTH ( STRING )
```

```
C *****
C *
C * Function LNTH returns the length of a character string. *
C * When using the Lahey F77L compiler, the intrinsic func- *
C * tion NBLANK can be used as we do here. This function *
C * was supplied to make conversion to other compilers eas- *
C * ier. *
C * *
C *****
```

```
C *****
C *
C * Named COMMON blocks used in this routine: *
C * *
C * none *
C * *
C *****
```

```
C *****
C *
C * Variables used in this routine: *
C * *
C * IC - Generic index. *
C * LENGTH - The declared length of STRING. *
C * LNTH - The location of the last nonblank character *
C * in STRING. *
C * STRING - A character string. *
C * *
C *****
```

```
INTEGER IC
INTEGER LENGTH
INTEGER LNTH
```

```
CHARACTER*(*) STRING
```

```
C Get the declared length of STRING using the FORTRAN 77 intrinsic
C function LEN.
```

```
LENGTH = LEN( STRING )
```

```
C Find the location of the last nonblank character in STRING.
```



```

DO 100 IC=LENGTH,1,-1

LNTH = IC

IF ( STRING(IC:IC) .NE. ' ' ) GO TO 200

100 CONTINUE

STRING is all blanks.

LNTH = 0

200 RETURN
END
SUBROUTINE LODOUT ( NCALLS )

```

```

C *****
C *
C * Subroutine LODOUT is used to compute blade loads and *
C * print them out. *
C * *
C *****

C *****
C *
C * External references in this routine: *
C * *
C * AERO - Calculates the aerodynamic forces on the *
C * blade. *
C * CONVRT - Performs units conversions. *
C * LNTH - Returns the length of a string. *
C * NXTPHI - Calculates the next values of the yaw vari- *
C * ables. *
C * SIMPSN - Composite Simpson's integration. *
C * TRPZOD - Composite trapezoidal integration. *
C * *
C *****

C *****
C *
C * Named COMMON blocks used in this routine: *
C * *
C * AER01 - Holds coefficients related to aerodynamic *
C * loads calculations such as ClAlpha, CdZero, *
C * etc. *
C * AIRFRC - Holds values used in aerodynamic calcula- *
C * tions. *
C * BLADE - Holds blade property values such as stiff- *
C * ness and mass distributions. *
C * CONST Turbine and other constants used in load *
C * calculations. *
C * FORMS - Holds blade deflections. *
C * LIMITC - Holds values used in the LIMITS routine. *
C * LITERL - Holds data set titles. *
C * LODVAL - Holds values used to compute blade loads. *
C * POSITN - Holds parameters related to blade position *
C * such as PHI, PSI, etc. *

```

```

C      *   SARAYS - Holds new and old values for the general- *
C      *   *   ized coordinates. *
C      *   SHAPE - Holds blade coordinate shape functions. *
C      *   TENSIN - Holds tension component integrals. *
C      *   TURBN - Holds turbine parameters such as number of *
C      *   *   blades, rotor speed, etc. *
C      *   WIND - Holds wind shear and tower shadow parame- *
C      *   *   ters. *
C      *   *   *
C      *   *****

```

```

C      *   *****
C      *   *   *
C      *   Local and dummy variables used in this routine: *
C      *   *   *
C      *   AVE MOM - Mean flapwise bending moment at 0.2*R. *
C      *   BLDANG - Blade azimuth position. *
C      *   COEF1 - Complicated term. *
C      *   COEF2 - Complicated term. *
C      *   COEF3 - Complicated term. *
C      *   COEF4 - Complicated term. *
C      *   COEF5 - Complicated term. *
C      *   COEF6 - Complicated term. *
C      *   COEF7 - Complicated term. *
C      *   COEF8 - Complicated term. *
C      *   CPSI - Cosine of the blade angle. *
C      *   DMSBAC - Complicated term. *
C      *   ECENGR - Integral of ECNTFN. *
C      *   EDGEFN - Edgewise shear force distribution. *
C      *   EINTGR - Integral of EDGEFN. *
C      *   FACTR1 - Complicated term. *
C      *   FINTGR - Integral of FLAPFN. *
C      *   FLAPFN - Flapwise shear force distribution. *
C      *   FPS2KW - Factor for converting Ft-Lbs/sec to KW. *
C      *   I - Generic index. *
C      *   IBEGIN - Azimuth position for beginning of print re- *
C      *   *   gion 1. *
C      *   IEND - Azimuth position for end of print region 1. *
C      *   ILABEL - Strings used for printout. *
C      *   IPRNT1 - Printout interval for results in print re- *
C      *   *   gion 1. *
C      *   IPSI - Integerized disk station azimuth positions. *
C      *   IPSIST - The next STEPMX station in integer degrees. *
C      *   IPT - Data point index. *
C      *   IST - Station index. *
C      *   IVALUE - Temporary storage. *
C      *   J - Generic index. *
C      *   LABEL1 - String to hold variable names. *
C      *   LABEL2 - String to hold units for variables. *
C      *   LABEL3 - String to hold variable descriptions. *
C      *   LABEL4 - String. *
C      *   LABEL5 - String. *
C      *   LL - Generic index. *
C      *   M - Generic index. *
C      *   NCALLS - Number of calls to LODOUT. *
C      *   NOWPSI - Current value of azimuth position. *
C      *   NPTS - Number of points along the blade used to *
C      *   *   perform Simpson's integration for calculat- *
C      *   *   ing the moments and forces at the blade *
C      *   *   root. (passed from FLAP1) *

```

```

C      *      NSHP  - Counter on DO loops for the coordinate *
C      *      shape function. *
C      *      NSTN  - Number of stations around rotor disk. *
C      *      NTORQS - Number of values used to compute TRQSUM. *
C      *      NTOT  - Number of values used to compute AVEMOM. *
C      *      OMGASQ - Omega^2. *
C      *      POWER - Power output of wind turbine. *
C      *      PRDCT0 - Temporary storage. *
C      *      PRDCT1 - Temporary storage. *
C      *      PRDCT2 - Temporary storage. *
C      *      PRODD  - Temporary storage. *
C      *      PXAERO - Aerodynamic loads in the edgewise direc- *
C      *      tion. *
C      *      PYAERO - Aerodynamic loads in the flapwise direc- *
C      *      tion. *
C      *      QZAERO - Integral of QZFCN. *
C      *      QZFCN  - Aerodynamic moment per unit length about *
C      *      the elastic axis. *
C      *      RDIST  - Distance out along blade. *
C      *      RESLTS - Temporary storage. *
C      *      RPO    - Phi in degrees. *
C      *      RP1    - Phi-dot in degrees. *
C      *      RP2    - Phi-dot-dot in degrees. *
C      *      RPHI  - Phi and its derivatives at this disk sta- *
C      *      tion. *
C      *      RTIME  - Time values in yaw solution. *
C      *      SINTGR - The integral of VXFCN. *
C      *      SPSI   - Sine of the blade angle. *
C      *      STEP1  - Distance between stations along the blade. *
C      *      TIMNOW - Current time. *
C      *      TINTGR - Integral of TSNFCN. *
C      *      TODEGS - Flag used to tell CONVRT to convert 'free' *
C      *      variables to degrees. *
C      *      TORADS - Flag used to tell CONVRT to convert 'free' *
C      *      variables to radians. *
C      *      TORQFN - The torque produced by an incremental aero- *
C      *      dynamic force. *
C      *      TRQSUM - Total torque. Integral of TORQFN. *
C      *      TSNFCN - Product of the tension force and the slope *
C      *      at a blade station. *
C      *      VALUE  - Temporary storage. *
C      *      VXFCN  - Product of the edgewise shear force and the *
C      *      blade slope at a blade station. *
C      *
C      *****

```

```

REAL      AVEMOM
REAL      BLDANG
REAL      COEF1
REAL      COEF2
REAL      COEF3
REAL      COEF4
REAL      COEF5
REAL      COEF6
REAL      COEF7
REAL      COEF8
REAL      CPSI
REAL      DMSBAC

```

REAL	ECENGR
REAL	EDGEFN (21)
REAL	EINTGR
REAL	FACTR1
REAL	FINTGR
REAL	FLAPFN (21)
REAL	FPSZKW
REAL	OMGASQ
REAL	POWER
REAL	PRDCTO
REAL	PRDCT1
REAL	PRDCT2
REAL	PRODUCT (21)
REAL	PRODD
REAL	PXAERO (21)
REAL	PYAERO (21)
REAL	QZAERO
REAL	QZFCN (21)
REAL	RDIST
REAL	RPO
REAL	RP1
REAL	RP2
REAL	RPHI (360,0:2)
REAL	RTIME (360)
REAL	SIMPSN
REAL	SINTGR
REAL	SPSI
REAL	STEP1
REAL	TIMNOW
REAL	TINTGR
REAL	TORQFN (21)
REAL	TRPZOD
REAL	TRQSUM
REAL	TSNFCN (21)
REAL	VALUE (26)
REAL	VXFCN (21)
REAL	ACOF (0:10,21)
REAL	BCOF (0:10,21)

INTEGER	H
INTEGER	I
INTEGER	IPRNT1
INTEGER	IPSI (360)
INTEGER	IPSIST
INTEGER	IP T
INTEGER	IST
INTEGER	IVALUE (4)
INTEGER	J
INTEGER	LL
INTEGER	LNTH
INTEGER	M
INTEGER	NCALLS
INTEGER	NOWPSI
INTEGER	NPTS
INTEGER	NSHP
INTEGER	NSTN
INTEGER	NTORQS
INTEGER	NTOT
INTEGER	MITEM
INTEGER	NHARM

```

CHARACTER*10  I LABEL (4)
CHARACTER*9   LABEL1 (26)
CHARACTER*11  LABEL2 (26)
CHARACTER*45  LABEL3 (9)
CHARACTER*19  LABEL4
CHARACTER*2   LABEL5
CHARACTER*1   ANS1
CHARACTER*50  LABEL6 (9)

LOGICAL       TODEGS
LOGICAL       TORADS

INCLUDE       'C:INCLUDE\AERO1.INC'

INCLUDE       'C:INCLUDE\AIRFRC.INC'

INCLUDE       'C:INCLUDE\BLADE2.INC'

INCLUDE       'C:INCLUDE\CONST2.INC'

INCLUDE       'C:INCLUDE\FORMS.INC'

INCLUDE       'C:INCLUDE\LIMITC.INC'

INCLUDE       'C:INCLUDE\LITERL.INC'

INCLUDE       'C:INCLUDE\LODVAL.INC'

INCLUDE       'C:INCLUDE\POSITN.INC'

INCLUDE       'C:INCLUDE\SARAYS.INC'

INCLUDE       'C:INCLUDE\SHAPE.INC'

INCLUDE       'C:INCLUDE\TENSIN2.INC'

INCLUDE       'C:INCLUDE\TURBN.INC'

INCLUDE       'C:INCLUDE\RESLTS.INC'

INCLUDE       'C:INCLUDE\WIND2.INC'

SAVE         I LABEL
SAVE         LABEL1
SAVE         LABEL2
SAVE         LABEL3
SAVE         NPTS
SAVE         TODEGS
SAVE         TORADS
SAVE         IPSI

DATA         FPS2KW / 0.0013558 /

DATA         I LABEL / 'KSHADW = ' , 'NBLADS = '
&           , 'NSHAPS = ' , 'NYAW = ' /

DATA         LABEL1
& / 'ALENTH = ' , 'ALPHAO = ' , 'BETAO ' , 'BLSHNK = '

```

```

& , 'BLTIP = ' , 'CHI = ' , 'CSUBMA = ' , 'DRGFRM = '
& , 'EUERR = ' , 'HUBHT = ' , 'HUBRAD = ' , 'OMEGA = '
& , 'PHIAMP = ' , 'PHIOMG = ' , 'PHIO = ' , 'PSIZER = '
& , 'RHOAIR = ' , 'SHERXP = ' , 'STEPMX = ' , 'STEPMN = '
& , 'TSUBP = ' , 'TSUBO = ' , 'THETAP = ' , 'THETAT = '
& , 'TRMERR = ' , 'VHUB = ' /
DATA LABEL2
& / 'feet ' , 'degrees ' , 'degrees ' , 'feet '
& , 'feet ' , 'degrees ' , ' ' , ' ' , ' '
& , 'percent ' , 'feet ' , 'feet ' , 'RPM '
& , 'degrees ' , 'degrees/sec' , 'degrees ' , 'degrees '
& , 'slugs/ft^3 ' , ' ' , 'degrees ' , 'degrees '
& , ' ' , ' ' , 'degrees ' , 'degrees '
& , 'percent ' , 'feet/second' /
DATA LABEL3
& / 'Blade section flap displacement ( feet ) '
& , 'Blade section flapwise slope ( feet/foot ) '
& , 'Blade section flap velocity ( feet/second ) '
& , 'Blade tension ( Lb ) '
& , 'Blade edgewise shear ( Lb ) '
& , 'Blade flapwise shear ( Lb ) '
& , 'Blade flapwise moment ( ft-Lbs ) '
& , 'Blade edgewise moment ( ft-Lbs ) '
& , 'Blade torsion ( ft-Lbs ) ' /
DATA LABEL6
& / 'Blade flap-displacement expansion coefficients '
& , 'Blade flapwise slope expansion coefficients '
& , 'Blade flap-velocity expansion coefficients '
& , 'Blade tension force expansion coefficients '
& , 'Blade edgewise shear expansion coefficients '
& , 'Blade flapwise shear expansion coefficients '
& , 'Blade flapwise moment expansion coefficients '
& , 'Blade edgewise moment expansion coefficients '
& , 'Blade torsional moment expansion coefficients ' /

DATA NPTS / 21 /

DATA TODEGS / .TRUE. /

DATA TORADS / .FALSE. /

4000 FORMAT ( /// 37X , 'Analysis of Wind Turbine Blade Loads',
& / 39X , 'Solar Energy Research Institute' //// )
4100 FORMAT ( 3( 10X , A // ) )
4200 FORMAT ( 10X , A , ' Rotor'
& /// 7X , 'Run Parameters, blade data and machine data used in'
& ' this analysis: ' / )
4300 FORMAT ( 9X , 3( 1X , A , F7.3 , 1X , A , 5X , : ) // )
4400 FORMAT ( /// 9X , 4( 1X , A , I3 , 12X ) / )
4500 FORMAT ( '1' /// 1X , A , 65X , A , A / )
4600 FORMAT ( ' Psi Time Phi Phi-D Phi-DD' , 38X , 'X / R '
& / 1X , 131( '-' )
& / ' deg sec deg deg/s deg/s^2 .0 .1'
& , ' .2 .3 .4 .5 .6'
& , ' .7 .8 .9 1.0'
& / 1X , 131( '-' ) / )
4700 FORMAT( 14 , F6.2 , F6.1 , F7.2 , F7.2 , 3X , 11(1X , 1PG8.2E1) )
4800 FORMAT ( // ' Average Flapwise Moment = ' , F9.1
& , ' (ft-Lbs) at the 20% station' / )
5000 FORMAT ( '1' //// ' Mean Rotor Torque and Power for ' , 2A // )

```

```

5100 FORMAT ( 10X , 'Mean Rotor Torque =', F13.2 , ' ft-Lbs'
& // 10X , 'Mean Rotor Power =', F13.2 , ' kW'
& // 10X , 'No. of Data Points =', I13 )

```

```

5200 FORMAT ('1' ///// 1X, A, 65X, A, A/)

```

```

5300 FORMAT (69X, 'X / R ' / 1X, 131('--')/ 131('--')/
& 12X, '.0      .1      .2      .3      .4'
&'      .5      .6      .7      .8      .9'
&'      1.'//
& 1X, 131('--')/131('--')/

```

```

5400 FORMAT (1X, 'A',I1,'=',3X, 11(3X,1PG8.2E1))

```

```

5500 FORMAT (1X, 'B',I1,'=',3X, 11(3X,1PG8.2E1))

```

```

5600 FORMAT (1X, 131('--'))

```

C Initialize torque count and sum.

```

NTORQS = 0
TRQSUM = 0.0

```

C Set some constants that are user to compute tension and shear.

```

OMGASQ = OMEGA**2
COEF1 = 2.0*OMEGA*STHP
COEF4 = OMGASQ*STHP*CTHP
COEF6 = OMGASQ*CTHP*CTHP
COEF7 = OMGASQ*STHP*STHP

```

C Fill the IPSI array with PSI disk station values. This section
C of code is executed only the first time this routine is called.

```

IF( NCALLS .EQ. 0 ) THEN

```

```

    IPRNT1 = PRINT1*RAD2DG + 0.001
    NSTN = 1
    IPSIST = 0
    IPSI(NSTN) = IPSIST

```

```

120 IF ( IPSIST .LT. 360 ) THEN

```

```

    IPSIST = IPSIST + IPRNT1
    NSTN = NSTN + 1
    IPSI(NSTN) = IPSIST

```

```

    GO TO 120
ENDIF

```

```

ENDIF

```

```

    IPSI(NSTN) = 360

```

C Initialize the time values in the RTIME array for the trim run.

```

IF ( ( NCALLS .EQ. 0 ) .OR. ( PHIAMP .EQ. 0.0 ) ) THEN

```

```

DO 200 I=1,NSTN
200  RTIME(I) = 0.0

ELSE

C      Calculate the time values around the disk stations for the
C      yaw runs.

      RTIME(1) = 2*PI*( NCALLS - 1 )/OMEGA

DO 210 IST=2,NSTN
210.  RTIME(IST) = RTIME(1) + IPSI(IST)/( RAD2DG*OMEGA )

END IF

C      Initialize outer computation loop used for going around the disk.

PRODD = 0.5*RHOAIR*CSUBMA

DO 370 IST=1,NSTN

C      Compute the PHI values at this disk azimuth.

TIMNOW = RTIME(IST)

CALL NXTPHI(TIMNOW)

RPHI(IST,0) = PHI(0)
RPHI(IST,1) = PHI(1)
RPHI(IST,2) = PHI(2)

C      Compute constants used in computing the shear and moment
C      values.

PSI(1) = IPSI(IST)/RAD2DG
NOWPSI = IPSI(IST)
CPSI   = COS( PSI(1) )
SPSI   = SIN( PSI(1) )
FACTR1 = OMGASQ*BETA0 + 2*OMEGA*CPSI*PHI(1) + SPSI*PHI(2)
COEF2  = GRAV*( -CHI*CTHP + STHP*SPSI + BETA0*CTHP*CPSI )
COEF3  = GRAV*( CHI*STHP + CTHP*SPSI - BETA0*STHP*CPSI )
COEF5  = GRAV*CPSI
COEF8  = GRAV*SPSI*STHP

C      Fill the V arrays.

C      V      = RESLTS( , ,1)
C      V-PRIME = RESLTS( , ,2)
C      V-DOT  = RESLTS( , ,3)

DO 310 IPT=1,NPTS

      RESLTS(IST,IPT,1) = 0.0
      RESLTS(IST,IPT,2) = 0.0

```



```

RESULTS(IST,IPT,3) = 0.0

DO 300 NSHP=1,NSHAPS

    RESULTS(IST,IPT,1) = RESULTS(IST,IPT,1)
&      + SHAPE(NSHP,0,IPT)*SNEW(NSHP,0,NOWPSI)

    RESULTS(IST,IPT,2) = RESULTS(IST,IPT,2)
&      + SHAPE(NSHP,1,IPT)*SNEW(NSHP,0,NOWPSI)

    RESULTS(IST,IPT,3) = RESULTS(IST,IPT,3)
&      + SHAPE(NSHP,0,IPT)*SNEW(NSHP,1,NOWPSI)

300  CONTINUE

C      The values for VV(0,IPT) and VV(1,IPT) are needed for the
C      AERO and VREL routines.

    VV(0,IPT) = RESULTS(IST,IPT,1)
    VV(1,IPT) = RESULTS(IST,IPT,3)

310  CONTINUE

C      Compute the aerodynamic force components and the Qz compo-
C      nent form integrals and save them for use in computing the
C      shears and moments.

    BLDANG = PSI(1)

    CALL AERO ( NPTS , BLDANG )

C      This section of code computes the rotor torque component
C      that produces the turbine shaft torque. The torque is
C      averaged over the disk to give average rotor torque for one
C      rotor revolution. This does not use weighted values. All
C      values have equal weight regardless of the azimuth spacing.
C      Thus these results will only be accurate when PRINT1 and
C      PRINT2 have the same value.

    STEP1 = BLTIP/( NPTS - 1 )

    IF ( NOWPSI .LT. 360 ) THEN

        DO 320 I=1,NPTS

            RDIST = HUBRAD + STEP1*( I - 1 )
            TORQFN(I) = RDIST*( DAETA(I)*CTHP + DAZETA(I)*STHP )

320  CONTINUE

            TRQSUM = TRQSUM + SIMPSN( 0 , BLTIP , NPTS , TORQFN )
            NTORQS = NTORQS + 1

        END IF

    DO 330 IPT=1,NPTS

```

```

DMSBAC = PRODD*CHORD(IPT)*WV(IPT)**2
QZFCN(IPT) = DMSBAC + ESUBAC(IPT)*DAZETA(IPT)

```

330 CONTINUE

DO 350 IPT=1,NPTS

```

PXAERO(IPT) = TRPZOD( IPT , BLTIP , DAETA , NPTS )
PYAERO(IPT) = TRPZOD( IPT , BLTIP , DAZETA , NPTS )

```

C Compute the constants needed to compute tension
C and shear.

```

PRDCTO = 0.0
PRDCT1 = 0.0
PRDCT2 = 0.0

```

PRODCT(IPT) = 0.0

DO 340 NSHP=1,NSHAPS

```

PRDCTO = PRDCTO + SNEW(NSHP,0,NOWPSI)*TCORLS(NSHP,IPT)
PRDCT1 = PRDCT1 + SNEW(NSHP,1,NOWPSI)*TCORLS(NSHP,IPT)
PRDCT2 = PRDCT2 + SNEW(NSHP,2,NOWPSI)*TCORLS(NSHP,IPT)

```

```

&           PRODCT(IPT) = PRODCT(IPT)
&                   + SNEW(NSHP,0,NOWPSI)*CIFMOM(NSHP,IPT)

```

340 CONTINUE

```

&           RESLTS(IST,IPT,4) = OMGASQ*TOMGA(IPT) + COEF1*PRDCT1
&                   - COEF5*TGRAV(IPT)

```

```

&           RESLTS(IST,IPT,6) = PYAERO(IPT) - FACTR1*CTHP*TOMGA(IPT)
&                   + COEF7*PRDCTO - PRDCT2
&                   + COEF2*TGRAV(IPT) + COEF4*OFFMAS(IPT)

```

```

&           RESLTS(IST,IPT,5) = PXAERO(IPT) + FACTR1*STHP*TOMGA(IPT)
&                   + COEF4*PRDCTO + COEF3*TGRAV(IPT)
&                   + COEF6*OFFMAS(IPT)

```

```

EDGEFN(IPT) = RESLTS(IST,IPT,5)
VXFCN (IPT) = EDGEFN(IPT)*RESLTS(IST,IPT,2)
TSNFCN(IPT) = RESLTS(IST,IPT,4)*RESLTS(IST,IPT,2)
FLAPFN(IPT) = RESLTS(IST,IPT,6)

```

350 CONTINUE

C Compute the torsion and moment array values for this
C azimuth position.

DO 360 IPT=1,NPTS

```

EINTGR = TRPZOD( IPT , BLTIP , EDGEFN , NPTS )
SINTGR = TRPZOD( IPT , BLTIP , VXFCN , NPTS )
TINTGR = TRPZOD( IPT , BLTIP , TSNFCN , NPTS )
QZAERO = TRPZOD( IPT , BLTIP , QZFCN , NPTS )

```

```
FINTGR = TRPZOD( IPT , BLTIP , FLAPFN , NPTS )
ECENGR = TRPZOD( IPT , BLTIP , ECNTFN , NPTS )
```

```
RESLTS(IST,IPT,7) = TINTGR - FINTGR + COEF7*PRODC(IPT)
```

```
&
RESLTS(IST,IPT,8) = EINTGR - OMGASQ*ECENGR
- COEF4*PRODC(IPT) + COEF5*OFFMAS(IPT)
```

```
&
RESLTS(IST,IPT,9) = QZAERO - SINTGR + COEF4*DELTIM(IPT)
+ COEF8*OFFMAS(IPT)
```

```
360 CONTINUE
```

```
370 CONTINUE
```

```
TRQSUM = TRQSUM*NBLADS/NTORQS
POWER = TRQSUM*OMEGA*FPS2KW
```

```
C Print out the resulting values with a heading on the first
C pass only. Convert values to degrees for the printout.
```

```
CALL CONVRT ( TODEGS )
```

```
IF ( MOD( NCALLS , NYAW+1 ) .EQ. 0 ) THEN
```

```
VALUE( 1) = ALENTH
VALUE( 2) = ALPHA
VALUE( 3) = BETAO
VALUE( 4) = BLSHKK
VALUE( 5) = BLTIP
VALUE( 6) = CHI
VALUE( 7) = CSUBMA
VALUE( 8) = DRGFRM
VALUE( 9) = EUERR
VALUE(10) = HUBHT
VALUE(11) = HUBRAD
VALUE(12) = OMEGA
VALUE(13) = PHIAMP
VALUE(14) = PHIOMG
VALUE(15) = PHIO
VALUE(16) = PSIZER
VALUE(17) = RHOAIR
VALUE(18) = SHERXP
VALUE(19) = STEPMX
VALUE(20) = STEPMN
VALUE(21) = TSBP
VALUE(22) = TSUBO
VALUE(23) = THETAP
VALUE(24) = THETAT
VALUE(25) = TRMERR
VALUE(26) = VHUB
```

```
IVALUE(1) = KSHADW
IVALUE(2) = NBLADS
IVALUE(3) = NSHAPS
IVALUE(4) = NYAW
```

```
WRITE (4,4000)
WRITE (4,4100) TITLE1(1:LNTH(TITLE1))
```

```

&          , TITLE2(1:LNTH(TITLE2))
&          , TITLE3(1:LNTH(TITLE3)) .

DO 400 J=1,9
400 WRITE (4,4300) ( LABEL1(I), VALUE(I), LABEL2(I), I=J,26,9 )

      WRITE (4,4400) ( I LABEL(I) , I VALUE(I) , I=1,4 )

END IF

C      Convert values back to radians for use in internal
C      calculations.

CALL CONVRT ( TORADS )

C      This section of code computes the mean flapwise moment at the
C      20% blade station for NPTS=21.  If NPTS is changed, the second
C      subscript of RESLTS( , ,7) must be changed also.

C      Programmer note:
C      Changed to what?

NTOT = 0
AVEMOM = 0.0

DO 410 LL=1,NSTN-1

      AVEMOM = AVEMOM + RESLTS(LL,5,7)
      NTOT = NTOT + 1

410 CONTINUE

AVEMOM = AVEMOM/NTOT

C      Form the proper chart headings and print out the nine charts
C      of the results from this run.

IF ( NCALLS .EQ. 0 ) THEN

      LABEL4 = 'Trim Solution
      LABEL5 = '

ELSE

      LABEL4 = 'Yaw Solution, Rev #'
      WRITE (LABEL5,'(I2.2)') NCALLS

END IF

DO 430 M=1,9

      WRITE (4,4500) LABEL3(M) , LABEL4 , LABEL5
      WRITE (4,4600)

DO 420 I=1,NSTN

```

```

RPO = RPHI(I,0)*RAD2DG
RP1 = RPHI(I,1)*RAD2DG
RP2 = RPHI(I,2)*RAD2DG

WRITE (4,4700) IPSI(I) , RTIME(I) , RPO , RP1 , RP2
&
, ( RESLTS(I,J,M) , J=1,NPTS,2 )

420 CONTINUE

: Print the average flapwise moment at the 20% blade station.

IF ( M .EQ. 7 ) WRITE (4,4800) AVEMOM

430 CONTINUE

IF( NCALLS .EQ. 0) THEN
PRINT *, ' '
500 PRINT *, 'Do you want to perform fourier analysis of'
PRINT *, 'any of the results data?'
PRINT *, ' '
PRINT *, ' note: shaft loads harmonics will appear in'
PRINT *, ' the shaft loads file.'
PRINT *, ' '
READ *, ANS1
IF ( ANS1 .EQ. 'Y' .OR. ANS1 .EQ. 'y' ) THEN
PRINT *, 'Read in the result data item # '
PRINT *, 'that you want analyzed'
PRINT *, ' '
PRINT *, '1 = flapwise displacement'
PRINT *, '2 = flapwise slope'
PRINT *, '3 = flapwise segment velocity'
PRINT *, '4 = blade tension'
PRINT *, '5 = blade edgewise shear'
PRINT *, '6 = blade flapwise shear'
PRINT *, '7 = blade flapwise moment'
PRINT *, '8 = blade edgewise moment'
PRINT *, '9 = blade torsional moment'
PRINT *, ' '
READ *, MITEM
PRINT *, 'Read in the highest order harmonic desired'
READ *, NHARM

CALL SERIES( MITEM, NHARM, ACOF, BCOF, NSTN,
&
IPSI, IPRNT1)

WRITE(4,5200) LABEL6(MITEM), LABEL4, LABEL5
WRITE(4,5300)

DO 550 H = 0,NHARM

WRITE(4,5400) H, (ACOF(H,J),J=1,NPTS,2)
WRITE(4,5500) H, (BCOF(H,J),J=1,NPTS,2)
WRITE(4,5600)
550 CONTINUE

GO TO 500
ELSEIF( ANS1 .NE. 'y' .AND. ANS1 .NE. 'Y') THEN
GO TO 600
ENDIF

```

```

C      When all the results tables have been printed, print out the
C      average rotor torque and power for this rotor revolution. This
C      codes gives equal weight to each azimuth position regardless
C      of the azimuth spacing. Thus the power and torque values are
C      only accurate when PRINT1 and PRINT2 are the same.

```

```

600  WRITE (4,5000) LABEL4 , LABEL5
      WRITE (4,5100) TRQSUM , POWER , NTOQRS

```

```

      IF( NBLADS .EQ. 2) THEN
          CALL SHAFT2(IPSI, IPRNT1, NSTN)
      ELSE
          CALL SHAFT3(IPSI, IPRNT1, NSTN)
      ENDIF

```

```

ENDIF

```

```

C      Increment the number of calls to this routine before
C      returning.

```

```

NCALLS = NCALLS + 1

```

```

RETURN

```

```

END

```

```

SUBROUTINE MULT ( AMATRX , M , N )

```

```

C      *****
C      *
C      * Subroutine MULT premultiplies an incoming matrix by the *
C      * inverse CMMASS matrix. The inverse CMMASS matrix is a *
C      * square symmetric matrix of order 4. The incoming ma- *
C      * trix can be of any size but must have exactly 4 rows. *
C      *
C      *****

```

```

C      *****
C      *
C      * External references in this routine:
C      *
C      * none
C      *
C      *****

```

```

C      *****
C      *
C      * Named COMMON blocks used in this routine:
C      *
C      * INV - Holds the inverse of the mass matrix.
C      *
C      *****

```

```

C      *****
C      *
C      * Local and dummy variables used in this routine:
C      *
C      * AMATRX - The incoming matrix to be premultiplied by
C      *           the inverse CMMASS matrix.
C      * I      - Generic index.
C      *
C      *****

```

```

C      *      J      - Generic index.          *
C      *      K      - Generic index.          *
C      *      M      - Number of rows in the incoming matrix. *
C      *      N      - Number of columns in the incoming matrix. *
C      *      TEMP   - Temporary work matrix.  *
C      *                                                    *
C      *****

```

```

REAL      AMATRX (4,4)
REAL      TEMP   (4,4)

INTEGER   I
INTEGER   J
INTEGER   K
INTEGER   M
INTEGER   N

INCLUDE   'C:INCLUDE\INV.INC'

```

```

C      Multiply AINVRs by AMATRX putting the result into TEMP.

```

```

DO 30 I=1,M
    DO 20 J=1,N
        TEMP(I,J) = 0.0
        DO 10 K=1,M
10     TEMP(I,J) = TEMP(I,J) + AINVR(I,K) * AMATRX(K,J)
        CONTINUE
    CONTINUE
30 CONTINUE

```

```

C      Move the resulting temporary matrix into the original
C      incoming matrix.

```

```

DO 50 I=1,M
    DO 40 J=1,N
40     AMATRX(I,J) = TEMP(I,J)
    CONTINUE
50 CONTINUE

```

```

RETURN
END
SUBROUTINE NXTPHI ( TIMNOW )

```

```

C      *****
C      *                                                    *
C      * Subroutine NXTPHI computes the next values of the yaw *
C      * variables. If this is a trim run, then the yaw varia- *
C      * bles do not change. If this is a yawing run, then the *
C      * yaw variables are computed based on the next value of *

```

```

C      * the time variable.
C      *
C      * The basic yaw function used here is:
C      *
C      *   Phi = Phi-sub-0 + SIN( Omega-sub-Phi*Time ).
C      *
C      * The two derivatives with respect to time, Phi-dot and
C      * Phi-double-dot are derived in a straightforward manner
C      * via differentiation with respect to time.
C      *
C      * The indices of the PHI array correspond to the order of
C      * the derivative of Phi with respect to time.
C      *
C      *****

```

```

C      *****
C      *
C      * External references in this routine:
C      *
C      *   none
C      *
C      *****

```

```

C      *****
C      *
C      * Named COMMON blocks used in this routine:
C      *
C      *   POSITN - Holds parameters related to blade position
C      *             such as PHI, PSI, etc.
C      *   TURBN  - Holds turbine parameters such as number of
C      *             blades, rotor speed, etc.
C      *
C      *****

```

```

C      *****
C      *
C      * Local and dummy variables used in this routine:
C      *
C      *   OMPHIT - Phase angle of the sinusoidal yaw function.
C      *             It corresponds to the Omega-sub-Phi*T term
C      *             of the formulation notes. The Omega-sub-Phi
C      *             component is the yaw velocity amplitude
C      *             divided by the yaw angle amplitude.
C      *   SOMPHT - Sine of Omega-sub-Phi*T.
C      *   TIMNOW - Current time. TIMNOW is identically zero
C      *             for the trim solution computation.
C      *
C      *****

```

```

REAL      OMPHIT
REAL      SOMPHT
REAL      TIMNOW

```

```

INCLUDE    'C:INCLUDE\POSITN.INC'

```

```

INCLUDE    'C:INCLUDE\TURBN.INC'

```

```

C      Check to see if this is time zero.

```



```

IF ( TIMNOW .EQ. 0.0 ) THEN

C      Set the yaw function and its derivatives for TIME=0.

      PHI(0) = PHI0
      PHI(1) = PHIOMG
      PHI(2) = 0.0

ELSE

C      Compute the yaw function and its derivatives for times
C      greater than time zero.

      OMPHIT = TIMNOW*PHIOMG/PHIAMP
      SOMPHT = SIN( OMPHIT )
      PHI(0) = PHI0 + PHIAMP*SOMPHT
      PHI(1) = PHIOMG*COS( OMPHIT )
      PHI(2) = -PHIOMG*PHIOMG*SOMPHT/PHIAMP

END IF

RETURN
END
SUBROUTINE NXTPSI ( IPSIST )

C      *****
C      *
C      * Subroutine NXTPSI computes the next value of the azi- *
C      * muth angle, Psi, based on the current value of the Eu- *
C      * ler error and the previous delta-Psi value. If the er- *
C      * ror is too large, a smaller delta-Psi will be used to *
C      * compute the value of Psi, unless the delta-Psi is al- *
C      * ready at the STEPMM lower limit. Likewise, if the Eu- *
C      * ler error is below a certain limit, the delta-Psi value *
C      * is increased for the next Psi computation. *
C      *
C      *****

C      *****
C      *
C      * External references in this routine: *
C      *
C      * none *
C      *
C      *****

C      *****
C      *
C      * Named COMMON blocks used in this routine: *
C      *
C      * CONST - Turbine and other constants used in load *
C      * calculations. *
C      * LIMITC - Holds values used in the LIMITS routine. *
C      * POSITN - Holds parameters related to blade position *
C      * such as PHI, PSI, etc. *
C      * TURBN - Holds turbine parameters such as number of *

```

```

C      *          blades, rotor speed, etc.          *
C      *
C      *****
C
C      *****
C      *
C      * Local and dummy variables used in this routine: *
C      *
C      *     IPSIST - The next STEPMX station in integer degrees. *
C      *     NEW    - Array index for new data. *
C      *     OLD    - Array index for old data. *
C      *     PSIST  - The next STEPMX station in radians. *
C      *
C      *****

```

```

REAL      PSIST

INTEGER   IPSIST
INTEGER   NEW
INTEGER   OLD

INCLUDE   'C:\INCLUDE\CONST2.INC'

INCLUDE   'C:\INCLUDE\LIMITC.INC'

INCLUDE   'C:\INCLUDE\POSITN.INC'

INCLUDE   'C:\INCLUDE\TURBN.INC'

SAVE     NEW
SAVE     OLD

DATA     NEW    / 1 /
DATA     OLD    / 0 /

```

```

C      Check the error.  If it is too large, decrease delta-Psi by
C      50%.  If it is very small, increase delta-Psi by 50%.  The
C      value of delta-Psi must always be greater than STEPMN.

```

```

IF ( ERROR .GT. EUERR ) THEN

    DELPSI(NEW) = AMAX1( 0.5*DELPSI(NEW) , STEPMN )

ELSE IF ( ERROR .LT. 0.1*EUERR ) THEN

    DELPSI(NEW) = 1.5*DELPSI(NEW)

END IF

```

```

C      This section of code checks the position of the new Psi against
C      the next STEPMX station.  If the next Psi will go past the
C      STEPMX station, the delta-Psi is adjusted to bring the next Psi
C      directly onto the STEPMX point.  If the next Psi will fall just
C      short of a STEPMX station, the delta-Psi is adjusted to assure
C      that it will not be necessary to use a delta-Psi smaller than
C      STEPMN to reach the next STEPMX station on the next iteration.

```

```

C      Programmer note:

C      The following logic can produce a delta-Psi that is less
C      than STEPMM for two steps. It would then move back within
C      tolerances. This case comes up when we are within slightly
C      less than two STEPMMs of the next STEPMX station. This
C      algorithm cannot produce a delta-Psi that is less than
C      STEPMM/2.                                MLB

```

```

PSIST = IPSIST/RAD2DG

```

```

IF ( PSI(OLD)+DELPSI(NEW) .GT. PSIST ) THEN

```

```

    DELPSI(NEW) = PSIST - PSI(OLD)

```

```

ELSE IF ( PSI(OLD)+DELPSI(NEW)+STEPMM .GT. PSIST ) THEN

```

```

    IF ( (DELPSI(NEW) .NE. STEPMM) .OR. (ERROR .LE. EUERR) ) THEN

```

```

        DELPSI(NEW) = 0.5*( PSIST - PSI(OLD) )

```

```

    END IF

```

```

END IF

```

```

C      Set new Psi and delta-Time.

```

```

PSI(NEW) = PSI(OLD) + DELPSI(NEW)

```

```

DELTAT(NEW) = DELPSI(NEW)/OMEGA

```

```

C      Get time values if we're working on a yawing solution.

```

```

IF ( ITRIM .EQ. 0 ) TIME(NEW) = TIME(OLD) + DELTAT(NEW)

```

```

RETURN

```

```

END

```

```

SUBROUTINE RUN ( NPTS , NEWSET , HAVRUN )

```

```

C      *****
C      *
C      * Subroutine RUN performs the modeling of the rotor blade *
C      * motion. The coefficients and data read in by subrou- *
C      * tine DATAIN are used along with the run limit and run *
C      * setup values input in subroutines LIMITS and SETUP. *
C      *
C      * There are two basic steps to the run solution - the *
C      * trim solution and the yawing solution. In the trim so- *
C      * lution, the yaw position and yaw rate are kept at a *
C      * fixed value, and the time is kept fixed at zero. The *
C      * equations are solved for successive revolutions around *
C      * the rotor disk until the tip displacement functions no *
C      * longer change significantly from one revolution to the *
C      * next. This is the trim solution. Once the trim solu- *
C      * tion is achieved, the trim solution is completed, with *
C      * the yaw angle, yaw angular velocity and acceleration *
C      * computed from a given function and the time elapsed *

```

```

C      * since the start of the yaw solution. After each rotor *
C      * disk revolution of the yaw solution, the loads are cal- *
C      * culated and printed out. *
C      * *
C      *****
C      *****
C      * *
C      * External references in this routine: *
C      * *
C      * CONVRT - Performs units conversions. *
C      * DSKREV - Performs a full disk revolution solution to *
C      * the blade equations of motion. *
C      * GETFIL - Get the name of the results file and open *
C      * it. *
C      * LIMITS - Interactive input of run limits. *
C      * LODOUT - Calculates and prints blade loads. *
C      * SETUP - Interactive modification of free variables. *
C      * SHAPES - Calculates the four coordinate shape func- *
C      * tions. *
C      * SOLVE - Calculates the inverse CMMASS matrix for *
C      * premultipling other coefficient matrices. *
C      * TRMTST - Compares the results of two consecutive ro- *
C      * tor revolutions. *
C      * *
C      *****
C      *****
C      * *
C      * Named COMMON blocks used in this routine: *
C      * *
C      * CONST - Turbine and other constants used in load *
C      * calculations. *
C      * LIMITC - Holds values used in the LIMITS routine. *
C      * POSITN - Holds parameters related to blade position *
C      * such as PHI, PSI, etc. *
C      * SARAYS - Holds new and old values for the general- *
C      * ized coordinates. *
C      * TURBN - Holds turbine parameters such as number of *
C      * blades, rotor speed, etc. *
C      * *
C      *****
C      *****
C      * *
C      * Local and dummy variables used in this routine: *
C      * *
C      * ANS - Used to store input responses from key- *
C      * board. *
C      * HAVRUN - Flag that indicates that the model has been *
C      * run. Used for diagnostic runs. *
C      * - Generic index. *
C      * ITCNT - The count of the number of disk revolutions *
C      * required to achieve a trim solution. *
C      * J - Generic index. *
C      * NCALLS - Number of calls to LODOUT. *
C      * NEWSET - Flag to control calls to SOLVE. *
C      * NPTS - Number of points along the blade used to *
C      * perform Simpson's integration for calculat- *
C      * ing the moments and forces at the blade *

```

```

C      *          root. (passed from FLAP1)          *
C      *      NSHP - Counter on DO loops for the coordinate *
C      *          shape function.                    *
C      *      RESFIL - Name of file to which results are written. *
C      *      TODEGS - Flag used to tell CONVRT to convert 'free' *
C      *          variables to degrees.              *
C      *      TORADS - Flag used to tell CONVRT to convert 'free' *
C      *          variables to radians.              *
C      *
C      *
C      *****

```

```

INTEGER      I
INTEGER      ITCNT
INTEGER      J
INTEGER      NCALLS
INTEGER      NPTS
INTEGER      NSHP

```

```

LOGICAL      HAVRUN
LOGICAL      NEWSET
LOGICAL      TODEGS
LOGICAL      TORADS

```

```

CHARACTER*1  ANS
CHARACTER*50 RESFIL

```

```

INCLUDE      'C:INCLUDE\CONST2.INC'

```

```

INCLUDE      'C:INCLUDE\LIMITC.INC'

```

```

INCLUDE      'C:INCLUDE\POSITN.INC'

```

```

INCLUDE      'C:INCLUDE\SARAYS.INC'

```

```

INCLUDE      'C:INCLUDE\TURBN.INC'

```

```

SAVE        RESFIL
SAVE        TODEGS
SAVE        TORADS

```

```

DATA        RESFIL / 'RESULTS.DAT' /
DATA        TODEGS / .TRUE. /
DATA        TORADS / .FALSE. /

```

```

2000 FORMAT ( A )
4000 FORMAT ( / ' The trim condition is not satisfied after' , I3.2
&          , ' rotor'
&          / ' revolutions. Shall we continue? (=Y,N) > ' )
4100 FORMAT ( '& The trim condition was not satisfied.' )
4200 FORMAT ( / ' Trim test #' , I2.2 , ' completed.' )
4300. FORMAT ( '& The trim condition was satisfied.' )
6000 FORMAT ( / ' Do you want to do another run with this data? (Y,=N)'
&          , ' > ' )

```

```

C      Compute the values of the four coordinate shape functions for
C      for each of the NPTS blade stations along the blade.

```

```

CALL SHAPES ( NPTS )

```

```

C      The main run loop begins here.  The interactive program se-
C      quence starts.

100 CONTINUE

C
C      Clear NCALLS which represents the number of calls to LOOOUT.
C      It is used to control printing of the title page.  It is
C      incremented in LOOOUT just before returning.

NCALLS = 0

C      Set up a run by first calling the SETUP and LIMITS routines.
C      Temporarily convert the units of the 'free' variables to de-
C      grees and RPM for interactive use.

CALL CONVRT ( TODEGS )
CALL SETUP
CALL LIMITS
CALL CONVRT ( TORADS )

C      Before starting the model run, check for potential error in the
C      yaw function.  A value of zero for PHIAMP in a yaw solution
C      will cause the program to abort.

IF ( ( NYAW .GT. 0 ) .AND. ( PHIAMP .EQ. 0.0 ) ) THEN

    PRINT *, ' '
    PRINT *, 'Error in input data.  PHIAMP cannot be zero'
    PRINT *, 'for a yaw solution.  Please review the setup'
    PRINT *, 'and limits values.'

    GO TO 600

END IF

C      On the first pass through the RUN routine, invert the mass
C      coefficient matrix and premultiply all the coefficient ma-
C      trices by the result.  This is done just once per data set.

IF ( NEWSET ) THEN

    CALL SOLVE
    NEWSET = .FALSE.

END IF

200 PRINT *, ' '
PRINT *, 'Are you ready to run the model? (=Y,N) > '
READ 2000, ANS

IF ( ( ANS .EQ. 'N' ) .OR. ( ANS .EQ. 'n' ) ) RETURN

IF ( ( ANS .NE. 'Y' ) .AND. ( ANS .NE. 'y' ) )

```

```

&                .AND. ( ANS .NE. ' ' ) ) THEN

    PRINT *, ' >>> Invalid response. Please try again. <<<'
    GO TO 200

END IF

C      Open the file that is to contain the results.

CALL GETFIL ( RESFIL )

C      Zero the blade deflection, velocity and acceleration for the
C      start of the trim solution run.

DO 320 NSHP=1,NSHAPS
DO 310 I=0,2
    DO 300 J=0,360

        SNEW(NSHP,I,J) = 0.0
        SOLD(NSHP,J)   = 0.0

300     CONTINUE
310     CONTINUE
320     CONTINUE

C      Start the trim run. When the ITRIM flag is set to 2, the first
C      pass through DSKREV will also execute the STRTUP startup rou-
C      tine. STRTUP computes the static deflection of the blade at
C      the 270 degree azimuth position, under the given wind condi-
C      tions. This static deflection is used to start the actual mo-
C      del run, and helps to assure rapid convergence to the trim so-
C      lution by removing many of the startup transients associated
C      with beginning execution without a realistic initial blade tip
C      deflection.

    ITRIM      = 2
    PSI(1)    . = 270/RAD2DG
    DELPSI(1) = STEPMM
    ERROR      = 0.0

    CALL DSKREV ( NPTS )

    ITRIM = 1

C      Iterate for the trim solution. Keep count of the rotor re-
C      volutions and give the user a chance to bail out every ten
C      revolutions.

    ITCNT = 0

400 IF ( ITRIM .EQ. 1 ) THEN

    IF ( ITCNT .NE. 0 ) THEN

        IF ( MOD( ITCNT , 10 ) .EQ. 0 ) THEN

```

```
PRINT 4000, ITCNT
READ 2000, ANS
```

```
IF ( ( ANS .EQ. 'N' ) .OR. ( ANS .EQ. 'n' ) ) THEN
```

```
PRINT *, ' '
PRINT *, 'FLAP terminated by user.'
PRINT *, ' '
```

```
STOP
```

```
END IF
```

```
ELSE
```

```
PRINT 4100
```

```
END IF
```

```
END IF
```

```
C      Initialize the azimuth angle and run another revolution.
C      Test the last set of solutions against this set for stabil-
C      ity. When TRMTST is satisfied, ITRIM will be set to zero
C      the loop will be terminated.
```

```
PSI(1) = 0.0
```

```
CALL DSKREV ( NPTS )
```

```
ITCNT = ITCNT + 1
```

```
CALL TRMTST ( ITRIM )
```

```
PRINT 4200, ITCNT
```

```
GO TO 400
```

```
END IF
```

```
C      Trim solution completed.
```

```
PRINT 4300
```

```
C      Calculate results of the trim solution.
```

```
CALL LODOUT ( NCALLS )
```

```
C      Initialize the yaw run loop by starting time at zero. Run yaw
C      solution NYAW times. Calculate the loads and print out the
C      results after each disk revolution.
```

```
IF ( NYAW .GT. 0 ) THEN
```

```
TIME(1) = 0.0
```



```

DO 500 I=1,NYAW

    PSI(1) = 0.0

    CALL DSKREV ( NPTS )
    CALL LODOUT ( NCALLS )

500 CONTINUE

END IF

C      Run complete.

600 PRINT 6000
    READ 2000, ANS

    IF ( ( ANS .EQ. 'Y' ) .OR. ( ANS .EQ. 'y' ) ) THEN

        PRINT *, ' '
        PRINT *, 'You must not change the number of shapes, NSHAPS!!!'
        PRINT *, ' '

        GO TO 100

    ELSE IF ( ( ANS .NE. 'N' ) .AND. ( ANS .NE. 'n' )
&          & .AND. ( ANS .NE. ' ' ) ) THEN

        PRINT *, ' >>> Invalid response. Please try again. <<<'

        GO TO 600

    END IF

C      Set the HAVRUN flag to true to enable diagnostic runs.

HAVRUN = .TRUE.

RETURN
END
SUBROUTINE SAVE1 ( IPSIST , NSHAPS , STEMP )

C      *****
C      *
C      * Subroutine SAVE1 makes a permanent copy of the tip dis- *
C      * placement variables at each STEPMX station around the *
C      * rotor disk. These values are used by the loads routine *
C      * to calculate the blade loads based upon the tip dis- *
C      * placements. Only the values corresponding to the spec- *
C      * ified number of shape functions are saved. *
C      *
C      *****
C      *****
C      *
C      * External references in this routine: *
C      *
C      *

```

```

C      *      none
C      *
C      *****

C      *****
C      *
C      *      Named COMMON blocks used in this routine:
C      *
C      *      CONST - Turbine and other constants used in load
C      *      calculations.
C      *      LIMITC - Holds values used in the LIMITS routine.
C      *      POSITN - Holds parameters related to blade position
C      *      such as PHI, PSI, etc.
C      *      SARAYS - Holds new and old values for the general-
C      *      ized coordinates.
C      *
C      *****

C      *****
C      *
C      *      Local and dummy variables used in this routine:
C      *
C      *      IPSIST - The next STEPMX station in integer degrees.
C      *      NEW - Array index for new data.
C      *      NSHAPS - Number of blade shape functions, 4 maximum.
C      *      NSHP - Counter on DO loops for the coordinate
C      *      shape function.
C      *      STEMP - Temporary array holding the tip displace-
C      *      ment values. The third dimension repre-
C      *      sents the order of the time derivative.
C      *
C      *****

```

```

REAL      STEMP (4,0:1,0:2)

INTEGER    IPSIST
INTEGER    NEW
INTEGER    NSHAPS
INTEGER    NSHP

```

```

INCLUDE    'C:INCLUDE\CONST2.INC'

```

```

INCLUDE    'C:INCLUDE\LIMITC.INC'

```

```

INCLUDE    'C:INCLUDE\POSITN.INC'

```

```

INCLUDE    'C:INCLUDE\SARAYS.INC'

```

```

SAVE      NEW

```

```

DATA      NEW / 1 /

```

```

C      Move the values stored in STEMP into SNEW.

```

```

DO 10 NSHP=1,NSHAPS

```

```

    SNEW(NSHP,0,IPSIST) = STEMP(NSHP,NEW,0)

```

```
SNEW(NSHP,1,IPSIST) = STEMP(NSHP,NEW,1)
SNEW(NSHP,2,IPSIST) = STEMP(NSHP,NEW,2)
```

10 CONTINUE

```
C      Set the STEPMX station pointer, IPSIST, for the next STEPMX
C      location on the rotor disk.
```

```
IPSIST = IPSIST + STEPMX*RAD2DG + 0.001
```

```
RETURN
END
SUBROUTINE SETUP
```

```
C      *****
C      *
C      * Subroutine SETUP allows the user to interactively *
C      * change the 'free' variables of FLAP. The 'free' vari- *
C      * ables are those that do not affect the computation of *
C      * the coefficient matrices or property arrays and which *
C      * are not specifically machine dependent. *
C      *
C      *****

C      *****
C      *
C      * External references in this routine: *
C      *
C      * none *
C      *
C      *****

C      *****
C      *
C      * Named COMMON blocks used in this routine: *
C      *
C      * BLADE - Holds blade property values such as stiff- *
C      * ness and mass distributions. *
C      * CONST Turbine and other constants used in load *
C      * calculations. *
C      * LITERL - Holds data set titles. *
C      * TURBN - Holds turbine parameters such as number of *
C      * blades, rotor speed, etc. *
C      * WIND - Holds wind shear and tower shadow parame- *
C      * ters. *
C      *
C      *****

C      *****
C      *
C      * Local and dummy variables used in this routine: *
C      *
C      * ANS - Used to store responses to questions. *
C      * ICASE - Number of variable to be changed. *
C      *
C      *****
```

```

INTEGER      ICASE

CHARACTER*1  ANS

INCLUDE      'C:INCLUDE\BLADE2.INC'

INCLUDE      'C:INCLUDE\CONST2.INC'

INCLUDE      'C:INCLUDE\LITERL.INC'

INCLUDE      'C:INCLUDE\TRBINF.INC'

INCLUDE      'C:INCLUDE\TURBN.INC'

INCLUDE      'C:INCLUDE\WIND2.INC'

```

```
1000 FORMAT ( / ' Current values for the "free" variables:'
```

```

&      // ' 1 ALENTH = ' , F10.4 , ' feet      '
&      ' 12 PHIAMP = ' , F10.4 , ' degrees'
&      / ' 2 ALPHAO = ' , F10.4 , ' degrees  '
&      ' 13 PHIOMG = ' , F10.4 , ' degrees/sec'
&      / ' 3 BETA0 = ' , F10.4 , ' degrees  '
&      ' 14 PSISHD = ' , F10.4 , ' degrees'
&      / ' 4 CHI = ' , F10.4 , ' degrees  '
&      ' 15 PSIZER = ' , F10.4 , ' degrees'
&      / ' 5 GRAV = ' , F10.4 , ' feet/sec^2 '
&      ' 16 RHOAIR = ' , F10.4 , ' Slugs/feet^3'
&      / ' 6 HUBHT = ' , F10.4 , ' feet      '
&      ' 17 SHERXP = ' , F10.4
&      / ' 7 KSHADW = ' , I10 , 12X
&      ' 18 THETAP = ' , F10.4 , ' degrees'
&      / ' 8 NBLADS = ' , I10 , 12X
&      ' 19 THETAT = ' , F10.4 , ' degrees'
&      / ' 9 NSHAPS = ' , I10 , 12X
&      ' 20 TSUBO = ' , F10.4
&      / ' 10 OMEGA = ' , F10.4 , ' RPM      '
&      ' 21 TSUBP = ' , F10.4
&      / ' 11 PHIO = ' , F10.4 , ' degrees  '
&      ' 22 VHUB = ' , F10.4 , ' feet/second'
&      / ' 23 TIMINC = ' , F10.6 , ' seconds  '
&      ' 24 NUMSCN = ' , I10)

```

```
2000 FORMAT ( A )
```

C Print the values of the free variables.

```

100 PRINT 1000, ALENTH , PHIAMP
&      , ALPHAO , PHIOMG
&      , BETA0 , PSISHD
&      , CHI , PSIZER
&      , GRAV , RHOAIR
&      , HUBHT , SHERXP
&      , KSHADW , THETAP
&      , NBLADS , THETAT
&      , NSHAPS , TSUBO
&      , OMEGA , TSUBP
&      , PHIO , VHUB
&      , TIMINC , NUMSCN

```

C Allow user to change values of the 'free' variables. Display
C values of all variables after each change.

```
200 PRINT *, 'Would you like to change any values? (Y,N) > '  
    READ 2000, ANS  
  
    IF ( ( ANS .EQ. 'Y' ) .OR. ( ANS .EQ. 'y' ) ) THEN  
  
210 PRINT *, 'Enter the number of the variable you would like'  
    PRINT *, 'to change (1-24) > '  
    READ *, ICASE  
  
    GO TO (300,302,305,310,315,320,325,330,335,340,345  
&      ,350,355,360,365,370,375,380,385,390,392,395  
&      , 403, 404) ICASE  
  
    PRINT *, ' >>> Invalid response. Please try again. <<<'  
    PRINT *, ' '  
  
    GO TO 210  
  
300 PRINT *, 'Enter new REAL value for ALENTH > '  
    READ *, ALENTH  
    GO TO 100  
  
302 PRINT *, 'Enter new REAL value for ALPHAO > '  
    READ *, ALPHAO  
    GO TO 100  
  
305 PRINT *, 'Enter new REAL value for BETA0 > '  
    READ *, BETA0  
    GO TO 100  
  
310 PRINT *, 'Enter new REAL value for CHI > '  
    READ *, CHI  
    GO TO 100  
  
315 PRINT *, 'Enter new REAL value for GRAV > '  
    READ *, GRAV  
    GO TO 100  
  
320 PRINT *, 'Enter new REAL value for HUBHT > '  
    READ *, HUBHT  
    GO TO 100  
  
325 PRINT *, 'Enter new INTEGER value for KSHADW > '  
    READ *, KSHADW  
    GO TO 100  
  
330 PRINT *, 'Enter new INTEGER value for NBLADS > '  
    READ *, NBLADS  
    GO TO 100  
  
335 PRINT *, 'Enter new INTEGER value for NSHAPS > '  
    READ *, NSHAPS  
    GO TO 100  
  
340 PRINT *, 'Enter new REAL value for OMEGA > '  
    READ *, OMEGA
```

```

GO TO 100

345 PRINT *, 'Enter new REAL value for PHIO > '
    READ *, PHIO
    GO TO 100

350 PRINT *, 'Enter new REAL value for PHIAMP > '
    READ *, PHIAMP
    GO TO 100

355 PRINT *, 'Enter new REAL value for PHIOMG > '
    READ *, PHIOMG
    GO TO 100

360 PRINT *, 'Enter new REAL value for PSISHD > '
    READ *, PSISHD
    GO TO 100

365 PRINT *, 'Enter new REAL value for PSIZER > '
    READ *, PSIZER
    GO TO 100

370 PRINT *, 'Enter new REAL value for RHOAIR > '
    READ *, RHOAIR
    GO TO 100

375 PRINT *, 'Enter new REAL value for SHERXP > '
    READ *, SHERXP
    GO TO 100

380 PRINT *, 'Enter new REAL value for THETAP > '
    READ *, THETAP
    GO TO 100

385 PRINT *, 'Enter new REAL value for THETAT > '
    READ *, THETAT
    GO TO 100

390 PRINT *, 'Enter new REAL value for TSUBO > '
    READ *, TSUBO
    GO TO 100

392 PRINT *, 'Enter new REAL value for TSUBP > '
    READ *, TSUBP
    GO TO 100

395 PRINT *, 'Enter new REAL value for VHUB > '
    READ *, VHUB
    GO TO 100

403 PRINT *, 'Enter new REAL value for TIMINC>'
    READ *, TIMINC
    PRINT *, TIMINC
    GO TO 100

404 PRINT *, 'Enter new REAL value for NUMSCN>'
    READ *, NUMSCN
    PRINT *, NUMSCN
    GO TO 100

```

```

ELSE IF ( ( ANS .NE. 'N' ) .AND. ( ANS .NE. 'n' )
& .AND. ( ANS .NE. ' ' ) ) THEN

PRINT *, '>>> Invalid response. Please try again. <<<'
PRINT *, ' '

GO TO 200

END IF

```

C Compute commonly used constants.

```

RR      = BLTIP + HUBRAD
ABAR    = ALENTH/RR
RROMGA  = RR*OMEGA*PI/30.0
CTHP    = COS( THETAP/RAD2DG )
STHP    = SIN( THETAP/RAD2DG )

```

```

RETURN
END
SUBROUTINE SHAPES ( NPTS )

```

```

C *****
C *
C * Subroutine SHAPES computes the values of the four co- *
C * ordinate shape functions at each of the NPTS stations *
C * along the blade. This is done for all four shape func- *
C * tions regardless of the value specified in NSHAPS. *
C * This routine is run only when the program is first in- *
C * itialized and is not run again for any subsequent iter- *
C * ations of the RUN routine. *
C * *
C * These functions are identical to those included in the *
C * COEFFS routine of Module 1. *
C * *
C *****

```

```

C *****
C *
C * External references in this routine: *
C * *
C * none *
C * *
C *****

```

```

C *****
C *
C * Named COMMON blocks used in this routine: *
C * *
C * BLADE - Holds blade property values such as stiff- *
C * ness and mass distributions. *
C * *
C *****

```

```

C *****
C *
C * Local and dummy variables used in this routine: *

```

```

C      *
C      *      I      - Generic index.
C      *      L      - Blade length, BLTIP.
C      *      LSQRD  - Square of blade length.
C      *      NPTS   - Number of points along the blade used to
C      *                perform Simpson's integration for calculat-
C      *                ing the moments and forces at the blade
C      *                root.
C      *      STEP   - Distance between points along the blade.
C      *      X      - Location along the blade.
C      *      X2     - X^2.
C      *      X3     - X^3.
C      *      X4     - X^4.
C      *
C      *****

```

```

REAL      L
REAL      LSQRD
REAL      STEP
REAL      X
REAL      X2
REAL      X3
REAL      X4
REAL      POLY(4,21)
REAL      POLYDT(4,21)
REAL      POLYDD(4,21)

```

```

INTEGER   I
INTEGER   NPTS

```

```

INCLUDE   'C:INCLUDE\BLADE2.INC'

```

```

INCLUDE   'C:INCLUDE\SHAPE.INC'

```

```

INCLUDE   'C:INCLUDE\MODAL.INC'

```

```

C      Initialize some constants.

```

```

STEP = 1.0/( NPTS - 1 )
L     = BLTIP
LSQRD = BLTIP**2
X     = -STEP

```

```

DD 20 I = 1, NPTS

```

```

X = X + STEP
X2 = X * X
X3 = X2 * X
X4 = X3 * X

```

```

POLY(1,I) = X2*(( X - 4.0 ) * X + 6.0) / 3
POLY(2,I) = X3*(( 3 * X - 10.0 ) * X + 10.0) / 3
POLY(3,I) = X4*(( 2 * X - 6.0 ) * X + 5.0)
POLY(4,I) = X * X4 * (( 10 * X - 28.0 ) * X + 21.0) / 3
POLYDT(1,I) = 4 * X * (( X - 3.0 ) * X + 3.0) / ( 3 * L )
POLYDT(2,I) = 5 * X2 * (( 3 * X - 8.0 ) * X + 6.0) / ( 3 * L )
POLYDT(3,I) = 2 * X3 * (( 6 * X - 15.0 ) * X + 10.0) / L
POLYDT(4,I) = 7 * X4 * (( 10 * X - 24.0 ) * X + 15.0) / ( 3 * L )

```



```

POLYDD(1,I) = 4 *(( X - 2.0 ) * X + 1.0) / LSQRD
POLYDD(2,I) = 20 * X * (( 3 * X - 6.0 ) * X + 3.0) / ( 3 * LSQRD )
POLYDD(3,I) = 60 * X2 * (( X - 2.0 ) * X + 1.0) / LSQRD
POLYDD(4,I) = 140 * X3 * (( X - 2.0 ) * X + 1.0) / LSQRD

20 CONTINUE

DO 670 I = 1,4
DO 660 J = 1,NPTS
SHAPE(I,0,J) = 0.
SHAPE(I,1,J) = 0.
SHAPE(I,2,J) = 0.
660 CONTINUE
670 CONTINUE

DO 700 I = 1,NPTS
DO 690 J = 1,4
DO 680 K = 1,4
SHAPE(J,0,I) = SHAPE(J,0,I) + LAMDA(K,J) * POLY(K,I)
SHAPE(J,1,I) = SHAPE(J,1,I) + LAMDA(K,J) * POLYDT(K,I)
SHAPE(J,2,I) = SHAPE(J,2,I) + LAMDA(K,J) * POLYDD(K,I)
680 CONTINUE
690 CONTINUE
700 CONTINUE

DO 703 I = 1,4
TIPDFL = 1.
DO 701 K = 1,NPTS
SHAPE(I,0,K) = SHAPE(I,0,K) / TIPDFL
SHAPE(I,1,K) = SHAPE(I,1,K) / TIPDFL
SHAPE(I,2,K) = SHAPE(I,2,K) / TIPDFL
701 CONTINUE
703 CONTINUE

RETURN
END
FUNCTION SIMPSN ( LOWLIM , UPLIM , NPTS , FOFX )

```

```

C *****
C *
C * Function SIMPSN performs a composite Simpson's integra- *
C * tion of a given data set. This routine is identical to *
C * the SIMPSN routine used by COEFFS in Module 1. *
C *
C *****

C *****
C *
C * External references in this routine: *
C *
C * none *
C *
C *****

C *****
C *
C * Named COMMON blocks used in this routine: *
C *
C * none *

```



```

C      * result of multiplying the inverse CMMASS matrix by the *
C      * CMMASS matrix is printed on the screen for diagnostic *
C      * purposes. It should be very close to the Identity mat- *
C      * rix. *
C      * *
C      *****
C
C      *****
C      * *
C      * External references in this routine: *
C      * *
C      *   INVERT - Provides an interface to the GAUSS routine. *
C      *   MULT   Premultiplies the incoming matrix by the *
C      *           inverse CMMASS matrix. *
C      * *
C      *****
C
C      *****
C      * *
C      * Named COMMON blocks used in this routine: *
C      * *
C      *   INV    - Holds the inverse of the mass matrix. *
C      *   MATRX1 - Holds stiffness coefficient matrices. *
C      *   MATRX2 - Holds other matrices related to coriolis *
C      *           stiffening, gravity, etc. *
C      *   TURBN  - Holds turbine parameters such as number of *
C      *           blades, rotor speed, etc. *
C      * *
C      *****
C
C      *****
C      * *
C      * Local and dummy variables used in this routine: *
C      * *
C      *   I .    - Generic index. *
C      *   J      - Generic index. *
C      *   K      - Generic index. *
C      *   TEMP   - A temporary storage array used for matrix *
C      *           manipulation. *
C      * *
C      *****

```

```

REAL      TEMP   (4,4)

INTEGER   I
INTEGER   J
INTEGER   K

INCLUDE   'C:\INCLUDE\INV.INC'

INCLUDE   'C:\INCLUDE\MATRX1.INC'

INCLUDE   'C:\INCLUDE\MATRX2.INC'

INCLUDE   'C:\INCLUDE\TURBN.INC'

```

```

4000 FORMAT ( 1X , 4F12.7 / )

```

```

C      Invert the CMASS matrix.

      CALL INVERT ( CMASS , AINVR , NSHAPS )

C      Premultiply the other coefficient matrices by the inverse
C      CMASS matrix.

      CALL MULT ( CKBEND , NSHAPS , NSHAPS )
      CALL MULT ( CKTOMG , NSHAPS , NSHAPS )
      CALL MULT ( CKTGRV , NSHAPS , NSHAPS )
      CALL MULT ( CKQLOD , NSHAPS , NSHAPS )

C      The coefficient matrix CKTCRL must be separated into individual
C      2-dimensional matrices for multiplication by the inverse CMASS
C      matrix. Then the individual matrices are recombined into the
C      original 3-dimensional form.

      DO 140 I=1,NSHAPS

          DO 110 J=1,NSHAPS

              DO 100 K=J,NSHAPS

                  TEMP(J,K) = CKTCRL(I,J,K)
                  TEMP(K,J) = CKTCRL(I,K,J)

100          CONTINUE

110          CONTINUE

              CALL MULT ( TEMP , NSHAPS , NSHAPS )

              DO 130 J=1,NSHAPS

                  DO 120 K=J,NSHAPS

                      CKTCRL(I,J,K) = TEMP(J,K)
                      CKTCRL(I,K,J) = TEMP(K,J)

120          CONTINUE

130          CONTINUE

140          CONTINUE

C      Load three of the 1-dimensional matrices into a single matrix
C      of order 4 by 3 and premultiply it by the inverse CMASS ma-
C      trix. Then move the resulting columns back into the original
C      vectors.

      DO 200 J=1,NSHAPS

          TEMP(J,1) = CMRIGD(J)
          TEMP(J,2) = CMBLNC(J)
          TEMP(J,3) = CMGRAV(J)

200          CONTINUE

```

```

CALL MULT ( TEMP , NSHAPS , 3 )

DO 210 J=1,NSHAPS

    CMRIGD(J) = TEMP(J,1)
    CMBLNC(J) = TEMP(J,2)
    CMGRAV(J) = TEMP(J,3)

210 CONTINUE

C      Premultiply the CMMASS matrix by its inverse and save for diag-
C      nostic purposes. Print out the result.

CALL MULT ( CMMASS , NSHAPS , NSHAPS )

PRINT *, ' '
PRINT *, 'Product of CMMASS premultiplied by its inverse:'
PRINT *, ' '

DO 400 I=1,NSHAPS
400 PRINT 4000, ( CMMASS(I,J) , J=1,NSHAPS )

C      CMMASS is replaced by its inverse for use in the RUN routine
C      in computing the solution for the aerodynamic forces.

DO 500 I=1,NSHAPS

    DO 510 J=1,NSHAPS
510    CMMASS(I,J) = AINVR(I,J)

500 CONTINUE

RETURN
END
SUBROUTINE STRTUP ( STEMP , NPTS )

C      *****
C      *
C      * Subroutine STRTUP computes the static deflection of the *
C      * blade at the startup position (Psi=270). This is then *
C      * used to compute further values based on an initial de- *
C      * flection. The initial static deflection is computed *
C      * based on the blade azimuth and the static (instantane- *
C      * ous) aerodynamic loads on the blade. *
C      *
C      *****

C      *****
C      *
C      * External references in this routine: *
C      *
C      * AFORCE - Calculates the value of the aerodynamic *
C      * force integral. *
C      * FORM1 - Calculates the values of the blade dis- *
C      * placement function. *

```

```

C      *      INVERT - Provides an interface to the GAUSS routine.  *
C      *      NXPPhi - Calculates the next values of the yaw vari- *
C      *                   ables. *
C      * *
C      *****

```

```

C      *****
C      * *
C      *      Named COMMON blocks used in this routine: *
C      * *
C      *      AIRFRC - Holds values used in aerodynamic calcula- *
C      *                   tions. *
C      *      CONST - Turbine and other constants used in load *
C      *                   calculations. *
C      *      MATRX1 - Holds stiffness coefficient matrices. *
C      *      MATRX2 - Holds other matrices related to coriolis *
C      *                   stiffening, gravity, etc. *
C      *      POSITN - Holds parameters related to blade position *
C      *                   such as PHI, PSI, etc. *
C      *      SARAYS - Holds new and old values for the general- *
C      *                   ized coordinates. *
C      *      START - Holds initial blade deflection. *
C      *      TURBN - Holds turbine parameters such as number of *
C      *                   blades, rotor speed, etc. *
C      * *
C      *****

```

```

C      *****
C      * *
C      *      Local and dummy variables used in this routine: *
C      * *
C      *      BLDANG - Blade azimuth position used in the teeter- *
C      *                   ing rotor option. *
C      *      FSTAR - Complicated term. *
C      *      I - Generic index. *
C      *      IDENT - The identity matrix. *
C      *      K - Generic index. *
C      *      KINVRS - Inverse of KSTAR matrix. *
C      *      KSTAR - Complicated term. *
C      *      L - Generic index. *
C      *      M - Generic index. *
C      *      NPTS - Number of points along the blade used to *
C      *                   perform Simpson's integration for calculat- *
C      *                   ing the moments and forces at the blade *
C      *                   root. (passed from FLAP1) *
C      *      OMSGQR - Omega^2. *
C      *      STEMP - Temporary array holding the tip displace- *
C      *                   ment values. The third dimension repre- *
C      *                   sents the order of the time derivative. *
C      *      TIMNOW - Current time. *
C      * *
C      *****

```

```

REAL      BLDANG
REAL      FSTAR (4)
REAL      IDENT (4,4)
REAL      KINVRS (4,4)
REAL      KSTAR (4,4)
REAL      OMSGQR
REAL      STEMP (4,0:1,0:2)

```

```

REAL      TIMNOW

INTEGER   I
INTEGER   K
INTEGER   L
INTEGER   M
INTEGER   NPTS

INCLUDE   'C:INCLUDE\AIRFRG.INC'

INCLUDE   'C:INCLUDE\CONST2.INC'

INCLUDE   'C:INCLUDE\MATRX1.INC'

INCLUDE   'C:INCLUDE\MATRX2.INC'

INCLUDE   'C:INCLUDE\POSITN.INC'

INCLUDE   'C:INCLUDE\SARAYS.INC'

INCLUDE   'C:INCLUDE\START.INC'

INCLUDE   'C:INCLUDE\TURBN.INC'

```

C Initialize some arrays.

```
DO 120 M=1,NSHAPS
```

```
  DO 100 I=0,2
```

```
    STEMP(M,0,I) = 0.0
```

```
    STEMP(M,1,I) = 0.0
```

```
100  CONTINUE
```

```
  DO 110 K=1,NSHAPS
```

```
110  IDENT(M,K) = 0.0
```

```
    IDENT(M,M) = 1.0
```

```
120  CONTINUE
```

Compute the FAERO values for use in calculating the FSTAR values. These are actually FAERO multiplied by the inverse CMMASS matrix.

```
TIMNOW = TIME(1)
```

```
CALL NXTPHI ( TIMNOW )
```

```
BLDANG = PSI(1)
```

```
CALL FORM1 ( STEMP , NPTS , NSHAPS )
```

```
CALL AFORCE ( NPTS , BLDANG )
```

```
BLDANG = PSI(1)
```

```
CALL FORM1 ( STEMP , NPTS , NSHAPS )  
CALL AFORCE ( NPTS , BLDANG )
```

```
C      Compute the FSTAR values.
```

```
OMGSQR = OMEGA**2
```

```
DO 310 M=1,NSHAPS
```

```
      FSTAR(M) = FAERO(M) - OMGSQR*BETAO*CTHP*CMRIGD(M)  
&      + OMGSQR*STHP*CTHP*CMBLNC(M)  
&      - GRAV*( CHI*CTHP + STHP )*CMGRAV(M)
```

```
310  CONTINUE
```

```
C      Compute the KSTAR values.
```

```
DO 410 M=1,NSHAPS
```

```
      DO 400 K=1,NSHAPS  
400   KSTAR(M,K) = CKBEND(M,K)  
&      + OMGSQR*( CKTOMG(M,K) - STHP*STHP*CKQLOD(M,K)  
&      - STHP*STHP*IDENT(M,K) )
```

```
410  CONTINUE
```

```
C      Invert the KSTAR matrix.
```

```
CALL INVERT ( KSTAR , KINVRS , NSHAPS )
```

```
C      Compute  $S(K) = S(L) = (KSTAR - INVERSE(L,M)) * FSTAR(M)$ .
```

```
DO 510 L=1,NSHAPS
```

```
      S0(L) = 0.0
```

```
      DO 500 M=1,NSHAPS
```

```
500   S0(L) = S0(L) + KINVRS(L,M)*FSTAR(M)
```

```
510  CONTINUE
```

```
C      Load the resulting static deflection values into the appropriate  
C      tip data array and set all other values to zero.
```

```
DO 610 K=1,NSHAPS
```

```
      DO 600 I=0,1
```

```
          STEMP(K,I,0) = S0(K)  
          STEMP(K,I,1) = 0.0  
          STEMP(K,I,2) = 0.0
```


600 CONTINUE

610 CONTINUE

RETURN

END

SUBROUTINE TRACE (STEPMX , NPTS)

```
*****
*                               *
* Subroutine TRACE prints out the values of certain vari- *
* ables at each printout interval around the disk. The *
* printout includes the current values of DELPSI, the *
* blade tip acceleration, velocity and deflection, the *
* error value and the values of the relative fluid veloc- *
* ity in the edgewise and flapwise directions. This is *
* done for each STEPMX station and is part of the diag- *
* nostic features of the code. It is controlled by the *
* TRACEF flag set in the subroutine LIMITS. *
*                               *
*****
```

```
*****
*                               *
* External references in this routine: *
*                               *
* none *
*                               *
*****
```

```
*****
*                               *
* Named COMMON blocks used in this routine: *
*                               *
* AIRFRC - Holds values used in aerodynamic calcula- *
* tions. *
* CONST Turbine and other constants used in load *
* calculations. *
* POSITN - Holds parameters related to blade position *
* such as PHI, PSI, etc. *
* TURBN - Holds turbine parameters such as number of *
* blades, rotor speed, etc. *
* VREL1 - Holds blade section velocity components. *
*                               *
*****
```

```
*****
*                               *
* Local and dummy variables used in this routine: *
*                               *
* JCALLS - Print counter. *
* K - Generic index. *
* NEW - Array index for new data. *
* NPTS - Number of points along the blade used to *
* perform Simpson's integration for calculat- *
* ing the moments and forces at the blade *
* root. (passed from FLAP1) *
*                               *
*****
```

```

C      *      STEMP - Temporary array holding the tip displace- *
C      *      ment values. The third dimension repre- *
C      *      sents the order of the time derivative. *
C      *      X      - Psi in degrees. *
C      *      XX     - DeltaPsi in degrees. *
C      *      *      *
C      *****

```

```

REAL      STEMP (4,0:1,0:2)
REAL      X
REAL      XX

```

```

INTEGER    JCALLS
INTEGER    K
INTEGER    NEW
INTEGER    NPTS

```

```

INCLUDE    'C:\INCLUDE\AIRFRC.INC'

```

```

INCLUDE    'C:\INCLUDE\CONST2.INC'

```

```

INCLUDE    'C:\INCLUDE\POSITN.INC'

```

```

INCLUDE    'C:\INCLUDE\TURBN.INC'

```

```

INCLUDE    'C:\INCLUDE\VREL1.INC'

```

```

SAVE      JCALLS
SAVE      NEW

```

```

DATA      JCALLS / -1 /
DATA      NEW    / 1 /

```

```

1000 FORMAT( / ' Psi d-Psi Accel Velocity Deflect Error
&          , ' FAero VETa-Tip VZeta-Tip' / )
1100 FORMAT( F5.0 , F6.2 , 2F10.3 , F8.3 , F11.6 , F10.3 , 2F9.3 )

```

```

C      Get Psi and delta-Psi in degrees.

```

```

X = PSI(1)*RAD2DG
XX = DELPSI(1)*RAD2DG

```

```

C      JCALLS is used to print column headings every ten lines.

```

```

JCALLS = JCALLS + 1

```

```

IF ( MOD( JCALLS , 10 ) .EQ. 0 ) WRITE (4,1000)

```

```

DO 100 K=1,NSHAPS
100 WRITE (4,1100) X , XX , STEMP(K,NEW,2) , STEMP(K,NEW,1)
&          , STEMP(K,NEW,0) , ERROR , FAERO(K) , VETA(NPTS)
&          , VZETA(NPTS)

```

```

RETURN
END
SUBROUTINE TRMTST ( ITRIM )

```

```

C *****
C *
C * Subroutine TRMTST compares the results of two consecu- *
C * tive rotor revolutions. The trim error condition is *
C * satisfied if the value of QUANT2 times the trim error *
C * fraction is less than the QUANT1 value. If any one az- *
C * imuth location fails the trim test criterion, control *
C * is returned to the calling routine and another disk *
C * revolution is performed. If all the STEPMX stations *
C * pass the test, then the trim solution exists and the *
C * loads are computed. *
C *
C *****

C *****
C *
C * External references in this routine: *
C *
C * none *
C *
C *****

C *****
C *
C * Named COMMON blocks used in this routine: *
C *
C * CONST - Turbine and other constants used in load *
C * calculations. *
C * LIMITC - Holds values used in the LIMITS routine. *
C * SARAYS - Holds new and old values for the general- *
C * ized coordinates. *
C * START - Holds initial blade deflection. *
C * TURBN - Holds turbine parameters such as number of *
C * blades, rotor speed, etc. *
C *
C *****

C *****
C *
C * Local and dummy variables used in this routine: *
C *
C * I - Generic index. *
C * ISTEPMX - STEPMX integerized. *
C * ITRIM - Flag that indicates that the trim solution *
C * has been completed when set to 0. *
C * NSHP - Counter on DO loops for the coordinate *
C * shape function. *
C * QUANT1 - This contains the sum of the differences *
C * between the blade tip deflections computed *
C * for this rotor revolution and the last rev- *
C * olution. This summation is also over the *
C * coordinate shapes used in this run. *
C * QUANT2 - This contains the sum of the blade tip de- *
C * flections computed by subroutine STRTUP for *
C * the static blade deflection of each coordi- *
C * nate function used in this run. *
C *
C *****

```

```

REAL      QUANT1
REAL      QUANT2

INTEGER   I
INTEGER   ISTEPMX
INTEGER   ITRIM
INTEGER   NSHP

INCLUDE   'C:INCLUDE\CONST2.INC'

INCLUDE   'C:INCLUDE\LIMITC.INC'

INCLUDE   'C:INCLUDE\SARAYS.INC'

INCLUDE   'C:INCLUDE\START.INC'

INCLUDE   'C:INCLUDE\TURBN.INC'

C      Integerize the STEPMX interval.

ISTPMX = RAD2DG*STEPMX + 0.001

C      Compute the sum of the tip deflections that were computed in
C      subroutine STRTUP.

QUANT2 = 0.0

DO 100 NSHP=1,NSHAPS
100 QUANT2 = QUANT2 + SO(NSHP)

QUANT2 = ABS( QUANT2 )

C      Check each STEPMX station around the disk.

DO 210 I=ISTPMX,360,ISTPMX

QUANT1 = 0.0

C      Compute the sum of the differences between tip deflections
C      for this rotor revolution and the last.

DO 200 NSHP=1,NSHAPS
200 QUANT1 = QUANT1 + SNEW(NSHP,0,I) - SOLD(NSHP,I)

C      Compare the trim error fraction to the current deflection
C      differences.  If any station fails the test, return for
C      another revolution.

IF( ABS( QUANT1 ) .GT. ( 0.01*QUANT2*TRMERR ) ) RETURN

210 CONTINUE

```

```

C      All stations satisfied the trim error criterion. The trim solution
C      is now complete. Set the ITRIM flag to zero to signal it. Loads
C      can now be computed and the yaw run started.

```

```

ITRIM = 0

```

```

RETURN

```

```

END

```

```

FUNCTION TRPZOD ( LOWLIM , BLTIP , FOF , NPTS )

```

```

C      *****
C      *
C      * Function TRPZOD performs composite trapezoidal integra- *
C      * tion on a set of data points transmitted from the *
C      * calling routine. For derivation of the formula and *
C      * limitations, see Carnahan, p. 78 (see full reference in *
C      * comments for function SIMPSN). For computational effi- *
C      * ciency, the interval width is not used in the formula- *
C      * tion until the end when it is multiplied by the sum. *
C      *
C      * This function is similar to function TRAP in Module 1 *
C      * of the FLAP code. *
C      *
C      *****

C      *****
C      *
C      * External references in this routine: *
C      *
C      * none *
C      *
C      *****

C      *****
C      *
C      * Named COMMON blocks used in this routine: *
C      *
C      * none *
C      *
C      *****

C      *****
C      *
C      * Local and dummy variables used in this routine: *
C      *
C      * BLTIP - Blade length. All integrations using this *
C      * function are performed from the lower limit *
C      * indexed by LOWLIM to the upper limit BLTIP. *
C      *
C      * FOF - Array of data points to be integrated. They *
C      * are treated by this function as the value *
C      * of a function evaluated at specific points. *
C      *
C      * H - Subinterval length given by H=(B-A)/N. *
C      *
C      * I - Index into the FOF array. *
C      *
C      * LOWLIM - Index of the lower integration limit. The *
C      * blade position indexed by LOWLIM is given *
C      * by BLTIP*(LOWLIM-1)/(NPTS-1). *
C      *
C      * NPTS - Number of points along the blade used to *
C      * perform Simpson's integration for calculat- *

```

```

C      *           ing the moments and forces at the blade *
C      *           root. (passed from FLAP1)                *
C      *      TRPZOD - Value of the integral from the blade posi- *
C      *           tion indexed by LOWLIM to BLTIP.          *
C      *                                                     *
C      *****

```

```

REAL      BLTIP
REAL      FOF      (201)
REAL      H
REAL      TRPZOD

```

```

INTEGER   I
INTEGER   LOWLIM
INTEGER   NPTS

```

```

C      Check to see if the lower and upper limits of integration are
C      the same. If so, the integral is zero.

```

```

IF ( LOWLIM .EQ. NPTS ) THEN

```

```

    TRPZOD = 0.0
    RETURN

```

```

END IF

```

```

C      Compute the distance between data points.

```

```

H = BLTIP/( NPTS - 1 )

```

```

C      Initialize integral to the contribution of the end points.

```

```

TRPZOD = 0.5*( FOF(LOWLIM) + FOF(NPTS) )

```

```

C      If there are only two data points, then we are done.

```

```

IF ( LOWLIM+1 .EQ. NPTS ) GO TO 20

```

```

C      Add in the contribution of the intermediate points.

```

```

DO 10 I=LOWLIM+1,NPTS-1
10 TRPZOD = TRPZOD + FOF(I)

```

```

C      Multiply by the interval width and return.

```

```

20 TRPZOD = H*TRPZOD

```

```

RETURN
END
SUBROUTINE VREL ( INBORD , NPTS , BLDANG )

```

```

C *****
C *
C * Subroutine VREL computes the relative velocity compo- *
C * nents for each of the blade stations. These values are *
C * needed to compute the aerodynamic forces. *
C *
C *****

C *****
C *
C * External references in this routine: *
C *
C *   INDUCD - Calculates the induced velocities along the *
C *           blade. *
C *   WINDVL - Computes wind velocity components. *
C *
C *****

C *****
C *
C * Named COMMON blocks used in this routine: *
C *
C *   BLADE - Holds blade property values such as stiff- *
C *           ness and mass distributions. *
C *   CONST - Turbine and other constants used in load *
C *           calculations. *
C *   DELTV - Holds turbine inputs for possible future *
C *           use. Not currently used. *
C *   FORMS - Holds blade deflections. *
C *   POSITN - Holds parameters related to blade position *
C *           such as PHI, PSI, etc. *
C *   TURBN - Holds turbine parameters such as number of *
C *           blades, rotor speed, etc. *
C *   VINDUC - Holds induced velocity components. *
C *   VREL1 - Holds blade section velocity components. *
C *   WNDVEL - Holds values used in wind shear and tower *
C *           shadow computations. *
C *
C *****

C *****
C *
C * Local and dummy variables used in this routine: *
C *
C *   BLDANG - Blade azimuth position. *
C *   CPSI - Cosine of the blade angle. *
C *   I - Generic index. *
C *   INBORD - The number of blade stations that are not *
C *           on the airfoil section. INBORD is used in *
C *           other routines to differentiate between *
C *           sections of the blade with and without an *
C *           airfoil section. *
C *   NPTS - Number of points along the blade used to *
C *           perform Simpson's integration for calculat- *
C *           ing the moments and forces at the blade *
C *           root. (passed from FLAP1) *
C *   PHIDBR - Temporary storage. *
C *   PHIDCT - Temporary storage. *

```

```

C      *      PHIDST - Temporary storage.          *
C      *      QUANT1 - Temporary storage.          *
C      *      QUANT2 - Temporary storage.          *
C      *      QUANT3 - Temporary storage.          *
C      *      QUANT4 - Temporary storage.          *
C      *      R      - Distance from hub axis.      *
C      *      ROMEGA - Temporary storage.          *
C      *      SPSI   - Sine of the blade angle.     *
C      *      SPSI2  - Temporary storage.          *
C      *      SPSI3  - Temporary storage.          *
C      *      STEP   - Distance between points along the blade. *
C      *      X      - The radial location along the blade (nondi- *
C      *                mensional).                *
C      *      Z      - Blade station pointer. Z goes from zero to *
C      *                the tip.                    *
C      *
C      *****

```

```

REAL      BLDANG
REAL      CPSI
REAL      PHIDBR
REAL      PHIDCT
REAL      PHIDST
REAL      QUANT1
REAL      QUANT2
REAL      QUANT3
REAL      QUANT4
REAL      R
REAL      ROMEGA
REAL      SPSI
REAL      SPSI2
REAL      SPSI3
REAL      STEP
REAL      X
REAL      Z

```

```

INTEGER   I
INTEGER   INBORD
INTEGER   NPTS

```

```

INCLUDE   'C:\INCLUDE\BLADE2.INC'
INCLUDE   'C:\INCLUDE\CONST2.INC'
INCLUDE   'C:\INCLUDE\DELT.V.INC'
INCLUDE   'C:\INCLUDE\FORMS.INC'
INCLUDE   'C:\INCLUDE\POSITN.INC'
INCLUDE   'C:\INCLUDE\TURBN.INC'
INCLUDE   'C:\INCLUDE\VINDUC.INC'
INCLUDE   'C:\INCLUDE\VREL1.INC'
INCLUDE   'C:\INCLUDE\WINDVEL.INC'

```



```

C      Compute the wind velocity components and then the induced
C      velocity components.

CALL WINDVL ( NPTS , BLDANG )
CALL INDUCD ( INBORD , NPTS , BLDANG )

C      Set up constants used in this computation.

CPSI  = COS( BLDANG )
SPSI  = SIN( BLDANG )
SPSI2 = -SPSI*STHP
SPSI3 = -SPSI*CTHP
PHIDBR = PHI(1)/OMEGA
PHIDST = PHIDBR*STHP*SPSI
PHIDCT = PHIDBR*CTHP*SPSI
ROMEGA = 1.0/RRROMGA
STEP  = BLTIP/( NPTS - 1 )
Z      = 0.0

C      Compute the velocity components VEta and VZeta.

DO 100 I=1,NPTS

R = HUBRAD + Z

C      Clear the velocity components on the nonaerodynamic portion
C      of the blade.

IF ( I .LT. INBORD ) THEN

VETA(I) = 0.0
VZETA(I) = 0.0

ELSE

X      = R/RR
VETA(I) = -X*CTHP
VZETA(I) = -X*STHP - VV(1,I)*ROMEGA

QUANT1 = VINDR(I) + ROMEGA*( VWIND(I) - HUBVEL )
&      + ROMEGA*DELTVY(I) - DVIND(I)
QUANT2 = DELTVX(I)*ROMEGA + PHI(0)*VINDR(I)
QUANT3 = PHIDBR*( ABAR + BETA0*X )
QUANT4 = DELTVZ(I)*ROMEGA - CHI*VINDR(I)

VETA(I) = VETA(I) - QUANT1*STHP
&      + CPSI*( CTHP*( QUANT2 + QUANT3 )
&      + PHIDBR*VV(0,I)/RR )
&      + SPSI3*QUANT4 + X*PHIDST
VZETA(I) = VZETA(I) + QUANT1*CTHP
&      + CPSI*( (QUANT2 + QUANT3)*STHP )
&      + SPSI2*QUANT4 + X*PHIDCT

C      Convert the velocity components into dimensional form
C      before returning to the calling routine. The VEta term
C      is negated to account for the sign convention that pos-

```

```
C      itive velocities are from the leading edge to the trail-
C      ing edge.
```

```
VETA(I)  -VETA(I)*RRROMGA
VZETA(I) = VZETA(I)*RRROMGA
```

```
END IF
```

```
C      Increment the location along the blade and make another pass.
```

```
Z = Z + STEP
```

```
100 CONTINUE
```

```
RETURN
```

```
END
```

```
SUBROUTINE WINDVL ( NPTS , BLDANG )
```

```
C      *****
C      *
C      * Subroutine WINDVL computes the wind velocity components *
C      * along the blade for a given time and azimuth position. *
C      * Provision has been made to include a time dependent *
C      * function for the hub velocity, but none is included *
C      * now. Likewise, time dependent functions deltaX, deltaY *
C      * and deltaZ can be included in the future in the section *
C      * set aside for them here. They are now set to zero. *
C      *
C      *****
```

```
C      *****
C      *
C      * External references in this routine: *
C      *
C      * none *
C      *
C      *****
```

```
C      *****
C      *
C      * Named COMMON blocks used in this routine: *
C      *
C      * BLADE - Holds blade property values such as stiff- *
C      * ness and mass distributions. *
C      * CONST Turbine and other constants used in load *
C      * calculations. *
C      * DELTV - Holds turbine inputs for possible future *
C      * use. Not currently used. *
C      * POSITN - Holds parameters related to blade position *
C      * such as PHI, PSI, etc. *
C      * TURBN - Holds turbine parameters such as number of *
C      * blades, rotor speed, etc. *
C      * WIND - Holds wind shear and tower shadow parame- *
C      * ters. *
C      * WNDVEL - Holds values used in wind shear and tower *
C      * shadow computations. *
```

```

C      *
C      *****
C
C      *****
C      *
C      * Local and dummy variables used in this routine:
C      *
C      * BLDANG - Blade azimuth position used in the teeter-
C      *           ing rotor option.
C      * HH - Hub radius divided by its height.
C      * I - Generic index.
C      * J - Generic index.
C      * NPTS - Number of points along the blade used to
C      *         perform Simpson's integration for calculat-
C      *         ing the moments and forces at the blade
C      *         root.
C      * P - Complicated term.
C      * R - Location of the current point along the
C      *         blade.
C      * STEP - Distance between points along the blade.
C      *
C      *****

REAL      BLDANG
REAL      HH
REAL      P
REAL      R
REAL      STEP

INTEGER   I
INTEGER   J
INTEGER   NPTS

INCLUDE   'C:INCLUDE\BLADE2.INC'

INCLUDE   'C:INCLUDE\CONST2.INC'

INCLUDE   'C:INCLUDE\DELTV.INC'

INCLUDE   'C:INCLUDE\POSITN.INC'

INCLUDE   'C:INCLUDE\TURBN.INC'

INCLUDE   'C:INCLUDE\WIND2.INC'

INCLUDE   'C:INCLUDE\WNDVEL.INC'

INCLUDE   'C:INCLUDE\TRBINF.INC'

C      Compute the wind velocity at the hub. A time dependent function
C      may be added in the future.

      HUBVEL = VHUB

C      Compute the wind shear components.

R      = HUBRAD
STEP = BLTIP/( NPTS - 1 )

```

```

DO 110 I=1,NPTS

    HH = R/HUBHT

    WSHR(0,I) = 0.25*SHERXP*( SHERXP - 1.0 )*HH**2
    WSHR(1,I) = SHERXP*HH
C    WSHR(2,I) = 0.
    WSHR(2,I) = WSHR(0,I)
    WSHR(3,I) = 0.0
    WSHR(4,I) = 0.0
    WSHR(5,I) = 0.0

    R = R + STEP

    WSHEAR(I) = WSHR(0,I)

    DO 100 J=1,5
100    WSHEAR(I) = WSHEAR(I) + WSHR(J,I)*COS( J*BLDANG )

110 CONTINUE

C    Compute tower shadow effects. When blade #1 is close to 360
C    degrees azimuth, the second blade must know that it is in the
C    tower shadow.

    IF ( ABS( BLDANG - PSISHD ) .LE. PSIZER ) THEN

        P      = KSHADW*PI/PSIZER
        TSHADW = TSUBO + TSUBP*COS( P*( BLDANG - PSISHD ) )

    ELSE IF ( ABS( BLDANG - PSISHD - 2*PI ) .LE. PSIZER ) THEN

        P      = KSHADW*PI/PSIZER
        TSHADW = TSUBO + TSUBP*COS( P*( BLDANG - PSISHD - 2*PI ) )

    ELSE

        TSHADW = 0.0

    END IF

    DO 200 I=1,NPTS
200    VWIND(I) = HUBVEL*( 1.0 + WSHEAR(I) - TSHADW )

C *****
C *
C * This place is reserved for future time dependent functions. *
C *
C *****

C    Input the time dependent windspeed fluctuations if
C    working on a turbulent analysis: ITURB .EQ. 1

    R = HUBRAD/(HUBRAD+BLTIP)
    STEP = (1.-R)/(NPTS-1)

```

C Flag for deciding if working on a turbulence analysis.

```
IF( ITURB .EQ. 1 ) THEN
```

C Linearly interpolate along the blade span
C using the three values as interpolation points
C to get windspeed values along the entire 21
C set of blade points.

```
DO 600 I = 1, NPTS

    IF(R .LE. 0.3333333) THEN
        DELTVY(I)=(VYNOW1(1)-VYNOWH)*3.*R+VYNOWH
    ELSEIF(R .LE. 0.6666666)THEN
        DELTVY(I)=(VYNOW1(2)-VYNOW1(1))*3.*(R- .3333333)
&         + VYNOW1(1)
    ELSE
        DELTVY(I)=(VYNOW1(3)-VYNOW1(2))*3.*(R- .6666666)
&         + VYNOW1(2)
    ENDIF
    R=R+STEP
600 CONTINUE
```

```
ENDIF
```

```
RETURN
END
```

```
SUBROUTINE SERIES(M,N,A,B,NST,IPS,IPR)
REAL A(0:10,21)
REAL B(0:10,21)
REAL FACTOR
REAL FI
```

```
INTEGER IPS(360)
INTEGER M
INTEGER N
INTEGER NST
INTEGER IPR
```

```
INCLUDE 'C:INCLUDE\RESLTS.INC'
```

```
FACTOR = FLOAT(IPR)/180.
```

```
DO 100 I = 0,N
```

```
FI = FLOAT(I)
```

```
DO 80 J = 1,21
```

```
SUMA2 = 0.
SUMB2 = 0.
```

```
DO 75 IST = 2,NST-1
```

```
PSI = IPS(IST)* .017453293
SUMA2 = SUMA2 + COS(FI*PSI)*RESLTS(IST,J,M)
SUMB2 = SUMB2 + SIN(FI*PSI)*RESLTS(IST,J,M)
```

```
75 CONTINUE
```

```

PSI1 = 0.
PSIN = 360.0*.017453293

SUMA = 2.*SUMA2 + COS(FI*PSI1)*RESLTS(1,J,M) +
&   COS(FI*PSIN)*RESLTS(NST,J,M)

SUMB = 2.*SUMB2 + SIN(FI*PSI1)*RESLTS(1,J,M) +
&   SIN(FI*PSIN)*RESLTS(NST,J,M)

IF( I .EQ. 0) THEN
  A(I,J) = 0.25*FACTOR*SUMA
  B(I,J) = 0.25*FACTOR*SUMB
ELSE
  A(I,J) = 0.5*FACTOR*SUMA
  B(I,J) = 0.5*FACTOR*SUMB
ENDIF

80  CONTINUE
100 CONTINUE

RETURN
END

SUBROUTINE TRBCLC( NPTS )

C   Subroutine for calculation of turbulence. We will assume that
C   turbulence is being modeled from rotationally sampled wind data
C   as predicted from the VEERS Wind Simulation model.
C   The file of data must contain 4 columns ( as evidenced in the
C   read statement below.
C   The first column is blade azimuth angle, the second column
C   is the windspeed for blade #1 at the 50% rotor radius station,
C   the third column is the windspeed for blade #1 at the tip,
C   and finally the fifth column is the windspeed at the
C   center of the hub.
C   Before this windspeed data is read in, the user is asked for the
C   name of the file containing the turbulent windspeed data, is asked
C   whether this data is in metric (meters/sec) or english units
C   (ft/s) and is asked for the name of the file to contain the
C   predicted turbulent loads data. For the structure of this file,
C   see the block of comments near the WRITE statement toward the
C   end of this subroutine.

C   BE SURE TO RUN THE TRIM SOLUTION CORRESPONDING WITH THIS
C   TURBULENCE ANALYSIS WITH A VALUE OF SHERXP EQUAL TO ZERO
C   IF THE VEERS GENERATED WINDSPEED DATA ALREADY HAS THE
C   EFFECTS OF WINDSHEAR. IF YOU DON'T THEN THE PREDICTIONS
C   WILL HAVE TOO MUCH CYCLIC CONTENT, DUE TO TWO TIMES THE
C   DESIRED WINDSHEAR VALUES.

REAL STEMF (4, 0:1 , 0:2)
REAL ANGLE
REAL AZIDAT
REAL AZIINC
REAL AZIOLD
REAL BLDANG
REAL DELVY1 (10)
REAL PSIDIF
REAL RESLTS (21,9)

```

```
REAL VY1 (10)
REAL VYHUB
REAL VYSAV1 (0:1,10)
REAL VYSAVH (0:1)
```

```
INTEGER I
INTEGER J
INTEGER NEW
INTEGER NPTS
INTEGER NSHP
INTEGER OLD
```

```
CHARACTER *50 WNDFIL
CHARACTER *50 LODFIL
CHARACTER * 2 ANS
```

```
INCLUDE 'C:INCLUDE\BLADE2.INC'
INCLUDE 'C:INCLUDE\LIMTC.INC'
INCLUDE 'C:INCLUDE\POSITN.INC'
INCLUDE 'C:INCLUDE\SARAYS.INC'
INCLUDE 'C:INCLUDE\TURBN.INC '
INCLUDE 'C:INCLUDE\TRBINF.INC'
INCLUDE 'C:INCLUDE\CONST2.INC'
INCLUDE 'C:INCLUDE\DELTV.INC'
INCLUDE 'C:INCLUDE\WIND2.INC'
```

```
SAVE NEW
SAVE OLD
SAVE STEMP
```

```
DATA NEW / 1 /
DATA OLD / 0 /
```

```
PRINT *, ' '
PRINT *, 'Turbulence Analysis Run Set-up'
PRINT *, ' '
```

```
C Read in the name of the file containing the VEERS generated
C windspeed data.
```

```
PRINT *, 'Read in the name of the wind residual time series file'
READ *, WNDFIL
PRINT *, WNDFIL
```

```
C See if the windspeed data is in metric or english units.
```

```
PRINT *, 'Is the wind data in metric units (meters/sec)?'
READ *, ANS
PRINT *, ANS
PRINT *, ' '
```

```
C Give the name of the file you want to write rotor and blade
C teeter, loads, shaft-loads, etc. out to.
```

```
PRINT *, 'Read in the name of the file for loads output'
READ *, LODFIL
PRINT *, LODFIL
```

```
OPEN (15, FILE = WNDFIL, STATUS = 'UNKNOWN')
```

```
OPEN (16, FILE = LODFIL, STATUS = 'UNKNOWN')
```

```
NSCN = 1  
AZIDAT = 0.
```

```
C AZIDAT is the azimuth angle read from data,  
C VY1(J) is the windspeed data  
C for blade number 1, and VYHUB is the hubcenter windspeed.  
C Currently MSTAT is limited to 2. We usually read in windspeed  
C data at the 50% and 100% rotor radius location, for the  
C blade and then the hubcenter windspeed.
```

```
C Set the shear exponent from the trim run to  
C zero, since the file generated from the  
C VEERS model already has the effects of windshear  
C in it. Failure to do so will result in too much  
C windshear. Other parameters such as tower shadow  
C inputs are not set to zero unless the user  
C reruns the trim solution with zero values  
C for Tp, T0 - the tower shadow parameters.
```

```
C Initialize values for SHEREXP, PSI(0),  
C AZIOLD, ERROR, DELPSI(1),  
C STEMP, etc.
```

```
SHERXP = 0.  
PSI(0) = 0.  
AZIOLD = -0.0001  
ERROR = 0.  
DELPSI(1) = STEPMN  
AZIINC = TIMINC*OMEGA
```

```
c set the initial blade deflection, velocity,  
c and acceleration values to what was calculated  
c in the trim solution at zero azimuth angle. This  
c serves to start the solution process.
```

```
DO 260 NSHP = 1, NSHAPS  
DO 250 I = 0, 2  
    STEMP(NSHP,OLD,I) = SNEW(NSHP, I , 360)  
250 CONTINUE  
260 CONTINUE
```

```
C Set the left-hand endpoint windspeed value  
C needed in the linear interpolation process  
C equal to VHUB since we have not read in  
C a windspeed data line from the VEERS file yet.  
C The right-hand endpoint value will be the  
C new line of windspeed data read in.  
C These values are necessary in order to have  
C endpoints for interpolation, since the blade  
C azimuth in the numerical integration process  
C will lie between azimuth values read from  
C the data (AZIDAT). Setting this first left-  
C hand point to VHUB starts the process. I=0  
C stands for the left-hand endpoint value,  
C while I=1 is the right-hand endpoint.
```


C VYSAV1 is for blade 1,
 C and VYSAVH is the hub-center. J is equal
 C to 1 or 2 depending on whether it's the 50%
 C station or the blade tip.

```

      DO 300 J = 1,MSTAT
        VYSAV1(0,J) = 0.
300   CONTINUE
        VYSAVH(0) = 0.

```

```
1000 READ (15,*) AZIDAT, (VY1(J), J=1,MSTAT), VYHUB
```

```

      IF (( ANS .EQ. 'Y') .OR. ( ANS .EQ. 'y')) THEN
        DO 220 J = 1,MSTAT
          VY1(J) = 3.28*VY1(J)
220   CONTINUE
          VYHUB = 3.28*VYHUB
      ENDIF

```

C Convert AZIDAT to radians

```
AZIDAT = AZIDAT/RAD2DG
```

C Be sure that the windspeed data produced by the VEERS model
 C contains the hubheight or mean windspeed. If it doesn't then
 C the next 4 lines of code should be commented out.
 C The purpose of the next 4 lines of code is
 C to subtract out the mean windspeed from the data input.

```

      DO 230 J = 1,MSTAT
        VY1(J) = VY1(J)-VHUB
230 CONTINUE
        VYHUB = VYHUB-VHUB

```

C We read in one line of windspeed data at a time.
 C We interpolate the windspeed data to get turbulent
 C windspeed fluctuations when the blade azimuth angle
 C lies between successive values in the input file.

C Set the right-hand endpoint windspeed in the
 C interpolation process equal to the windspeeds
 C just read in.

```

      DO 350 J = 1, MSTAT
        VYSAV1(1,J) = VY1(J)
350. CONTINUE
        VYSAVH(1) = VYHUB

```

C If we have passed through 360 degrees
 C then subtract out 360 degrees from
 C PSI. We are not able to deal with
 C azimuth angles greater than 360 deg.
 C Be sure to convert to radians.

```

      IF( (AZIDAT - AZIOLD) .LT. 0.) THEN
        PSI(0) = PSI(0) - 360./RAD2DG
        AZIOLD = AZIOLD - 360./RAD2DG
      ENDIF

```

```

C   Find the next azimuth angle in the
C   code numerical solution process ( not
C   the azimuth angle of the next line
C   of wind data. PSI(1) represents
C   this new azimuth angle (radians).
C   PSIDIF represents the difference between
C   this new azimuth location and the last
C   azimuth angle read in from the data.

400  CALL NXTAZI ( AZIDAT)

      PSIDIF = PSI(1) - AZIOLD

C   Interpolate in order to determine turbulent windspeed
C   data for azimuth angles lying between the previously
C   read in line of data and the new line of data.
C   VYNOW1(J) is interpolated windspeed for blade 1 at
C   this new azimuth angle. VYNOW2(J) is the interpolated
C   windspeed for blade 2. VYNOWH is the interpolated
C   hub center windspeed for this azimuth position.
C   These windspeed values are the ones that ultimately
C   get passed into the WINDVL subroutine.
C   The windspeed values for blade radial stations lying
C   between the hub, 50% radial station and blade tip
C   get formed in WINDVL by linear interpolation along
C   the blade span. If the user wants to read windspeed
C   data at more than
C   these stations then SUBROUTINE WINDVL will have
C   to be changed and more columns of data would have
C   to be read in from the VEERS file.

      DO 450 J = 1, MSTAT
          DELVY1(J) = VYSAV1(1,J) - VYSAV1(0,J)
          VYNOW1(J) = (DELVY1(J)/AZIINC)*PSIDIF + VYSAV1(0,J)
450  CONTINUE
      DELVYO = VYSAVH(1) - VYSAVH(0)
      VYNOWH = (DELVYO/AZIINC)*PSIDIF + VYSAVH(0)

      CALL EULER ( STEMP, NSHAPS, NPTS)

      IF(( ERROR .GT. EUERR) .AND. ( DELPSI(1) .GT. STEPMM))
&      GO TO 400

      DO 510 NSHP = 1, NSHAPS
      DO 500 I = 0,2
          STEMP ( NSHP, OLD, I) = STEMP(NSHP, NEW, I)
500  CONTINUE
510  CONTINUE

      DELPSI(0) = DELPSI(1)
      DELTAT(0) = DELTAT(1)
      PSI(0)    = PSI(1)

      IF( ABS(PSI(1)-AZIDAT) .GE. 0.1*STEPMM) THEN
          GO TO 400
      ELSE

          ANGLE = AZIDAT*RAD2DG

```

```

512     IF( ANGLE .LT. 360) GO TO 515
        ANGLE = ANGLE - 360.
        GO TO 512

C   Calculate blade loads and store
C   loads and response results in the
C   array RESLTS

515     BLDANG = PSI(1)
        CALL LODCLC(BLDANG, STEMP, RESLTS)

C   This is the portion of the subroutine that writes
C   out results to the user designated loads output
C   file. ANGLE is the azimuth angle, RESLTS(I,J) is the
C   results matrix for blade #1 at the I'th station.
C   J corresponds to the results item to printed out:
C   J=1 to 7.
C   I corresponds to the number of the blade radial
C   station, from 1 to 21, with 1 at the root and
C   21 at the blade tip.
C
C           J=1 BLADE DEFLECTION (FT.)
C           J=2 BLADE SLOPE (FT./FT.)
C           J=3 BLADE FLAP+TEETER VELOCITY (FT/SEC)
C           J=4 BLADE TENSION (LB.)
C           J=5 BLADE EDGEWISE SHEAR FORCE (LB.)
C           J=6 BLADE FLAPWISE SHEAR FORCE (LB.)
C           J=7 BLADE FLAPWISE MOMENT (FT-LB)
C           J=8 BLADE EDGEWISE MOMENT (FT-LB)
C           J=9 BLADE TORSIONAL MOMENT (FT-LB)
C
C
C   Here we are printing out azimuth,
C   root flap-bending for blade 1 ,
C   65% span flap-bending for blade 1,
C   This statement will need to be
C   changed by the user to write out items
C   needed.

        WRITE(16,*) ANGLE, RESLTS(1,7),
&           RESLTS(13,7)

C   Set the left-hand endpoint windspeeds to the right-
C   hand values and read in a new line of windspeed
C   data from the
C   VEERS generated windspeed file, until NSCN is
C   equal to NUMSCN.
C
        DO 520 J = 1,MSTAT
520     VYSAV1(0,J) = VYSAV1(1,J)
        VYSAVH(0) = VYSAVH(1)
        NSCN = NSCN + 1
        AZIOLD = AZIDAT
        IF( NSCN .LE. NUMSCN) GO TO 1000
        ENDIF

```

RETURN
END

SUBROUTINE NXTAZI (AZI)

```
C *****  
C * *  
C * Subroutine NXTAZI computes the next value of the azi- *  
C * muth angle, Psi, based on the current value of the Eu- *  
C * ler error and the previous delta-Psi value. If the er- *  
C * ror is too large, a smaller delta-Psi will be used to *  
C * compute the value of Psi, unless the delta-Psi is al- *  
C * ready at the STEPMN lower limit. Likewise, if the Eu- *  
C * ler error is below a certain limit, the delta-Psi value *  
C * is increased for the next Psi computation. *  
C * *  
C *****  
  
C *****  
C * *  
C * External references in this routine: *  
C * *  
C * none *  
C * *  
C *****  
  
C *****  
C * *  
C * Named COMMON blocks used in this routine: *  
C * *  
C * CONST Turbine and other constants used in load *  
C * calculations. *  
C * LIMITC - Holds values used in the LIMITS routine. *  
C * POSITN - Holds parameters related to blade position *  
C * such as PHI, PSI, etc. *  
C * TURBN - Holds turbine parameters such as number of *  
C * blades, rotor speed, etc. *  
C * *  
C *****  
  
C *****  
C * *  
C * Local and dummy variables used in this routine: *  
C * *  
C * AZI - The next STEPMX station . *  
C * NEW - Array index for new data. *  
C * OLD - Array index for old data. *  
C * *  
C *****
```

REAL AZI

INTEGER NEW
INTEGER OLD

INCLUDE 'C:INCLUDE\CONST2.INC'

INCLUDE 'C:INCLUDE\LIMITC.INC'

```
INCLUDE      'C:INCLUDE\POSITN.INC'
```

```
INCLUDE      'C:INCLUDE\TURBN.INC'
```

```
SAVE         NEW
```

```
SAVE         OLD
```

```
DATA         NEW      / 1 /
```

```
DATA         OLD      / 0 /
```

```
C           Check the error.  If it is too large, decrease delta-Psi by  
C           50%.  If it is very small, increase delta-Psi by 50%.  The  
C           value of delta-Psi must always be greater than STEPMN.
```

```
IF ( ERROR .GT. EUERR ) THEN
```

```
    DELPSI(NEW) = AMAX1( 0.5*DELPSI(NEW) , STEPMN )
```

```
ELSE IF ( ERROR .LT. 0.1*EUERR ) THEN
```

```
    DELPSI(NEW) = 1.5*DELPSI(NEW)
```

```
END IF
```

```
C           This section of code checks the position of the new Psi against  
C           the next STEPMX station.  If the next Psi will go past the  
C           STEPMX station, the delta-Psi is adjusted to bring the next Psi  
C           directly onto the STEPMX point.  If the next Psi will fall just  
C           short of a STEPMX station, the delta-Psi is adjusted to assure  
C           that it will not be necessary to use a delta-Psi smaller than  
C           STEPMN to reach the next STEPMX station on the next iteration.
```

```
C           Programmer note:
```

```
C           The following logic can produce a delta-Psi that is less  
C           than STEPMN for two steps.  It would then move back within  
C           tolerances.  This case comes up when we are within slightly  
C           less than two STEPMNs of the next STEPMX station.  This  
C           algorithm cannot produce a delta-Psi that is less than  
C           STEPMN/2.                               MLB
```

```
IF ( PSI(OLD)+DELPSI(NEW) .GT. AZI ) THEN
```

```
    DELPSI(NEW) = AZI - PSI(OLD)
```

```
ELSE IF ( PSI(OLD)+DELPSI(NEW)+STEPMN .GT. AZI ) THEN
```

```
    IF ( (DELPSI(NEW) .NE. STEPMN) .OR. (ERROR .LE. EUERR) ) THEN
```

```
        DELPSI(NEW) = 0.5*( AZI - PSI(OLD) )
```

```
    END IF
```

```
END IF
```

```

C      Set new Psi and delta-Time.

PSI(NEW)   = PSI(OLD) + DELPSI(NEW)
DELTAT(NEW) = DELPSI(NEW)/OMEGA

C      Get time values if we're working on a yawing solution.

IF ( ITRIM .EQ. 0 ) TIME(NEW) = TIME(OLD) + DELTAT(NEW)

RETURN
END

SUBROUTINE LODCLC( BLDANG, STEMP, RESLTS)

C      *****
C      *
C      * Subroutine LODCLC is used to compute blade flap loads. *
C      *
C      *****

C      *****
C      *
C      * External references in this routine:
C      *
C      * TRP20D - Composite trapezoidal integration.
C      *
C      *****

C      *****
C      *
C      * Named COMMON blocks used in this routine:
C      *
C      * AERO1 - Holds coefficients related to aerodynamic
C      *        loads calculations such as ClAlpha, CdZero,
C      *        etc.
C      * AIRFRC - Holds values used in aerodynamic calcula-
C      *        tions.
C      * BLADE - Holds blade property values such as stiff-
C      *        ness and mass distributions.
C      * CONST - Turbine and other constants used in load
C      *        calculations.
C      * LIMITC - Holds values used in the LIMITS routine.
C      * LODVAL - Holds values used to compute blade loads.
C      * POSITN - Holds parameters related to blade position
C      *        such as PHI, PSI, etc.
C      * SHAPE - Holds blade coordinate shape functions.
C      * TENSIN - Holds tension component integrals.
C      * TURBN - Holds turbine parameters such as number of
C      *        blades, rotor speed, etc.
C      * WIND - Holds wind shear and tower shadow parame-
C      *        ters.
C      *
C      *****

C      *****
C      *
C      *

```

```

C      * Local and dummy variables used in this routine:      *
C      *                                                         *
C      *   BLDANG - Blade azimuth position.                    *
C      *   COEF1 - Complicated term.                          *
C      *   COEF2 - Complicated term.                          *
C      *   COEF4 - Complicated term.                          *
C      *   COEF7 - Complicated term.                          *
C      *   CPSI   - Cosine of the blade angle.                 *
C      *   FACTR1 - Complicated term.                          *
C      *   FINTGR - Integral of FLAPFN.                        *
C      *   FLAPFN - Flapwise shear force distribution.         *
C      *   I      - Generic index.                             *
C      *   IPT    - Data point index.                          *
C      *   J      - Generic index.                             *
C      *   LL     - Generic index.                             *
C      *   M      - Generic index.                             *
C      *   NPTS   - Number of points along the blade used to  *
C      *             perform Simpson's integration for calculat- *
C      *             ing the moments and forces at the blade  *
C      *             root. (passed from FLAP1)                  *
C      *   NSHP   - Counter on DO loops for the coordinate    *
C      *             shape function.                            *
C      *   OMGASQ - Omega^2.                                    *
C      *   PRDCTO - Temporary storage.                          *
C      *   PRDCT1 - Temporary storage.                          *
C      *   PRDCT2 - Temporary storage.                          *
C      *   PRODCT - Temporary storage.                          *
C      *   PYAERO - Aerodynamic loads in the flapwise direc-  *
C      *             tion.                                       *
C      *   RESLTS - Temporary storage.                          *
C      *   SPSI   - Sine of the blade angle.                    *
C      *   TINTGR - Integral of TSNFCN.                         *
C      *   TSNFCN - Product of the tension force and the slope *
C      *             at a blade station.                         *
C      *                                                         *
C      * *****

```

```

REAL      BLDANG
REAL      COEF1
REAL      COEF2
REAL      COEF4
REAL      COEF7
REAL      CPSI
REAL      FACTR1
REAL      FINTGR
REAL      FLAPFN (21)
REAL      EDGEFN (21)
REAL      TSNFCN (21)
REAL      VXFCN (21)
REAL      OMGASQ
REAL      PRODD
REAL      PRDCTO
REAL      PRDCT1
REAL      PRDCT2
REAL      PRODCT (21)
REAL      PYAERO (21)
REAL      PXAERO (21)
REAL      QZFCN (21)
REAL      RESLTS (21,9)

```

```

REAL      SPSI
REAL      STEMP (4, 0:1, 0:2)
REAL      TINTGR
REAL      TRPZOD

INTEGER    IPT
INTEGER    NPTS
INTEGER    NSHP

INCLUDE    'C:INCLUDE\AERO1.INC'

INCLUDE    'C:INCLUDE\AIRFRC.INC'

INCLUDE    'C:INCLUDE\BLADE2.INC'

INCLUDE    'C:INCLUDE\CONST2.INC'

INCLUDE    'C:INCLUDE\LIMITC.INC'

INCLUDE    'C:INCLUDE\LODVAL.INC'

INCLUDE    'C:INCLUDE\POSITN.INC'

INCLUDE    'C:INCLUDE\SHAPE.INC'

INCLUDE    'C:INCLUDE\TENSIN2.INC'

INCLUDE    'C:INCLUDE\TURBN.INC'

INCLUDE    'C:INCLUDE\WIND2.INC'

SAVE      NPTS
SAVE      NEW

DATA      NPTS   / 21 /
DATA      NEW    / 1  /

```

C Initialize some constants

```

OMGASQ = OMEGA**2
COEF1  = 2.0*OMEGA*STHP
COEF4  = OMGASQ*STHP*CTHP
COEF6  = OMGASQ*CTHP*CTHP
COEF7  = OMGASQ*STHP*STHP

CPSI   = COS( BLDANG )
SPSI   = SIN( BLDANG )
FACTR1 = OMGASQ*BETA0 + 2*OMEGA*CPSI*PHI(1) + SPSI*PHI(2)
COEF2  = GRAV*( -CHI*CTHP + STHP*SPSI + BETA0*CTHP*CPSI )
COEF3  = GRAV*( CHI*STHP + CTHP*SPSI - BETA0*STHP*CPSI )
COEF5  = GRAV*CPSI
COEF8  = GRAV*SPSI*STHP

PRODD  = 0.5*RHOAIR*CSUBMA

DO 350 IPT = 1, NPTS

  RESLTS(IPT,1) = 0.

```



```

RESULTS(IPT,2) = 0.
RESULTS(IPT,3) = 0.

DO 300 NSHP = 1, NSHAPS

    RESULTS(IPT,1) = RESULTS(IPT,1)+
&     SHAPE(NSHP,0,IPT)*STEMP(NSHP,NEW,0)
    RESULTS(IPT,2) = RESULTS(IPT,2)+
&     SHAPE(NSHP,1,IPT)*STEMP(NSHP, NEW, 0)
    RESULTS(IPT,3) = RESULTS(IPT,3)+
&     SHAPE(NSHP,0,IPT)*STEMP(NSHP, NEW, 1)
300 CONTINUE

PYAERO(IPT) = TRPZOD( IPT, BLTIP, DAZETA, NPTS)
PXAERO(IPT) = TRPZOD( IPT, BLTIP, DAETA, NPTS)
DMSBAC      = PRODD*CHORD(IPT)*WJ(IPT)**2
QZFCN(IPT)  = DMSBAC + ESUBAC(IPT)*DAZETA(IPT)

PRDCTO = 0.
PRDCT1 = 0.
PRDCT2 = 0.
PRODCT(IPT) = 0.

DO 340 NSHP = 1, NSHAPS

    PRDCTO = PRDCTO +STEMP(NSHP,NEW,0)*TCORLS(NSHP,IPT)
    PRDCT1 = PRDCT1 +STEMP(NSHP,NEW,1)*TCORLS(NSHP,IPT)
    PRDCT2 = PRDCT2 +STEMP(NSHP,NEW,2)*TCORLS(NSHP,IPT)
    PRODCT(IPT) = PRODCT(IPT) + STEMP(NSHP, NEW, 0)
&     * CIFMOM(NSHP, IPT)
340 CONTINUE

RESULTS(IPT,4) = OMGASQ * TOMGA(IPT) + COEF1 * PRDCT1
&     - COEF5 * TGRAV(IPT)

RESULTS(IPT,5) = PXAERO(IPT) - FACTR1 * STHP * TOMGA(IPT)
&     + COEF4 * PRDCTO + COEF3 * TGRAV(IPT)
&     + COEF6 * OFFMAS(IPT)

RESULTS(IPT,6) = PYAERO(IPT) - FACTR1 * CTHP * TOMGA(IPT)
&     + COEF7 * PRDCTO - PRDCT2 + COEF2 * TGRAV(IPT)
&     + COEF4 * OFFMAS(IPT)

EDGEFN(IPT) = RESULTS(IPT,5)
VXFNCN (IPT) = EDGEFN(IPT)*RESULTS(IPT,2)
TSNFNCN(IPT) = RESULTS(IPT,4) * RESULTS(IPT,2)
FLAPFN(IPT) = RESULTS(IPT,6)
350 CONTINUE

DO 360 IPT = 1,NPTS

    EINTGR = TRPZOD(IPT, BLTIP, EDGEFN, NPTS)
    SINTGR = TRPZOD(IPT, BLTIP, VXFNCN , NPTS)
    TINTGR = TRPZOD(IPT, BLTIP, TSNFNCN, NPTS)
    QZAERO = TRPZOD(IPT, BLTIP, QZFCN , NPTS)
    FINTGR = TRPZOD(IPT, BLTIP, FLAPFN, NPTS)
    ECENGR = TRPZOD(IPT, BLTIP, ECNTFN, NPTS)

```

```

RESULTS(IPT,7) = TINTGR - FINTGR + COEF7*PRODDT(IPT)
RESULTS(IPT,8) = EINTGR - OMGASQ*ECENGR
&   - COEF4*PRODDT(IPT) + COEF5*OFFMAS(IPT)
RESULTS(IPT,9) = QZAERO - SINTGR + COEF4*DELTIM(IPT)
&   + COEF8*OFFMAS(IPT)

```

360 CONTINUE

```

RETURN
END

```

SUBROUTINE SHAFT2(IPS,IPR,NSTN)

```

INCLUDE      'C:\INCLUDE\CONST2.INC'
INCLUDE      'C:\INCLUDE\TURBN.INC'
INCLUDE      'C:\INCLUDE\RESLTS.INC'
INCLUDE      'C:\INCLUDE\SHFLOD.INC'
INCLUDE      'C:\INCLUDE\BLADE2.INC'

```

```

CHARACTER * 50 SHFOUT
CHARACTER * 15 LABEL1
CHARACTER * 10 LABEL2(6)
CHARACTER * 12 LABEL3(0:5)
CHARACTER * 12 LABEL4(0:5)
CHARACTER * 10 LABEL5(6)

```

```

INTEGER IPS(360)
INTEGER IPR
INTEGER NSTN
INTEGER NSTN1
INTEGER NST1
INTEGER IST
INTEGER IST2

```

```

REAL A(0:10,6)
REAL B(0:10,6)
REAL C(0:10,6)
REAL D(0:10,6)
REAL SBETA0
REAL CBETA0
REAL FACTOR
REAL FI
REAL PS11
REAL PSIN

```

```

SAVE LABEL1
SAVE LABEL2
SAVE LABEL3
SAVE LABEL4
SAVE LABEL5

```

```

DATA LABEL1
& / 'Azimuth Angle'/

```

```

DATA LABEL2
& / 'Fxr','Fyr',
& 'Fzr','Mxr','Myr','Mzr'/

```

```

DATA LABEL3
& / 'cos(0*PSI)', 'cos(PSI)',
& 'cos(2.*PSI)', 'cos(3.*PSI)',
& 'cos(4.*PSI)', 'cos(5.*PSI)'/

```

```

DATA LABEL4
& / 'sin(0.*PSI)', 'sin(PSI)', 'sin(2.*PSI)',
& 'sin(3.*PSI)', 'sin(4.*PSI)', 'sin(5.*PSI)'/

```

```

DATA LABEL5
& / 'Fyh', 'Fyh', 'Fzh',
& 'Mxh', 'Myh', 'Mzh'/'

```

```
4000 FORMAT (/, 1X, A, 6( 1X, A))
```

```
4200 FORMAT (/, 2X, F10.3, 6(1X, F10.3))
```

```
4300 FORMAT (//)
```

```
4400 FORMAT (/, 17X, 6(1X, A))
```

```
4500 FORMAT (/, 1X, A , 6(1X, F10.3))
```

```

SBETA0 = SIN(BETA0)
CBETA0 = COS(BETA0)

```

```

PSI1 = 0.
PSIN = 360.*.017453293

```

```
FACTOR = FLOAT(IPR)/180.
```

```

PRINT *, 'Read in name of shaft loads output file < '
READ *, SHFOUT
PRINT *, SHFOUT
OPEN( 10, FILE = SHFOUT, STATUS = 'UNKNOWN')

```

```

NSTN1 = NSTN - 1
DO 360 IST = 1, NSTN1

```

```
F(1,1,IST) = RESULTS(IST,1,5)*CTHP + RESULTS(IST,1,6)*STHP
```

```

F(2,1,IST) = RESULTS(IST,1,6)*CBETA0*CTHP +
& RESULTS(IST,1,4)*SBETA0 - RESULTS(IST,1,5)*CBETA0*STHP

```

```

F(3,1,IST) = RESULTS(IST,1,5)*SBETA0*STHP -
& RESULTS(IST,1,6)*SBETA0*CTHP + RESULTS(IST,1,4)*CBETA0

```

```
F(4,1,IST) = RESULTS(IST,1,7)*CTHP + RESULTS(IST,1,8)*STHP
```

```

F(5,1,IST) = RESULTS(IST,1,8)*CBETA0*CTHP
& + RESULTS(IST,1,9)*SBETA0
& -RESULTS(IST,1,7)*CBETA0*STHP

```

```

F(6,1,IST) = RESULTS(IST,1,7)*SBETA0*STHP -
& RESULTS(IST,1,8)*SBETA0*CTHP + RESULTS(IST,1,9)*CBETA0

```

```
360 CONTINUE
```

```
DO 370 I = 1,6
```

```

      F(I,1,NSTN) = F(I,1,1)
370 CONTINUE

      NST1 = INT(NSTN/2. + .0001)

      DO 390 IST = 1, NSTN

        IST2 = IST + NST1

        IF( IST2 .GE. NSTN) THEN
          IST2 = IST - NST1
        ENDIF

        DO 385 I = 1,6

          F(I,2,IST2) = F(I,1,IST)

385 CONTINUE

390 CONTINUE

      DO 400 I = 1,6

        F(I,2,NSTN) = F(I,2,1)

400 CONTINUE

      DO 500 IST = 1,NSTN

        PSI = IPS(IST) * .017453293

        SHFL0D(1,IST) = F(1,1,IST) - F(1,2,IST)

        SHFL0D(2,IST) = F(2,1,IST) + F(2,2,IST)

        SHFL0D(3,IST) = F(3,1,IST) - F(3,2,IST)

        SHFL0D(4,IST) = F(4,1,IST) - F(4,2,IST)
& - HUBRAD*( F(2,1,IST) - F(2,2,IST))

        SHFL0D(5,IST) = F(5,1,IST) + F(5,2,IST)
& + HUBRAD*( F(1,1,IST) + F(1,2,IST))

        SHFL0D(6,IST) = F(6,1,IST) - F(6,2,IST)

        HUBL0D(1,IST) = SHFL0D(1,IST)*COS(PSI) + SHFL0D(3,IST)
& * SIN(PSI)

        HUBL0D(2,IST) = SHFL0D(2,IST)

        HUBL0D(3,IST) = SHFL0D(3,IST)*COS(PSI) - SHFL0D(1,IST)
& * SIN(PSI)

        HUBL0D(4,IST) = SHFL0D(4,IST)*COS(PSI) + SHFL0D(6,IST)
& * SIN(PSI)

```

```

HUBL0D(5,IST) = SHFL0D(5,IST)

HUBL0D(6,IST) = SHFL0D(6,IST)*COS(PSI) -
& SHFL0D(4,IST)*SIN(PSI)

```

```
500 CONTINUE
```

```
WRITE(10,*) 'Low-Speed Shaft Loads in Rotor coordinates'
```

```
WRITE(10,4000) LABEL1, ( LABEL2(J), J=1,6)
```

```
DO 420 IST = 1, NSTN
```

```
WRITE(10,4200) IPS(IST), (SHFL0D(J,IST), J=1,6)
```

```
420 CONTINUE
```

```
WRITE(10,4300)
```

```
WRITE(10,*) 'Hub loads in fixed frame hub coordinates'
```

```
WRITE(10,4000) LABEL1, ( LABEL5(J), J=1,6)
```

```
DO 430 IST = 1, NSTN
```

```
WRITE(10,4200) IPS(IST), (HUBL0D(J,IST), J=1,6)
```

```
430 CONTINUE
```

C Compute harmonics of rotor shaft loads: Fourier Series expansion.

C Also compute harmonics of fixed frame hub loads, in hub coordinates.

```
DO 800 II = 1,6
```

```
DO 700 I = 0,5
```

```
SUMA2 = 0.
```

```
SUMB2 = 0.
```

```
SUMC2 = 0.
```

```
SUMD2 = 0.
```

```
FI = FLOAT(I)
```

```
DO 650 IST = 2, NSTN1
```

```
PSI = IPS(IST) * .017453293
```

```
SUMA2 = SUMA2 + COS(FI*PSI)*SHFL0D(II,IST)
```

```
SUMB2 = SUMB2 + SIN(FI*PSI)*SHFL0D(II,IST)
```

```
SUMC2 = SUMC2 + COS(FI*PSI)*HUBL0D(II,IST)
```

```
SUMD2 = SUMD2 + SIN(FI*PSI)*HUBL0D(II,IST)
```

```
650 CONTINUE
```

```
SUMA = 2.*SUMA2 + COS(FI*PSI1)*SHFL0D(II,1) +
```

```
& COS(FI*PSIN)*SHFL0D(II,NSTN)
```

```
SUMB = 2.*SUMB2 + SIN(FI*PSI1)*SHFL0D(II,1) +
```

```
& SIN(FI*PSIN)*SHFL0D(II,NSTN)
```

```
SUMC = 2.*SUMC2 + COS(FI*PSI1)*HUBL0D(II,1) +
```

```
& COS(FI*PSIN)*HUBL0D(II,NSTN)
```

```
SUMD = 2.*SUMD2 + SIN(FI*PSI1)*HUBL0D(II,1) +
```

```
& SIN(FI*PSIN)*HUBL0D(II,NSTN)
```

```
IF( I .EQ. 0) THEN
```

```
A(I,II) = 0.25 * FACTOR*SUMA
```

```
B(I,II) = 0.25 * FACTOR*SUMB
```

```

      C(I,II) = 0.25 * FACTOR*SUMC
      D(I,II) = 0.25 * FACTOR*SUMD

ELSE
      A(I,II) = 0.50 * FACTOR*SUMA
      B(I,II) = 0.50 * FACTOR*SUMB
      C(I,II) = 0.50 * FACTOR*SUMC
      D(I,II) = 0.50 * FACTOR*SUMD

ENDIF
700 CONTINUE
800 CONTINUE

WRITE(10,4300)

WRITE(10,*) 'Harmonics of Rotor Shaft Loads'
WRITE(10,4400) ( LABEL2(J), J=1,6)
DO 900 I = 0,5
      WRITE(10,4500) LABEL3(I),(A(I,II), II=1,6)
      WRITE(10,4500) LABEL4(I),(B(I,II), II=1,6)
900 CONTINUE

WRITE(10,4300)

WRITE(10,*) 'Harmonics of Hub loads in Fixed Coordinates'
WRITE(10,4400) ( LABEL5(J), J=1,6)
DO 920 I = 0,5
      WRITE(10,4500) LABEL3(I), ( C(I,II), II=1,6)
      WRITE(10,4500) LABEL4(I), ( D(I,II), II=1,6)
920 CONTINUE
RETURN
END

SUBROUTINE SHAFT3(IPS,IPR,NSTN)

INCLUDE      'C:\INCLUDE\CONST2.INC'
INCLUDE      'C:\INCLUDE\TURBN.INC'
INCLUDE      'C:\INCLUDE\RESLTS.INC'
INCLUDE      'C:\INCLUDE\SHFLOD.INC'
INCLUDE      'C:\INCLUDE\BLADE2.INC'

CHARACTER * 50 SHFOUT
CHARACTER * 15 LABEL1
CHARACTER * 10 LABEL2(6)
CHARACTER * 12 LABEL3(0:5)
CHARACTER * 12 LABEL4(0:5)
CHARACTER * 10 LABEL5(6)

INTEGER IPS(360)
INTEGER IPR
INTEGER NSTN
REAL A(0:10,6)
REAL B(0:10,6)
REAL C(0:10,6)
REAL D(0:10,6)

REAL FACTOR
REAL FI

```

```
SAVE LABEL1
SAVE LABEL2
SAVE LABEL3
SAVE LABEL4
SAVE LABEL5
```

```
DATA LABEL1
& / 'Azimuth Angle'/
```

```
DATA LABEL2
& / 'Fxr', 'Fyr',
& 'Fzr', 'Mxr', 'Myr', 'Mzr'/
```

```
DATA LABEL3
& / 'cos(0*PSI)', 'cos(PSI)',
& 'cos(2.*PSI)', 'cos(3.*PSI)',
& 'cos(4.*PSI)', 'cos(5.*PSI)'/
```

```
DATA LABEL4
& / 'sin(0.*PSI)', 'sin(PSI)', 'sin(2.*PSI)',
& 'sin(3.*PSI)', 'sin(4.*PSI)', 'sin(5.*PSI)'/
```

```
DATA LABEL5
& / 'Fxb', 'Fyb', 'Fzb',
& 'Mxb', 'Myb', 'Mzb'/'
```

```
4000 FORMAT (/ , 1X, A, 6( 1X, A))
```

```
4200 FORMAT (/ , 2X, F11.2, 6(1X, F11.2))
```

```
4300 FORMAT (//)
```

```
4400 FORMAT (/ , 17X, 6(1X, A))
```

```
4500' FORMAT (/ , 1X, A , 6(1X, F11.2))
```

```
SBETA0 = SIN(BETA0)
CBETA0 = COS(BETA0)
```

```
PSI1 = 0.
PSIN = 360.*.017453293
```

```
FACTOR = FLOAT(IPR)/180.
```

```
PRINT *, '      '
PRINT *, '      '
PRINT *, 'Read in name of shaft loads output file'
READ *, SHFOUT
OPEN( 10, FILE = SHFOUT, STATUS = 'UNKNOWN')
```

```
NSTN1 = NSTN - 1
DO 360 IST = 1, NSTN1
```

```
F(1,1,IST) = RESLTS(IST,1,5)*CTHP + RESLTS(IST,1,6)*STHP
```

```
. F(2,1,IST) = RESLTS(IST,1,6)*CBETA0*CTHP + RESLTS(IST,1,4)*SBETA0
& - RESLTS(IST,1,5)*CBETA0*STHP
```

```
F(3,1,IST) = RESLTS(IST,1,5)*SBETA0*STHP - RESLTS(IST,1,6)*SBETA0
```

```

& *CTHP + RESLTS(IST,1,4)*CBETA0

F(4,1,IST) = RESLTS(IST,1,7)*CTHP + RESLTS(IST,1,8)*STHP

F(5,1,IST) = RESLTS(IST,1,8)*CBETA0*CTHP + RESLTS(IST,1,9)*SBETA0
& -RESLTS(IST,1,7)*CBETA0*STHP

F(6,1,IST) = RESLTS(IST,1,7)*SBETA0*STHP - RESLTS(IST,1,8)*SBETA0
& *CTHP + RESLTS(IST,1,9)*CBETA0

360 CONTINUE

DO 370 I = 1,6
    F(I,1,NSTN) = F(I,1,1)
370 CONTINUE

NST1 = INT(NSTN/3. + .0001)
NST2 = INT(2.*NSTN/3. + .0001)

DO 390 IST = 1, NSTN1

    IST2 = IST + NST2
    IST3 = IST + NST1

    IF( IST3 .GE. NSTN) THEN
        IST3 = IST - NST2
    ENDIF

    IF( IST2 .GE. NSTN) THEN
        IST2 = IST - NST1
    ENDIF

DO 385 I = 1,6

    F(I,2,IST2) = F(I,1,IST)
    F(I,3,IST3) = F(I,1,IST)

385 CONTINUE
390 CONTINUE

DO 400 I = 1,6

    F(I,2,NSTN) = F(I,2,1)
    F(I,3,NSTN) = F(I,3,1)

400 CONTINUE

FACTR = .86603

DO 500 IST = 1,NSTN

    PSI = IPS(IST) * .017453293

    SHFLOD(1,IST) = F(1,1,IST) - 0.5*(F(1,2,IST)+F(1,3,IST))
& + FACTR*(F(3,2,IST)-F(3,3,IST))

```



```

SHFLOD(2,IST) = F(2,1,IST) + F(2,2,IST) + F(2,3,IST)

SHFLOD(3,IST) = F(3,1,IST) - 0.5*(F(3,2,IST)+F(3,3,IST))
& - FACTR*(F(1,2,IST)-F(1,3,IST))

SHFLOD(4,IST) = F(4,1,IST) - 0.5*(F(4,2,IST)+F(4,3,IST))
& + FACTR*(F(6,2,IST)-F(6,3,IST))-HUBRAD*F(2,1,IST)
& + 0.5*HUBRAD*(F(2,3,IST)+F(2,2,IST))

SHFLOD(5,IST) = F(5,1,IST) + F(5,2,IST) + F(5,3,IST)
& + HUBRAD*(F(1,1,IST)+F(1,2,IST)+F(1,3,IST))

SHFLOD(6,IST) = F(6,1,IST) - 0.5*(F(6,2,IST)+F(6,3,IST))
& - FACTR*(F(4,2,IST)-F(4,3,IST))
& + FACTR*HUBRAD*(F(2,2,IST)-F(2,3,IST))

HUBLOD(1,IST) = SHFLOD(1,IST)*COS(P5I) + SHFLOD(3,IST)
& * SIN(P5I)

HUBLOD(2,IST) = SHFLOD(2,IST)

HUBLOD(3,IST) = SHFLOD(3,IST)*COS(P5I) - SHFLOD(1,IST)
& * SIN(P5I)

HUBLOD(4,IST) = SHFLOD(4,IST)*COS(P5I) + SHFLOD(6,IST)
& * SIN(P5I)

HUBLOD(5,IST) = SHFLOD(5,IST)

HUBLOD(6,IST) = SHFLOD(6,IST) * COS(P5I) - SHFLOD(4,IST)
& * SIN(P5I)

```

500 CONTINUE

```
WRITE(10,*) 'Low-Speed Shaft Loads in Rotor coordinates'
```

```
WRITE(10,4000) LABEL1, ( LABEL2(J), J=1,6)
```

```
DO 420 IST = 1, NSTN
```

```
WRITE(10,4200) IPS(IST), (SHFLOD(J,IST), J=1,6)
```

420 CONTINUE

```
WRITE(10,4300)
```

```
WRITE(10,*) 'Hub loads in fixed frame hub coordinates'
```

```
WRITE(10,4000) LABEL1, ( LABEL5(J), J=1,6)
```

```
DO 430 IST = 1, NSTN
```

```
WRITE(10,4200) IPS(IST), (HUBLOD(J,IST), J=1,6)
```

430 CONTINUE

- C Compute harmonics of rotor shaft loads: Fourier Series expansion.
- C Also compute harmonics of fixed frame hub loads, in hub coordinates.

```
DO 800 II = 1,6
```

```
DO 700 I = 0,5
```

```
SUMA2 = 0.
```

```
SUMB2 = 0.
```

```

SUMC2 = 0.
SUMD2 = 0.

FI = FLOAT(I)

DO 650 IST = 2, NSTN1
  PSI = IPS(IST) * .017453293
  SUMA2 = SUMA2 + COS(FI*PSI)*SHFLOD(II,IST)
  SUMB2 = SUMB2 + SIN(FI*PSI)*SHFLOD(II,IST)
  SUMC2 = SUMC2 + COS(FI*PSI)*HUBLOD(II,IST)
  SUMD2 = SUMD2 + SIN(FI*PSI)*HUBLOD(II,IST)

650 CONTINUE

SUMA = 2.*SUMA2 + COS(FI*PSI1)*SHFLOD(II,1) +
& COS(FI*PSIN)*SHFLOD(II,NSTN)
SUMB = 2.*SUMB2 + SIN(FI*PSI1)*SHFLOD(II,1) +
& SIN(FI*PSIN)*SHFLOD(II,NSTN)
SUMC = 2.*SUMC2 + COS(FI*PSI1)*HUBLOD(II,1) +
& COS(FI*PSIN)*HUBLOD(II,NSTN)
SUMD = 2.*SUMD2 + SIN(FI*PSI1)*HUBLOD(II,1) +
& SIN(FI*PSIN)*HUBLOD(II,NSTN)

IF( I .EQ. 0) THEN
  A(I,II) = 0.25 * FACTOR*SUMA
  B(I,II) = 0.25 * FACTOR*SUMB
  C(I,II) = 0.25 * FACTOR*SUMC
  D(I,II) = 0.25 * FACTOR*SUMD

ELSE
  A(I,II) = 0.50 * FACTOR*SUMA
  B(I,II) = 0.50 * FACTOR*SUMB
  C(I,II) = 0.50 * FACTOR*SUMC
  D(I,II) = 0.50 * FACTOR*SUMD

ENDIF
700 CONTINUE
800 CONTINUE

WRITE(10,4300)

WRITE(10,*) 'Harmonics of Rotor Shaft Loads'
WRITE(10,4400) ( LABEL2(J), J=1,6)
DO 900 I = 0,5
  WRITE(10,4500) LABEL3(I),(A(I,II), II=1,6)
  WRITE(10,4500) LABEL4(I),(B(I,II), II=1,6)
900 CONTINUE

WRITE(10,4300)

WRITE(10,*) 'Harmonics of Hub loads in Fixed Coordinates'
WRITE(10,4400) ( LABEL5(J), J=1,6)
DO 920 I = 0,5
  WRITE(10,4500) LABEL3(I), ( C(I,II), II=1,6)
  WRITE(10,4500) LABEL4(I), ( D(I,II), II=1,6)
920 CONTINUE
RETURN
END

```

Appendix E

Modules 1 and 2 Flowcharts




Fig. E-1. Module 1 Flowchart




Fig. E-2. Module 2 Flowchart

Document Control Page	1. NREL Report No. NREL/TP-257-4674	2. NTIS Accession No. DE92010579	3. Recipient's Accession No.
4. Title and Subtitle User's Guide for the NREL Force and Loads Analysis Program (FLAP)		5. Publication Date August 1992	
		6.	
7. Author(s) Alan D. Wright		8. Performing Organization Rept. No. NREL/TP-257-4674	
9. Performing Organization Name and Address National Renewable Energy Laboratory 1617 Cole Blvd. Golden, CO 80401		10. Project/Task/Work Unit No. WE21.8202	
		11. Contract (C) or Grant (G) No. (C) (G)	
12. Sponsoring Organization Name and Address National Renewable Energy Laboratory 1617 Cole Blvd. Golden, CO 80401		13. Type of Report & Period Covered Technical Report	
		14.	
15. Supplementary Notes			
16. Abstract (Limit: 200 words) This report gives the reader an overview of and instructions on the proper use of the National Renewable Energy Laboratory <u>Force and Loads Analysis Program (FLAP, Version 2.2)</u> . It is intended as a tool for prediction of rotor and blade loads and response for two- or three-bladed rigid hub wind turbines. The effects of turbulence are accounted for. The objectives of the report are to give an overview of the code and also show the methods of data input and correct code execution steps in order to model an example two-bladed rigid hub turbine. A large portion of the discussion (Sections 6.0, 7.0, and 8.0) is devoted to the subject of inputting and running the code for wind turbulence effects. The ability to include turbulent wind effects is perhaps the biggest change in the code since the release of FLAP version 2.01 in 1988. This report is intended to be a user's guide. It does not contain a theoretical discussion on equations of motion, assumptions, underlying theory, etc.			
17. Document Analysis a. Descriptors wind turbines; loads; structures; computer codes b. Identifiers/Open-Ended Terms c. UC Categories 261			
18. Availability Statement National Technical Information Service U.S. Department of Commerce 5285 Port Royal Road Springfield, VA 22161		19. No. of Pages 238	
		20. Price A11	