

# SonicWall 1TB SSD Storage Module Installation Instructions

This document provides instructions for removing and installing the SonicWall 1TB SSD storage module in your SonicWall NSsp or high-end NSa appliance. The SSD must be installed in the M1 slot on the back of your NSa or NSsp appliance. There is no need to power down the appliance.

## M1 Slot in NSsp Rear Panel



M1 Slot for SSD Storage Module

**CAUTION:** The SSD storage module contains parts and assemblies susceptible to damage by electrostatic discharge (ESD). To prevent damage, handle the module using standard ESD procedures such as storing in an electrostatic bag and handling while grounded.

For more information on safety and regulatory requirements, refer to the *Safety, Regulatory and Legal Information Guide* for the product in which the SSD storage module is being installed.

## Removing the Cover Plate or Defective SSD

To remove the cover plate or defective SSD from the appliance:

- 1 If there is a cover plate on the M1 slot, but no SSD storage module inside, loosen the thumb screws on the cover plate.
- 2 Grip the thumb screws to remove the cover plate, and set it aside.



- 3 If there is a defective SSD storage module in the slot, use a screwdriver to loosen and remove the screw on the left side. Then loosen the thumb screw on the right side and pull it to slide the SSD storage module out of the appliance.



**NOTE:** The cover plate has two thumbscrews to loosen. The new SSD storage module only has a thumbscrew on the right side. A screw fits into the hole on the left side.

## Installing the SSD

**CAUTION:** Do NOT insert anything except the SSD storage module into the slot labeled for the module (M1). The module is not designed to fit in the M0 slot.

To install the new SSD storage module in the appliance:

- 1 Remove the new SSD storage module from the shipping package.
- 2 Remove the M1 cover plate or the defective SSD storage module from the appliance. (See previous section.)
- 3 Insert the new SSD storage module into the empty M1 slot, label side up.
- 4 Press the SSD storage module firmly into place to seat the connectors.
- 5 Tighten the thumb screw by pushing in and turning to the right.
- 6 Insert the screw on the left side of the module and tighten with a screwdriver.
- 7 Apply the new seal (provided with the SSD) so that it covers the screw on the left side of the SSD storage module in the M1 slot.

**NOTE:** Be sure to apply the FIPS sticker properly over the screw to ensure warranty protection for the new SSD storage module.

This SSD storage module is for use only with the SonicWall appliances indicated below. Use of this SSD with a SonicWall appliance that is not approved voids the warranty for that appliance. Contact SonicWall Support for details at <https://www.sonicwall.com/support/contact-support>.

This module, 02-SSC-8894 SONICWALL SSD STORAGE 1TB FOR GEN7 NSA NSSP FIREWALLS, is approved for use with:

SonicWall NSsp 13700 and lower-numbered NSsp models

SonicWall NSa 4700 and higher NSa x700 models

For information and related documents, see the following web site:

<https://www.sonicwall.com/support>

# SonicWall 1TB SSD Storage Module Installation Guide

Copyright © 2021 SonicWall Inc. All rights reserved.

SonicWall is a trademark or registered trademark of SonicWall Inc. and/or its affiliates in the U.S.A. and/or other countries. All other trademarks are property of their respective owners.

The information in this document is provided in connection with SonicWall Inc. and/or its affiliates' products. No license, express or implied, by estoppel or otherwise, to any intellectual property right is granted by this document. SonicWall Inc. and/or its affiliates do not make any commitment to update the information contained in this document. For more information, visit <http://www.sonicwall.com/legal>.

## Legend



**WARNING:** A WARNING icon indicates a potential for property damage, personal injury, or death.



**CAUTION:** A CAUTION icon indicates potential damage to hardware or loss of data if instructions are not followed.



**IMPORTANT, NOTE, TIP, MOBILE, or VIDEO:** An information icon indicates supporting information.

SonicWall 1TB SSD Storage Module Installation Guide  
Updated - August 2021  
232-005672-51 Rev A



SONICWALL®