


ASSEMBLY INSTRUCTION

SKU CODE: (WF291898-WF291899-WF291900)

This set is included 3 boxes if don't receive full 3 boxes please contact our customer service team



! SAFETY WARNINGS !

1. This bed is designed for use only mattress (es) meeting the following specifications on the upper bunk, and lower bunk

Upper bed


Bed Type	Length	Width	Thickness
<i>Twin Standard</i>	<i>74" - 75"</i>	<i>38 1/2"</i>	<i>6" max</i>

Lower bed






















Bed Type	Length	Width	Thickness
<i>Full Standard</i>	<i>74" - 75"</i>	<i>53 1/2"</i>	<i>8"</i>

2. Replacement parts, including additional guardrails, maybe obtained from any of our (GIGACLOUD TECHNOLOGY (USA) INC. 18961 ARENTH AVENUE CITY OF INDUSTRY, CA, 91748) dealers
3. Follow the information on the warnings appearing on the upper bunk bed end structure and on the carton. Do not remove warning label from bed
4. Always use the recommended size mattresses or mattress supports, or both, to help prevent the likelihood of entrapment or falls.
5. Surface of mattress must be at least 5" (127mm) below the upper edge of guardrails
6. Do not allow children under 6 years of age to use the upper bunk.
7. Periodically check and ensure that the guardrail, ladder, and other components are in their proper position, free from damage, and that all connectors are tight.
8. Do not allow horseplay on or under the bed and prohibit jumping on the bed.
9. Always use the ladder for entering and leaving the upper bunk Always use the ladder for entering and leaving the upper bunk.
10. Do not use substitute part. Contact the manufacture or dealer for replacement part
11. Use of a night light may provide added safety precaution for a child using the upper bunk..
12. Always use guardrails on both long sides of the upper bunk. If the bunk bed will be placed next to the wall, the guardrail that runs the full length of the bed should be placed against the wall to prevent entrapment between the bed and wall.
13. The use of water or sleep flotation mattresses is prohibited
14. STRANGULATION HAZARD - Never attach or hang items to any part of the bunk bed that are not designed for use with the bed; for example, but not limited to, hook, belts and jump ropes
15. Keep these instruction for future reference
16. Prohibit more than one person on upper bunk
17. We recommend assembling your bunk bed on the shipping carton to protect your floor or carpet
18. Be certain all staples are out of the box before beginning assembly on the shipping carton.

ASSEMBLY INSTRUCTION



Part List (Box 1-WF291898)

<p>A1</p>  <p>Leg-1pc</p>	<p>A2</p>  <p>Leg-1pc</p>	<p>A3</p>  <p>Leg-1pc</p>
<p>A4</p>  <p>Leg-1pc</p>	<p>A5</p>  <p>Leg-1pc</p>	<p>A6</p>  <p>Leg-1pc</p>
<p>A7</p>  <p>Leg-1pc</p>	<p>A8</p>  <p>Leg-1pc</p>	<p>B1</p>  <p>Frame-1pc</p>
<p>B2</p>  <p>Wood Bar-1pc</p>	<p>B4</p>  <p>Frame-1pc</p>	<p>B5</p>  <p>Frame-1pc</p>
<p>B6</p>  <p>Frame-1pc</p>	<p>B8</p>  <p>Frame-1pc</p>	<p>D2</p>  <p>Long Slats-12pcs</p>
<p>D3</p>  <p>Long Slat With Center Holes-2pcs</p>	<p>D4</p>  <p>Support Slats-2pcs</p>	<p>E1</p>  <p>Side Ladder-1pc</p>
<p>E2</p>  <p>Side Ladder-1pc</p>	<p>E3</p>  <p>Step Ladders-4pcs</p>	<p>F2</p>  <p>Stair-leg-1pc</p>

Part List (Box 1-WF291898)

F9
























Stair-Wood Bar-1pc

G7




Stair-Wood bar-1pc

Part List & Hardware List (Box 2-WF291899)

<p>A9</p>  <p>Leg-1pc</p>	<p>A10</p>  <p>Leg-1pc</p>	<p>B3</p>  <p>Lower Rails-2pcs</p>
<p>B7</p>  <p>Lower Rails-2pcs</p>	<p>C1</p>  <p>Guardrails- 2pcs</p>	<p>C2</p>  <p>Side Rail- 1pc</p>
<p>C3</p>  <p>Guardrails- 2pcs</p>	<p>C4</p>  <p>Side Rail- 1pc</p>	<p>C5</p>  <p>Support Side Rails- 3pcs</p>
<p>C6</p>  <p>Side Rail- 1pc</p>	<p>C7</p>  <p>Support Side Rails- 3pcs</p>	<p>C8</p>  <p>Guardrails- 2pcs</p>
<p>C9</p>  <p>Side Rail- 1pc</p>	<p>C10</p>  <p>Guardrails- 2pcs</p>	<p>C11</p>  <p>Side Rail- 1pc</p>
<p>D1</p>  <p>Slats-14pcs</p>	<p>F1</p>  <p>Stair-leg-1pc</p>	<p>G1</p>  <p>Stair-leg-1pc</p>
<p>N1</p>  <p>Drawer-Front Panel-1pc</p>	<p>N2</p>  <p>Drawer-Side Panel-1pc</p>	<p>N3</p>  <p>Drawer-Side Panel-1pc</p>


Part List & Hardware List (Box 2-WF291899)

N4




Drawer-Center Panel-1pc

N5




Drawer-Center Panel-1pc

N6
























Drawer-Bottom Panels-2pcs

N8



















Drawer-Back Panel-1pc





















Part List (Box 3-WF291900)

<p>B9</p>  <p>Wood Bar-1pc</p>	<p>D1</p>  <p>Slats-14pcs</p>	<p>F3</p>  <p>Stair-Wood Bars-2pcs</p>
<p>F4</p>  <p>Stair-Wood Bar-1pc</p>	<p>F5</p>  <p>Stair-Wood Bars-3pcs</p>	<p>F6</p>  <p>Stair-Wood Bar-1pc</p>
<p>F7</p>  <p>Stair-Wood Bar-1pc</p>	<p>F8</p>  <p>Stair-Wood Bar-1pc</p>	<p>F10</p>  <p>Stair-Wood Bar-1pc</p>
<p>F11</p>  <p>Stair-Wood Bars-3pcs</p>	<p>F12</p>  <p>Stair-Panels-2pcs</p>	<p>F13</p>  <p>Stair-Panel-1pc</p>
<p>F14</p>  <p>Stair-Panel-1pc</p>	<p>F15</p>  <p>Stair-Panel-1pc</p>	<p>G2</p>  <p>Stair-leg-1pc</p>
<p>G3</p>  <p>Stair-Wood bar-1pc</p>	<p>G4</p>  <p>Stair-Wood bar-1pc</p>	<p>G5</p>  <p>Stair-Wood bar-1pc</p>
<p>G6</p>  <p>Stair-Wood bar-1pc</p>	<p>G8</p>  <p>Stair-Wood bar-1pc</p>	<p>G9</p>  <p>Stair-Panel-1pc</p>







Part List (Box 3-WF291900)


<p>G10</p>  <p>Stair-Panel-1pc</p>	<p>G11</p>  <p>Stair-Panel-1pc</p>	<p>H1</p>  <p>Stair-Wood Bars(Back)-3pcs</p>
<p>H2</p>  <p>Stair-Back Panel-1pc</p>	<p>H3</p>  <p>Stair-Back Panel-1pc</p>	<p>H4</p>  <p>Stair-Front Panel-1pc</p>
<p>H5</p>  <p>Stair-Front Panels-2pcs</p>	<p>H6</p>  <p>Stair-Front Panel-1pc</p>	<p>K1</p>  <p>Stair-Top Panel-1pc</p>
<p>K2</p>  <p>Stair-Top Panels-2pcs</p>	<p>K3</p>  <p>Stair-Top Panel-1pc</p>	<p>K4</p>  <p>Stair-Top Panel-1pc</p>
<p>K5</p>  <p>Stair-Top Panel-1pc</p>	<p>K6</p>  <p>Stair-Top Panel-1pc</p>	<p>M</p>  <p>Stair-Wood Bar-1pc</p>
<p>N7</p>  <p>Drawer-Sup Bottom Panels-3pcs</p>		

Hardware List(Box 2-WF291899)

<p>1</p>  <p>Ø1/4" x 15 mm Canopy head though -7pcs</p>	<p>2</p>  <p>Ø1/4" x 25 mm Hex-Head bolts 2pcs</p>	<p>3</p>  <p>Ø1/4" x 50 mm Hex-Head bolts 3pcs</p>
<p>4</p>  <p>Screws 1/4"x100 23pcs</p>	<p>5</p>  <p>Ø10 x 40 mm Wood dowel 77pcs</p>	<p>6</p>  <p>M4 x 30 mm Wood Screws 115pcs</p>
<p>7</p>  <p>Ø1/4" x 80 mm Hex-Head bolts 32pcs</p>	<p>8</p>  <p>Ø1/4" x 13 mm Horizontal-Hole bolts 36pcs</p>	<p>9</p>  <p>Screws 1/4"x30 9pcs</p>
<p>10</p>  <p>Ø1/4" x 35 mm Hex-Head bolts 19pcs</p>	<p>11</p>  <p>Ø12x 110 mm Wood dowel 4pcs</p>	<p>12</p>  <p>Ø1/4" x 70 mm Hex-Head bolts 4pcs</p>
<p>13</p>  <p>Ø1/4" x 40 mm Hex-Head bolts 8pcs</p>	<p>14</p>  <p>Screws 1/4"x50 13pcs</p>	<p>15</p>  <p>M4 x 20 mm Wood Screws 18pcs</p>
<p>16</p>  <p>Steel Bracket 2pc</p>	<p>17</p>  <p>Screws 1/4"x80 16pcs</p>	<p>18</p>  <p>M4 x 15 mm Wood Screws 29pcs</p>
<p>19</p>  <p>M3 x 12 mm Wood Screws 18pcs</p>	<p>20</p>  <p>Door Catches 45x17x13 6pcs</p>	

Hardware List(Box 2-WF291899)


21  Allen Key 1pc	22  Stop Drawer - 2pcs	23  Wood Handle- 3pcs
24  Ø1/6" x 25 mm- 3pcs	25  Wheels- 4pcs	26  Screws 1/4"x60 2pcs






Assembly Tools Required (Not Included)




STEP 1-1: Following below illustration:

-Using hardware #1,#2 connect B2 Woodbar with B1 Frame



2		1	
	2pcs		2pcs




4		26	
	4pcs		2pcs
		5	
			2pcs



STEP 1-2: Following below illustration:

-Using hardware #3,#26 and dowel 2 connect A1,A2 Legs with Frame (completed on step 1-1)

STEP 2-1: Following below illustration:


-Using hardware #4 and Dowel 5 connect A3,A4 with B6 Frame




4	5
	
4pcs	8pcs

STEP 2-2: Following below illustration:




-Using hardware #6 connect B7 with Frame(completed on step 2-1)




6

4pcs

STEP 3: Following below illustration:

-Using hardware #7, #8 and dowel #5 to Assembly Frames (Completed on step 1-2,2-2)
with siderail C2,C4 and Guardrails C1(x2),C2(x2)
-Look at detail view for more detail

8		7		5	
16pcs		16pcs		12pcs	





STEP 4:



Following below illustration:

-Screw 14 slats D1 with Side Rail C2,C4 by using hardware #6.

-Using hardware #9 connect C5 Woodbar with Frame (Completed on step 3)



-Look at detail view for more detail


9	6
	
3pcs	28pcs



STEP 5-1: Following below illustration:


-Using hardware #4 and Dowel 5 connect A5,A6 with B4 Frame


4	5
	
4pcs	8pcs



STEP 5-2: Following below illustration:



-Using hardware #6 connect B3 with Frame(completed on step 5-1)


6	
5pcs	



STEP 6-1: Following below illustration:


-Using hardware #4 and Dowel 5 connect A7,A8 with B5 Frame


4	5
	
4pcs	8pcs



STEP 6-2: Following below illustration:




-Using hardware #6 connect B3 with Frame(completed on step 6-1)


6	
5pcs	



STEP 7: Following below illustration:

-Using hardware #7, #8 and dowel #5 to Assembly Frames (Completed on step 5-2,6-2) with siderail C6(x2)
-Look at detail view for more detail

8		7		5	
8pcs		8pcs		4pcs	



STEP 8-1:


Following below illustration:

- Using hardward #10 to Assembly Slats D3 with Center Leg D4
- Look at detail view for more detail

10



2pcs



STEP 8-2:

Following below illustration:

- Screw 12 slats D2 and 2 Slats D3 (completed on step 8-1) with Side Rail C6 by using hardward #6.
- Screw 2 Stop drawer on Siderail using hardward #3

22




2pcs

6



32pcs




STEP 9:


Following below illustration:

- Align Stack upper bunk bed (completed on step 4) onto lower bunk bed (completed on step 8-2) using Wood dowel 11.
- Look at detail view for more detail

11






4pcs



STEP 10-1: Following below illustration:


-Using hardware #4 and Dowel 5 connect A9,A10 with B8 Frame and B9 Wood Bar




4	5
	
6pcs	10pcs

STEP 10-2: Following below illustration:

-Using hardware #6 connect B7 with Frame(completed on step 10-1)




6

4pcs

STEP 11: Following below illustration:

-Using hardware #9 connect Rail C5 with siderail C11 and Guardrails C10(x2)

9
3pcs



1		9	
1pc		3pcs	
10		5	
1pc		2pcs	
		7	
		2pcs	
		8	
		2pcs	

STEP 12: Following below illustration:

-12.1: Using hardware #9 connect Rail C5 with siderail C9 and Guardrails C8(x2)







-12.2: Using hardware #1, #7, #8, #10 and Dowel 5 connect Rail C7 with Frame (completed on step 12.1)



STEP 12:

Following below illustration:

-Using hardware #1,#7,#8,#12,#13 and dowel #5 to Assembly Frames (Completed on step 9,10-2) with Frames (Completed on step 11,12.2)

-Look at detail view for more detail

8		7		5	
	10pcs		6pcs		7pcs
13		1		12	
	4pcs		4pcs		4pcs



STEP 13:



Following below illustration:

- Screw 14 slats D1 with Side Rail C9,C11 by using hardward #6.
- Look at detail view for more detail

6






28pcs



STEP 14-1: Following below illustration Using hardward #14, Dowel 5 to Assembly Ladder.

Look at detail view for more detail






5		14	
	16pcs		8pcs

STEP 14-2: Following below illustration

-Using hardware #15 connect Steel Bracket (#16) with Frame (completed on step 14-1)

-Look at detail view for more detail




15	
	4pcs
16	
	2pcs



STEP 15: Following below illustration

- Using hardward #15 connect Ladder (completed on step 14-2)with Frame(completed on step13)
- Look at detail view for more detail

15




2pcs



Inside Side Rail View

STEP 16-1: Following below illustration

- Using hardware #17 connect F1, M Wood bars with F3(x2), F4
- Look at detail view for more detail




17




3pcs

STEP 16-2: Following below illustration


- align the details to the right place
- Look at detail view for more detail




STEP 16-3:



STEP 16-4:





STEP 17-1:



17



2pcs



17



5pcs


STEP 17-2:



STEP 18:

Following below illustration


- Using hardware #13,#14 connect Frames (completed on step 16-4,17-2) with Back Wood Bars H1(x3) and H2 Panels
- Look at detail view for more detail



STEP 19:

Following below illustration

- Using hardware #18 to Assembly Door Catches with K1,K2(x2) panels
- Using hardware #19 to Assembly Hinge with H4(x1),H5(x2) panels
- .Look at detail view for more detail



STEP 20:


Following below illustration

- Using hardward #10 to Assembly Frames(completed on step 18) with K3 panel,
- Look at detail view for more detail

10



4pcs




STEP 21: Following below illustration

- Using hardware #10 to Assembly Frames(completed on step 20) with K2(X2),K1 panels,
- Look at detail view for more detail

10






12pcs



STEP 22: Following below illustration

-Using hardware #15,#18 to Assembly Frames(completed on step 21) with K4,K5,K6 panels,
-Look at detail view for more detail

18	15
	
4pcs	10pcs




STEP 23: Following below illustration

-Using hardware #18 to Assembly Frames(completed on step 22) with H2,H3 panels,
-Look at detail view for more detail

18



13pcs




STEP 24: Following below illustration

Using hardware #3 to Assembly Frames(completed on step 23) with Frame(completed on step 15).
Look at detail view for more detail


3




3pcs



STEP 25-1:ASSEMBLY DRAWER



23




3pcs

24



3pcs

STEP 25-2:ASSEMBLY DRAWER





6




8pcs


STEP 25-3:ASSEMBLY DRAWER




6	
11pcs	

STEP 25-4:ASSEMBLY DRAWER



25	
4pcs	

19	
12pcs	

STEP 24:: CONGRARULATION. YOU HAVE COMPLETED THE BED. just one more step to push the Drawer into it

