


# fi-6010N Network Scanner

*ScanSnap*  
**iScanner**

Operator's Guide







# Contents

---

Copyright .....	xvii
Introduction .....	xxiii
■ Manuals .....	xxiii
■ Regulatory Information .....	xxiv
■ Trademarks .....	xxvi
■ Notice of Liability .....	xxviii
■ Safety Precautions .....	xxx
<b>Chapter 1   Scanner Overview .....</b>	<b>1</b>
<b>1.1   Scanner Features .....</b>	<b>2</b>
■ Basic uses for scanned documents .....	2
■ Configure and manage with ease .....	3
■ Advanced security measures .....	3
<b>1.2   Part Names and Functions .....</b>	<b>4</b>
1.2.1   External Parts .....	4
1.2.2   Internal Parts .....	6
<b>1.3   User Types and Operations .....</b>	<b>7</b>
<b>1.4   System Requirements .....</b>	<b>12</b>
1.4.1   Requirements for Admin Tool.....	12
■ Software (English Versions) .....	12
■ Hardware .....	12
1.4.2   Requirements for Central Admin Console .....	13
■ Software (English Versions) .....	13
■ Hardware .....	13

---

1.4.3	Requirements for Central Admin Server.....	14
	■ Software (English Versions) .....	14
	■ Hardware .....	14
1.4.4	Requirements for Related Servers .....	15
	■ LDAP Server .....	17
	■ SMTP Server .....	17
	■ File Server .....	17
	■ SharePoint Server .....	17
	■ FTP Server .....	17
	■ Print Server .....	18
	■ DNS Server .....	18
	■ WINS Server .....	18
	■ DHCP Server .....	18
	■ NTP Server .....	18
	■ Fax Server .....	18
1.4.5	Network Requirements.....	19
1.4.6	Scanner Requirements for iScanner Central Admin.....	19
1.4.7	Port Number List.....	20

## **Chapter 2 Basic Scanner Operations ..... 23**

<b>2.1</b>	<b>Turning the Power On/Off .....</b>	<b>24</b>
	■ Turning the Power On .....	24
	■ Turning the Power Off .....	25
<b>2.2</b>	<b>Using the Scanner Buttons .....</b>	<b>26</b>
2.2.1	Using the Startup Button .....	26
2.2.2	Using the Top Cover [SCAN] Button .....	27
<b>2.3</b>	<b>Using the LCD Touch Panel .....</b>	<b>28</b>
<b>2.4</b>	<b>Using the Keyboard .....</b>	<b>29</b>
2.4.1	Using the Keyboard: Administrator.....	29
2.4.2	Using the Keyboard: Regular Users .....	30

---

<b>Chapter 3</b>	<b>Administrator Operations (Overview)</b>	<b>31</b>
3.1	Operating and Managing Scanners	32
3.2	Required Scanner Function Settings	33
<b>Chapter 4</b>	<b>Administrator Operations (Touch Panel and Admin Tool)</b>	<b>37</b>
4.1	Administrator Screens via the Touch Panel	38
4.2	Administrator Screens via the Admin Tool	40
4.3	iScanner Administrator Login: via the Touch Panel	42
4.4	Setting up for Administrator Access via the Admin Tool	44
4.4.1	Checking the Internet Explorer Cache Settings	44
4.4.2	Setting the Internet Explorer Trusted Sites	45
4.4.3	Installing the Admin Tool	47
4.4.4	Uninstalling the Admin Tool	52
4.5	iScanner Administrator Login: via the Admin Tool	53
4.6	Using the System Settings Menus	56
4.6.1	Calibrating the Touch Panel	56
4.6.2	Setting the Scanner Name	59
4.6.3	Setting the Language	62
4.6.4	Setting the Region/Timezone	63
4.6.5	Setting the Date/Time	64
4.6.6	Setting the Time to Standby Mode	66
4.6.7	Setting the Login Method	68
4.6.8	Changing the Admin Password	71

---

4.6.9	Setting a File Name Format for When Saving Scanned Data .....	72
4.6.10	Setting a File Name Format for When Attaching Scanned Data to e-Mail .....	76
4.6.11	Setting the Multifeed Detection Method .....	78
4.6.12	Setting Scanning Performance .....	81
	■ Offset Settings .....	82
	■ Length Magnification Setting .....	82
4.6.13	Setting General Scanner Settings .....	83
4.6.14	Managing Certificates.....	84
	■ Importing a Certificate File .....	84
	■ Deleting a Certificate File .....	85
<b>4.7</b>	<b>Using the Network Settings Menus .....</b>	<b>86</b>
4.7.1	Giving the Scanner an IP Address .....	86
4.7.2	Setting the Admin Network .....	88
4.7.3	Setting a Central Admin Server .....	90
4.7.4	Setting the DNS Server .....	93
4.7.5	Setting the WINS Server .....	95
4.7.6	Setting the NTP Server .....	96
4.7.7	Setting the Proxy Server .....	98
4.7.8	Setting the Login LDAP Server .....	100
	■ LDAP Search Target .....	104
4.7.9	Setting the e-Mail LDAP Server .....	108
4.7.10	Setting the LDAP Search Parameters .....	111
4.7.11	Setting the e-Mail Server (SMTP Server) .....	116
4.7.12	Setting the Fax Server .....	118
4.7.13	Setting the Network Printers .....	119
	■ Checking the Printer Drivers .....	120
	■ Setting the Printer Properties .....	121
	■ Registering a Network Printer (Network Tree) .....	124
	■ Registering a Network Printer (Network Path) .....	127
	■ Renaming a Network Printer .....	129
	■ Removing a Network Printer .....	130
	■ Viewing the Printer Details .....	131

---

4.7.14	Setting the Network Folders .....	132
	■ Registering a Network Folder (Network Tree) .....	133
	■ Registering a Network Folder (Network Path) .....	136
	■ Registering a Network Folder (FTP Path) .....	138
	■ Renaming a Network Folder .....	141
	■ Removing a Network Folder .....	143
	■ Viewing the Network Folder Details .....	144
4.7.15	Setting the SharePoint Folders .....	145
	■ Renaming a SharePoint Folder (Display Name) .....	147
	■ Removing a SharePoint Folder .....	148
4.7.16	Setting the Destination for Alert Notifications .....	149
4.7.17	Checking the Network Connection with a Ping Test .....	150
4.7.18	Checking the Network Operating Status .....	152
	■ Checking the Network Status .....	152
	■ Setting the Link Speed/Duplex Mode .....	153
<b>4.8</b>	<b>Using the Device Status Menus .....</b>	<b>154</b>
4.8.1	Viewing the System Status .....	154
4.8.2	Viewing the Status of Installed Options .....	155
4.8.3	Viewing the Usage Status .....	156
	■ Viewing the Status of Consumable Parts .....	156
	■ Resetting the Usage Counter .....	157
4.8.4	Viewing the Add-in Status .....	158
<b>4.9</b>	<b>Using the Operation Logs Menus .....</b>	<b>159</b>
4.9.1	Managing the User Log .....	159
	■ Viewing the User Log Details .....	159
	■ Downloading the User Logs in CSV Format .....	161
	■ Clearing the User Logs .....	161
4.9.2	Managing the System Log .....	162
	■ Viewing the System Log Details .....	162
	■ Downloading the System Log in CSV Format .....	164
	■ Clearing the System Log .....	164

---

<b>4.10</b>	<b>Using the Maintenance Menus .....</b>	<b>165</b>
4.10.1	Maintaining the User Data Store .....	165
	■ Backing up the User Data Store .....	167
	■ Restoring the User Data Store .....	169
	■ Clearing the User Data Store .....	170
4.10.2	Maintaining the System Settings .....	171
	■ Downloading the System Settings in CSV Format .....	171
	■ Backing up System Settings .....	172
	■ Restoring System Settings .....	173
	■ Resetting Factory Defaults .....	174
4.10.3	Updating the Scanner's System Software .....	175
4.10.4	Installing/Uninstalling an Add-in Module .....	177
	■ Installing an Add-in Module .....	177
	■ Uninstalling an Add-in Module .....	178
4.10.5	Setting the Information Output Level .....	179
4.10.6	Obtaining Technical Support .....	180
<b>4.11</b>	<b>Setting Job Features .....</b>	<b>181</b>
4.11.1	Job Setting Quick User Guide .....	183
4.11.2	Setting a Job Sequence .....	185
	■ Adding a job sequence .....	185
	■ Cloning a job sequence .....	197
	■ Editing a job sequence .....	197
	■ Deleting a job sequence .....	198
	■ Filtering job sequences .....	198
	■ Filtering the LDAP List .....	199
4.11.3	Setting a Job Menu .....	203
	■ Adding a job menu .....	203
	■ Cloning a job menu .....	208
	■ Editing a job menu .....	208
	■ Deleting a job menu .....	209
	■ Viewing the detailed settings for a job menu .....	209
4.11.4	Setting a Job Group .....	210
	■ Adding a job group .....	210
	■ Editing a job group .....	215
	■ Deleting a job group .....	215

■ Viewing the detailed settings for a job group .....	216
■ Assigning job menus to users not included in a job group .....	216
■ Filtering the LDAP List .....	218

**Chapter 5 Administrator Operations (Central Admin Console) ..... 223**

**5.1 Function List ..... 224**

**5.2 Using Central Admin Console Window ..... 227**

**5.3 Central Admin Console Quick Guide ..... 229**

**5.4 Pre-settings for Using Central Admin Console ..... 231**

5.4.1	Installing the Central Admin Server Software.....	231
	■ Importing the Certificate .....	235
5.4.2	Installing the Central Admin Console .....	236
5.4.3	Setting up a Firewall for the Central Admin Server .....	239
5.4.4	Configuring the Scanner Settings for Central Admin Management.....	239
5.4.5	Uninstalling the Central Admin Server Software/Console .....	240
	■ Uninstalling the Central Admin Server Software .....	240
	■ Uninstalling the Central Admin Console .....	240

**5.5 Central Admin Server Login: via the Central Admin Console ..... 241**

**5.6 Setting the Central Admin Server ..... 244**

■ [Change Administrator Password] button .....	245
■ [User Roaming Data (Select & Clear)] button .....	245
■ Scanner Registration .....	246
■ Network Connection .....	246
■ Screen Settings .....	247
■ LDAP Server .....	247
■ SharePoint Server Connection Settings .....	250

---

■ Software Update Time-Period Restrictions .....	251
■ Operation Monitoring .....	252
■ Error Notification Settings .....	252
■ Data Import/Export .....	252
■ Log Retention .....	252
■ Audit Log Settings .....	253
■ [OK] button .....	253
■ [Cancel] button .....	253
<b>5.7 Setting Scanner Configuration .....</b>	<b>254</b>
■ [Import Config] button .....	257
■ [Export Config] button .....	258
■ Filter Conditions .....	258
■ [New] button .....	259
■ [Clone] button .....	260
■ [Edit] button .....	260
■ [Delete] button .....	260
■ [Select All] button .....	260
■ [Deselect All] button .....	260
■ Scanner information list .....	261
<b>5.8 Monitoring and Maintaining the iScanner Network .....</b>	<b>263</b>
■ iScanner Network .....	263
■ iScanner Updates .....	264
■ iScanner Events .....	265
<b>5.9 Updating the System .....</b>	<b>266</b>
■ Registered System Update .....	266
■ Upload & Release a New System Update .....	266
■ [Back] button .....	267
<b>5.10 Installing an Add-in .....</b>	<b>268</b>
■ Add-in Groups .....	268
■ Registered Add-in Module .....	268
■ Upload & Release a New Add-in .....	269
■ [Back] button .....	270



---

<b>5.11</b>	<b>Updating the Scanner System Settings</b>	<b>271</b>
	■ Settings Groups	271
	■ Registered Scanner Settings	272
	■ Upload & Release a New Set of Scanner Settings	272
	■ [Back] button	274
<b>5.12</b>	<b>Setting the Job Mode</b>	<b>275</b>
	■ Registered Job Mode Settings	275
	■ Create & Release a New Set of Job Mode Settings	276
	■ [Back] button	277
<b>5.13</b>	<b>Viewing the Update Status Lists</b>	<b>278</b>
	■ Filter Conditions	278
	■ [Call Now] button	279
	■ [Clear Update Failures] button	279
	■ [Select All] button	279
	■ [Deselect All] button	279
	■ Scanner list	279
	■ [Back] button	280
<b>5.14</b>	<b>Viewing the Scanners Operating Status</b>	<b>281</b>
	■ Scanner Operating Status	282
	■ Filter Conditions	283
	■ [Clear All Errors] Button	283
<b>5.15</b>	<b>Viewing Event Log</b>	<b>284</b>
	■ [Download] button	284
	■ [Clear Log] button	284
	■ Filter Conditions	284
	■ Event Log	285
<b>5.16</b>	<b>Collecting and Exporting Audit Logs</b>	<b>286</b>
5.16.1	Collecting Audit Logs	287
5.16.2	Exporting Audit Logs	287
5.16.3	File Format of Audit Logs	289

---

<b>5.17</b>	<b>Maintaining Central Admin Settings .....</b>	<b>291</b>
5.17.1	Backing Up Central Admin Settings .....	291
5.17.2	Restoring Central Admin Settings .....	293
5.17.3	Obtaining Technical Support on the Central Admin Server .....	294
5.17.4	Migrating Data to an Updated Version of the Central Admin Server Software.....	295
<b>Chapter 6</b>	<b>Regular User Operations .....</b>	<b>297</b>
<b>6.1</b>	<b>Loading Documents .....</b>	<b>298</b>
6.1.1	How to Load Documents .....	298
6.1.2	Loading Documents Using a Carrier Sheet.....	301
<b>6.2</b>	<b>Using Touch Panel Screens: Regular User .....</b>	<b>304</b>
6.2.1	Common Buttons and Indicators .....	304
6.2.2	Regular User Settings Overview .....	305
6.2.3	Main Menu Screen .....	306
6.2.4	Job Menu Screen .....	308
<b>6.3</b>	<b>Logging in: Regular User Mode .....</b>	<b>311</b>
<b>6.4</b>	<b>Sending the Scanned Data by e-Mail .....</b>	<b>314</b>
6.4.1	Selecting an e-Mail Target from the e-Mail Address Book .....	319
6.4.2	Adding an e-Mail Target to the e-Mail Address Book .....	324
6.4.3	Editing an e-Mail Target in the e-Mail Address Book .....	327
6.4.4	Deleting an e-Mail Target from the e-Mail Address Book .....	329
<b>6.5</b>	<b>Sending the Scanned Data by Fax .....</b>	<b>330</b>
6.5.1	Selecting a Fax Number from the Fax Number List .....	332
6.5.2	Adding a Contact to the Fax Number List.....	335
6.5.3	Editing a Contact in the Fax Number List .....	337
6.5.4	Deleting a Contact from the Fax Number List .....	338

---

<b>6.6</b>	<b>Printing the Scanned Data .....</b>	<b>339</b>
6.6.1	Scaling.....	344
6.6.2	Positioning .....	349
6.6.3	Simplex/Duplex.....	351
<b>6.7</b>	<b>Saving the Scanned Data to a Network Folder .....</b>	<b>352</b>
<b>6.8</b>	<b>Saving the Scanned Data in a SharePoint Folder ....</b>	<b>357</b>
<b>6.9</b>	<b>Setting the Scan Options .....</b>	<b>365</b>
6.9.1	Carrier Sheet .....	372
6.9.2	Color Mode .....	373
6.9.3	Paper Size .....	374
	■ Long Page Mode .....	376
6.9.4	Resolution.....	378
6.9.5	Scan Mode .....	379
6.9.6	File Format .....	380
6.9.7	Searchable PDF .....	382
6.9.8	PDF Password.....	385
6.9.9	Compression .....	387
6.9.10	Brightness.....	390
6.9.11	Contrast .....	391
6.9.12	Sharpness .....	392
6.9.13	Dropout Color .....	393
6.9.14	Background Removal .....	394
6.9.15	Blank Page Skip .....	395
6.9.16	Page Orientation.....	396
6.9.17	Multifeed Detection (Layer and Length) .....	399
6.9.18	Edge Cropping.....	400
<b>6.10</b>	<b>Enabling/Disabling the Scan Viewer .....</b>	<b>402</b>

---

<b>6.11</b>	<b>Editing the Scanned Data in the Scan Viewer .....</b>	<b>405</b>
6.11.1	Viewing a Scanned Page .....	406
6.11.2	Rotating a Scanned Page.....	407
6.11.3	Adding a Scanned Page.....	408
6.11.4	Deleting a Scanned Page.....	409
<b>6.12</b>	<b>Checking the User Log .....</b>	<b>410</b>
<b>6.13</b>	<b>Maintenance .....</b>	<b>412</b>
<b>6.14</b>	<b>Processing a Job .....</b>	<b>413</b>
6.14.1	Enabling/Disabling the Message Screen.....	417
6.14.2	Changing a File Name (for Save/e-Mail Attachment) .....	419
6.14.3	Checking the Number of Sheets to Be Scanned .....	420
<b>Chapter 7</b>	<b>Scanner Care .....</b>	<b>423</b>
<b>7.1</b>	<b>Cleaning .....</b>	<b>424</b>
7.1.1	Cleaning Materials.....	424
7.1.2	Which Parts and When.....	425
<b>7.2</b>	<b>Cleaning the ADF .....</b>	<b>426</b>
7.2.1	Cleaning the ADF .....	427
<b>7.3</b>	<b>Cleaning the LCD Touch Panel .....</b>	<b>433</b>
<b>7.4</b>	<b>Cleaning the Keyboard .....</b>	<b>434</b>
<b>7.5</b>	<b>Cleaning the Carrier Sheet .....</b>	<b>435</b>

<b>7.6</b>	<b>Replacing Parts .....</b>	<b>436</b>
7.6.1	Part Numbers and Replacement Cycles .....	436
	■ Part numbers and replacement cycle for consumable parts .....	436
	■ Part numbers and replacement cycle for Carrier Sheet .....	437
7.6.2	Checking the Consumable Alert Status.....	438
7.6.3	Replacing the Pad Assy .....	439
7.6.4	Replacing the Pick Roller .....	440
7.6.5	Purchasing the Carrier Sheet .....	444
<b>7.7</b>	<b>Performing a Scan Test .....</b>	<b>445</b>
<b>Chapter 8</b>	<b>Troubleshooting .....</b>	<b>449</b>
<b>8.1</b>	<b>Removing Jammed Documents .....</b>	<b>450</b>
<b>8.2</b>	<b>Dealing with Detached Keycaps .....</b>	<b>454</b>
<b>8.3</b>	<b>Network Connection Troubleshooting .....</b>	<b>456</b>
8.3.1	Basic Network Operation Tests .....	456
	■ Checking basic network operation with a Ping test .....	456
	■ Checking the network operating status .....	458
	■ Checking the NTP server settings by synchronizing the system time .....	459
	■ Checking the mail server by sending a test mail .....	460
8.3.2	Other Network Connection Troubleshooting .....	461
	■ Failure to connect to a server using its IP address .....	461
	■ Failure to connect to a server using its host name or FQDN .....	463
	■ Failure to add a network printer .....	464
	■ Failure to print on a network printer .....	464
8.3.3	Failure to Access the Scanner using a Web Browser, Admin Tool, or Central Admin Server.....	465
<b>8.4</b>	<b>Other Troubleshooting .....</b>	<b>468</b>

---

<b>8.5</b>	<b>Points to Check before Contacting Your FUJITSU Scanner Dealer .....</b>	<b>472</b>
8.5.1	General Details.....	472
8.5.2	Error Status .....	473
	■ Problem when connecting to the scanner via computer .....	473
	■ Document feed trouble .....	473
	■ Problem with Central Admin .....	474
	■ Other problems .....	474
<b>8.6</b>	<b>Checking the Scanner Labels .....</b>	<b>475</b>
<b>8.7</b>	<b>Pre-Maintenance Preparations .....</b>	<b>476</b>
<b>Appendix A</b>	<b>ADF Paper Specifications .....</b>	<b>477</b>
<b>A.1</b>	<b>Paper Size .....</b>	<b>478</b>
<b>A.2</b>	<b>Paper Requirements .....</b>	<b>479</b>
A.2.1	Paper Type.....	479
A.2.2	Paper Weight.....	479
A.2.3	Precautions.....	479
<b>A.3</b>	<b>Maximum Document Loading Capacity .....</b>	<b>482</b>
<b>A.4</b>	<b>Area not to be Perforated .....</b>	<b>483</b>
<b>A.5</b>	<b>Multifeed Detection Conditions .....</b>	<b>484</b>
A.5.1	Detection by Layer.....	484
A.5.2	Detection by Length.....	484
A.5.3	Detection by both Layer and Length.....	485
<b>Appendix B</b>	<b>Management Settings and Files .....</b>	<b>487</b>
<b>B.1</b>	<b>e-Mail Address Setting Values .....</b>	<b>488</b>

---

<b>B.2</b>	<b>Scanner Configuration File Format .....</b>	<b>489</b>
B.2.1	Scanner Configuration File Format (for Importing) .....	489
B.2.2	Scanner Configuration File Format (for Exporting) .....	490
<b>Appendix C</b>	<b>Root Certification Authority .....</b>	<b>493</b>
<b>C.1</b>	<b>Root Certification Authority List .....</b>	<b>494</b>
<b>Appendix D</b>	<b>Scanner Specifications .....</b>	<b>497</b>
<b>D.1</b>	<b>Device Specifications .....</b>	<b>498</b>
<b>D.2</b>	<b>Scanner Specifications .....</b>	<b>499</b>
<b>D.3</b>	<b>Languages Supported By and Keyboard Covers     Provided With .....</b>	<b>500</b>
<b>Appendix E</b>	<b>Operation Messages .....</b>	<b>501</b>
<b>E.1</b>	<b>Administrator Messages .....</b>	<b>502</b>
E.1.1	Administrator Screen Messages.....	503
E.1.2	System Log Messages .....	516
■	Information .....	516
■	Error .....	519
■	Warning .....	521
E.1.3	Alert Monitor System Log Messages.....	522
■	Information .....	522
■	Error .....	523
■	Warning .....	525
<b>E.2</b>	<b>Regular User Messages .....</b>	<b>526</b>
E.2.1	Regular User Screen Messages.....	526
E.2.2	System Log Messages .....	549
■	Information .....	549
■	Warning .....	551
■	Error .....	551

---

E.2.3	User Log .....	571
<b>E.3</b>	<b>Central Admin Messages .....</b>	<b>584</b>
E.3.1	Central Admin Console Messages .....	584
E.3.2	System Log Messages .....	588
■	Information .....	588
■	Warning .....	588
■	Error .....	590
E.3.3	Event Log .....	595
■	System Event Log .....	595
■	Central Admin Console Event Log .....	597
E.3.4	Backup/Restore Command Messages .....	601
■	Information .....	601
■	Error .....	601
E.3.5	Audit Log Export Command Messages .....	605
<b>Appendix F</b>	<b>Compatibility with Different Versions .....</b>	<b>607</b>
<b>F.1</b>	<b>Backing Up/Restoring User Data and Scanner Settings .....</b>	<b>608</b>
<b>F.2</b>	<b>Updating System Settings from the Central Admin Server .....</b>	<b>609</b>
<b>F.3</b>	<b>Functional Compatibility between the Scanner and Central Admin Server .....</b>	<b>610</b>
<b>F.4</b>	<b>Backing Up/Restoring Data between Different Versions of the Central Admin Server Software .....</b>	<b>611</b>
<b>Appendix G</b>	<b>Glossary .....</b>	<b>613</b>
<b>Index</b>	<b>.....</b>	<b>619</b>



# Copyright

---

## NetAdvantage 2007

Copyright 2000-2007 Infragistics, Inc.

## LEADTOOLS for .NET

Copyright© 2005 LEAD Technologies, Inc.

## WinPcap3.1

Copyright© 1999 - 2005 NetGroup, Politecnico di Torino (Italy).  
Copyright© 2005 - 2006 CACE Technologies, Davis (California).  
All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

1. Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
2. Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
3. Neither the name of the Politecnico di Torino, CACE Technologies nor the names of its contributors may be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY THE COPYRIGHT HOLDERS AND CONTRIBUTORS "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE COPYRIGHT OWNER OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

This product includes software developed by the University of California, Lawrence Berkeley Laboratory and its contributors.

This product includes software developed by the Kungliga Tekniska Hogskolan and its contributors.

This product includes software developed by Yen Yen Lim and North Dakota State University.

---

Portions Copyright© 1990, 1991, 1992, 1993, 1994, 1995, 1996, 1997 The Regents of the University of California.  
All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

1. Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
2. Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
3. All advertising materials mentioning features or use of this software must display the following acknowledgement: "This product includes software developed by the University of California, Berkeley and its contributors."
4. Neither the name of the University nor the names of its contributors may be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY THE INSTITUTE AND CONTRIBUTORS "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE REGENTS OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

---

Portions Copyright© 1983 Regents of the University of California.  
All rights reserved.

Redistribution and use in source and binary forms are permitted provided that the above copyright notice and this paragraph are duplicated in all such forms and that any documentation, advertising materials, and other materials related to such distribution and use acknowledge that the software was developed by the University of California, Berkeley. The name of the University may not be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED "AS IS" AND WITHOUT ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, WITHOUT LIMITATION, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE.

---

Portions Copyright© 1995, 1996, 1997 Kungliga Tekniska Hogskolan (Royal Institute of Technology, Stockholm, Sweden).  
All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

1. Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
2. Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
3. All advertising materials mentioning features or use of this software must display the following acknowledgement: "This product includes software developed by the Kungliga Tekniska Hogskolan and its contributors."
4. Neither the name of the University nor the names of its contributors may be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY THE INSTITUTE AND CONTRIBUTORS "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE INSTITUTE OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

---

Portions Copyright© 1997 Yen Yen Lim and North Dakota State University.  
All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

1. Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
2. Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
3. All advertising materials mentioning features or use of this software must display the following acknowledgement: "This product includes software developed by Yen Yen Lim and North Dakota State University"
4. The name of the author may not be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY THE AUTHOR "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE AUTHOR BE LIABLE FOR ANY DIRECT, INDIRECT,

---

INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

Portions Copyright© 1993 by Digital Equipment Corporation.

Permission to use, copy, modify, and distribute this software for any purpose with or without fee is hereby granted, provided that the above copyright notice and this permission notice appear in all copies, and that the name of Digital Equipment Corporation not be used in advertising or publicity pertaining to distribution of the document or software without specific, written prior permission.

THE SOFTWARE IS PROVIDED "AS IS" AND DIGITAL EQUIPMENT CORP. DISCLAIMS ALL WARRANTIES WITH REGARD TO THIS SOFTWARE, INCLUDING ALL IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS. IN NO EVENT SHALL DIGITAL EQUIPMENT CORPORATION BE LIABLE FOR ANY SPECIAL, DIRECT, INDIRECT, OR CONSEQUENTIAL DAMAGES OR ANY DAMAGES WHATSOEVER RESULTING FROM LOSS OF USE, DATA OR PROFITS, WHETHER IN AN ACTION OF CONTRACT, NEGLIGENCE OR OTHER TORTIOUS ACTION, ARISING OUT OF OR IN CONNECTION WITH THE USE OR PERFORMANCE OF THIS SOFTWARE.

---

Portions Copyright© 1995, 1996, 1997, 1998, and 1999 WIDE Project.  
All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

1. Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
2. Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
3. Neither the name of the project nor the names of its contributors may be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY THE PROJECT AND CONTRIBUTORS "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE PROJECT OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

---

Portions Copyright© 1996 Juniper Networks, Inc. All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that: (1) source code distributions retain the above copyright notice and this paragraph in its entirety, (2) distributions including binary code include the above copyright notice and this paragraph in its entirety in the documentation or other materials provided with the distribution.

The name of Juniper Networks may not be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED "AS IS" AND WITHOUT ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, WITHOUT LIMITATION, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE.

---

Portions Copyright© 2001 Daniel Hartmeier  
All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

- Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
- Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.

THIS SOFTWARE IS PROVIDED BY THE COPYRIGHT HOLDERS AND CONTRIBUTOR "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE COPYRIGHT HOLDERS OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

---

Portions Copyright 1989 by Carnegie Mellon.

Permission to use, copy, modify, and distribute this program for any purpose and without fee is hereby granted, provided that this copyright and permission notice appear on all copies and supporting documentation, the name of Carnegie Mellon not be used in advertising or publicity pertaining to distribution of the program without specific prior permission, and notice be given in supporting documentation that copying and distribution is by permission of Carnegie Mellon and Stanford University. Carnegie Mellon makes no representations about the suitability of this software for any purpose. It is provided "as is" without express or implied warranty.

---

## WinDump3.9.5

Copyright© 1999 - 2005 NetGroup, Politecnico di Torino (Italy).  
Copyright© 2005 - 2006 CACE Technologies, Davis (California).  
All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

1. Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
2. Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
3. Neither the name of the Politecnico di Torino, CACE Technologies nor the names of its contributors may be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY THE COPYRIGHT HOLDERS AND CONTRIBUTORS "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE COPYRIGHT OWNER OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

This product includes software developed by the University of California, Lawrence Berkeley Laboratory and its contributors.

## Secure iNetSuite 2.0J

Copyright© 2007 Dart Communications

# Introduction

---

Thank you for purchasing the fi-6010N Network Scanner.

This easy-to-use image scanner is designed to be connected to a computer network system and is primarily for office use.

## ■ Manuals

The following manuals are prepared for the scanner. Read them as needed.

Manual	Description
fi-6010N Network Scanner Getting Started (paper)	Provides useful and detailed information on setting up, connecting, and caring for your scanner. Read this manual first. In this guide, it is indicated as "Getting Started".
fi-6010N Network Scanner Operator's Guide (This Manual) (PDF)	Contains further information about scanner settings, scanner administration, and scanner operations, and may be used as a general reference. To read the manual, download it from the scanner. For more details about how to download the manual, refer to the "Getting Started".

---

## ■Regulatory Information

### FCC Declaration

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is located.
- Consult your dealer or an experienced radio/TV technician.

**FCC warning:** Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

---

#### NOTICE

The use of a shielded interface cable is required to comply with the Class B limits of Part 15 of FCC rules. The length of the AC cable must be 2 meters (6.6 feet) or less.

---

### Canadian DOC Regulations

This digital apparatus does not exceed the Class B limit for radio noise emissions from digital apparatus set out in the Radio interference Regulations of the Canadian Department of Communications.

This Class B digital apparatus complies with Canadian ICES-003.

Le présent appareil numérique n'émet pas de parasites radioélectriques dépassant les limites applicables aux appareils numériques de la classe B et prescrites dans le Règlement sur le brouillage radioélectrique dictées par le Ministère des Communications du Canada.

Cet appareil numérique de la classe B est conforme la norme NMB-003 du Canada.

### Bescheinigung des Herstellers / Importeurs

Für den fi-6010N wird folgendes bescheinigt:

- In Übereinstimmung mit den Bestimmungen der EN45014(CE) funkentstört
- Maschinenlärminformationsverordnung 3.GPSGV: Der höchste Schalldruckpegel beträgt 70 dB (A) oder weniger, gemäß EN ISO 7779.




---

## Use in High-safety Applications

This product has been designed and manufactured on the assumption that it will be used in office, personal, domestic, regular industrial, and general-purpose applications. It has not been designed and manufactured for use in applications (simply called "high-safety applications" from here on) that directly involve danger to life and health when a high degree of safety is required, for example, in the control of nuclear reactions at nuclear power facilities, automatic flight control of aircraft, air traffic control, operation control in mass-transport systems, medical equipment for sustaining life, and missile firing control in weapons systems, and when provisionally the safety in question is not ensured. The user should use this product with adopting measures for ensuring safety in such high-safety applications. PFU LIMITED assumes no liability whatsoever for damages arising from use of this product by the user in high-safety applications, and for any claims or compensation for damages by the user or a third party.

## About the Use of Mercury



To avoid unexpected injury, read the following carefully.  
Doing the following actions may result in serious personal injuries:

- Do not lick or consume the substance contained in the lamp.
- Do not incinerate, crush, or shred the lamps or scanner parts.
- Do not breathe the chemical liquid contained in the scanner lamps.

## LCD Peculiarities

- The LCD backlight is a fluorescent tube that contains some mercury.
- Be aware that neither of the following is considered a fault.
  - Despite the fact that the latest advanced technology has been used to produce the scanner's TFT color LCD's, the large number of pixels involved means that an occasional (always-on) bright dot or (always-off) dark dot may be visible.
  - The characteristics of the LCD mean that there may be some variation in hue and intensity of colors across the screen.

## Replacing Batteries

In order to retain data such as BIOS information, this product has a battery (CMOS RAM battery) on board.



- Do not replace the battery yourself, as there is a risk of explosion if the wrong type is used. Please contact your maintenance engineer in charge when the battery runs low.
  - Do not touch the battery. Never install or remove the battery by yourself. Doing so may cause electric shock or static electricity which can damage the device.
-

---

## About Maintenance

The user must not perform repairs on this scanner.

Contact your FUJITSU scanner dealer or an authorized FUJITSU scanner service provider for repairs to this product.

## ■ Trademarks

Microsoft, Windows, Windows Vista, Windows Server, and SharePoint are either registered trademarks or trademarks of Microsoft Corporation in the United States and/or other countries.

Adobe, the Adobe logo, Acrobat, and Acrobat Reader are either registered trademarks or trademarks of Adobe Systems Incorporated in the United States and/or other countries.

Intel, Pentium, and Intel Core are trademarks or registered trademarks of Intel Corporation in the United States and other countries.

ABBYY, FineReader are trademarks of ABBYY.

Other company names and product names are the trademarks or registered trademarks of the respective companies.

## How Trademarks are Indicated in This Manual

References to operating systems (OS) and applications are indicated as follows:

Windows	Microsoft® Windows® operating system
Windows XP	Microsoft® Windows® XP Professional operating system Microsoft® Windows® XP Home Edition operating system
Windows Vista	Microsoft® Windows Vista® Home Basic operating system Microsoft® Windows Vista® Home Premium operating system Microsoft® Windows Vista® Business operating system Microsoft® Windows Vista® Enterprise operating system Microsoft® Windows Vista® Ultimate operating system
Windows 7	Microsoft® Windows® 7 Home Premium operating system Microsoft® Windows® 7 Professional operating system Microsoft® Windows® 7 Enterprise operating system Microsoft® Windows® 7 Ultimate operating system
Windows 2000 Server	Microsoft® Windows® 2000 Server Microsoft® Small Business Server 2000 Microsoft® Windows® 2000 Advanced Server
Windows Server 2003	Microsoft® Windows Server® 2003, Standard Edition Microsoft® Windows Server® 2003, Enterprise Edition Microsoft® Windows Server® 2003, Datacenter Edition

---

Windows Server 2008	Microsoft® Windows Server® 2008 Standard Microsoft® Windows Server® 2008 Enterprise Microsoft® Windows Server® 2008 Datacenter
Exchange	Microsoft® Exchange 2000 Server Microsoft® Exchange Server 2003 Microsoft® Exchange Server 2007 (supported by 64-bit operating systems only)
.NET Framework	Microsoft® .NET Framework
SharePoint	Microsoft® Office SharePoint® Server 2007
Internet Explorer	Microsoft® Internet Explorer®
Internet Information	Microsoft® Internet Information Services
SQL Server 2005 Express Edition	Microsoft® SQL Server® 2005 Express Edition
Adobe Acrobat	Adobe® Acrobat®
Adobe Reader	Adobe® Reader®
RightFax	RightFax Business Server (Version 9.3)
Intel Pentium III Processor	Intel® Pentium® III Processor

## Manufacturer

### PFU LIMITED

International Sales Dept., Imaging Business Division, Products Group  
Solid Square East Tower  
580 Horikawa-cho, Saiwai-ku, Kawasaki-shi Kanagawa 212-8563, Japan  
Phone: (81-44) 540-4538

All Rights Reserved, Copyright© PFU LIMITED 2009-2010

---

## ■ Notice of Liability

BEFORE USING THIS PRODUCT, PLEASE READ THIS MANUAL CAREFULLY. IF THIS PRODUCT IS NOT USED CORRECTLY, UNEXPECTED INJURY CAN OCCUR TO USERS OR BYSTANDERS.

Keep this manual in a safe place so that it can be easily referred to during use of this product.

While all efforts have been made to ensure the accuracy of all information in this manual, PFU assumes no liability to any party for any damage caused by errors or omissions or by statements of any kind in this manual, its updates or supplements, whether such errors are omissions or statements resulting from negligence, accidents, or any other cause. PFU further assumes no liability arising from the application or use of any product or system described herein; nor any liability for incidental or consequential damages arising from the use of this manual. PFU disclaims all warranties regarding the information contained herein, whether expressed, implied, or statutory.

### Warning Indications Used in This Manual



This indication alerts operators to an operation that, if not strictly observed, may result in severe injury or death.





This indication alerts operators to an operation that, if not strictly observed, may result in safety hazards to personnel or damage to equipment.

---

---

## Symbols Used in This Manual

This manual uses the following symbols in the explanations in addition to the warning indications.



A TRIANGLE symbol indicates that special care and attention is required. The drawing inside the triangle shows the specific caution.



A CIRCLE with a diagonal line inside shows action which users may not perform. The drawing inside or under the circle shows the specific action that is not allowed.



Outline characters on a colored background show instructions users should follow. It may also include the drawing that shows the specific instruction.



This symbol is used to indicate information about administrator operations. In Chapter 4, operations that can be performed by either or both of the administrator login modes are indicated by the following symbols:



: Administrator operating via the touch panel.



: Administrator operating via the network interface using the fi Network Scanner Admin Tool.



: Administrator operating via the network interface using the iScanner Central Admin Console.



This symbol is used to indicate information about regular user operations.

---

## Warning Label



### High Temperature

The glass scanner windows surface inside the ADF becomes hot when the scanner is used. Be careful not to touch the surface of the glass scanner windows.



Do NOT remove from the scanner, stain or scratch the warning labels.



## Screen Examples in This Manual

The screen examples in this manual are subject to change without notice in the interest of product improvement. If the actual displayed screen differs from the screen examples in this manual, operate by following the actual displayed screen while referring to the User's Manual of the scanner application you are using.

The screen examples in this manual are of Windows Vista.

## ■ Safety Precautions

This manual describes important details for ensuring the safe and correct use of this product.

Thoroughly read this manual before you start to use this product. In particular, be sure to read and fully understand the Safety Precautions described in this manual before you use this product.

Also, store this manual in a safe place so that it can be easily referred to during use of this product.



---

### Do not damage the AC cable.



A damaged AC cable may cause fire or electric shock. Do not place heavy objects on AC cables, or pull, bend, twist, heat, damage or modify AC cables.

Do not use damaged AC cables or power plugs, or install any cables or power plugs to loose wall sockets.

---

### Use only specified AC cables and connector cables.



Use only specified AC cables and connector cables. Failure to use the correct cables might cause electric shock and/or equipment failure.

Please do not use the AC cable provided with this scanner for other devices, since this might cause equipment failure and other troubles or an electric shock.

---

---

**Use this scanner only at the indicated power voltage. Do not connect to multiple-power strips.**



Use this scanner only at the indicated power voltage and current. Improper power voltage and current might cause fire or electric shock. Do not connect to multiple-power strips.

---

**Do not touch the AC cable with wet hands.**



Do not touch the power plug with wet hands. Doing so can cause electric shock.

---

**Wipe any dust from the power plug.**



Wipe off any dust from metal parts on the power plug or metal fittings with a soft, dry cloth. Accumulated dust can cause fire or electric shock.

---

**Do not install the device in locations that has oil smoke, steam, humidity, and dust.**



Do not install the scanner in locations subject to oil smoke, steam, humidity, and dust. Doing so might cause a fire or electric shock.

---

**Turn the scanner OFF if it is damaged.**



If the scanner is damaged for any reason, turn the scanner off and unplug the power cable. Contact your FUJITSU scanner dealer or an authorized FUJITSU scanner service provider.

---

**Do not use the scanner if there is a strange odor.**



If you detect heat coming from the device or detect other problems such as smoke, strange smells or noises, immediately turn off the scanner and disconnect its power plug. Make sure that any smoke coming from it has stopped, before contacting your FUJITSU scanner dealer or an authorized FUJITSU scanner service provider.

---

**Do not put liquids inside the scanner.**



Do not insert or drop metal objects in to the scanner. Do not scan wet documents or documents with paper clips or staples. Do not splash or allow the scanner to get wet.



If foreign objects (water, small metal objects, liquids, etc.) get inside the scanner, immediately turn off the scanner and disconnect the power plug from the power outlet. Then, contact your FUJITSU scanner dealer or an authorized FUJITSU scanner service provider. Pay particular attention to this warning in households where there are small children.



---

### **Do not touch the inside of the scanner unless necessary.**



Do not take apart or modify the scanner. The inside of the scanner contains high-voltage components. Touching these components might cause electric shock or fire.

---

### **Do not use aerosol sprays near the scanner.**



Do not use any aerosol sprays or alcohol based sprays to clean the scanner. Dust blown up by strong air from the spray may enter the inside of the scanner. This may cause the scanner to fail or malfunction. Sparks, caused by static electricity, generated when blowing off dust and dirt from the outside of the scanner may cause a fire.

---

### **Do not place the scanner within the reach of small children.**



To avoid injuries, do not place the scanner in an area where small children may be able to reach.

---

### **Do not touch the heated section for a long time.**



Do not touch the heated section such as the bottom of the scanner for a long time. Doing so may cause a low-temperature burn on your skin.

---

### **Do not cover the scanner with something during its operation.**



Do not use the scanner while covered with a blanket, etc. Doing so may raise the temperature inside and cause a fire.

---

### **Do not use the scanner where it gets wet.**



Do not use the scanner at a place such as a bathroom, shower room, or swimming pool where it may easily get wet. Doing so might cause electric shock or fire.





---

### **Do not install the scanner on unstable surfaces.**



Make sure that the scanner is installed on a flat, level surface and that none of its parts extend beyond the surface top, such as a desk or table. Do not install the scanner on unstable surfaces. Install the scanner on a level surface that is free of vibration to prevent it from falling.



Install the scanner on a strong surface that will support the weight of the scanner and other devices.

---

### **Firmly insert the power plug.**



Firmly insert the power plug as far it can go into the power outlet.

---

### **Do not block the ventilation ports.**



Do not block the ventilation ports. Blocking the ventilation ports generates heat inside of scanner, which may result in fire or scanner failure.

---

### **Do not place heavy objects or stand on top of the scanner.**



Do not place heavy objects on the scanner or use the scanner's surface top to perform other work. Improper installation might cause injuries and equipment failure.

---

### **Do not use the scanner immediately after moving it from a cold place into a warm room.**



Do not use the device immediately after moving it from a cold place into a warm room. Condensation may occur, which might lead to scanning errors. Let the device dry about one or two hours before you use it.

---

### **Before moving the scanner, disconnect the power plug from the power outlet.**



Do not move the scanner with the power and interface cables connected as this can damage the cables, which can later cause fire, electric shock as well as injury. Before moving the scanner, be sure to disconnect the power plug from the power outlet, and all other data cables. Make sure that the floor is free of any obstructions.

---

---

**Protect the scanner from static electricity.**



Install the scanner away from strong magnetic fields and other sources of electronic noise. Also, protect the scanner against any static electricity, which can cause the scanner to malfunction.

---

**Avoid any contact when scanner is in use.**



Avoid touching any scanner mechanism during scanning since this may cause injuries.

---

**Disconnect the power plug from the power outlet when the scanner is not used for a long period of time.**



When the scanner is not going to be used for a long period of time, be sure to disconnect the power plug from the power outlet.

---

**Do not install the scanner in direct sunlight.**



Do not install the scanner under direct sunlight or near heating apparatus. Doing so might cause excessive heat to build up inside the scanner, which can cause scanner trouble or even fire. Install the scanner in a well-ventilated location.

---

**Handle documents carefully.**



When handling documents, be careful not to cut your fingers with them.

---

**Do not make the scanner wet while carrying it outside.**



When carrying the scanner outside while it is raining or snowing, pay special attention so the scanner does not get wet.

---

**Do not place the scanner in areas, which are subject to high levels of shock or vibration.**



Do not place the scanner in areas, which are subject to high levels of shock or vibration. Doing so may cause the scanner to malfunction.

---

---

### **Be aware of the pick spring.**



When you perform cleaning, make sure that the inside of the scanner is free of any foreign object, and be careful not to get your hand or the cloth caught on the pick spring (metal part) as a deformed pick spring (metal part) may cause injury.



# Chapter 1

## Scanner Overview

Admin User

- 1.1 Scanner Features ..... 2
- 1.2 Part Names and Functions ..... 4
- 1.3 User Types and Operations..... 7
- 1.4 System Requirements..... 12


# 1.1 Scanner Features

## ■ Basic uses for scanned documents

This easy-to-operate network scanner is used to scan documents for further use:


1. Scanned document files can be sent as an e-mail attachment.
2. Scanned document files can be sent by fax.
3. Scanned document files can be printed on a network printer.
4. Scanned document files can be saved in a network folder.
5. Scanned document files can be saved in a SharePoint folder(\*).

(\*): In this manual, a folder on the SharePoint server in which scanned document files are saved, is referred to as "SharePoint folder".



## ■ Configure and manage with ease

Configuration and management of the scanner can be easily performed via the touch panel, or via the fi Network Scanner Admin Tool (hereinafter referred to as Admin Tool) or the iScanner Central Admin Console (hereinafter referred to as Central Admin Console), installed on a computer.



## ■ Advanced security measures

The following security functions are provided for the scanner.

- Login authentication can restrict user access.
- Scans can be converted to password protected PDF files.
- Scanned data can be protected.

Since the scanner is intended to be shared by multiple users, data privacy is an important factor.

The following security measures are used to protect the data against untoward access:

- Encryption
  - While it may be temporarily stored in the scanner before being e-mailed, faxed, printed, or saved, the scanned data is always kept in an encrypted form, in order to prevent exposure of data via analysis of the disk contents.
- Scanned data deletion
  - After the scanned data has been e-mailed, faxed, printed or saved, the temporary data is deleted. Even if an error interrupts this process, leaving some scanned data in the scanner, this will automatically be deleted at the next start up.
- Key regeneration
  - When the user data store is cleared from the scanner, the old cipher key is deleted and a new cipher key is generated. This totally eliminates the possibility of access to any user data remaining in the freed disk space.


In addition, input of files from external media or networks is not possible.

Therefore, the scanner is protected against virus infection.


## 1.2 Part Names and Functions

### 1.2.1 External Parts

- Front view




- Rear view





No.	Part name	Function
1	Startup button	Turns on scanner or brings up the "Login" screen from standby mode. For details, refer to <a href="#">"2.2.1 Using the Startup Button" (page 26)</a> .
2	[SCAN] button	Starts the scan process. For details, refer to <a href="#">"2.2.2 Using the Top Cover [SCAN] Button" (page 27)</a> .
3	LCD touch panel	Accepts user input and displays the scanner control screens. The LCD touch panel buttons are used to setup scans. For details, refer to <a href="#">"2.3 Using the LCD Touch Panel" (page 28)</a> .
4	Keyboard	Used to enter text in the control screen input fields. May also be used instead of the touch panel to operate the control screens. For details, refer to <a href="#">"2.4 Using the Keyboard" (page 29)</a> .
5	Output tray	Scanned documents are ejected from the ADF onto this tray. Small documents may be retrieved by lifting up the keyboard after scanning has completed.
6	ADF paper chute	Holds the documents waiting to be scanned (scan side down).
7	Side guides	Adjust to the width of the paper, to prevent skewing of the scanned pages.
8	Top cover	Frames the LCD touch panel, and covers the upper scanner/ADF mechanism. Must be opened to clean inside the scanner, or when replacing consumable parts.
9	ADF release button	Push to unlock the top cover.
10	Back cover	When connecting cables, press the tabs on both sides of the back cover to unlock it, and pull it out from the scanner.
11	Security cable slot	Slot for commercially available security cable to prevent against theft. The following security cable is recommended. Type: Right angle Cylindrical part: diameter 25mm (max), length 50mm (max) (includes bent part if a straight cable is used)
12	AC adaptor connector	Connects the scanner to the AC adaptor.
13	LAN connector	Connects the scanner to the network.

## 1.2.2 Internal Parts



No.	Part name	Function
1	Pad assy	Help to guide documents from the ADF paper chute to the glass scanner windows.
2	Pick roller	
3	Sheet guide	
4	Glass scanner windows	Place where the documents are scanned.
5	ADF (Automatic Document Feeder)	Drives the documents from the ADF paper chute, past the glass scanner windows, to the output tray.

## 1.3 User Types and Operations

The scanner functions available after login vary in the following ways for different types of user:

- **Administrator**  
Can setup and manage the scanner. The administrator can operate via the scanner's touch panel, or via the network interface by using the Admin Tool, or Central Admin Console installed in a computer. With the Central Admin Console, settings pre-defined on the Central Admin Server can be applied to multiple scanners at a time.
- **Regular User**  
Can scan documents and then send, print, or save the resulting data.

Top Menu Tab /Side Menu Tab	Used to ...	Administrator			Regular User	See ...
		Touch Panel	Admin Tool	Central Admin		
System Settings						
Import Scanner Settings	Import scanner settings	—	—	A	—	<a href="#">page 272</a>
Screen Calibration	Calibrate the touch panel	A	—	—	—	<a href="#">page 56</a>
Scanner Name	Set the scanner name	A	A	—	—	<a href="#">page 59</a>
Language/Key- board Selection	Set the language	A	A	—	—	<a href="#">page 62</a>
Region/Timezone	Set the region/timezone	A	A	A	—	<a href="#">page 63</a>
Date/Time	Set the date/time	A	A	A (*1)	—	<a href="#">page 64</a>
Standby Mode	Set the standby mode and/or automatic logout	A	A	A	—	<a href="#">page 66</a>
Login Settings	Set the login settings	A	A	A	—	<a href="#">page 68</a>
Admin Password	Change the admin password	A	A	—	—	<a href="#">page 71</a>
File Names (Save)	Set the file name format used for when saving scanned data	A	A	A	—	<a href="#">page 72</a>
File Names (e-Mail)	Set the file name format used for when attaching scanned data to e-mails	A	A	A	—	<a href="#">page 76</a>
Multifeed Settings	Set the multifeed detection method	A	A	A	—	<a href="#">page 78</a>
Scanner Adjust- ment	Set the offset and magnifi- cation settings	A	A	—	—	<a href="#">page 81</a>
General Scanner Settings	Set general scanner settings	A	A	A	—	<a href="#">page 83</a>
Certificate Man- agement	Manage certificates	A (*2)	A	A	—	<a href="#">page 84</a>

Top Menu Tab /Side Menu Tab	Used to ...	Administrator			Regular User	See ...
		Touch Panel	Admin Tool	Central Admin		
Network Settings						
IP Address	Set the IP address	A	A	—	—	<a href="#">page 86</a>
Admin Network	Set the admin network	A	A	A (*3)	—	<a href="#">page 88</a>
Central Admin Server	Set the Central Admin Server	A	A	A (*4)	—	<a href="#">page 90</a>
DNS Server	Set the DNS server	A	A	A	—	<a href="#">page 93</a>
WINS Server	Set the WINS server	A	A	A	—	<a href="#">page 95</a>
NTP Server	Set the NTP server	A	A	A (*5)	—	<a href="#">page 96</a>
Proxy Server	Set the proxy server	A	A	A	—	<a href="#">page 98</a>
Login LDAP Server	Set the login LDAP server	A	A	A	—	<a href="#">page 100</a>
e-Mail LDAP Server	Set the e-Mail LDAP server	A	A	A	—	<a href="#">page 108</a>
Customize LDAP Search	Customize the LDAP search parameters	A	A	A	—	<a href="#">page 111</a>
SMTP Server	Set the e-mail server (SMTP server)	A	A	A	—	<a href="#">page 116</a>
Fax Server	Set the fax server	A	A	A	—	<a href="#">page 118</a>
Network Printer	Set the network printers	A	A	A (*6)	—	<a href="#">page 119</a>
Network Folder	Set the network folders	A	A	A (*6)	—	<a href="#">page 132</a>
SharePoint Folder	Set the SharePoint folders	—	A	A (*6)	—	<a href="#">page 145</a>
Alert Notification	Set the destination for alert notifications	A	A	A	—	<a href="#">page 149</a>
Ping	Check the network connec- tion with a Ping test	A	A	—	—	<a href="#">page 150</a>
Network Status	Check the network operat- ing status	A	A	—	—	<a href="#">page 152</a>

Top Menu Tab /Side Menu Tab	Used to ...	Administrator			Regular User	See ...
		Touch Panel	Admin Tool	Central Admin		
<b>Device Status</b>						
System Status	View the system status	A	A	A (*7)	—	<a href="#">page 154</a>
Installed Options	View the installation status of available options	A	A	A (*7)	—	<a href="#">page 155</a>
Usage Status	View the usage status	A	A	A (*7)	—	<a href="#">page 156</a>
Add-in Status	View the Add-in status	A	A	A (*7)	—	<a href="#">page 158</a>
<b>Operation Logs</b>						
User Log	Manage user logs	A (*8)	A	—	—	<a href="#">page 159</a>
System Log	Manage the system log	A (*8)	A	—	—	<a href="#">page 162</a>
<b>Maintenance</b>						
User Data Store	Maintain the user data store	—	A	—	—	<a href="#">page 165</a>
System Settings File	Maintain the system settings	—	A	—	—	<a href="#">page 171</a>
System Update	Update the scanner system software	—	A	A (*9)	—	<a href="#">page 175</a>
Add-in Manager	Install/uninstall an Add-in module	—	A	A (*9)	—	<a href="#">page 177</a>
Technical Support	Set the information output level	A	A	—	—	<a href="#">page 179</a>
	Obtain technical support	—	A	—	—	<a href="#">page 180</a>
<b>Job Mode Settings</b>						
Job Sequences	Set a job sequence	—	A	A	—	<a href="#">page 185</a>
Job Menus	Set a job menu	—	A	A	—	<a href="#">page 203</a>
Job Groups	Set a job group	—	A	A	—	<a href="#">page 210</a>
e-Mail	Send the scanned data by e-mail	—	—	—	A	<a href="#">page 314</a>
Fax	Send the scanned data by fax	—	—	—	A	<a href="#">page 330</a>
Print	Print the scanned data	—	—	—	A	<a href="#">page 339</a>
Save	Save the scanned data to a network folder	—	—	—	A	<a href="#">page 352</a>
Scan to SharePoint	Save the scanned data to a SharePoint folder	—	—	—	A	<a href="#">page 357</a>

Top Menu Tab /Side Menu Tab	Used to ...	Administrator			Regular User	See ...
		Touch Panel	Admin Tool	Central Admin		
Scan Settings	Set the scan options	—	—	—	A	<a href="#">page 365</a>
Scan Viewer	Enable/disable the scan viewer	—	—	—	A	<a href="#">page 402</a>
Maintenance						
Edit e-Mail Addresses	Edit e-mail targets in the e-mail address book	—	—	—	A	<a href="#">page 327</a>
Edit Fax Numbers	Edit contacts in the fax number list	—	—	—	A	<a href="#">page 337</a>
Roller Cleaning	Clean the ADF	—	—	—	A	<a href="#">page 426</a>
Scan Test	Perform a scan test	—	—	—	A	<a href="#">page 445</a>
Consumable Alert	Indicate when parts need replacing	—	—	—	A	<a href="#">page 436</a>
User Log	Check user operations	—	—	—	A	<a href="#">page 410</a>
Job Menu	Process a job	—	—	—	A	<a href="#">page 413</a>

A: available —: not available

- (\*1): The "Date/Time" input field and [Get Time] button cannot be used.
- (\*2): Certificates cannot be imported.
- (\*3): Contents of the SSL Certificate are not shown.
- (\*4): Address or port number cannot be set.
- (\*5): Synchronization not possible.
- (\*6): Printers, folders and SharePoint folders that can be accessed from the Central Admin Server can be set.
- (\*7): Operations cannot be performed from the "Edit Scanner Settings" screen, but can be viewed on the Central Admin Console "Scanner Details" window.
- (\*8): The [Download] button is not displayed.
- (\*9): Operations cannot be performed from the "Edit Scanner Settings" screen, but can be performed from the Central Admin Console "Scanner Admin Operations" window.

---

## 1.4 System Requirements

### 1.4.1 Requirements for Admin Tool

For use of the Admin Tool, the following requirements apply:

#### ■ Software (English Versions)

- Operating System
  - Windows XP SP2 or later
  - Windows Vista
  - Windows 7
  - Windows Server 2003 SP2 or later
  - Windows Server 2008
- .NET Framework 2.0 SP1 or later, or .NET Framework 3.0 SP1 or later (\*1)
- Internet Explorer 6 SP2 or later (\*2)

(\*1): If .NET Framework is not installed, it will be notified. Download .NET Framework from the Microsoft Web site and install it into the computer. When installing .NET Framework, check that there is enough free disk space. For .NET Framework 2.0, at least 280MB of additional free disk space is required.

(\*2): Confirm that the latest security patch has been applied. If the latest patch has not been applied, downloading operations (such as manual download) may not be possible. For Windows XP, "KB933566" must be applied to Internet Explorer.

#### ■ Hardware

- Any computer which runs the supported software
  - 32MB or more of free memory space
  - 64MB or more of free disk space
- XGA monitor or better
- LAN cable
- Pointing device (e.g. mouse)



## 1.4.2 Requirements for Central Admin Console

For use of the Central Admin Console, the following requirements apply:

### ■ Software (English Versions)

- Operating System
  - Windows XP SP2 or later
  - Windows Vista
  - Windows 7
  - Windows Server 2003 SP2 or later
  - Windows Server 2008
- Admin Tool
- .NET Framework 2.0 SP1 or later, or .NET Framework 3.0 SP1 or later (\*1)
- Internet Explorer 6 SP2 or later (\*2)

(\*1): If .NET Framework is not installed, it will be notified. Download .NET Framework from the Microsoft Web site and install it into the computer. When installing .NET Framework, check that there is enough free disk space. For .NET Framework 2.0, at least 280MB of additional free disk space is required.

(\*2): Confirm that the latest security patch has been applied. If not applied, problems with the screen display may arise. MS08-024 (KB947864) and subsequent security update programs are required.

### ■ Hardware

- Any computer which runs the supported software
  - 32MB or more of free memory space
  - 64MB or more of free disk space
- XGA monitor or better
- LAN cable
- Pointing device (e.g. mouse)

---

### 1.4.3 Requirements for Central Admin Server

For use of the Central Admin Server, the following requirements apply:

#### ■ Software (English Versions)

- Operating System
  - Windows 2000 Server SP4 or later
  - Windows Server 2003 SP2 or later
  - Windows Server 2008 (\*1)
- .NET Framework 2.0 SP1 or later, or .NET Framework 3.0 SP1 or later
- Internet Explorer 6 SP2 or later (\*2)
- Internet Information Services 5.0 or later (\*3)
- SQL Server 2005 Express Edition (\*4)

(\*1): To use HTTPS, CAPICOM must be previously installed. If CAPICOM is not installed, the self-signed certificate is not imported for communicating with HTTPS.

(\*2): Confirm that the latest security patch has been applied. If the latest patch has not been applied, downloading operations (such as manual download) may not be possible.

(\*3): A Web server function of Internet Information Services 5.0 or later must be installed.

(\*4): If SQL Server 2005 Express Edition is not already installed, install it at the same time as the Central Admin Sever installation.

For Windows 2000 Server, Microsoft Data Access Components (MDAC) 2.8 SP1 or later, must also be installed.

#### ■ Hardware

- Any computer which runs the supported software
  - Intel Pentium III Processor, 1GHz and above, or equally interchangeable processor
  - 512MB or more of free memory space
  - 700MB or more of free disk space
- XGA monitor or better
- LAN cable

### 1.4.4 Requirements for Related Servers

For related servers, the following requirements apply:

Server	Operating system	Required Function
LDAP Server	Windows 2000 Server	Active Directory
	Windows Server 2003	
	Windows Server 2008	
	Solaris	OpenLDAP
SMTP Server	Windows 2000 Server	SMTP, Exchange
	Windows Server 2003	
	Windows Server 2008	
File Server	Windows 2000 Server	Windows Shared Folder
	Windows Server 2003	
	Windows Server 2008	
SharePoint Server	Windows Server 2003	SharePoint
	Windows Server 2008	
FTP Server	Windows 2000 Server	FTP
	Windows Server 2003	
	Windows Server 2008	
Print Server	Windows 2000 Server	Windows Shared Printer (*1)
	Windows Server 2003	
	Windows Server 2008	
DNS Server	Windows 2000 Server	DNS
	Windows Server 2003	
	Windows Server 2008	
WINS Server	Windows 2000 Server	WINS
	Windows Server 2003	
	Windows Server 2008	
DHCP Server	Windows 2000 Server	DHCP
	Windows Server 2003	
	Windows Server 2008	

---

<b>Server</b>	<b>Operating system</b>	<b>Required Function</b>
NTP Server	Windows 2000 Server	NTP
	Windows Server 2003	
	Windows Server 2008	
	Red Hat Enterprise Linux	
Fax Server	Windows 2000 Server	RightFax
	Windows Server 2003	
	Windows Server 2008	

(\*1): To use as network printer, Windows XP compatible printer driver must be installed.

## ■ LDAP Server

LDAP (Lightweight Directory Access Protocol) is a protocol for accessing a directory databases over a TCP/IP network. It can be used to administrator networked users e-mail addresses and operating environments.

When connected using encryption (SSL), this is called the "LDAPS Server".

The LDAP server can be used to perform the following:

- User authentication at login
- Finding or entering e-mail addresses in an address book

## ■ SMTP Server

SMTP (Simple Mail Transfer Protocol) is a protocol for sending e-mail.

The SMTP server can be used to perform the following:

- Sending the scanned data as an e-mail
- Sending the scanned data by fax

## ■ File Server

The file server shares the disk on a server with other computers on a network, and enables use of the disk from an external computer.

Using this file server enables a scanned image to be saved to a file server network folder.

## ■ SharePoint Server

SharePoint is the collective name for the elements of an Internet Explorer based document management platform provided by Microsoft.

Using a SharePoint server enables scanned images to be saved to a SharePoint folder on the SharePoint server.

## ■ FTP Server

The FTP (File Transfer Protocol) is a protocol for transmitting files.

An FTP server which connects with SSL encryption is called an "FTPS Server".

Using this FTP server enables a scanned image to be saved to an FTP server network folder.

---

## ■ Print Server

The print server is used to print the scanned data. Printers to be used are set on the print server.



- Windows XP compatible printer drivers must be registered.
- Printer must be able to spool print jobs (to hard disk or memory). Contact your printer dealer if uncertain whether your printer has a spool function.
- Printers that allow the status of print errors to be easily checked (via an LCD control panel, or similar) are recommended.



For printing, use only printers connected to the print server.



## ■ DNS Server

A DNS server provides name-resolution which determines IP address corresponding to host name or FQDN.

## ■ WINS Server

The WINS server handles name registration requests from WINS clients, register their names and IP addresses, and responds to NetBIOS name queries submitted by clients, returning the IP address of a queried name if it is listed in the server database.

In addition, when a DNS name resolution fails, the query can be transferred to the WINS server.

## ■ DHCP Server

The DHCP server automatically assigns an IP address for this scanner and other client computers.

## ■ NTP Server

The NTP server is used when a client makes a time query through network.

## ■ Fax Server

The fax server is used for sending faxes.

This scanner supports the following fax servers:

- RightFax Business Server (Version 9.3)

This fax server can be used to send the scanned data by fax.



## 1.4.5 Network Requirements

This section describes the required network conditions for Central Admin.

For Central Admin, the following network conditions are required.

- HTTP/HTTPS communication is possible from the Central Admin Server to the scanner
- HTTP/HTTPS communication is possible from the scanner to the Central Admin Server
- HTTP/HTTPS communication is possible from the Central Admin Console to the Central Admin Server.
- Wake-On-LAN Magic Packet routing is possible from the Central Admin Server to the scanner (when Wake-On-LAN is used)



The connection between a scanner and Central Admin Server has the following limitations.

- Communication via an HTTP proxy is not supported.
- Networks where IP addresses using NAT/NAPT are not supported.



## 1.4.6 Scanner Requirements for iScanner Central Admin

Up to 1,000 scanners can be managed with iScanner Central Admin. If 1,000 scanners are registered on the server, no more scanners can be registered as targets for central admin. If the number of scanners exceeds 1,000, multiple Central Admin Servers will be prepared. The target scanners for each server should not exceed 1,000.

## 1.4.7 Port Number List

Function	From/To	Port Number	Protocol Number
Admin Tool Connection	Admin Tool ⇌ Scanner	80 (HTTP) (*1)	6 (TCP)
		443 (HTTPS) (*1)	6 (TCP)
Central Admin Server Connection	Central Admin Server ⇌ Scanner	80 (HTTP) (*1)	6 (TCP)
		443 (HTTPS) (*1)	6 (TCP)
	Scanner ⇌ Central Admin Server	20444 (HTTP/HTTPS) (*1)	6 (TCP)
	Central Admin Console ⇌ Central Admin Server	10444 (HTTP/HTTPS) (*1)	6 (TCP)
	Central Admin Server ⇌ LDAP server	389 (LDAP)	6 (TCP)
		636 (LDAPS)	6 (TCP)
		3268 (Active Directory Global Catalog)	6 (TCP)
		3269 (Active Directory Global Catalog over SSL)	6 (TCP)
	Central Admin Server ⇌ Print server	137,138,139,445 (SMB)	6 (TCP) 17 (UDP)
	Central Admin Server ⇌ File server	137,138,139,445 (SMB)	6 (TCP) 17 (UDP)
	Central Admin Server ⇌ FTP server	20,21 (FTP) (*1)	6 (TCP)
	Central Admin Server ⇌ FTPS server	989,990 (FTPS) (*1)	6 (TCP)
	Central Admin Server ⇌ SMTP server	25 (SMTP) (*1)	6 (TCP)
	Central Admin Server ⇌ Proxy server	Free	6 (TCP)
Central Admin Server SharePoint link	30444 (HTTP/HTTPS) (*1)	6 (TCP)	
DHCP Server	Scanner ⇌ DHCP server	67 (DHCP)	17 (UDP)
DNS Server	Scanner ⇌ DNS server	53 (DNS)	17 (UDP)
WINS Server	Scanner ⇌ WINS server	1512 (WINS)	17 (UDP)



Function	From/To	Port Number	Protocol Number
Synchronization	Scanner ⇔ SNTP server	123 (SNTP)	17 (UDP)
Proxy Server	Scanner ⇔ Proxy server	Free	6 (TCP)
Authentication/e-Mail Address Search	Scanner ⇔ LDAP server	389 (LDAP) (*1)	6 (TCP)
		636 (LDAPS) (*1)	6 (TCP)
		3268 (Active Directory Global Catalog) (*1)	6 (TCP)
		3269 (Active Directory Global Catalog over SSL) (*1)	6 (TCP)
Sending e-Mail	Scanner ⇔ SMTP server	25 (SMTP) (*1)	6 (TCP)
Sending Fax	Scanner ⇔ SMTP server	25 (SMTP) (*1)	6 (TCP)
Print	Scanner ⇔ Print server	137,138,139,445 (SMB)	6 (TCP) 17 (UDP)
SharePoint Server	Scanner ⇔ SharePoint server	80 (HTTP) (*1)	6 (TCP)
		443 (HTTPS) (*1)	6 (TCP)
FTP Server	Scanner ⇔ FTP server	20,21 (FTP) (*1)	6 (TCP)
FTPS Server	Scanner ⇔ FTPS server	989,990 (FTPS) (*1)	6 (TCP)
Saving to a Folder	Scanner ⇔ File server	137,138,139,445 (SMB)	6 (TCP) 17 (UDP)
Ping	Scanner ⇔ Another computer or server	—	1 (ICMP)

(\*1): Changing the Port Number is possible



# Chapter 2

## Basic Scanner Operations

Admin

User

2

2.1 Turning the Power On/Off .....	24
2.2 Using the Scanner Buttons .....	26
2.3 Using the LCD Touch Panel .....	28
2.4 Using the Keyboard .....	29

---

## 2.1 Turning the Power On/Off


### ■ Turning the Power On



Do not move or shake the scanner when it is turned on.  
This can damage the rotating hard disk drive and cause data to be lost.



1. Press the startup button.



⇒ After the system starts up, the "Login" screen appears.



After turning the power off, wait for at least 10 seconds before turning the power back on again.






## 2.2 Using the Scanner Buttons

### 2.2.1 Using the Startup Button

When the scanner is off or in standby mode, pressing the startup button will start the scanner up and display the login screen.



\* Other than pressing the startup button, any of the following operations will startup the scanner from standby mode.

- Loading the document in the ADF paper chute.
- Closing the top cover.
- Pressing a keyboard key.

The screen displayed after a re-startup varies according automatic login settings in the following way:

- If automatic login is enabled, the operation screen is displayed.  
However, if "Never" is specified for "Standby after", and automatic login is disabled for the currently logged in user, the login screen is displayed.
- If automatic login is disabled, the login screen is displayed.

The idle time before standby mode entered can be changed. For details, refer to ["4.6.6 Setting the Time to Standby Mode"](#) (page 66).




When the scanner is starting up or in standby mode, be careful to never hold the startup button down for 4 seconds, as this will cause the scanner to shutdown. If this happens, saved scanned data may become unusable. If the startup button is accidentally held down too long, causing the scanner to shutdown, temporarily detach the AC adaptor to ensure that the power is completely off. After turning the power off, wait for at least 10 seconds before turning the power back on again. To shutdown the scanner correctly, press the [Shut-down] button on the "Login" screen.



Automatic login without displaying the "Login" screen is possible. For more details about how to set automatic login, refer to ["4.6.7 Setting the Login Method"](#) (page 68).



### 2.2.2 Using the Top Cover [SCAN] Button

When the  icon is displayed in a [Scan] button on the touch panel, either the touch panel [Scan] button or top cover [SCAN] button may be pressed to start the scan.



The touch panel [Scan] button may appear as follows:

- [Scan]
- [Scan & Send]
- [Scan & Print]
- [Scan & Save]
- [Scan More]

---

## 2.3 Using the LCD Touch Panel

When using the LCD touch panel, buttons only need to be lightly pressed to select them. For details how to operate the touch panel, refer to "[4.1 Administrator Screens via the Touch Panel](#)" (page 38) or "[6.2 Using Touch Panel Screens: Regular User](#)" (page 304).



- Do not use a pen or other hard object on the LCD touch panel. The LCD touch panel may be damaged.
- If the screen is dirty, this may cause the LCD touch panel to malfunction. Clean the screen if it is visibly dirty. For details, refer to "[7.3 Cleaning the LCD Touch Panel](#)" (page 433).



## 2.4 Using the Keyboard

Selecting buttons or entering text can also be done on the keyboard.  
The keyboard can be used in the following ways:

### 2.4.1 Using the Keyboard: Administrator

Key	Used to ...
Tab	Switch focus to the next field or button.
Space	Select the button in focus. However, this cannot be used for the [Download], [Get CSV], and [Backup] buttons.
Enter	Set the contents of the current screen. (Used instead of the [OK] button or [Login] button.)
↑↓	Change the value of the numerical input for the field in focus.
Page Up Page Down	Scroll up or down the contents on the screen. (Used instead of the scroll buttons.)



The keyboard cannot be used to select a top or left side menu button.  
Select buttons in the top menu by pressing the touch panel, or by using the mouse via the network interface.

---

## 2.4.2 Using the Keyboard: Regular Users

Key	Used to ...
Tab	Switch focus to the next field or button.
Space	Select the button in focus.
Enter	Set the contents of the current screen. (Used instead of the [OK] button or [Login] button.) (On Search screens, may be used instead of the [Find] button.)
Esc	Return to the previous screen. (On the "Main Menu" screen, may be used instead of the [Logout] button.)
Alt+F4	Shutdown the scanner. (Used instead of the [Shutdown] button on the "Login" screen.)
↑↓	Scroll up or down between items.
Page Up Page Down	Scroll up or down the page on the screen.

# Chapter 3

---

## Administrator Operations (Overview)

Admin User




<b>3.1 Operating and Managing Scanners</b> .....	<b>32</b>
<b>3.2 Required Scanner Function Settings</b> .....	<b>33</b>

## 3.1 Operating and Managing Scanners

Scanner settings management can be implemented in the following ways.

- **LCD Touch Panel**  
Scanner settings management can be implemented directly via the scanner's touch panel.
- **Admin Tool**  
Scanner settings management, and updates can be implemented via the network interface by using the Admin Tool installed on a computer. Settings can be performed for one scanner at a time.
- **Central Admin Console**  
Scanner settings management, and updates can be implemented via the network interface by using the Central Admin Console installed on a computer. Settings can be performed for multiple scanners at a time. In this case, settings made with the Central Admin Console are applied to scanners via a Central Admin Server.



## 3.2 Required Scanner Function Settings

Which scanner settings are required differs according to scanner functions to be used. The function buttons are displayed on the "Main Menu" screen, in accordance with the specified settings.



Top Menu						
Left Side Menu	e-Mail	Fax	Print	Save	Scan to Share Point	See ...
System Settings						
Import Scanner Settings	—	—	—	—	—	<a href="#">page 272</a>
Screen Calibration	—	—	—	—	—	<a href="#">page 56</a>
Scanner Name	<b>N</b>	<b>N</b>	<b>N</b>	<b>N</b>	<b>N</b>	<a href="#">page 59</a>
Language/Keyboard Selection	—	—	—	—	—	<a href="#">page 62</a>
Region/Timezone	A	A	A	A	A	<a href="#">page 63</a>
Date/Time	A	A	A	A	A	<a href="#">page 64</a>
Standby Mode	—	—	—	—	—	<a href="#">page 66</a>
Login Settings	—	—	—	—	—	<a href="#">page 68</a>
Admin Password	A	A	A	A	A	<a href="#">page 71</a>
File Names (Save)	—	—	—	A	A	<a href="#">page 72</a>
File Names (e-Mail)	A	—	—	—	—	<a href="#">page 76</a>
Multifeed Settings	—	—	—	—	—	<a href="#">page 78</a>
Scanner Adjustment	—	—	—	—	—	<a href="#">page 81</a>
General Scanner Settings	—	—	—	—	—	<a href="#">page 83</a>
Certificate Management	—	—	—	—	—	<a href="#">page 84</a>

Top Menu						
Left Side Menu	e-Mail	Fax	Print	Save	Scan to Share Point	See ...
Network Settings						
IP Address	N	N	N	N	N	<a href="#">page 86</a>
Admin Network	—	—	—	—	—	<a href="#">page 88</a>
Central Admin Server	—	—	—	—	—	<a href="#">page 90</a>
DNS Server	A	A	A	A	A	<a href="#">page 93</a>
WINS Server	A	A	A	A	A	<a href="#">page 95</a>
NTP Server	A	A	A	A	A	<a href="#">page 96</a>
Proxy Server	—	—	—	—	—	<a href="#">page 98</a>
Login LDAP Server	A (*1)	A (*1)	A (*1)	A (*1)	A (*1)	<a href="#">page 100</a>
e-Mail LDAP Server	—	—	—	—	—	<a href="#">page 108</a>
Customize LDAP Search	—	—	—	—	—	<a href="#">page 111</a>
SMTP Server	N	N	—	—	—	<a href="#">page 116</a>
Fax Server	—	N	—	—	—	<a href="#">page 118</a>
Network Printer	—	—	N	—	—	<a href="#">page 119</a>
Network Folder	—	—	—	N	—	<a href="#">page 132</a>
SharePoint Folder	—	—	—	—	N	<a href="#">page 145</a>
Alert Notification	A	A	A	A	A	<a href="#">page 149</a>
Ping	—	—	—	—	—	<a href="#">page 150</a>
Network Status	—	—	—	—	—	<a href="#">page 152</a>

N: Necessary A: Advisable —: Not required

(\*1): Only necessary if connecting to an LDAP server.








# Chapter 4

## Administrator Operations (Touch Panel and Admin Tool)

This chapter provides an explanation of administrator operations (setting up and managing the scanner) via the scanner's touch panel, or via the network interface using the Admin Tool. The same operations may also be performed via the Central Admin Console "Edit Scanner Settings" and "Job Mode Settings" screens. For more details about the Central Admin Console screens, refer to ["Chapter 5 Administrator Operations \(Central Admin Console\)" \(page 223\)](#). Messages may appear while performing operations described in this chapter. For more details about these messages and actions to take, refer to ["E.1.2 System Log Messages" \(page 516\)](#).


Symbols used in this chapter:






-  : Administrator operating via the touch panel.
-  : Administrator operating via the network interface using the Admin Tool.
-  : Administrator operating via the network interface using the Central Admin Console.




<b>4.1 Administrator Screens via the Touch Panel.....</b>	<b>38</b>
<b>4.2 Administrator Screens via the Admin Tool .....</b>	<b>40</b>
<b>4.3 iScanner Administrator Login: via the Touch Panel.....</b>	<b>42</b>
<b>4.4 Setting up for Administrator Access via the Admin Tool .....</b>	<b>44</b>
<b>4.5 iScanner Administrator Login: via the Admin Tool .....</b>	<b>53</b>
<b>4.6 Using the System Settings Menus .....</b>	<b>56</b>
<b>4.7 Using the Network Settings Menus .....</b>	<b>86</b>
<b>4.8 Using the Device Status Menus.....</b>	<b>154</b>
<b>4.9 Using the Operation Logs Menus.....</b>	<b>159</b>
<b>4.10 Using the Maintenance Menus.....</b>	<b>165</b>
<b>4.11 Setting Job Features.....</b>	<b>181</b>

## 4.1 Administrator Screens via the Touch Panel

On the touch panel screens (administrator), when one of the top menu tabs is selected, the related function tabs are displayed on the left side menu.



Actual icon	Shown in manual as...	Used to ...
	[Left] button, [Right] button	Switch between top menu tabs (scrolling the top menu as necessary).
	[Up] button, [Down] button	Switch between side menu tabs (scrolling the left side menu as necessary).
	[List] button	Display a list of possible selections.
	[Logout] button	Log the current user out.
	[OK] button	Accept any changes to the current screen settings.


Actual icon	Shown in manual as...	Used to ...
	[Cancel] button	Abandon any input to the current screen, and keep present settings and/or return to the previous screen.
	[On] button	If the button color is yellow, it means that the button is selected.
	[Off] button	If the button color is blue, it means that the button is not selected.

## 4.2 Administrator Screens via the Admin Tool

When using the Admin Tool to access the scanner via its network interface, pressing one of the function buttons at the top of the Admin Tool window causes the related function screen to be displayed in the window.


- When the [Scanner Settings] button is pressed









On the Admin Tool scanner settings screens, when one of the top menu tabs is selected, the related function tabs are displayed on the left side menu.



- When the [Job Menu Settings] button is pressed

On the Admin Tool job mode settings screens, when one of the Job Settings Menu tabs is selected, the associated settings screen is displayed.



Function button	Shown in manual as...	Used to ...
 Exit	[Exit] button	Close the Admin Tool.
 Disconnect	[Disconnect] button	Disconnect the connection to a scanner.
 Scanner Settings	[Scanner Settings] button	Access the scanner settings top menu.
 Job Menu Settings	[Job Menu Settings] button	Access the job menu settings window.
 Download Manual	[Download Manual] button	Download the manual.
 About...	[About] button	Show the version of the Admin Tool installed.
 OK	[OK] button	Accept any changes to the current screen settings.
 Cancel	[Cancel] button	Abandon any input to the current screen, and keep present settings and/or return to the previous screen.

---

## 4.3 iScanner Administrator Login: via the Touch Panel



- If the normal screen display does not appear (for example: an "X" mark appears), wait for a few minutes and try again. If the problem still occurs, contact your FUJITSU scanner dealer or an authorized FUJITSU scanner service provider.
- If a button is rapidly pressed many times in succession, a "The page cannot be displayed" message may appear. Selecting another tab or reloading the page will refresh the screen.



- The user name and initial password for the administrator are as follows:  
User Name: admin  
Password: password
- The scanner setup can be configured by one user.
- Session timeout time is 20 minutes (fixed). The session timeout time is extended by a further 20 minutes for the following:
  - when a tab on the top menu or left side menu is pressed
  - when the [OK] button is pressed



1. Enter a "User Name" and "Password".

Enter "admin" for the user name.

Passwords must be between 7 and 127 characters long.

Alphanumeric characters (case sensitive) and symbols may be entered.



- The "Caps Lock" indicator is on if the keyboard's Caps Lock is set.
- The "Num Lock" indicator is on if the keyboard's Num Lock is set.
- If "Global Catalog" is selected for the login LDAP server, the "UPN Suffix" input field is displayed.

A UPN suffix is not required when logging in as an administrator. Even if entered, it will be ignored.

2. Press the [Login] button.

⇒ If the user name and password are valid, the "System Settings" screen appears.

## 4.4 Setting up for Administrator Access via the Admin Tool

This section describes the required settings for logging in via the Admin Tool.




The following are required for administrator login via the Admin Tool:

- ["4.6.2 Setting the Scanner Name" \(page 59\)](#)
- ["4.6.8 Changing the Admin Password" \(page 71\)](#)
- ["4.7.1 Giving the Scanner an IP Address" \(page 86\)](#)
- ["4.7.2 Setting the Admin Network" \(page 88\)](#)
- ["4.7.4 Setting the DNS Server" \(page 93\)](#)
- ["4.7.5 Setting the WINS Server" \(page 95\)](#)

### 4.4.1 Checking the Internet Explorer Cache Settings

Check the Internet Explorer cache settings.

1. From the Internet Explorer [Tools] menu, select [Internet Options].  
⇒ The "Internet Options" dialog box appears.
2. On the [General] tab, press the [Settings] button on the "Browsing history".  
⇒ The "Temporary Internet Files and History Settings" dialog box appears.



3. For "Check for newer versions of stored pages", select "Automatically".
4. For "Disk space to use", specify 63MB or above.





- 
4. Enter the URL of the scanner in the "Add this website to the zone" field, and press the [Add] button.

Example: `http://IP_address or scanner_name/`



Different browser versions may require a different set up procedure.



If any updates or service packs are available for Internet Explorer, make sure they are applied.



### 4.4.3 Installing the Admin Tool

To setup the scanner via the network interface, install the Admin Tool to your computer.

1. According to the settings described in ["4.7.2 Setting the Admin Network" \(page 88\)](#), specify the URL in the following way.

- SSL is [Off], no port number change  
http://scanner\_name or IP\_address/
- SSL is [Off], port number change  
http://scanner\_name or IP\_address:port\_number/  
For port\_number, enter the changed port number.
- SSL is [On], no port number change  
https:// scanner\_name or IP\_address/
- SSL is [On], port number change  
https://scanner\_name or IP\_address:port\_number/  
For port\_number, enter the changed port number.

For SSL, the "Security Alert" window is displayed when connecting.

Press the [Yes] button on the "Security Alert" window.


⇒ The login screen appears.

2. Enter a "User Name" and "Password".

Enter "admin" for the user name.

Passwords must be between 7 and 127 characters long.

Alphanumeric characters (case sensitive) and symbols may be entered.




The screenshot shows a login interface with a blue background and a globe graphic. At the top right, there are two buttons: "Getting Started" and "Operator's Guide". Below these, there are two input fields: "User Name" and "Password". The "User Name" field contains the text "admin". The "Password" field is masked with dots. At the bottom right, there is a "Login" button.

3. Press the [Login] button.


⇒ The download screen appears.

4. Press the [Next] button for the fi Network Scanner Admin Tool download.



⇒ The fi Network Scanner Admin Tool download screen appears.

5. Press the [Download] button.




Downloading is not possible while an administrator or user operation is being processed.



⇒ The "File Download - Security Warning" dialog box appears.

6. Press the [Run] button.



⇒ The fi Network Scanner Admin Tool Setup Wizard appears.




Do not close the Web browser or logout until installation is complete.



If .NET Framework is not installed, the Microsoft Website is accessed when installing the Admin Tool.  
After installing .NET Framework, try again from [Step 1](#).



7. Press the [Next] button.



⇒ The "Select Installation Folder" window appears.

---


8. Specify an installation folder for the Admin Tool.

To select a different folder, press the [Browse] button.


To check the free space available for the currently selected folder, press the [Disk Cost] button.



Installation will fail if the length of any installation path (folder path plus installation file name) exceeds 259 characters. Select an installation folder that respects this limit.



9. Select the target user(s), and press the [Next] button.



- ⇒ Follow the prompts of the install wizard windows until a "fi Network Scanner Admin Tool has been successfully installed" message indicates that the installation has completed. Press the [Close] button.
- ⇒ When the installation is completed, logout of the scanner, and close the Web browser.
- ⇒ The Admin Tool should now be usable.  
Select the [Start] button, select the [All Programs] - [fi-scanner V2] sub-menu, and then select on the [fi Network Scanner Admin Tool].



- If this tool has already been installed, skip to section "4.5 iScanner Administrator Login: via the Admin Tool" (page 53) for details about Admin Tool operations.
- From the Web browser [Tools] menu, select [Internet Options], and note the following points about the settings shown on the "Internet Options" dialog box.
  - In the [Accessibility] dialog box shown when selecting the [Accessibility] button on the [General] tab, do not change the formatting and user style sheet settings. If these settings are changed, the displayed style of the Admin Tool may be corrupted.
  - In the "Language Preference" dialog box shown when selecting the [Languages] button on the [General] tab, move the same language as for the Central Admin Server operation system to the top. If a different language is specified, a problem may occur with the input or displays for the Admin Tool.
  - On the [Security] tab, if "Security level for this zone" is set to "High", part of the Admin Tool screen may not be correctly displayed. In this case, on the [Security] tab, add the scanner or Central Admin Server to the trusted site zone and select the [Default Level] button. Or select the [Custom Level] button and set [Binary and script behaviors] to "Enable".
- When the font size is large, part of the dialog box may not be shown correctly. In this case, use a smaller font size.

#### 4.4.4 Uninstalling the Admin Tool

This description uses Windows Vista as an example.

Uninstall the Admin Tool from [Control Panel] - [Programs] - [Programs and Features] in the computer in which it is installed.



Close the Admin Tool before uninstalling. If the Admin Tool is uninstalled while still open, normal operation of the open Admin Tool is not guaranteed.



## 4.5 iScanner Administrator Login: via the Admin Tool



The Admin Tool can be set up to manage the scanner via a computer. This section explains how to login using the Admin Tool.




- If the normal screen display does not appear (for example: an "X" mark appears), wait for a few minutes and try again. If the problem still occurs, contact your FUJITSU scanner dealer or an authorized FUJITSU scanner service provider.
- If a button is rapidly pressed many times in succession, a "The page cannot be displayed" message may appear. Selecting another tab or reloading the page will refresh the screen.



- For details about setting up to manage the scanner via a computer, refer to ["1.4.1 Requirements for Admin Tool" \(page 12\)](#).
- The user name and initial password for the administrator are as follows:  
User Name: admin  
Password: password
- The scanner setup can be configured by one user.
- Session timeout time is 20 minutes (fixed). The session timeout time is extended by a further 20 minutes for the following:
  - when a tab on the top menu or left side menu is pressed
  - when the [OK] button is pressed



1. From the [Start] menu, point to [All Programs]-[fi-scanner V2], and then select [fi Network Scanner Admin Tool].
  - ⇒ The Admin Tool is started.
2. Specify the "Connect to" (of the scanner).
  - Enter the IP address, scanner name, or FQDN for the scanner to be setup or managed.



- If the port number was changed in ["4.7.2 Setting the Admin Network" \(page 88\)](#), enter the port number changed for Port Number.
- When trying to connect with a port number other than the specified number, it will take up to 20 seconds before a connection error occurs.
- To use SSL, select the [Use HTTPS] checkbox.
- If the Admin Tool is started while there is insufficient free memory, a script error may occur. Try again after ensuring that there is enough free memory.


3. Press the [Connect] button.
  - ⇒ The login screen appears.

4. Enter a "User Name" and "Password".

Enter "admin" for the user name.

Passwords must be between 7 and 127 characters long.

Alphanumeric characters (case sensitive) and symbols may be entered.



5. Press the [Login] button.

⇒ If the user name and password are valid, the "System Settings" screen appears.


---

## 4.6 Using the System Settings Menus

### 4.6.1 Calibrating the Touch Panel Touch Panel

This should be done when the touch panel responses seem out of alignment with the positions of objects on the LCD screen.


1. Select the [System Settings] tab on the top menu.
2. Select the [Screen Calibration] tab on the left side menu.  
⇒ The "Screen Calibration" screen appears.
3. Press the [Calibrate Screen] button.




⇒ A blank calibration screen appears, with a red "+" (adjustment mark) in the top-left corner.

4. Touch the "+" with your fingertip.

After being touched, the "+" will move to the next calibration position. Each time it stops, touch it again.




**HINT** 

The keyboard may also be used on the calibration screen:

- Press the [Home] key to jump straight to the post-calibration test screen.
- Use the [←] [↑][↓][→] to move the "+" to a different calibration point. This allows a bad touch to be redone.
- Press the [Esc] key to stop the calibration process and return to the "Screen Calibration" screen.
- Press the [Enter] key to close the error dialog. (Not normally needed.)

Repeat until the test screen appears, with the following "Calibration" dialog box:



---

5. Trace a line on the screen with your fingertip.

⇒ A corresponding line will appear on-screen.

If the line does not appear correctly, press the [Calib screen] button to return to [Step 4](#).  
If the screen becomes cluttered, press the [CLR screen] button to remove all the lines.  
The [Cursor on/off] button cannot be used.

6. When you are satisfied with the touch screen response, press the [Update] button.

⇒ This saves the current calibration data, completing the calibration process, and returns you to the "Screen Calibration" screen.



If the calibration is not performed carefully, or the [Enter] key is pressed before all the calibration points have been touched, the following error message may appear:

Parameter Error. Please input, again  
Press the [Enter] key to dismiss the error dialog, and perform the calibration from [Step 4](#) again, being careful to touch each calibration point accurately.





- 
4. Specify the scanner as a workgroup or domain member.
    - For a workgroup  
Press the [Workgroup] button, and enter a workgroup name.  
Workgroup names may be up to 15 characters long.  
The default name is "WORKGROUP".
    - For a domain  
Press the [Domain] button and enter a domain name.  
Domain names may be up to 155 characters long.

5. Press the [OK] button.

⇒ The restart confirmation screen appears.



In the following case, the authentication screen appears.

- When specifying the scanner as a domain member
- When changing the name of a scanner that is a member of a domain

1. Enter a user name.  
User names may be up to 256 characters long. Check the required authentication information when adding to a domain, and enter a user name which can be added to the domain.
2. Enter a password.  
Passwords may be up to 256 characters long (case sensitive).
3. Press the [OK] button.  
If the user name and password are valid, the restart confirmation screen appears.



## 6. Press the [Now] button.


⇒ The system is restarted.



- If the new scanner name is the same as another device name already in use on the network, communication problems will occur. In this case, try the following steps:
  1. Disconnect the LAN cable, and press the [Shutdown] button on the touch panel to turn the scanner off.
  2. Reboot the scanner with the LAN cable disconnected, and enter a non-duplicate scanner name.
  3. Reboot the scanner again.
  4. Re-connect the LAN cable to the scanner.
- The connection will be lost if the scanner name is changed via the network interface. To continue with other settings, wait a short time for the device to restart, then login to the network interface again.

### 4.6.3 Setting the Language Touch Panel Admin Tool

1. Select the [System Settings] tab on the top menu.
2. Select the [Language/Keyboard Selection] tab on the left side menu.
  - ⇒ The "Language/Keyboard Selection" screen appears.




You can select whether or not to display this screen again at the next scanner startup. To display the screen again, for "Show the "Language/Keyboard Selection" screen at next start up?", press the [Yes] button. To not display this screen at next start up, press the [No] button.

3. Press the [List] button for the "Language" input field.
  - ⇒ A list of languages appears.
4. Select a language.
  - Select the desired language for the operating environment.
  - ⇒ This returns to the "Language/Keyboard Selection" screen.
5. Press the [OK] button.
  - ⇒ A language setting confirmation message appears in the selected language.
6. Press the [OK] button.
  - ⇒ The system is restarted.

#### 4.6.4 Setting the Region/Timezone Touch Panel Admin Tool Central Admin

1. Select the [System Settings] tab on the top menu.
2. Select the [Region/Timezone] tab on the left side menu.
  - ⇒ The "Region/Timezone" screen appears.



3. Press the [List] button for the "Timezone" input field.
  - The default timezone is "(GMT+09:00) Osaka, Sapporo, Tokyo".
  - ⇒ A list of timezones appears.
4. Select a timezone.
5. Select whether "Daylight Savings Time" should be on or off.
  - This option is not shown for timezones where daylight savings time is not used.
6. Press the [OK] button.
  - ⇒ The Region/Timezone is set.


## 4.6.5 Setting the Date/Time

Touch Panel

Admin Tool

Central Admin

1. Select the [System Settings] tab on the top menu.
2. Select the [Date/Time] tab on the left side menu.
  - ⇒ The "Date/Time" screen appears, with the date/time of the screen display shown in [Date/Time].



For Central Admin Console, the "Date/Time" input field and [Get Time] button cannot be used.

3. Press the Date Format [List] button.
  - ⇒ A date format list appears.
4. Select a date format.

This date format is applied to the date/time when it is used to name scan data files and the date shown on screens.
5. Enter the current date and time in the "Date/Time" input field.

The date and time shown are those current for when the "Date/Time" tab on the left side menu was selected.

The date/time range that may be entered is from "April 1st 2008, 00:00:00" to "December 31st 2037, 23:59:59".

When entering a one digit number for date and time, such as for January, prepend "0" and enter "01" in the input field.

## 6. Press the [OK] button.

⇒ The date and time are set.



- Pressing the [Get Time] button refreshes the current value of the internal system date/time.
- An adjustment that advances the system time by 20 minutes or more results in a session timeout and causes the scanner to logout. However, the specified time adjustment will be made.

---

## 4.6.6 Setting the Time to Standby Mode


Touch  
Panel

Admin  
Tool

Central  
Admin

The scanner can be set to automatically log out and then enter a standby state after specified periods of non-use.

For any screen after regular user login, if no operations have been performed for the specified "Logout after" period of time, the scanner automatically logs the user out.



The scanner will not logout while the following operations are ongoing:

- Scanning documents
- e-Mailing a scan
- Faxing a scan
- Printing a scan
- Saving a scan

When logged in as a regular user, if no operations are performed for the specified "Standby after" period of time, the scanner enters standby mode. The touch panel is switched off when the scanner enters standby mode.

When the startup button is pressed, the scanners will startup from standby mode.


The screen displayed after a re-startup varies according automatic login settings in the following way:

- If automatic login is enabled, the operation screen is displayed.  
However, if "Never" is specified for "Standby after", and automatic login is disabled for the currently logged in user, the login screen is displayed.
- If automatic login is disabled, the login screen is displayed.

For screen transmissions, refer to ["2.2.1 Using the Startup Button" \(page 26\)](#).

1. Select the [System Settings] tab on the top menu.
2. Select the [Standby Mode] tab on the left side menu.

⇒ The "Standby Mode" screen appears.



3. Press the [List] button for the "Logout after" input field.

⇒ A list of "Logout after" times appears.

4. Select the desired time before automatic log out.  
The default time is "5min".

5. Press the [List] button for the "Standby after" input field.

⇒ A list of "Standby after" times appears.

6. Select the desired time before standby mode.  
The default time is "15min".



If the [Never] button is selected for "Logout after", the selected time for "Standby after" is used as the wait time before switching to standby mode.

If a button other than [Never] is selected, set a "Standby after" time that is longer than the "Logout after" time.



7. Press the [OK] button.

⇒ The scanner is set to first standby and then automatically log out after the specified times.

## 4.6.7 Setting the Login Method

Touch Panel

Admin Tool

Central Admin

The login settings are as follows.

- Automatic login settings  
Set the scanner to automatically login without displaying the "Login" screen, when the scanner power is switched on or restarted.  
For automatic login, the user name and password specified in the "Login Settings" screen is used. However, if the scanner automatically logs out, or the [Logout] button is pressed, the "Login" screen is displayed.
- guest account validity  
Set whether or not to enable login with the guest account.

1. Select the [System Settings] tab on the top menu.
2. Select the [Login Settings] tab on the left side menu.  
⇒ The "Login Settings" screen appears.

The screenshot displays the 'Login Settings' screen within a software interface. At the top, there are four tabs: 'System Settings' (selected), 'Network Settings', 'Device Status', and 'Operation Logs'. On the left side, there is a vertical menu with options: 'Date / Time', 'Standby Mode', 'Login Settings' (selected), 'Admin Password', and a scroll indicator. The main content area is titled 'Enter the user login settings.' and contains the following elements:

- 'Auto Login' with two buttons: 'On' (blue) and 'Off' (yellow).
- 'User Name' and 'Password' input fields.
- 'Num Lock' and 'Caps Lock' toggle buttons (both currently off).
- 'Guest Account' with two buttons: 'On' (yellow) and 'Off' (blue).

At the bottom of the screen, there are three buttons: 'Logout' (with a document icon), 'Cancel' (with a red 'X' icon), and 'OK' (with a green play icon).

3. Select whether or not to enable automatic login.  
The default setting is [Off].  
Select the [On] button to enable automatic login.  
Select the [Off] button to disable automatic login.





- The automatic login setting is applied after the scanner is restarted or resumed from standby mode.
- If Central Admin is enabled in a scanner for which automatic login is enabled, when the scanner is started or resumed from standby mode, preference is given to checking for available scanner settings, add-in installs and system settings in the Central Admin Server, over automatic login. If scanner settings, add-in installs or system settings are available, they are applied to the scanner. However, if the number of scanners connecting to the Central Admin Server exceeds the maximum number possible, the processes is skipped, and automatic login is performed. Updates will be applied when a scanner is logged out, or when next started or resumed from standby mode.




4. Enter a user name and password.

User name and password can only be set if the [On] button was selected in [Step 3](#).

Field Name	Description
User Name	User names may be up to 64 characters long. All alphanumerics (case sensitive) and some symbols are allowed. User names may not start with a "@" or ".". The following symbols cannot be used: /\ [ ] : ;   = , + * ? < > "
Password	Passwords may be up to 256 characters long, and all alphanumerics (case sensitive) and symbols are allowed.



 Even if the system environment allows the use of other characters in an LDAP password, only those specified above may be used in an automatic login password.

The scanner follows the Active Directory user name format when authenticating the user login.

- When the "Server Type" of the LDAP server is "Active Directory" or "Active Directory Global Catalog"

User Name Format	Authentication Process
SAM Account Name Does not contain a "@"	Authenticate the user login name (sAMAccountName). Example: user
User Principal Name Contains a "@"	Authenticate the user login name (userPrincipalName). Example: user@example.com





## 4.6.9 Setting a File Name Format for When Saving Scanned Data



Set a file name format when saving scanned data in a folder.

The "Save as" entered on the "Save" or "Scan to SharePoint" screen is displayed as the default value for this setting.



The following file names cannot be used:

- CON
- PRN
- AUX
- CLOCK\$
- NUL
- COM0 to COM9
- LPT0 to LPT9



1. Select the [System Settings] tab on the top menu.
2. Select the [File Names (Save)] tab on the left side menu.

⇒ The "File Names (Save)" screen appears.

3. If desired, set a sub-folder in which to save the scanned data.
  - If none of the Sub-Folder buttons is selected, the scanned data will be saved in the designated network or SharePoint folder.
  - If a Sub-Folder button is selected, the scanned data will be saved in a sub-folder of the network folder or SharePoint folder, with this sub-folder being created if it does not already exist.
    - If the [Scanner Name] button is selected  
The sub-folder will be named after the scanner used for the scan.
    - If the [User Name] button is selected  
The sub-folder will be named after the user who is logged in when the scan is performed.
    - If the [Date] button is selected  
The sub-folder will be named after the date of the scan, using the naming format selected in the Date Format list.



If multiple buttons are selected, folder names are created in the following order.

- Scanner Name
- User Name
- Date

Select the Delimiter [List] button to change the delimiter.

For example, for scanner name "Scanner", user name "user", date "12312009", delimiter "\_", the folder name is "Scanner\_user\_12312009".

#### 4. Select a file name format.

By default, "Scanner Name" + "Date" + "Time" + "3 digit Seq. Number" is entered.

- If the [Prefix] button is selected  
The character string entered in the input field is used as the file name.  
This may be up to 128 characters long, excluding the following symbols.  
\\ : \* ? " < > |  
For "Scan to SharePoint", the following symbols cannot be used.  
~ " # % & \* : < > ? { | }
- If the [Scanner Name] button is selected  
The scanner name is used as the file name.
- If the [User Name] button is selected  
The name of the currently logged in user is used as the file name.
- If the [Date] button is selected  
The date of the scan is used as the file name. Select the Date Format [List] button to change the date format.
- If the [Time] button is selected  
The start time of the scan is used as the file name.



If multiple buttons are selected, file names are created in the following order.

- Prefix
- Scanner Name
- User Name
- Date
- Time

Select the Delimiter [List] button to change the delimiter.

For example, for prefix "file", scanner name "Scanner", user name "user", date "12312009", time "12:00:30", delimiter "\_", the file name is "file\_Scanner\_user\_12312009\_120030".

5. Press the Seq. Number [List] button.

⇒ The sequence number list appears.

6. Select a sequence number.

The sequence number is added to the end of a file name.

The default value is "Min 3 digit Seq. Number".

If "No Sequence Number" is selected, a sequence number is not added.



If the file name which exceeds the maximum sequence number possible already exists in the target folder for saving, the sequence numbers are not added correctly.



The following explains the way in which sequence numbers are added.

- Sequence numbers start from 1, and file names are assigned using the largest value that exists.

For example, if "A" is entered in the "Prefix" input field, "Min 3 digit Seq. Number" is selected for the Seq. Number [List] button, and "A001.pdf", "A002.pdf", and "A004.pdf" already exist, subsequent file names are assigned in the following order.

"A005.pdf", "A006.pdf", "A007.pdf", "A008.pdf"...

File name "A003.pdf" is skipped.

- If the selected number of columns for the Seq. Number [List] button is exceeded, subsequent file names are assigned using the next digit.

For example, if "A" is entered in the "Prefix" input field, "Min 3 digit Seq. Number" is selected for the Seq. Number [List] button, and "A001.pdf" to "A998.pdf" already exist, subsequent file names are assigned in the following order.

"A999.pdf", "A1000.pdf", "A1001.pdf", "A1002.pdf"...

- The maximum sequence number is "4294967295". If it is exceeded, the skipped minimum number is used for the file name.

For example, if "A" is entered in the "Prefix" input field, "Min 3 digit Seq. Number" is selected for the Seq. Number [List] button, and if "A001.pdf", "A003.pdf", and "A4294967295.pdf" already exist, subsequent file names are assigned in the following order.

"A002.pdf", "A004.pdf", "A005.pdf", "A006.pdf"...

7. Press the Date Format [List] button.

⇒ The date format list appears.

8. Select a date format.

The date format is used for the file or folder name when saving scanned data.

9. Press the Delimiter [List] button.

⇒ The delimiter list appears.

10. Select a delimiter.

The delimiter is used for the file or folder name when saving scanned data.

If "None" is selected, a delimiter is not added.

11. Press the [Preview] button.

⇒ The specified file name format is displayed to the right of the [Preview] button.

12. Check the file name format.

13. Press the [OK] button.

⇒ The file name format is set.

## 4.6.10 Setting a File Name Format for When Attaching Scanned Data to

**e-Mail** Touch Panel Admin Tool Central Admin

Set a file name format for when attaching scanned data to an e-mail.

The "File Name" entered on the "Send e-Mail" screen is displayed as the default value for this setting.



The following file names cannot be used:

- CON
- PRN
- AUX
- CLOCK\$
- NUL
- COM0 to COM9
- LPT0 to LPT9



1. Select the [System Settings] tab on the top menu.
2. Select the [File Names (e-Mail)] tab on the left side menu.  
⇒ The "File Names (e-Mail)" screen appears.

System Settings | Network Settings | Device Status | Operation Logs

File Names (Save) | File Names (e-Mail) | Multifeed Settings | Scanner Adjustment

Specify the file name format used when attaching scan data to e-mails.

Preview [Scanner Name]MMddyymmss

Name Format

Prefix

Scanner Name | User Name | Date | Time

Date Format: MMddyymm

Delimiter: None

Logout | Cancel | OK



## 3. Select a file name format.

By default, "Scanner Name" + "Date" + "Time" is entered.

- If the [Prefix] button is selected  
The character string entered in the input field is used as the file name.  
This may be up to 128 characters long, excluding the following symbols.  
\\ : \* ? " < > |
- If the [Scanner Name] button is selected  
The scanner name is used as the file name.
- If the [User Name] button is selected  
The name of the currently logged in user is used as the file name.
- If the [Date] button is selected  
The date of the scan is used as the file name. Select the Date Format [List] button to change the date format.
- If the [Time] button is selected  
The start time of the scan is used as the file name.



If multiple buttons are selected, file names are created in the following order.

- Prefix
- Scanner Name
- User Name
- Date
- Time

Select the Date Format [List] button to change the date format. Select the Delimiter [List] button to change the delimiter.

For example, for prefix "file", scanner name "Scanner", user name "user", date "12312009", time "12:00:30", delimiter "\_", the file name is "file\_Scanner\_user\_12312009\_120030".



## 4. Press the Date Format [List] button.

⇒ The date format list appears.

## 5. Select a date format.

The date format is used for the file name when attaching scanned data to an e-mail.

## 6. Press the Delimiter [List] button.

⇒ The delimiter list appears.

## 7. Select a delimiter.

The delimiter is used for the file name when attaching scanned data to an e-mail.  
If "None" is selected, a delimiter is not added.

## 8. Press the [Preview] button.

⇒ The specified file name format is displayed to the right of the [Preview] button.

## 9. Check the file name format.

## 10. Press the [OK] button.

⇒ The file name format is set.

## 4.6.11 Setting the Multifeed Detection Method

Touch Panel

Admin Tool

Central Admin


By default, multifeed detection will monitor for paper overlaps in the central column (17.5mm either side from the center of the document) of the document being scanned. However, any photos or attachments in this area will also be detected as a multifeed.

When scanning documents, multifeed detection area may be adjusted to ignore the area (excluding the photograph or attachments) and prevent mis-detections.



For document requirements for multifeed detection, refer to "[A.5 Multifeed Detection Conditions](#)" (page 484).

1. Select the [System Settings] tab on the top menu.
2. Select the [Multifeed Settings] tab on the left side menu.

⇒ The "Multifeed Settings" screen appears.



- Set the area for multifeed detection in the "Multifeed Detection" section.  
Starting from the top edge of a document sheet, set the area to be checked for multifeeds.

Full	Multifeeds will be detected within 17.5mm from either side of the center of paper.
Middle	<p>Multifeeds will be detected within "#1" (upper limit) and "#2" (lower limit) set. (a)</p> 
Top & Bottom	<p>Multifeeds will be detected from the top of the page to "#1" (upper limit), and from #2 (lower limit) to the bottom of the page. (b)</p> 



Multifeed may not be detected for the top and bottom 25mm of a document.



4. In [Step 3](#), if [Middle] or [Top & Bottom] is selected, enter both "#1" (upper limit) and "#2" (lower limit).

#1: Even numbers from 0 to 508mm can be entered. Odd numbers will be made even by adding one.

#2: Even numbers from 0 to 510mm can be entered. Odd numbers will be made even by adding one.



- For multifeed detection, a length of at least 5mm is required. Specify a value for #2 that is at least 6mm greater than that for #1.
- "#2" can have a maximum value of 510mm. If the paper size setting is long page mode but the length of the document is longer than 510mm, multifeed cannot be detected by length.
- When [Middle] is selected, if the document is shorter than "#1", multifeed will not be detected. When [Top & Bottom] is selected, if the document is shorter than "#2", multifeed will not be detected for the bottom part.
- If the values specified for "#1" and "#2" exceed the actual paper size, multifeeds will not be detected.



5. Press the [OK] button.

⇒ The document area to be monitored for multifeeds is set.



## 4.6.12 Setting Scanning Performance

Touch  
PanelAdmin  
Tool

Usually, it is not necessary to make any setting changes.

1. Select the [System Settings] tab on the top menu.
  2. Select the [Scanner Adjustment] tab on the left side menu.
- ⇒ The "Scanner Adjustment" screen appears.

The screenshot shows the "Scanner Adjustment" screen with the following settings:

- System Settings** (selected tab)
- Network Settings**
- Device Status**
- Operation Logs**
- File Names (Save)**
- File Names (e-Mail)**
- Multifeed Settings**
- Scanner Adjustment** (selected tab)
- Logout** button
- Cancel** button
- OK** button

**Enter the scan offset and magnification settings.**

**Front Side Offsets**

- Horizontal Offset:  x 0.5mm (-4 << +4)
- Vertical Offset:  x 0.5mm (-4 << +4)

**Reverse Side Offsets**

- Horizontal Offset:  x 0.5mm (-4 << +4)
- Vertical Offset:  x 0.5mm (-4 << +4)

**Length Magnification**  (-3.1% << +3.1%)

4

---

## ■ Offset Settings

If the scanned output is found to be displaced relative to the actual documents being scanned, the scan offsets can be adjusted.

1. On the "Scanner Adjustment" screen, under [Front Side Offsets]/[Reverse Side Offsets], enter values for the "Horizontal Offset" and "Vertical Offset" input fields.

Offset lengths are measured in units of 0.5mm and may be set to between -4 (-2mm) and +4 (+2mm).

2. Press the [OK] button.

⇒ The offset settings are set.

## ■ Length Magnification Setting

If the scanned output is found to be vertically distorted (stretched or squashed) relative to the actual documents being scanned, the length magnification can be adjusted.

1. On the "Scanner Adjustment" screen, enter the value for the "Length Magnification" input field.

This changes the length magnification correction value of the vertical scan. Using the factory default setting as a starting point, the length of the scan can be magnified or reduced to between -3.1 and 3.1%.

2. Press the [OK] button.


⇒ The length magnification setting is set.

### 4.6.13 Setting General Scanner Settings



Usually, it is not necessary to make any setting changes.  
The operating mode for scanning can be set.

1. Select the [System Settings] tab on the top menu.
  2. Select the [General Scanner Settings] tab on the left side menu.
- ⇒ The "General Scanner Settings" screen appears.



3. Select an operating mode for scanning a document.  
Press the [Performance] button to prioritize the performance speed.  
Press the [Image Quality] button to prioritize the image quality.



Image Quality mode is designed to produce high resolution images, but has the following drawbacks:

- Image file sizes increase and scan speeds decrease.
- At a resolution of 600dpi, a maximum of 100 pages may be scanned.
- The Background Removal option cannot be used.



4. Press the [OK] button.  
⇒ The operating mode is set.

## 4.6.14 Managing Certificates


Certificates to be used for server authentication in SSL communication can be imported or removed.

### ■ Importing a Certificate File Admin Tool Central Admin

X.509 certificate files (\*.cer, \*.crt) can be imported.

Up to 100 certificate files can be imported.

1. Select the [System Settings] tab on the top menu.
2. Select the [Certificate Management] tab on the left side menu.
  - ⇒ The "Certificate Management" screen appears.



3. Specify an authentication certificate file.
  - ⇒ Press the [Browse] button to specify a certificate file.
4. Press the [Import] button.
  - ⇒ The certificate file is imported.
  - The imported file is saved in the Trusted Root Certificate Authority store.



When a certificate file is distributed from the Central Admin Server, any previously imported certificates will be deleted, and replaced by the contents of the new file.



**■ Deleting a Certificate File**Touch  
PanelAdmin  
ToolCentral  
Admin

1. Select the [System Settings] tab on the top menu.
2. Select the [Certificate Management] tab on the left side menu.  
⇒ The [Certificate Management] screen appears.
3. Select a certificate file to be deleted, and press the [Delete] button.  
⇒ The confirmation window appears.
4. Select the [Yes] button.  
⇒ The certificate file is deleted.

## 4.7 Using the Network Settings Menus

### 4.7.1 Giving the Scanner an IP Address Touch Panel Admin Tool

An IP address must be set in order to connect the scanner to a network.

1. Select the [Network Settings] tab on the top menu.
2. Select the [IP Address] tab on the left side menu.
  - ⇒ The DHCP or IP address setting screen appears.

The screenshot shows the 'Network Settings' screen. At the top, there are navigation tabs: 'System Settings', 'Network Settings' (highlighted), 'Device Status', and 'Operation Logs'. On the left side, there is a vertical menu with options: 'Admin Network', 'Central Admin Server', and 'DNS Server'. The main area is titled 'Enter the network addresses.' and contains a 'DHCP' section with 'On' (highlighted in yellow) and 'Off' buttons. Below this, there are three rows of input fields for 'IP Address', 'Subnet Mask', and 'Default Gateway', each with four individual digit boxes. At the bottom, there are three buttons: 'Logout', 'Cancel', and 'OK'.

3. Select whether or not a DHCP is required.
  - Set the scanner's IP address. This may be done automatically, by pressing the DHCP [On] button. By default, this is set as [On].
  - The IP address may also be set manually, by pressing the DHCP [Off] button and entering the following numerical addresses:
    - IP Address
    - Subnet Mask
    - Default Gateway

## 4. Press the [OK] button.

⇒ The information entered is set.



- If the IP address is the same as one already in use, network communication problems will occur. In this case, try the following steps:
  1. Disconnect the LAN cable, and press the [Shutdown] button on the touch panel to turn the scanner off.
  2. Reboot the scanner with the LAN cable disconnected, and enter a nonduplicate IP address.
  3. Re-connect the LAN cable to the scanner.
- When DHCP is set to "On", the following scanner settings are assigned by the DHCP server:
  - IP Address
  - Subnet Mask
  - Default Gateway
  - DNS Server
  - WINS Server
  - Domain SuffixEven if DNS or WINS server is set, priority is given to the scanner settings over the DHCP settings.
- The connection will be lost if the scanner's IP address is changed via the network interface. If connecting via an IP address, to continue with other settings, login to the network interface again using the new IP address.

## 4.7.2 Setting the Admin Network

Touch Panel

Admin Tool

Central Admin

To use the Admin Tool or Central Admin Server for the scanner, perform the connection settings.

1. Select the [Network Settings] tab on the top menu.
2. Select the [Admin Network] tab on the left side menu.

⇒ The "Admin Network" screen appears.

Enter the settings for the remote administration connection.

Port Number  (1 - 65535)

SSL

SSL Certificate This certificate has expired or is not yet valid.  
Issued by : -----  
Valid from --/--/---- to --/--/----

For Central Admin Console, contents of the SSL Certificate are not shown.

3. Enter a port number from 1 to 65535, to be used by the scanner to communicate with the Admin Tool or Central Admin Server.

The default setting is 80.



- Port numbers 135, 139, 445, and numbers from 1025 to 1124, cannot be specified as they are already reserved in the scanner.
- If port numbers other than HTTP: 80, HTTPS: 443 are to be specified, it is recommended that numbers over 5000 are used. If a port number lower than 5000 is specified, verify the Admin Tool connectivity with the port number first.



## 4. Select whether or not to enable SSL (Transport Layer Security).

Select the [On] button enables SSL. If SSL is enabled, press the [Regenerate] button to create another SSL Certificate. When a new SSL Certificate is created, the contents of the certificate are changed. The contents of the SSL Certificate are as follows.

- Issued by  
Shows the SSL Certificate issuer.
- Valid from  
Shows the SSL Certificate expiration date. The expiration date is five years from the date on which the certificate was created. This is shown in date form.

Selecting the [Off] button disables SSL.

## 5. Press the [OK] button.

⇒ The communication settings are set.



- If the Admin Network settings are changed using the Admin Tool, the Admin Tool is disconnected from the scanner. If any further actions are required, the Admin Tool will need to be reconnected to the scanner.
- If SSL is enabled, SSL is also used for communication between the Central Admin Server and the scanner. When Central Admin is enabled, change the settings on the Central Admin Console "Central Admin Server Settings" screen.
- The following settings combinations are not possible.
  - Port Number "80" and SSL "On"
  - Port Number "443" and SSL "Off"




### 4.7.3 Setting a Central Admin Server

Touch Panel Admin Tool Central Admin

If "On" is selected for "Central Admin", scanners can be targeted for Central Admin.

1. Select the [Network Settings] tab on the top menu.
2. Select the [Central Admin Server] tab on the left side menu.  
⇒ The "Central Admin Server" screen appears.



For Central Admin Console, Address and Port Number cannot be set.

3. Select whether or not to enable Central Admin Server.

The default setting is [Off].

For the Central Admin Console, the default value is [On] so that scanners for which Central Admin is enabled will become targets.

Select the [On] button to enable Central Admin Server.

Select the [Off] button to disable Central Admin Server. If [Off] is selected, no other settings can be entered. Press the [OK] button to set the selected contents.



If registration with the Central Admin Server is successful, the text will change to "This scanner's server-side status is: Registered".

Even when setting values are correct, if the network is disconnected or the Central Admin Server is in a suspended state, registration will fail. In either case, if the Central Admin Server is [On], the process will be run again the next time the scanner is turned on or resumed from the standby mode.

4. Enter the Central Admin Server IP address, host name, or FQDN in the "Address" input field.
  - For an IP address  
The following format should be used xxx . xxx . xxx . xxx (xxx is a value from 0 to 255).
  - For a host name or FQDN  
Up to 255 characters may be entered.
5. Enter a port number from 1 to 65535, to be used by the scanner to communicate with the Central Admin Server.  
The default setting is 20444.
6. Select whether or not to enable roaming mode.  
The default setting is [Off].  
Select the [On] button to enable roaming mode. If roaming mode is enabled, a regular user can login on different scanners while retaining their user data.  
The following user data can be used in roaming mode.
  - "My List" e-Mail Address Books
  - Scan Settings
  - Name of the last network printer used
  - Name of the last network folder used
  - Name of the last SharePoint folder usedIf the same network printer/folder or SharePoint folder is not set for each scanner, the name of the latest one used is not shown.  
Select the [Off] button to disable roaming mode.
7. Select whether or not to enable job mode.  
The default setting is [Off].  
Select the [On] button to enable job mode. If job mode is enabled, even if logging on via a different scanner, the job buttons of regular users can be used. However, if the job modes on the Central Admin Server have not been released, the job modes set with the Admin Tool are used.  
Select the [Off] button to disable job mode.
8. Set whether to enable automatic update for the scanner systems (including security, installed options), scanner settings, and Add-ins.  
The default value is [Off].  
Select the [On] button to enable automatic updates for the specified date and time. Enter the date and time for automatic updates in the "Scheduled Date/Time" field.



- Automatic updates start when the scanner is in a standby mode or when no user is logged in while it is turned on.  
Even if notifications from the Central Admin Server or Wake-On-LAN cannot be used, an update can be performed according to the specified date and time.
- If a user is logged in at the scheduled date and time, updates start after the user has logged out.
- It takes approximately 10 minutes to enable this setting. Therefore, make sure that the scheduled date and time starts at least 10 minutes after the setting is made.
- When the setting for an automatic update from the Central Admin Server is distributed to the scanners, if the update is scheduled to start within ten minutes after the setting was distributed, the setting will not be applied.  
To enable new system settings in an environment where update calls cannot be issued, scanners must be restarted or logged out.  
In order to prevent software updates from running at the same time, enable software update time-period restrictions ("[5.6 Setting the Central Admin Server](#)" (page 244)). System settings can be updated even when software updates are restricted.
- If the scheduled automatic update time is set in both the Central Admin Console and with the Admin Tool, the most recent settings will be enabled.

Select the [Off] button to disable automatic updates.

9. Press the [OK] button.

⇒ The Central Admin Server settings are set.

⇒ The scanner information is transmitted to the Central Admin Server.

If the process is successful, the text will change to "This scanner's server-side status is: Registered".



- For details about the settings required to use SSL for communication between the Central Admin Server and scanner, refer to "[4.7.2 Setting the Admin Network](#)" (page 88).
- When user roaming or job settings enabled, if communication with the Central Admin Server is not possible a confirmation message will appear at login.  
If [OK] is selected, the settings information saved in the scanner are used.  
Selecting the [Cancel] button returns to the login screen.



### 4.7.4 Setting the DNS Server

Touch  
PanelAdmin  
ToolCentral  
Admin

A primary DNS and secondary DNS can be set.

1. Select the [Network Settings] tab on the top menu.
2. Select the [DNS Server] tab on the left side menu.
  - ⇒ The "DNS Server" screen appears.

Enter the DNS server settings.

Primary DNS  .  .  .

Secondary DNS  .  .  .

DNS Dynamic Update

DNS Suffix

FQDN

3. Enter the following numerical addresses:
  - Primary DNS
  - Secondary DNS
 If a DNS server setting is not required, enter "0.0.0.0".
4. Select whether or not to dynamically update the DNS.
  - The default setting is [Off].
  - Select the [On] button to enable DNS dynamic update.
  - Select the [Off] button to disable DNS dynamic update.

---

5. Enter a "DNS Suffix".

This can only be set if the [On] button was pressed in [Step 4](#).


The *scanner\_name* + *DNS\_suffix*, may be up to 255 characters long. Alphanumeric characters and the following symbols may be used.

—  
A "." (dot) is added in between the *scanner\_name* and *DNS\_suffix*.

For example, if a scanner name is 9 characters long, because a "." dot will be added to the *scanner\_name*, the DNS suffix may be up to 245 long.

According to the settings, a FQDN is named in the following order.

1. *Scanner\_name* + *DNS\_suffix* entered here.
2. *Scanner\_name* + *domain\_suffix* acquired from DHCP server.
3. *Scanner\_name* + domain input on the "Scanner Name" screen.



6. Press the [OK] button.

⇒ The information entered is set.

### 4.7.5 Setting the WINS Server

Touch  
PanelAdmin  
ToolCentral  
Admin

A primary WINS and secondary WINS can be set.

1. Select the [Network Settings] tab on the top menu.
2. Select the [WINS Server] tab on the left side menu.
  - ⇒ The "WINS Server" screen appears.

3. Enter the following numerical addresses:
  - Primary WINS
  - Secondary WINS
 If a WINS server setting is not required, enter "0.0.0.0".
4. Press the [OK] button.
  - ⇒ The information entered is set.

## 4.7.6 Setting the NTP Server

Touch Panel

Admin Tool

Central Admin

1. Select the [Network Settings] tab on the top menu.
2. Select the [NTP Server] tab on the left side menu.

⇒ The "NTP Server" screen appears.

The screenshot shows the 'NTP Server' configuration screen. At the top, there are four tabs: 'System Settings', 'Network Settings', 'Device Status', and 'Operation Logs'. On the left side, there is a vertical menu with four items: 'WINS Server', 'NTP Server', 'Proxy Server', and 'Login LDAP Server'. The main content area is titled 'Enter the NTP server settings.' and contains a section for 'NTP Server' with an 'Address' input field. A 'Sync Time' button is located in the bottom right of the main area. At the bottom of the screen, there are three buttons: 'Logout', 'Cancel', and 'OK'.

For Central Admin Console, can only set the NTP server address.

3. Enter the NTP server IP address, host name, or FQDN in the "Address" input field.
  - For an IP address  
The following format should be used xxx . xxx . xxx . xxx (xxx is a value from 0 to 255).
  - For a host name or FQDN  
Up to 255 characters may be entered.  
If an NTP server is not required, leave this field blank.
4. Press the [Sync Time] button.
  - ⇒ The result of the time synchronization for the specified NTP server is shown.  
If no error message appears, the NTP server setting is valid.  
If an error message appears, refer to ["E.1.1 Administrator Screen Messages"](#) (page 503).
5. Press the [OK] button on the confirmation message screen.

6. Press the [OK] button.

⇒ The NTP server is set.



- The system time is automatically synchronized every 6 hours to that supplied by the NTP server.
- When the NTP server settings are changed, the system time is synchronized immediately.
- An adjustment that advances the system time by 20 minutes or more results in a session timeout and causes the scanner to logout.

## 4.7.7 Setting the Proxy Server

Touch Panel

Admin Tool


Central Admin



Set whether a proxy server is used when connecting to SharePoint server via the Admin Tool or Central Admin Console. This cannot be set from the LCD touch panel.

In this section, the Admin Tool screen is used as an example.

1. Select the [Network Settings] tab on the top menu.
  2. Select the [Proxy Server] tab on the left side menu.
- ⇒ The "Proxy Server" screen appears.



The screenshot displays the 'Proxy Server' configuration window. On the left is a vertical menu with 'Proxy Server' selected. The main area is titled 'Enter the proxy server settings.' and contains two sections:

- FTP Proxy Server** (Used by FTP Path Network Folders): Includes radio buttons for 'On' and 'Off' (selected), and input fields for 'Address' and 'Port Number' (range 1-65535).
- SharePoint Proxy Server** (Used by SharePoint Folders): Includes radio buttons for 'On' and 'Off' (selected), input fields for 'Address' and 'Port Number' (range 1-65535), and an 'Exceptions' text box with the instruction 'Do not use a proxy for addresses that start with:' and 'Use semi-colons (;) to separate entries'.

At the bottom are 'OK' and 'Cancel' buttons.

3. Use the "FTP Proxy Server" option to set whether or not a proxy server is used for FTP server connection.

The default setting is [Off].

Select [On] to enable FTP connection via a proxy server.

- 1 Enter the proxy server IP address, host name, or FQDN in the "Address" input field.
  - For an IP address
 

The following format should be used xxx . xxx . xxx . xxx (xxx is a value from 0 to 255).
  - For a host name or FQDN
 

Up to 255 characters may be entered.
- 2 Enter a port number for the proxy server, from 1 to 65535, in the "Port Number" field.

Select [Off] to enable direct FTP connection (not via a proxy server).



This "FTP Proxy Server" setting must be set to [On] if the "Proxy" setting for any FTP server network folder is set to [On]. If the "FTP Proxy Server" setting is set to [Off], FTP server network folders cannot be used.

For details of how to set an FTP server folder as a proxied network folder, refer to "4.7.14 Setting the Network Folders" (page 132).

4. Use the "SharePoint Proxy Server" option to set whether or not a proxy server is used for SharePoint server connection.

The default setting is [Off].

Select [On] to enable SharePoint connection via a proxy server.

- 1 Enter the Central Admin Server IP address, host name, or FQDN in the "Address" input field.
  - For an IP address
 

The following format should be used xxx . xxx . xxx . xxx (xxx is a value from 0 to 255).
  - For a host name or FQDN
 

Up to 255 characters may be entered.
- 2 Enter a port number from 1 to 65535, to be used by the scanner to communicate with the Central Admin Server.
- 3 Any IP addresses, host names, or FQDN that are to be accessed directly (not via the proxy server) should be entered in the "Exceptions" field.
  - Multiple addresses must be separated using semi-colons (";").
  - "\*" may be used as a wildcard character.
  - An IP address may be followed by a "/" and then a subnet mask.

Select [Off] to enable direct SharePoint connection (not via a proxy server).

5. Press the [OK] button.

⇒ The proxy server is set.

## 4.7.8 Setting the Login LDAP Server



If a login LDAP server is set, user authentication will be checked.

1. Select the [Network Settings] tab on the top menu.
2. Select the [Login LDAP Server] tab on the left side menu.

⇒ The "Login LDAP Server" screen appears.

This server is used to authenticate user logins.

Server Type: Off

Port Number: 389 (1 - 65535)

SSL: Off

Address: [Empty field]

Search Base (DN): [Empty field]  
(eg: cn=Users, dc=example, dc=com)

Search Timeout: 60 sec

Login User Attributes: uid, cn

Buttons: Logout, Cancel, Connect, OK

3. Set the connection settings for the login LDAP server.
  - Select [Active Directory] if the Active Directory server is to be used for user logins.
  - Select [Active Directory Global Catalog] if a global catalog LDAP server is to be used for user logins.
  - Select [Other LDAP Server] if an LDAP server other than the Active Directory is to be used for user logins.
  - Select [Off] if an LDAP server is not required for user logins. If [Off] is selected, no other settings can be entered. Select the [OK] button to confirm the setting contents.
4. Enter a port number from 1 to 65535, to be used by the scanner to communicate with an LDAP server.
  - The default setting is as follows.
  - When [Off] is selected for "SSL"
    - If [Active Directory] or [Other LDAP Server] is selected, 389.
    - If [Active Directory Global Catalog] is selected, 3268.
  - When [On (Full Validation: CA + Certificate)] or [On (Certificate Only, CA not validated)] is selected for "SSL"
    - If [Active Directory] or [Other LDAP Server] is selected, 636.
    - If [Active Directory Global Catalog] is selected, 3269.



5. Select whether and how to enable SSL (Transport Layer Security).
  - If [On (Full Validation: CA + Certificate)] is selected, SSL is enabled, and CAs and server certificates are validated as follows:
    - Certificate authority (CA) validation
      - Check the certification path of the LDAP server certificate by following the chain of certifying authorities back to an accepted Trust Anchor.
    - Server certificate validation
      - Check that the current date/time is within the certificate validity period.
      - Check that the public key certificate has not been tampered with.
      - Check that the certificate has not been revoked.
  - If [On (Certificate Only, CA not validated)] is selected, SSL is enabled, and server certificates but not CAs are validated as follows:
    - Server certificate validation
      - Check that the current date/time is within the certificate validity period.
      - Check that the public key certificate has not been tampered with.
      - Check that the certificate has not been revoked.
  - If [Off] is selected, SSL is disabled.
6. Enter the LDAP server IP address, host name, or FQDN in the "Address" input field.
  - For an IP address
    - The following format should be used xxx . xxx . xxx . xxx (xxx is a value from 0 to 255).
  - For a host name or FQDN
    - Up to 255 characters may be used.
7. In the "Search Base (DN)" input field, enter the distinguished name of the LDAP search base.
  - The character string entered here will be the root under which LDAP entries will be searched for.
  - This may be up to 255 characters long.
  - When [Active Directory] or [Other LDAP Sever] is selected, if settings are omitted, the entire contents of the LDAP server are searched.
  - When [Active Directory Global Catalog] is selected, if settings are omitted, the entire contents of the global server are searched.
  - For more details about the character string to be entered, and connection to the LDAP search target, refer to ["LDAP Search Target" \(page 104\)](#).
8. Press the [List] button for the "Search Timeout" input field.
  - ⇒ A list of "search timeout" times appears.
9. Select the LDAP List search timeout delay.
  - The default time is 60 seconds.
  - ⇒ The selected "Search Timeout" value is displayed.

10. Select login user attributes.

When [Other LDAP Server] is selected for the "Server Type", select whether LDAP server login users can be searched for by "uid" or "cn".

When [uid] is selected, users to be logged in are searched with "uid".

When [cn] is selected, users to be logged in are searched with "cn".

11. To check the connection with the LDAP server, press the [Connect (Test)] button.

⇒ The screen for setting access authorization details appears.

1. Enter the authentication details for confirming access to the LDAP server.

- When the "Server Type" is [Active Directory] or [Active Directory Global Catalog]

- When the "Server Type" is [Other LDAP Server]

LDAP Server Access Authorization

User Name

Password

Cancel Num Lock Caps Lock OK

LDAP Server Access Authorization

Authorized User (DN)\*   
(eg: cn=root, dc=example, dc=com)

Password

\*Anonymous user connection will be attempted if an Authorized User (DN) is not entered.

Cancel Num Lock Caps Lock OK

- For the "User Name" and/or "Authorized User (DN)", alphanumeric characters (case sensitive) and symbols may be entered.
- Enter an "Authorized User (DN)" in DN format.
- For the "Password", alphanumeric characters (case sensitive) and symbols may be entered.



- For settings via the Admin Tool, when [Other LDAP Server] is selected for "Server Type", even if the [Connect (Test)] button is pressed, the screen for setting access authorization details will not be shown. Enter the access authorization details on the "Login LDAP Server" screen.
- The "Caps Lock" and "Num Lock" indicators are shown when the administrator logs in via the scanner's touch panel.  
The "Caps Lock" indicator is on if the keyboard's Caps Lock is set.  
The "Num Lock" indicator is on if the keyboard's Num Lock is set.

2. Press the [OK] button.

⇒ When the connection is successful, the "Login LDAP Server" screen appears.

## 12. Press the [OK] button.

- ⇒ If a setting other than [Other LDAP Server] is selected for "Server Type", the login LDAP server settings are completed.
- ⇒ If [Other LDAP Server] is selected for "Server Type", the screen for setting access authorization details is displayed.  
Enter the access authorization details for the LDAP server login user to be searched and press the [OK] button to set the login LDAP server.

LDAP Server Access Authorization

Authorized User (DN)\*  
  
(eg: cn=root, dc=example, dc=com)

Password

\*Anonymous user connection will be attempted if an Authorized User (DN) is not entered.

Num Lock    Caps Lock

- For the "Authorized User (DN)", alphanumeric characters (case sensitive) and symbols may be entered.
- Enter an "Authorized User (DN)" in DN format.
- For the "Password", alphanumeric characters (case sensitive) and symbols may be entered.




- For settings via the Admin Tool, when [Other LDAP Server] is selected for "Server Type", even if the [OK] button is pressed, the screen for setting access authorization details will not be displayed. Enter the access authorization details on the "Login LDAP Server" screen.
- The "Caps Lock" and "Num Lock" indicators are shown when the administrator logs in via the scanner's touch panel.  
The "Caps Lock" indicator is on if the keyboard's Caps Lock is set.  
The "Num Lock" indicator is on if the keyboard's Num Lock is set.

## ■ LDAP Search Target

The search range and method for LDAP server searches differs according to the LDAP server connection, or search base (DN) settings (Step 3 or Step 7 of "4.7.8 Setting the Login LDAP Server" (page 100)).

- For connecting with LDAP server (when [Active Directory] or [Other LDAP Server] is selected in Step 3)

The following shows an example (where the domain name is *example.com*) for the "Search Base (DN)" to be entered in Step 7. The italic text represents variable character strings.




Hereinafter, Active Directory is used as an example to describe search targets.


Example 1: When searching for (administrator, user A, user B)

*CN=Users, DC=example, DC=com*

Active Directory configuration is as follows.




Example 2: When searching for (user C, user D, user E)  
 OU=department, DC=example, DC=com  
 Active Directory configuration is as follows.




4

Example 3: When searching for (user C, user D)  
 OU=section A, OU=department, DC=example, DC=com  
 Active Directory configuration is as follows.




Example 4: When searching for all users  
no "Search Base (DN)" setting, or DC=example, DC=com



- For connecting with Global Catalog (when [Active Directory Global Catalog] is selected in Step 3)

The following shows an example (where the parent domain name is *example.com*, and sub-domain name is *sub.example.com*) for the "Search Base (DN)" to be entered in Step 7. The italic text represents variable character strings.



Example: When searching in whole domain

no "Search Base (DN)" setting, or *DC=example, DC=com*

The LDAP search target differs as follows, according to whether a user logs in with a *sAMAccountName* or *userPrincipalName*.

Regular User	Login Name	Login Possible
	Top: <i>sAMAccountName</i> Bottom: <i>userPrincipalName</i>	
User A	<i>userA</i>	OK
	<i>userA@example.com</i>	OK
User H	<i>userH</i>	NG
	<i>userH@sub.example.com</i>	OK

The SAM Account Name is the Active Directory user login name (*sAMAccountName*).

The User Principal Name is the Active Directory user login name (*userPrincipalName*).

## 4.7.9 Setting the e-Mail LDAP Server



If an e-mail LDAP server is set, the searches within the LDAP List on the "e-Mail Address Book" screen can be performed.

1. Select the [Network Settings] tab on the top menu.
2. Select the [e-Mail LDAP Server] tab.
  - ⇒ The "e-Mail LDAP Server" screen appears.

This server is used to search for e-mail addresses.


Server Type	Use Login LDAP
Port Number	389 (1 - 65535)
SSL	Off
Address	
Search Base (DN)	
	(eg: cn=Users, dc=example, dc=com)
Maximum Results	1000
Search Timeout	60 sec

Logout Cancel Schema Connect OK

3. Set the e-mail LDAP server connection settings.
  - Select [Use Login LDAP] to reuse the user login LDAP server settings for e-mail address searches or lookup. If [Use Login LDAP] is selected, no other settings can be entered. Press the [OK] button to set the e-mail LDAP server settings.
  - Select [Active Directory] if the Active Directory server is to be used for e-mail address searches.
  - Select [Active Directory Global Catalog] if a global catalog LDAP server is to be used for e-mail address searches.
  - Select [Other LDAP Server] if an LDAP server other than the Active Directory is to be used for e-mail address searches.
4. Perform [Step 4](#) to [Step 11](#) (excluding [Step 10](#)) of "[4.7.8 Setting the Login LDAP Server](#)" ([page 100](#)).
5. Press the [List] button for the "Maximum Results" input field.
  - ⇒ A list of "number of maximum results" appears.



6. Select the maximum number of results for e-mail LDAP list searches.  
The default maximum is 1000.  
⇒ The selected "Maximum Results" value is displayed.
7. When [Other LDAP Server] is selected for "Sever Type" only, press the [Schema] button to use the search items and schema.  
⇒ The screen for adjusting the search item schema for LDAP search appears.  
Press the [Use Defaults] button to return entered contents to the default values.  
Press the [OK] button to set the search item schema, and return to the "e-Mail LDAP Server" screen.



Search Item	Description
First Name	Enter the schema name that is to be associated with the "First Name" search item. The default value is "givenName".
Last Name	Enter the schema name that is to be associated with the "Last Name" search item. The default value is "sn".
Common Name	Enter the schema name that is to be associated with the "Common Name" search item. The default value is "cn".
Display Name	Enter the schema name that is to be associated with the "Display Name" search item. The default value is "displayName".


---

Search Item	Description
Initials	Enter the schema name that is to be associated with the "Initials" search item. The default value is "initials".
Comment	Enter the schema name that is to be associated with the "Comment" search item. The default value is "description".
Workplace	Enter the schema name that is to be associated with the "Workplace" search item. The default value is "physicalDeliveryOfficeName".
Phone Number	Enter the schema name that is to be associated with the "Phone Number" search item. The default value is "telephoneNumber".
E-mail Address	Enter the schema name that is to be associated with the "E-mail Address" search item. The default value is "mail". This cannot be omitted.
Homepage	Enter the schema name that is to be associated with the "Homepage" search item. The default value is "wWWHomePage".

8. Press the [OK] button.

⇒ The e-mail LDAP server is set.

---


 To use the e-mail LDAP server, use a login user account. If the login LDAP server and e-mail LDAP server are different, according to the domain configuration or login name format, it may not be possible to use the e-mail LDAP server. For more details, refer to "[LDAP Search Target](#)" (page 104).

---

### 4.7.10 Setting the LDAP Search Parameters




The search conditions ([First Name] and [Last Name] buttons on the following screen) on the "e-Mail Address Book" - [LDAP List] tab can be customized.



For details about the "e-Mail Address Book" - [LDAP List] tab, refer to ["6.4.1 Selecting an e-Mail Target from the e-Mail Address Book"](#) (page 319).



1. Select the [Network Settings] tab on the top menu.
2. Select the [Customize LDAP Search] tab on the left side menu.

⇒ The "Customize LDAP Search" screen appears.








The following table shows the correspondence between the administrator "Customize LDAP Search" screen settings, and the regular user search condition buttons on the "e-Mail Address Book" - [LDAP List] tab.

Setting Area	Descriptions
Left Button	<p>Determines the setting of the left button on the [LDAP List] tab.</p>  <p>The screenshot shows the 'e-Mail Address Book' interface with the 'LDAP List' tab selected. Below the tabs are three search condition buttons: 'First Name', 'Last Name', and 'e-Mail Address'. The 'First Name' button is highlighted with a red dashed circle. Below these buttons is a 'Search Target' input field and a 'Find' button.</p>
Middle Button	<p>Determines the setting of the middle button on the [LDAP List] tab.</p>  <p>The screenshot shows the 'e-Mail Address Book' interface with the 'LDAP List' tab selected. Below the tabs are three search condition buttons: 'First Name', 'Last Name', and 'e-Mail Address'. The 'Last Name' button is highlighted with a red dashed circle. Below these buttons is a 'Search Target' input field and a 'Find' button.</p>


3. Specify the item(s) to be searched.


LDAP search is performed on the specified item(s).

Multiple search items can be selected. If multiple items are selected, an "OR" search is performed, finding entries containing any of the search words.

Buttons	The items to be searched in the Active Directory
First Name	<p>Searches the first names of users registered in the LDAP server.</p> 
Last Name	<p>Searches the last names of users registered in the LDAP server.</p> 
Common Name	<p>Searches the common names of users registered in the LDAP server.</p>  <p>This item can be set in the "Active Directory Users and Computers". The [Common Name] button must be selected to search for Active Directory groups.</p>



Buttons	The items to be searched in the Active Directory
Display Name	Searches the display names of users registered in the LDAP server. 

- HINT** 
- If none of the [First Name], [Last Name], [Common Name], or [Display Name] buttons are selected, the corresponding search parameter button on the "e-Mail Address Book" - [LDAP List] tab cannot be selected.
  - If the [Display Name] button is selected, and the display format for LDAP search results is "First Name" - "Last Name" or "Last Name" - "First Name", search results are shown as a "-" if a first name or last name has not been registered.  
Example: For LDAP search results format "First Name" - "Last Name", with a first name not registered  
Search result display format: Last Name ----

4. Press the [List] button for the "Result Format" input field.  
⇒ The result format screen appears.
5. Specify the format of the LDAP search result.  
Displays the LDAP search result according to the specified format.

Result Format	Descriptions
FirstName LastName	Shows "First Name" - "Last Name" of the users registered in the LDAP server.
LastName FirstName	Shows "Last Name" - "First Name" of the users registered in the LDAP server.
CommonName	Shows "Common Name" of the users registered in the LDAP server. The [Common Name] button must be selected to have group names appear when searching for Active Directory groups.
DisplayName	Shows "Display Name" of the users registered in the LDAP server.

6. Enter the button name.

The characters input here are displayed on the button name on the [LDAP List] tab. This may be up to 18 characters long. Only alphanumeric characters may be entered. A space (only one) also can be used, but the space will be displayed as a line break on the button. Please note that a space between words cannot be made within a line. Only one blank space can be entered.



If the button names are changed, check the actual button image shown on the LDAP "e-Mail Address Book" screen. The button image may not show all characters entered.



7. Press the [OK] button.

⇒ The LDAP search parameters are set.

## 4.7.11 Setting the e-Mail Server (SMTP Server)

Touch Panel

Admin Tool

Central Admin



e-Mail cannot be sent if authentication is required by the e-mail server before sending.

1. Select the [Network Settings] tab on the top menu.
2. Select the [SMTP Server] tab on the left side menu.  
⇒ The "SMTP Server" screen appears.

System Settings	Network Settings	Device Status	Operation Logs
Enter the SMTP server settings.			
SMTP Server			
Address <input type="text"/>			
Port Number <input type="text" value="25"/> (1 - 65535)			
Split Mails <input checked="" type="radio"/> On <input type="radio"/> Off			
Segment Size <input type="text" value="256"/> KB (64 << 10240)			
Maximum Attachment Size <input type="text" value="10"/> MB (1 << 20)			
Address Warning Limit <input type="text" value="100"/> (2 << 1000)			
Logout		Cancel	
OK			

3. Enter the SMTP server IP address, host name, or FQDN in the "Address" input field.
  - For an IP address  
The following format should be used xxx . xxx . xxx . xxx (xxx is a value from 0 to 255).
  - For a host name or FQDN  
This may be up to 255 characters long.  
If an SMTP server is not required, leave this field blank.
4. Enter a port number from 1 to 65535, to be used by the scanner to communicate with the SMTP Server.  
The default setting is 25.



5. At "Split Mails", set whether to send split e-mails.  
 The default setting is [Off].  
 Press the [On] button to send split e-mails.  
 Press the [Off] button to send an e-mail without splitting it.
6. For "Segment Size", set a value from 64 to 10240 as the maximum size for splitting an e-mail.  
 The default size is "256 KB".
7. Set the "Maximum Attachment Size" for e-mails (total data size when sending an e-mail). This may be between 1 and 20 MB.  
 The default size is "10MB".



Set this value so as not to exceed the value of the message size restriction set in the SMTP server.



8. For "Address Warning Limit", set a value from 2 and 1000 as the maximum number of addresses to which e-mail can be sent without confirmation. If the number of recipient addresses specified for an e-mail is then larger than this value, a warning dialog will be shown to prevent inadvertent transmission of a mass e-mailing.  
 The default value is "100".
9. Press the [OK] button.  
 ⇒ The SMTP server is set.

## 4.7.12 Setting the Fax Server

Touch Panel

Admin Tool

Central Admin

1. Select the [Network Settings] tab on the top menu.
2. Select the [Fax Server] tab on the left side menu.  
⇒ The "Fax Server" screen appears.

The screenshot shows a web-based configuration interface. At the top, there are five tabs: System Settings, Network Settings (highlighted in green), Device Status, and Operation Logs. On the left side, there is a vertical menu with several options: e-Mail LDAP Server, Customize LDAP Search, SMTP Server, and Fax Server (highlighted in blue). The main content area is titled "Enter the e-mail address for the fax server." and contains a text input field labeled "Fax Server e-Mail Address". At the bottom of the screen, there are three buttons: "Logout" (with a red X icon), "Cancel" (with a red circle and slash icon), and "OK" (with a green play icon).

3. Enter a monitored fax server (RightFax) e-mail address in the "Fax Server e-Mail Address" field.  
If the fax server setting is not required, leave the field blank.  
For more details about e-mail Address setting values, refer to "[B.1 e-Mail Address Setting Values](#)" (page 488).
4. Press the [OK] button.  
⇒ The fax server is set.

### 4.7.13 Setting the Network Printers

Touch  
PanelAdmin  
ToolCentral  
Admin

Set a printer connected to the network.

The procedure for setting a network printer is as follows.

1. Check the printer driver.

For more details, refer to "[Checking the Printer Drivers](#)" (page 120).

2. Set the printer properties.

For more details, refer to "[Setting the Printer Properties](#)" (page 121).

3. Register the network printer.

Up to 100 network printers can be registered.

A network printer can be registered in one of the following ways.

- Network Tree

Select a network printer from the network tree.

For more details, refer to "[Registering a Network Printer \(Network Tree\)](#)" (page 124).

- Network Path

Directly enter the network printer path name.

For more details, refer to "[Registering a Network Printer \(Network Path\)](#)" (page 127).




- Be sure to read the printer manual beforehand for information about setting a printer, adding a network printer, and other cautions.
- If the drive on which the spool folder for the print server exists does not have enough free space, printing will stop. Make sure that there is enough space in the drive before printing.
- Do not set a virtual printer.
- If a printer connected to different print servers is to be registered as a network printer multiple times, the software version of the driver should be the same on each print server. If the software version of the printer driver differs, printing errors may occur.

## ■ Checking the Printer Drivers

The driver installed on the print server must be compatible with Windows XP.

Use the following procedure to check whether the drivers installed on the print server are Windows XP compatible drivers.

1. From the [Start] menu on the print server, select [Control Panel] - [Printers and Faxes].
  - ⇒ The "Printers and Faxes" window appears.
2. Right-click on a printer, and select [Properties].
  - ⇒ Printer properties appear.
3. Press the [Additional Drivers] button in the [Sharing] tab.
  - ⇒ The "Additional Drivers" window appears.
4. Check that the "Processor" is "x86" (or intel), and that "Installed" is "Yes" for version Windows XP.



When the "Installed" status is "Yes", the driver has been installed and the printer can be used as a network printer. Press the [Cancel] button.


When the "Installed" status is "No", select version "Windows XP", and press the [OK] button.

⇒ The Windows XP compatible driver is installed.

## ■ Setting the Printer Properties


Use the following procedures to set a printer.

1. From the [Start] menu on the print server, select [Control Panel] - [Printers and Faxes].
  - ⇒ The "Printers and Faxes" window appears.
2. Right-click on a printer, and select [Properties].
  - ⇒ The "printer properties" window appears.
3. Press the [Printing Defaults] button in the [Advanced] tab.



⇒ The "printing defaults" window is displayed.

4. Change the settings and press the [OK] button.




⇒ The printer properties are set.




It is recommended that the same one printer is added to the print server multiple times for each set of properties settings, according to usage. For example, "for color printing" and "for black & white printing".

For a color printing example, the procedure for adding a printer is as follows.


1. From the [Start] menu on the print server, select [Control Panel] - [Printers and Faxes].  
⇒The "Printers and Faxes" window appears.
2. Double-click the [Add Printer].  
⇒The "Add Printer Wizard" window appears.
3. Follow prompts on the wizard window until the "Use Existing Driver" window appears.
4. Select "Keep existing driver [recommended]" and press the [Next] button.



5. Follow the prompts on the wizard window until the "Printer Sharing" window appears.
6. Specify the shared name.  
Enter "FUJITSUX.2 (Color)" for color printing.



It is recommended to name the printer with an alias that indicates the contents of the properties settings as follows.



⇒ Follow the prompts on the wizard window. The "Completing the Add Printer Wizard" message indicates that the printer addition has completed. Press the [Finish] button.

⇒ The printer is added on the "Printers and Faxes" window.


7. Right-click the added printer and select [Properties].

⇒ The "printer properties" window appears.

8. Press the [Printing Defaults] button on the [Advanced] tab.

⇒ The printing defaults window appears.

9. Select "Color" on the [Paper/Quality] tab, and press the [OK] button.




⇒ Printing is set to "Color".

After this, if the printer set for color printing on the print server is added to the scanner printer list, the user can specify to use this printer already set for color printing.

For details about adding the printer to the scanner printer list, refer to "[Registering a Network Printer \(Network Tree\)](#)" (page 124) or "[Registering a Network Printer \(Network Path\)](#)" (page 127).

## ■ Registering a Network Printer (Network Tree)

1. Select the [Network Settings] tab on the top menu.
2. Select the [Network Printer] tab on the left side menu.
  - ⇒ The "Network Printer" screen appears.





3. Press the [Add] button.
  - ⇒ The screen for selecting a network printer is displayed.



Desired domains may not be shown in the Printer Network. In this case, directly enter the network printer path name, or wait for a few minutes and re-open the screen for selecting a network printer.




4. Select a domain .



⇒ If login is required, an "Authentication" screen appears.

If login is not required, the network tree expands and computer names are displayed under the selected domain.



The "Caps Lock" and "Num Lock" indicators are shown on the authentication screen, when the administrator logs in via the scanner's touch panel. The "Caps Lock" indicator is on if the keyboard's Caps Lock is set. The "Num Lock" indicator is on if the keyboard's Num Lock is set.

1. Enter a User Name.  
This may be up to 256 characters long.
2. Enter a Password.  
This may be up to 256 characters long (case sensitive).

3. Press the [OK] button.
  - ⇒ When the user name and password are valid, or if login is not required, the network tree expands and computer names are displayed under the selected domain.



5. Select a computer

⇒ If login is required, a login authentication screen appears.

If login is not required, the network tree expands and computer names are displayed under the selected domain.

1. Enter a User Name.
  - This may be up to 256 characters long.
2. Enter a Password.
  - This may be up to 256 characters long (case sensitive).
3. Press the [OK] button.
  - ⇒ When the user name and password is valid, or if login is not required, the network tree expands and network printers are displayed under the selected computer name.



6. Select a network printer



A network printer that has already registered cannot be added.



7. Press the [Select] button.

⇒ The screen returns to the "Network Printer" screen, and the registered network printer is added to the network printer list.



- Once the network printer is registered, do not change the shared name or printer alias on the print server.
- To change the shared name or printer alias, remove the registered network printer first, and then change the share name/printer alias, and register it again.



- The default network printer alias will be the same as the alias selected from the network tree. For details on changing the printer alias, refer to ["Renaming a Network Printer" \(page 129\)](#).
- While the network tree is displayed, enter characters to be searched for in the "Find" field, and press the [Back] or [Next] button to focus the network tree on the specified characters.



## ■ Registering a Network Printer (Network Path)

1. Select the [Network Settings] tab on the top menu.
2. Select the [Network Printer] tab on the left side menu.
  - ⇒ The "Network Printer" screen appears.
3. Press the [Add] button.
  - ⇒ The screen for selecting a network printer is displayed.
4. Press the [Network Path] button.
  - ⇒ The screen for adding a network printer is displayed.



Pressing the [Network Tree] button returns to the screen for selecting a network printer from the network tree.

5. Enter a "Printer Alias".
  - This may be up to 80 characters long. "\" cannot be used in a printer alias.
  - If you do not enter a name for "Printer Alias" and press the [Add] button, the shared name will be used as the "Printer Alias".

---

## 6. Enter a "Network Path".

"Network Path" may be up to 255 characters long.

Set the network path in the following format:

`\\Domain_name\Computer_name\Printer_alias`

For the "Domain\_name", specify the NetBIOS domain name or the workgroup name that the network printer belongs to.

For the "Computer\_name", specify the IP address, host name, or FQDN.

When specifying the IP address or FQDN for "Computer\_name", a primary DNS suffix setting for the print server is required.

When a primary DNS suffix for the print server is already set, the following settings are not required.

The procedure for setting a primary DNS suffix is as follows.


1. From the [Start] menu on the print server, select [Control Panel]-[System].  
⇒ The "System Properties" window appears.
2. Select the [Change] button in the [Computer Name] tab.  
For the Windows 2000 Server, select the [Properties] button in the [Network Identification] tab.  
⇒ The "Computer Name Changes" window appears.
3. Select the [More] button.  
⇒ The "DNS Suffix and NetBIOS Computer Name" window appears.
4. For "Primary DNS suffix of this computer", specify the DNS suffix to be appended to the name of this computer when completing its FQDN.  
Example: `example.com`
5. After these changes are applied, restart the computer.

## 7. Press the [Add] button.

⇒ The screen returns to the "Network Printers" screen, and the registered network printer is added to the network printer list.



- The already registered network printer cannot be added.
- Once the network printer is registered, do not change the shared name or printer alias on the print server.
- To change the shared name or printer alias, remove the registered network printer first, and then change the share name/printer alias, and register it again.




- The default network printer alias will be the same as the alias selected from the network tree. For details on changing the printer alias, refer to ["Renaming a Network Printer" \(page 129\)](#).
- The authentication screen may appear.



## ■ Renaming a Network Printer

1. Select the [Network Settings] tab on the top menu.
2. Select the [Network Printer] tab on the left side menu.  
⇒ The "Network Printer" screen appears.
3. Select the network printer that is to be renamed.
4. Press the [Rename] button.  
⇒ The screen for renaming a network printer is displayed.
5. Enter a new printer alias.  
This may be up to 80 characters long. The folder alias may not contain backslashes (\).  
Trailing spaces are truncated, so a spaces-only alias is not allowed.



Enter the new printer alias.

Printer Alias:  
Printer02

Network Path:  
\\WORKGROUP\WORK\FUJITSUX


Cancel OK

6. Press the [OK] button.  
⇒ The network printer is renamed.



## ■ Viewing the Printer Details

1. Select the [Network Settings] tab on the top menu.
2. Select the [Network Printer] tab on the left side menu.  
⇒ The "Network Printer" screen appears.
3. Select the desired network printer from the printer list.
4. Press the [Details] button.  
⇒ The information for the selected network printer is displayed.



---

## 4.7.14 Setting the Network Folders

Touch  
Panel

Admin  
Tool

Central  
Admin

A list of network folders may be set as "Save" targets for scanned data. Any accessible file server folder or FTP server folder may be specified. Up to 100 network folders and FTP server folders can be added. A network folder can be added in either of the following ways.

- Network Tree  
Select a network folder from the network tree.  
For details, refer to "[Registering a Network Folder \(Network Tree\)](#)" (page 133).
- Network Path  
Set a network folder by directly entering the path alias for the file server folder.  
For details, refer to "[Registering a Network Folder \(Network Path\)](#)" (page 136).
- FTP Path  
Set a network folder by directly entering the path alias for the FTP server folder.  
For details, refer to "[Registering a Network Folder \(FTP Path\)](#)" (page 138).



Note the following when registering a network folder.


- The network folder is registered as a network path. If the network folder is on a Windows file server and the length of the full Windows path including the file name exceeds 259 characters, the scan data will not be saved. Before registering a (Windows) network folder, check that the length of the full file path+name is not likely to exceed 259 characters.
- If the selected folder was created using a language foreign to that of the browsing operating system, the network folder may not register correctly. If the name of the network folder contains unrecognizable characters, check the codeset used.
- If the number folders to be displayed is large, they may take a long time to appear.





## ■ Registering a Network Folder (Network Tree)


1. Select the [Network Settings] tab on the top menu.
2. Select the [Network Folder] tab on the left side menu.
  - ⇒ The "Network Folder" screen appears.




3. Press the [Add] button.
  - ⇒ The screen for adding a network folder is displayed.




Desired domains may not be shown in the Network Folders. In this case, directly enter the path alias for the file server, or wait for a few minutes and re-open the screen for adding a network folder.

4. Select a domain 



⇒ If login is required, an "Authentication" screen appears.

If login is not required, the network tree expands and computer names are displayed under the selected domain.



The "Caps Lock" and "Num Lock" indicators are shown on the authentication screen, when the administrator logs in via the scanner's touch panel. The "Caps Lock" indicator is on if the keyboard's Caps Lock is set. The "Num Lock" indicator is on if the keyboard's Num Lock is set.

1. Enter a User Name.  
This may be up to 256 characters long.
2. Enter a Password.  
This may be up to 256 characters long (case sensitive).
3. Press the [OK] button.  
⇒ When the user name and password are valid, or if login is not required, the network tree expands and computer names are displayed under the selected domain.



5. Select a computer .

⇒ If login is required, an "Authentication" screen appears.

If login is not required, the network tree expands and computer names are displayed under the selected domain.

1. Enter a User Name.  
This may be up to 256 characters long.
2. Enter a Password.  
This may be up to 256 characters long (case sensitive).
3. Press the [OK] button.  
⇒ When the user name and password is valid, or if login is not required, the network tree expands and network folders are displayed under the selected computer name.



6. Select a network folder .

The selected folder will be opened to show any sub-folders, which themselves may be selected in turn (up to seven levels deep, including the parent domain).

7. Press the [Select] button.

⇒ The selected network folder is added to the network folder list.



- The default network folder alias will be the same as the alias selected from the network tree. For details on changing the folder alias, refer to ["Renaming a Network Folder" \(page 141\)](#).
- Select a readable and writable network folder.
- The "Network" tree can show up to 400 domain, computer, and network folder items on the touch panel screen, and up to 10,000 items on the Admin Tool screen.
- While the network tree is displayed, enter characters to be searched for in the "Find" field, and press the [Back] or [Next] button to focus the network tree on the specified characters.



## ■ Registering a Network Folder (Network Path)

1. Select the [Network Settings] tab on the top menu.
2. Select the [Network Folder] tab on the left side menu.
  - ⇒ The "Network Folder" screen appears.
3. Press the [Add] button.
  - ⇒ The screen for selecting a network folder is displayed.
4. Press the [Network Path] button.
  - ⇒ The screen for adding a network folder (Network Path) is displayed.

The screenshot shows a web-based interface for adding a network folder. At the top, there are navigation tabs: System Settings, Network Settings (highlighted), Device Status, and Operation Logs. On the left, there is a vertical menu with options: Network Printer, Network Folder (highlighted), Alert Notification, and Ping. The main content area is titled 'Add a network folder.' and contains two input fields: 'Folder Alias' with a note '\* If left blank, the shared folder name will be used.' and 'Network Path' with an example '(eg: \\Domain\Computer\Folder[\Folder])'. At the bottom, there are four buttons: Logout, Cancel, Network Tree, and Add.



Pressing the [Network Tree] button returns to the screen for selecting a folder from the network tree.

5. Enter a "Folder Alias".
  - This may be up to 80 characters long. "\" cannot be used in a folder alias.
  - If you do not enter a name for "Folder Alias" and press the [Add] button, the shared name will be used as the "Folder Alias".

## 6. Enter a "Network Path".

Set the network path in the following format:

```
\\Domain_name\Computer_name\Folder_name [\Folder_name]
```

The minimum requirement for a network path is:

```
\\Domain_name\Computer_name\Folder_name
```

This may be up to 255 characters long.

Sub folders ( [\Folder\_name] is the example above) are optional.

"/" and "\" can be used as a delimiter for the folder alias.

If "/" is used, the network folder name is registered as "folder\_name/folder\_name".

For the "Domain\_name", specify the NetBIOS domain name or the workgroup name that the network folder belongs to.

For the "Computer\_name", specify the IP address, host name, or FQDN.

## 7. Press the [Add] button.

⇒ The network folder is added to the network folder list.



- The default network folder alias will be the same as the alias selected from the network tree. For details on changing the folder alias, refer to ["Renaming a Network Folder" \(page 141\)](#).
- Select a readable and writable network folder.
- The authentication screen may be displayed.

## ■ Registering a Network Folder (FTP Path)

1. Select the [Network Settings] tab on the top menu.
2. Select the [Network Folder] tab on the left side menu.
  - ⇒ The "Network Folder" screen appears.
3. Press the [Add] button.
  - ⇒ The screen for selecting a network folder is displayed.
4. Press the [FTP Path] button.
  - ⇒ The screen for entering a network folder (FTP Path) is displayed.

Enter the FTP server settings.

Folder Alias	<input type="text"/>		
FTP Path	<input type="text"/>		
User Name	<input type="text"/>	Password	<input type="text"/>
Authentication	<input type="button" value="Remember"/>	<input checked="" type="button" value="Each Time"/>	Port Number
Protocol	<input checked="" type="button" value="FTP"/>	<input type="button" value="FTPS"/>	<input type="text" value="21"/>
Passive Mode	<input checked="" type="button" value="On"/>	<input type="button" value="Off"/>	(1 - 65535)
Encryption	<input type="button" value="Explicit"/>	<input type="button" value="Implicit"/>	
Proxy *	<input type="button" value="On"/>	<input type="button" value="Off"/>	*See the Proxy Server Menu

5. Enter a "Folder Alias".

This may be up to 80 characters long. "\" cannot be used in a folder alias.  
If you do not enter a name for "Folder Alias" and press the [OK] button, the FTP path will be used as the "Folder Alias". If the FTP path includes "\", the name of the bottommost folder in the path is used as the "Folder Alias". For example, if the FTP path is specified as "FTPSERVER\folder", the "Folder Alias" will be "folder".
6. Enter a "FTP Path".

This may be up to 255 characters long.  
Set the FTP path in the following format:  
Computer\_name\Folder\_alias  
For the "Computer\_name", specify the IP address, host name, or FQDN.
7. Enter a user name and password for login to the FTP sever.

"User Name" or "Password" may be up to 256 characters long. Passwords are case sensitive.

8. For "Authentication", specify whether or not to save the entered "User Name" and "Password".

When the [Remember] button is selected, the "User Name" and "Password" are saved. The "User Name" and "Password" saved for authentication are used on the regular user screen.

When the [Each Time] button is selected, the "User Name" and "Password" are not saved. When selecting a network folder initially, authentication is required on the regular user screen. However, if the user is registered in the LDAP server, and the LDAP user name and password can be used for authentication, the authentication screen will not appear even if the [Each Time] button is selected.
9. For "Protocol", specify how to access the FTP server.

The default value is "FTP".

When the [FTP] button is selected, the FTP server will be connected without SSL encryption.

When the [FTPS] button is selected, the FTP server will be connected through SSL encryption.
10. Set a "Port Number" for the FTP server.

The default number is 21. Numbers from 1 to 65535 can be set.
11. For "Passive Mode", specify whether or not to access in passive mode.

The default value is "On".

"Passive Mode" can be selected only when the [FTP] button is selected in [Step 9](#).

When the [On] button is selected, the FTP server is connected in passive mode.

When the [Off] button is selected, the FTP server is connected in active mode.

When the [FTPS] button is selected in [Step 9](#), the FTP server is connected in passive mode.
12. For "Encryption", specify the type of encryption.

"Encryption" can be selected when the [FTPS] button is selected in [Step 9](#).

When the [Explicit] button is selected, the FTP server will be connected without SSL encryption, and encryption will start before user name and password are authenticated.

When the [Implicit] button is selected, SSL encryption will work when the FTP server connection is started.
13. For "Proxy", specify whether or not a proxy server is to be used.

The "Proxy" setting is only available when a proxy server has been set on the "Proxy Server" screen. For details about proxy server settings, refer to ["4.7.7 Setting the Proxy Server" \(page 98\)](#).

When the [ON] button is selected, the FTP connection is via the proxy server specified on the "Proxy Server" screen.

When the [OFF] button is selected, the FTP server is connected to directly, without using the proxy server.

---

14. Press the [OK] button.

⇒ User authentication may be required to access the FTP server. Then, the network folder is added to the network folder list.



For the Central Admin Console, to use a Central Admin Sever with an enabled firewall, set the "Passive Mode" to "On".




Select a readable and writable network folder.





## ■ Renaming a Network Folder

1. Select the [Network Settings] tab on the top menu.
2. Select the [Network Folder] tab on the left side menu.
  - ⇒ The "Network Folder" screen appears.
3. Select the network folder that is to be renamed.
4. Press the [Edit] button.
  - ⇒ The screen for renaming a network folder is displayed.
5. Enter a folder alias.
  - This may be up to 80 characters long. The folder alias may not contain backslashes (\).
  - Trailing spaces are truncated, so a spaces-only alias is not allowed.



The screenshot shows a software interface with a top navigation bar containing 'System Settings', 'Network Settings' (highlighted), 'Device Status', and 'Operation Logs'. On the left, a vertical menu lists 'Network Printer', 'Network Folder' (highlighted), 'Alert Notification', and 'Ping'. The main area is titled 'Enter the new folder alias.' and contains two input fields: 'Folder Alias' with the text 'Folder02' and 'Network Path' with the text '\\WORKGROUP\WORK\Folder'. At the bottom, there are three buttons: 'Logout', 'Cancel', and 'OK'.



If the network folder is an FTP server folder, the following screen is displayed. In this case, the "FTP Path" cannot be changed.

Category	Field/Option	Value
Folder Alias	Folder Alias	Folder02FTP
FTP Path	FTP Path	(disabled)
User Name	User Name	abc
Password	Password	...
Authentication	Remember	Selected
Each Time	Each Time	Not Selected
Protocol	FTP	Selected
FTPS	FTPS	Not Selected
Passive Mode	On	Selected
Off	Off	Not Selected
Encryption	Explicit	Selected
Implicit	Implicit	Not Selected
Proxy *	On	Selected
Off	Off	Not Selected
Port Number	Port Number	21

(1 - 65535)

\*See the Proxy Server Menu

Logout Cancel OK

6. Press the [OK] button.

⇒ The network folder is renamed.


## ■ Removing a Network Folder

1. Select the [Network Settings] tab on the top menu.
2. Select the [Network Folder] tab on the left side menu.
  - ⇒ The "Network Folder" screen appears.
3. Select the network folder that is to be removed from the folder list.
4. Press the [Remove] button.
  - ⇒ The screen for removing a network folder is displayed.
5. Confirm the details of the network folder that is to be removed are correct, and press the [Yes] button.
  - ⇒ The selected network folder is removed from the network folders list.


---

## ■ Viewing the Network Folder Details

1. Select the [Network Settings] tab on the top menu.
2. Select the [Network Folder] tab on the left side menu.  
⇒ The "Network Folder" screen appears.
3. Select the desired network folder from the folder list.
4. Press the [Details] button.  
⇒ The information for the selected network folder is displayed.



If the network folder is an FTP server folder, the following screen is displayed.




## 4.7.15 Setting the SharePoint Folders

Admin  
ToolCentral  
Admin

A list of SharePoint folders may be set as "Scan to SharePoint" targets for scanned data.

1. Select the [Network Settings] tab on the top menu.
2. Select the [SharePoint Folder] tab on the left side menu.

⇒ The "SharePoint Folder" screen appears.



3. The "Scan to SharePoint" option determines whether users are allowed to save scanned data in SharePoint folders.

The default setting is [Off].

Selecting [On] allows scanned data to be saved in a SharePoint folder.

Selecting [Off] prevents scanned data from being saved in a SharePoint folder.

4. Specify a SharePoint server site URL in the "URL" field.

Either of the following formats may be used:

- Not using SSL


`http://SharePoint_server_IP_address, host_name, or FQDN[:port_number]/[site_name]`  
Port 80 is used if the port number is skipped.

- Using SSL

`https://SharePoint_server_IP_address, host_name, or FQDN[:port_number]/[site_name]`  
Port 443 is used if the port number is skipped.


If a site name is not entered, all sites under the base URL are shown.

URLs up to 512 characters long may be entered.

Pressing  produces a list of the (up to) ten most recently specified URLs, allowing easy reselection of URLs.

5. Press the [Connect] button.

⇒ A "Sign In" screen appears.



The image shows a "Sign In" dialog box with three input fields: "User Name", "Password", and "Domain". Below the fields are two buttons: "OK" and "Cancel".

Enter the sign in details for the specified SharePoint server.

1. Enter a User Name.

This may be up to 256 characters long.

2. Enter a Password.

This may be up to 256 characters long (case sensitive).

3. Enter a Domain.

This may be up to 64 characters long.

4. Press the [OK] button.

⇒ If the sign in is successful, the available SharePoint server folders are shown in the "SharePoint Site Folders" list area.

6. Select the folder that is to be a save target from the "SharePoint Site Folders" list, and press the [<<<] button.

⇒ The selected folder is added to the "Scan to SharePoint Folders" list, making it available to users as a save target.



HINT

- Do not set a folder in which scan data cannot be saved, such as a SharePoint library "Slide Library" type.
- Do not set a server site and folder URL path that exceeds 184 characters.
- When a folder is added to "Scan to SharePoint Folders" list, if the specified folder name already exists in the list, a parenthesized sequence number (starting from "(2)") will be appended to the folder name.



ATTENTION

- To set a SharePoint folder from the Central Admin Server, install .NET Framework 3.0 Service Pack 1 or later into the Central Admin Server, and restart it.
- In the following cases, SharePoint folders cannot be set from the Central Admin Server.
  - .NET Framework 3.0 Service Pack 1 or later is not installed in the Central Admin Server
  - Central Admin Server software is installed in the Windows 2000 Server



## ■ Renaming a SharePoint Folder (Display Name)

SharePoint folder display names may be changed as follows.

1. Select the [Network Settings] tab on the top menu.
2. Select the [SharePoint Folder] tab on the left side menu.
  - ⇒ The "SharePoint Folder" screen appears.
3. From the "Scan to SharePoint Folders" list, select the folder that is to be renamed.
4. Press the [Edit] button.
  - ⇒ The "Scan to SharePoint folder details" screen appears.
5. Enter the name that is to be shown for the selected SharePoint folder.
  - Up to 80 characters can be used. A folder name may not consist only of blank spaces.
  - Spaces at the end of a folder name will not be recognized as part of the folder name.

6. Press the [OK] button.
  - ⇒ The SharePoint folder is renamed.

---

## ■ Removing a SharePoint Folder

An already set SharePoint folder may be removed from the list of save targets.

1. Select the [Network Settings] tab on the top menu.
2. Select the [SharePoint Folder] tab on the left side menu.
  - ⇒ The "SharePoint Folder" screen appears.
3. From the "Scan to SharePoint Folders" list, select the folder that is to be removed.
4. Press the [Remove] button.
  - ⇒ A confirm removal screen appears for the selected folder.
5. Check that the correct folder is being removed, then press the [Yes] button.
  - ⇒ The indicated folder is removed.



## 4.7.16 Setting the Destination for Alert Notifications



An e-mail address can be specified to which an alert notification will be sent whenever a scanner alert situation occurs.


If an SMTP server has not been setup, alert notifications cannot be sent. For more details about how to set an SMTP server, refer to "[4.7.11 Setting the e-Mail Server \(SMTP Server\)](#)" (page 116). When the destination for alert notification is set, alert notification messages will be sent to the registered e-mail address in the following title.

Network Scanner (XXXX) Error

For more details, refer to "[E.1.3 Alert Monitor System Log Messages](#)" (page 522).

1. Select the [Network Settings] tab on the top menu.
2. Select the [Alert Notification] tab on the left side menu.

⇒ The "Alert Notification" screen appears.



3. Enter an e-mail address to which the alert notification will be sent.  
For details about e-mail address settings values, refer to "[B.1 e-Mail Address Setting Values](#)" (page 488).
4. To confirm that the entered e-mail address is valid, press the [Test] button.  
Check that the test mail successfully arrives at the expected e-mail address.
5. Press the [OK] button.

⇒ The destination for alert notifications is set.

---


## 4.7.17 Checking the Network Connection with a Ping Test



The network connection can be checked using a ping test.

1. Select the [Network Settings] tab on the top menu.
2. Select the [Ping] tab on the left side menu.

⇒ The "Ping" screen appears.




3. Enter the IP address, host name, or FQDN for the server to be used to check the network connection.
  - For an IP address  
The following format should be used xxx . xxx . xxx . xxx (xxx is a value from 0 to 255).
  - For a host name or FQDN  
Up to 255 characters may be used.

## 4. Press the [Ping] button.

⇒ A ping test is performed and the results are displayed.

For more details about the result, refer to "[Checking basic network operation with a Ping test](#)" (page 456).



## 4.7.18 Checking the Network Operating Status

Touch Panel

Admin Tool

### ■ Checking the Network Status

The operating status of the network can be checked.


The following information is shown. If the information is not shown, refer to "[8.3 Network Connection Troubleshooting](#)" (page 456) and check the settings.

The following information is shown.

- MAC Address
- IP Address
- Subnet Mask
- Default Gateway
- DNS Server IP Address
- WINS Server IP Address

1. Select the [Network Settings] tab on the top menu.
2. Select the [Network Status] tab on the left side menu.

⇒ The "Network Status" screen shows the status of the currently operating network connection.





- If connection to LDAP server is not possible, try the following steps:
  1. Disconnect the LAN cable, and press the [Shutdown] button on the touch panel to turn the scanner off.
  2. Reboot the scanner with the LAN cable disconnected, and enter a nonduplicate IP address.
  3. Re-connect the LAN cable to the scanner.
- If the DHCP server cannot be reached when DHCP is set to [On], the IP Address is set to "169.254.xxx.yyy" (where xxx and yyy are arbitrary values between 0 and 255).

## ■ Setting the Link Speed/Duplex Mode

If the network is not communicating properly, even though the network operating status is correct, change the Link Speed/Duplex Mode settings.


1. Select the [Network Settings] tab on the top menu.
2. Press the [Network Status] tab on the left side menu.
  - ⇒ The "Network Status" screen shows the status of the currently operating network connection.
3. Press the Link Speed/Duplex Mode [List] button.
  - ⇒ The Link Speed/Duplex Mode list appears.
4. Change the setting from "Auto-Negotiation" to a fixed Link Speed/Duplex Mode.
5. Press the [OK] button.
  - ⇒ The Link Speed/Duplex Mode setting is changed.

## 4.8 Using the Device Status Menus

### 4.8.1 Viewing the System Status



1. Select the [Device Status] tab on the top menu.
  2. Select the [System Status] tab on the left side menu.
- ⇒ The system status information is displayed.




The following system status information is available.

Info	Details
System Version	Shows the current scanner system and security versions.
Scanner Version	Shows the current scanner firmware version.
Date of Registration	Shows the date on which the scanner was first used.
Cumulative On Time	Shows the total elapsed usage time of the scanner.

**4.8.2 Viewing the Status of Installed Options** Touch Panel Admin Tool

Details of what options and when they were installed in the scanner can be viewed.

1. Select the [Device Status] tab on the top menu.
  2. Select the [Installed Options] tab on the left side menu.
- ⇒ The "Installed Options" screen appears.



The following status for installed options is available.

Info	Details
Date	Shows the date on which an option was installed.
Time	Shows the time when an option was installed.
Option Name / Details	Shows the name and details of an installed option.

### 4.8.3 Viewing the Usage Status Touch Panel Admin Tool


Information about the number of documents that have been scanned and the status of the scanner's consumable parts (pad assy or pick roller) can be viewed.

For details on consumable replacement, refer to ["7.6 Replacing Parts" \(page 436\)](#).

#### ■ Viewing the Status of Consumable Parts

1. Select the [Device Status] tab on the top menu.
2. Select the [Usage Status] tab on the left side menu.

⇒ The "Usage Status" screen appears.



The "Status" fields show the total number of pages scanned and the current conditions of the pad assy or pick roller.

"Total Throughput" is shown in units of 10 sheets scanned.

"PAD ASSY" and "PICK ROLLER" are shown in units of 500 sheets scanned.



Consumables	Color	Status	Action
PAD ASSY	Green	Total throughput: 0 to 44,999 sheets	No action required.
	Orange	Total throughput: 45,000 to 49,999 sheets	Pad assy needs to be replaced soon. Obtain a replacement part.
	Red	Total throughput: Over 50,000 sheets	Pad assy has passed its rated lifetime and needs to be replaced.
PICK ROLLER	Green	Total throughput: 0 to 94,999 sheets	No action required.
	Orange	Total throughput: 95,000 to 99,999 sheets	Pick roller needs to be replaced soon. Obtain a replacement part.
	Red	Total throughput: Over 100,000 sheets	Pick roller has passed its rated lifetime and needs to be replaced.

### ■ Resetting the Usage Counter

After part replacement, the usage counter can be reset to return the part status to normal. For more details about replacing consumable parts, refer to ["7.6 Replacing Parts" \(page 436\)](#).

1. Select the [Device Status] tab on the top menu.
2. Select the [Usage Status] tab on the left side menu.
  - ⇒ The "Usage Status" screen appears.
3. Press the [Clear] button for the part replaced.
  - ⇒ The counter reset confirmation screen appears.
4. Press the [Yes] button.
  - ⇒ The counter value is reset to "0", and the "Status" field turns green again.

## 4.8.4 Viewing the Add-in Status


Touch Panel

Admin Tool

If an add-in module is installed, the following steps can be performed.  
An Add-in is an application created by using the fi-6010N SDK (development kit).

1. Select the [Device Status] tab on the top menu.
2. Select the [Add-in Status] tab on the left side menu.

⇒ The "Add-in Status" screen appears.



The following information is shown.

Info	Details
Add-in	Shows the name of the add-in module.
Version	Shows the current add-in module version number.

## 4.9 Using the Operation Logs Menus

### 4.9.1 Managing the User Log

The most recent 1,000 user log entries are saved by the scanner.



- User logs may contain private information such as e-mail addresses or fax numbers, so care should be taken when managing such data.
- If a log file error is detected during system operation, the log file will be cleared and the following log entry recorded:  
Error 81001004 Corrupted user log file was deleted.

#### ■ Viewing the User Log Details



The user log summary is shown in date/time order. Even if the [Region/Timezone] or [Date/Time] settings are changed, the order of the log entries will not be changed.

1. Select the [Operation Logs] tab on the top menu.
2. Select the [User Log] tab on the left side menu.

⇒ The "User Log" screen appears.




---

3. Select the log you wish to view.

⇒ The details of the selected log are displayed.

Pressing the [OK] button returns to the "User Log" screen.



The following information is shown.

Info	Info options	Description
Date	MM/dd/yyyy dd/MM/yyyy yyyy/MM/dd	Shows the date of each operation (format specified on the Date/Time screen is used). For more details, refer to <a href="#">"4.6.5 Setting the Date/Time" (page 64)</a> .
Time	hh:mm:ss	Shows the time of each operation.
User	xxxxxxxxxxxxxxxx	Operating user names are displayed in the following format. SAM_account_name@domain_name
Result	In Progress	Currently processing a scan operation.
	OK	Operation completed successfully.
	Error	Operation failed to complete successfully.
Code	xxxxxxx	Shows a code for each operation. If a response is required, refer to <a href="#">"Appendix E Operation Messages" (page 501)</a> .
Operation	e-Mail	The scanned data is sent as an e-mail attachment.
	Fax	The scanned data is sent as a fax.
	Print	The scanned data is sent to the print server, and the sending status is shown in the "Result" column until the scanned data is completely sent to the print server.
	Save	Scanned data is saved in a network folder.
Pages	xxx	Shows the number of pages scanned.
Description	xxxxxxxxxxxxxxxx	Shows detailed information for each message.

## ■ Downloading the User Logs in CSV Format Admin Tool

Operation logs for regular users are stored in the scanner with the default file name "OperationLog.csv".

When downloaded to a computer, the file will contain CSV format data. The file is saved in the following form:

```
"Date","Time","User","Result","Code","Operation","Pages","Description"
```

1. Select the [Operation Logs] tab on the top menu.
2. Select the [User Log] tab on the left side menu.
  - ⇒ The "User Log" screen appears.
3. Press the [Download] button.
  - ⇒ The "File Download" dialog box appears.
4. Press the [Save] button.



The size of the user log file is displayed in the "File Download" dialog box. Make sure there is enough free space on the disk where it is to be saved and press the [Save] button. If there is not enough free disk space, an incomplete file may be saved.

- ⇒ The "Save As" dialog box appears.

5. Enter a file name.
  - The file will contain CSV format data.
6. Press the [Save] button.
  - ⇒ A file containing CSV format data is saved.

## ■ Clearing the User Logs Touch Panel Admin Tool

1. Select the [Operation Logs] tab on the top menu.
2. Select the [User Log] tab on the left side menu.
  - ⇒ The "User Log" screen appears.
3. Press the [Clear All] button.
  - ⇒ The "clear all" confirmation screen appears.
4. Press the [Yes] button.
  - ⇒ All the user operation logs are cleared.

## 4.9.2 Managing the System Log

Up to 1,000 system information logs (such as for startup, shutdown, and system errors) are saved in the scanner.



- System log may contain private information such as e-mail addresses or fax numbers, so care should be taken when managing such data.
- If a log file error is detected during system operation, the log file will be cleared and the following log entry recorded:  
Error 81001003 Corrupted system log file was deleted.

### ■ Viewing the System Log Details

Touch Panel

Admin Tool

The system log summary is shown in date/time order.

Even if the [Region/Timezone] or [Date/Time] settings are changed, the order of the log entries will not be changed.

1. Select the [Operation Logs] tab on the top menu.
  2. Select the [System Log] tab on the left side menu.
- ⇒ The "System Log" screen appears.

Date	Time	Type	Message
4/2/2008	03:24:48	Information	010D0002 User name @ logged out.
4/2/2008	03:23:52	Information	010D0001 User name @ logged in.
4/2/2008	03:23:45	Error	110D0001 Login failed. Check the user name and p...
4/2/2008	03:23:17	Information	010D0002 User name @ logged out.
4/2/2008	03:22:57	Information	010D0001 User name @ logged in.
4/2/2008	03:18:28	Information	010D0002 User name @ logged out.
4/2/2008	03:18:01	Information	010D0001 User name @ logged in.
4/2/2008	03:05:53	Information	01000001 (IP Address) Settings were changed. Info : DHCP = Off.



---

## ■ Downloading the System Log in CSV Format Admin Tool

The default file name is "SystemLog.csv".

When downloaded to a computer, the file will contain CSV format data. The file is saved in the following form:

```
"Date","Time","Type","Message"
```

1. Select the [Operation Logs] tab on the top menu.
2. Select the [System Log] tab on the left side menu.  
⇒ The "System Log" screen appears.
3. Press the [Download] button.  
⇒ The "File Download" dialog box appears.
4. Press the [Save] button.



The size of the user log file is displayed in the "File Download" dialog box. Make sure there is enough free space on the disk where it is to be saved and press the [Save] button. If there is not enough free disk space, an incomplete file may be saved.

⇒ The "Save As" dialog box appears.

5. Enter a file name.  
The file will contain CSV format data.
6. Press the [Save] button.  
⇒ A file containing CSV format data is saved.

## ■ Clearing the System Log Touch Panel Admin Tool

1. Select the [Operation Logs] tab on the top menu.
2. Select the [System Log] tab on the left side menu.  
⇒ The "System Log" screen appears.
3. Press the [Clear All] button.  
⇒ The "clear all" confirmation screen appears.
4. Press the [Yes] button.  
⇒ The system log is cleared.



## 4.10 Using the Maintenance Menus

### 4.10.1 Maintaining the User Data Store

Admin Tool

The scanner's user data store can be backed-up, restored, and deleted.

The user data store contains the following information:

- Fax Number List
- "My List" e-Mail Address Books
- Scan Settings
- User Logs
- Name of the last network printer used
- Name of the last network folder used
- Name of the last SharePoint folder used

Scanner login user names are authenticated with the LDAP server, and when a new name is encountered, the scanner automatically adds an entry for that user to the user data store. The user data store may contain up to 1,000 users.



- Once 1,000 user names have been used to login, new user logins are no longer possible until the entire user data store is cleared. Refer to ["Backing up the User Data Store" \(page 167\)](#) and ["Clearing the User Data Store" \(page 170\)](#) for details.

It is recommended that the user data store be backed up before it is cleared.

- When restoring from a user data store backup, if a backed up user name corresponds to that of an existing user in the current user data store, the backup user data will overwrite the current user data. If the backed up user name is "unknown", the backed up data will be added as a "new" user. Addition of new users cannot cause the 1,000 user limit to be exceeded, or the user data store restoration will fail.
- When the User Data Store is restored from a backup, the Fax Number List is also reverted to its old state.


The following example illustrates how the number of users could exceed 1,000:

1. 100 users (A001 to A100) log in.
2. The user data store is backed up (with 100 users: A001 to A100).
3. The user data store (containing users A001 to A100) is cleared.
4. 960 "new" users (A001 to A050 and B001 to B910) login.

5. The user data store (containing users A001 to A100) backed up in Step 2 is restored.

- ⇒ Users A001 to A100 are to be restored, of whom 50 are already in the current user data store (users A001 to A050) and so will be overwrite targets.
- ⇒ Users A051 to A100 are considered "new" users and thus need to be added to the user data store. However 960 existing users + 50 new users = 1010 users.
- ⇒ As the number of users would exceed the 1,000 user limit, the Step 2 user data store (containing users A001 to A100) is not restored.

The user data store contents are organized as follows:



The user data store may contain private information such as e-mail addresses or fax numbers, so care should be taken when managing such data.

## ■ Backing up the User Data Store


As a precaution, the user data store should be backed up regularly.

The default file name is "restored\_data".



User logs cannot be backed up.

1. Select the [Maintenance] tab on the top menu.
2. Select the [User Data Store] tab on the left side menu.
  - ⇒ The "User Data Store" screen appears.
3. Press the [Backup] button.



⇒ The "File Download - Security Warning" dialog box appears.

4. Press the [Save] button.



The size of the user log file is displayed in the "File Download - Security Warning" dialog box. Make sure there is enough free space on the disk where it is to be saved and press the [Save] button. If there is not enough free disk space, an incomplete file may be saved.

⇒ The "Save As" dialog box appears.

---

5. Enter a file name.

Use of a name that includes the scanner name and backup date is recommended.

6. Press the [Save] button.

⇒ A backup copy of the user data store is saved.



Do not change the contents of data store backup files.

If changed, the file may no longer be used as a backup. Trying to restore from a changed user data store backup file may render the scanner inoperable.



## ■ Restoring the User Data Store

The scanner's user data store can be restored from a backed-up user data store file.



- Restoring user data overwrites all user information stored at the time of restoration, and returns all e-mail address books, fax number list, and scan settings to the time the backup was taken.
- During user data store restoration, do not press and hold down the startup button for longer than 4 seconds, as it may cause the scanner to function abnormally.



User logs cannot be backed up, therefore cannot be restored.



1. Select the [Maintenance] tab on the top menu.
2. Select the [User Data Store] tab on the left side menu.
  - ⇒ The "User Data Store" screen appears.
3. Select a user data store backup file.
  - Press the [Browse] button to select a file.
4. Press the [Restore] button.
  - ⇒ An "OK to overwrite?" confirmation message appears.
5. Press the [Yes] button.
  - ⇒ After the user data store is restored, a restore completion message appears.
6. Press the [OK] button.

---

## ■ Clearing the User Data Store

The scanner's user data store can be deleted.



Clearing the user data store cannot be undone.



1. Select the [Maintenance] tab on the top menu.
2. Select the [User Data Store] tab on the left side menu.
  - ⇒ The "User Data Store" screen appears.
3. Press the [Clear] button.
  - ⇒ The clear confirmation screen appears.
4. Press the [Yes] button.
  - ⇒ The user data store is cleared.



### 4.10.2 Maintaining the System Settings Admin Tool

The scanner's system settings set by the administrator can be saved in CSV format, backed up, restored, or returned to their factory default values.



System settings do not include the network printer settings.




#### ■ Downloading the System Settings in CSV Format

System settings downloaded in CSV format may be viewed by using spreadsheet software. CSV system settings files are of the following format:

"Function\_name", "Option\_name", "Value"

The default file name is "Configuration\_download.csv".

1. Select the [Maintenance] tab on the top menu.
2. Select the [System Settings File] tab on the left side menu.
  - ⇒ The "System Settings File" screen appears.
3. Press the [Get CSV] button.



⇒ The "File Download" dialog box appears.

- 
4. Press the [Save] button.



The size of the user log file is displayed in the "File Download" dialog box. Make sure there is enough free space on the disk where it is to be saved and press the [Save] button. If there is not enough free disk space, an incomplete file may be saved.

⇒ The "Save As" dialog box appears.

5. Name the file and specify where it should be saved.

The file will contain CSV format data.

6. Press the [Save] button.

⇒ The system settings for the scanner are downloaded.

## ■ Backing up System Settings

The administrator can backup the scanner system settings.

Backup files can later be used to restore system settings. Backup should be performed regularly.

The default file name is "SystemSettingsFile".

1. Select the [Maintenance] tab on the top menu.

2. Select the [System Settings File] tab on the left side menu.

⇒ The "System Settings File" screen appears.

3. Press the [Backup] button.

⇒ The "File Download - Security Warning" dialog box appears.

4. Press the [Save] button.



The size of the user log file is displayed in the "File Download - Security Warning" dialog box. Make sure there is enough free space on the disk where it is to be saved and press the [Save] button. If there is not enough free disk space, an incomplete file may be saved.

⇒ The "Save As" dialog box appears.

5. Name the file and specify where it should be saved.

The date of backup or scanner name should be used as an easy-to-understand file name.

6. Press the [Save] button.

⇒ The system settings are backed up.





Do not change the contents of system settings backup files. If changed, the file may no longer be used as a backup. Trying to restore from a changed system settings backup file may render the scanner inoperable.

## ■ Restoring System Settings

The system settings backup file can be returned to the scanner to restore system settings to those at the time backup was taken.

1. Select the [Maintenance] tab on the top menu.
2. Select the [System Settings File] tab on the left side menu.
  - ⇒ The "System Settings File" screen appears.
3. Enter a backup file to restore from.
  - Press the [Browse] button to select a file.
4. Press the [Restore] button.
  - ⇒ A confirmation message appears.
5. Press the [Yes] button.
  - ⇒ After factory default settings have been restored, the scanner is restarted.



During system settings restoration, do not press and hold down the startup button for longer than 4 seconds, as it may cause the scanner to function abnormally.



The network interface connection will be lost when the scanner is restarted to complete the restoration of the system settings. To continue with other settings, wait a short time for the device to restart, then login to the network interface again.

As the network interface connection to the scanner requires the IP address or scanner name, if this is changed by the restoration of the system settings (i.e. if the backed up IP address or scanner name is different to the pre-restoration IP address or scanner name), the new IP address or scanner name will be needed. If not known, the current state of these settings can always be checked by physically logging in to the scanner via the touch panel interface.



### 4.10.3 Updating the Scanner's System Software

Admin Tool

The scanner system, security system, and installed options can be updated as follows.


1. Select the [Maintenance] tab on the top menu.
  2. Select the [System Update] tab on the left side menu.
- ⇒ The "System Update" screen appears.

3. Select a system update file.  
Press the [Browse] button to select a file.
4. Press the [Upload] button.

⇒ The "Current System Version" and "Was Updated On" values are displayed.



When installed options or the system including installed options are updated, the following window appears.



5. Press the [OK] button.

⇒ The system update process is started.

After the system has updated, the scanner is restarted.



- Wait for the system to restart.
- During the update, do not press and hold down the startup button for longer than 4 seconds, as it may cause the scanner to function abnormally.



The network interface connection will be lost when the scanner is restarted to complete the system update. To continue with other settings, wait a short time for the device to restart, then login to the network interface again.


### 4.10.4 Installing/Uninstalling an Add-in Module Admin Tool

An Add-in is an application created using the fi-6010N SDK (Developer's Kit). This section describes how to install and uninstall an Add-in module.

#### ■ Installing an Add-in Module

1. Select the [Maintenance] tab on the top menu.
2. Select the [Add-in Manager] tab on the left side menu.

⇒ The "Add-in Manager" screen appears.




3. Select an Add-in installation file.  
Press the [Browse] button to select a file.
4. Press the [Install] button.  
⇒ A confirmation message appears.
5. Press the [OK] button.  
⇒ After the Add-in module has been installed, the scanner is restarted.

---

## ■ Uninstalling an Add-in Module

1. Select the [Maintenance] tab on the top menu.
2. Select the [Add-in Manager] tab on the left side menu.

⇒ The "Add-in Manager" screen appears.




3. Press the [Uninstall] button.  
⇒ A confirmation message appears.
4. Press the [OK] button.  
⇒ After the Add-in module has been uninstalled, the scanner is restarted.

### 4.10.5 Setting the Information Output Level



1. Select the [Maintenance] tab on the top menu.
2. Select the [Technical Support] tab on the left side menu.
  - ⇒ The "Technical Support" screen appears.



3. Enter the desired information output level.
  - The default level is "1".
  - Increasing the value of the output level increases the amount of information details collected, but decreases the performance level. Set the level requested by your FUJITSU scanner dealer or an authorized FUJITSU scanner service provider.
4. Press the [Set] button.
  - ⇒ The information output level is set.



If the "Information Output Level" is set to "5", the output data may contain private user information such as e-mail addresses, so care should be taken when managing such data.


## 4.10.6 Obtaining Technical Support Admin Tool

If any problems occur when setting up or using the scanner, technical support information can be collected to help determine the cause of the problem.

The information obtained should be sent to your FUJITSU scanner dealer along with the scanner when given for repair.

1. Select the [Maintenance] tab on the top menu.
2. Select the [Technical Support] tab on the left side menu.

⇒ The "Technical Support" screen appears.



3. Press the [Download] button.

⇒ The "File Download - Security Warning" dialog box appears.

4. Press the [Save] button.



The size of the user log file is displayed in the "File Download - Security Warning" dialog box. Make sure there is enough free space on the disk where it is to be saved and press the [Save] button. If there is not enough free disk space, an incomplete file may be saved.

⇒ The "Save As" dialog box appears.

5. Name the file and specify where it should be saved.
6. Press the [Save] button.

⇒ The technical information is downloaded.




# 4.11 Setting Job Features

After the job sequence, job menu, and job group settings are performed on the Job Menu, a regular user can use each assigned job menu at login, and process a job.

## 1. Job Sequence Settings

A job sequence is a single operation that pulls together several user operations (e-Mail/Fax/Print/Save) according to the settings on the "Scan Settings" screen.


For example, the operation of sending scanned data by e-mail and then saving it in a folder can be set as a single job sequence.



## 2. Job Menu Settings

A job menu is a menu arrangement of the job sequences set by the user.


For example, you can assign a job sequence that sends scan data by e-mail and then saves it in a folder as a button, and set it on a "Job Menu".



### 3. Job Group Settings


A job group is a group of users assigned with the same job menu, by the administrator. Users associated with a group can use its job menu. All users who are not included in any job group belong to a default group.

For example, job menu A is assigned to group A, and job menu D is assigned to the default group. User C is included in group A, therefore can use job menu A. Users not included in a job group are able to use job menu D.



### 4.11.1 Job Setting Quick User Guide

The procedure for an administrator to set up job is shown below.



---

## Processing a job

Process the job.

When a user logs in, the assigned job menu is displayed, and a job can be selected and processed.

Before processing a job set on the Central Admin Console "Job Mode Settings" screen, the job mode settings set on the "Job Mode Settings" screen must be released.

For details, refer to ["6.14 Processing a Job" \(page 413\)](#).

### 4.11.2 Setting a Job Sequence



Set the scan options and job item (e-Mail/Fax/Print/Save) to be processed together as a job sequence.


Up to 1,000 job sequences can be set.

#### ■ Adding a job sequence

This section describes how to add a job sequence.

1. Select the [Job Sequences] tab.

⇒ The "Jobs List" window appears.



2. Select the [New] button.

⇒ The "Job Details" window appears.


3. Set the [Job Name] and [Comment].

Enter a job name in [Job Name]. This may be up to 64 characters long.

Enter comments about the job sequence in [Comment]. This may be up to 256 characters long.



- Select the [▶] button to the left of [Common Settings], and set the operations for when a job is processed.



- **Message Screen**

Set whether or not to display the actual "Message Screen" when a job is processed.

For details about the "Message Screen", refer to ["6.14.1 Enabling/Disabling the Message Screen" \(page 417\)](#).

Enter a title and message text for the message shown on the "Message Screen".

"Title" may be up to 24 characters long.

"Message" may be up to 256 characters long.



The layout of the message displayed in the message screen settings, and the actual "Message Screen" layout in the scanner may differ. Check the layout in the scanner and then enter the title and message in the "Message Screen".



- Whether or not the title and message set in "Message Screen" are shown depends on whether the [Message Screen] button on the "Job Menu" screen is [On] or [Off].
- If a title or message is not set in "Message Screen", even if the [Message Screen] button on the "Job Menu" is set to [On], the actual "Message Screen" is not displayed.



- **Common File Name**

Select the [Allow per-Job adjustment] checkbox to make it possible to change the file name when scanned data is sent by e-mail or saved in a folder, when processing a job.

Set a file name format when scanned data is sent with e-mail/saved in a folder.



Press the [Name Format] button to specify a file name on the "File Names (Common)" screen.

"Sub-folders" is enabled only when scanned data is saved to a folder.

For details about setting values, refer to ["4.6.9 Setting a File Name Format for When Saving Scanned Data" \(page 72\)](#).

4

- Check the Scan Count

When the number of sheets to be scanned for a job is fixed, set whether to check that the expected amount of sheets has been scanned.

- If [Yes] is selected

The number of scanned sheets is checked while a job is being processed.

- For "Expected Count", enter the expected number of sheets to be scanned, between 1 and 999.



- If a "Print" job item is included, the expected number of sheets to be scanned becomes 1 to 100.
      - For "Print", up to 100 pages can be scanned. For other than "Print", up to 999 pages can be scanned. For duplex scanning, make sure to set the number of pages so as not to exceed these respective maximums.

- Select the [Allow per-Job adjustment] checkbox to make it possible to change the expected count of sheets to be scanned on the "Scan Count" screen, according to each job.
        - Select the [Confirm the Scan Count] checkbox to have the actual and expected sheet counts displayed on the "Scan Count" screen after scanning is complete.
- If [No] is selected
 

The number of scanned sheets is not checked while a job is being processed.

- If error occurs
  - If an error occurs while an item in the job sequence is being performed, set whether or not to continue with unfinished items before ending a job.
    - If [Proceed to next Job Item] is selected
      - If an error occurs while an item in the job sequence is being performed, job processing proceeds to the next item in the sequence and completes all unfinished items before ending a job.
    - If [Terminate the Job] is selected
      - If an error occurs while an item in the job sequence is being performed, job processing ends without completing any unfinished items.
- When Job finishes
  - Set whether to notify of a completion when all operations of a job finish successfully.
    - If [Pause on Job Progress screen] is selected
      - When the job finishes successfully, the "Job Progress" screen is shown to notify that the job is completed.
    - If [Close the Job Progress screen] is selected
      - Returns to the Job Menu when the job finishes successfully.

5. Select the [▶] button to the left of [Scan Settings].

Set the desired scan options, such as Carrier Sheet, color mode, and paper size.

For details about setting values, refer to "6.9 Setting the Scan Options" (page 365).

The screenshot shows the 'Scan Settings' window with the following configurations:

- Save:**
  - File Format:  PDF,  TIFF,  MTIFF,  JPEG
  - Searchable PDF: No
  - Text Recognition Language: English
  - Require PDF Password:  No,  Yes
  - Compression: Medium
- Basic:**
  - Carrier Sheet:  Off,  A3,  B4,  11" x 17"
  - Color Mode:  Auto,  RGB Color,  Grayscale,  Black & White
  - Paper Size: Auto
  - Resolution:  150dpi,  200dpi,  300dpi,  600dpi
  - Scan Mode:  Simplex,  Duplex
- Quality:**
  - Brightness: Medium
  - Contrast: Medium
  - Sharpness: None
  - Dropout Color: None
  - Background Removal: Medium
- Advanced:**
  - Blank Page Skip:  Off,  Auto
  - Page Orientation:  Long Edge,  Short Edge
  - Multifeed Setup:  None,  Length,  Ultrasonic,  Both
  - Edge Cropping:  Off,  On



## 6. Set a job item.

Select the list button under [Job Items] to select one of following items:

- e-Mail
- Fax
- Print
- Save

When the [Delete This Item] button is clicked, a confirmation window appears. Click the [OK] button to delete the item.

When the [Insert New Item] button is selected, the item selected in the list of items is inserted before the current item.



Up to ten items can be set.

7. If [e-Mail] is selected for the job item in [Step 6](#), perform settings related to sending e-mail.

For details about setting values, refer to ["6.4 Sending the Scanned Data by e-Mail"](#) (page 314).

If the [e-Mail address of user] option button is selected for [To] and/or [From], when a job is processed, the e-mail address of the logged in user is specified. However, in the following cases, an error will occur during the job process.

- If the currently logged in user does not have an e-mail address
- If the currently logged in user is using the guest account



Select the [Browse] button to set a different e-mail address from the "LDAP List" window.

	User Name	e-Mail Address
<input type="checkbox"/>		
<input type="checkbox"/>		
<input type="checkbox"/>		
<input type="checkbox"/>		
<input type="checkbox"/>		
<input type="checkbox"/>		
<input type="checkbox"/>		
<input type="checkbox"/>		

Settings entered in the following screen are shown.

- For Admin Tool  
"e-Mail LDAP Server" screen
  - For Central Admin Console  
"LDAP Server" section on the "Central Admin Server Settings" screen
- However, whether or not SSL is used, depends on each LDAP server settings.
- For more details about how to filter the LDAP List, refer to ["Filtering the LDAP List" \(page 199\)](#).



Press the [Name Format] button, and specify a file name from the "File Names (e-Mail)" screen.

File Names (e-Mail)

[Scanner Name]MMdyyyyhmmss Preview

Name Format

When e-mailing data, using the following naming elements

Prefix

Scanner Name

User Name

Date

Time

Common Formatting

Date Format: MMdyyyy


Delimiter: None

OK Cancel

For details about setting values, refer to ["4.6.10 Setting a File Name Format for When Attaching Scanned Data to e-Mail"](#) (page 76).

8. If [Fax] is selected for the job item in [Step 6](#), perform settings related to sending a fax. For details about setting values, refer to ["6.5 Sending the Scanned Data by Fax" \(page 330\)](#). If the [e-Mail address of user] option button is selected for "Notification To (Sender's e-Mail Address)", the e-mail address of the logged in user is used when a job sequence is performed. However, in the following cases, an error will occur when a job sequence is performed.


- If the currently logged in user does not have an e-mail address
- If logged in with the guest account


 **HINT** Select the [Browse] button to set a different e-mail address from the "LDAP List" window.


Settings entered in the following screen are shown.

- For Admin Tool  
"e-Mail LDAP Server" screen
  - For Central Admin Console  
"LDAP Server" section on the "Central Admin Server Settings" screen
- However, whether or not SSL is used, depends on each LDAP server settings.
- For more details about how to filter the LDAP List, refer to ["Filtering the LDAP List" \(page 199\)](#).

9. If [Print] is selected for the job item in **Step 6**, perform settings related to printing. For details about setting values, refer to **"6.6 Printing the Scanned Data"** (page 339).



HINT  Select the [Browse] button to set the network printer from the "Printer List" window.



Printer Alias▲	Network Path
<b>FUJITSUX.2(Black&amp;White)</b>	<b>\\DOMAIN01.SERVER\FUJITSUX.2(Black&amp;White)</b>
FUJITSUX.2(Duplex A4)	\\DOMAIN01.SERVER\FUJITSUX.2(Duplex A4)
FUJITSUX.2(RGB Color)	\\DOMAIN01.SERVER\FUJITSUX.2(RGB Color)
Printer01	\\DOMAIN01.SERVER\FUJITSUX2
Printer02	\\DOMAIN01.SERVER\FUJITSUX



10. If [Save] is selected for the job item in [Step 6](#), perform settings related to saving. For details about setting values other than those for a "Save process results file", refer to ["6.7 Saving the Scanned Data to a Network Folder"](#) (page 352).

- Save process results file

When a job to save scanned data in a folder is processed, set whether to output the job process result (process results file) to the same folder as the scanned data.

- If [Yes] is selected

A process results file is also output when scanned data is saved.

The file name of the process result that is output, is the file name of the saved scanned data (including the extension), with ".xml" added to change it to that format.

For example, if the file name of the saved scanned data is "abc.pdf", it becomes "abc.pdf.xml".

If multiple TIFF or JPEG files are saved, a sequence number is added after the file name.

Example: abc-0001.tif.xml, abc-0001.jpg.xml



- If a process results file with the same name already exists, set whether to overwrite the process results file in the [Overwrite Same Name Files] option button.
- It may not be possible to output a process results file if scanning fails, according to the cause of the failure.
- When a process results file is output for the saving multiple TIFF or JPEG format files case, it is assigned the name of the first output file with ".xml" appended, and all of the TIFF or JPEG output file names are recorded in the process results file's "FileName" field.



- If [No] is selected

A process results file is not output when scanned data is saved.

Process results files are formatted as follows:

- Process results files are in an XML format.
- Process results files use the UTF-8 charset.
- Process results files contain the following output:

Item	Value
ResultFileVersion	V1.0
ScannerName	Scanner name
User	User name
Date	Save completion date
Time	Save completion time
Result	Save process results
ResultCode	Result code
Result Description	Result details
Pages	Number of saved pages
SheetCount_Job	Number of sheets to be scanned, set by the job
SheetCount_User	Number of sheets to be scanned, set by the user
SheetCount_Scan	Actual number of scanned sheets
FileName	Saved file name(s) (Multiple files)
Path	Saved file path name



- Select the [Browse] button to set the network folder from the "Folder List" window.

Folder Alias	Network Path
Folder01	\\DOMAIN01\SERVER\Folder01
Folder02	\\DOMAIN01\SERVER\Folder
Folder03	\\DOMAIN01\SERVER\Catalog
Folder04	\\DOMAIN01\SERVER\Letter
Folder05	\\DOMAIN01\SERVER\Photo

- Select the [Name Format] button to set the file name from the "File Names (Save)" window.

Sub-folders

Create sub-folders as necessary, using the following naming elements

Scanner Name

User Name

Date

Name Format

Save data, using the following naming elements

Prefix

Scanner Name

User Name

Date

Time

Sequence Number Minimum digits 3

Common Formatting

Date Format MMdyyyy

Delimiter None

For more details about settings values, refer to ["4.6.9 Setting a File Name Format for When Saving Scanned Data"](#) (page 72).

11. Select the [OK] button.

⇒ A job sequence is added to the "Jobs List" window.



## ■ Cloning a job sequence

This section describes how to clone a job sequence.

1. Select the [Job Sequences] tab.
  - ⇒ The "Jobs List" window appears.
2. Select the job sequence to be cloned.
3. Select the [Clone] button.
  - ⇒ The "Job Details" window appears.
4. Clone the detailed job sequence settings.
5. Select the [OK] button.
  - ⇒ A job sequence is added to the "Jobs List" window.

## ■ Editing a job sequence

This section describes how to edit a job sequence.

1. Select the [Job Sequences] tab.
  - ⇒ The "Jobs List" window appears.
2. Select the job sequence to be edited.
3. Select the [Edit] button.
  - ⇒ The "Job Details" window appears.
4. Edit the detailed job sequence settings.
5. Select the [OK] button.
  - ⇒ The settings of the job sequence are changed.

---

## ■ Deleting a job sequence

This section describes how to delete a job sequence.

1. Select the [Job Sequences] tab.
  - ⇒ The "Jobs List" window appears.
2. Select the job sequence to be deleted.
3. Select the [Delete] button.
  - ⇒ The confirmation window appears.
4. Select the [OK] button.
  - ⇒ The job sequence is deleted.

## ■ Filtering job sequences

This section describes how to filter job sequences.

1. Select the [Job Sequences] tab.
  - ⇒ The "Jobs List" window appears.
2. Enter [Job Name] and [Comment].
  - Enter either a part of or full [Job Name] and [Comment] for the job sequence(s) to be filtered.
  - "Job Name" may be up to 64 characters long.
  - "Comment" may be up to 256 characters long.
3. Select the [Find] button.
  - ⇒ The filtered results appear.



To display all results, delete all information for [Job Name] and [Comment], and then select the [Find] button.

## ■ Filtering the LDAP List

This section describes how to filter the LDAP List on the "LDAP List" window.

1. In the [User Name] drop-down list box, select the display format for the user names shown on the user name/e-mail address list.
2. Enter the LDAP server and character string to be used for LDAP searches in the "Search Base" field.  
The LDAP entries under the character string entered here will become the search target.  
This may be up to 520 characters long.
3. In the [Search Position] drop-down list box, select the filtering method.  
The default setting is [Head (abc...)].




Search Position	Description	Example Target	Search Result
Head (abc...)	Filtered by words that start with the character string entered in <a href="#">Step 4</a> .	abc	abc, abc1, abcd, ...
Anywhere (...abc...)	Filtered by words that include the character string entered in <a href="#">Step 4</a> .	abc	abc, abc1, xabc, xabcy, ...
Tail (...abc)	Filtered by words that end with the character string entered in <a href="#">Step 4</a> .	abc	abc, 1abc, xabc, ...


4. Enter the filter character string.  
Enter the user name and e-mail address to be filtered, in whole or in part.  
Up to 256 characters may be entered for both user names and e-mail addresses.  
If both a user name and e-mail address is entered, data containing either of them are searched as "AND Search".

5. Select the filter target.

If multiple items are selected, data containing any of the search words are searched as "OR Search".

- The "Server Type" of the login LDAP server is [Active Directory] or [Active Directory Global Catalog]

Checkbox name	Filter target in the Active Directory/Active Directory Global Catalog
First Name	<p>Filters the first names of users registered in the LDAP server.</p> 
Last Name	<p>Filters the last names of users registered in the LDAP server.</p> 
Common Name	<p>Filters the common names of users registered in the LDAP server.</p>  <p>This item can be set in [Active Directory Users and Computers]. The [Common Name] checkbox must be selected to filter the Active Directory group names.</p>

Checkbox name	Filter target in the Active Directory/Active Directory Global Catalog
Display Name	<p>Filters the display names of users registered in the LDAP server.</p> 


- The "Server Type" of the login LDAP server is [Other LDAP Server]

Checkbox name	Filter target in the LDAP server
First Name	Filters on the first names of users as such are defined by the "First Name" field in the "Adjust the search item schema" screen from the "e-Mail LDAP Server" screen.
Last Name	Filters on the last names of users as such are defined by the "Last Name" field in the "Adjust the search item schema" screen from the "e-Mail LDAP Server" screen.
Common Name	Filters on the common names of users as such are defined by the "Common Name" field in the "Adjust the search item schema" screen from the "e-Mail LDAP Server" screen.
Display Name	Filters on the display names of users as such are defined by the "Display Name" field in the "Adjust the search item schema" screen from the "e-Mail LDAP Server" screen.

---

6. Select the [Find] button.

⇒ The filtered results appear.



- If the [Find] button is selected, an authentication screen appears. Perform the following procedure for authentication.
  1. Enter a user name and password.  
User names may be up to 129 characters long.  
Passwords may be up to 256 characters long (case sensitive).

Connecting to the LDAP server. Enter a User Name and Password.

User Name

Password

OK Cancel

2. Select the [OK] button.
- To display all results, delete all filter strings and then select the [Find] button.



**4.11.3 Setting a Job Menu** Admin Tool Central Admin


Assign the job sequence set in "4.11.2 Setting a Job Sequence" (page 185) to a job button, and job buttons on a job menu.

Up to 100 job menus may be set.


**■ Adding a job menu**

This section describes how to add a job menu.


1. Select the [Job Menus] tab.
  - ⇒ The "Job Menus List" window appears.



2. Select the [New] button.
  - ⇒ The "Job Menu Layout" area becomes active.



3. Enter the job menu name.  
This may be up to 64 characters long.
4. Select the job button position, and select the [Edit] button.  
⇒ The "Job Button Settings" window appears.




5. Enter the job button name.  
This may be up to 32 characters long.
6. In the [Select Button Pixmap] drop-down list box, select a job button pixmap.  
The selected job button pixmap is inserted into the job button mockup image on the right, allowing the resulting button design to be checked.
7. Set whether to start up the Add-in module.  
To start up the Add-in module when the job button is selected, select the [Use button to start Add-in module] checkbox.  
If this checkbox is selected, the Add-in module is assigned to the job button, rather than the job sequence. The "Job Button Name" and "Select Button Pixmap" are ignored. The button specified by the Add-in module appears in the Job Menu.



Even if the checkbox is selected, if the Add-in module is not installed in a scanner, the target job menu button will not be shown on the screen.




8. Select a job from the list.

 To filter jobs, enter part of a "Job Name" and "Comment", or select all, and press the [Find] button.  
"Job Name" may be up to 64 characters long.  
"Comment" may be up to 256 characters long.  
To clear all filtered results, delete the entered "Job Name" and "Comment", and press the [Find] button.

9. Select the [OK] button.

⇒ A job button is set on the "Job Menu Layout" area.

10. Repeat [Step 4](#) through [Step 9](#) as required for the number of job buttons.




- Up to six job buttons can be set.
- To delete a job button, select the job button that you want to delete and press the [Delete] button.

11. Change the position of the job buttons as necessary.

Select the job button to move, and then select either the [Up] button or the [Down] button to move it.

The relationship between the order of job buttons on the "Job Menu Layout" area and the arrangement of buttons on the "Job Menu" is shown below.



12. In the Message Screen list, set whether to show a [Message Screen] button on the "Job Menu" screen.

- If [Decide per-Job] is selected  
The [Message Screen] button on the "Job Menu" screen is enabled, and it is possible to select whether or not to show the message screen when a job is processed according to each job.
- If [Always display] is selected  
The [Message Screen] button on the "Job Menu" screen is disabled, and the message screen is displayed when a job is processed.
- If [Never display] is selected  
The [Message Screen] button on the "Job Menu" screen is disabled, and the message screen is not displayed when a job is processed.

13. In the Scan Viewer list, set whether to show the [Scan Viewer] button on the "Job Menu" screen.
  - If [Decide per-Job] is selected  
The [Scan Viewer] button on the "Job Menu" screen is enabled, and it is possible to select whether or not to show the "Scan Viewer" when scanning, according to each job.
  - If [Always display] is selected  
The [Scan Viewer] button on the "Job Menu" screen is disabled, and the "Scan Viewer" is shown when scanning.
  - If [Never display] is selected  
The [Scan Viewer] button on the "Job Menu" screen is disabled, and the "Scan Viewer" is not shown when scanning.
14. Select the [OK] button.
  - ⇒ A job menu is added to the "Job Menus List" window.

---

## ■ Cloning a job menu

This section describes how to clone a job menu.

1. Select the [Job Menus] tab.
  - ⇒ The "Job Menus List" window appears.
2. Select the job menu to be cloned.
3. Select the [Clone] button.
  - ⇒ The "Job Menu Layout" area becomes active.
4. Clone the detailed job menu settings.
5. Select the [OK] button.
  - ⇒ A job menu is added to the "Job Menus List" window.

## ■ Editing a job menu

This section describes how to edit a job menu.

1. Select the [Job Menus] tab.
  - ⇒ The "Job Menus List" window appears.
2. Select the job menu to be edited.
3. Select the [Edit] button.
  - ⇒ The "Job Menu Layout" area becomes active.
4. Edit the detailed job menu settings.
5. Select the [OK] button.
  - ⇒ The details of the job menu are changed.

## ■ Deleting a job menu

This section describes how to delete a job menu.

1. Select the [Job Menus] tab.
  - ⇒ The "Job Menus List" window appears.
2. Select the job menu to be deleted.
3. Select the [Delete] button.
  - ⇒ The confirmation window appears.
4. Select the [OK] button.
  - ⇒ The job menu is deleted.

## ■ Viewing the detailed settings for a job menu

This section describes how to view the detailed settings for a job menu.

1. Select the [Job Menus] tab.
  - ⇒ The "Job Menus List" window appears.
2. Select the job menu to view.
  - ⇒ The details for the selected job menu appears in the "Job Menu Layout" area.



The information for the selected job menu shown in the "Job Menu Layout" area cannot be edited. To edit this information, select the [Edit] button.



2. Select the [New] button.
  - ⇒ The "Settings For Selected Group(s)" area become active.

The screenshot shows the 'Job Groups' configuration interface. On the left, the 'Job Groups List' table has one row: 'Default Group' with a 'Last Modified' time of '12:58:39 PM'. The 'Settings For Selected Group(s)' panel on the right is active. It contains a text input for 'Job Group Name', a section 'Assign the following Job Menu' with a dropdown and a 'Select...' button, a section 'Modes Available To User' with radio buttons for 'Both Job & Multi-Function' (selected), 'Job Only', and 'Multi-Function Menu', and a section 'Group Member Settings' with 'Number of Members: 0' and an 'Edit' button, and a checkbox for 'Include guest account as a member'. 'OK' and 'Cancel' buttons are at the bottom.

3. Enter the job group name.
  - This may be up to 64 characters long.
4. Select the [Select] button.
  - ⇒ The "Select Job Menu" window appears.

The screenshot shows the 'Select Job Menu' dialog box. It features a table with two columns: 'Job Menu Name' and 'Last Modified'. The table contains two rows: 'Job MenuA' with a last modified time of '9:30:17 AM' (highlighted in orange) and 'Job MenuD' with a last modified time of '9:31:33 AM'. 'OK' and 'Cancel' buttons are located at the bottom of the dialog.

5. Select a job menu.
6. Select the [OK] button.
  - ⇒ A job menu is set on the "Settings For Selected Group(s)" area.

7. Set the whether or not to show the Multi-Function Main Menu after login.
  - If [Both Job & Multi-Function] is selected  
The menu to appear first after a regular user login can be set on the "Initial Post-Login Menu".

- If the [Multi-Function Menu] option button is selected  
The Multi-Function Main Menu appears first after a regular user login.
- If the [Job Menu] option button is selected  
The Job Menu appears first after a regular user login.

The user can use both the Multi-Function Main Menu (refer to "3.2 Required Scanner Function Settings" (page33)) and Job Menu (refer to "4.11.3 Setting a Job Menu" (page203)) by pressing the [Menu Mode] button.

- If [Job Only] is selected

The Multi-function Main Menu is not shown. The Job Menu always appears after a regular user login.

The user cannot switch between the Multi-Function Main Menu and Job Menu by pressing the [Menu Mode] button.



If the same one user is included in multiple job groups, the "Modes Available To User" settings of the group that appears first in the list on the "Job Groups List" window are used. For example, if a user belongs to the 3rd and 5th groups in the list, the settings for the 3rd group will be used. Therefore, specify the same "Modes Available To User" settings for all groups.

8. Select the [Edit] button.

⇒ The "Group Member Settings" window appears.

9. Select the member name format.

The "Member Name" of the "Group Membership List" or "LDAP List" is shown, according to the format selected in [Member Name Format].



10. Enter the LDAP server and character string to be used for LDAP searches in the "Search Base" field.

The LDAP entries under the character string entered here will become the search target.

This may be up to 520 characters long.

Settings entered in the following screen are shown.

- For Admin Tool  
"Login LDAP Server" screen
- For Central Admin Console  
"LDAP Server" section on the "Central Admin Server Settings" screen

However, whether or not SSL is used, depends on each LDAP server settings.

11. Select the checkbox of a user name or Active Directory group to be added to a job group from the LDAP List.



- To view detailed information about a logged in user or Active Directory group, select the "Member Name" or "Domain Name" link.

- To select the checkboxes for all users and Active Directory groups, press the [Select All] button.  
To clear the checkboxes for all users and Active Directory groups, press the [Deselect All] button.
- To filter the LDAP List, refer to ["Filtering the LDAP List" \(page 218\)](#) for more details.

---

12. Select the [ <<< ] button.

⇒ The user or Active Directory group is added to the in the Group Membership List. Users or Active Directory groups added to the Group Membership List are grayed on the LDAP list.



- Up to 1,000 users or Active Directory groups can be registered as job group members.
- To delete a user or Active Directory group registered in the Group Membership List, select the checkbox for the user or Active Directory group to be deleted, and then select the [ >>> ] button. Users or Active Directory groups deleted from the Group Membership List are returned to the LDAP List.
- To filter job group members, enter the "Member Name" and "Domain Name" in part or in full, and then select the [Find] button.  
If "User Principle Name" is selected for the member name format, the "Member Name" may be up to 1024 characters long.  
If "SAM Account Name" is selected for the member name format, the "Member Name" may be up to 20 characters long.  
"Domain Name" may be up to 256 characters long.  
To display all results, clear both "Member Name" and "Domain Name" fields under the Filter Conditions, and then select the [Find] button.
- If the login LDAP server type is changed, all job group members of the old server type are automatically deleted the next time the group members are edited.

13. Select the [OK] button.

⇒ The number of members registered as job group members is shown in "Number of Members" on the "Settings For Selected Group(s)" window.

14. To include the guest account as a job group member, select the [Include guest account as a member] checkbox.

15. Select the [OK] button.

⇒ A job group is added to the "Job Groups List" window.

## ■ Editing a job group

This section describes how to edit a job group.

1. Select the [Job Groups] tab.
  - ⇒ The "Job Groups List" window appears.
2. Select the checkbox for the job group to be edited.
3. Select the [Edit] button.
  - ⇒ The "Settings For Selected Group(s)" input fields become active.
4. Change the detailed job group settings.
5. Select the [OK] button.
  - ⇒ The details of the job group are changed.

## ■ Deleting a job group

This section describes how to delete a job group.

1. Select the [Job Groups] tab.
  - ⇒ The "Job Groups List" window appears.
2. Select the job group to be deleted.
3. Select the [Delete] button.
  - ⇒ The confirmation window appears.
4. Select the [OK] button.
  - ⇒ The job group is deleted

## ■ Viewing the detailed settings for a job group

This section describes how to view the detailed settings for a job group.

1. Select the [Job Groups] tab.

⇒ The "Job Groups List" window appears.

2. Select the job group to view.

⇒ The details for the selected job menu appears in the "Settings For Selected Group(s)" area.



The information for the selected job group shown on the "Settings For Selected Group(s)" screen cannot be edited. To edit this information, select the [Edit] button.



## ■ Assigning job menus to users not included in a job group

Users who are not included in any job group automatically belong to a Default Group. This section describes how to assign job menus to those users.


1. Select the [Job Groups] tab.

⇒ The "Job Groups List" window appears.

2. Select the "Default Group" option button.

3. Press the [Edit] button.

⇒ The "Settings For Selected Group(s)" area becomes active.



4. Select the [Select] button.

⇒ The "Select Job Menu" window appears.

5. Select a job menu.

6. Select the [OK] button.

⇒ A job menu is set on the "Settings For Selected Group(s)" area.

7. Set whether or not to display the "Multi-Function Main Menu".

- If [Both Job & Multi-Function] is selected

The menu to appear first after a regular user login can be set on the "Initial Post-Login Menu".

- If the [Multi-Function Menu] option button is selected

The Multi-Function Main Menu appears first after a regular user login.

- If the [Job Menu] option button is selected

The Job Menu appears first after a regular user login.

The user can use both the Multi-Function Main Menu (refer to ["3.2 Required Scanner Function Settings" \(page33\)](#)) and Job Menu (refer to ["4.11.3 Setting a Job Menu" \(page203\)](#)) by pressing the [Menu Mode] button.

- If [Job Only] is selected

The Multi-function Main Menu is not shown. The Job Menu always appears after a regular user login.

The user cannot switch between the Multi-Function Main Menu and Job Menu by pressing the [Menu Mode] button.

8. Select the [OK] button.

⇒ A job menu is assigned to users who are not included in a job group.

## ■ Filtering the LDAP List

This section describes how to filter the LDAP List on the "Job Group Member Settings" screen.

1. In the [Search Position] drop-down list box on the "LDAP List" window, select the filtering method.

The default setting is [Head (abc...)].

Search Position	Description	Example Target	Search Result
Head (abc...)	Filtered by words that start with the character string entered in <a href="#">Step 2</a> .	abc	abc, abc1, abcd, ...
Anywhere (...abc...)	Filtered by words that include the character string entered in <a href="#">Step 2</a> .	abc	abc, abc1, xabc, xabcy, ...
Tail (...abc)	Filtered by words that end with the character string entered in <a href="#">Step 2</a> .	abc	abc, labc, xabc, ...


2. Enter the filter character string.





Enter the filter target, in whole or in part.  
This may be up to 256 characters long.

3. Select the filter target.


If multiple items are selected, data containing any of the search words are searched as "OR Search".

- The "Server Type" of the login LDAP server is [Active Directory] or [Active Directory Global Catalog]

Checkbox name	Filter target in the Active Directory/Active Directory Global Catalog
User Principal Name	Filters the user principal names registered in the LDAP server. 

Checkbox name	Filter target in the Active Directory/Active Directory Global Catalog
<p>SAM Account Name</p>	<p>Filters the SAM account names of users registered in the LDAP server.</p> 
<p>Last Name</p>	<p>Filters the last names of users registered in the LDAP server.</p> 
<p>First Name</p>	<p>Filters the first names of users registered in the LDAP server.</p> 
<p>Common Name</p>	<p>Filters the common names of users registered in the LDAP server.</p>  <p>This item can be set in [Active Directory Users and Computers]. The [Common Name] checkbox must be selected to filter the Active Directory group names.</p>



Checkbox name	Filter target in the Active Directory/Active Directory Global Catalog
Display Name	<p>Filters the display names of users registered in the LDAP server.</p> 

- If the "Server Type" of the login LDAP server is [Other LDAP Server]

Checkbox name	Filter target in the LDAP server
cn	Filters users on the "cn" attribute.
uid	Filters users on the "uid" attribute.
First Name	Filters on the first names of users as such are defined by the "First Name" field in the "Adjust the search item schema" screen from the "e-Mail LDAP Server" screen.
Last Name	Filters on the last names of users as such are defined by the "Last Name" field in the "Adjust the search item schema" screen from the "e-Mail LDAP Server" screen.
Common Name	Filters on the common names of users as such are defined by the "Common Name" field in the "Adjust the search item schema" screen from the "e-Mail LDAP Server" screen.
Display Name	Filters on the display names of users as such are defined by the "Display Name" field in the "Adjust the search item schema" screen from the "e-Mail LDAP Server" screen.



## 4. Select the [Find] button.

⇒ The filtered results appear.



- If the login LDAP server type is [Active Directory] or [Active Directory Global Catalog], when the [Find] button is pressed, a confirmation window appears.

Perform the following procedure for authentication.

1. Enter a user name and password.

User names may be up to 129 characters long.

Passwords may be up to 256 characters long (case sensitive).

2. Select the [OK] button.
- To display all results, delete all filter strings and then select the [Find] button.
  - When there is a large number of filtered results on the "LDAP List" window, or a large number registered job group members (1000 at maximum), it may take several seconds until the [Group Member Settings] window appears. This can be resolved by performing the following.
    - Add a filter condition(s)
    - Reduce the "Maximum Results" specified on the "e-Mail LDAP Server" screen
    - Divide job groups
    - Specify an Active Directory group



# Chapter 5

## Administrator Operations (Central Admin Console)

Admin

This chapter explains system setting and control of this scanner performed using the Central Admin Console.

Messages may appear while performing operations described in this chapter. For more details about these messages and actions to take, refer to ["E.1.2 System Log Messages"](#) (page 516).

<b>5.1 Function List.....</b>	<b>224</b>
<b>5.2 Using Central Admin Console Window.....</b>	<b>227</b>
<b>5.3 Central Admin Console Quick Guide .....</b>	<b>229</b>
<b>5.4 Pre-settings for Using Central Admin Console.....</b>	<b>231</b>
<b>5.5 Central Admin Server Login: via the Central Admin Console .....</b>	<b>241</b>
<b>5.6 Setting the Central Admin Server.....</b>	<b>244</b>
<b>5.7 Setting Scanner Configuration .....</b>	<b>254</b>
<b>5.8 Monitoring and Maintaining the iScanner Network .....</b>	<b>263</b>
<b>5.9 Updating the System .....</b>	<b>266</b>
<b>5.10 Installing an Add-in.....</b>	<b>268</b>
<b>5.11 Updating the Scanner System Settings .....</b>	<b>271</b>
<b>5.12 Setting the Job Mode.....</b>	<b>275</b>
<b>5.13 Viewing the Update Status Lists.....</b>	<b>278</b>
<b>5.14 Viewing the Scanners Operating Status .....</b>	<b>281</b>
<b>5.15 Viewing Event Log .....</b>	<b>284</b>
<b>5.16 Collecting and Exporting Audit Logs.....</b>	<b>286</b>
<b>5.17 Maintaining Central Admin Settings .....</b>	<b>291</b>



## 5.1 Function List

The functions that can be used in the Central Admin Console are as follows.

Function	Used to...	See...
Scanner Configuration Management	<p>View information for each scanner in the Central Admin Console. Also you can export the information in CSV format by using the export function.</p> <ul style="list-style-type: none"> <li>● Edit Scanner Configuration Settings for the configuration of scanners can be added, edited and deleted in the Central Admin Console. Files can also be imported or exported in CSV format.</li> <li>● fi Network Scanner Admin Tool [Start] An Admin Tool of a specified scanner can be started up from the Central Admin Console.</li> </ul>	<p><a href="#">"5.7 Setting Scanner Configuration" (page 254)</a></p>
Software Update	<p>Update modules for scanner system/security/installed options. Add-ins can be pre-defined in the Central Admin Server, and applied to multiple scanners.</p> <ul style="list-style-type: none"> <li>● Update Call Pre-defined system update modules and Add-ins can be applied to multiple scanners at once.</li> <li>● Scanner Notification Schedule A time zone for an update can be specified.</li> </ul>	<p><a href="#">"5.6 Setting the Central Admin Server" (page 244)</a></p>
		<p><a href="#">"5.7 Setting Scanner Configuration" (page 254)</a></p>
		<p><a href="#">"5.8 Monitoring and Maintaining the iScanner Network" (page 263)</a></p>
		<p><a href="#">"5.9 Updating the System" (page 266)</a></p>
		<p><a href="#">"5.10 Installing an Add-in" (page 268)</a></p>
		<p><a href="#">"5.13 Viewing the Update Status Lists" (page 278)</a></p>

Function	Used to...	See...
Scanner Settings Update	<p>Create scanner settings in the Central Admin Server, and upload/release them to multiple scanners.</p> <p>The contents of the scanner settings can be changed per settings group.</p> <ul style="list-style-type: none"> <li>●Update Call Scanner settings can be applied to multiple scanners at once.</li> </ul>	"5.8 Monitoring and Maintaining the iScanner Network" (page 263)
		"5.11 Updating the Scanner System Settings" (page 271)
		"5.13 Viewing the Update Status Lists" (page 278)
Automatic Update	<p>Automatically update scanner systems, security, installed options, scanner settings, and Add-ins, on the date specified on the scanner side. Updates can be performed on a specified date even in an environment where update calls or Wake-On-LAN cannot be used, because the scanner is automatically resumed and updated even when in standby mode.</p>	"4.7.3 Setting a Central Admin Server" (page 90)
		"5.11 Updating the Scanner System Settings" (page 271)
Status Monitoring	<p>Monitor the error status, operating status, and consumable part status for each scanner.</p> <ul style="list-style-type: none"> <li>●Normalcy Monitoring Monitoring of scanner errors can be performed in the Central Admin Server. Errors can be notified of to the Central Admin Console. If an error occurs, a notification e-mail can be sent to the administrator.</li> <li>●Operating Status Monitoring The power status and login status of each scanner can be displayed in the Central Admin Console.</li> <li>●Consumables Monitoring When a consumable part needs to be replaced in the near future, a notification can be displayed in the Central Admin Console.</li> </ul>	"5.6 Setting the Central Admin Server" (page 244)
		"5.7 Setting Scanner Configuration" (page 254)
		"5.14 Viewing the Scanners Operating Status" (page 281)

Function	Used to...	See...
Job Mode Settings	Share jobs between multiple scanners. Job mode settings can be created and edited in the Central Admin Console.	<a href="#">"5.12 Setting the Job Mode" (page 275)</a>
User Data Roaming	Share user information such as the e-mail address book and scan settings between scanners.	<a href="#">"4.7.3 Setting a Central Admin Server" (page 90)</a>
		<a href="#">"5.6 Setting the Central Admin Server" (page 244)</a>
Audit Log Collection	Collect the scanner system and user logs in the Central Admin Server, so that each operation performed by a scanner can be inspected.	<a href="#">"5.6 Setting the Central Admin Server" (page 244)</a>
	Collected logs can be exported using the audit log export command, and output to an arbitrary folder.	<a href="#">"5.16 Collecting and Exporting Audit Logs" (page 286)</a>


## 5.2 Using Central Admin Console Window

The main windows of the Central Admin Console are as follows.

- "Scanner Admin Operations" window
- "Scanner Operation Monitor" window
- "Scanner Config List" window
- "Event Log" window

You can set the "Scanner Admin Operations" window or "Scanner Operation Monitor" window as the Main screen to be displayed after a Central Admin Console login.

This section describes the buttons and links displayed on the Central Admin Console window.




Button/Link	Shown in manual as...	Used to ...
	[Exit] button	Exit the Central Admin Console.
	[Disconnect] button	Disconnect the connection to the Central Admin Server.
	[About] button	Show the version of the Central Admin Console.

Button/Link	Shown in manual as...	Used to ...
<a href="#">[Central Admin Server Settings]</a>	[Central Admin Server Settings] link	Access the "Central Admin Server Settings" window. For details, refer to <a href="#">"5.6 Setting the Central Admin Server"</a> (page 244).
	[Admin Operations] button	Show the "Scanner Admin Operations" window. For details, refer to <a href="#">"5.8 Monitoring and Maintaining the iScanner Network"</a> (page 263).
	[Operation Monitor] button	Show the "Scanner Operation Monitor" window. For details, refer to <a href="#">"5.14 Viewing the Scanners Operating Status"</a> (page 281).
	[Config List] button	Show the "Scanner Config List" window. For details, refer to <a href="#">"5.7 Setting Scanner Configuration"</a> (page 254).
	[Event Log] button	Show the "Event Log" window. For details, refer to <a href="#">"5.15 Viewing Event Log"</a> (page 284).




## 5.3 Central Admin Console Quick Guide


Administrator operations for management using the Central Admin Console are as follows.




For more details, refer to ["5.4 Pre-settings for Using Central Admin Console"](#) (page 231).



For more details, refer to ["5.5 Central Admin Server Login: via the Central Admin Console"](#) (page 241).



For more details, refer to ["5.6 Setting the Central Admin Server"](#) (page 244).



For more details, refer to ["5.7 Setting Scanner Configuration"](#) (page 254)

---

## Scanner settings / management

- [Monitoring and Maintaining the iScanner Network](#)
- [Updating the System](#)
- [Installing an Add-in](#)
- [Updating the Scanner System Settings](#)
- [Setting the Job Mode](#)
- [Viewing the Update Status Lists](#)



## Monitoring

- [Viewing the Scanners Operating Status](#)
- [Viewing Event Log](#)
- [Collecting and Exporting Audit Logs](#)



## Maintaining

For more details, refer to the following.

- ["5.8 Monitoring and Maintaining the iScanner Network" \(page 263\)](#)
- ["5.9 Updating the System" \(page 266\)](#)
- ["5.10 Installing an Add-in" \(page 268\)](#)
- ["5.11 Updating the Scanner System Settings" \(page 271\)](#)
- ["5.12 Setting the Job Mode" \(page 275\)](#)
- ["5.13 Viewing the Update Status Lists" \(page 278\)](#)

For more details, refer to the following.

- ["5.14 Viewing the Scanners Operating Status" \(page 281\)](#)
- ["5.15 Viewing Event Log" \(page 284\)](#)
- ["5.16 Collecting and Exporting Audit Logs" \(page 286\)](#)

For more details, refer to ["5.17 Maintaining Central Admin Settings" \(page 291\)](#).


## 5.4 Pre-settings for Using Central Admin Console

This section explains the required pre-settings for using the Central Admin Console.

### 5.4.1 Installing the Central Admin Server Software


Install the Central Admin Server software in a computer.  
The following describes the required settings for scanner.

1. Perform [Step 1 to Step 3 of "Installing the Admin Tool" \(page 47\)](#).  
⇒ The download screen appears.
2. Press the [Next] button for the iScanner Central Admin Server.



⇒ The iScanner Central Admin Server download screen appears.

3. Press the [Download] button.



- Downloading is not possible while a scanner operation is in process.
- Do not close the Web browser or logout until installation is complete.
- The required 700MB of free disk includes 200MB which is required to install SQL Server 2005 Express Edition.

⇒ Follow the wizard instructions displayed on the window.

The following port number and protocol settings will be required. Enter the same port number and protocol settings as used for the pre-settings.

- Port number for scanner communication
- Port number for Central Admin Console communication

After installation, the port number and protocol settings can be changed on the Central Admin Console "Central Admin Server Settings" screen.

⇒ After installation is complete, restart the computer.



- If the Central Admin Server software is already installed, skip to ["5.4.2 Installing the Central Admin Console" \(page 236\)](#).
- When installing the Central Admin Server over an older version of the software, all of the old Central Admin system settings should be automatically reused. However, as a precaution, it is still recommended that the old settings be backed up before proceeding with the upgrade installation. To back up the Central Admin settings, refer to ["5.17.1 Backing Up Central Admin Settings" \(page 291\)](#).
- Make sure that the Central Admin Server date and time values are set correctly. If the date/time difference between the values set in the server and actual values is large, normal operation may not be possible.
- After the Central Admin Server software is installed, a Windows user account (Account name: iSCentralAdmin) is added. This user is required for Central Admin, therefore, do not change or delete the account.



- For details of the operating environment when installing the Central Admin Server software, refer to ["1.4.3 Requirements for Central Admin Server" \(page 14\)](#).
- When installing the Central Admin Server software, the same necessary pre-settings before logging in with the Admin Tool are required. For more details, refer to ["4.4 Setting up for Administrator Access via the Admin Tool" \(page 44\)](#).
- To install the Central Admin Server software on Windows Server 2008, login as an administrator. Do not install with Administrators group rights.
- If the following error message appears, installation was not successful.
 

An installation package for the product Microsoft SQL Server Native Client cannot be found. Try the installation agent using a valid copy of the installation package 'sqlncli.msi'.

In this case, uninstall "SQL Server Native Client". Then, try installing the Central Admin Server software again.
- If the installation process fails and the following error message appears, stop the IIS service and re-start manually. Then, re-install the Central Admin Server software.
 

The installation process was canceled because the system was busy. Try restarting the Installation Wizard again later.
- If the following error message appears in Windows Server 2008, check that IIS Management Console is installed. If IIS Management Console is not installed, select and install IIS Management Console in "Role Services".
 

Installation requires that the IIS Management Console be installed.

Refer to the manual for details.

To select the role services for IIS, point to [Administrative Tools] - [Server Manager], select Web Server (IIS) in "Roles Summary".



- In order to use HTTPS for communication to a scanner, or computer installed with Central Admin Console software, a self-signed certificate is automatically imported on the Central Admin Server. However, it is recommended that a formal certificate is installed manually. For more details, refer to ["Importing the Certificate" \(page 235\)](#).
- If an interruption or error occurs during the installation or uninstallation process, the following software components may be installed.
  - AMMANAGER instance of Microsoft SQL Server 2005
  - Microsoft SQL Server Native Client
  - Microsoft SQL Server Setup Support Files
  - Microsoft SQL Server VSS Writer
  - MSXML 6.0 Parser

In this case, uninstall the software components described above.

For more details about uninstalling software components, the following is a description of the process using Windows Server 2003 as an example.

To uninstall a software component, select [Control Panel] - [Add or Remove Programs].

To uninstall "Microsoft SQL Server 2005 AMMANAGER instance", point to "Add or Remove Programs", select "Microsoft SQL Server 2005" and press the [Remove] button. Select the [Remove SQL Server 2005 instance components] checkbox, select "AMMANAGER: Database Engine" under "Select all instance", and press the [Next] button. From here on after, follow the instructions on the wizard displayed on the screen. For programs other than "Microsoft SQL Server 2005 AMMANAGER instance", deletion is not necessary as they are used by other applications.

- If the following changes are to be made after the Central Admin Server software has been installed, uninstall the Central Admin Server software, and re-install after making the changes.
  - If the Central Admin Server is to be used as the Active Directory domain controller
  - If the domain controller role assignment is to be deleted

## ■ Importing the Certificate

This section uses Windows Server 2003 as an example.

1. To startup IIS Manager, on the [Start] menu, point to [Administrative Tools], and select [Internet Information Services (IIS) Manager].
2. Show the web sites for importing the certificate.
 

Certificates are be imported to the following Web sites:

  - AmConsole
  - AmService
3. Right-click the Web site and select "Properties".
4. On the [Directory Security] tab, select "Server Certificate" in the "Secure communications" frame.
  - ⇒ The [Welcome to the Web Server Certificate Wizard] appears.
  - ⇒ Follow the wizard instructions displayed on the window.



For Windows Server 2008, set the fingerprint for the imported certificate in the CertHash.xml file.

The CertHash.xml installation path is as follows.

```
Central_Admin_Server_installation_folder\AmManager\Sys\CertHash.xml
```

An example for setting the fingerprint for the certificate "cc ce a0 66 e3 9c 9b 2a 65 45 03 a3 c4 f4 e5 e6 ad ec df 9f" is as follows.


```
<?xml version="1.0" encoding="utf-8" ?>
<IISPolicy>
  <CertHash>cc ce a0 66 e3 9c 9b 2a 65 45 03 a3 c4 f4 e5 e6
ad ec df 9f</CertHash>
</IISPolicy>
```

---

## 5.4.2 Installing the Central Admin Console

Install the Central Admin Console in a computer.


1. Perform [Step 1](#) to [Step 3](#) of "Installing the Admin Tool" (page 47).  
⇒ The download screen appears.
2. Press the [Next] button for the iScanner Central Admin Console.



⇒ The iScanner Central Admin Console download screen appears.



3. Press the [Download] button.



- Downloading is not possible while a scanner operation is in process.
- Do not close the Web browser or logout until installation is complete.



⇒ Follow the wizard instructions displayed on the window.

When "Installation complete" is displayed, the installation is complete. Press the [Close] button.

⇒ After installation is completed, log out from fi-6010N on the Web browser and close the Web browser.

⇒ After installation, the Central Admin Console can be started by selecting the [Start] menu - [All Programs] - [iScanner Central Admin] - [iScanner Central Admin Console].



- The Admin Tool must be installed before installing the Central Admin Console. For more details about how to install the Admin Tool, refer to ["4.4.3 Installing the Admin Tool" \(page 47\)](#).
- If the Central Admin Console is already installed, skip to ["5.4.3 Setting up a Firewall for the Central Admin Server" \(page 239\)](#).
- From the Web browser [Tools] menu, select [Internet Options], and note the following points about the settings shown on the [Internet Options] dialogbox.
  - In the [Accessibility] dialog box shown when selecting the [Accessibility] button on the [General] tab, do not change the formatting and user style sheet settings. If these settings are changed, the displayed style of the Central Admin Console may be corrupted.
  - In the [Language Preference] dialog box shown when selecting the [Languages] button on the [General] tab, move the same language as for the Central Admin Server operation system to the top. If a different language is specified, a problem may occur with the input or displays for the Central Admin Console.
  - On the [Security] tab, if "Security level for this zone" is set to "High", part of the Admin Tool screen may not be correctly displayed. In this case, on the [Security] tab, add the scanner or Central Admin Server to the trusted site zone and select the [Default Level] button. Or select the [Custom Level] button and set [Binary and script behaviors] to "Enable".
  - On the [Advanced] tab, select the "Play animations in webpages" checkbox under "Multimedia". In Windows Server 2003 or Windows Server 2008, this checkbox is not selected by default.
- When the font size is large, part of the dialog box may not be shown correctly. In this case, use a smaller font size.



- For details of the operating environment when installing the Central Admin Console, refer to ["1.4.2 Requirements for Central Admin Console" \(page 13\)](#).
- When installing the Central Admin Console, the same necessary pre-settings before logging in with the Admin Tool are required. For more details, refer to ["4.4 Setting up for Administrator Access via the Admin Tool" \(page 44\)](#).

### 5.4.3 Setting up a Firewall for the Central Admin Server

This section describes how firewall settings for the Central Admin Server.

Set the following port number for communication in the Central Admin Server, to enable management by the Central Admin Console.

From/To	Protocol	Port Number
Scanner ⇒ Central Admin Server	HTTP/ HTTPS (TCP)	Port number set for scanner communication
Central Admin Console ⇒ Central Admin Server	HTTP/ HTTPS (TCP)	Port number set for Central Admin communication

For details about setting a firewall, refer to the manual for the relevant firewall.

### 5.4.4 Configuring the Scanner Settings for Central Admin Management

This section describes the scanner settings environment.

The following settings for connecting a scanner to the Central Admin Server are required to enable management by the Central Admin Console.

- "Admin Network" screen from the "Network Settings" tab  
For more details, refer to ["4.7.2 Setting the Admin Network" \(page 88\)](#).
- "Central Admin Server" screen from the "Network Settings" tab  
For more details, refer to ["4.7.3 Setting a Central Admin Server" \(page 90\)](#).

---

## 5.4.5 Uninstalling the Central Admin Server Software/Console

This section describes how to uninstall the Central Admin Server Software/Console. Refer to this section if uninstallation is required.

### ■ Uninstalling the Central Admin Server Software

This section uses Windows Server 2008 as an example.

Uninstall Central Admin Server software from [Control Panel] - [Programs] - [Programs and Features] in the computer in which it is installed.



- Before starting uninstallation, disconnect the Central Admin Server from the network.  
If the uninstallation process is completed while the Central Admin Server is connected to the network, normal operation cannot be guaranteed.
- All files in the installation folder are deleted when the Central Admin Server software is uninstalled. Back up the information related to Central Admin as required. For details, refer to ["5.17.1 Backing Up Central Admin Settings" \(page 291\)](#).
- If the following message appears while uninstalling the Central Admin Server software, press the [Retry] button. Even if the same message appears again, re-start the Central Admin Server, and uninstall it again.  
`Another application has exclusive access to the file ASPNETDB.MDF.Please shut down all other applications, then click Retry.`



### ■ Uninstalling the Central Admin Console

This section uses Windows Vista as an example.

Uninstall the Central Admin Console from [Control Panel] - [Programs] - [Programs and Features] in the computer in which it is installed.



- Before starting uninstallation, close the Central Admin Console.  
If the uninstallation process is completed while the Central Admin Console is in operation, normal operation cannot be guaranteed.
- Even if uninstalled, data will remain. Delete this data if it is not required.  
For Windows XP, data is saved in the following way.  
`C:\Documents and Settings\User_name  
\Local Settings\Application Data\FUJITSU  
\iScannerCentralAdminConsoxxx`  
The character string shown in italics is variable.  
*User\_name* can be the name of any Central Admin Console user.






1. Select the [Start] menu - [All Programs] - [iScanner Central Admin] - [iScanner Central Admin Console].

⇒ The Central Admin Console starts.

2. Set the "Connect to" field.

Enter the Central Admin Server IP address, host name, or FQDN.




- If the port number was changed in "[5.6 Setting the Central Admin Server](#)" ([page 244](#)), enter the port number changed for Port Number.
- To use SSL, select the [Use HTTPS] checkbox.
- If Central Admin Console is started while there is insufficient free memory, a script error may occur. Try again after ensuring that there is enough free memory.
- For Windows Server 2003 and Windows Server 2008, when first connecting to the Central Admin Server, a confirmation screen for whether or not to add the specified URL to the trusted site zone may appear. In this case, after adding the Central Admin Server URL as a trusted site, close the Central Admin Console once, and re-open.

3. Press the [Connect] button.


⇒ The Central Admin Console login screen appears.

4. Enter a "User Name" and "Password".  
 Enter "admin" for the user name.  
 Passwords must be between 7 and 127 alphanumeric characters long (case sensitive).



Central Admin Server Software Version

5. Select the [Login] button.  
 ⇒ If the user is authenticated, the Central Admin Console main window appears.  
 The main window shown after login can be changed.  
 For details, refer to "5.6 Setting the Central Admin Server" (page 244).



## 5.6 Setting the Central Admin Server

Operating environment for the Central Admin Server is set up by changing the administrator password and setting network and LDAP server.

The central admin server settings can be set from the "Central Admin Server Settings" window.

To open the "Central Admin Server Settings" window, select the [Central Admin Server Settings] link in the Central Admin Console main window.

**Central Admin Server Settings**

Change Administrator Password    User Roaming Data (Select & Clear)

Scanner Registration  
 Automatically add new scanners to the Central Admin configuration when they are discovered.

Network Connection  
 Use HTTPS to communicate with the Central Admin Console  
**Central Admin Console Port Number** 10444  
 Use HTTPS to communicate with scanners  
**Scanner Communication Port Number** 20444  
**Maximum Connections** 10

Wake-On-LAN  
**Port Number** 443  
**# Tries** 3  
**Interval** 1 sec

Screen Settings  
**Default Screen** Admin Operations  
**Screen Refresh Interval** 60 sec

LDAP Server  
 Enable LDAP searches  
**LDAP Server Type** Active Directory  
 Use SSL     Certificate Only, CA not validated  
**LDAP Server** (IP address, hostname, or FQDN)  
**Port Number** 389  
**LDAP Server Authentication**  
**Authorized User (DN)** (eg. cn=root, dc=example, dc=com)  
**Password**  
\* Anonymous user connection will be attempted if an Authorized User (DN) is not entered.  
**Login User Attributes** uid  
**Search Base (DN)** (eg. cn=Users, dc=example, dc=com)  
**Maximum Results** 1000  
**Search Timeout** 60 sec  
**Schema** Adjust

SharePoint Server Connection Settings  
 Use a proxy server for SharePoint server connections  
**Proxy Server** (IP address, hostname, or FQDN)  
**Proxy Server Port Number** 80  
**Exceptions**  
Use semi-colons (;) to separate entries  
**iScanner Shared Folder Service Port Number** 30444

Software Update Time-Period Restrictions  
 Always allow     Never allow     Only allow in the following time period  
Start 00 Hour 00 Min    End 00 Hour 00 Min

Operation Monitor  
 Check Operating Status  
**Operating Status Icon Labels** Scanner Name

Error Notification Settings  
 Send error notification e-mails  
**SMTP Server** (IP address, hostname, or FQDN)  
**SMTP Server Port Number** 25  
**Recipient e-Mail Address**  
**Sender e-Mail Address**    Test

Data Import/Export  
**CSV File Charset** Shift\_JIS

Log Retention  
**Keep records for** 30 days

Audit Log Settings  
 Collect Audit Logs  
**Save for** 30 days

OK    Cancel



## ■ [Change Administrator Password] button

This opens the "Change Administrator Password" window to change the administrator password.

- **Current Password**  
Enter the current password.
- **New Password/Confirm New Password**  
Password must be between 7 and 127 characters long (case sensitive). Blank spaces at the start and end will be removed.
- **[Change Password] button**  
Changes the administrator password to the entered password.
- **[Cancel] button**  
Returns to the "Central Admin Server Settings" window without confirming the entered contents.

## ■ [User Roaming Data (Select & Clear)] button

This opens the "User Roaming Data (Select & Clear)" window to delete unnecessary user roaming data.

User Name	Info Last Modified
<input type="checkbox"/> abc@	8:42:42 AM
<input type="checkbox"/> user01@	8:43:11 AM
<input type="checkbox"/> user02@	8:43:40 AM
<input type="checkbox"/> xyz@	8:45:44 AM

- **[Clear All] button**  
Deletes all user roaming data even if filtered.

- 
- Filter Conditions
    - Filters the users displayed in the user list.
    - User Name
      - Enter a part of or entire user name of the scanner to be filtered.
      - This can be up to 64 characters long.
    - [Refresh List] button
      - Refreshes the list by filtering using the entered filtering conditions.
  - [Clear] button
    - Select the checkbox of the user name to be deleted, and select the [Clear] button to delete.
  - [Select All] button
    - Selects all checkboxes in the user list.
  - [Deselect All] button
    - Deselects all checkboxes in the user list.
  - User list
    - Access the user list.
  - [Back] button
    - Returns to the "Central Admin Server Settings" window.

## ■ Scanner Registration

Sets whether to reject registration of a scanner whose configuration information is not set.

- Automatically add new scanners to the Central Admin configuration when they are discovered.
  - Select the checkbox to add a new scanner automatically.
  - If the checkbox is selected, scanner configuration can automatically be added to the Central Admin Server.
  - Scanner configuration information can be set from the "Scanner Config List" window displayed by selecting the [Config List] button in the Central Admin Console main window.

## ■ Network Connection

Sets up the network to communicate with scanners and the Central Admin Console.

- Use HTTPS to communicate with the Central Admin Console
  - Select this checkbox to use HTTPS for Central Admin Console communication.
- Central Admin Console Port Number
  - Enter the port number used to communicate with the Central Admin Console.
  - The default is "10444". Values that can be specified are 80, 443, and within the range 1024 to 65535.
- Use HTTPS to communicate with scanners
  - Select the checkbox to use HTTPS to communicate with scanners. If this checkbox setting is changed, the "SSL" setting on the "Admin Network" screen from the "Network Settings" tab screen must also be changed for all managed scanners.
- Scanner Communication Port Number
  - Enter the port number used to communicate with scanners using HTTP/HTTPS.
  - The default is "20444". The value can be specified within the range of 1 to 65535.

- **Maximum Connections**  
Select the maximum number of scanners that can be connected simultaneously to the Central Admin Server.  
The default is "10".
- **Wake-On-LAN**  
Configures the Wake-On-LAN settings to start the scanner to be controlled from the Central Admin Server.
  - **Port Number**  
Enter the port number to be used to send magic packet for Wake-On-LAN.  
The default is "443". The value can be specified within the range of 1 to 65535.
  - **# Tries**  
Select the number of times magic packet is sent for Wake-On-LAN.  
The default is "3".
  - **Interval**  
Select the interval for sending magic packet for Wake-On-LAN.  
The default is "1" sec.

## ■ Screen Settings

These settings are for the Central Admin Console main windows.

- **Default Screen**  
Select the main window ("Scanner Admin Operations" or "Scanner Operation Monitor" window) to be shown after a Central Admin Console login.
- **Screen Refresh Interval**  
Enter the interval in seconds, in which to automatically refresh the "Scanner Admin Operations" window and "Scanner Operating Monitor" window displays.  
The default is 60 seconds.

## ■ LDAP Server

Configures the LDAP server used for the "Job Mode Settings" window displayed by selecting the [Job Mode Settings] link on the "Scanner Admin Operations" window in the Central Admin Console.

- **Enable LDAP searches**  
Select this checkbox to enable LDAP searches.  
If the checkbox is not selected, the following items cannot be entered.
  - **LDAP Server Type**  
Select the type of the LDAP server to be connected.
  - **Use SSL**  
Select the checkbox to use SSL to communicate with the LDAP server.
  - **Certificate Only, CA not validated**  
Select this checkbox to validate the server certificate but not the certification path (certificate authority).
  - **LDAP Server**  
Enter the LDAP server IP address, host name, or FQDN.  
This may be up to 255 characters long.

- 
- **Port Number**

Enter a port number to be used for communication with the LDAP server. Input a value between 1 and 65535.

The default values are as follows.

    - If the [Use SSL] checkbox is selected

The default value is "636" if [Active Directory] or [Other LDAP Server] is selected.  
The default value is "3269" if [Active Directory Global Catalog] is selected.
    - If the [Use SSL] checkbox is not selected

The default value is "389" if [Active Directory] or [Other LDAP Server] is selected.  
The default value is "3268" if [Active Directory Global Catalog] is selected.
  - **LDAP Server Authentication**

Enter an authorized user name and password when searching for users to be logged in to the LDAP server, only when [Other LDAP Server] is selected for "LDAP Server Type".

    - **Authorized User (DN)**

Alphanumeric characters and symbols can be used for an authorized user name.  
Enter an authorized user name in DN format.  
If left blank, the user is authenticated as an anonymous user.
    - **Password**

Alphanumeric characters (case sensitive) and symbols can be used for a password.  
This may be up to 255 characters long.
  - **Login User Attributes**

Select login user attributes.  
Select whether to search for LDAP server login users by either "uid" or "cn", only when [Other LDAP Server] is selected for the "LDAP Server Type".
  - **Search Base (DN)**

Enter a character string to be used as the LDAP search base.  
LDAP entry under the string entered here is set as the search target.  
This may be up to 255 characters long.
  - **Maximum Results**

Select the maximum number of LDAP search results to be displayed.  
The default is 1000.
  - **Search Timeout**

Select the timeout time of LDAP search.  
The default is 60 sec.

- Schema

If [Other LDAP Server] is selected for "LDAP Server Type", press the [Adjust] button to set the search items for LDAP searches and the LDAP server schema.

When a server type other than [Other LDAP Server] is selected for the "LDAP Server Type", the search item schema cannot be adjusted (the [Adjust] button is disabled).

Press the [Use Defaults] button to reset the input values to default values.

Adjust the search item schema.

First Name <input type="text" value="givenName"/>	Comment <input type="text" value="description"/>
Last Name <input type="text" value="sn"/>	Workplace <input type="text" value="physicalDeliveryOfficeName"/>
Common Name <input type="text" value="cn"/>	Phone Number <input type="text" value="telephoneNumber"/>
Display Name <input type="text" value="displayName"/>	E-mail Address <input type="text" value="mail"/>
Initials <input type="text" value="initials"/>	Homepage <input type="text" value="wWWHomePage"/>

Search Item	Description
First Name	Enter the schema name that is to be associated with the "First Name" search item The default value is "givenName".
Last Name	Enter the schema name that is to be associated with the "Last Name" search item. The default value is "sn".
Common Name	Enter the schema name that is to be associated with the "Common Name" search item. The default value is "cn".
Display Name	Enter the schema name that is to be associated with the "Display Name" search item. The default value is "displayName".
Initials	Enter the schema name that is to be associated with the "Initials" search item. The default value is "initials".
Comment	Enter the schema name that is to be associated with the "Comment" search item. The default value is "description".

Search Item	Description
Workplace	Enter the schema name that is to be associated with the "Workplace" search item. The default value is "physicalDeliveryOfficeName".
Phone Number	Enter the schema name that is to be associated with the "Phone Number" search item. The default value is "telephoneNumber".
E-mail Address	Enter the schema name that is to be associated with the "E-mail Address" search item. The default value is "mail". This search item cannot be skipped.
Homepage	Enter the schema name that is to be associated with the "Homepage" search item. The default value is "wWWHomePage".

## ■ SharePoint Server Connection Settings

These settings are for connecting with SharePoint server when a SharePoint folder is to be used in the scanner system settings.

- Use a proxy server for SharePoint server connections

Select this check box to use a proxy server for SharePoint Server connections.

If this check box is not selected, the following cannot be entered.

- Proxy Server

Enter the IP address, host name, or FQDN for the proxy server to be used.

Up to 255 characters may be entered.

- Proxy Server Port Number

Enter a port number from 1 to 65535, to be used by the scanner to communicate with the proxy server.

- Exceptions

Enter any IP addresses, host names, or FQDN that are to be accessed directly (not via the proxy server).

- Multiple addresses must be separated using semi-colons (";").

- "\*" may be used as a wildcard character.

Up to 2064 characters may be entered.

- iScanner Shared Folder Service Port Number

Enter the port number to be used by the iScanner Shared Folder Service.

The default value is the port number which was specified at the time of installation (the default value at installation is 30444).

The value can be specified within the range of 1024 to 65535.



When Central Admin Server software is installed in the Windows 2000 Server, "SharePoint Server Connection Settings" cannot be set.



When no SharePoint folders are used, stopping the iScanner Shared Folder Service causes no problems.

## ■ Software Update Time-Period Restrictions

Set whether to automatically update the scanner system, security, installed options, and Add-ins using the Central Admin Server.

- Always allow

Always allow updates.

- Never allow

Never allow updates.

- Only allow in the following time period

Only allow updates within a restricted time period. Set the restricted time period with the [Start] and [End] fields.



- When an update is available for both systems (security and installed options included) and Add-ins, if the update of systems is completed outside the specified time-period, update is not run for Add-ins.
- The length of time required for a software update can be estimated as follows:

$$\frac{\text{Update module size} \times \text{No. of target scanners} \times 1.5}{\text{Network throughput}}$$

Example: the following update case should be estimated as:

$$\frac{15 \times 40 \times 1.5}{1} = 900 \text{ seconds (15 minutes)}$$

- Update module size: 15 MB
- Number of scanners: 40
- Network throughput: 8 Mbps = 1 MB/s

---

## ■ Operation Monitoring

Set whether to check the operating status of scanners.

- Check Operating Status  
Select this checkbox to check the operating status of scanners.
- Operating Status Icon Labels  
Select the type of character string to be shown below icons to indicate the scanner status on the "Scanner Operation Monitor" window ([page 281](#)).

## ■ Error Notification Settings

Set whether to send a notification e-mail to the administrator if an error occurs.

A notification e-mail is sent when the "Error" event log occurs.

If an error of the same code occurs more than once continuously within a minute, a notification e-mail is sent only for the first occurrence of the error.

- Send error notification e-mails  
Select this checkbox to send a notification e-mail to the administrator when an error occurs.
- SMTP Server  
Set the IP address of the SMTP server, host name, or FQDN.
- SMTP Server Port Number  
Enter the number of the port to be used for communication between the scanners and SMTP server. Input a value between 1 and 65535.  
The default value is 25.
- Recipient e-Mail Address  
Set the recipient e-mail address for the administrator.
- Sender e-Mail Address  
Set the sender e-mail address.
- [Test] button  
Send a test e-mail to confirm that the e-mail address set in [Recipient e-Mail Address] can receive error notification e-mails correctly.

## ■ Data Import/Export

Set the character code for input/output files.

- CSV File Charset  
Select the charset of CSV files to be used for scanner configuration import/export or event download.

## ■ Log Retention

Sets the number of days to keep the event log.

- Keep records for  
Select the maximum number of days to keep the event log.  
The default is 30 days.



## ■ Audit Log Settings

Set whether to automatically collect scanner system logs and user logs, and save them in the Central Admin Server. The system and user logs collected in the Central Admin Server are collectively referred to as "audit log(s)".

- Collect Audit Logs

Select this checkbox to automatically collect the audit logs and save them in the Central Admin Server.

- Save for

Select the maximum number of days to keep the audit logs.  
The default is 30 days.

## ■ [OK] button

Confirms the entered contents and returns to the Central Admin Console main window.

## ■ [Cancel] button

Returns to the Central Admin Console main window without confirming the entered contents.

## 5.7 Setting Scanner Configuration

Scanner configuration is set by adding, editing and deleting scanner configuration.

Scanner configuration can be set from the "Scanner Config List" window.

The "Scanner Config List" window is displayed by selecting the [Config List] button in the Central Admin Console main window.

Scanner Name	IP Address	Settings Group	Add-in Group	Comment	Status		
<input type="checkbox"/> FI-0072	192.168.0.117-200	Setting1			Free	500	500
<input type="checkbox"/> FI-0200	192.168.0.117-200				Free	1,000	1,000
<input type="checkbox"/> FI-0201	192.168.0.117-200				Free	500	500
<input type="checkbox"/> FI-0202	192.168.0.117-200				Free	1,500	1,500
<input type="checkbox"/> FI-0203	192.168.0.117-200				In use	4,000	4,000
<input type="checkbox"/> FI-0204	192.168.0.117-200				Free	2,500	2,000
<input type="checkbox"/> FI-0205	192.168.0.117-200				Free	35,000	35,000
<input type="checkbox"/> FI-0206	192.168.0.117-200				Free	30,000	30,000
<input type="checkbox"/> FI-0207	192.168.0.117-200				Offline	20,000	20,000
<input type="checkbox"/> FI-0208	192.168.0.117-200				Unknown	0	0
<input type="checkbox"/> FI-0209	192.168.0.117-200				Offline	10,000	10,000

Scanner configuration is information used to identify scanners on the Central Admin Server, when registering configuration information from a scanner to the Central Admin Server.

The registered scanners can be reviewed, and modified by the Central Admin Server functions.

Initially, scanner configuration for each scanner in the scanner group is automatically added. To prevent scanner configuration from automatically being added, clear the [Automatically add new scanners to the Central Admin configuration when they are discovered] checkbox in the "Central Admin Server Settings" window in advance.

Scanner configuration can be registered on the Central Admin Server in the following ways.

- Import from the Central Admin Console "Scanner Config List" window  
Import a defined scanner configuration file, and register scanner configuration for several scanners at once.
- Add directly from the Central Admin Console "Scanner Config List" window  
Add scanner configuration directly from the Central Admin Console "Scanner Config List" window for one scanner at a time.

The following table shows which config items are added/imported to the Central Admin Server from a config file or from a scanner.

Item	Comment	Configuration from file	Configuration from scanner
MAC Address	Scanner MAC address	Yes	Yes
IP Address	Scanner IP address	Yes	Yes
Subnet Mask	Scanner subnet mask	Yes	Yes
Scanner Name	Scanner name	Yes	Yes
Port Number	Scanner port number	Yes	Yes
Use HTTPS?	Whether or not HTTPS is used to communicate with the scanner	Yes	Yes
Model	Scanner model	Yes	Yes
Add-in Group	Group name used to identify applied Add-in install modules	Yes	—
Settings Group	Group name used to identify applied scanner settings	Yes	—
Comment	Note	Yes	—
System Updates	Whether or not the system is to be updated	Yes	—
Info Last Modified	Last date and time scanner configuration was modified	— (*1)	— (*1)
Registered	Whether or not a target scanner is added to the Central Admin Server from the scanner.	— (*1)	— (*1)
Update Status	Indicates the most recent update statuses (System Updates, Add-in Installs, Scanner Settings)	— (*1)	— (*1)
System Version	Scanner system version	—	Yes
Add-in Version	Scanner Add-in install module version	—	Yes
Scanner Settings	Identifies which set of Central Admin Server supplied scanner settings has been applied	—	Yes
Last Inventory Taken	Date and time inventory was last taken	— (*1)	— (*1)


Item	Comment	Configuration from file	Configuration from scanner
Last System Update	Date/time of the last known successful system update	— (*1)	— (*1)
Last Add-in Install	Date/time of the last known successful add-in install	— (*1)	— (*1)
Last Scanner Settings Update	Date/time of the last known successful scanner settings update	— (*1)	— (*1)
Current System Update Status	The current system update status	— (*1)	— (*1)
Current Add-in Install Status	The current add-in installs status	— (*1)	— (*1)
Current Scanner Settings Status	The current scanner settings status	— (*1)	— (*1)
Scanner Version	Scanner firmware version	—	Yes
PAD ASSY (Sheets)	Number of times pad assy has been used	—	Yes
PICK ROLLER (Sheets)	Number of times pick roller has been used	—	Yes
Total Throughput (Sheets)	Total number of scanned sheets	—	Yes
Date of Registration	Date on which scanner was registered	—	Yes
Cumulative On Time (Hours)	Total scanner "On" time, in hours	—	Yes
Last Audit Log Collected	Last date and time audit log was collected	— (*1)	— (*1)
Security Update Version	Security update version	—	Yes
Error Status	Whether or not an error occurred in the scanner	—	—
Operating Status	Scanner operating status	—	Yes
Installed Options	A list of installed options	—	Yes

(\*1): Automatically set from the Central Admin Sever.

## ■ [Import Config] button

This button opens the "Import Scanner Config" window to allow the import of pre-created scanner configuration data from a file. Such a scanner configuration file may contain data for several scanners, all of whose configurations are then changed at once.

Details of the importable data (settings) allowed in a scanner configuration file are given in ["B.2.1 Scanner Configuration File Format \(for Importing\)" \(page 489\)](#). Note that only those settings detailed as being importable may be imported.



- **Scanner Config File**

Select the [Browse] button and specify the scanner configuration file to be imported.

- **[Import] button**

Imports the entered scanner configuration file and returns to the "Scanner Config List" window.



- Importing a scanner configuration file that contains zero scanner entries will cause all of the existing scanner configuration information to be deleted.
- The imported scanner configuration file overwrites the current scanner configuration.
- If the imported scanner configuration information contains the same MAC address or scanner name as in the existing scanner configuration information, the MAC address or the scanner name will be recognized as already existing. This is determined in the order of MAC address, scanner name. In this case, on the table shown in ["5.7 Setting Scanner Configuration" \(page 254\)](#), items in the "Configuration from file" column marked "Yes" are replaced, and those marked with "—" are left as they are.
- If the same MAC address or scanner name does not exist, the imported scanner configuration information will be added.



- **[Cancel] button**

Returns to the "Scanner Config List" window without confirming the entered contents.

---

## ■ [Export Config] button

Shows the "Save As" window to specify a file to export scanner configuration.

A screen to confirm whether or not to export the scanner configuration will be displayed directly after the [Export Config] button is selected.

- [Include detailed scanner information] checkbox

Select this checkbox to output all scanner information.

- [Add configuration item titles] checkbox

Select this checkbox to add item titles to the first column of the scanners configuration file.

For details on the format of the scanner configuration file to be exported, refer to "[B.2.1 Scanner Configuration File Format \(for Importing\)](#)" (page 489).

## ■ Filter Conditions

Filters the scanners displayed in the scanner list.

- Scanner Name

Enter a part of or entire scanner name of the scanner to be filtered.

This may be up to 15 characters long.

- IP Address

Enter a part of or entire IP address of the scanner to be filtered.

This may be up to 15 characters long.

- Settings Group

Select the settings group of the scanner to be filtered.

The default is "(All)".

- Add-in Group

Select the Add-in group of the scanner to be filtered.

The default is "(All)".

- Comment

Enter a part of or entire comment on the scanner to be filtered.

This may be up to 64 characters long. Line-feed cannot be used.

- Status

Select the operating status of the scanner to be filtered.

The default is "(All)".

- [Refresh List] button

Refreshes the list by filtering using the entered filtering conditions.

## ■ [New] button

The button displays the "Edit Scanner Details" window to add scanner configuration information.

- **Scanner Name (Required)**
  - Enter the scanner name.
  - This may be up to 15 characters long. Alphanumerical characters and hyphens may be used. Scanner names cannot consist of numerical characters only.
  - A hyphen cannot be used as the first character of a scanner name.
- **IP Address**
  - Enter the numeric IP address.
  - This may be up to 15 characters long. Numbers and periods (.) may be used.
- **MAC Address**
  - Enter the MAC address of the scanner.
  - This may be up to 17 characters long. Alphanumeric characters and colons (:) may be used.
- **Settings Group**
  - Enter the settings group of the scanner. Press the list button to select a settings group name from the currently used settings groups.
  - This group name is used to identify the settings contents of a group.
  - The settings group name entered here is displayed on the "Scanner Settings" window, Settings Groups.
  - This may be up to 32 characters long.
  - The following character strings cannot be used:  
(Default) (All) \_\_default\_\_ \_\_all\_\_
  - "\_\_" is two underbars entered one after another.
- **Add-in Group**
  - Enter the Add-in group of the scanner. Press the list button to select an Add-in group name from the currently used Add-in groups.
  - This group name is used to identify an Add-in module.
  - The Add-in name entered here is displayed on the "Add-in Installs" window, Add-in Groups.
  - This may be up to 32 characters long.
  - The following character strings cannot be used:  
(Default) (All) \_\_default\_\_ \_\_all\_\_
  - "\_\_" is two underbars entered one after another.
- **System Updates**
  - Select the checkbox to not update the system.

- **Comment**  
Enter the comments on the scanner.  
This may be up to 256 characters long.
- **[OK] Button**  
Adds the entered scanner configuration information and returns to the "Scanner Config List" window.
- **[Cancel] button**  
Returns to the "Scanner Config List" window without confirming the entered contents.

### ■ **[Clone] button**

Select the checkbox of the scanner to be cloned and select the [Clone] button to display the "Edit Scanner Details" window to clone the scanner configuration information.

### ■ **[Edit] button**

Select the checkbox of the scanner to be edited and select the [Edit] button to display the "Edit Scanner Details" window to edit the information.

### ■ **[Delete] button**

Deletes a scanner from the scanner network.

Select the checkbox(es) of the scanner(s) to be deleted, and select the [Delete] button to delete.



- Deleting the scanner configuration does not exclude a scanner from Central Admin management. Therefore, the Central Admin Server setting in the scanner will not be "Unregistered". To exclude a scanner from Central Admin management, select "Central Admin" to [Off] in the scanner.
- To exclude multiple scanners from Central Admin management at one time, release a new set of scanner settings to target scanners.
- To include the scanner in the iScanner Network again, re-register the scanner on the Central Admin Server.



### ■ **[Select All] button**

Selects all checkboxes in the scanner list.

### ■ **[Deselect All] button**

Deselects all checkboxes in the scanner list.



## Scanner information list

Shows the scanner information list.

- Scanner name link

Shows the "Scanner Details" window to view the scanner information details.

**Scanner Details**

Back Clear Error Status Event Log fi Network Scanner Admin Tool [Start]

Networking Info

Scanner Name	FI-HUM0UERP4AOQ
Model	fi-6010N
IP Address	192.168.1.100
Port Number	80
Use HTTPS?	No
MAC Address	08:00:20:08:00:20
Comment	
Info Last Modified	2012/08/08 10:00:00

Software Status

System Updates	Apply
Current System Update Status	NotTarget
System Version	1.0.0.0
Scanner Version	1.0.0.0
Installed Options	1.0.0.0
Last System Update	
Add-in Group	
Current Add-in Install Status	NotTarget
Add-in Version	
Last Add-in Install	
Settings Group	
Current Scanner Settings Status	NotTarget
Last Scanner Settings Update	

Hardware Status

Operating Status	Free
Error Status	No
Last Inventory Taken	2012/08/08 10:00:00
Total Throughput (Sheets)	4,100
PAD ASSY (Sheets)	4,000
PICK ROLLER (Sheets)	4,000
Date of Registration	2012/08/08
Cumulative On Time (Hours)	1
Last Audit Log Collected	

Back

- [Back] button  
Returns to the "Scanner Config List" window.
- [Clear Error Status] button  
Clears error marks when the "Error Status" is indicated as "Yes". When the error marks are cleared, "Yes" changes to "No".
- [Event Log] button  
Displays the "Event Log" screen so that the event of the selected scanner can be checked.
- [fi Network Scanner Admin Tool [Start]] button  
Communicates to the Wake-On-LAN Magic Packet and starts and connects the Admin Tool to a scanner, after the scanner has started up.



- If "Auto Login" is set to [On] on the [System Settings] - "Login Settings" screen, the Admin Tool cannot be started.
- Scanners are identified by their IP addresses. If the scanner information includes multiple scanners with the same IP address, scanners which are not to be targeted may be connected.




If the scanner is not started, using Wake-On-LAN to start the scanner and connect with the Admin Tool will take a few minutes.  
If a "Connection error" occurs, and the screen returns to the screen for specifying a connection, try re-connecting.

## 5.8 Monitoring and Maintaining the iScanner Network

The registration status of scanners, the status of various scanner processes, and the event log can be viewed.

Selecting an [iScanner Updates] link on the "Scanner Admin Operations" window opens another window for a specific management operation such as a system update.

The "Scanner Admin Operations" window is displayed by selecting the [Admin Operations] button in the Central Admin Console main window.



### ■ iScanner Network

Shows the registration status of scanners.

The scanner group managed by the Central Admin Server is called the "iScanner Network".

- # Scanners
  - Shows the total number of scanners.
- # Registered
  - Shows the total number of scanners registered with the Central Admin Server.
- # Unregistered
  - Shows the total number of scanners not registered, according to the scanner configuration defined on the Central Admin Server.
- Consumable Alerts
  - Shows a replacement notification for the following consumables.
    - Pad assy
    - Pick roller

---

## ■ iScanner Updates

Shows the status of various scanner processes.

The following is a description of the displayed items.

- Update Type
  - System Updates
    - Shows the "System Updates" window to register update module, set notifications etc.
    - For details, refer to ["5.9 Updating the System" \(page 266\)](#).
  - Add-in Installs
    - Shows the "Add-in Installs" window to register install module, set notification calls etc.
    - For details, refer to ["5.10 Installing an Add-in" \(page 268\)](#).
  - Scanner Settings
    - Shows the "Scanner Settings" window to register scanner settings, set notification calls etc.
    - For details, refer to ["5.11 Updating the Scanner System Settings" \(page 271\)](#).
  - Job Mode Settings
    - Shows the "Job Mode Settings" window to register jobs, perform settings etc.
    - For details, refer to ["5.12 Setting the Job Mode" \(page 275\)](#).
- Server-Side Data
  - Available
    - Shows available status.
  - Available(\*)
    - Scanners already targeted to receive an update notification call are marked with an asterisk (\*).
  - None
    - Shows unavailable status.
- Scanner-Side Update Status
  - Targeted
    - Shows the number of scanners targeted for updates.
  - Finished
    - Shows the number of scanner which have finished updating.
  - Pending
    - Shows the number of scanners updating/waiting to be updated.
  - Failed
    - Shows the number of scanners which could not be updated.



Access the "Update Status List" window for each of the following update types:

- System Updates
- Add-in Installs
- Scanner Settings

For details, refer to ["5.13 Viewing the Update Status Lists" \(page 278\)](#).

### ■ iScanner Events

Shows latest 100 events in the event log.

- Log for events that occur in the Central Admin Server
- Log for events that occur in a scanner, where "Type" is "Error" or "Warning"

The following is a description of the displayed items.

- Date/Time  
Date and time of event that occurred in the Central Admin Server.
- Origin  
If the originating event occurred in the Central Admin Server, <Server> is shown. If it occurred in a scanner, the scanner name is shown.
- Type  
There are three event log types.
  - Info
  - Error
  - Warning
- Message

## 5.9 Updating the System

The system, security, and installed options can be updated by uploading a new system update module and setting update calls.



The system can be updated according to the time specified on the scanner side. For more details, refer to ["4.7.3 Setting a Central Admin Server" \(page 90\)](#).

The system can be updated from the "System Updates" window.

The "System Updates" window is displayed by selecting the [System Updates] link on the "Scanner Admin Operations" window in the Central Admin Console.

### ■ Registered System Update

- Current Release

Displays the type and version, and the release date of the currently available update module. Selecting the [Cancel] button cancels release of the update module and deletes the module.

### ■ Upload & Release a New System Update

Uploads a new system update module and issues an update call as needed.

The new system update module will be released, and applied to the scanners when one of the following occurs:

- Scanner is started, or resumed from the standby mode
- Scanner is logged out
- Scanner is notified of any update modules
- Scanner has an automatic update scheduled

Updates can be applied to the scanners that are in power-off or standby mode using Wake-On-LAN.

In the following cases, update modules cannot be uploaded.

- The module type is either a system or security option, and the same or upgraded module version has already been registered
- For an installed option update module, the same update module is already uploaded
- System Update Module
  - Select the [Browse] button to specify the update module file.
  - Select the [Upload] button to upload the update module.
- Issue an Update Call
  - Select the checkbox to issue an update call.
  - When the checkbox is selected, even if a scanner is not started or logged in to, the update module is sent and applied to the scanner according to the Scanner Notification Schedule. However, if the update is released while logged in to a scanner, the update will be applied after logged out. If any other available updates are pending, those are also applied at the same time.
- Scanner Notification Schedule
  - Sets the schedule to notify update module.
  - Now
    - Issues a call immediately.
  - Later
    - Specifies the date and time to issue a call.
    - The default value is 00:00 of the following day. The value can be specified within the range between the current time and a month later.
    - The scanner notification schedule uses the Central Admin Server timezone.



When issuing a call, set a time that does not conflict with that set for "Software Update Time-Period Restrictions" on the "Central Admin Server Settings" window.

- [Register] button

Registers the uploaded update module.



When a new system update is available, it will only be installed in a scanner if the new version is higher than the current version. Targeted scanners are restarted after the new system update has been installed.

Pending updates are performed in the following order:

1. System Updates
2. Add-in Installs
3. Scanner Settings

## ■ [Back] button

Returns to the Central Admin Console main window.

## 5.10 Installing an Add-in


An Add-in for scanner can be installed by uploading an Add-in module and setting update calls.



Add-ins can be updated according to the time specified on the scanner side.  
For more details, refer to ["4.7.3 Setting a Central Admin Server"](#) (page 90).

An Add-in can be installed from the "Add-in Installs" window.

The "Add-in Installs" window is displayed by selecting the [Add-in Installs] link on the "Scanner Admin Operations" window in the Central Admin Console.



### ■ Add-in Groups

Displays Add-in groups.

Scanners which are not to be assigned to Add-in groups belong to the "(Default)" group.

Select a group for registering a new Add-in module.

If an Add-in is released, "(Released)" is shown after the Add-in group name.

The default value is "(Default)".

### ■ Registered Add-in Module

- Add-in Group

Displays the Add-in group name selected in the "Add-in Groups" list.

- Current Release

Displays the version and the release date of the currently available Add-in module.

Selecting the [Cancel] button cancels release of the Add-in module and deletes the module.



## ■ Upload & Release a New Add-in

Uploads a new Add-in module and issues an update call as needed.

The new Add-in update module will be released, and applied to the scanners when the one of the following occurs:

- Scanner is started, or resumed from the standby mode
- Scanner is logged out
- Scanner is notified of any update modules
- Scanner has an automatic update scheduled

Updates can be applied to the scanners that are in power-off or standby mode using Wake-On-LAN.

If the Add-in module is already available, the module is replaced. However, if the date of the last modified Add-in module version is the same as, or earlier than the currently available one, the module cannot be uploaded.

- Upload an Add-in Module for the Add-in Group selected above.
  - Select the [Browse] button to specify the install module file.
  - Select the [Upload] button to upload the Add-in module.
- Issue an Update Call
  - Check the checkbox to issue an update call.
  - When the checkbox is selected, even if a scanner is not started or logged in to, the update module is sent and applied to the scanner according to the Scanner Notification Schedule. However, if the update is released while logged in to a scanner, the update will be applied after logged out. If any other available updates are pending, those are also applied at the same time.
- Scanner Notification Schedule
  - Sets the schedule to notify Add-in module.
  - Now
    - Issues a call immediately.
  - Later
    - Specifies the date and time to issue a call.
    - The default value is 00:00 of the following day. The value can be specified within the range between the current time and a month later.
    - Update call schedule uses the Central Admin Server timezone.



When issuing a call, set a time that does not conflict with that set for "Software Update Time-Period Restrictions" on the "Central Admin Server Settings" window.



---

- [Register] button

Registers the uploaded Add-in module to the selected Add-in group.



When a new Add-in module is available, it will only be not installed in a scanner if both the name and version match that of the current Add-in. Scanners are restarted twice when installing a new Add-in, once to uninstall the old Add-in, and once again after the new Add-in has been installed.

Pending updates are performed in the following order:

1. System Updates
2. Add-in Installs
3. Scanner Settings

- [Back] button

Returns to the Central Admin Console main window.

## 5.11 Updating the Scanner System Settings

The scanner settings can be updated by uploading new sets of scanner settings and setting update calls.



The scanner settings can be updated according to the time specified on the scanner side.

For more details, refer to ["4.7.3 Setting a Central Admin Server"](#) (page 90).

The scanner settings can be updated from the "Scanner Settings" window.

The "Scanner Settings" window is displayed by selecting the [Scanner Settings] link on the "Scanner Admin Operations" window in the Central Admin Console.

### ■ Settings Groups

Displays the settings groups.

Scanners which are not to be assigned to settings groups belong to the "(Default)" group.

Select a group for registering a new set of scanner settings.

If scanner settings are released, "(Released)" is shown after the settings group name.

The default value is "(Default)".

---

## ■ Registered Scanner Settings

- Settings Group

Displays the settings group name selected in the "Settings Groups" list.

- Current Release

Displays the release date of the currently available scanner settings.

Selecting the [Cancel] button cancels release of the scanner settings.



If the scanner settings are canceled, checking or changing the settings contents becomes difficult. Also, editing and viewing of the network printers/folders setting contents on the Job Sequence "Job Mode Settings" screen, may not be possible. For more details, refer to ["Create & Release a New Set of Job Mode Settings" \(page 276\)](#).



## ■ Upload & Release a New Set of Scanner Settings

Uploads scanner settings and issues an update call as needed.

The new set of scanner settings will be released, and applied to the scanners when one of the following occurs:

- Scanner is started, or resumed from the standby mode
- Scanner is logged out
- Scanner is notified of any update modules
- Scanner has an automatic update scheduled

Updates can be applied to the scanners that are in power-off or standby mode using Wake-On-LAN. However, if the update is released while logged in to a scanner, the update will be applied after logged out.



If scanner settings are already available, the scanner settings are replaced.

- [Edit Scanner Settings] button

Shows the "Edit Scanner Settings" window to set up the scanner settings.

If scanner settings are available, the available scanner settings values are shown.

If no scanner settings have been released, the default values are shown.



If you return to the Main Menu from the "Scanner Settings" screen without registering the scanner settings, the edited contents will be lost.

5

- [System Settings] tab

The setting items are the same as those set in the system settings menu in the window for administrator operations. For details, refer to ["4.6 Using the System Settings Menus" \(page 56\)](#).

However, the [Import Scanner Settings] button for the "System Settings" menu is only displayed on the Central Admin Console "Edit Scanner Settings" window.

The current configuration of the scanners saved by using the Admin Tool can be sent to the Central Admin Server from the "Import Scanner Settings" screen. The current configuration of the scanners is the information saved in ["Backing up System Settings" \(page 172\)](#).

The current configuration of the scanners can be imported in the following way.

- 1 Specify the scanner configuration file to be imported.  
Select a file using the [Browse] button.
- 2 Press the [Import] button.  
⇒ The current configuration of the scanners is sent to the Central Admin Server.

The imported scanner settings are applied to the scanner according to the Scanner Notification Schedule.

- [Network Settings] tab

The setting items are the same as those set in the network settings menu in the window for administrator operations. For details, refer to ["4.7 Using the Network Settings Menus" \(page 86\)](#).

- 
- [Close] button  
Registers the entered scanner settings and returns to the "Scanner Settings" window.
  - Issue an Update Call  
Select the checkbox to issue an update call.  
When the checkbox is selected, even if a scanner is not started or logged in to, the update module is sent and applied to the scanner according to the Scanner Notification Schedule. However, if the update is released while logged in to a scanner, the update will be applied after logged out. If any other available updates are pending, those are also applied at the same time.
  - Scanner Notification Schedule  
Sets the schedule to notify scanner settings.
    - Now  
Issues a call immediately.
    - Later  
Specifies the date and time to issue a call.  
The default value is 00:00 of the following day. The value can be specified within the range between the current time and a month later.  
The Scanner Notification Schedule uses the Central Admin Server timezone.
  - [Register] button  
Registers the entered scanner settings to the selected settings group.



When a new set of scanner settings is available, first any existing network printer and network folder settings are deleted, then the new scanner settings are written over the old scanner settings.

Once the new scanner settings have been applied, any changes to the settings of individual scanners are retained until the next time a new set of scanner settings becomes available from the Central Admin Server.

Pending updates are performed in the following order:

1. System Updates
2. Add-in Installs
3. Scanner Settings

## ■ [Back] button

Returns to the Central Admin Console main window.

## 5.12 Setting the Job Mode

The job mode can be set by registering a new job mode and setting a release schedule.

The job mode can be set from the "Job Mode Settings" window.

The "Job Mode Settings" window is displayed by selecting the [Job Mode Settings] link on the "Scanner Admin Operations" window in the Central Admin Console.

### ■ Registered Job Mode Settings

- Current Release

Shows the upload date and the release date of the current job mode settings.

Selecting the [Cancel] button cancels release of the job mode settings.

- Scheduled Release

Shows the next scheduled upload date and the release date of the job mode settings.

Selecting the [Cancel] button cancels release schedule of the job mode settings.

Even if available job mode settings are canceled, job mode settings already sent to a scanner will not become invalid. To not use job mode settings in a scanner, on the [Network Settings], "Central Admin Server" screen, set "Job Mode" to "Off".

## ■ Create & Release a New Set of Job Mode Settings


Creates and releases a new set of job mode settings.

After registering a new set of job mode settings, the job mode settings are replaced.

- [Job Mode Settings] button

The button displays the "Job Mode Settings" window to configure job mode settings.

The contents of the last configured job mode settings are shown.



- [Job Sequences] tab

The setting items are the same as those set in the [Job Sequences] tab in the job mode settings menu in the window for administrator operations. For details, refer to ["4.11.2 Setting a Job Sequence" \(page 185\)](#).

To set "Print" or "Save" for a job sequence, a network printer or network folder must be previously added on the "Edit Scanner Settings" screen. The job sequences and "Edit Scanner Settings" screen settings are related in the following way.

- The network printers shown on the "Printer List" window when "Print" is selected as a job item, are the network printers set on the "Edit Scanner Settings" screen.
- The network folders shown on the "Folder List" window when "Save" is selected as a job item, are the network folders set on the "Edit Scanner Settings" screen.

- [Job Menus] tab

The setting items are the same as those set in the [Job Menus] tab in the job mode settings menu in the window for administrator operations. For details, refer to ["4.11.3 Setting a Job Menu" \(page 203\)](#).

- [Job Groups] tab

The setting items are the same as those set in the [Job Groups] tab in the job mode settings menu, in the window for administrator operations. For details, refer to ["4.11.4 Setting a Job Group" \(page 210\)](#).

- [Close] button

Registers the entered job mode settings and returns to the "Job Mode Settings" window.



- **Settings Release Schedule**
  - Sets the schedule to release job mode settings.
  - **Now**
    - Release immediately.
  - **Later**
    - Specifies the date and time to release.
    - The default value is 00:00 of the following day. The value can be specified within the range between the current time and a month later.
    - The Release Schedule uses the Central Admin Server timezone.
- **[Register] button**
  - Registers the entered job mode settings.

### ■ **[Back] button**

Returns to the Central Admin Console main window.

## 5.13 Viewing the Update Status Lists

Status details can be viewed for each of the following update types:

- System Updates
- Add-in Installs
- Scanner Settings

The update status list for each update type can be viewed in the respective "Status Details" window.

This window appears when one of the "Scanner-Side Update Status" - "Targeted" numerical links is selected on the "Scanner Admin Operations" window in the Central Admin Console.

**Update Status List (System Updates)**

Select target scanners and click the [Call Now] button to notify them of a pending update.

Filter Conditions

Scanner Name	IP Address	Settings Group	Add-in Group	Status
<input type="checkbox"/> iScanner0	192.168.0.10	SG01	AG01	Pending
<input type="checkbox"/> iScanner1	192.168.0.11	SG01	AG01	Pending
<input type="checkbox"/> iScanner2	192.168.0.12	SG01	AG01	Pending
<input type="checkbox"/> iScanner3	192.168.0.13	SG02	AG01	Pending
<input type="checkbox"/> iScanner4	192.168.0.14			Pending
<input type="checkbox"/> iScanner5	192.168.0.15			Pending
<input type="checkbox"/> iScanner6	192.168.0.16	SG02	AG02	Pending
<input type="checkbox"/> iScanner7	192.168.0.17		AG02	Pending
<input type="checkbox"/> iScanner8	192.168.0.18		AG02	Pending
<input type="checkbox"/> iScanner9	192.168.0.19	SG01		Pending

\* Click the scanner names to view individual scanner details.  
\* Scanners already targeted to receive an update notification call are marked with an asterisk (\*).

Back

### ■ Filter Conditions

Filters the scanners displayed in the scanner list.

- Scanner Name
  - Enter a part of or entire scanner name of the scanner to be filtered.
  - This may be up to 15 characters long.
- IP Address
  - Enter a part of or entire IP address of the scanner to be filtered.
  - This may be up to 15 characters long.
- Settings Group
  - Select the settings group of the scanner to be filtered.
  - The default is "(All)".
- Add-in Group
  - Select the Add-in group of the scanner to be filtered.
  - The default is "(All)".
- Status
  - Select the update status of the scanner to be filtered.
  - The default is "(All)".
- [Refresh List] button
  - Refreshes the list by filtering using the entered filtering conditions.

## ■ [Call Now] button

Select the checkbox of the scanners to be notified, and select the [Call Now] button to issue a call. If a target scanner is in error status, the error is cleared before notification. The scanner-side status is changed to "Pending", and becomes an update target. All update call targets are "Pending" for "Scanner-Side Status".

## ■ [Clear Update Failures] button

Select the checkbox for the scanner in error status, and press the [Clear Update Failures] button to clear the error. The scanner-side status is changed to "Pending", and becomes an update target.

## ■ [Select All] button

Selects all checkboxes in the scanner list.

## ■ [Deselect All] button

Deselects all checkboxes in the scanner list.

## ■ Scanner list

Shows the list of scanners and their status with respect to the type of Scanner-Side Update selected in the Central Admin Console main window.

- Scanner name link

Opens the "Scanner Details" window to view the scanner details.

For details on the "Scanner Details" window, refer to ["5.7 Setting Scanner Configuration"](#) (page 254).

**Scanner Details**

Back Clear Error Status Event Log fi Network Scanner Admin Tool [Start]

Networking Info

Scanner Name	FI-HUM0UERP4AOQ
Model	fi-6010N
IP Address	192.168.1.100
Port Number	80
Use HTTPS?	No
MAC Address	08:00:20:08:00:20
Comment	
Info Last Modified	2012/08/08 10:00:00

Software Status

System Updates	Apply
Current System Update Status	NotTarget
System Version	1.0.0.0
Scanner Version	1.0.0.0
Installed Options	1.0.0.0
Last System Update	
Add-in Group	
Current Add-in Install Status	NotTarget
Add-in Version	
Last Add-in Install	
Settings Group	
Current Scanner Settings Status	NotTarget
Last Scanner Settings Update	

Hardware Status

Operating Status	Free
Error Status	No
Last Inventory Taken	2012/08/08 10:00:00
Total Throughput (Sheets)	4,100
PAD ASSY (Sheets)	4,000
PICK ROLLER (Sheets)	4,000
Date of Registration	2012/08/08
Cumulative On Time (Hours)	1
Last Audit Log Collected	

Back

---

- Version

The versions shown apply to the type of Scanner-Side Update selected in the Central Admin Console main window.


- **[Back] button**

Returns to the Central Admin Console main window.

## 5.14 Viewing the Scanners Operating Status

The operating status of the scanners can be viewed.



The operating status of the scanners can be viewed on the "Scanner Operation Monitor" window. The "Scanner Operation Monitor" window is displayed by selecting the [Operation Monitor] button in the Central Admin Console main window.



The operating status of a scanner is indicated by the following icons/marks.

Press an icon to show the "Scanner Details" window.

Icon/Mark	Status	Description
	In Use	Shows that the scanner is online, and that a user is logged in.
	Free	Shows that the scanner is online, and that no user is logged in.
	Offline	Shows that scanner power is off, or that the scanner is in standby mode.
	Unreported	Shows that the operating status of the scanner is unknown.
	Unregistered	Shows that the scanner is added to the scanner configuration, and is not added to the Central Admin configuration.

Icon/Mark	Status	Description
	Error	Shown if the following errors occur in a scanner. <ul style="list-style-type: none"> <li>Scanner monitoring error (messages with an error code from 81000001 to 81000012) For details of errors, refer to <a href="#">"E.1.3 Alert Monitor System Log Messages"</a> (page 522).</li> <li>Unexpected error (messages with the error code 81001001 or 81001002) For details of errors, refer to <a href="#">"E.1.2 System Log Messages"</a> (page 516).</li> </ul>
	Consumable Alerts	Shown when a consumable part is near or has reached its replacement time.




Immediately after the Central Admin Server starts up, the operating status of the registered scanners is shown as "Unreported". In this case, the status of each scanner will be updated when one of the following occurs:

- A scanner is logged in/out
- The scanner power is turned on, or it is resumed from standby mode
- The scanner power is turned off, or it is set to standby mode



## ■ Scanner Operating Status


- Online (In use)  
Shows the number of scanners that are currently operating. The number of scanners with logged in users are shown in ( ).
- Offline  
Shows the number of scanners that are currently turned off or in standby mode.
- Unreported  
Shows the number of scanners whose operating status is not reported.
- Consumable Alerts  
Shows the number of scanners whose consumable parts are soon to pass or have passed their rated lifetime already.
- Error  
Shows the number of scanners in which an error has occurred. The error mark () is shown to indicate the scanner with an error.

## ■ Filter Conditions

Filters the scanners displayed in the scanner list.

- Scanner Name
  - Enter a part of or entire scanner name of the scanner to be filtered.
  - This may be up to 15 characters long.
- IP Address
  - Enter a part of or entire IP address of the scanner to be filtered.
  - This may be up to 15 characters long.
- Settings Group
  - Select the settings group of the scanner to be filtered.
  - The default is "(All)".
- Add-in Group
  - Select the Add-in group of the scanner to be filtered.
  - The default is "(All)".
- Comment
  - Enter the description of the scanner to be filtered.
- Status
  - Select the operating status of the scanner to be filtered.
  - The default is "(All)".
- [Apply] button
  - Apply the entered filter conditions and refresh the list.

## ■ [Clear All Errors] Button

Clear all error marks  shown on the "Scanner Operation Monitor" window.

If there are multiple pages of scanner operating status, the status of all error marked scanners are cleared.

## 5.15 Viewing Event Log


Event logs output from the scanners or the Central Admin Server can be viewed.

The latest 100 event log items can be viewed on the "Scanner Admin Operations" window.

- Log for all events that occur on the Central Admin Server
- Log for events that occur in the scanners, where "Type" is "Error" or "Warning"

To view all event logs, check the "Event Log" window.

The "Event Log" window is displayed by selecting the [Event Log] button in the Central Admin Console main window.



### ■ [Download] button

Shows the "Save As" window to specify a file to output event logs.

The default file name is "execlog.csv".

When downloaded to a computer, the file will contain CSV format data. The file is saved in the following form:

```
Date/Time,Origin,Type,Event_ID,"Message"
```

The types are, E: Error, W: Warning, I: Info.

### ■ [Clear Log] button

Clears all event logs.

### ■ Filter Conditions

Filters the events displayed in the event log list.

#### ● Origin

Select the origin of the events to be displayed.

- Server  
Shows the events that occurred in the Central Admin Server.
- Scanner  
Shows the events that occurred in each scanner.




- Type
  - Select the type of the events to be opened.
  - Error
    - Opens the event logs whose type is Error.
  - Warning
    - Opens the event logs whose type is Warning.
  - Info
    - Opens the event logs whose type is Info.
- [Refresh List] button
  - Refreshes the list by filtering using the entered filtering conditions.

## ■ Event Log

Opens the event list.

- Date/Time link
  - Displays the "Event Details" window to view the event details.



- [Back] button
  - Returns to the "Event Log" window.


## 5.16 Collecting and Exporting Audit Logs

Scanner system logs and user logs can be collected and saved in the Central Admin Server. System logs collected in the Central Admin Server are referred to as "audit logs (system)", and user logs as "audit logs (user)". Both types of logs are referred to collectively as "audit logs".

By automatically collecting system logs and user logs in the Central Admin Server, you can record users' past operations.


To view audit logs, export those collected in the Central Admin Server to an arbitrary folder by executing a command.


The status of audit logs collection can be checked in the "Scanner Details" window.



## 5.16.1 Collecting Audit Logs

To automatically collect audit logs in the Central Admin Server, enable the audit log collection in the "Central Admin Server Settings" window. For more details, refer to ["5.6 Setting the Central Admin Server" \(page 244\)](#).

 The audit logs are managed according to the date on which they are collected in the Central Admin Server. Do not change the Central Admin Server date and time setting to a date that has already passed.

 If the audit log is collected, disk space for saving the audit log is required. Refer to the following for estimates of the required disk space.

Under the following conditions, one log per days requires 25 KB.  
Power on/off: once, Login/Logout: 20 times, Number of scan operations: 100.

## 5.16.2 Exporting Audit Logs

To export audit logs collected in the Central Admin Server, execute "AmExportLog.exe" in the command prompt on the computer installed with the Central Admin Server software.

- Command storage location


Under the [\AmManager\Bin] folder in the installation folder of the Central Admin Server software

- Command executable format

```
AmExportLog -d OutputFolder [-v]
```

The italic text represents variable character strings.

To show the status of the process, specify -v.

 An [AuditLogs] folder is created in the specific output folder. In this [Audit-Logs] folder, a folder is created for each date to save audit logs. The date of a folder corresponds to that of when audit logs are collected in the Central Admin Server. Therefore, the date may differ from that on the scanner when the logs are created.

---

- File name format of an output audit log

- Audit log (system)

```
ScannerName_MACAddress_syslog.csv
```

- Audit log (user)

```
ScannerName_MACAddress_usrlog.csv
```

- Return value

- 0  
Succeeded
- Other than 0  
Failed



- Do not execute this command twice at the same time.
- If a file name already exists, the existing file will be overwritten.
- When exported, audit logs are deleted from the Central Admin Server.
- If an error occurs while exporting, the audit logs that have been exported are deleted from the Central Admin Server.



### 5.16.3 File Format of Audit Logs

Audit log files are formatted as follows:

- Audit logs use the UTF-8 charset.
- Audit logs are in a CSV format.
- Audit logs contain the following output:
  - Audit log (system)

This log contains the following output items:

```
"Sequence number","Date","Time","Type","Code","Message"
```

These items are defined as follows:

Log Item	Description
Sequence number	A file sequence number between "1" and "4294967295". This number increments from "1" as files are added, and resets to "0" (indicating an overflow) after "4294967295".
Date	Corresponds to the system log "Date". (*)
Time	Corresponds to the system log "Time". (*)
Type	Corresponds to the system log "Type". (*)
Code	Detailed in <a href="#">"E.1.2 System Log Messages" (page 516)</a> .
Message	Corresponds to the system log "Messages". (*) Also refer to <a href="#">"E.1.2 System Log Messages" (page 516)</a> .

(\*): For details, refer to ["4.9.2 Managing the System Log" \(page 162\)](#).

---

- Audit log (user)

This log contains the following output items:

```
"Sequence number","Date","Time","User","Code",  
"Operation","Result","Pages","Description"
```


These items are defined as follows:

Log Item	Description
Sequence number	A file sequence number between "1" and "4294967295". This number increments from "1" as files are added, and resets to "0" (indicating an overflow) after "4294967295".
Date	Corresponds to the user log "Date". (*)
Time	Corresponds to the user log "Time". (*)
User	Corresponds to the user log "User". (*)
Code	Corresponds to the user log "Code". (*)
Operation	Corresponds to the user log "Operation". (*)
Result	Corresponds to the user log "Result". (*)
Pages	Corresponds to the user log "Pages". (*)
Description	Corresponds to the user log "Description". (*)

(\*): For details, refer to ["4.9.1 Managing the User Log" \(page 159\)](#).

## 5.17 Maintaining Central Admin Settings

Central admin settings set by the administrator can be backed up, restored, and obtained.



### 5.17.1 Backing Up Central Admin Settings

All data managed in the Central Admin Server (excluding audit logs) can be backed up. Central admin settings can be restored using the backup file. Take backups periodically just in case.

To back up central admin settings, execute "AmBackup.exe" in the command prompt on the computer installed Central Admin Server software.

When backing up, the Central Admin Server is in a temporarily suspended state, and connection from the Central Admin Console or uploading/downloading of user roaming data, and release of updates to scanners is not possible. On the "Scanner Operation Monitor" window, the operating status of all scanners is indicated as "Unreported".

- Command storage location

Under the [\AmManager\Bin] folder in the installation folder of the Central Admin Server software

- Command executable format

```
AmBackup.exe BackupFolderName
```

The character string shown in italics is variable.

- Return value
  - 0  
Succeeded
  - other than 0  
Failed



- Specify a folder without files and sub-folders as the backup folder. If the specified backup folder does not exist, it is created.
- Do not change the backup folder structure. If changed, restoration may not be processed correctly.
- Do not change the content of the backup file of central admin settings. If the backup file content is changed and restored, processes related to central control may operate improperly.
- For Windows 2000 Server, IIS will be stopped while a command is running.
- All files in the installation folder are deleted when the Central Admin Server software is uninstalled. Therefore, save all backup files to a location other than in the installation folder.



Before executing the `AmBackup.exe` command, confirm that the storage disk has sufficient free space. If free space is insufficient, an incomplete file may be saved.

The required free capacity is approximately twice the free capacity under the [Data] folder in the installation folder.



## 5.17.2 Restoring Central Admin Settings

Central admin settings that has been backed up can be restored to the Central Admin Server. To restore central admin settings, execute "AmRestore.exe" in the command prompt on the computer installed with the Central Admin Server software.

- Command storage location

Under the [\AmManager\Bin] folder in the installation folder of the Central Admin Server software

- Command executable format

AmRestore.exe *BackupFolderName*

The character string shown in italics is variable.

- Return value
  - 0  
Succeeded
  - other than 0  
Failed



- Make sure to run the AmRestore.exe command after changing the current directory to the [Bin] folder in the installation folder of the Central Admin Server software.
- The language for the backup and restore Central Admin Servers must be the same. If languages are different, Central Admin may not operate correctly when restoring.
- For Windows 2000 Server, IIS will be stopped while a command is running.



- The admin password is not backed up and restored by using the AmBackup.exe and AmRestore.exe commands. Even if the AmRestore.exe command is executed, the admin password is not changed.
- For Windows Server 2008, to use HTTPS for communication to a scanner, or computer installed with the Central Admin Console, additional settings may be required for the target Central Admin Server to be restored. For more details, refer to "[Importing the Certificate](#)" (page 235).

---

## 5.17.3 Obtaining Technical Support on the Central Admin Server

If any problems occur when setting up or using central admin, technical support information on the Central Admin Server can be collected to help determine the cause of the problem.

To obtain technical support information, execute "AmInvestigate.exe" in the command prompt on the computer installed with the Central Admin Server software.

When obtaining technical support, the Central Admin Server is in a temporarily suspended state. Do not try to obtain technical support unless requested by your FUJITSU scanner dealer, or a problem occurs.

- Command storage location

Under the [\AmManager\Bin] folder in the installation folder of the Central Admin Server software

- Command executable format

```
AmInvestigate.exe -d OutputFolder [-p EncryptedPassword] [-v]
```

The character string shown in italics is variable.

To show the status of the process, specify -v.

- Return value
  - 0  
Succeeded
  - other than 0  
Failed

The information is output to the specific output folder for each type. If an encrypted password is specified, the technical support information is encrypted.

## 5.17.4 Migrating Data to an Updated Version of the Central Admin Server Software

When updating the Central Admin Server software version in order to use a different server as the Central Admin Server, data from the previous version of the Central Admin Server software must be transferred to the new version.

The data can be migrated by executing the "AmBackup.exe" and "AmRestore.exe" commands in the computer in which the Central Admin Server software is installed.



If you back up data by executing "AmBackup.exe" in the [Bin] folder from the installation folder of the previous version, you cannot restore the data in the new version of the Central Admin Server.



- If updating the version of the current Central Admin Server software, you do not need to migrate data.
- Make sure to export audit logs in advance, as they are not migrated by this operation.



1. Copy the following folder in the new version of the Central Admin Server software to an arbitrary folder of the previous version.

[\AmManager\Bin] folder in the installation folder of the new Central Admin Server software

In the following cases, overwrite the "ServiceSetting.dll" file in the Bin folder that was copied to an arbitrary location in [Step 1](#), with the file of the same name from the previous version of the Central Admin Server software.

- When migrating data from Windows 2000 Server or Windows Server 2003 to Windows Server 2008
- When migrating data from Windows Server 2008 to Windows 2000 Server or Windows Server 2003

The "ServiceSetting.dll" file is stored in the following location:

Under the [\AmManager\Bin] folder in the installation folder of the previous Central Admin Server software

2. Execute "AmBackup.exe" in the [Bin] folder which was copied to an arbitrary folder of the previous version of the Central Admin Server.

For details about "AmBackup.exe", refer to ["5.17.1 Backing Up Central Admin Settings" \(page 291\)](#).

⇒ The data of the previous version of the Central Admin Server is backed up.

- 
3. Execute "AmRestore.exe" in the following folder of the new version of the Central Admin Server.

For details about "AmRestore.exe", refer to ["5.17.2 Restoring Central Admin Settings" \(page 293\)](#).

Under the [AmManager\Bin] folder in the installation folder of the Central Admin Server software
--

⇒ The data backed up in [Step 2](#) is restored in the new version of the Central Admin Server.

This concludes migrating the data from a previous version of the Central Admin server to a new version.

# Chapter 6

## Regular User Operations

User

This scanner is used to scan documents which then can be sent by e-mail or fax, printed on a network printer, or saved to a network folder.

To perform the operations described in this chapter, the scanner must first be setup by the administrator.

For details of scanner setup, refer to "[Chapter 4 Administrator Operations \(Touch Panel and Admin Tool\)](#)" (page 37).

Messages may appear while performing operations described in this chapter. For more details about these messages and actions to take, refer to "[E.2 Regular User Messages](#)" (page 526).

<b>6.1 Loading Documents</b> .....	<b>298</b>
<b>6.2 Using Touch Panel Screens: Regular User</b> .....	<b>304</b>
<b>6.3 Logging in: Regular User Mode</b> .....	<b>311</b>
<b>6.4 Sending the Scanned Data by e-Mail</b> .....	<b>314</b>
<b>6.5 Sending the Scanned Data by Fax</b> .....	<b>330</b>
<b>6.6 Printing the Scanned Data</b> .....	<b>339</b>
<b>6.7 Saving the Scanned Data to a Network Folder</b> .....	<b>352</b>
<b>6.8 Saving the Scanned Data in a SharePoint Folder</b> .....	<b>357</b>
<b>6.9 Setting the Scan Options</b> .....	<b>365</b>
<b>6.10 Enabling/Disabling the Scan Viewer</b> .....	<b>402</b>
<b>6.11 Editing the Scanned Data in the Scan Viewer</b> .....	<b>405</b>
<b>6.12 Checking the User Log</b> .....	<b>410</b>
<b>6.13 Maintenance</b> .....	<b>412</b>
<b>6.14 Processing a Job</b> .....	<b>413</b>



---

## 6.1 Loading Documents

This section describes how to load documents onto the scanner.


### 6.1.1 How to Load Documents

1. Check the number of document sheets.


For document sheet limits, refer to ["A.3 Maximum Document Loading Capacity"](#) (page 482).

2. Fan the documents.


1. Lightly grip the ends of the document stack in both hands, and flex it back and forth two or three times.



2. Rotate the documents 90 degrees, and fan again.
  3. Align the edges of the document sheets.
3. Load the documents into the ADF paper chute.
    1. Extend the ADF paper chute and adjust the side guides to hold the documents.




2. Load the documents face down. If only one side is to be scanned, it should face down in the ADF paper chute.




3. Adjust the side guides to the width of the documents.  
Move the side guides so that they touch both sides of the documents.  
If there is any space between the side guides and the edges of documents, the scanned data may be skewed.



- The output tray holds the document sheets after they have been scanned. It can be pulled out and adjusted to the size of the document being scanned.
  1. Pull out before scanning.
  2. The extension flap of output tray may also be lifted up, as shown in the figure below.



- Small documents may be retrieved by lifting up the keyboard after scanning has completed.





### 6.1.2 Loading Documents Using a Carrier Sheet

A Carrier Sheet is a plastic sheet specifically used for loading non-standard documents onto the scanner. It allows you to scan documents that cannot be scanned in the regular way. Also, documents larger than A4 size, such as A3 and B4, can be scanned by folding in half, inserting into the Carrier Sheet, and scanning in duplex mode. The scanned images will be merged output as one page. You can also merge both front and back side images of a document smaller than A4 size to output a double-page spread image.




- When using a Carrier Sheet, set the size of the scanned document to be output. For more details, refer to "6.9.1 Carrier Sheet" (page 372).
- When a Carrier Sheet is used for scanning, continuous scanning is not possible. Scan one page at one time.




1. Fold the sheet to be scanned in half.

Fold the sheet tightly and smooth out the crease. Otherwise, the sheet may be skewed during scanning.




2. Open the Carrier Sheet and insert the document.


Align the fold with the right edge of the Carrier Sheet so that the document fits into the Carrier Sheet at the upper corner.



- 
3. Load the Carrier Sheet with the black and white striped section (printed section) facing downwards as shown in the following figure.



4. Adjust the side guides to the width of the Carrier Sheet.  
Adjust the side guides so that there is no space between the guides and the Carrier Sheet. Space between the guides and Carrier Sheet may cause the Carrier Sheet to become unaligned during scanning, and skew the scanned image.
5. Start the scan.  
⇒ The front and back side images are merged into a double-page spread image.





There may be a gap between the front and back side images, or a line may appear on the output image.

When a sheet of thick paper is scanned, images on the both right and left side may be skewed to a trapezoidal shape.

The degree of skewing varies depending on the condition of the document (how it is folded or loaded).

Troubleshoot the problem as follows, and the situation may be improved.








- Is the document neatly folded? If not, fold it neatly.
- Is the edge of the document aligned with the edge of the Carrier Sheet? If not, align the document with the Carrier Sheet.
- Try to scan the document with the front side of the Carrier Sheet facing the paper chute or vice verse.

Also, the folded part of the document may be mis-detected, causing unintentional trimming of the scanned image. In this case, the folded edge of the document should be placed 1mm away from the edge of the Carrier Sheet.

## 6.2 Using Touch Panel Screens: Regular User

### 6.2.1 Common Buttons and Indicators

After the user logs in, the following buttons and indicators are shown on the touch panel screens.

Icon	Shown in manual as...	Used to ...
	[Up] button, [Down] button	Scroll up or down between items.
	[OK] button	Set the contents of the current screen.
	[Cancel] button	Cancel the contents of the current screen, or return to the previous screen.
	[Yes] button	If the color of the button is yellow, it means that the button is selected.
	[No] button	If the color of the button is blue, it means that the button is not selected.
	[Caps Lock] indicator	Indicate that the [Caps Lock] key has been set (on the keyboard).
	[Num Lock] indicator	Indicate that the [Num Lock] key has been set (on the keyboard).



If the [Logout] button or [Cancel] button is pressed before the [OK] button, the contents of the screen will not be set.



## 6.2.2 Regular User Settings Overview

Regular users can configure the following settings.

- **Login**  
Set the scanner to automatically login without displaying the "Login" screen, when the scanner power is switched on or restarted.  
Also, set whether or not to enable login with the guest account.
- **Initial Post-Login Menu**  
Set whether to display the "Multi-Function Main Menu" or "Job Menu".  
Switch between the "Multi-Function Man Menu" and "Job Menu", or display only the "Job Menu".
- **User Roaming Data**  
If roaming mode is enabled, a regular user can login on different scanners while retaining their user data.  
The following user data can be used in roaming mode.
  - "My List" e-Mail Address Books
  - Scan Settings
  - Name of the last network printer used
  - Name of the last network folder used
 If the same network printer/folder is not set for each scanner, the name of the latest one used is not shown.
- **Job Roaming Info**  
Retain job settings managed on the Central Admin Server, when logging in to different scanners.





When Roaming Mode or Job Mode is [On], if communication with the Central Admin Server is not possible at login, a confirmation message will appear. If the [OK] button is selected, the settings saved in the scanner are used. Selecting the [Cancel] button returns to the login screen.

## 6.2.3 Main Menu Screen

The type of buttons (e-Mail/Fax/Print/Save) displayed on the main menu differs according to the settings of the relevant server.

The following describes the main menu according to settings for e-Mail, Fax, Print and Save.



Icon	Shown in manual as...	Used to ...
	[Menu Mode] button	Switch between the "Multi-Function Main Menu" and the "Job Menu". For details, refer to <a href="#">"6.2.4 Job Menu Screen" (page 308)</a> .
	[Maintenance] button	Access the "Maintenance" screen. For details, refer to <a href="#">"6.13 Maintenance" (page 412)</a> .


Icon	Shown in manual as...	Used to ...
	[Consumable Alert] button	<p>Access the "Consumable Alert" screen. A colored alert indicator is used to warn that a "consumable replacement" is pending.</p>  Replacement is not required.  Parts need to be replaced soon. Contact a system administrator.  Parts need to be replaced now. Replace the necessary part. For details, refer to <a href="#">"7.6 Replacing Parts" (page 436)</a> .
	[User Log] button	Access the "User Log" screen. For details, refer to <a href="#">"6.12 Checking the User Log" (page 410)</a> .
	[e-Mail] button	Access the "Send e-Mail" screen. For details, refer to <a href="#">"6.4 Sending the Scanned Data by e-Mail" (page 314)</a> .
	[Fax] button	Access the "Send Fax" screen. For details, refer to <a href="#">"6.5 Sending the Scanned Data by Fax" (page 330)</a> .
	[Print] button	Access the "Print" screen. For details, refer to <a href="#">"6.6 Printing the Scanned Data" (page 339)</a> .
	[Save] button	Access the "Save" screen. For details, refer to <a href="#">"6.7 Saving the Scanned Data to a Network Folder" (page 352)</a> .
	[Scan to SharePoint] button	Access the "Scan to SharePoint" screen. For details, refer to <a href="#">"6.8 Saving the Scanned Data in a SharePoint Folder" (page 357)</a> .
	[Logout] button	Logout the current user.

## 6.2.4 Job Menu Screen











The type of buttons displayed on the job menu differs according to the job settings. The following describes an example of a job menu according to job settings.









When a regular user belongs to multiple job groups, buttons to switch the job menu name or "Job Menu" screen appear as shown below.





Icon	Shown in manual as...	Used to...
	[Menu Mode] button	Switch between the "Multi-Function Main Menu" and the "Job Menu". For more details refer to, " <a href="#">6.2.3 Main Menu Screen</a> " (page 306)
	[Switch Menu] button	Switch between the following menus. <ul style="list-style-type: none"> <li>● The menu containing the [Maintenance], [Consumable Alert], and [User Log] buttons</li> <li>● The menu containing job menu switch buttons (shown when a regular user belongs to multiple job groups)</li> </ul>
	[Maintenance] button	Access the "Maintenance" screen. For details, refer to " <a href="#">6.2.3 Main Menu Screen</a> " (page 306).
	[Consumable Alert] button	Access the "Consumable Alert" screen. For details, refer to " <a href="#">6.2.3 Main Menu Screen</a> " (page 306).
	[User Log] button	Access the "User Log" screen. For details, refer to " <a href="#">6.2.3 Main Menu Screen</a> " (page 306).
	Job menu name field	This field appears only when a regular user belongs to multiple job groups. The currently selected job menu name is shown in this area.
	Job menu switch buttons	These buttons appear only when a regular user belongs to multiple job groups. <ul style="list-style-type: none"> <li>● Press  to show a list of job groups to which a regular user belongs. When a job menu is selected, the corresponding "Job Menu" screen appears.</li> <li>● Press  to move to the previous "Job Menu" screen.</li> <li>● Press  to move to the next "Job Menu" screen.</li> </ul>

Icon	Shown in manual as...	Used to...
	[Job] button	Start the specified job process for each job button. For more details, refer to <a href="#">"6.14 Processing a Job"</a> (page 413).
	[Logout] button	Logout the current user.
 (When the button is enabled)	[Message Screen] button	Set whether or not to show the "Message Screen". For more details, refer to <a href="#">"6.14.1 Enabling/Disabling the Message Screen"</a> (page 417).
 (When the button is disabled)	—	It is not possible to select whether or not to show the "Message Screen". Whether or not to show the "Message Screen" depends on the settings configured by the administrator.
 (When the button is enabled)	[Scan Viewer] button	Set whether or not to show the "Scan Viewer". For more details, refer to <a href="#">"6.10 Enabling/Disabling the Scan Viewer"</a> (page 402).
 (When the button is disabled)	—	It is not possible to select whether or not to show the "Scan Viewer". Whether or not to show the "Scan Viewer" depends on the settings configured by the administrator.

## 6.3 Logging in: Regular User Mode



Do not move or shake the scanner when it is turned on.  
This can damage the rotating hard disk drive and cause data to be lost.



LDAP authentication for the scanner requires entry of a login name that matches the type of user names saved on the LDAP server.

The following forms of login authentication may be used by the scanner, depending on the LDAP server type and user name format.

- When the "Server Type" of the LDAP server is [Active Directory] or [Active Directory Global Catalog]

User Name Format	Authentication Process
SAM Account Name Does not contain a "@"	Authenticate the user login name (sAMAccountName). Example: user
User Principal Name Contains a "@"	Authenticate the user login name (userPrincipalName). Example: user@example.com

- When the "Server Type" of the LDAP server is [Other LDAP Server]

User Name Format	Authentication Process
uid	Authenticate the user login name (uid). Example: user
cn	Authenticate the user login name (cn). Example: user

Note that the authenticated user info is also used when saving scans to a network folder. When the scanner is turned on or restarted, automatic login without displaying the "Login" screen is possible.

Login is not possible if the Active Directory account option is "User must change password at next logon". Contact an administrator to change a password, and then try logging in.



- When using the scanner without an LDAP server, enter the following user name and password. For details about the LDAP server, refer to "[LDAP Server](#)" (page 17).


User Name: guest

Password: guest

However, this cannot be used if login with the guest account is disabled.

- For details about automatic login or enabling login with the guest account, refer to "[4.6.7 Setting the Login Method](#)" (page 68).
- Only one administrator or user can login to the scanner at any one time.

1. Push the startup button.



⇒ The "Login" screen appears.

2. Enter a "User Name" and "Password" that has been stored in the LDAP server.

Login  Caps Lock  Num Lock

User Name :

Password :

Field Name	Description
User Name	User names may be up to 64 characters long. All alphanumerics (case sensitive) and some symbols are allowed. User names may not start with a "@" or ".". The following symbols cannot be used: / \ [ ] : ;   = , + * ? < > "
Password	Passwords may be up to 256 characters long, and all alphanumerics (case sensitive) and symbols are allowed.



- The "Caps Lock" indicator is on if the keyboard's Caps Lock is set.
- The "Num Lock" indicator is on if the keyboard's Num Lock is set.
- If "Active Directory Global Catalog" is selected for the login LDAP server, the "UPN Suffix" input field is displayed.

User names including a UPN suffix may be up to 64 characters long. If a UPN suffix is entered, "@" and the "UPN\_suffix" will be appended to the "User\_name".

The entered UPN suffix is remembered and used again at the next login. For example, if the user name is "user", and "example.com" is entered for the UPN suffix, it is corrected to "user@example.com".

In this case, this is the "User Principal Name".

A UPN suffix is not required when logging in as a guest. Even if entered, it will be ignored.

### 3. Press the [Login] button.

⇒ If the user name and password are valid, the "Main Menu" screen appears.



Send e-Mail Caps Lock   
Num Lock

To :

Cc :  File Name :

Bcc :  From :

Subject :

Body :

3. Enter a file name for the scan data into the "File Name:" field.

File names may be up to 128 characters long, excluding the following symbols.

\ / : \* ? " < > |

The default value is the file name specified on the administrator "File Names (e-Mail)" screen. For details, refer to ["4.6.10 Setting a File Name Format for When Attaching Scanned Data to e-Mail" \(page 76\)](#).



The following file names cannot be used:

- CON
- PRN
- AUX
- CLOCK\$
- NUL
- COM0 to COM9
- LPT0 to LPT9

- 
4. Check that address shown in the "From:" field is correct.
    - Direct input for this field is only possible if logged in with the guest account. Enter a "From" e-mail address. For details about the e-mail address settings, refer to ["B.1 e-Mail Address Setting Values" \(page 488\)](#).



e-Mail addresses can be selected directly from the e-mail address book. For details, refer to ["6.4.1 Selecting an e-Mail Target from the e-Mail Address Book" \(page 319\)](#).

- If logged in with an account other than the guest account, the "From" input field is not shown, but the user e-mail address registered with the LDAP server is set for this field.
5. Enter an e-mail title into the "Subject:" field.

The subject may be up to 128 characters long.
  6. Enter the e-mail contents into the "Body:" field.

The body may be up to 512 characters long, including line feeds.

7. Select whether or not to request a return receipt.



If  is pressed and becomes , a return receipt will be requested.



8. Press the [Scan] button.

When [Scan Viewer] is Off, this will be a [Scan&Send] button.  
⇒ Scanning starts.

Each page is briefly shown on the screen as it is scanned.

The maximum number of pages that can be scanned is 999.

When [Blank Page Skip] is enabled, the number of scanned pages excluding skipped blank pages is shown.

Additional pages can be scanned in place of skipped blank pages, until the maximum number of scanned pages is reached.

When the scan has completed, the "Scan Viewer" screen opens.

For more details about the "Scan Viewer" screen, refer to ["6.11 Editing the Scanned Data in the Scan Viewer" \(page 405\)](#).



- [Scan Viewer] is initially "On".
- When the [Scan&Send] button is pressed (when [Scan Viewer] is "Off"), after the last page has been displayed on the "Scanning" screen, the scan data is attached to an e-mail and sent, and the touch panel screen returns to the "Main Menu".

For more details, refer to ["6.10 Enabling/Disabling the Scan Viewer" \(page 402\)](#)



9. Check the scanned data.

For more details about the "Scan Viewer" screen, refer to ["6.11 Editing the Scanned Data in the Scan Viewer" \(page 405\)](#).

10. On the "Scan Viewer" screen, press the [Send] button.

⇒ The scanned data is sent with the specified file as an e-mail attachment.

If "Split Mails" is set to "On", split e-mails will be sent.

If the number of e-mail addresses exceeds the specified maximum number, a warning message will appear.



Mailing scan data to `cdef@example.com`

⇒ The "Main Menu" screen is shown again.



- The following items are set by the administrator in advance.
  - The maximum number of e-mail addresses to be specified in the "To" field
  - Whether to split an e-mail to be sent, and the maximum size of a split e-mail
  - The maximum size of an attached file

To change these settings, contact the administrator. For more details about these settings, refer to ["4.7.11 Setting the e-Mail Server \(SMTP Server\)" \(page 116\)](#).

- For photos and images, a high compression level can be used to create a smaller file. For more details, refer to ["6.9.9 Compression" \(page 387\)](#).
- If the file format is JPEG or TIFF, a file will be attached for each page in the scan.
  - If the number of pages is over ten and the [Scan Viewer] is On, a confirmation dialog will appear after the "Send e-Mail" screen [Send] button is pressed.
  - If the number of pages is over ten and the [Scan Viewer] is Off, a confirmation dialog will appear after the "Send e-Mail" screen [Scan&Send] button is pressed.
- If the e-mail fails to send, an error message with the following title is sent by e-mail from the scanner to the "From" address.  
Network Scanner (XXXX) Error

### 6.4.1 Selecting an e-Mail Target from the e-Mail Address Book

The following explains how to select e-mail addresses by using an e-mail address book, not by directly entering an e-mail address with a keyboard as described in [Step 2](#) and [Step 4](#) of "6.4 Sending the Scanned Data by e-Mail" (page 314).



The e-mail address book contains "My List" and "LDAP List" sections. Operations other than search operations for both sections are the same. The search method for "My List" is Anywhere. For "LDAP List" searches, choose from Head, Anywhere, and Tail search methods.

- "My List" is an e-mail address book that can be created by each user.
- "LDAP list" is an e-mail address book which uses data stored on the LDAP server. The LDAP list cannot be edited.

In the following cases, the [LDAP List] tab is not shown, therefore cannot be used.

- If an LDAP server is not used
- If logged in with the guest account


The following e-mail targets can be selected from the e-mail address book.

e-Mail Target	Icon Shown in the e-Mail Address Book	My List	LDAP List
Distribution List		A	— (*)
e-Mail Address		A	A


A: available —: not available

(\*): Not shown in the LDAP list.

The following explains how to select an e-mail address using the "LDAP List".

- 
1. On the "Send e-Mail" screen, press the  button to the right of the e-mail address field.

⇒ The "e-Mail Address Book" screen for the LDAP list appears.



2. Select the search parameter.

The search parameters and button names shown on the left and middle buttons can be customized. For details about customizing the search parameters and the button names, refer to ["4.7.10 Setting the LDAP Search Parameters"](#) (page 111).

Pressing the left or middle button displays the search results according to the search parameter shown on the button, in alphabetical order. If multiple items are selected, data containing any of the search words are searched as "OR Search".


Pressing the [e-Mail Address] button displays the search results by e-mail address, in alphabetical order.

3. Press the [Search Position] button.

⇒ The "Search Position" screen appears.

## 4. Select a search position setting.

By default, [Head (abc...)] is set.



Search Position	Search Method	Example Target	Search Result
Head (abc...)	The LDAP e-mail address book is searched for entries which start with the character string entered in <a href="#">Step 5</a> .	abc	abc, abc1, abcd, ...
Anywhere (...abc...)	The LDAP e-mail address book is searched for entries which include the character string entered in <a href="#">Step 5</a> .	abc	abc, abc1, xabc, xabcy, ...
Tail (...abc)	The LDAP e-mail address book is searched for entries which end with the character string entered in <a href="#">Step 5</a> .	abc	abc, 1abc, xabc, ...



When the LDAP server contains several tens of thousands of entries, "Anywhere" and "Tail" searches can take a long time.

⇒ The screen returns to the "e-Mail Address Book" LDAP list. The selected position is displayed to the right of the [Search Position] button.


5. Enter a search string.

Contacts can be searched for individually, or all at the same time. Search strings may be up to 256 characters long.

Wild card characters cannot be used. The actual characters \* ? [ ] will be searched for.

6. Press the [Find] button.

⇒ The search results are displayed on the right side. Five results are displayed at a time.



- The number of LDAP search results displayed can be specified. LDAP server settings can be changed by the administrator. For details, refer to "4.7.8 Setting the Login LDAP Server" (page 100).
- If items are missing for search results according to the display format of the search results, "----" is shown instead. For example, if the display format is "LastName FirstName", and the user "LastName: Fujitsu, FirstName: None" is registered on the LDAP server, the search result is displayed as follows. Search result display format: Fujitsu ----
- Search methods differ for the My List and LDAP List. Therefore, search results differ according to the list selected.

Search Character	My List	LDAP List
Case	Insensitive	Insensitive
Diacritical/Accent marks	Sensitive	Insensitive

## 7. Select the desired e-mail target from the search results.



- Selecting an e-mail address and pressing the [+] button, can be used to add a selected e-mail address to an e-mail. To add multiple e-mail addresses, simply select another e-mail address and press the [+] button.
- Selecting an e-mail address and pressing the [Add to My List] button, adds the selected e-mail address to the "My List" e-mail address book.
- Selecting an e-mail address and pressing the [Details] button, allows you to check information for the selected e-mail contact.

## e-Mail Address Details

Last Name	ABC
First Name	DEF
e-Mail Address	ABC@example.com
Common Name	ABC
Display Name	ABC



## 8. Press the [OK] button.

⇒ The address is added to the field in the "Send e-Mail" screen.

When multiple e-mail addresses are entered using the e-mail address book, a ";" is automatically entered in between each address.

Up to 30 e-mail addresses can be entered at one time.

## 6.4.2 Adding an e-Mail Target to the e-Mail Address Book


The following explains how to add an e-mail address or a distribution list to your My List. e-Mail targets cannot be added to the LDAP list.

The maximum number of e-mail targets that can be stored in the e-mail address book is as follows.


- Total of 5,000 e-mail targets which include distribution lists and/or e-mail addresses
- Total of 10,000 e-mail addresses

1. Open the "e-Mail Address Book" screen in either of the following ways.



- On the "Send e-Mail" screen, press  to the right of an e-mail address field.
- On the "Main Menu" or "Job Menu" screen, press the [Maintenance] button, then on the "Maintenance" screen, press the [Edit e-Mail Address] button. For details, refer to "6.13 Maintenance" (page 412).

2. Select the [My List] tab.



The screenshot shows the "e-Mail Address Book" interface. At the top, there are "Caps Lock" and "Num Lock" indicators. Below the title bar, there are two tabs: "My List" (selected) and "LDAP List". The "My List" tab contains a form with fields for "First Name", "Last Name", and "e-Mail Address". There is a search section with a "Search Target" field, a "Find" button, and a "Search Position" dropdown set to "Head (abc...)". At the bottom of the form, there are "Add", "Edit", and "Delete" buttons. The "Add" button is highlighted. On the right side of the form, there are navigation buttons: a plus sign (+), an up arrow (▲), and a down arrow (▼). At the bottom of the screen, there are "Cancel" and "OK" buttons.

3. Press the [Add] button.

⇒ The "Add e-Mail Address" screen appears.



4. Enter the details of the e-mail target being added.
  - For e-mail addresses  
On the [e-Mail Address] tab, enter the "First Name", "Last Name", and "e-Mail Address". Up to 64 characters can be specified for "First Name" and "Last Name". "First Name" and "Last Name" can be skipped.  
For more details about e-mail address setting values, refer to ["B.1 e-Mail Address Setting Values"](#) (page 488).

The screenshot shows a dialog box titled "Add e-Mail Address". At the top right, there are indicators for "Caps Lock" and "Num Lock". Below the title bar, there are two tabs: "e-Mail Address" (which is selected and highlighted in green) and "Distribution List". The main content area contains three text input fields with the following labels: "First Name:", "Last Name:", and "e-Mail Address:". To the right of these fields, there is a faint, light blue envelope icon. At the bottom of the dialog, there are two buttons: "Cancel" (with a red 'X' icon) and "OK" (with a green play button icon).

- For distribution lists

On the [Distribution List] tab, enter the "List Name" and "e-Mail Addresses" to be added to the distribution list.

Up to 64 characters can be specified for "List Name". The following symbols cannot be used.

; @


For more details about e-mail address setting values, refer to "[B.1 e-Mail Address Setting Values](#)" (page 488).

A distribution list can contain up to 100 e-mail addresses. Multiple addresses must be separated using semi-colons (";").

e-Mail addresses can be selected from the e-mail address book, which can be accessed by



pressing



5. Press the [OK] button.


⇒ The e-mail address or distribution list is added to your My List address book.

### 6.4.3 Editing an e-Mail Target in the e-Mail Address Book


The following explains how to edit an e-mail address or distribution list stored in your My List. e-Mail targets stored in the LDAP list cannot be edited.

1. Open the "e-Mail Address Book" screen in either of the following ways.



- On the "Send e-Mail" screen, press  to the right of an e-mail address field.
  - On the "Main Menu" or "Job Menu" screen, press the [Maintenance] button, then on the "Maintenance" screen, press the [Edit e-Mail Address] button. For details, refer to ["6.13 Maintenance" \(page 412\)](#).
2. Select the [My List] tab.
  3. Select the e-mail address or distribution list to be edited.
  4. Press the [Edit] button.  
⇒ The "Edit e-Mail Address" screen appears.
  5. Edit the details of the selected e-mail target.
    - For e-mail addresses  
Edit the "First Name", "Last Name", and "e-Mail Address".  
Up to 64 characters can be specified for "First Name" and "Last Name". "First Name" and "Last Name" can be skipped.  
For more details about e-mail address setting values, refer to ["B.1 e-Mail Address Setting Values" \(page 488\)](#).



Edit e-Mail Address
Caps Lock 
Num Lock

 e-Mail Address

First Name :

Last Name :

e-Mail Address :

 Cancel
 O K

- For distribution lists

Edit the "List Name" and "e-Mail Addresses" contained in the distribution list.

Up to 64 characters can be specified for "List Name". The following symbols cannot be used.

; @

For more details about e-mail address setting values, refer to "[B.1 e-Mail Address Setting Values](#)" (page 488).

A distribution list can contain up to 100 e-mail addresses. Multiple addresses must be separated using semi-colons (";").

e-Mail addresses can be selected from the e-mail address book, which can be accessed by



pressing

Dialog box titled "Edit e-Mail Address" with "Caps Lock" and "Num Lock" indicators. A green tab labeled "Distribution List" is visible. The dialog contains a "List Name" field with the text "Distribution List1" and an "e-Mail Addresses" field with the text "ABC@example.com; cdef@example.com". There is a small envelope icon next to the "e-Mail Addresses" field. At the bottom, there are "Cancel" and "OK" buttons.

6. Press the [OK] button.


⇒ The edited e-mail address is saved in your My List address book.

### 6.4.4 Deleting an e-Mail Target from the e-Mail Address Book


The following explains how to delete an e-mail address or a distribution list from your My List. e-Mail targets cannot be deleted from the LDAP list.

1. Open the "e-Mail Address Book" screen in either of the following ways.



- On the "Send e-Mail" screen, press  to the right of an e-mail address field.
  - On the "Main Menu" or "Job Menu" screen, press the [Maintenance] button, then on the "Maintenance" screen, press the [Edit e-Mail Address] button. For details, refer to "[6.13 Maintenance](#)" (page 412).
2. Select the [My List] tab.
  3. Select the e-mail address or distribution list to be deleted.
  4. Press the [Delete] button.
    - ⇒ The "Delete e-Mail Address" screen appears.

The following is an example screen which is shown when an e-mail address is deleted.
  5. Check the correct e-mail target has been set for deletion and press the [OK] button.



- ⇒ The e-mail target is deleted from the e-mail address book.

## 6.5 Sending the Scanned Data by Fax

1. On the "Main Menu" screen, press the [Fax] button.

⇒ The "Send Fax" screen appears.



The scan information can be changed by pressing the [Scan Settings] button.

For more details, refer to ["6.9 Setting the Scan Options" \(page 365\)](#).

2. Enter a fax number into the "Recipient Fax No." field.

Recipient fax numbers may be up to 64 digits long.

Numbers and the following symbols can also be used.

-\*#



Recipient fax numbers can be selected directly from the fax number list.

For details, refer to ["6.5.1 Selecting a Fax Number from the Fax Number List" \(page 332\)](#).

3. In the "Notification To (Sender's e-Mail Address)" field, enter an e-mail address for Send Fax result alert e-mails.


For more details about e-mail address setting values, refer to ["B.1 e-Mail Address Setting Values" \(page 488\)](#).

## 4. Press the [Scan&amp;Send] button.


When [Scan Viewer] is On, this will be a [Scan] button.

⇒ Scanning starts.

After the last page is displayed on the "Scanning" screen, the scan data is sent by fax, and the touch panel screen returns to the "Main Menu".




Faxing scan data to 123456789

- HINT 
- [Scan Viewer] is initially "Off".
  - When the [Scan] button is pressed (when [Scan Viewer] is "On"), each page is briefly shown on the screen as it is scanned. The maximum number of pages that can be scanned is 999. When [Blank Page Skip] is enabled, the number of scanned pages excluding skipped blank pages is shown. Additional pages can be scanned in place of skipped blank pages, until the maximum number of scanned pages is reached. When the scan has completed, the "Scan Viewer" screen opens. For more details about the "Scan Viewer" screen, refer to ["6.10 Enabling/Disabling the Scan Viewer" \(page 402\)](#) and ["6.11 Editing the Scanned Data in the Scan Viewer" \(page 405\)](#).
  - A delivery report message with the following title is sent by e-mail from the scanner to the "Notification To (Sender's e-Mail Address)" address.  
Network Scanner (XXXX) Error

## 6.5.1 Selecting a Fax Number from the Fax Number List

As mentioned in [Step 2](#) of "6.5 Sending the Scanned Data by Fax" (page 330), instead of entering a fax number with keyboard, fax numbers may be directly selected from a fax number list.



1. On the "Send Fax" window, press  .  
⇒ The "Fax Number List" screen appears.

2. Select the search parameter.

Pressing the [Fax No.] button displays the search results by fax numbers, in number order.  
Pressing the [Recipient] button displays the search results by recipient names, in alphabetical order.

The screenshot shows the "Fax Number List" screen. At the top, there is a title bar with "Fax Number List" on the left and "Caps Lock" and "Num Lock" indicators on the right. Below the title bar, there are two buttons: "Recipient" (yellow) and "Fax No." (blue). A "Search Target:" label is above a text input field. To the right of the input field is a "Find" button with a magnifying glass icon. Below the input field is a "Search Position" button and the text "Head (abc...)". At the bottom of the search area are three buttons: "+ Add", "Edit", and "Delete". The main area displays a list of recipient names: " Dwight David Eisenhower", " John Fitzgerald Kennedy", " London Business Johnson", " Rutherford Richard Hey", and " Stephen Gross Clark". To the right of the list are up and down arrow buttons and a page indicator "1 / 1". At the bottom of the screen are "Cancel" and "OK" buttons.

3. Press the [Search Position] button.  
⇒ The "Search Position" screen appears.



## 4. Select a search position setting.

By default, [Head (abc...)] is set.




Search Position	Search Method	Example Target	Search Result
Head (abc...)	The LDAP fax number list is searched for entries which start with the character string entered in <a href="#">Step 5</a> .	abc	abc, abc1, abcd, ...
Anywhere (...abc...)	The LDAP fax number list is searched for entries which include the character string entered in <a href="#">Step 5</a> .	abc	abc, abc1, xabc, xabcy, ...
Tail (...abc)	The LDAP fax number list is searched for entries which end with the character string entered in <a href="#">Step 5</a> .	abc	abc, 1abc, xabc, ...

⇒ The screen returns to the "Fax Number List". The selected position is displayed to the right of the [Search Position] button.

## 5. Enter a search string.

Contacts can be searched for individually, or all at the same time. A search string may be up to 64 characters long. Wild card characters cannot be used (the actual characters \* ? [ ] will be searched for).

6. Press the [Find] button.  
⇒ The search results are displayed on the right side. Five results are displayed at a time.




7. Select a fax number.
8. Press the [OK] button.  
⇒ The fax number is added to the field in the "Send Fax" screen.  
Only one fax number can be entered at a time.

## 6.5.2 Adding a Contact to the Fax Number List

A maximum of 1,000 contacts can be stored in the fax number list.  
Fax contact numbers added to the list are accessible to all users.

1. Open the "Fax Number List" screen in either of the following ways.



- On the "Send Fax" screen, press .
- On the "Main Menu" or "Job Menu" screen, press the [Maintenance] button, then on the "Maintenance" screen, press the [Edit Fax Numbers] button. For details, refer to "[6.13 Maintenance](#)" (page 412).

2. Press the [Add] button.

⇒ The "Add Fax Number" screen appears.



---

3. Enter the fax contact details.

Recipients may be up to 64 characters long.

Fax numbers may be up to 64 digits long. Numbers and the following symbols can also be used.

-\*#

Caps Lock   
Num Lock 


**Add Fax Number**



  

Recipient :

Fax No. :



 Cancel OK

4. Press the [OK] button.


⇒ The contact is added to the fax number list.

### 6.5.3 Editing a Contact in the Fax Number List



Fax contact numbers edited in the list are accessible to all users.

1. Open the "Fax Number List" screen in either of the following ways.



- On the "Send Fax" screen, press .
  - On the "Main Menu" or "Job Menu" screen, press the [Maintenance] button, then on the "Maintenance" screen, press the [Edit Fax Numbers] button. For details, refer to ["6.13 Maintenance" \(page 412\)](#).
2. Select the fax contact that is to be edited.
  3. Press the [Edit] button.
    - ⇒ The "Edit Fax Number" screen appears.
  4. Edit the contact information.
    - Recipients may be up to 64 characters long.
    - Fax numbers may be up to 64 digits long. Numbers and the following symbols can also be used.

-\*#

**Edit Fax Number** Caps Lock   
Num Lock 

Recipient :


abcdefg


  

Fax No. :

123456789|

 Cancel

 OK


5. Press the [OK] button.
  - ⇒ The edited fax number list contact is saved.

## 6.5.4 Deleting a Contact from the Fax Number List

Fax contact numbers deleted from the list are no longer accessible to any user.

1. Open the "Fax Number List" screen in either of the following ways.



- On the "Send Fax" screen, press .
  - On the "Main Menu" or "Job Menu" screen, press the [Maintenance] button, then on the "Maintenance" screen, press the [Edit Fax Numbers] button. For details, refer to ["6.13 Maintenance" \(page 412\)](#).
2. Select the fax contact that is to be deleted.
  3. Press the [Delete] button.  
⇒ The "Delete Fax Number" confirmation screen appears.
  4. Check the contact that is set to be deleted is the correct one and press the [OK] button.

Delete Fax Number

OK to delete the following data?

Recipient : abcdefg

Fax No. : 123456789



 Cancel

 OK


⇒ The contact is deleted from the fax number list.

## 6.6 Printing the Scanned Data

1. On the "Main Menu" screen, press the [Print] button.


⇒ The "Print" screen appears.

Network printer preferences are saved for each user, and will be shown each time that user logs in.

 The scan information can be changed by pressing the [Scan Settings] button. For more details, refer to ["6.9 Setting the Scan Options" \(page 365\)](#).

2. To change the printer, press the [Select] button.

At the first login, the network printer registered by the administrator in "Printer" is displayed. After the first login, each time a user logs in, the name of the last network printer used is displayed.




⇒ The "Printer List" screen appears.



### 3. Select a printer.



- Pressing the [Details] button on the "Printer List" screen displays information about the selected network printer. If a printer name is too long for one line, it will wrap onto the next line. Any hidden parts of the name may be revealed by finger dragging and scrolling.
- Only the administrator may add printers to the list, or edit the details of printers already on the list. For more details about adding printers, refer to ["4.7.13 Setting the Network Printers" \(page 119\)](#).






- 4. Press the [OK] button.  
⇒ This returns you to the "Print" screen.



- User authentication may sometimes be required to access a network printer. When the authentication is required, the "Print Server Authentication" screen appears. The authentication procedure follows.
  1. Enter a "User Name" and "Password" for the printer.  
Passwords are case sensitive.



2. Press the [OK] button.
  - Current user printing privileges for the specified printer are checked before printing. When printing privileges are being checked, data may be spooled temporarily.

- 5. Make any required print setting changes.  
[Scaling], [Positioning], and [Simplex/Duplex] settings can be changed. For more details refer to "[6.6.1 Scaling](#)" (page 344), "[6.6.2 Positioning](#)" (page 349), and "[6.6.3 Simplex/Duplex](#)" (page 351).  
To return to the print setting to the factory settings, press the [Default] button.  
According to the printer, settings from the printers properties screen may be used instead.
- 6. Enter a number in "No. of Copies" field.  
The default number is 1. Numbers from 1 to 99 can be used.  
According to the printer, settings from the printers properties screen may be used instead.

---

7. Press the [Scan] button.

When [Scan Viewer] is Off, this will be a [Scan&Print] button.

⇒ Scanning starts.

Each page is briefly shown on the screen as it is scanned.

The maximum number of pages that can be scanned is 100.

When [Blank Page Skip] is enabled, the number of scanned pages excluding skipped blank pages is shown.

Additional pages can be scanned in place of skipped blank pages, until the maximum number of scanned pages is reached.

When the scan has completed, the "Scan Viewer" screen opens.

For more details about the "Scan Viewer" screen, refer to ["6.11 Editing the Scanned Data in the Scan Viewer"](#) (page 405).



- [Scan Viewer] is initially "On".
- When the [Scan&Print] button is pressed (when [Scan Viewer] is "Off"), after the last page is displayed on the "Scanning" screen, the scan data is printed, and the touch panel screen returns to the "Main Menu". For details, refer to ["6.10 Enabling/Disabling the Scan Viewer"](#) (page 402).
- Current user printing privileges for the specified printer are checked before printing. When printing privileges are being checked, data may be spooled temporarily.


8. Check the scanned data.

For more details about the "Scan Viewer" screen, refer to ["6.11 Editing the Scanned Data in the Scan Viewer"](#) (page 405).


9. On the "Scan Viewer" screen, press the [Print] button.

⇒ The scanned data is printed.

The document name for the scanned data to be printed is the name of the scanner.



Printing scan data on FUJITSUX.2(Color)



The printing status is displayed in the user log until printing has finished. The network printer printing result is not displayed. For more details about the user log, refer to "6.12 Checking the User Log" (page 410).



If the printing fails, an error message with the following title is sent by e-mail from the scanner, to the e-mail address registered in the LDAP server for the currently logged-in user.

Network Scanner (XXXX) Error




## 6.6.1 Scaling

Set the print size for the scanned data.

The setting selected here will be used every time the user prints a document.


1. Press the [Scaling] button.



⇒ The "Scaling" screen appears.

2. Select the print scale of the data.


By default, this is "100%".














● Shrink to Fit

The image is reduced so that the entire image fits into the area available for printing (area inside the dotted line). Further enlargement is not possible.

If the positioning setting is "Center", the control point for printing is the center point of the area available for printing. If the positioning setting is "Top Left", the control point for printing is the top left corner of the area available for printing. For more details on the positioning setting, refer to "6.6.2 Positioning" (page 349).




Print Sheet	Scanned Data	Positioning	Result
Small 	Large 	Center	
		Top Left	







Print Sheet	Scanned Data	Positioning	Result
Large 	Small 	Center	
		Top Left	
Same 	Same 	Center	
		Top Left	

- 100%




The image is printed at full scale, regardless of the paper size.

If the positioning setting is "Center", the control point for printing is the center point of the print sheet. If the positioning setting is "Top Left", the control point for printing is the top left corner of the print sheet. For more details on the positioning setting, refer to "6.6.2 Positioning" (page 349).



Print Sheet	Scanned Data	Positioning	Result
Small 	Large 	Center	
		Top Left	
Large 	Small 	Center	
		Top Left	



Print Sheet	Scanned Data	Positioning	Result
Same 	Same 	Center	
		Top Left	

⇒ This returns to the "Print" screen. The selected scaling setting is displayed to the right of the [Scaling] button.



- Nothing is printed in the margin set in the printer settings.  
If edge cropping has been set, the width of the edge cropping setting may be larger than the margin set in the printer settings. For more details, refer to ["6.9.18 Edge Cropping" \(page 400\)](#).
- If "Shrink to Fit" is set, the edge cropping area is not included in the print data.  
If "100%" is set, the edge cropping area is included in the print data.
- When "Shrink to Fit" is set, the printing result may differ from the original document since the starting position or available area of printing depends on each individual printer.






### 6.6.2 Positioning

Set the print position of the scanned data.



The setting selected here will be used every time the user prints a document.

1. Press the [Positioning] button.
  - ⇒ The "Positioning" screen appears.
2. Select the print positioning of the data.
  - By default, this is "Center".



Button	Scaling	Control Point
Center	Shrink to Fit	Uses the center point of the area available for printing as a control point. 
	100%	Uses the center point of the sheet as a control point. 



Button	Scaling	Control Point
Top Left	Shrink to Fit	<p>Uses the top left corner of the area available for printing as a control point.</p> 
	100%	<p>Uses the top left corner of the print sheet as a control point.</p> 

For more details on the print scaling setting, refer to ["6.6.1 Scaling" \(page 344\)](#).  
 ⇒ This returns to the "Print" screen. The selected positioning setting is displayed to the right of the [Positioning] button.

### 6.6.3 Simplex/Duplex

Set whether to print on one side (simplex mode) or both sides (duplex mode).

1. Press the [Simplex/Duplex] button.  
⇒ The "Simplex/Duplex" screen appears.
2. Select a print mode.


Initially, this setting is "Duplex (Long Edge)".

"Long Edge" means that sheets are flipped vertically for printing.

"Short Edge" means that sheets are flipped horizontally for printing.



According to the printer, settings from the printers properties screen may be used instead.



- ⇒ This returns you to the "Print" screen.  
The selected mode is displayed to the right of the [Simplex/Duplex] button.

## 6.7 Saving the Scanned Data to a Network Folder

1. On the "Main Menu" screen, press the [Save] button.

⇒ The "Save" screen appears.

Network folder preferences are saved for each user, and will be shown each time that user logs in.



Scan preferences can be changed by pressing the [Scan Settings] button. For more details, refer to "6.9 Setting the Scan Options" (page 365).

2. Press the [Select] button.

Save

Caps Lock  
Num Lock

Save in :  
[Empty text box] [Select...]

Save as :  
[File name]

Overwrite old files?  
[No] [Yes]

Cancel Scan Settings Default Scan Viewer On Scan


⇒ The "Folder List" screen appears.

## 3. Select a network folder.



- On the "Folder List" screen, select a folder and press the [Details] button to view the details of the selected network folder. If a folder name is too long for one line, it will wrap onto the next line. Any hidden parts of the name may be revealed by finger dragging and scrolling.
- Only network folders which are in the list may be selected. Only the administrator may add folders to the list, or edit the details of folders already on the list.

For more details about adding network folders, refer to ["4.7.14 Setting the Network Folders"](#) (page 132).



4. Press the [OK] button.

⇒ This returns you to the "Save" screen.



User authentication may sometimes be required to access the file server. If authentication is required, the "File Server Authentication" screen appears. The authentication procedure is as follows.

1. Enter a "User Name" and "Password" for the file server. Passwords are case sensitive.

2. Press the [OK] button.

5. In the "Save as:" field, enter a file name for the scanned data to be saved.

File names may be up to 128 characters long. \ and / are used as folder separator characters. The following symbols cannot be used.

: \* ? " < > |

The default setting is the file name set on the administrator "File Names (Save)" screen.

For more details, refer to ["4.6.9 Setting a File Name Format for When Saving Scanned Data" \(page 72\)](#).



- The following file names cannot be used:

- CON
- PRN
- AUX
- CLOCK\$
- NUL
- COM0 to COM9
- LPT0 to LPT9

- If the file format is changed in "Scan Settings", the file name set on the "File Names (Save)" screen is reset in the "Save As" field.

## 6. Select if existing files with the same name are to be overwritten.

The default setting is [No].

If a file name already exists on the network, the existing file will not be overwritten and the scanned data will be lost. Whether or not the file was successfully saved can be checked in the user log.

For more details about accessing the user log, refer to ["6.12 Checking the User Log"](#) (page 410).

## 7. Press the [Scan] button.

When [Scan Viewer] is Off, this will be a [Scan&Save] button.

⇒ Scanning starts.

Each page is briefly shown on the screen as it is scanned.

The maximum number of pages that can be scanned is 999.

When [Blank Page Skip] is enabled, the number of scanned pages excluding skipped blank pages is shown.

Additional pages can be scanned in place of skipped blank pages, until the maximum number of scanned pages is reached.

When the scan has completed, the "Scan Viewer" screen opens.

For more details about the "Scan Viewer" screen, refer to ["6.11 Editing the Scanned Data in the Scan Viewer"](#) (page 405).




- [Scan Viewer] is initially "On".
- When the [Scan&Save] button is pressed (when [Scan Viewer] is "Off"), after the last page is displayed on the "Scanning" screen, the scan data is saved, and the touch panel screen returns to the "Main Menu".  
For more details, refer to ["6.10 Enabling/Disabling the Scan Viewer"](#) (page 402).


## 8. Check the scanned data.

For more details about the "Scan Viewer" screen, refer to ["6.11 Editing the Scanned Data in the Scan Viewer"](#) (page 405).

- 
- 9. On the "Scan Viewer" screen, press the [Save] button.
    - ⇒ The specified file name is used to save the scanned data in the selected network folder.



Saving scan data in Folder01



- ⇒ The "Main Menu" screen is shown again.



If the saving to the network folder fails, an error message with the following title is sent by e-mail from the scanner to the e-mail address registered in the LDAP server for the currently logged-in user.

Network Scanner (XXXX) Error



## 6.8 Saving the Scanned Data in a SharePoint Folder

1. On the "Main Menu" screen, press the [Scan to SharePoint] button.

⇒ The "Scan to SharePoint" screen appears.



Scan preferences can be changed by pressing the [Scan Settings] button. For more details, refer to ["6.9 Setting the Scan Options" \(page 365\)](#).


2. Press the [Select] button for the "Save in" field.

⇒ The "Folder List" screen appears.

### 3. Select a folder.



- On the "Folder List" screen, select a folder and press the [Details] button to view the details of the selected folder. If a folder name is too long for one line, it will wrap onto the next line. Any hidden parts of the name may be revealed by finger dragging and scrolling.
- Only folders which are in the list may be selected. Only the administrator may add folders to the list, or edit the details of sites or folders already on the list. For more details about adding folders, refer to "[4.7.15 Setting the SharePoint Folders](#)" (page 145).



4. Press the [OK] button.



According to the setting, user authentication may be required to access the SharePoint server. In this case, the "Sign In" screen is shown. Perform the following procedure for authentication.

1. Enter the "User Name", "Password", and "Domain". Passwords are case sensitive.

2. Press the [OK] button.

⇒ This returns you to the "Scan to SharePoint" screen.

5. In the "Save as" field, enter a file name for the scanned data to be saved.

File names may be up to 113 characters long. \ and / are used as folder separator characters. The following symbols cannot be used.

~ " # % & \* : < > ? { | }

The default setting is the file name set on the administrator "File Names (Save)" screen.

For more details, refer to ["4.6.8 Changing the Admin Password" \(page 71\)](#).




- The following file names cannot be used:
  - CON
  - PRN
  - AUX
  - CLOCK\$
  - NUL
  - COM0 to COM9
  - LPT0 to LPT9
- If the file format is changed in "Scan Settings", the file name set on the "File Names (Save)" screen is reset in the "Save As" field.

6. Press the [Document Splitting] button.

⇒ The "Document Splitting" screen appears.

Configure the settings to split a file of scanned data into multiple files when the file size exceeds the maximum file limit.



1. In the "Max. File Size" field, enter the maximum file size at which a file is to be split into multiple files.

The default setting is 45. The value can be specified within the range of 1 to 45 MB. The number of pages that can be saved in a file varies according to the resolution and color mode of scanned data.

Approximate page file sizes are shown below.

Page sizes are estimated for when the paper size is specified as A4, and the color mode and resolution are changed accordingly, from default scan settings.

Actual paper size: A4 size (general catalog)

File format: PDF


Scanner paper size setting: A4

Resolution	Approximate File Size of a Page (KB)		
	RGB Color	Grayscale	Black & White
150 dpi	310		124
200 dpi	550		220
300 dpi	1250		500
600 dpi	5000		2000



- When the file size of a single page exceeds the specified maximum file size, the page is saved as one file.
- The file name format of split files is:  
"original\_file\_name-file\_number-total\_number\_of\_split\_files"  
File numbers and the total number of split files are added in 4 digits. For example, if the total number of split files is "5", it will be shown as "0005".

2. Press the [OK] button.  
⇒ The "Scan to SharePoint" screen is shown again.
7. In "Content Type", set the content type for the scanned data to be managed on the SharePoint server.
  1. Press the [Select] button for the "Content Type" field.  
⇒ A content type selection screen appears.
  2. Select a content type, and press the [OK] button.






⇒ The selected content type is set.

According to the selected content type, a list of properties defined on the SharePoint server is shown in the "Scan to SharePoint" screen.

8. Set properties in either of the following ways.

- Enter properties directly in the "Scan to SharePoint" screen.
- Press the button on the side of a property to be edited, and set the property in the "Edit Properties" screen.

-  is shown for a property setting that can be directly entered. These settings can also be directly entered on the "Scan to SharePoint" screen.
-  is shown for a property to be set by selecting an available item.



- The following properties cannot be set via the "Edit Properties" screen:
  - Description
  - Categories
  - Date Picture Taken
- If properties that cannot be set are required when saving to a SharePoint folder, the file will be saved in a checked out state. The checked out state can be released once the mandatory fields have been set. Checked out files cannot be overwritten.





The following properties can be set.

- Single line of text
- Multiple lines of text
- Choice
- Number
- Currency
- Date and Time
- Yes/No
- Person or Group
- Hyperlink or Picture

9. Select if existing files with the same name are to be overwritten.

The default setting is [No].

If a file name already exists, the existing file will not be overwritten and the scanned data will be lost. Whether or not the file was successfully saved can be checked in the user log. For more details about accessing the user log, refer to ["6.12 Checking the User Log"](#) (page 410).

10. Press the [Scan] button.

When [Scan Viewer] is Off, this will be a [Scan&Save] button.

⇒ Scanning starts.

Each page is briefly shown on the screen as it is scanned.

The maximum number of pages that can be scanned is 999.

When [Blank Page Skip] is enabled, the number of scanned pages excluding skipped blank pages is shown.

Additional pages can be scanned in place of skipped blank pages, until the maximum number of scanned pages is reached.

When the scan has completed, the "Scan Viewer" screen opens.

For more details about the "Scan Viewer" screen, refer to ["6.11 Editing the Scanned Data in the Scan Viewer"](#) (page 405).



- [Scan Viewer] is initially "On".
- When the [Scan&Save] button is pressed (when [Scan Viewer] is "Off"), after the last page is displayed on the "Scanning" screen, the scan data is saved, and the touch panel screen returns to the "Main Menu".  
For more details, refer to ["6.10 Enabling/Disabling the Scan Viewer"](#) (page 402).

11. Check the scanned data.

For more details about the "Scan Viewer" screen, refer to ["6.11 Editing the Scanned Data in the Scan Viewer"](#) (page 405).


---

12. On the "Scan Viewer" screen, press the [Save] button.



- When a file is overwritten, the properties of the existing file are replaced by those of the new file.
- When multiple files are saved in TIFF or JPEG format, identical properties are set to all the files.
- If required items other than "Single line of text" or "Multiple lines of text" are set for the properties of the specified folder content types, files saved in the SharePoint folder will be checked out. To change the checkout status, enter values for the required items via a Web browser, and then check in the files.

⇒ The specified file name is used to save the scanned data in the selected SharePoint folder.



Saving scan data in SharePoint Folder1



⇒ The "Main Menu" screen is shown again.




## 6.9 Setting the Scan Options

On the following screens, press the [Scan Settings] button to access the "Scan Settings" screens.


- "Send e-Mail" screen
- "Send Fax" screen
- "Print" screen
- "Save" screen
- "Scan to SharePoint" screen

The "Scan Settings" screen contains the following items.


- [Basic] tab




- [Save] tab



- [Quality] tab



- [Advanced] tab



The following two classes of setting options are available.

- Default  
These are the factory settings. To put a high priority on the scan speed, press the [Default] button.
- Custom  
This is shown when the user has customized any scanning preferences from the "Default" option.  
Press each scan option button to set it as desired.  
Function settings (for e-Mail, Fax, Print, Save) are saved for each user, and will be used each time that user logs in.  
For details, refer to the sections from "6.9.1 Carrier Sheet" (page 372) onward.

The following scan option settings are used if the Default settings are selected.

Tab	Option	Default					When Custom, see...
		e-Mail	Fax	Print	Save	Scan to SharePoint	
Basic	Carrier Sheet	Off	Off	Off	Off	Off	<a href="#">page 372</a>
	Color Mode	Auto	Black & White(*)	Auto	Auto	Auto	<a href="#">page 373</a>
	Paper Size	Auto	Auto	Auto	Auto	Auto	<a href="#">page 374</a>
	Resolution	200dpi	200dpi	200dpi	200dpi	200dpi	<a href="#">page 378</a>
	Scan Mode	Duplex	Duplex	Duplex	Duplex	Duplex	<a href="#">page 379</a>

Tab	Option	Default					When Custom, see...
		e-Mail	Fax	Print	Save	Scan to SharePoint	
Save	File Format	PDF	TIFF(*)	JPEG(*)	PDF	PDF	<a href="#">page 380</a>
	Searchable PDF	No	No(*)	No(*)	No	No	<a href="#">page 382</a>
	PDF Password	No	No(*)	No(*)	No	No	<a href="#">page 385</a>
	Compression	Medium	Medium(*)	Low(*)	Medium	Medium	<a href="#">page 387</a>
Quality	Brightness	Medium	Medium	Medium	Medium	Medium	<a href="#">page 390</a>
	Contrast	Medium	Medium	Medium	Medium	Medium	<a href="#">page 391</a>
	Sharpness	None	None	None	None	None	<a href="#">page 392</a>
	Dropout Color	None	None	None	None	None	<a href="#">page 393</a>
	Background Removal	Medium	Medium	Medium	Medium	Medium	<a href="#">page 394</a>
Advanced	Blank Page Skip	Auto	Auto	Off	Auto	Auto	<a href="#">page 395</a>
	Page Orientation	Auto	Off	Off(*)	Auto	Auto	<a href="#">page 396</a>
	Multifeed Setup	Ultrasonic	Ultrasonic	Ultrasonic	Ultrasonic	Ultrasonic	<a href="#">page 399</a>
	Edge Cropping	Off	Off	Off	Off	Off	<a href="#">page 400</a>

(\*): Fixed value. Cannot be changed.



- The selected setting is displayed to the right of each button.
- Settings changed before the previous logout are shown by red characters for each regular user.
- When the "Scan Settings" screen is opened from the "Send Fax" or "Print" screen, the [Save] tab is not displayed.

Setting these scan options may influence other scan settings items.

- Setting an option may cause other option settings to become invalid.
- Other option settings may cause these option settings to become invalid.

Scan option settings may be influenced in the following ways.

Tab	Option		Setting which become invalid	Conditions of setting which become invalid
Basic	Carrier Sheet		<ul style="list-style-type: none"> <li>● Paper Size</li> <li>● Resolution, "600dpi"</li> <li>● Scan Mode</li> <li>● Brightness</li> <li>● Contrast</li> <li>● Dropout Color</li> <li>● Background Removal</li> <li>● Blank Page Skip</li> <li>● Page Orientation, other than "Auto"</li> <li>● Multifeed Setup</li> </ul>	—
	Color Mode	Auto	<ul style="list-style-type: none"> <li>● Paper Size, long page mode</li> <li>● JPEG file format</li> <li>● Dropout Color</li> </ul>	—
		RGB Color	<ul style="list-style-type: none"> <li>● Dropout Color</li> </ul>	—
		Grayscale	<ul style="list-style-type: none"> <li>● Dropout Color, "None" (when Resolution is "600dpi")</li> <li>● High Compression for Color PDF</li> </ul>	—
		Black & White	<ul style="list-style-type: none"> <li>● JPEG file format</li> <li>● Compression</li> </ul>	—

Tab	Option		Setting which become invalid	Conditions of setting which become invalid
Basic	Paper Size	Auto	● Resolution, "600dpi"	● Carrier Sheet
		Long Page Mode	<ul style="list-style-type: none"> <li>● Resolution, "600dpi"</li> <li>● Searchable PDF</li> <li>● Blank Page Skip</li> <li>● Page Orientation</li> <li>● Multifeed Setup</li> </ul>	<ul style="list-style-type: none"> <li>● Carrier Sheet</li> <li>● Color Mode, "Auto"</li> </ul>
		Other than Auto and Long Page Mode	—	● Carrier Sheet
	Resolution	600dpi	<ul style="list-style-type: none"> <li>● Searchable PDF, "All Pages" and "Pages"</li> <li>● High Compression for Color PDF</li> <li>● Dropout Color, "None" (when Color Mode is "Grayscale")</li> <li>● Page Orientation, other than "Auto"</li> </ul>	<ul style="list-style-type: none"> <li>● Carrier Sheet</li> <li>● Paper Size, "Auto" and long page mode</li> </ul>
		Other than 600dpi	—	—
	Scan Mode		—	● Carrier Sheet
Save	File Format	PDF	—	—
		JPEG	<ul style="list-style-type: none"> <li>● Searchable PDF</li> <li>● PDF Password lock</li> </ul>	● Color Mode, "Auto" or "Black & White"
		TIFF MTIFF	● Compression, "High Compression for Color PDF"	—
	Searchable PDF	First Page	—	<ul style="list-style-type: none"> <li>● Paper Size, long page mode</li> <li>● Other than PDF output file format</li> </ul>
		All Pages Pages	—	<ul style="list-style-type: none"> <li>● Paper Size, long page mode</li> <li>● Other than PDF output file format</li> <li>● Resolution, "600dpi"</li> </ul>
	Require PDF Password		—	● Other than PDF output file format

Tab	Option		Setting which become invalid	Conditions of setting which become invalid
Save	Compression	High Compression for Color PDF	—	<ul style="list-style-type: none"> <li>● Color Mode, "Grayscale" or "Black &amp; White"</li> <li>● Other than PDF output file format</li> <li>● Resolution, "600dpi"</li> </ul>
		Other than High Compression for Color PDF	—	<ul style="list-style-type: none"> <li>● Color Mode, "Black &amp; White"</li> </ul>
Quality	Brightness		—	<ul style="list-style-type: none"> <li>● Carrier Sheet</li> </ul>
	Contrast		—	<ul style="list-style-type: none"> <li>● Carrier Sheet</li> </ul>
	Sharpness		—	—
	Dropout Color	None	—	<ul style="list-style-type: none"> <li>● Carrier Sheet</li> <li>● Color Mode, "Auto" or "RGB Color"</li> <li>● Resolution, "600dpi" (when Color Mode is "Grayscale")</li> </ul>
		Other than None	—	<ul style="list-style-type: none"> <li>● Carrier Sheet</li> <li>● Color Mode, "Auto" or "RGB Color"</li> </ul>
Background Removal		—	<ul style="list-style-type: none"> <li>● Carrier Sheet</li> </ul>	
Advanced	Blank Page Skip		—	<ul style="list-style-type: none"> <li>● Carrier Sheet</li> <li>● Paper Size, long page mode</li> </ul>
	Page Orientation	Auto	—	<ul style="list-style-type: none"> <li>● Paper Size, long page mode</li> </ul>
		Other than Auto	—	<ul style="list-style-type: none"> <li>● Carrier Sheet</li> <li>● Paper Size, long page mode</li> <li>● Resolution, "600dpi"</li> </ul>
	Multifeed Setup		—	<ul style="list-style-type: none"> <li>● Carrier Sheet</li> <li>● Paper Size, long page mode</li> </ul>
	Edge Cropping		—	—

## 6.9.1 Carrier Sheet

Set whether or not to use a Carrier Sheet. If a Carrier Sheet is to be used, set the output size of the scanned image.

1. On the "Scan Settings" screen, select the [Basic] tab.
2. Press the [Carrier Sheet] button.  
⇒ The "Carrier Sheet Output Image Size" screen appears.
3. If a Carrier Sheet is to be used, select the output size for the scanned image.

### Carrier Sheet Output Image Size

When this option is used, the front and back scans are stitched together into a single image.



Fold the oversize document being scanned, and fully insert it into the carrier sheet, with the fold against the edge with the thick line.



Carrier Sheet Setup	Status
Off	Scan without using a Carrier Sheet
A3	Scan with a Carrier Sheet, and output as A3 size (297 × 420mm)
B4	Scan with a Carrier Sheet, and output as B4 size (257 × 364mm)
11" × 17"	Scan with a Carrier Sheet, and output as a "11 × 17 inch" size (279.4 × 431.8mm)

\*: All paper sizes are of portrait orientation.


⇒ This returns you to the "Scan Settings" screen. The selected setting is displayed to the right of the [Carrier Sheet] button.



## 6.9.2 Color Mode

Set whether the document is scanned in "color" or "black and white".

1. On the "Scan Settings" screen, select the [Basic] tab.
2. Press the [Color Mode] button.  
⇒ The "Color Mode" screen appears.
3. Select the color mode.



Color Mode	Description
Auto	Automatically decides whether to scan in color or in black and white based on document contents.
RGB Color	Scans documents in color.
Grayscale	Scans documents in grayscale.
Black & White	Scans documents in black and white.

- ⇒ Selecting a color mode returns you to the "Scan Settings" screen.  
The selected mode is displayed to the right of the [Color Mode] button.



Usually, the color mode should be set as [Auto].

If this setting is specified, there is no need to change the color mode each time you scan a document.

Note that black and white mode may be automatically selected for the following kinds of documents:


- Faintly toned nonwhite papers
- Documents with only a minor amount of color
- Documents printed in gray or other close-to-black colors.

To ensure such documents are scanned in color mode, press the [RGB Color] button on the "Color Mode" screen.

## 6.9.3 Paper Size

Set a paper size for the scan data.

1. On the "Scan Settings" screen, select the [Basic] tab.
2. Press the [Paper Size] button.  
⇒ The "Paper Size" screen appears.
3. Select a paper size for the scan data.



Button	Paper size (mm)	Button	Paper size (mm)
A4	210 × 297	Letter	215.9 × 279.4
A5	148 × 210	Legal	215.9 × 355.6
A6	105 × 148	Executive	184.2 × 266.7
B5	182 × 257	Postcard	100 × 148
B6	128 × 182	Business Card	51 × 89

\*: All paper sizes are of portrait orientation.

⇒ Selecting a paper size returns you to the "Scan Settings" screen. The selected size is displayed to the right of the [Paper Size] button.



When the [Auto] setting is used, the paper size is set to the same size (Maximum: 215.9 × 355.6mm) as the actual document being scanned. However, if using any of the following types of documents, the automatic paper size detection may not function correctly:

- Paper of weight less than 52g/m<sup>2</sup> (14lb)
- Documents that are not rectangular
- Documents with margins that are filled with dark colors




- If a paper size other than [Auto] is selected and only one side of the documents is scanned, artwork on the reverse side of the paper may bleed through onto the front side scan. If this happens, blank pages may not be recognized as such, and thus may not be skipped by the "Skip Blank Page" function. For more details, refer to ["6.9.15 Blank Page Skip" \(page 395\)](#).
- When [Custom] settings are used, any paper size for the scan data can be specified.
  1. Press the [Custom] button.  
⇒The "Custom Paper Size" screen appears.
  2. Enter the paper size for the scan data.  
The size ranges that can be set are:  
Width: 2 to 8.5in (50.8 to 216mm)  
Height: 2.91 to 14in (74 to 355.6mm)  
If the height is 14in or longer, the paper size setting must be set to allow long pages. For more details, refer to ["Long Page Mode" \(page 376\)](#).

3. Press the [OK] button.  
⇒The custom paper size is set.

## ■ Long Page Mode

When scanning pages which are longer than standard documents, the "Allow long pages" setting must be specified.

1. On the "Scan Settings" screen, select the [Basic] tab.
2. Press the [Paper Size] button.  
⇒ The "Paper Size" screen appears.
3. Press the [Custom] button.



⇒ The "Custom Paper Size" screen appears.

4. For "Allow long pages?", press the [Yes] button.



5. Enter the paper size for the scan data.

The size ranges that can be set are:

Width: 2 to 8.5 in (50.8 to 216 mm)

Height: 2.91 to 34 in (74 to 863.6 mm)

6. Press the [OK] button.


⇒ This returns you to the "Scan Settings" screen. "Custom" is displayed to the right of the [Paper Size] button.

## 6.9.4 Resolution

Changing the resolution level affects the scan data in the following ways.

	High resolution	Low resolution
Scan speed	Slow	Fast
Scan quality	High	Low
File size	Large	Small

1. On the "Scan Settings" screen, select the [Basic] tab.
2. Press the [Resolution] button.  
⇒ The "Resolution" screen appears.
3. Select a resolution level.




- ⇒ Selecting a resolution level returns you to the "Scan Settings" screen. The selected level is displayed to the right of the [Resolution] button.

### 6.9.5 Scan Mode

Set whether one side or both sides of documents are scanned.

1. On the "Scan Settings" screen, select the [Basic] tab.
2. Press the [Scan Mode] button.  
⇒ The "Scan Mode" screen appears.
3. Select [Simplex] if only the front sides of the documents are to be scanned. Select [Duplex] if both front and reverse sides are to be scanned.



- ⇒ Selecting a scan mode returns you to the "Scan Settings" screen. The selected mode is displayed to the right of the [Scan Mode] button.

## 6.9.6 File Format

Set the file format for the scan data.

For some scan settings, it may not be possible to select certain file formats.

Option	PDF	JPEG	TIFF	MTIFF
Searchable PDF	A	—	—	—
PDF Password	A	—	—	—
Compression	A (*1)	A	A (*1)	A (*1)

A: Format can be used, —: Format cannot be used

(\*1): Can only be used if the "Color Mode" is [Auto] or [RGB Color]

Compression also differs for certain file formats as follows:

Color Mode	Document	File Format		
		PDF	JPEG	TIFF/MTIFF
Auto	Color	JPEG High Compression for Color PDF	JPEG	JPEG
	Black & White (*)	MMR	(NA)	MMR
RGB Color	Color or Black & White	JPEG High Compression for Color PDF	JPEG	JPEG
Grayscale	Color or Black & White	JPEG	JPEG	JPEG
Black & White	Color or Black & White	MMR	(NA)	MMR


(NA): Not available





- When PDF format is selected, select whether or not to use "High Compression for Color PDF" mode. When "High Compression for Color PDF" is selected, characters and backgrounds on the document are compressed separately. In order to do this, the file size of the document that mostly consists of text characters becomes smaller while keeping the quality of the characters as they are. However, this mode is not appropriate for scanning photographs or pictures since these graphical materials are recognized as background and compressed as such, causing degradation in the scanned image. If this setting is specified, the contrast of the image may become higher.
- If PDF format is selected, Adobe Reader 4.0 or later is required to view the created PDF file.

1. On the "Scan Settings" screen, select the [Save] tab.
2. Press the [File Format] button.  
⇒ The "File Format" screen appears.
3. Select a file format.



- ⇒ Selecting a file format returns you to the "Scan Settings" screen. The selected format is displayed to the right of the [File Format] button.

---

## 6.9.7 Searchable PDF

When the file format is PDF, the scanned data can be converted to a searchable PDF.



The scanner may fail to correctly recognize the following kinds of documents (characters) as text. However, by changing color mode and/or improving image quality for scanning, such a document may be successfully recognized.


- Handwritten documents
  - Documents including smaller characters and scanned in low quality
  - Skewed documents
  - Documents written in languages other than English
  - Documents including texts written in italic characters
  - Superscript/subscript letters and complex mathematical formulas
  - Characters are written against an unevenly-colored or patterned background
    - Characters to which effects (Shadow, Outline, and the like) are applied
    - Shaded characters
  - Documents of complex layout as well as documents including unreadable characters due to print-through and smudges
- (For such documents, the recognition time may be long)



Creating a searchable PDF will take some additional time.

1. On the "Scan Settings" screen, select the [Save] tab.
2. Press the [Searchable PDF] button.
  - ⇒ The "Searchable PDF" screen appears.


3. Select which pages are to be made searchable in the PDF.



Searchable PDF	Description
No	A searchable PDF is not created.
First Page	Only the first page of the PDF is made searchable.
All Pages	All pages of the PDF are made searchable.
Pages...	Only the specified range of pages in the PDF is made searchable.



- The page numbers set here correspond to those shown on the Preview and "Scan Viewer" windows.
- After pressing the [Pages] button, the "Searchable PDF for Pages" screen appears. Multiple ranges of pages cannot be set.
  1. Press the [Pages] button.  
⇒The "Searchable PDF for Pages" screen appears.
  2. Enter a start page and end page.  
Values between 1 and 999 may be entered.



First Searchable Page :  ~ Last Searchable Page :

1 ≤ First Page ≤ Last Page ≤ 999


These numbers are the same as those in the Preview and Scan Viewer.




3. Press the [OK] button.
  - If [First Page], [All Pages], or [Pages] is selected, [Text Recognition Language] can also be selected.
    1. Press the [Text Recognition Language] button.  
⇒The "Text Recognition Language" screen appears.
    2. Select the searchable language for the PDF.
    3. Press the [OK] button.  
⇒This returns you back to the "Searchable PDF" screen. The selected range is displayed to the right of the [Text Recognition Language] button.
4. Press the [OK] button.  
⇒ This returns you to the "Scan Settings" screen. The selected range is displayed to the right of the [Searchable PDF] button.

## 6.9.8 PDF Password

PDF files can be locked with a user-specified password.



1. On the "Scan Settings" screen, select the [Save] tab.
2. Press the [PDF Password] button.  
⇒ The "Require PDF Password" screen appears.
3. Select whether or not a password is required.



⇒ When [Yes] is selected, the "PDF Password" screen appears.

4. Enter a password and confirm password.

Passwords may be up to 16 characters long.

In addition to alphanumeric characters, spaces and the following symbols can be used:

! " # \$ % & ' ( ) \* + , - . / : ; < = > ? @ [ \ ] ^ \_ ` { | } ~

"Password" and "Confirm Password" are case sensitive.

PDF Password Caps Lock   
Num Lock

Password :

Confirm Password :





- The "Caps Lock" indicator is on if the keyboard's Caps Lock is set.
- The "Num Lock" indicator is on if the keyboard's Num Lock is set.

5. Press the [OK] button.

⇒ The PDF will be created with password protection.



On the "Require PDF Password" screen, pressing the [No] button cancels the set password.

The next time a password is set, pressing the [Yes] button enters the previously set password by default.

## 6.9.9 Compression

When [Auto], [RGB Color], or [Grayscale] is selected for the "6.9.2 Color Mode" (page 373), it is also possible to set the compression level.

Setting a compression level (1 to 5) reduces the file size when scanning documents such as photographs or figures.

Changing the compression level affects the scanned data in the following ways.

	High compression	Low compression
Quality	Low	High
File size	Small	Large

1. On the "Scan Settings" screen, select the [Save] tab.


2. Press the [Compression] button.

⇒ The "Compression" screen appears.

3. Select a compression level.

The lower the selected compression level is, the higher the quality of the resulting scan will be, but at the expense of a larger file.

When PDF format is selected in "6.9.6 File Format" (page 380), "High Compression for Color PDF" can be used.



⇒ Selecting a compression level returns you to the "Scan Settings" screen. The selected level is displayed to the right of the [Compression] button.



- When "High Compression for Color PDF" is selected, characters and backgrounds on the document are compressed separately. In order to do this, the file size of the document that mostly consists of text characters becomes smaller while keeping the quality of the characters as they are. However, this mode is not appropriate for scanning photographs or pictures since these graphical materials are recognized as background and compressed as such, causing degradation in the scanned image. If this setting is specified, the contrast of the image may become higher.
- If "High Compression for Color PDF" is selected, according to the type of document, the file size may be larger than if a standard compression level is used.
  - Documents with many photographs or figures and only a few characters
  - Complex layout documents with multiple columns
  - Documents which have a background pattern behind characters
- For documents with many characters scanned at 300dpi resolution, a smaller file size than that of High Compression for Color PDF is possible.
- When one color page is scanned, the file size criteria are shown as follows. These numbers are for reference, other documents may vary in size.

Actual paper size: A4 size (general catalog)

File format: PDF

Scanner paper size setting: A4

- File size (KB) for color files

Resolution	Low	Medium Low	Medium	Medium High	High	High Compression for Color PDF
150dpi	406	232	197	153	94	158
200dpi	647	358	302	238	149	140
300dpi	1319	693	580	448	272	115
600dpi	3827	2034	1736	1377	854	—

- File size (KB) for grayscale files

Resolution	Low	Medium Low	Medium	Medium High	High	High Compression for Color PDF
150dpi	380	233	186	153	85	—
200dpi	618	373	293	239	133	—
300dpi	1422	825	606	494	245	—
600dpi	3416	2147	1827	1338	720	—





- File size (KB) for black & white files


Resolution	Compression level cannot be selected
150dpi	104
200dpi	176
300dpi	382
600dpi	1430

---

## 6.9.10 Brightness

The brightness setting can be adjusted to improve the visual appearance of the scanned data.

1. On the "Scan Settings" screen, select the [Quality] tab.
2. Press the [Brightness] button.  
⇒ The "Brightness" screen appears.
3. Select a brightness level.




⇒ Selecting a brightness level returns you to the "Scan Settings" screen. The selected level is displayed to the right of the [Brightness] button.

### 6.9.11 Contrast

The color contrast setting can be adjusted to improve the visual appearance of the scan.

1. On the "Scan Settings" screen, select the [Quality] tab.
2. Press the [Contrast] button.  
⇒ The "Contrast" screen appears.
3. Select a contrast level.




- ⇒ Selecting a contrast level returns you to the "Scan Settings" screen. The selected level is displayed to the right of the [Contrast] button.

## 6.9.12 Sharpness

The sharpness setting adjusts the sharpness of characters on an image to improve the visual appearance of the scanned data. When using the sharpness setting, the sharpness level can be adjusted with this setting.

1. On the "Scan Settings" screen, select the [Quality] tab.
2. Press the [Sharpness] button.
  - ⇒ The "Sharpness" screen appears.
3. If the sharpness setting is to be used, select a sharpness level.



Sharpness	Status
None	Characters are not sharpened.
Weak	Sharpens characters at a weak level
Medium Weak	Sharpens characters at a medium weak level
Medium	Sharpens characters at a medium level
Medium Strong	Sharpens characters at a medium strong level
Strong	Sharpens characters at a strong level

- ⇒ Selecting a sharpness level returns you to the "Scan Settings" screen. The selected level is displayed to the right of the [Sharpness] button.

### 6.9.13 Dropout Color


Selecting either green, red, or blue (primary colors), removes the details of the selected color from a scanned image.

For example, if a document with black characters and a green border is scanned, only the black characters will appear on the scanned image if [Green] is selected at the dropout color.

When using the dropout color setting, the color details to be removed can be selected with this setting.



1. On the "Scan Settings" screen, select the [Quality] tab.
2. Press the [Dropout Color] button.  
⇒ The "Dropout Color" screen appears.
3. If color details are to be removed, select a color to be used as the dropout color.



Dropout Color	Status
None	Scan without removing any color details.
Red	Scan and remove all red details.
Green	Scan and remove all green details.
Blue	Scan and remove all blue details.


⇒ Selecting a dropout color returns you to the "Scan Settings" screen. The selected setting is displayed to the right of the [Dropout Color] button.




## 6.9.14 Background Removal

The background of a scanned image can be removed to make image clearer. The level of background removal can be adjusted.

1. On the "Scan Settings" screen, select the [Quality] tab.
2. Press the [Background Removal] button.  
⇒ The "Background Removal" screen appears.
3. Select a background removal level.



⇒ Selecting a background removal level returns you to the "Scan Settings" screen. The selected level is displayed to the right of the [Background Removal] button.

 When [Image Quality] is selected for "Operating Mode" on the "General Scanner Settings" screen, the background removal level cannot be adjusted. For details, refer to ["4.6.13 Setting General Scanner Settings" \(page 83\)](#).

### 6.9.15 Blank Page Skip

The scan process can be set to skip any blank pages in the scanned document.


For example, when a stack of documents containing both two-sided and one-sided documents is scanned in duplex scan mode, this feature removes only the reverse side (i.e. blank page) of one-sided documents from the scanned data.



- If the Brightness setting (see "6.9.10 Brightness" (page 390)) is set to [Dark] or [Medium Dark], blank pages may not be recognized as such by the scanner.
- No scanned data is produced if all of the sheets in the document stack are recognized as blank pages.
- The following types of documents may be accidentally recognized as blank pages.  
Before discarding the scanned documents, check for pages accidentally removed from the scanned data. If any pages have been removed, the document may need to be re-scanned.
  - Almost blank pages containing only a few characters
  - Page of only one color (including black), without any patterns, lines, or characters.



1. On the "Scan Settings" screen, select the [Advanced] tab.
2. Press the [Blank Page Skip] button.  
⇒ The "Blank Page Skip" screen appears.
3. Select whether or not blank pages are to be skipped.



- ⇒ This returns you to the "Scan Settings" screen. The selected setting is displayed to the right of the [Blank Page Skip] button.

## 6.9.16 Page Orientation

Automatically rotates each scanned data page that contains text through 0°, 90°, 180°, or 270°, so the text is upright.



This function determines a document orientation based on Roman characters printed on the document. Therefore, it may not work properly for the following kinds of documents: When scanning such documents, do not set automatic page orientation.

- Documents with many extremely large/small characters
- Documents on which the pitch of lines or characters is extremely narrow, or characters overlap
- Documents with many characters that contact underlines or ruled lines
- Documents with many photographs or figures and only a few characters
- Documents which have a background pattern behind characters
- Documents with characters printed in various direction (e.g. plans)
- Documents written in languages other than English
- Documents with only capital letters
- Handwritten documents
- Unclear or smeared characters

1. On the "Scan Settings" screen, select the [Advanced] tab.
2. Press the [Page Orientation] button.  
⇒ The "Page Orientation" screen appears.
3. Select whether or not automatic page orientation is required.







### Page Orientation



Should page orientation be used?

If every page is to be rotated in the same direction, set the angle.  
(Only "Off" and "Auto" are allowed when Carrier Sheet is used or for "600dpi")

What is the bind direction? (Only available for "Duplex" scans.)




Page Orientation	Status
Off	Scanned page is not automatically rotated.
Auto	Automatically rotates scanned page.
Top-feed 	Scanned page is not rotated.
Left-feed 	Rotates scanned page 90 degrees left.
Right-feed 	Rotates scanned page 90 degrees right.
Bottom-feed 	Rotates scanned page 180 degrees.
Long Edge 	<p>This setting can only be used if the [Top-feed], [Left-feed], [Right-feed], or [Bottom-feed] button is selected.</p> <p>Select this setting when scanning a document with opposing left and right pages.</p> <p>The scanned data is output with the same orientation as the original document.</p> <div style="text-align: center;">  </div>

Page Orientation	Status
<p data-bbox="288 315 424 349">Short Edge</p> 	<p data-bbox="512 315 1415 387">This setting can only be used if the [Top-feed], [Left-feed], [Right-feed], or [Bottom-feed] is selected.</p> <p data-bbox="512 398 1415 468">Select this setting when scanning a document with opposing top and bottom pages.</p> <p data-bbox="512 479 1383 548">The front side of the document is output with the same orientation as the original data, whereas the data on the reverse side is rotated 180 degrees.</p> <div data-bbox="512 560 1431 1003" style="text-align: center;">  </div>

⇒ This returns you to the "Scan Settings" screen. The selected setting is displayed to the right of the [Page Orientation] button.

HINT



Irrespective of what page orientation is decided, pages may still be manually rotated as desired in the "Scan Viewer" screen.


For more details about the "Scan Viewer" screen, refer to ["6.11 Editing the Scanned Data in the Scan Viewer"](#) (page 405).

### 6.9.17 Multifeed Detection (Layer and Length)

"Multifeed" is an error that occurs when two or more sheets are fed simultaneously into the scanner by the ADF. The scanner can be set to detect multifeeds and stop the scan with an error message. Multifeeds are to be detected by layer and length. The following explains how to set whether or not multifeeds are to be detected, and setup multifeed detection method.

For multifeed requirements, refer to "A.5 Multifeed Detection Conditions" (page 484).

1. On the "Scan Settings" screen, select the [Advanced] tab.
2. Press the [Multifeed Setup] button.  
⇒ The "Multifeed Setup" screen appears.
3. If multifeeds are to be detected, select which detection method is to be used.



Multifeed Setup	Status
None	Multifeeds are not detected. If scanning plastic cards, select [None]. For more details about scanning plastic cards, refer to "A.2 Paper Requirements" (page 479).
Ultrasonic	Multifeeds are detected by layer.
Length	Multifeeds are detected by length.
Both	Multifeeds are detected by both layer and length.



An error will occur if the [Length] or [Both] multifeed setting is used with the [Auto] paper size, and the document bundle being scanned contains different size pages.




- ⇒ This returns you to the "Scan Settings" screen. The selected setting is displayed to the right of the [Multifeed Setup] button.

## 6.9.18 Edge Cropping


For scanned data, the width of the area for edge cropping can be adjusted, so that unwanted sections are not scanned.

If using edge cropping, the width of the edges to be cropped can be adjusted with this setting.

1. On the "Scan Settings" screen, select the [Advanced] tab.
2. Press the [Edge Cropping] button.  
⇒ The "Edge Cropping" screen appears.
3. If edge cropping is to be used, enter the width of the edges to be cropped.



Edge Cropping Setup	Status
Off	Scan without cropping edges.
On	Scan and crop edges. Enter a value for Top/Bottom and Left/Right from 0 to 50. Enter values in units of 1mm.




4. Press the [OK] button.

⇒ This returns you to the "Scan Settings" screen. The selected setting is displayed to the right of the [Edge Cropping] button.



- If the edge cropping width (top to bottom/left to right edge cropping width total) is larger than the document, the edge cropping setting is not applied.
- If page orientation is set, edge cropping is performed after the document orientation is corrected. In the following example, [Left-feed] is selected for page orientation.




## 6.10 Enabling/Disabling the Scan Viewer

The "Scan Viewer" can be set to appear before the scanned data is processed.

The scanned data can be checked and edited on the "Scan Viewer". For details, refer to ["6.11 Editing the Scanned Data in the Scan Viewer" \(page 405\)](#).

If desired, in the following screens, the "Scan Viewer" can be set to be appear before the scanned data is finally processed.

- "Send e-Mail" screen
- "Send Fax" screen
- "Print" screen
- "Save" screen
- "Scan to SharePoint" screen
- "Job Menu" screen



The following explains how to enable or disable the "Scan Viewer" using the "Send e-Mail" screen.

1. On the "Send e-Mail" screen, press the [Scan Viewer] button.
  - ⇒ Pressing the [Scan Viewer] button will toggle the setting back and forth between "On" and "Off".

The screenshot shows the "Send e-Mail" screen with the following elements:

- Header: "Send e-Mail" and status indicators for "Caps Lock" and "Num Lock".
- Fields: "To:", "Cc:", "Bcc:", "Subject:", "Body:", "File Name:", and "From:".
- Buttons: "Cancel", "Scan Settings", "Default", "Scan Viewer On", and "Scan".

Operations after scanning vary according to whether the "Scan Viewer" is set to "On" or "Off".  
 If sending an e-mail, scan operation proceeds as follows:

**When "Scan Viewer" is "On"  
 and sending an e-mail**

**When "Scan Viewer" is "Off"  
 and sending an e-mail**

On the "Send e-Mail" screen, press the [Scan] button.	On the "Send e-Mail" screen, press the [Scan&Send] button.
---	--



Documents are scanned.



The scanned data is shown on the "Scan Viewer" screen and may be edited.




On the "Scan Viewer" screen, check and edit the scanned data, and then press the [Send] button.




The scanned data is sent as an e-mail attachment.



- During the scan, the following screen is shown.  
The file size is shown in units of 10KB on the right of the screen.  
If "High Compression for Color PDF" has been selected, the pre-compression file size is shown.  
Note that because the final output file has not been created yet, the actual file size may differ from the estimated value shown.  
Also note that skipped blank pages are not included in the total file size page count.



- When the "Scan Viewer" is set to "Off", after the last page has been scanned, the [Cancel] button is displayed for 5 seconds.




If the [Cancel] button is pressed, a confirmation message appears. When the [OK] button is pressed, the scanned data is deleted and the screen returns to one of the following:

- Send e-Mail
- Send Fax
- Print
- Save
- Scan to SharePoint
- Job Menu



## 6.11 Editing the Scanned Data in the Scan Viewer

When the "Scan Viewer" is set to "On", the scanned data can be checked and edited in the "Scan Viewer".





---


## 6.11.1 Viewing a Scanned Page


The scanned data shown in the "Scan Viewer" screen can be displayed as actual or reduced size. The scanned data can be moved by dragging it across the screen.

1. On the "Scan Viewer" screen, use the following buttons to scroll through the pages of scanned data.


When  is pressed, the top page of the scanned data will be shown.


When  is pressed, the previous page of the scanned data will be shown.


When  is pressed, the next page of the scanned data will be shown.

When  is pressed, the last page of the scanned data will be shown.

2. Check the contents of the page shown.

When  is pressed, the scanned data will be shown without any magnification or reduction.

When  is pressed, the width of the scanned data will be scaled to fit the "Scan Viewer" screen.


When  is pressed, the height of the scanned data will be scaled to fit the "Scan Viewer" screen.


## 6.11.2 Rotating a Scanned Page


The scanned data showed on the "Scan Viewer" screen can be rotated 90 degrees right or left, or 180 degrees.


If the scanned data is rotated 90 degrees, the edited scanned data, in its rotated condition, can be sent as an e-mail attachment, by fax, print, or saved to a network folder.

1. On the "Scan Viewer" screen, use the following buttons to display the page you wish to rotate.


When  is pressed, the top page of the scanned data will be shown.


When  is pressed, the previous page of the scanned data will be shown.


When  is pressed, the next page of the scanned data will be shown.

When  is pressed, the last page of the scanned data will be shown.

2. Press either [90°] or the [180°] button.

When  is pressed, the page is rotated 90 degrees to the left.

When  is pressed, the page is rotated 90 degrees to the right.

When  is pressed, the page is rotated 180 degrees.



The actual scanned data is updated to include the rotated page as soon as the button is pressed.

If the [Cancel] button is pressed, all the scanned data is deleted and the screen returns to one of the following.

- Send e-Mail
- Send Fax
- Print
- Save
- Scan to SharePoint
- Job Menu

---

### 6.11.3 Adding a Scanned Page

On the "Scan Viewer" screen, an additional page can be scanned.

1. Load the documents into the ADF paper chute.
2. On the "Scan Viewer" screen, press the [Scan More] button.

⇒ Scanning starts.

Each page is briefly shown on the screen as it is scanned.

Any additionally scanned pages are added after the current scanned data. The page numbers of additional pages will follow on from the last page of the current scanned data.

The maximum number of pages that can be scanned is 100 for a print operation, and 999 for other operations.

When [Blank Page Skip] is enabled, the number of scanned pages excluding skipped blank pages is shown.

Additional pages can be scanned in place of skipped blank pages, until the maximum number of scanned pages is reached.

When the scan has completed, the "Scan Viewer" screen opens and shows any additionally scanned pages.

### 6.11.4 Deleting a Scanned Page

Specified pages can be deleted from the scanned data shown on the "Scan Viewer" screen. If specified pages are deleted, the remaining scanned data is sent as an e-mail attachment, by fax, print, or saved to a network folder, without the deleted pages.

1. On the "Scan Viewer" screen, press the [Previous] or [Next] button to display the page you wish to delete.
2. Press the [Delete] button.  
⇒ A confirmation message appears.
3. Press the [OK] button.  
⇒ The page is deleted.



- If the scanned data consists of only one page, that page cannot be deleted. To re-scan the document, press the [Cancel] button.
- The deleted page is removed from the actual scanned data as soon as the button is pressed, so this procedure can not be undone.
- If the [Cancel] button is pressed, a confirmation message appears. When the [OK] button is pressed, the scanned data is deleted and the screen returns to whichever one of the following it came from:
  - Send e-Mail
  - Send Fax
  - Print
  - Save
  - Scan to SharePoint
  - Job Menu

## 6.12 Checking the User Log

The latest 100 user operation logs are shown for the current user.

Even if the [Region/Timezone] or [Date/Time] settings are changed, the order of the log entries will not be changed.

1. On the "Main Menu" or "Job Menu" screen, press the [User Log] button.

⇒ The "User Log" screen appears.

**User Log**

Result	Code	Date	Time	Operation	Pages	
OK	00000000	08/28/2007	00:29:53	Print	2	<input type="button" value="Update"/>
Error	12010001	08/28/2007	00:29:29	e-Mail	4	
Error	12010001	08/28/2007	00:28:15	e-Mail	4	
OK	00000000	08/27/2007	23:39:46	Save	18	<input type="button" value="▲"/>
OK	00000000	08/27/2007	23:37:59	Save	12	1 / 3
OK	00000000	08/27/2007	23:36:30	Save	6	<input type="button" value="▼"/>

2. Select the log you wish to view.

⇒ The details of the selected log are displayed.

Pressing the [OK] button returns to the "User Log" screen.



If the [Update] button is pressed, the log is updated to include the most recent operations.


The following information is shown.

Info	Info options	Description
Result	In Progress	Currently processing a scan operation.
	OK	Operation completed successfully.
	Error	Operation failed to complete successfully.
Code	xxxxxxxx	Shows a code for each operation. For details, refer to <a href="#">"E.2 Regular User Messages"</a> (page 526).
Date	MM/dd/yyyy dd/MM/yyyy yyyy/MM/dd	Shows the date of each operation (format specified on the Date/Time screen is used). For details, refer to <a href="#">"4.6.5 Setting the Date/Time"</a> (page 64).
Time	hh:mm:ss	Shows the time of each operation.
Operation	e-Mail	The scanned data is sent as an e-mail attachment.
	Fax	The scanned data is sent as a fax.
	Print	The scanned data is sent to the print server, and the sending status is shown in the "Result" column until the scanned data is completely sent to the print server.
	Save	Scanned data is saved in a network folder.
Pages	xxx	Shows the number of pages scanned.
Description	xxxxxxxxxxxxxxxxxxxx	Shows the status and description of the operation.

---

## 6.13 Maintenance

1. On the "Main Menu" or "Job Menu" screen, press the [Maintenance] button.  
⇒ The "Maintenance" screen appears.



- Pressing the [Edit e-Mail Addresses] button opens the "e-Mail Address Book" screen. e-Mail addresses can be added, edited, or deleted on the "e-Mail Address Book" screen. For details, refer to ["6.4.2 Adding an e-Mail Target to the e-Mail Address Book" \(page 324\)](#), ["6.4.3 Editing an e-Mail Target in the e-Mail Address Book" \(page 327\)](#), or ["6.4.4 Deleting an e-Mail Target from the e-Mail Address Book" \(page 329\)](#).
- Pressing the [Edit Fax Numbers] button opens the "Fax Number List" screen. Fax numbers can be added, edited, or deleted on the "Fax Number List" screen. For details, refer to ["6.5.2 Adding a Contact to the Fax Number List" \(page 335\)](#), ["6.5.3 Editing a Contact in the Fax Number List" \(page 337\)](#), or ["6.5.4 Deleting a Contact from the Fax Number List" \(page 338\)](#).
- Pressing the [Roller Cleaning] button opens the "Roller Cleaning" screen. The "Roller Cleaning" screen allows the feed rollers to be step rotated for cleaning. For details, refer to ["Feed rollers" \(page 430\)](#).
- Pressing the [Scan Test] button starts scan test. Scanned data can be checked on the "Scan Viewer" screen. Use this to check that the scanner scans normally. For more details about the "Scan Viewer" screen, refer to ["7.7 Performing a Scan Test" \(page 445\)](#).




## 6.14 Processing a Job

This section uses an example where buttons from [Job1] to [Job6] have been set.

1. On the "Job Menu" screen, press the [Job] button.



When you are included in multiple job groups, the "Job Menu" screens can be switched by using the job menu switch buttons.



⇒ The "Message Screen" appears.



- If either the title or message is not set in [Message Screen] on the "Job Details" window, even if the [Message Screen] button is set to [On], the "Message Screen" will not be shown. For more details, refer to [Step 4 of "4.11.2 Setting a Job Sequence" \(page 185\)](#).
- If "Off" is selected for the [Message Screen] button, scanning is started without showing the "Message Screen", and the job is processed. For more details, refer to ["6.14.1 Enabling/Disabling the Message Screen" \(page 417\)](#).
- When the [Message Screen] button is disabled, whether or not the "Message Screen" is shown depends on the settings configured by the administrator.

---

2. Press the [Scan] button on the "Message Screen".

⇒ Scanning starts.

Each page is briefly shown on the screen as it is scanned.

When the scan has completed, the "Scan Viewer" opens.

For more details about the "Scan Viewer", refer to ["6.11 Editing the Scanned Data in the Scan Viewer" \(page 405\)](#).



- When "Off" is set, the "Scan Viewer" is not shown.
- When a file name can be changed, the "File Name" screen is shown before a scan. For more details, refer to ["6.14.2 Changing a File Name \(for Save/e-Mail Attachment\)" \(page 419\)](#).
- When the setting of the "Scan Count" can be changed, the "Scan Count" screen is shown before a scan. For more details, refer to ["6.14.3 Checking the Number of Sheets to Be Scanned" \(page 420\)](#).

3. Check the scanned data.

For more details about the "Scan Viewer" screen, refer to ["6.11 Editing the Scanned Data in the Scan Viewer" \(page 405\)](#).

4. Press the [OK] button on the "Scan Viewer".

⇒ The data is processed according to the specified job.

While the job is being processed, the process is shown in real time on the "Job Progress" screen.



Icon				Used to...
e-Mail	Fax	Print	Save	
				Show the current item in process (big icon).
				Show items waiting to be processed.
				Show items which have completed successfully.
				Show items which have not completed successfully.
				Show items which have been canceled.



- To view the job report, press the [Job Report] button on the "Job Progress" screen.

Job Report

Operation	Status
1 : e-Mail	Error 12010100
2 : Fax	OK
3 : Print	OK
4 : Save	OK
5 : e-Mail	OK
6 : Fax	Error 12020100

Details Icon View OK

- To view detailed information for the job report, select a function name on the "Job Report" screen and press the [Details] button.

Job Detail Information

Result	Error
Code	12010100
Date	
Time	07:14:53
Operation	e-Mail
Pages	1
Description	Error: e-mail could not be sent.

Report To Administrator OK

- If the status is shown as "Error", the [Report To Administrator] button is shown on the "Job Report Details" screen. Press the [Report To Administrator] button to send detailed information of the job report to an administrator by e-mail. (The e-mail address is the "Notification e-Mail Address" set on the administrator "Alert Notification" screen.)

⇒ If the job sequence is processed successfully, the touch panel screen returns to the "Job Menu".

If an error occurs during the job process, press the [OK] button on the "Job Progress" or "Job Report" screen. Pressing the [OK] button returns to the "Job Menu".



---

Operations differ according to whether the [Message Screen] button is "Off" or "On".


- If a job sequence is processed when the [Message Screen] button is set to "On", the "Message Screen" will be shown.



Processing Job1.

- 1.e-Mail
- 2.Fax
- 3.Print
- 4.Save
- 5.e-Mail
- 6.Fax
- 7.Print
- 8.Save
- 9.e-Mail
- 10.Fax




 **HINT** After checking the message, press the [Scan] button to start the scan. If any further job setup steps are required, press the [OK] button that appears instead.

- If a job sequence is processed when the [Message Screen] button is set to "Off", the job will be processed without showing the "Message Screen".

## 6.14.2 Changing a File Name (for Save/e-Mail Attachment)

When a job is processed, file names to be used when saving or attaching scanned data to an e-mail can be changed.




1. Press a job button on the "Job Menu" screen.
2. On the "File Name" screen, enter the file name for the scanned data to be saved or sent by e-mail.

File names may be up to 128 characters long. \ and / are used as folder separator characters. The following symbols cannot be used.

: \* ? " < > |

The default value is the file name specified in the "Common File Name" input field on the "Job Details" window. For details, refer to ["4.11.2 Setting a Job Sequence" \(page 185\)](#).



Enter the file name to be used for the scan data.


A sequence number will be appended to the file name.



- 
- When sequence numbers are set to be appended to file names, a sequence number is appended to the end of the default file name. The guidance message "A sequence number will be appended to the file name." is shown on the screen.
  - A sequence number will not be appended to a file name that has been edited.
  - After entering the file name, press the [Scan] button to start the scan. If any further job setup steps are required, press the [OK] button that appears instead.


### 6.14.3 Checking the Number of Sheets to Be Scanned

When a job is processed, the expected number of sheets to be scanned can be specified, so that the actual number of scanned sheets can be checked after a scan.

 For either of the following settings, the "Scan Count" screen is not shown.

- The "Scan Count" is not to be checked
- The "Scan Count" is to be checked, but the "Scan Count" screen is set not to appear (The [Allow per-Job adjustment] checkbox in the "Check the Scan Count" on the "Job Details" window is disabled)

1. Press a job button on the "Job Menu" screen.
2. On the "Scan Count" screen, enter the number of sheets that are to be scanned, between 1 and 999.

 ● When [Print] is included in the job sequence, the number of sheets to be scanned can be set within the range of 1 to 100, but not 1 to 999.

● For printing, the maximum number of pages that can be scanned at once is 100, and for the other operations it is 999. Make sure not to set a value that exceeds the maximum number when performing a duplex scan.

#### Scan Count

Enter the number of sheets that are to be scanned.


Expected Count:  sheets (1-999)




3. Press the [Scan] button.

⇒ Scanning starts.



When the "Scan Viewer" is shown after a scan, you can check whether the number of scanned sheets is the same as that set in the "Scan Count" screen at .



Even if pages are deleted on the "Scan Viewer", the number of scanned sheets is not changed.

---

After scanning has completed, the following confirmation screen is shown if the number of scanned sheets is set to be checked. Contact the administrator to change the setting of whether or not to check the scan count. For more details, refer to ["4.11.2 Setting a Job Sequence" \(page 185\)](#).



The Scan Count is as follows:

Scanned: 4 sheets  
Expected: 5 sheets

Press the "OK" button to continue the scan, the "Cancel" button to end it, or the "Scan More" button to add further pages.



When the [Scan More] button is shown, press the button to add further pages.

To continue, press the [OK] button.

To cancel the process and delete the scanned data, press the [Cancel] button.

# Chapter 7

## Scanner Care

Admin

User

This chapter describes how to clean the scanner and replace parts in order to maintain the scanner in optimum scanning condition.



The glass scanner windows inside the ADF can become hot when the scanner is used.

Before cleaning inside the scanner or replacing any parts, turn off the power, unplug the AC adapter from the outlet, and wait for at least 15 minutes.

The power does not need to be turned off when cleaning the feed rollers.



Do not use any aerosol sprays or alcohol based sprays to clean the scanner.

Dust blown up by strong air from the spray may enter the inside of the scanner. This may cause the scanner to fail or malfunction.

Sparks, caused by static electricity, generated when blowing off dust and dirt from the outside of the scanner may cause a fire.


7.1 Cleaning.....	424
7.2 Cleaning the ADF .....	426
7.3 Cleaning the LCD Touch Panel.....	433
7.4 Cleaning the Keyboard.....	434
7.5 Cleaning the Carrier Sheet.....	435
7.6 Replacing Parts .....	436
7.7 Performing a Scan Test.....	445

---

## 7.1 Cleaning

### 7.1.1 Cleaning Materials

The following table shows the cleaning materials to be used with this scanner.

Item	Part No.	Remarks
Cleaner F1 	PA03950-0352	1 bottle (100 ml) Used to moisten the cloths before wiping parts clean.
Cleaning Paper	CA99501-0012	1 pack (10 sheets) For use with Cleaner F1.
Cleaning Wipe	PA03950-0419	1 pack (24 sheets) Pre-moistened with Cleaner F1, Cleaning Wipes are used instead of moistened cloths.
Soft, dry cloth	Any commercially available lint-free product	

Contact your FUJITSU scanner dealer or an authorized FUJITSU scanner service provider to obtain these products.

## 7.1.2 Which Parts and When

Clean all parts after every 1,000 sheets scanned.

- Pad assy
- Feed rollers
- Pick roller
- Idler rollers
- Glass scanner windows
- Ultrasonic sensors



The scanner must be cleaned more frequently when the following types of documents are used:

- Coated paper
- Documents with large areas of printing
- Chemically treated paper such as carbonless paper
- Paper containing large amounts of calcium carbonate filler
- Documents written in pencil
- Documents with insufficiently fused toner



---

## 7.2 Cleaning the ADF

The ADF should be cleaned after approximately every 1,000 scanned sheets. However, this criteria varies according to the type of documents scanned. For example, it may be necessary to clean the ADF more frequently when documents with insufficiently fused toner are scanned.



The glass scanner windows inside the ADF can become hot when the scanner is used.

Before cleaning inside the scanner or replacing any parts, turn off the power, unplug the AC adapter from the outlet, and wait for at least 15 minutes.

The power does not need to be turned off when cleaning the feed rollers.




When you perform cleaning, make sure that the inside of the scanner is free of any foreign object, and be careful not to get your hand or the cloth caught on the pick spring (metal part) as a deformed pick spring (metal part) may cause injury.

---


### 7.2.1 Cleaning the ADF

1. Push the ADF release button, then hold both sides of the top cover and lift it open.



Be careful that the top cover does not shut on your fingers.

2. Clean the following parts with a soft cloth moistened with Cleaner F1.




No.	Part name	Cleaning method
1	Pad assy	Refer to "Pad assy" (page 429).
2	Feed rollers (× 4)	Refer to "Feed rollers" (page 430).
3	Pick roller (× 1)	Refer to "Pick roller" (page 431).
4	Idler rollers (× 4)	Refer to "Idler rollers" (page 431).
5	Glass scanner windows (× 2)	Refer to "Glass scanner windows" (page 431).
6	Ultrasonic sensors (× 2)	Refer to "Ultrasonic sensors" (page 431).






When cleaning inside the ADF, take care that the cloth does not get snagged by the document sensors and damage them.



- Pad assy

When you perform cleaning, make sure that the inside of the scanner is free of any foreign object, and be careful not to get your hand or the cloth caught on the pick spring (metal part) as a deformed pick spring (metal part) may cause injury.



- Feed rollers

Use the following procedure when cleaning the feed rollers.

- 1 On the "Main Menu" or "Job Menu" screen, press the [Maintenance] button.  
⇒ The "Maintenance" screen appears.
- 2 Press the [Roller Cleaning] button.

Maintenance




Cancel

⇒ The "Roller Cleaning" screen appears.

Roller Cleaning

Press the keyboard [C] key to step the feed rollers forward.  
Press the [OK] button after the feed rollers have been cleaned.



OK

- 3 Open the top cover.
- 4 Lightly press a soft cloth moistened with Cleaner F1 against the surface of the feed rollers.

## 5 Press the [c] key on the keyboard.

⇒ The feed rollers will advance one step each time the [c] key is pressed.

Lightly press a soft cloth moistened with Cleaner F1 against the surface of the rotating rollers to clean them. Pressing the [c] key seven times will turn the roller one complete revolution. The feed rollers should be cleaned carefully and thoroughly, as dirty pick rollers can adversely affect the paper pickup performance.




In **Step 5**, all four feed rollers will turn at the same time.

When cleaning the feed rollers, be careful not to touch the rollers with your fingers while they are rotating.

## ● Pick roller

Gently rotate the pick roller as you wipe its surface clean, taking care not to damage the soft rubber. The pick roller should be cleaned carefully and thoroughly, as dirty pick rollers can adversely affect the paper pickup performance. When cleaning the pick roller, also be careful not to damage the black plastic glide strip.



## ● Idler rollers

Gently rotate the idler rollers as you wipe them clean, taking care not to scratch or ding them, or tear the sponge wheels. The idler rollers should be cleaned carefully and thoroughly, as dirty idler rollers can adversely affect the paper pickup performance.

## ● Glass scanner windows

Clean lightly with a soft cloth moistened with Cleaner F1.



A vertical black line on the scanned data may indicate the glass scanner windows are dirty.

## ● Ultrasonic sensors

Clean lightly with a soft cloth moistened with Cleaner F1.


- 
3. Holding both sides of the top cover, return it to its original position.  
You should hear a click.



- Make sure that the top cover is completely closed. If not completely closed, document jams and feeding errors may occur.
- When closing the top cover, do not slam it shut by pushing the touch panel as this may damage it.



Hold both sides  
to close



## 7.3 Cleaning the LCD Touch Panel

To prevent the touch panel screen from becoming dirty, it should be regularly cleaned with a soft, dry cloth.

Take care when cleaning the touch panel. It can be easily damaged, and should never be scratched or banged with hard objects.



Always use a dry (not damp) cloth to clean the screen.  
If dust is allowed to collect and compact around the frame of the screen, it can cause the touch panel to malfunction.



---

## 7.4 Cleaning the Keyboard

To prevent the keyboard from becoming dirty, it should also be regularly cleaned with a soft, dry cloth.



Always use a dry (not damp) cloth to clean the keyboard. Do not apply Cleaner F1.



## 7.5 Cleaning the Carrier Sheet

If the surface or interior of the Carrier Sheet becomes dirty or dusty, use a soft dry cloth slightly moistened with Cleaner F1 (sold separately) or a mild detergent, to lightly wipe off the dirt and dust.





- Never use paint thinner or other organic solvents.
- Do not rub too hard, as the Carrier Sheet may become scratched or deformed.
- After cleaning the interior of the Carrier Sheet, wait until it has completely dried before closing it.
- As a guideline, it is recommended to replace the Carrier Sheet every 500 scans. For details about purchasing a Carrier Sheet, refer to ["7.6.5 Purchasing the Carrier Sheet" \(page 444\)](#).

## 7.6 Replacing Parts

### 7.6.1 Part Numbers and Replacement Cycles

#### ■ Part numbers and replacement cycle for consumable parts

The following table specifies the replacement part numbers, the standard replacement cycles, and the color of the [Consumable Alert] button.

Part name	Part No.	Replacement cycle	Consumable alert status
PAD ASSY 	PA03289-0111	After every 50,000 sheets scanned or once a year (when using 80 g/m <sup>2</sup> (20 lb) A4/Letter woodfree or wood containing paper)	Green until the number of documents scanned reaches 45,000 sheets. Orange after 45,000 sheets. Red after 50,000 sheets. For more details about how to check the consumable alert status, refer to <a href="#">"7.6.2 Checking the Consumable Alert Status"</a> (page 438).
PICK ROLLER 	PA03289-0001	After every 100,000 sheets scanned or once a year (when using 80 g/m <sup>2</sup> (20 lb) A4/Letter woodfree or wood containing paper)	Green until the number of documents scanned reaches 95,000 sheets. Orange after 95,000 sheets. Red after 100,000 sheets. For more details about how to check the consumable alert status, refer to <a href="#">"7.6.2 Checking the Consumable Alert Status"</a> (page 438).

These replacement cycles are rough guidelines. They may vary according to the type of documents scanned, scanner usage, and cleaning frequency.




- When the consumable alert status is orange or red, contact your scanner administrator to replace the necessary part.
- Use only the PFU LIMITED parts specified. Do not use consumable parts made by other manufacturers.

To obtain these parts, contact your FUJITSU dealer or an authorized FUJITSU scanner service provider.



## ■ Part numbers and replacement cycle for Carrier Sheet

The following table specifies the replacement part numbers and the standard replacement cycles.

Part name	No. of items	Part No.	Replacement cycle	Remarks
Carrier Sheet 	5	PA03360-0013	After used for 500 scans	For details about purchasing a Carrier Sheet, refer to <a href="#">"7.6.5 Purchasing the Carrier Sheet"</a> (page 444).

This replacement cycle is a rough guideline. This may vary according to the type of documents scanned, scanner usage, and cleaning frequency. If parts become noticeably dirty, replace them accordingly.



Use only the PFU LIMITED parts specified. Do not use parts made by other manufacturers.





To obtain these parts, contact your FUJITSU dealer or an authorized FUJITSU scanner service provider.

## 7.6.2 Checking the Consumable Alert Status

1. On the "Main Menu" or "Job Menu" screen, press the [Consumable Alert] button.  
⇒ The "Consumable Alert" screen appears.
2. Check which part needs to be replaced and press the [OK] button.  
Parts whose "Usage Counter" value is bigger than the "Replace at" value should be replaced. The value of the "Usage Counter" is in units of 500 sheets scanned.  
For details on how to check the status of consumable parts on the administrator screen, refer to ["4.8.3 Viewing the Usage Status" \(page 156\)](#).

### Consumable Alert

Part	Usage Counter	Replace At	Current Status
 PAD ASSY	60.500	50.000	Replace Now
 PICK ROLLER	60.500	100.000	

 OK

3. Replace the part.  
Part replacement procedures are detailed in the following sections, ["7.6.3 Replacing the Pad Assy" \(page 439\)](#), ["7.6.4 Replacing the Pick Roller" \(page 440\)](#).

### 7.6.3 Replacing the Pad Assy

1. Remove any documents from the ADF paper chute.
2. Push the ADF release button, then hold both sides of the top cover and lift it open.




Be careful that the top cover does not shut on your fingers.



3. Remove the pad assy from the scanner.  
Squeeze the prongs on either side of the pad assy together and pull it upwards and to the front, taking care not to snag the pick springs.

Squeeze prongs together and pull up



4. Insert the new pad assy.  
Holding the new pad assy by its sides, insert into the pad assy socket, taking care not to snag the pick springs.



Make sure that the pad assy is firmly and fully inserted. If it is not correctly attached, document jams and other feeding errors may occur.



- 
5. Close the top cover.

You should hear a click when it is returned to its original position.



Be careful that the top cover does not shut on your fingers.



6. Reset the pad assy usage counter.

The usage counter must be reset by an administrator. For details, refer to "[Resetting the Usage Counter](#)" (page 157).

## 7.6.4 Replacing the Pick Roller


1. Remove any documents from the ADF paper chute.
2. Remove the ADF paper chute.
3. Push the ADF release button, then hold both sides of the top cover and lift it open.




Be careful that the top cover does not shut on your fingers.



4. Remove the pick roller and its shaft from the scanner.
  1. Squeeze the tabs of the sheet guide release catch together with your fingers, and lift the sheet guide plate up and away.




2. Rotate the left side pick roller bushing in the direction indicated by the arrow.



Pick roller bushing      Pick roller shaft

3. Gently lift and slide the pick roller shaft out of the left side of the ADF in the direction of the arrow. Be careful as it is easy to bind the shaft in the right side bushing.




The pick roller bearing may be hard to rotate. Do not try to turn it with your fingernail. Use a paper clip to turn the roller bearing if you can not rotate it with your fingertip.

5. Remove the pick roller from the shaft.

Lift up the lock tab and slide the pick roller off the shaft.




Take care if lifting the pick roller lock tab with your fingernail as it may get chipped or broken. If worried, try lifting the tab using a paper clip as shown in the following diagram.




6. Attach the new pick roller.

Insert the shaft into the new pick roller, aligning the protruding pin on the shaft with the matching notch in the pick roller.




Make sure that the pick roller shaft is fully inserted. If it is not correctly attached, document jams and other feeding errors may occur. You should hear a "click" when the pick roller shaft is inserted correctly. Make sure you hear this noise when inserting the shaft into the pick roller.



## 7. Insert the pick roller and shaft back in the scanner.

To attach the pick roller to the scanner, follow the pick roller and shaft removal procedure in reverse.


1. Rotate the left side pick roller bushing in the direction indicated by the arrow.



Pick roller bushing

Pick roller shaft

2. Open the tabs of the sheet guide release catch in the direction indicated by the arrow to lock the sheet guide in place.



## 8. Close the top cover.

You should hear a click when it is returned to its original position.



Be careful that the top cover does not shut on your fingers.



## 9. Attach the ADF paper chute.

## 10. Reset the pick roller usage counter.

The usage counter must be reset by an administrator. For details, refer to "[Resetting the Usage Counter](#)" (page 157).


---

## 7.6.5 Purchasing the Carrier Sheet

If the "Carrier Sheet" provided with the scanner can no longer be used for scanning due to damage or wear-and-tear, you can purchase a new Carrier Sheet separately.

As a guideline, it is recommended to replace the Carrier Sheet every 500 scans. However, the number of times of use differs according to usage. Replace the Carrier Sheet when it becomes scratched or dirty.

The Carrier Sheet is as shown below:



To obtain the Carrier Sheet, contact your FUJITSU dealer or an authorized FUJITSU scanner service provider.



## 7.7 Performing a Scan Test

After scanner cleaning or replacement of consumable parts, perform a scan test.

1. On the "Main Menu" or "Job Menu" screen, press the [Maintenance] button.  
⇒ The "Maintenance" screen appears.
2. Press the [Scan Test] button.



Maintenance



Cancel

⇒ The "Scan Test" screen appears.















3. Load the document into the ADF paper chute for the scan test.



4. Press the [Scan] button.

Scan Test

Load a test page and press the [Scan] button.

■ Scan Settings Used ■

Option	Setting	Option	Setting
 Color Mode	Auto	 Sharpness	None
 Paper Size	Auto	 Dropout Color	None
 Resolution	200dpi	 Background Removal	Medium
 Scan Mode	Duplex	 Page Orientation	Off
 Compression	Medium	 Blank Page Skip	Off
 Brightness	Medium	 Multifeed Setup	Ultrasonic
 Contrast	Medium	 Edge Cropping	Off


⇒ The scan test starts.

When the scan test has completed, the "Scan Viewer" screen appears.

If the scanner fails to scan correctly, an error message is displayed. For more details about how to deal with error messages, refer to ["E.2 Regular User Messages" \(page 526\)](#).

## 5. Check the scanned data.

For more details about "Scan Viewer", refer to "6.11.1 Viewing a Scanned Page" (page 406) or "6.11.2 Rotating a Scanned Page" (page 407).



## 6. Press the [OK] button.

⇒ The "Maintenance" screen is shown again.



# Chapter 8

## Troubleshooting

Admin

User

This chapter provides information on dealing with scanner operation problems such as paper jams, points to check before contacting your FUJITSU scanner dealer, and help on how to check device labels.

For details of error messages which may appear during administrator setting procedures, refer to ["E.1.1 Administrator Screen Messages" \(page 503\)](#).

For details of error messages which may appear during scanner operations or cleaning, refer to ["E.2 Regular User Messages" \(page 526\)](#).

For details of messages which might appear when acquiring log information in ["4.9 Using the Operation Logs Menus" \(page 159\)](#), refer to ["E.1.2 System Log Messages" \(page 516\)](#).

For details of device status messages, refer to ["E.1.3 Alert Monitor System Log Messages" \(page 522\)](#).

<b>8.1 Removing Jammed Documents.....</b>	<b>450</b>
<b>8.2 Dealing with Detached Keycaps .....</b>	<b>454</b>
<b>8.3 Network Connection Troubleshooting.....</b>	<b>456</b>
<b>8.4 Other Troubleshooting .....</b>	<b>468</b>
<b>8.5 Points to Check before Contacting Your FUJITSU Scanner Dealer.....</b>	<b>472</b>
<b>8.6 Checking the Scanner Labels .....</b>	<b>475</b>
<b>8.7 Pre-Maintenance Preparations .....</b>	<b>476</b>


## 8.1 Removing Jammed Documents

If a document jam occurs, follow the procedure below to remove the jammed documents.



- When removing jammed documents, take care with dangling neckties, necklaces, etc. as they may easily become entangled in the scanner.
- The glass scanner windows inside the ADF can become hot when the scanner is used. Take care not burn your hands.

1. Remove all documents from the ADF paper chute.
2. Push the ADF release button, then hold both sides of the top cover and lift it open.



Be careful that the top cover does not slam shut on your fingers.

3. Remove the jammed document.



- Staples, paper clips, etc. can cause document jams. Check the document and feed path, and remove any such objects that may have come loose.  
Any staples, clips, etc. should be removed from the document before starting a scan.
- Take care not to snag the pick springs when removing jammed documents.


4. Holding both sides of the top cover, return it to its original position.

You should hear a click.



- Be careful that the top cover does not shut on your fingers.
- Make sure that the top cover is completely closed. If not completely closed, document jams and feeding errors may occur.
- When closing the top cover, do not slam it shut by pushing the touch panel as this may damage it.

Hold both sides to close






- Although no error message is displayed, document pages may remain in the ADF even after scanning is completed or canceled. Follow the procedure below to remove any such pages from the ADF.
  1. Remove all documents from the ADF paper chute.
  2. Push the ADF release button, then hold both sides of the top cover and lift it open.
  3. Remove the remaining documents.
  4. Close the top cover.
- If document pages become blocked while scanning, check the scanned data. Document pages which could not be scanned correctly may be shown in the "Scan Viewer". In this case, delete all pages not correctly scanned using the [Delete] button.

For more details about the "Scan Viewer" screen, refer to ["6.11.4 Deleting a Scanned Page"](#) (page 409).

If document jams or multifeed errors occur frequently, try the following procedures.


1. Align the edges of the document sheets.
2. Lightly grip the ends of the document stack in both hands and flex it back forth, as shown below.



⇒ The edge of the document stack that will be loaded into the ADF paper chute should be skewed.




3. Load the documents into the ADF paper chute, as shown in the following diagram.



---


## 8.2 Dealing with Detached Keycaps

If a keycap comes loose from the keyboard, fit it back onto its original location and push it down until it clicks into place.




If a keycap and key switch become loose, they should be reattached as follows.


1. Remove the key switch from the keycap.





2. With the flat part of the key switch facing downwards, reattach it to the keyboard.



3. Fit the keycap back onto its original location and push it down until it clicks into place.



 If the detached keycap has a wire brace, reattach the wire to the keyboard, align the keycap over the middle of the wire, and push the keycap down until it clicks into place.



---

## 8.3 Network Connection Troubleshooting

If a network connection is not possible, first check the scanner status and system settings.

The following section provides information about general troubles that may occur when connecting to a network.

If the cause of the problem is unknown or the problem persists, check the items in ["8.5 Points to Check before Contacting Your FUJITSU Scanner Dealer"](#) (page 472) and contact your FUJITSU scanner dealer or an authorized FUJITSU scanner service provider.

### 8.3.1 Basic Network Operation Tests

The following network operation tests are available on the administrator screen, and should be performed after the network has been setup.

- Checking basic network operation with a Ping test
- Checking the network operating status
- Checking the NTP server settings by synchronizing the system time (if using an NTP server)
- Checking the mail server by sending a test mail (if scanned data is to be sent as an e-mail, by fax, or when requesting alert notifications by e-mail)

#### ■ Checking basic network operation with a Ping test

Check the network connection status of the following computers and servers associated with the network.

For details about the pinging procedure, refer to ["4.7.17 Checking the Network Connection with a Ping Test"](#) (page 150).

- Computer with Admin Tool installed
- Computer with Central Admin Console installed
- Computer with Central Admin Server software installed
- DNS server
- WINS server
- NTP server
- LDAP server
- SMTP server
- File server
- FTP server
- Print server
- SharePoint server
- Domain controller



Depending on the server setting, there may be no response from a ping test.

When checking the network connection status of a server by its IP address, the following results are possible.

Result	Action
"Ping statistics" shows "Lost=0 (0% loss)"	None
"Ping statistics" shows "Lost=4 (100% loss)"	Check that the ping target IP address is correct.
	If the ping target IP address is correct, refer to <a href="#">"Failure to connect to a server using its IP address" (page 461)</a> for further solutions.
"Ping statistics" shows "Lost=N (1 to 99% loss)"	There may be a quality problem with the LAN cable. Replace the LAN cable and try again.
	In <a href="#">"4.7.18 Checking the Network Operating Status" (page 152)</a> , change the [Link Speed/Duplex Mode] from "Auto-Negotiation" to a fixed mode.
"Hardware error"	The LAN cable may have become disconnected during the Ping test. Check the status of the LAN cable and try again.

When checking the network connection status of a server by its host name or FQDN, the following results are possible.

Result	Action
"Ping statistics" shows "Lost=0 (0% loss)"	None
"Ping request could not find host xxxxxxxxxx. Please check the name and try again."	Check that the ping target host name or FQDN is correct.
	Check that the DNS server or WINS server settings are correct.
	If the ping target host name or FQDN is correct, refer to <a href="#">"Failure to connect to a server using its host name or FQDN" (page 463)</a> for further solutions.
"Ping statistics" shows "Lost=4 (100% loss)"	Check that the ping target host name or FQDN is correct.
	In <a href="#">"4.7.18 Checking the Network Operating Status" (page 152)</a> , change the [Link Speed/Duplex Mode] from "Auto-Negotiation" to a fixed mode.
"Ping statistics" shows "Lost=N (1 to 99% loss)"	There may be a quality problem with the LAN cable. Replace the LAN cable and try again.
	In <a href="#">"4.7.18 Checking the Network Operating Status" (page 152)</a> , change the [Link Speed/Duplex Mode] from "Auto-Negotiation" to a fixed mode.
"Hardware error"	The LAN cable may have become disconnected during the Ping test. Check the status of the LAN cable and try again.

---

## ■ Checking the network operating status

Check the network status.

For details about the checking procedure, refer to ["4.7.18 Checking the Network Operating Status" \(page 152\)](#).

Check the "Network Information" screen, and follow each action described below according to the message that is shown.

Network settings	Action
The information shown is all valid.	None
The information shown is not all valid.	If DHCP is not used: Check that the "IP Address" setting is correct.
	If DHCP is used: <ul style="list-style-type: none"><li>● Check that physical network connection to the DHCP server is functioning correctly.</li><li>● Check the DHCP server. The server may not be operating normally, or the DHCP settings (restricted number of leases or MAC address validation) may be causing invalid IP addresses to be assigned.</li></ul>
The information shown is valid, but pinging indicates that the network connection is not functioning normally.	In <a href="#">"4.7.18 Checking the Network Operating Status" (page 152)</a> , change the [Link Speed/Duplex Mode] from "Auto-Negotiation" to a fixed mode. If the problem persists, refer to <a href="#">"Failure to connect to a server using its IP address" (page 461)</a> for further solutions.

## ■ Checking the NTP server settings by synchronizing the system time

On the "NTP Server" screen, press the [Sync Time] button to check if the system time can be synchronized.

After pressing the [Sync Time] button, follow each action described below according to the message that is shown.

Message	Action
System time has been successfully synchronized.	None
System time synchronization failed.	<p>Try the following:</p> <ul style="list-style-type: none"> <li>● Check the specified NTP server IP address, host name, or FQDN for mistakes, and correct them.</li> <li>● Check the network path between to the NTP server for problems.</li> <li>● The NTP server may be busy. Wait a short time before trying again to synchronize the system time. If that does not work, the specified server may not be an NTP server, so try a different NTP server.</li> <li>● The specified NTP server cannot provide a trusted date and time. It attempted to acquire the date and time from a higher level NTP server, but failed. Try a different NTP server or have the network administrator investigate.</li> <li>● Check that the time is correct. If the time is incorrect, adjust the date/time, and try again.</li> <li>● Refer to "<a href="#">4.6.5 Setting the Date/Time</a>" (page 64), adjust the date/time, and try again.</li> </ul>

## ■ Checking the mail server by sending a test mail

On the "Central Admin Server Settings" screen or "Alert Notification" screen, press the [Test] button to check if an e-mail can be sent to the specified destination.

After pressing the [Test] button, follow each action described below according to the message that is shown.

Message	Action
Sending...	<p>If no error message appears and the "sending" indicator disappears, the test mail was sent successfully to the mail server.</p> <p>Check that the alert notification e-mail has arrived at the specified destination. If the alert notification e-mail has not arrived at the expected destination, check that the part of the e-mail address before the "@" has been entered correctly.</p>
Test e-mail could not be sent.	<p>Check that the computer connected to the SMTP server is running properly.</p>
	<p>Check if an e-mail can be sent to the address from other computers in the network.</p>
	<p>Ping the SMTP server to check that it and its network connection are working properly.</p>
	<p>If the SMTP server does not respond to the ping test, check that the system network is functioning normally by pinging the SMTP server from another machine in the network.</p> <ul style="list-style-type: none"> <li>● If it is only the scanner's network connection that does not work, refer to <a href="#">"Failure to connect to a server using its IP address" (page 461)</a> for further solutions.</li> <li>● If the problem seems to be with the SMTP server's network connection, request the network administrator to check that the SMTP server and its network connection are functioning normally.</li> </ul>
	<p>Check that the same port number has been correctly set for the scanner to SMTP server connection in <a href="#">"4.7.11 Setting the e-Mail Server (SMTP Server)" (page 116)</a> and <a href="#">"5.6 Setting the Central Admin Server" (page 244)</a>.</p>



### 8.3.2 Other Network Connection Troubleshooting

There are many reasons why a network connection may not be possible.

The following section provides information about general troubles that may occur when connecting to a network.

If the cause of the problem is unknown or the problem persists, check the items in ["8.5 Points to Check before Contacting Your FUJITSU Scanner Dealer"](#) (page 472) and contact your FUJITSU scanner dealer or an authorized FUJITSU scanner service provider.

#### ■ Failure to connect to a server using its IP address

If a server cannot be connected to by using its IP address, and does not respond to a ping test, try the following steps:

No.	Problem	Action
1	Connection error between a server and the scanner, or problem with the LAN cable.	<p>Check that the LAN cable has been attached to both the scanner and server correctly.</p> <p>If the server is connected using a LAN cable (straight type), in case auto-mdi (automatic selection) is not supported, a LAN cable (crossover type), switch, or router is required between the scanner and server.</p> <p>If this is not the case, the LAN cable may be faulty. Find a LAN cable that functions normally and try again.</p>
2	IP address or subnet mask is invalid.	<p>On the "IP Address" screen, check that the IP address or subnet mask settings are correct.</p> <p>For more details about the "IP Address" screen, refer to <a href="#">"4.7.1 Giving the Scanner an IP Address"</a> (page 86).</p>

No.	Problem	Action
3	When using DHCP, the DHCP server does not operate normally, or there is a problem with the DHCP server settings.	<p>If using DHCP, on the "Network Status" screen, check that IP address, subnet mask, and default gateway settings are all correct.</p> <p>If these settings are not correct, the DHCP server may not operate normally, or the DHCP server may not assign valid IP addresses because of restricted number of leases or MAC address validation.</p> <p>Check the DHCP server connection status and the details of the server settings.</p> <p>For more details about the "Network Status" screen, refer to <a href="#">"4.7.18 Checking the Network Operating Status"</a> (page 152).</p>
4	Another host or communication device is connected using the same IP address as the scanner.	<p>If the same IP address has already been used by another host or communication device, then even if the other device has been given a different IP address the server may not recognize the scanner's "duplicate" IP address until it is rebooted. Restart the server.</p> <p>If a duplicate IP address connection from another host or communication device exists on a LAN, both it will be unusable. If a duplicate IP address connection from another host or communication device exists, pull out its LAN cable and restart the server.</p>
5	Access is denied due to the establishment of a firewall between the server and the scanner.	<p>If a firewall has been established between the server and the scanner, check that it has not been set to deny access to the network.</p>

No.	Problem	Action
6	The network link speed/duplex mode for the scanner and server are different, or Auto-Negotiation is not supported by the server.	For this scanner, the default [Link Speed/Duplex Mode] setting is "Auto-Negotiation". On the "Network Status" screen, match the scanner and server's network link speed/duplex mode settings. If the problem persists in spite of having set both the scanner and server's network link speed/duplex settings to "Auto-Negotiation", select something other than "Auto-Negotiation" and check again. For more details about the "Network Status" screen, refer to <a href="#">"4.7.18 Checking the Network Operating Status"</a> (page 152).

### ■ Failure to connect to a server using its host name or FQDN

If a server cannot be connected to by using its host name or FQDN, and does not respond to a ping test, try the following steps:

No.	Problem	Action
1	Same as in <a href="#">"Failure to connect to a server using its IP address"</a> (page 461).	Check if a network connection is possible by trying the same solution for <a href="#">"Failure to connect to a server using its IP address"</a> (page 461).
2	The scanner's DNS server or WINS server settings are invalid.	Check that the DNS and WINS server settings are correct.
3	The DNS server or WINS server is not functioning normally, or there is an error with the DNS or WINS server network connection.	Ping the DNS and WINS servers to check they are functioning normally. If the DNS or WINS server is not functioning, request the network administrator to check its status.

## ■ Failure to add a network printer

If adding a network printer to/from the scanner is not possible, try the following steps. Also, refer to how to set printer settings, how to add a network printer, and the printer manual before hand.

No.	Problem	Action
1	The Windows XP printer driver has not been installed on the print server.	Install the Windows XP printer driver on the print server. Check that the Windows XP printer driver has been correctly installed on the print server. For more details, refer to " <a href="#">4.7.13 Setting the Network Printers</a> " (page 119).
2	Network printer shared name has been changed.	Check the shared name on the print server.
3	The specified network printer path is invalid.	Check that the specified network printer path is correct.

## ■ Failure to print on a network printer

If printing on a network printer which has been set in the scanner is not possible, try the following steps. Also, refer to how to set the printer settings, how to add a network printer, or the printer manual before hand.

No.	Problem	Action
1	Printer is not usable, due to an out of paper error, paper jam, or similar problem.	Check whether or not the printer is ready for printing, deal with the cause of the error, and try again.
2	Same as in " <a href="#">Failure to connect to a server using its IP address</a> " (page 461).	Check if a network connection is possible by trying the same solution for " <a href="#">Failure to connect to a server using its IP address</a> " (page 461).
3	Not authorized to print on network printer.	Contact the administrator to check if printing is allowed on the network printer.
4	Printing is impossible due to a printer or spooler error.	Try the following: <ul style="list-style-type: none"><li>● Check that printing is possible from the print server application.</li><li>● Check that the print server spooling is operating normally.</li></ul>

### 8.3.3 Failure to Access the Scanner using a Web Browser, Admin Tool, or Central Admin Server

If access is not possible when attempting to connect to the scanner using a Web browser or the Admin Tool, or when attempting to connect to the Central Admin Server from the Central Admin Console, try the following steps:

No.	Problem	Action
1	Same as in <a href="#">"Failure to connect to a server using its IP address"</a> (page 461).	Check if a network connection is possible by trying the same solution for <a href="#">"Failure to connect to a server using its IP address"</a> (page 461).
2	The DNS server or WINS server is not functioning normally, or the scanner name has not been registered in the DHCP or WINS server.	Check the connectivity of the specified IP address. If it is possible to connect the scanner using the Admin Tool with a specified IP address, specify the scanner's IP address in the DNS or WINS server. Also, check the DNS or WINS server settings using the Admin Tool or Web browser.
3	A misconfigured firewall between the Admin Tool or Web browser and the scanner is denying access.	If there is a firewall between the computer running the Admin Tool or Web browser and the scanner, check that its settings are not preventing access.
4	The URL of the target scanner is not registered as a trusted site.	Set the scanner URL as a trusted site for Internet Explorer. In Internet Explorer, set the following settings in the "Tools" menu, "Internet Options". In the [Security] tab, select [Trusted sites]. Press the [Sites] button, enter the URL of the scanner in the "Add this website to the zone" field, and press the [Add] button.


No.	Problem	Action
5	In Internet Explorer, in the "Tools" menu, "Internet Options", [Security] tab, the security level for the corresponding zone is set as "High", or in [Custom level], "Scripting", "Active scripting" is set to "Prompt" or "Disable".	<p>When connecting using the scanner name, the connection will be an intranet connection. When connecting using an IP address, it will be an internet connection. If the URL includes a scanner name, the scanner will be connected using an Intranet Zone. If the URL includes an IP address, the scanner will be connected using the Internet Zone.</p> <p>In Internet Explorer, in the "Tools" menu, "Internet Options", try the following settings for the corresponding zone.</p> <ul style="list-style-type: none"> <li>● To enable "Active scripting", set in one of the following ways: <ul style="list-style-type: none"> <li>● In the [Security] tab, set the required "Security level for this zone" to "Medium".</li> <li>● In the [Security] tab, select the [Custom level] button. Then, set the "Scripting", "Active scripting" to "Enable".</li> </ul> </li> <li>● If connecting via the Internet zone, on the [Privacy] tab, set the level to below "Medium High".</li> </ul> <p>After the above settings have been performed, in "Temporary Internet Files" or "Browsing history", press the [Delete cookies] button to delete all temporary internet files.</p>
6	The scanner is in standby mode.	Press the startup button to start the scanner.
7	A proxy server is being used.	<p>Set the proxy server to not be used.</p> <p>Open the "Internet Options" in the "Tools" menu of Internet Explorer, then press the [LAN settings] button in the [Connections] tab and remove the check from the "Use a proxy server for your LAN (These settings will not apply to dial-up or VPN connections)." option.</p>
8	There is an error with the connection protocol setting.	<p>Check if SSL is enabled on the "Admin Network" screen.</p> <p>For more details, refer to <a href="#">"4.7.2 Setting the Admin Network" (page 88)</a>.</p>
9	There is an error with the port number setting.	<p>Check the specified port number on the "Admin Network" screen.</p> <p>For more details, refer to <a href="#">"4.7.2 Setting the Admin Network" (page 88)</a>.</p>

No.	Problem	Action
10	In Internet Explorer, "Tools" menu - "Internet Options" - [Advanced] tab, the [Use SSL 3.0] checkbox under "Settings" - "Security" section is not selected.	Open the "Internet Options" in the "Tools" menu of Internet Explorer, then press the [Advanced] tab, "Settings" - "Security" section, select the [Use SSL 3.0] checkbox.

## 8.4 Other Troubleshooting

This section describes problems that may occur during scanning and gives information on how to deal with them. Before requesting repair, check the following list of common problems.

If the problem still cannot be solved after consulting the troubleshooting suggestions, check the points in "[8.5 Points to Check before Contacting Your FUJITSU Scanner Dealer](#)" (page 472) and then contact your FUJITSU scanner dealer or an authorized FUJITSU scanner service provider.

Problem	Check item	Suggestion
Scanner cannot be turned on.	Has the Startup button been pressed?	Press the Startup button.
	Are the AC cable and AC adapter properly connected to the scanner?	Connect the AC cable and the AC adapter. Disconnect the AC cable from the scanner, wait at least 10 seconds, then reattach the cable and turn the power back on again. If the problem persists, contact your FUJITSU scanner dealer or an authorized FUJITSU scanner service provider.
Scanning does not start.	Has the document been loaded correctly into the ADF paper chute?	Reload the documents into the ADF paper chute.
	Is the ADF completely closed?	Close the top cover completely.
	Does the same problem occur after turning the scanner power off and back on again, and re-logging in?	Disconnect the AC cable from the scanner, wait at least 10 seconds, then reattach the cable and turn the power back on again. If the problem persists, contact your FUJITSU scanner dealer or an authorized FUJITSU scanner service provider.
Even after pressing the top cover [SCAN] button, scanning does not start.	Is the  button displayed on the touch panel?	The top cover [SCAN] button can only be used on the following screens. <ul style="list-style-type: none"> <li>● "Send e-Mail" screen</li> <li>● "Send Fax" screen</li> <li>● "Print" screen</li> <li>● "Save" screen</li> <li>● "Scan Viewer" screen</li> <li>● "Scan Test" screen</li> <li>● "Message Screen"</li> <li>● "Scan Count" screen</li> <li>● Confirmation screen showing the number of scanned sheets</li> </ul>



Problem	Check item	Suggestion
Multifeed errors occur frequently.	Do the documents satisfy the conditions given in "A.2 Paper Requirements" (page 479)?	Use documents which satisfy the conditions described in "A.2 Paper Requirements" (page 479).
	Has the document been loaded correctly into the ADF paper chute?	Riffle and realign the document stack, then load it back into the ADF paper chute.
	Is the document stack more than 5mm thick?	Remove sheets from the stack to reduce it to a thickness of 5mm or less.
	Is the pad assy dirty?	Clean the pad assy. For more details, refer to "7.2 Cleaning the ADF" (page 426).
	Is the pad assy worn out?	Replace the pad assy. For more details, refer to "7.6 Replacing Parts" (page 436).
Paper is not fed into the scanner. (Pick errors are frequent or document feed stops midway)	Do the documents satisfy the conditions given in "A.2 Paper Requirements" (page 479)?	Use documents which satisfy the conditions described in "A.2 Paper Requirements" (page 479).
	Is the pick roller dirty?	Clean the pick roller. For more details, refer to "7.2 Cleaning the ADF" (page 426).
	Is the pick roller worn out?	Replace the pick roller. For more details, refer to "7.6 Replacing Parts" (page 436).
	Is there any foreign matter in the document feed path?	Clean the document feed path.
Scanned data is elongated.	Are the feed rollers dirty?	Clean the feed rollers. For more details, refer to "7.2 Cleaning the ADF" (page 426).
Shadow on the leading edge of the scanned data.	Are the feed rollers dirty?	Clean the feed rollers. For more details, refer to "7.2 Cleaning the ADF" (page 426).
Vertical line on the scanned data.	Are the glass scanner windows dirty?	For more details on cleaning the glass scanner windows, refer to "Chapter 7 Scanner Care" (page 423).
Scanned data appears skewed or distorted.	Has the document been loaded correctly?	Load the document correctly.
Quality of scanned data is poor.	Are the glass scanner windows dirty?	Clean the glass scanner windows.

<b>Problem</b>	<b>Check item</b>	<b>Suggestion</b>
Cannot login with administrator password.	Was the Caps Lock on when the password was entered?	Turn off the Caps Lock and try logging in again. If the password has been lost or forgotten, contact your FUJITSU scanner dealer or an authorized FUJITSU scanner service provider.
The "Keyboard error or not keyboard present" message is shown on the screen, the scanner does not startup.	After turning the scanner off, was the power turned back on again immediately?	Disconnect the AC cable from the scanner, wait at least 10 seconds, then reattach the cable and turn the power back on again. If the problem persists, contact your FUJITSU scanner dealer or an authorized FUJITSU scanner service provider.
Input field entry entered via the keyboard does not appear on the screen.	Has the input field been selected?	Select the input field and try again.
		Press the [Cancel] button and try again.
		To use the touch panel, touch the input field directly and try again.
Saving is not possible after pressing [Save] on the "File Download" dialog box.	Does the length of the "Save As" folder path (folder path plus file name) exceed 259 characters?	Select a [Save As] folder that respects the limit.
Status screen stops at "Printing scan data to...".	Is there enough free space in the drive on which the spool folder for the print server exists?	Make sure that there is enough space in the drive.
No response from pressing tab or enter key after a file download operation has been selected via the network interface or the download process does not start.	Has the [Download], [Get CSV] or [Backup] button been selected?	Try pressing a different tab or button on the screen.
An error occurs when installing an Admin Tool.	Is an Admin Tool of another language already installed?	Uninstall the existing Admin Tool, and try again.

Problem	Check item	Suggestion
The login screen is not displayed when connecting via the network.	Are the SSL settings correct?	Close the screen, correct the settings, and try connecting again.
	Was the [Yes] button selected on the "Security Warning" dialog box when connecting with HTTPS?	Close the screen and try connecting again. Select the [Yes] button on the "Security Warning" dialog box when connecting.

---

## 8.5 Points to Check before Contacting Your FUJITSU Scanner Dealer

Before contacting your FUJITSU scanner dealer or an authorized FUJITSU scanner service provider, check the following points.

### 8.5.1 General Details

Info	Findings
Model	fi-6010N
Serial No.	Example: 000001 For the serial number, refer to <a href="#">"8.6 Checking the Scanner Labels"</a> (page 475).
Production date	Year Month Example: 2010-01 (January, 2010) For details, refer to <a href="#">"8.6 Checking the Scanner Labels"</a> (page 475).
Date of purchase	Year Month Day
System version	
Symptoms	
Frequency of trouble	
Total throughput	

## 8.5.2 Error Status

### ■ Problem when connecting to the scanner via computer

Info	Findings
OS (Windows)	
Admin tool version	
Displayed error message	

### ■ Document feed trouble

Info	Findings
Document type	
Main purpose of use	
Last cleaned on	Year Month Day
Consumables last replaced on	Year Month Day
Error message details	

## ■ Problem with Central Admin


Info	Findings
Type of OS (Windows) for Central Admin Server software	
Type of OS (Windows) for Central Admin Console	
Central Admin Server software version	
Central Admin Console version	
Displayed error message	

## ■ Other problems

Info	Findings
Can both the original document and scanner image be sent by e-mail or fax?	Circle one: Available Unavailable

## 8.6 Checking the Scanner Labels

This section provides help on how to check the scanner's two information labels. The following diagrams show where the labels are located on the scanner.



- Label A (example): Contains various scanner information.

MODEL	fi-*****	**V	==	***A	**kg															
PART NO.	*****-****	DATE		200*-**																
SER. NO.	*****																			
PFU Limited a Fujitsu company																				
				MADE IN *****																

- Label B (example): Indicates the various standards that the scanner conforms to.



---

## 8.7 Pre-Maintenance Preparations

Before sending the scanner for maintenance, the user data store and system settings should be backed up. Refer to the following sections for details:


- ["Backing up the User Data Store" from "4.10.1 Maintaining the User Data Store" \(page 165\)"](#)
- ["4.10.2 Maintaining the System Settings" \(page 171\)](#)

After backing up the user data store and system settings, the original data may be deleted. Refer to the following sections for details:

If the hard disk is replaced, all settings will revert to their factory default values.

- ["Clearing the User Data Store" \(page 170\) from "4.10.1 Maintaining the User Data Store" \(page 165\)"](#)
- ["Clearing the System Log" \(page 164\) from "4.10.2 Maintaining the System Settings" \(page 171\)](#)

---

 The user data store may contain private information such as e-mail addresses or fax numbers, so care should be taken when managing such data.

---



# Appendix A



## ADF Paper Specifications

Admin

User

This appendix describes the paper size and quality requirements for ensuring that the ADF operates correctly when scanning documents.

<b>A.1 Paper Size .....</b>	<b>478</b>
<b>A.2 Paper Requirements.....</b>	<b>479</b>
<b>A.3 Maximum Document Loading Capacity .....</b>	<b>482</b>
<b>A.4 Area not to be Perforated .....</b>	<b>483</b>
<b>A.5 Multifeed Detection Conditions.....</b>	<b>484</b>

---

## A.1 Paper Size

The following paper sizes can be scanned with this scanner:

Width: 52 to 216 mm (2.1 to 8.5 in)

Length: 74 to 356 mm (\*) (2.9 to 14 in)

\* When "Custom" paper size setting is used, a page length of up to 863 mm (34 in) is allowed for document scanning.

---

## A.2 Paper Requirements

### A.2.1 Paper Type

The following paper types are recommended for use with the ADF:

- Woodfree paper
- Wood containing paper

When documents of a paper type other than those listed above are used, test-scan a few sheets first to check if the document can be scanned without problem.

### A.2.2 Paper Weight

The following paper weights can be used with the ADF:

- For general scanning
  - 52 to 127 g/m<sup>2</sup> (14 to 34 lb)
  - For A8 and Business Card size, 127 g/m<sup>2</sup> only
- For scanning with a Carrier Sheet
  - Up to 127 g/m<sup>2</sup> (Up to 34 lb)
  - Up to 63.5 g/m<sup>2</sup> (Up to 17 lb) (when scanning half fold paper)

### A.2.3 Precautions

The following documents may not scan successfully:

- Documents of non-uniform thickness (e.g. envelopes and documents with attachments)
- Wrinkled or curled documents (See the following HINT)
- Folded or torn documents
- Documents with appended photographs, notes, etc.
- Tracing paper
- Coated paper
- Carbon paper
- Carbonless paper
- Photosensitive paper
- Perforated or punched documents
- Documents that are not square or rectangular
- Exceptionally thin documents (less than 52 g/m<sup>2</sup>)
- Photographs

Do not attempt to scan the following types of documents:

- Paper-clipped or stapled documents
- Documents on which the ink is still wet
- Documents smaller than A8 Portrait
- Documents wider than Letter size (8.5inches = 216mm, A4 is 210mm wide)
- Non-paper documents (such as fabric, foil, transparent paper)



- Carbonless paper contains chemical substances that may damage the pad assy or the pick and other rollers when documents are fed. Pay attention to the following:

Cleaning:

If pick errors occur frequently, clean the pad assy and pick roller.

For details on cleaning the pad assy and pick roller, refer to "[Chapter 7 Scanner Care](#)" (page 423).



Replacing parts:

The service life of the pad assy and pick roller may be shortened when compared to scanning only wood containing paper documents.

- When wood containing paper manuscripts are scanned, the life of the pad assy and pick roller may be shortened compared with the case where woodfree paper manuscripts are scanned.
- When scanning photographs, the face of the photograph may become damaged.




- When scanning semi-transparent documents, set the scan [Brightness] to "Light" to avoid image bleed through.
- To prevent the rollers from becoming dirty, avoid scanning documents containing large areas written or filled in with pencil. If scanning of such documents is unavoidable, clean the rollers frequently.
- To operate correctly, the ADF requires the leading edges of all document sheets be evenly aligned. Make sure that curling of the leading edge is within the following tolerances:






Take the following precautions when scanning plastic cards (for example ID cards).

- In Scan Settings, set the Multifeed Setup to [None]. For more details about Multifeed Setup, refer to "6.9.17 Multifeed Detection (Layer and Length)" (page 399).
- Place one card at a time into the ADF paper chute.
- Cards must be fed through the ADF in portrait mode, as in the following figure.



- Cards should be placed face down in the ADF paper chute.
- Embossed cards should be placed with the raised lettering side down.




- Cards should be of the following specifications:  
 ISO7810-compliant, Type ID-1 cards  
 Width × Length: 2.1 × 3.4 in / 54 × 86 mm  
 Thickness: 0.03 ±0.003 in / 0.76 ±0.08 mm  
 Material: PVC (polyvinyl chloride) or PVCA (polyvinyl chloride acetate)
- Cards that are excessively stiff may not be fed smoothly by the ADF.
- Cards that have become dirty from handling should be wiped clean before scanning.

## A.3 Maximum Document Loading Capacity

The maximum number of sheets that can be loaded into the ADF paper chute is determined by the length and weight of the document paper.


The following graph shows the maximum document loading capacity of ADF according to paper size and weight.



Unit	Standard paper weights						
g/m <sup>2</sup>	52	64	75	80	90	104	127
lb	14	17	20	21	24	28	34
kg	45	55	64.5	69	77.5	90	110

## A.4 Area not to be Perforated

ADF feed problems can occur while scanning if the document has any holes (punched, etc) in the shaded area shown in the following figure.



---

## A.5 Multifeed Detection Conditions

There are three multifeed detection modes: document layer, document length, and both document layer and length. The following conditions must be satisfied in each of these detection modes. The type of document and document conditions can cause the multifeed detection rate to drop.

### A.5.1 Detection by Layer

If [Ultrasonic] is selected in "[6.9.17 Multifeed Detection \(Layer and Length\)](#)" (page 399), multi-feeds are detected by layer.

In this case, set sheets of the same thickness in the ADF at any one time.

- Document thickness: 0.065 to 0.15mm
- Punched holes are not allowed within 17.5mm (0.7in) either side of the center of paper.
- Do not glue on any other paper within 17.5mm (0.7in) either side of the center of paper.

### A.5.2 Detection by Length

If [Length] is selected in "[6.9.17 Multifeed Detection \(Layer and Length\)](#)" (page 399), multi-feeds are detected by length

In this case, set sheets of the same length in the ADF at any one time.

- Document length deviation: 1% or less
- Punched holes are not allowed within 17.5mm (0.7in) either side of the center of paper.



## A.5.3 Detection by both Layer and Length

If [Both] is selected in "6.9.17 Multifeed Detection (Layer and Length)" (page 399), multifeeds are detected by both layer and length.

In this case, set sheets of the same thickness and length in the ADF at any one time.


- Document thickness: 0.065 to 0.15mm
- Document length deviation: 1% or less
- Punched holes are not allowed within 17.5mm (0.7in) either side of the center of paper.
- Do not glue on any other paper within 17.5mm (0.7in) either side of the center of paper.



- Multifeed detection by layer will often mis-detect very thick paper or plastic documents. When scanning such documents, select "None" on the "Multi-feed Setup" screen.
- Multifeed may not be detected for the top and bottom 25mm of a document.



Area where multifeed detection is possible





# *Appendix B*

---

## Management Settings and Files

Admin

User



This appendix describes the scanner operating environment and management settings and files.

<b>B.1 e-Mail Address Setting Values .....</b>	<b>488</b>
<b>B.2 Scanner Configuration File Format .....</b>	<b>489</b>

## B.1 e-Mail Address Setting Values

e-Mail addresses may be up to 256 characters long. One of the following e-mail address formats must be used:

- *XXXXXXXX@IP\_address*
- *XXXXXXXX@Host\_name*
- *XXXXXXXX@Domain\_name*

<i>XXXXXXXX</i>	<p>Comprised of alphanumerics and the following symbols.  ! # \$ % &amp; ' * + - / = ? ^ _ ` {   } ~ .</p> <p>However, periods (.) cannot be used in the following cases.</p> <ul style="list-style-type: none"> <li>● Using periods (.) as a initial character</li> <li>● Using periods (.) as a last element</li> <li>● Using periods (.) consecutively</li> </ul>
<i>IP_address</i>	<p>Comprised of numbers separated by periods (.).</p> <p>IP addresses within the following ranges may be used:  1.0.0.1 - 126.255.255.254  128.0.0.1 - 191.255.255.254  192.0.0.1 - 223.255.255.254</p>
<i>Host_name</i>	<p>Comprised of alphanumerics and hyphens (-) only. Initial character may not be a hyphen.</p>
<i>Domain_name</i>	<p>Name elements comprised of alphanumerics and hyphens (-) are separated by periods (.).</p> <p>Each name element may contain up to 63 characters, and only alphabetic characters may be used for the last element.</p>

## B.2 Scanner Configuration File Format

The scanner configuration file format requirements differ for the following two cases.

- For importing
- For exporting

### B.2.1 Scanner Configuration File Format (for Importing)

This section describes the scanner configuration file format requirements for importing.

- The file charset should be the same as the value on the Central Admin Console, "Central Admin Server Settings" screen. The default charset is UNICODE (UTF-8).
- The file is in CSV format. The values for each item are as follows.

Item	Value and Format	Remarks
Mac Address	XX:XX:XX:XX:XX (X is an alphanumeric character)	Optional
IP Address	xxx.xxx.xxx.xxx (xxx is a value from 0 to 255)	Optional
Subnet Mask	xxx.xxx.xxx.xxx (xxx is a value from 0 to 255)	Optional
Scanner Name	Up to 15 alphanumeric characters long (hyphens may also be used)	Required
Port Number	Numerical value from 1 to 65535	Optional
Use HTTPS?	0: Do not use HTTPS (default) 1: Use HTTPS	Optional
Model	Up to 64 characters long	Optional
Add-in Group	Up to 32 characters long (*1)	Optional
Settings Group	Up to 32 characters long (*1)	Optional
Comment	Up to 256 characters long	Optional
System Updates	0: Enable (default) 1: Disable	Optional

(\*1): The following character strings cannot be used:  
(Default) (All) \_\_default\_\_ \_\_all\_\_  
" \_\_ " is two underbars entered one after another.

## B.2.2 Scanner Configuration File Format (for Exporting)

This section describes the scanner configuration file format requirements for exporting.

- The default value for the file name is "scannerinfo.csv".
- The file charset should be the same as the value on the Central Admin Console, "Central Admin Server Settings" screen. The default charset is UNICODE (UTF-8).
- A title line can be added as the first line in a file when the file is exported.
- The file is in CSV format. The values for each item are as follows.

Item	Value and Format	Remarks	
Mac Address	XX:XX:XX:XX:XX (X is an alphanumeric character)	None	
IP Address	xxx.xxx.xxx.xxx (xxx is a value from 0 to 255)		
Subnet Mask	xxx.xxx.xxx.xxx (xxx is a value from 0 to 255)		
Scanner Name	—		
Port Number	Numerical value from 1 to 65535		
Use HTTPS?	0: Do not use HTTPS (default) 1: Use HTTPS		
Model	—		
Add-in Group	Arbitrary character string		
Settings Group	Arbitrary character string		
Comment	Arbitrary character string		
System Updates	0: Enable (default) 1: Disable		
Info Last Modified	YYYYMMDD hh:mm:ss		When the [Include detailed scanner information.] checkbox is selected.
Registered	0: # Unregistered 1: # Registered		
Update Status	0: NotTarget 1: Finished 2: Pending 3: Error 4: Unregistered		
System Version	—		
Add-in Version	—		
Scanner Settings	—		
Last Inventory Taken	YYYYMMDD hh:mm:ss		



Item	Value and Format	Remarks
Last System Update	YYYYMMDD hh:mm:ss	When the [Include detailed scanner information.] checkbox is selected.
Last Add-in Install	YYYYMMDD hh:mm:ss	
Last Scanner Settings Update	YYYYMMDD hh:mm:ss	
Current System Update Status	0: NotTarget 1: Finished 2: Pending 3: Error 4: Unregistered	
Current Add-in Install Status	0: NotTarget 1: Finished 2: Pending 3: Error 4: Unregistered	
Current Scanner Settings Status	0: NotTarget 1: Finished 2: Pending 3: Error 4: Unregistered	
Scanner Version	—	
PAD ASSY	Numerical value	
PICK ROLLER	Numerical value	
Total Throughput	Numerical value	
Date of Registration	YYYYMMDD hh:mm:ss	
Cumulative On Time	Numerical value	
Last Audit Log Collected	YYYYMMDD hh:mm:ss	
Security Update Version	Syy-nn	
Error Status	0: No 1: Yes	
Operating Status	0: Unreported/Unregistered 1: Offline 3: Free 4: In use	
Installed Options	—	





# *Appendix C*

---

## **Root Certification Authority**

Admin User

This appendix provides an explanation of root certification authority.



**C.1 Root Certification Authority List..... 494**

---

## C.1 Root Certification Authority List

SSL (Secure Socket Layer) encrypted communication may be used by the scanner for user authentication and save operations to the FTP server or a SharePoint folder.

With SSL, trust certificates are exchanged to authenticate the communication opponents.

The following root certificate authorities are pre-registered in the scanner, but further root certificates may be imported. For details about importing certificates, refer to ["4.6.14 Managing Certificates"](#) (page 84).

Issuer	Valid until... (YYYY/MM/DD)
C&W HKT SecureNet CA Root	2010/10/16
CA 1	2019/3/11
Certiposte Classe A Personne	2018/6/24
Certiposte Serveur	2018/6/24
Certisign - Autoridade Certificadora - AC2	2018/6/27
Certisign - Autoridade Certificadora - AC4	2018/6/27
Certisign Autoridade Certificadora AC1S	2018/6/27
Certisign Autoridade Certificadora AC3S	2018/7/10
Class 1 Primary CA	2020/7/7
Class 2 Primary CA	2019/7/7
Class 3 Primary CA	2019/7/7
Class 3 Public Primary Certification Authority	2028/8/2
Class 3P Primary CA	2019/7/7
Class 3TS Primary CA	2019/7/7
Deutsche Telekom Root CA 1	2019/7/10
Deutsche Telekom Root CA 2	2019/7/10
DST (ANX Network) CA	2018/12/10
DSTCA E1	2018/12/11
DSTCA E2	2018/12/10
DST-Entrust GTI CA	2018/12/9
Entrust.net Secure Server Certification Authority	2019/5/26
Equifax Secure Certificate Authority	2018/8/23

<b>Issuer</b>	<b>Valid until... (YYYY/MM/DD)</b>
Equifax Secure eBusiness CA-1	2020/6/21
Equifax Secure eBusiness CA-2	2019/6/23
Equifax Secure Global eBusiness CA-1	2020/6/21
EUnet International Root CA	2018/10/3
FESTE, Public Notary Certs	2020/1/2
FESTE, Verified Certs	2020/1/2
First Data Digital Certificates Inc. Certification Authority	2019/7/4
FNMT Clase 2 CA	2019/3/19
GlobalSign Root CA	2014/1/28
GTE CyberTrust Global Root	2018/8/14
<a href="http://www.valicert.com/">http://www.valicert.com/</a>	2019/6/26
Microsoft Root Authority	2020/12/31
Microsoft Root Certificate Authority	2021/5/10
NetLock Expressz (Class C) Tanusitvanykiado	2019/2/20
NetLock Kozjegyzoi (Class A) Tanusitvanykiado	2019/2/20
NetLock Uzleti (Class B) Tanusitvanykiado	2019/2/20
PTT Post Root CA	2019/6/26
Saunalahden Serveri CA	2019/6/26
SecureNet CA Root	2010/10/16
SecureSign RootCA1	2020/9/15
SecureSign RootCA2	2020/9/15
SecureSign RootCA3	2020/9/15
SIA Secure Client CA	2019/7/9
SIA Secure Server CA	2019/7/9
Swisskey Root CA	2016/1/1
TC TrustCenter Class 1 CA	2011/1/1
TC TrustCenter Class 2 CA	2011/1/1
TC TrustCenter Class 3 CA	2011/1/1



<b>Issuer</b>	<b>Valid until... (YYYY/MM/DD)</b>
TC TrustCenter Class 4 CA	2011/1/1
Thawte Premium Server CA	2021/1/1
Thawte Server CA	2021/1/1
UTN - DATACorp SGC	2019/6/25
UTN-USERFirst-Hardware	2019/7/10
UTN-USERFirst-Network Applications	2019/7/10
VeriSign Trust Network	2028/8/2

# *Appendix D*

---

## **Scanner Specifications**

Admin

User

This appendix gives specifications for the scanner as a whole, and for scanner parts.

**D**

<b>D.1 Device Specifications.....</b>	<b>498</b>
<b>D.2 Scanner Specifications.....</b>	<b>499</b>
<b>D.3 Languages Supported By and Keyboard Covers Provided With.....</b>	<b>500</b>

---

## D.1 Device Specifications

Item	Specification
Dimensions (W × D × H)	315 × 415 × 281mm
Power consumption (AC)	88W
Weight	13kg
LCD touch panel	8.4-inch XGA TFT LCD monitor Analog resistive touch panel
Keyboard	101 keyboard
Network interface	LAN (10Base-T/100Base-TX)
Input power	AC100-240V± 10% 50/60Hz



This scanner is installed with a Wake-On-LAN card. If the last time the scanner power was turned off was due to an error of power failure, the Wake-On-LAN function will not work.

## D.2 Scanner Specifications

Item	Specification	Note	
Scanner type	ADF (Automatic Document Feeder)		
Image sensor	Color CCD × 2		
Light source	White cold cathode fluorescent discharge lamp × 2		
Scannable area	Maximum: Legal (8.5 × 14 in) Minimum: A8 (portrait) (52 × 74 mm) or 2 × 3 in	When "Custom" paper size setting is used, a page length of up to 863 mm (34 in) is allowed for document scanning.	
Paper weight	52 to 127 g/m <sup>2</sup> (14 to 34 lb)		
Scanning speed (A4/Letter, portrait) (*1)	Color	Simplex: 30 sheets/min. Duplex: 60 pages/min.	150 dpi
	Grayscale		
	Black & White		
	Color	Simplex: 25 sheets/min. Duplex: 50 pages/min.	200 dpi
	Grayscale		
	Black & White		
ADF paper chute capacity	50 sheets (Letter/A4, 80g/m <sup>2</sup> (20 lb))		
Optical resolution	600 dpi		
Output resolution	150 dpi, 200 dpi, 300 dpi, 600 dpi		
Grayscale level (internal/external)	1024/256 levels		

(\*1): The maximum hardware limitation. Actual scanning time includes software processing time such as data transfer time.



## D.3 Languages Supported By and Keyboard Covers Provided With

Scanner Unit Part Number	Supported Language		Keyboard Cover	
PA03544-B101	English	English (US Keyboard)	-	
	Italian	Italiano	PA03544-K600	ITA
	German	Deutsch	PA03544-K601	DEU
	French	Français	PA03544-K602	FRA
	Spanish	Español	PA03544-K603	ESP
	Portuguese	Português	PA03544-K604	PRT
	Russian	Русский	PA03544-K605	RUS
	Korean	한국어	PA03544-K606	KOR
	English	English (UK Keyboard)	PA03544-K608	GBR
	Turkish	Türkçe	PA03544-K610	TUR
PA03544-B102	English	English (US Keyboard)	-	
	Traditional Chinese	中文 (繁體)	PA03544-K607	CHN
	French (Canada)	Français (Canada)	PA03544-K609	CAN
PA03544-B105	English	English (US Keyboard)	-	
PA03544-B205	Spanish	Español	PA03544-K603	ESP
	Portuguese	Português (América do Sul)	PA03544-K604	PRT

To obtain a keyboard cover, contact your FUJITSU dealer or an authorized FUJITSU scanner service provider.



# Appendix E

---

## Operation Messages

Admin

User

This appendix provides information about messages which may appear during scanner operations, and how to deal with them.


E

<b>E.1 Administrator Messages .....</b>	<b>502</b>
<b>E.2 Regular User Messages .....</b>	<b>526</b>
<b>E.3 Central Admin Messages .....</b>	<b>584</b>





---

## E.1 Administrator Messages

The following messages may appear during administrator operation. Messages are displayed in the form of a dialog box as follows.



The following table describes the types of marks which may appear in a message dialog box.

Marks	Description
	Warning message. Displayed if invalid values have been entered for a setting. Check the message and press the [OK] button.
	Error message. Check the message and press the [OK] button.
	Information message. Check the message and press the [OK] button. No action required.
	Inquiry message. Check the message, select and press a button.

## E.1.1 Administrator Screen Messages

Screen	Message	Action
Scanner Name	Scanner name contains invalid characters.	Re-enter the scanner name using only specified valid characters. Do not enter a blank space before or after the scanner name. Do not use control characters or any of the following symbols: " / \ [ ] :   < > + = ; , ?
	Workgroup or domain name contains invalid characters.	Workgroup or domain name contains invalid characters. Workgroup names may be up to 15 alphanumeric characters long. Domain names may be up to 255 alphanumeric characters long, and ".-_" can also be used.
	Domain login failed.	Check the specified user name and password.
	Specified domain cannot be found.	Could not connect to domain. Check that the specified domain is correct, and that it is connected to the network.
	Workgroup or domain name has not been entered.	Group or domain name contains invalid characters. Group names may be up to 15 alphanumeric characters long. Domain names may be up to 255 alphanumeric characters long, and ".-_" can also be used.
Date/Time	Date/time setting is invalid.	Re-enter the date/time using only valid numbers.
	Time adjustment has caused the session to timeout. Logging out now.	No action required.
Login Settings	Invalid user name.	Enter a valid user name, and try again.
	User name contains invalid characters.	Re-enter the user name using only specified valid characters.

E

Screen	Message	Action
Admin Password	New password contains invalid characters.	Enter a valid new password. Alphanumeric characters (case sensitive) and symbols may be entered.
File Names	"Save as:" file name contains invalid characters (√:*?"<> ), or is set to a reserved string (CON, PRN, AUX, CLOCK\$, NUL, COM0, ..., COM9, LPT0, ..., LPT9). Re-enter the file name and try again.	Do not use the following symbols or reserved strings: √: * ? " < >   CON PRN AUX CLOCK\$ NUL COM0 - COM9 LPT0 - LPT9 Re-enter the file name using only the specified valid characters.
Certificate Management	Authentication certificate could not be imported.	Contact your FUJITSU scanner dealer or an authorized FUJITSU scanner service provider.
	Authentication certificate could not be imported into the "Trusted Root Certificate Authorities" store.	Contact your FUJITSU scanner dealer or an authorized FUJITSU scanner service provider.
	Authentication certificate could not be deleted.	Contact your FUJITSU scanner dealer or an authorized FUJITSU scanner service provider.
IP Address	IP address could not be set. Try again.	Try again. If that does not work, restart the scanner and try again.
Admin Network	Invalid combination of settings has been specified.	The following settings combinations are not possible. <ul style="list-style-type: none"> <li>● Port Number "80" and SSL "On"</li> <li>● Port Number "443" and SSL "Off"</li> </ul> Enter a valid settings combination for Port Number and SSL.
Central Admin Server	Scanner details could not be registered with the iScanner Central Admin server.	Check the Central Admin Server connection environment.
	Invalid address has been specified.	Enter a valid address, and try again.
DNS Server	DNS suffix contains invalid characters.	Re-enter the DNS suffix using only specified valid characters.



Screen	Message	Action
NTP Server	System time synchronization failed.	<p>Try the following:</p> <ul style="list-style-type: none"><li>● Check the NTP server IP address, host name, and FQDN settings.</li><li>● Check the network path between to the NTP server for problems.</li><li>● The NTP server may be busy. Wait a short time before trying again to synchronize the system time. If that does not work, the specified server may not be an NTP server, so try a different NTP server.</li><li>● The specified NTP server cannot provide a trusted date and time. It attempted to acquire the date and time from a higher level NTP server, but failed. Try a different NTP server or have the network administrator investigate.</li><li>● Check that the time is correct. If the time is incorrect, adjust the date/time, and try again.</li><li>● Refer to "<a href="#">4.6.5 Setting the Date/Time</a>" (page 64), adjust the date/time, and try again.</li></ul>
	Time synchronization has caused the session to timeout. Logging out now.	No action required.
LDAP Server	Connection test failed. Check the LDAP settings.	<p>Check that each item has been set correctly.</p> <ul style="list-style-type: none"><li>● Address</li><li>● Port number</li><li>● SSL</li><li>● Search base</li><li>● Authorized user (DN)</li><li>● User name</li><li>● Password</li></ul> <p>If there are no problems with the settings, contact a network administrator.</p>

Screen	Message	Action
Network Printer	Access was refused. Login is not possible at this time.	Try the following: <ul style="list-style-type: none"> <li>● Try again when login is possible.</li> <li>● Contact a network administrator to have the time setting changed.</li> </ul>
	Access was refused. The specified account is currently locked out.	Contact a network administrator.
	Access was refused.	Contact a server administrator to find out if an access permit has been set.
	Operation not possible. Network path is not working.	Contact a server administrator.
	Not connected to the network.	Check that the system network is functioning normally by performing a ping test from another machine in the network, other than the server with network printer. If the system network is not operating properly, refer to <a href="#">"Failure to connect to a server using its IP address"</a> (page 461) for further solutions.
	Number of network path connections has reached the maximum allowed. No more may be specified.	Close unneeded network connections, then try specifying the desired network path again.
	Length of specified network printer path exceeds the maximum selectable path length. This printer may not be selected.	Select a different network printer and try again.
	Cannot acquire network information.	Contact an administrator for the specified server.
	Specified user is no longer able to login to this network printer.	The specified user account has expired. <ul style="list-style-type: none"> <li>Try the following: <ul style="list-style-type: none"> <li>● Login with a different account.</li> <li>● Contact a network administrator to have the account validated.</li> </ul> </li> </ul>



Screen	Message	Action
Network Printer	Specified password is no longer valid for this network printer.	Specified password was expired. Try the following: <ul style="list-style-type: none"><li>● Login with a different account.</li><li>● Contact a network administrator to have the password validated again.</li></ul>
	Specified user needs to renew their password for this network printer.	Change the password before logging in to the network printer for the first time. Try the following: <ul style="list-style-type: none"><li>● Login with a different account.</li><li>● Contact a network administrator to have the password changed.</li></ul>
	Cannot add printer.	Try the following: <ul style="list-style-type: none"><li>● Check the specified network printer path.</li><li>● Check that the printer settings and access privileges for the network printer have been set correctly.</li><li>● Check that the shared printer settings have been set correctly on the print server.</li><li>● By performing a ping test, check if the network connection to the printer is working properly. If there is no response from the ping test, check that the system network is functioning normally by performing a ping test from another machine in the network.</li><li>● Check that the primary DNS suffix of the print server has been set correctly.</li></ul>
	Network printer tree information is not available.	Check whether the Central Admin Server "Computer Browser" service is stopped. If stopped, start the service.

Screen	Message	Action
SharePoint Folder	SharePoint access error occurred.	Check the network connection and server status, and try again.
	SharePoint site cannot be accessed.	
	SharePoint site not found.	Check the network connection and site settings, and try again.
Network Folder	Access was refused. Login is not possible at this time.	Try the following: <ul style="list-style-type: none"> <li>● Try again when login is possible.</li> <li>● Contact a network administrator to have the time setting changed.</li> </ul>
	Access was refused. The specified account is currently locked out.	Contact a network administrator.
	Specified network folder alias is already being used. Try a different alias.	Rename the network folder whose alias is already being used, and try adding the folder again.
	Access was refused.	Contact a server administrator to find out if an access permit has been set.
	Cannot find the network folder path.	Contact a server administrator.
	Operation not possible. Network path is not working.	Contact a server administrator.
	Not connected to the network.	Check that the system network is functioning normally by performing a ping test from another machine in the network, other than the server with network folder. If the system network is not operating properly, refer to <a href="#">"Failure to connect to a server using its IP address" (page 461)</a> for further solutions.
	Number of network path connections has reached the maximum allowed. No more may be specified.	Close unneeded network connections, then try specifying the desired network path again.
	Length of specified network folder path exceeds the maximum selectable path length. This folder may not be selected.	Select a different network folder and try again.





Screen	Message	Action
Network Folder	Cannot acquire network information.	Contact an administrator for the specified server.
	Specified user is no longer able to login to this network folder.	The specified user account has expired. Try the following: <ul style="list-style-type: none"><li>● Login with a different account.</li><li>● Contact a network administrator to have the account validated.</li></ul>
	Specified password is no longer valid for this network folder.	Specified password was expired. Try the following: <ul style="list-style-type: none"><li>● Login with a different account.</li><li>● Contact a network administrator to have the password validated again.</li></ul>
	Specified user needs to renew their password for this network folder.	Change the password before logging in to the network folder for the first time. Try the following: <ul style="list-style-type: none"><li>● Login with a different account.</li><li>● Contact a network administrator to have the password changed.</li></ul>
	Cannot connect to FTP path.	Try the following: <ul style="list-style-type: none"><li>● Check that the FTP path is correct.</li><li>● Check the user name and password.</li><li>● Check the protocol settings.</li><li>● Check the port number.</li><li>● Check the passive mode settings.</li><li>● Check the encryption settings.</li><li>● Check proxy settings.</li></ul>
	Network folder tree information is not available.	Check whether the Central Admin Server "Computer Browser" service is stopped. If stopped, start the service.

Screen	Message	Action
Alert Notification	Test e-mail could not be sent.	<p>Try the following:</p> <ul style="list-style-type: none"> <li>● Check if the computer connected to the SMTP server is running properly.</li> <li>● Check if an e-mail can be sent to the address from another computer in the network.</li> <li>● By performing a ping test, check if the SMTP server or the network connection to the SMTP server is working properly. If there is no response from the SMTP server ping test, check that the system network is functioning normally by performing an SMTP server ping test from another machine in the network. <ul style="list-style-type: none"> <li>● If the system network is not operating properly, refer to <a href="#">"Failure to connect to a server using its IP address" (page 461)</a> for further solutions.</li> <li>● If the only the SMTP server cannot connect to the network, request the network administrator to check that the SMTP server and the network connection to the server are functioning normally.</li> </ul> </li> </ul>

Screen	Message	Action
System Status	Cannot read data from a scanner unit.	<p>Try the following:</p> <ul style="list-style-type: none"> <li>● If the scanner does not restart automatically, press the [Shutdown] button on the "Login" screen to turn the power off, and turn the power back on again to restart the scanner.</li> <li>● If the error status persists after the scanner is restarted, press the [Shutdown] button on the "Login" screen, disconnect the AC cable from the scanner to turn the power off, wait for at least 10 seconds, then reconnect the AC cable and try turning the power back on again. If the error status persists, contact your FUJITSU scanner dealer or an authorized FUJITSU scanner service provider.</li> </ul>
Usage Status	Cannot read data from a scanner unit.	<p>Try the following:</p> <ul style="list-style-type: none"> <li>● If the scanner does not restart automatically, press the [Shutdown] button on the "Login" screen to turn the power off, and turn the power back on again to restart the scanner.</li> <li>● If the error status persists after the scanner is restarted, press the [Shutdown] button on the "Login" screen, disconnect the AC cable from the scanner to turn the power off, wait for at least 10 seconds, then reconnect the AC cable and try turning the power back on again. If the error status persists, contact your FUJITSU scanner dealer or an authorized FUJITSU scanner service provider.</li> </ul>



Screen	Message	Action
User Data Store	Specified backup file could not be uploaded, or is not a valid user data store.	Try the following: <ul style="list-style-type: none"> <li>● Check if the specified backup file is correct.</li> <li>● Try restoring the file again.</li> <li>● Specified backup file may not be uploaded because of network error. Check the network status.</li> </ul>
	Restoring from the specified backup file will cause the maximum number of user data stores to be exceeded. Clear the existing user data stores, and try again.	Up to 1,000 users can be registered. Clear the existing user data stores, and try again. <a href="#">"Clearing the User Data Store" (page 170)</a>
	User data could not be restored. Specified file contains unsupported data.	Versions do not match between the backup device and restoring device. Update the restoring device. <a href="#">"4.10.3 Updating the Scanner's System Software" (page 175)</a>
	User data could not be restored. The language of the backup file must be the same as the current language setting.	Change the language setting back to the language at the time of backup, and try restoring the user data again.
System Settings File	Specified backup file could not be found or could not be uploaded.	Try the following: <ul style="list-style-type: none"> <li>● Check if the specified backup file is correct.</li> <li>● Try restoring the file again.</li> <li>● Specified backup file may not be uploaded because of network error. Check the network status.</li> </ul>
	Backup data could not be restored. Specified file contains unsupported data.	Versions do not match between the backup device and restoring device. Update the restoring device. <a href="#">"4.10.3 Updating the Scanner's System Software" (page 175)</a>
	Backup data could not be restored. The language of the backup file must be the same as the current language setting.	Change the language setting back to the language at the time of backup, and try restoring the backup data again.

Screen	Message	Action
System Settings File	System settings were successfully restored. The scanner will be restarted.	No action required.
System Updates	Specified update file cannot be applied to this system.	Check the applicable system for the update file.
	Specified update file could not be uploaded, or is not a valid system update.	Try the following: <ul style="list-style-type: none"> <li>● Check if the specified update file is correct, and try again.</li> <li>● Specified update file may not be uploaded because of network error. Check the network status.</li> </ul>
Common	Error: problem with XXXXXX. Contact your FUJITSU scanner dealer or an authorized FUJITSU scanner service provider. Error code=xxxxxxx Result code=xxxxxxx (XXXXXX: Function Name)	Contact your FUJITSU scanner dealer or an authorized FUJITSU scanner service provider.
	Error: problem with XXXXXX. Contact your FUJITSU scanner dealer or an authorized FUJITSU scanner service provider. (XXXXXX: Function Name)	Contact your FUJITSU scanner dealer or an authorized FUJITSU scanner service provider.
Add-in Manager	Specified Add-in data contents are invalid.	Check the contents of the specified Add-in module.
	Specified Add-in file cannot be applied to this system.	Check the system version, prepare the correct version of the update file, and try again.
	Specified Add-in could not be uploaded.	Try the following: <ul style="list-style-type: none"> <li>● Check if the specified update file is correct, and try again.</li> <li>● Specified update file may not be uploaded because of a network error. Check the network status.</li> </ul>
	System version xx or later is required to install the specified Add-in.	Update the system, and then install the Add-in module.

Screen	Message	Action
Admin Tool	Connection error.	For more details about the process, refer to <a href="#">"8.3.3 Failure to Access the Scanner using a Web Browser, Admin Tool, or Central Admin Server"</a> (page 465).
	Cannot connect to this system version.	Install the Admin Tool from the scanner, and try again.
Job Settings	Session has timed out. Click the "Close" button in the toolbar to close the edit settings window.	Close the edit settings window, and try again.
	A fatal error has occurred. Close the Job Settings session, then try again. If the problem persists, the administrator should contact the FUJITSU scanner dealer or an authorized FUJITSU scanner service provider for help.	Close the Job Settings session, and try again.
	Insufficient memory to continue. Close the Job Settings session, then try again.	Ensure that there is enough memory capacity available, and try again.
	Insufficient free disk space to continue. Close the Job Settings session, then try again.	Ensure that there is enough free disk space available, and try again.
LDAP Connection	LDAP search base setting is invalid.	Correct the LDAP settings.
	LDAP server is busy.	Wait for a while, and try again.
	Search has timed out. Contact a system administrator.	Contact a system administrator.
	Cannot connect to the LDAP server. Check that the LDAP access settings are correct and that the LDAP server is running and accessible.	Contact a system administrator.
	LDAP server connection failed SSL authentication.	Contact a system administrator.
	LDAP access user name, password and/or search base settings are invalid.	Enter a valid user name and password, and try again.

Screen	Message	Action
LDAP Connection	LDAP authorized user (DN), password and/or search base settings are invalid.	Try the following: <ul style="list-style-type: none"> <li>● Check the LDAP server and search base settings.</li> <li>● Enter a valid authorized user (DN) and password.</li> </ul>
	LDAP server access failed. Check that the LDAP access settings and LDAP server settings are correct.	Contact a system administrator.
	Could not get data from the LDAP server. Check the LDAP search base settings.	Check the search base settings, and try again.
	Connecting to the LDAP server. Enter a User Name and Password.	Enter a user name and password.
	Connecting to the LDAP server. Enter an Authorized User (DN) and Password.	Try the following: <ul style="list-style-type: none"> <li>● Check the LDAP server and search base settings.</li> <li>● Enter a valid authorized user (DN) and password.</li> </ul>
	LDAP server access failed. Check that the LDAP access, LDAP server, Authorized User (DN), Password and Search Base settings are correct.	Try the following: <ul style="list-style-type: none"> <li>● Contact a server administrator to check the LDAP server operation.</li> <li>● Check the network settings.</li> <li>● Check the LDAP server and search base settings.</li> <li>● Enter a valid authorized user (DN) and password.</li> </ul>
	Number of matches has reached the maximum allowed. Try refining the search conditions.	Refine the search conditions, and try again.



---

## E.1.2 System Log Messages

System log messages which may appear during administrator operations can be arranged into the following three categories:

- Information
- Error
- Warning

### ■ Information

Code	Message	Action
01000001	(XXXXXX) Settings were changed. Info: (XXXXXX: Function Name)	No action required.
01000002	Pad assy usage counter was cleared.	
01000003	Pick roller usage counter was cleared.	
01000004	All users log was prepared for download.	
01000005	System log was prepared for download.	
01000006	User data store was prepared for download.	
01000007	User data store was restored.	
01000008	System settings were prepared for download.	
01000009	System was updated. Info: New System Version = x.x.x.x	
01000009	System was updated. Info: System Version = x.x.x.x	
01000009	System was updated. Info: Security Version = x.x.x.x	
01000009	System was updated. Info: Option xxxx = xxxx	
01000010	Test e-mail was sent successfully.	
01000011	User data store was cleared.	
01000012	System time was synchronized successfully.	
01000013	System settings restoral completed.	



Code	Message	Action
01000014	Technical support data was prepared for download.	No action required.
01000015	Add-in module was installed successfully. Add-in: xxxxxx Version: xxxxxx	
01000016	Add-in module was uninstalled successfully.	
01000017	System settings restoral started.	
01000018	Update Scheduler has been enabled.	
01000019	Update Scheduler has been disabled.	
01000020	Login LDAP server connection test succeeded.	
01000021	e-Mail address LDAP server connection test succeeded.	
01000022	Update is already in effect, and was not applied again. Info: System Version = x.x.x.x	
	Update is already in effect, and was not applied again. Info: Security Version = x.x.x.x	
0C010001	Created new Job. Job name: XXXXXX	
0C010002	Copied existing Job. Job name: XXXXXX Source name: YYYYYY	
0C010003	Edited Job. Job name: XXXXXX	
0C010004	Deleted Job. Job name: XXXXXX	
0C020001	Created new Job Menu. Menu name: XXXXXX	
0C020002	Copied existing Job Menu. Menu name: XXXXXX Source name: YYYYYY	
0C020003	Edited Job Menu. Menu name: XXXXXX	



<b>Code</b>	<b>Message</b>	<b>Action</b>
0C020004	Deleted new Job Menu. Menu name: <i>XXXXXX</i>	No action required.
0C030001	Created new User Group. Group name: <i>XXXXXX</i>	
0C030003	Edited User Group. (Deleted members belonging to a non-current server type.) (*) Group name: <i>XXXXXX</i>	
0C030004	Deleted User Group. Group name: <i>XXXXXX</i>	
0C040001	LDAP server access succeeded. Search base: <i>XXXXXX</i>	

(\*): Only recorded when a member of a different LDAP server type is deleted while editing the user group.

## ■ Error

Code	Message	Action
81001001	Error: problem with <i>XXXXXX</i> . Contact your FUJITSU scanner dealer or an authorized FUJITSU scanner service provider. Error code= <i>xxxxxxx</i> Result code= <i>xxxxxxx</i> ( <i>XXXXXX</i> : Function Name)	Contact your FUJITSU scanner dealer or an authorized FUJITSU scanner service provider.
81001002	Error: problem with <i>XXXXXX</i> . Contact your FUJITSU scanner dealer or an authorized FUJITSU scanner service provider. ( <i>XXXXXX</i> : Function Name)	Contact your FUJITSU scanner dealer or an authorized FUJITSU scanner service provider.
81001003	Corrupted system log file was deleted.	No action required.
81001004	Corrupted user log file was deleted.	
81001005	Settings could not be changed. Info: <i>XXXXXX</i> Add-in: <i>xxxxxxx</i> Version: <i>xxxxxxx</i>	Failed to register an Add-in, change Add-in settings, or change the restored scanner system settings. Check the scanner status and setting value. Cause of the error and the failed setting value are shown at Info: <i>XXXXXX</i> .
81001006	(IP Address) Settings could not be changed. Info: Specified IP address is already being used. DHCP = Off IP Address = <i>xxx.xxx.xxx.xxx</i> Subnet Mask = <i>xxx.xxx.xxx.xxx</i> Default Gateway = <i>xxx.xxx.xxx.xxx</i>	Returns to the previous IP address before it was changed. Enter a non-duplicated IP address, and try again.
81001007	Update Scheduler could not be enabled.	Contact your FUJITSU scanner dealer or an authorized FUJITSU scanner service provider.
81001008	Update Scheduler could not be disabled.	Contact your FUJITSU scanner dealer or an authorized FUJITSU scanner service provider.

<b>Code</b>	<b>Message</b>	<b>Action</b>
7C040001	LDAP search base setting is invalid. Search base: <i>XXXXXX</i>	Check the search base settings.
7C040002	LDAP server is busy. Search base: <i>XXXXXX</i>	Try the following: <ul style="list-style-type: none"> <li>● Wait for a while, and try again.</li> <li>● Contact a server administrator to check LDAP server operation.</li> </ul>
7C040003	Search has timed out. Contact a system administrator. Search base: <i>XXXXXX</i>	Contact a server administrator to check that the search timeout setting is correct.
7C040005	Cannot connect to the LDAP server. Check that the LDAP access settings are correct and that the LDAP server is running and accessible. Search base: <i>XXXXXX</i>	Try the following: <ul style="list-style-type: none"> <li>● Check the LDAP server and search base settings.</li> <li>● Contact a server administrator to check LDAP server operation.</li> </ul>
7C040006	LDAP server connection failed SSL authentication. Search base: <i>XXXXXX</i>	Contact a server administrator to check that the SSL authentication settings and certification for the LDAP server are correct.
7C040008	LDAP access user name, password and/or search base settings are invalid. Search base: <i>XXXXXX</i>	Try the following: <ul style="list-style-type: none"> <li>● Specify a correct user name and password.</li> <li>● Specify a valid user name and password.</li> <li>● Check the LDAP server and search base settings.</li> </ul>
7C040009	LDAP server access failed. Check that the LDAP access settings and LDAP server settings are correct. Search base: <i>XXXXXX</i> Detail error code: <i>XXXXXXXXXX</i> Detail error message: <i>XXXXXXXXXX</i>	Try the following: <ul style="list-style-type: none"> <li>● Contact a server administrator to check LDAP server operation.</li> <li>● Check that the network settings are correct.</li> </ul>
7C040010	Could not get data from the LDAP server. Check the LDAP search base settings. Search base: <i>XXXXXX</i>	Check the search base settings.

Code	Message	Action
7C040011	LDAP authorized user (DN), password and/or search base settings are invalid. Search base: <i>XXXXXX</i>	Try the following: <ul style="list-style-type: none"> <li>● Check the LDAP server and search base settings.</li> <li>● Set a valid authorized user (DN) and password.</li> </ul>
7C040012	LDAP server access failed. Check that the LDAP access, LDAP server, Authorized User (DN), Password and Search Base settings are correct. Search base: <i>XXXXXX</i> Detail error code: <i>XXXXXXXXXX</i> Detail error message: <i>XXXXXXXXXX</i>	Try the following: <ul style="list-style-type: none"> <li>● Contact a server administrator to check the LDAP server operation.</li> <li>● Check the network settings.</li> <li>● Check the LDAP server and search base settings.</li> <li>● Set a valid authorized user (DN) and password.</li> </ul>

■ **Warning**

Code	Message	Action
82001001	Cannot read data from a scanner unit.	Check the scanner connection.
82001002	Scheduled date/time for update is not more than 10 minutes away, so Update Scheduler could not be enabled.	Contact a server administrator to have the Update Scheduler set to a later time.



---

### E.1.3 Alert Monitor System Log Messages

System log messages which may be received from the scanner alert monitor service can be arranged into the following three types:

- Information
- Error
- Warning

#### ■ Information

The following table gives a summary of system log information messages which may be received from the scanner alert monitoring service.

No action is required.

Code	Message	Action
01001014	Scanner alert monitor started. Scanner alert monitor start date/time = <i>MM/dd/yyyy HH:mm:ss</i>	No action required.
01001015	Scanner alert monitor stopped.	
01001016	Scanner alert monitor stopped by system standby mode.	
01001017	Scanner alert monitor restarted after resume from standby.	

## ■ Error

The following table gives a summary of system log error messages which may be received from the scanner alert monitoring service.

The messages shown here are sent to the e-mail address specified in ["4.7.16 Setting the Destination for Alert Notifications"](#) (page 149).

Code	Message	Action
81000001	CPU power supply error.	Contact your FUJITSU scanner dealer or an authorized FUJITSU scanner service provider.
81000002	1.5V power supply error.	
81000003	3.3V power supply error.	
81000004	5V power supply error.	
81000005	12V power supply error.	
81000006	-12V power supply error.	
81000007	5V Standby power supply error.	
81000008	Battery power supply error.	
81000009	Internal temperature error.	<ul style="list-style-type: none"><li>● Check if the air ventilation inlet is blocked.</li><li>● Contact your FUJITSU scanner dealer or an authorized FUJITSU scanner service provider.</li></ul>
81000010	CPU temperature error.	
81000011	System fan speed error.	Contact your FUJITSU scanner dealer or an authorized FUJITSU scanner service provider.
81000012	CPU fan speed error.	

Code	Message	Action
81002003	Alert notification e-mail could not be sent.	<p>Check the following:</p> <ul style="list-style-type: none"> <li>● Check if the computer connected to the SMTP server is running properly.</li> <li>● Check if an e-mail can be sent to the address from another computer in the network.</li> <li>● By performing a ping test, check if the SMTP server or the network connection to the SMTP server is working properly. If there is no response from the SMTP server ping test, check that the system network is functioning normally by performing an SMTP server ping test from another machine in the network. <ul style="list-style-type: none"> <li>● If the system network is not operating properly, refer to <a href="#">"Failure to connect to a server using its IP address" (page 461)</a> for further solutions.</li> <li>● If only the SMTP server cannot connect to the network, request the network administrator to check that the SMTP server and the network connection to the server are functioning normally.</li> </ul> </li> </ul>
81002004	Device monitoring service error.	Contact your FUJITSU scanner dealer or an authorized FUJITSU scanner service provider.



## ■ Warning

The following table gives a summary of system log warning messages which may be received from the scanner alert monitoring service.

The messages shown here are sent to the e-mail address specified in "[4.7.16 Setting the Destination for Alert Notifications](#)" (page 149).

Code	Message	Action
82000005	Pad assy needs replacement soon.	Obtain a replacement pad assy soon. The pad assy should be replaced after every 50,000 scanned sheets or once a year.
82000006	Pad assy needs replacement now.	Pad assy has passed its rated lifetime (50,000 scanned sheets or once a year) and needs to be replaced.
82000007	Pick roller needs replacement soon.	Obtain a replacement pick roller. The pick roller should be replaced after every 100,000 scanned sheets or once a year.
82000008	Pick roller needs replacement now.	Pick roller has passed its rated lifetime (100,000 scanned sheets or once a year) and needs to be replaced.

E

---

## E.2 Regular User Messages

The following messages may appear during regular user operation.

### E.2.1 Regular User Screen Messages

Screen	Message	Action
Login	Administrator operation in progress, please wait...	Only one administrator or user can login to the scanner at any one time. Please wait until operations are completed.
	Login failed. Check the user name and password, and try again.	Try the following: <ul style="list-style-type: none"><li>● Enter a correct user name and password.</li><li>● Enter a valid user name and password.</li><li>● Contact a system administrator and have them check that the LDAP server is set.</li><li>● Contact a system administrator to have the server status checked.</li><li>● Contact a system administrator to check if the password has expired.</li><li>● Login is not possible if the Active Directory account option is "User must change password at next logon". Contact an administrator to set a password, and then try logging in.</li></ul>



Screen	Message	Action
Login	LDAP authorized user (DN), password and/or search base settings are invalid.	Try the following: <ul style="list-style-type: none"><li>● Enter a correct authorized user (DN) and password.</li><li>● Enter a valid authorized user (DN) and password.</li><li>● Contact an administrator to check that the LDAP server is set.</li><li>● Contact an administrator to check the status of the server.</li><li>● Contact an administrator to check that the password has not expired.</li></ul>
	Scanner initialization has failed. Try turning the power off and back on again. The administrator should contact the FUJITSU scanner dealer or an authorized FUJITSU scanner service provider for help	Try the following: <ul style="list-style-type: none"><li>● Check that the cables are connected to the scanner properly.</li><li>● If the scanner does not restart automatically, press the [Shutdown] button on the "Login" screen to turn the power off, and turn the power back on again to restart the scanner.</li><li>● If the error status persists after the scanner is restarted, press the [Shutdown] button on the "Login" screen, disconnect try turning the power off for 10 seconds, and back on again. If the error status persists, contact your FUJITSU scanner dealer or an authorized FUJITSU scanner service provider.</li></ul>
	Invalid LDAP Search Base format.	Contact a system administrator to have the LDAP search base format corrected. <a href="#">"4.7.8 Setting the Login LDAP Server" (page 100)</a>

Screen	Message	Action
Login	LDAP server is busy.	<p>Try the following:</p> <ul style="list-style-type: none"> <li>● Contact a system administrator to have the network settings checked. <a href="#">"8.3 Network Connection Troubleshooting"</a> (page 456)</li> <li>● Contact a system administrator to have the server status checked.</li> </ul>
	Number of user data stores has reached the maximum allowed. New users may not login until the old user data stores are deleted.	Contact a system administrator to have the user information deleted. <a href="#">"Restoring the User Data Store"</a> (page 169)
	Communicating with the Central Admin Server.	Login is not possible while the scanner is communicating with the Central Admin Server. Wait for the communication session to finish, then try again.
	User roaming data could not be downloaded from the Central Admin Server. OK to continue? (If you continue, the scanner will use the currently saved scan settings.)	Check the connection to the Central Admin Server.
Consumable Alert	Replace Soon	Replace the consumable part when convenient. For details, refer to <a href="#">"7.6 Replacing Parts"</a> (page 436).
	Replace Now	Replace the consumable part when convenient. For details, refer to <a href="#">"7.6 Replacing Parts"</a> (page 436).
Scanning	Document not found. Load a document into the ADF, making sure the side guides are adjusted correctly and try again.	Load the document into the ADF paper chute, and try again. Load the document to prevent any space between the side guides and the edges of the documents. For details, refer to <a href="#">"6.1 Loading Documents"</a> (page 298).

Screen	Message	Action
Scanning	Paper jam has occurred. Remove the documents from the ADF and try again.	Try the following: <ul style="list-style-type: none"> <li>● Remove the documents from the ADF.</li> <li>● Remove the pages which were not scanned correctly.</li> </ul>
	Top cover may be open. Close the top cover, reload the documents and try again.	Close the top cover, reload the documents and try again.
	Feed Error: Document(s) may not match the set paper size, ADF may have grabbed more than one sheet, or documents may not be suitable for scanning. Remove the documents from the ADF, check them and try again. If problem persists, consult the manual.	Press the ADF release button to open the top cover, and remove the documents from the ADF. If more than one sheet has been fed, reset the document and try again. Check that the actual document(s) size matches the paper size specified in the "Paper Size" screen. If not, specify the paper size again. For details, refer to <a href="#">"6.9.3 Paper Size" (page 374)</a> .



Screen	Message	Action
Scanning	Insufficient memory. Try turning the power off and back on again. If problem persists, the administrator should contact the FUJITSU scanner dealer or an authorized FUJITSU scanner service provider for help	<p>Try the following:</p> <ul style="list-style-type: none"> <li>● Reduce the size of the scan data or set a lower resolution level, and try again.</li> <li>● If the scanner does not restart automatically, press the [Shutdown] button on the "Login" screen to turn the power off, and turn the power back on again to restart the scanner.</li> <li>● If the error status persists after the scanner is restarted, press the [Shutdown] button on the "Login" screen, disconnect the AC cable from the scanner to turn the power off, wait for at least 10 seconds, then reconnect the AC cable and try turning the power back on again. If the error status persists, contact your FUJITSU scanner dealer or an authorized FUJITSU scanner service provider.</li> </ul>

Screen	Message	Action
Scanning	<p>An error has occurred. Some pages were skipped. Try again after turning the power off and back on again. If problem persists, the administrator should contact the FUJITSU scanner dealer or an authorized FUJITSU scanner service provider for help.</p> <p>Number of Skipped Pages: <i>XXX</i></p>	<p>Try the following:</p> <ul style="list-style-type: none"> <li>● If the scanner does not restart automatically, press the [Shutdown] button on the "Login" screen to turn the power off, and turn the power back on again to restart the scanner.</li> <li>● If the error status persists after the scanner is restarted, press the [Shutdown] button on the "Login" screen, disconnect the AC cable from the scanner to turn the power off, wait for at least 10 seconds, then reconnect the AC cable and try turning the power back on again. If the error status persists, contact your FUJITSU scanner dealer or an authorized FUJITSU scanner service provider.</li> </ul>
	<p>Scanner hardware failure. The administrator should contact the FUJITSU scanner dealer or an authorized FUJITSU scanner service provider for help.</p>	<p>Try the following:</p> <ul style="list-style-type: none"> <li>● If the scanner does not restart automatically, press the [Shutdown] button on the "Login" screen to turn the power off, and turn the power back on again to restart the scanner.</li> <li>● If the error status persists after the scanner is restarted, press the [Shutdown] button on the "Login" screen, disconnect the AC cable from the scanner to turn the power off, wait for at least 10 seconds, then reconnect the AC cable and try turning the power back on again. If the error status persists, contact your FUJITSU scanner dealer or an authorized FUJITSU scanner service provider.</li> </ul>



Screen	Message	Action
Scanning	When the file format is [MTIFF], the maximum file size for the total scanned data is 2GB. If the size of the scanned data exceeds 2GB, no MTIFF files can be created.	Try the following: <ul style="list-style-type: none"> <li>● Delete scanned pages from Scan Viewer until the total file size of the scanned data is less than 2GB.</li> <li>● Increase the compression level and try scanning again.</li> </ul>
	Scanning with the carrier sheet failed. Make sure the document is fully inserted into the top of the carrier sheet and the folded edge is on the side marked with the thick line, then try again. If the problem persists, the administrator should contact the FUJITSU scanner dealer or an authorized FUJITSU scanner service provider for help.	Make sure the document is fully inserted into the top of the Carrier Sheet and the folded edge is on the side marked with the thick line, then try again. If the problem persists, the administrator should contact the FUJITSU scanner dealer or an authorized FUJITSU scanner service provider for help.
Roller Cleaning	Scanner top cover is closed. Open the cover and try again.	Open the top cover to clean the feed rollers, and try again. For details, refer to <a href="#">"7.2.1 Cleaning the ADF" (page 427)</a> .
	Press the keyboard [C] key to step the feed rollers forward. Press the [OK] button after the feed rollers have been cleaned.	Clean the rollers, and then press the [OK] button.
Shutdown	Shutdown will occur after all jobs finish. Please wait...	Operations cannot be carried out while the scanner is shutting down. The scanner will shutdown automatically. Please wait.
Scan Test	Document not found. Load a document into the ADF, making sure the side guides are adjusted correctly and try again.	Load the document into the ADF paper chute, and try again. Load the document to prevent any space between the side guides and the edges of the documents. For details, refer to <a href="#">"6.1 Loading Documents" (page 298)</a> .



Screen	Message	Action
Scan Test	Feed Error: Document(s) may not match the set paper size, ADF may have grabbed more than one sheet, or documents may not be suitable for scanning. Remove the documents from the ADF, check them and try again. If problem persists, consult the manual.	Press the ADF release button to open the top cover, and remove the documents from the ADF. If more than one sheet has been fed, reset the document and try again. Check that the actual document(s) size matches the paper size specified in the "Paper Size" screen. If not, specify the paper size again. For details, refer to <a href="#">"6.9.3 Paper Size" (page 374)</a> .
	Paper jam has occurred. Remove the documents from the ADF and try again.	Try the following: <ul style="list-style-type: none"> <li>● Remove the documents from the ADF.</li> <li>● Remove the pages which were not scanned correctly.</li> </ul>
	Scanner initialization has failed. Try turning the power off and back on again. The administrator should contact the FUJITSU scanner dealer or an authorized FUJITSU scanner service provider for help.	Try the following: <ul style="list-style-type: none"> <li>● Check that the cables are connected to the scanner properly.</li> <li>● If the scanner does not restart automatically, press the [Shutdown] button on the "Login" screen to turn the power off, and turn the power back on again to restart the scanner.</li> <li>● If the error status persists after the scanner is restarted, press the [Shutdown] button on the "Login" screen, disconnect the AC cable from the scanner to turn the power off, wait for at least 10 seconds, then reconnect the AC cable and try turning the power back on again. If the error status persists, contact your FUJITSU scanner dealer or an authorized FUJITSU scanner service provider.</li> </ul>



Screen	Message	Action
Send e-Mail	Invalid "From" address. Re-enter the address and try again.	Enter a valid e-mail address including "@".
	Invalid "To" address. Re-enter the address and try again.	Enter a valid e-mail address including "@".
	Invalid "Cc" address. Re-enter the address and try again.	Enter a valid e-mail address including "@".
	Invalid "Bcc" address. Re-enter the address and try again.	Enter a valid e-mail address including "@".
	No more than 30 "To" addresses are allowed.	Reduce the number of "To" addresses to 30 or less.
	No more than 30 "Cc" addresses are allowed.	Reduce the number of "Cc" addresses to 30 or less.
	No more than 30 "Bcc" addresses are allowed.	Reduce the number of "Bcc" addresses to 30 or less.
	Current login (LDAP account) has become invalid.	Contact a system administrator to have the login account validated.
e-Mail Address Book	Search has timed out. Contact a system administrator.	Contact a system administrator to check the time of the search timeout. <a href="#">"4.7.8 Setting the Login LDAP Server" (page 100)</a>
	LDAP server is busy.	Try the following: <ul style="list-style-type: none"> <li>● Contact a system administrator to have the network settings checked. <a href="#">"8.3 Network Connection Troubleshooting" (page 456)</a></li> <li>● Contact a system administrator to have the server status checked.</li> </ul>
	Number of matches has reached the maximum allowed. Try refining the search conditions.	Enter more specific search conditions to narrow down the search.

Screen	Message	Action
Send Fax	Invalid fax number. Try again.	Enter a valid fax number. Only numbers 0 to 9, -, *, and # can be used.
	Invalid notification address (Sender's e-Mail Address). Try again.	Enter a valid notification address.
	Current login (LDAP account) has become invalid.	Contact a system administrator to have the login account validated.
Add Fax Number	Invalid fax number. Try again.	Enter a valid fax number. Only numbers 0 to 9, -, *, and # can be used.
Edit Fax Number	Invalid fax number. Try again.	Enter a valid fax number. Only numbers 0 to 9, -, *, and # can be used.
Print	Network is busy. Try again later.	Wait for a while, and try again.
	Cannot find the network printer path.	Try the following: <ul style="list-style-type: none"> <li>● Contact a server administrator.</li> <li>● Check that the spooler is operating properly.</li> </ul>
	Not connected to the network.	Check that the system network is functioning normally by performing a ping test from another machine in the network, other than the server with network printer. If the system network is not operating properly, refer to <a href="#">"Failure to connect to a server using its IP address" (page 461)</a> for further solutions.
	Access to network printer was refused.	Contact a server administrator to find out if an access permit has been set.
	Network path is too long.	Try the following: <ul style="list-style-type: none"> <li>● Set a shorter printer alias.</li> <li>● Contact a system administrator to have the network path shortened.</li> </ul>
	Number of network path connections has reached the maximum allowed. No more may be specified.	Close unneeded network connections, then try specifying the desired network path again.



Screen	Message	Action
Print	Current login (LDAP account) has become invalid.	Contact a system administrator to have the login account validated.
	Specified user is no longer able to login to this network printer.	Try the following: <ul style="list-style-type: none"> <li>● Login with a different account.</li> <li>● Contact a network administrator to have the account validated.</li> </ul>
	Specified password is no longer valid for this network printer.	Try the following: <ul style="list-style-type: none"> <li>● Login with a different account.</li> <li>● Contact a network administrator to have the account validated again.</li> </ul>
	Specified user needs to renew their password for this network printer.	Try the following: <ul style="list-style-type: none"> <li>● Login with a different account.</li> <li>● Contact a network administrator to have the password changed.</li> </ul>
	Access to network printer was refused. The specified account is currently locked out.	Contact a network administrator to have the account unlocked.
	Access to network printer was refused. Login is not possible at this time.	Try the following: <ul style="list-style-type: none"> <li>● Try again when login is possible.</li> <li>● Contact a network administrator to have the time setting changed.</li> </ul>

Screen	Message	Action
Print	Could not connect to the network printer.	Try the following: <ul style="list-style-type: none"> <li>● Check that the LAN cable is connected properly to the scanner and print server.</li> <li>● Contact a network administrator to check that the print server is working properly.</li> <li>● Check that the print server spooler is operating properly.</li> <li>● Contact a network administrator to find out if an access permit has been set.</li> <li>● Contact a system administrator to check that the scanner IP address and network printer settings are correct.</li> </ul> <a href="#">"8.3 Network Connection Troubleshooting" (page 456)</a>
	Error: network printer could not be accessed.	Contact a network administrator to check whether the network printer can be accessed.
	Invalid No. of copies. Enter a value between 1 and 99, and try again.	Enter a valid No. of copies. Only numbers 1 to 99 can be used.
Print Server Authentication	User name is required.	Enter a user name.
	Network is busy. Try again later.	Wait for a while, and try again.
	User name or password may be incorrect.	Re-enter the user name and password.
	Cannot find the network printer path.	Try the following: <ul style="list-style-type: none"> <li>● Contact a server administrator.</li> <li>● Check that the spooler is operating properly.</li> </ul>



Screen	Message	Action
Print Server Authentication	Not connected to the network.	Check that the system network is functioning normally by performing a ping test from another machine in the network, other than the server with network printer. If the system network is not operating properly, refer to <a href="#">"Failure to connect to a server using its IP address" (page 461)</a> for further solutions.
	Access to network printer was refused.	Contact a server administrator to find out if an access permit has been set.
	Number of network path connections has reached the maximum allowed. No more may be specified.	Close unneeded network connections, then try specifying the desired network path again.
	Specified user is no longer able to login to this network printer.	Try the following: <ul style="list-style-type: none"> <li>● Login with a different account.</li> <li>● Contact a network administrator to have the account validated.</li> </ul>
	Specified password is no longer valid for this network printer.	Try the following: <ul style="list-style-type: none"> <li>● Login with a different account.</li> <li>● Contact a network administrator to have the account validated again.</li> </ul>
	Specified user needs to renew their password for this network printer.	Try the following: <ul style="list-style-type: none"> <li>● Login with a different account.</li> <li>● Contact a network administrator to have the password changed.</li> </ul>
	Access to network printer was refused. The specified account is currently locked out.	Contact a network administrator to have the account unlocked.
	Access to network printer was refused. Login is not possible at this time.	Try the following: <ul style="list-style-type: none"> <li>● Try again when login is possible.</li> <li>● Contact a network administrator to have the time setting changed.</li> </ul>

Screen	Message	Action
Print Server Authentication	Could not connect to the network printer.	Try the following: <ul style="list-style-type: none"> <li>● Check that the LAN cable is connected properly to the scanner and print server.</li> <li>● Contact a network administrator to check that the print server is working properly.</li> <li>● Check that the print server spooler is operating properly.</li> <li>● Contact a network administrator to find out if an access permit has been set.</li> <li>● Contact a system administrator to check that the scanner IP address and network printer settings are correct.</li> </ul> <a href="#">"8.3 Network Connection Troubleshooting" (page 456)</a>
	Error: network printer could not be accessed.	Contact a network administrator to check whether the network printer can be accessed.
Save	User name or password may be incorrect.	Try the following: <ul style="list-style-type: none"> <li>● Directly enter a valid user name and password.</li> <li>● Check that the proxy server is operating properly.</li> <li>● Contact an administrator to check that the IP address settings, FTP server network folder, or proxy server settings are correct.</li> </ul> <a href="#">"8.3 Network Connection Troubleshooting" (page 456)</a>
	Cannot find the network folder path.	Contact a server administrator.
	File already exists. Choose a different name or change the overwrite permission setting.	Change the file name, or select [Yes] to overwrite the file with the same name.



Screen	Message	Action
Save	Not connected to the network.	Check that the system network is functioning normally by performing a ping test from another machine in the network, other than the server with network folder. If the system network is not operating properly, refer to <a href="#">"Failure to connect to a server using its IP address" (page 461)</a> for further solutions.
	Access to network folder was refused.	Contact a server administrator to find out if an access permit has been set.
	Network path is too long.	Try the following: <ul style="list-style-type: none"> <li>● Set a shorter file name.</li> <li>● Select a [Save in] folder with a shorter name.</li> <li>● Contact a system administrator to have the folder path name shortened.</li> </ul>
	Insufficient free space in the designated network folder.	Ensure the free space requirements are met, and try again.
	Number of network path connections has reached the maximum allowed. No more may be specified.	Close unneeded network connections, then try specifying the desired network path again.
	The file to be overwritten may be in use elsewhere.	Check that the file to be overwritten is closed, and try again.
	Current login (LDAP account) has become invalid.	Contact a system administrator to have the login account validated.
	Specified user is no longer able to login to this network folder.	Try the following: <ul style="list-style-type: none"> <li>● Login with a different account.</li> <li>● Contact a network administrator to have the account validated.</li> </ul>
	Specified password is no longer valid for this network folder.	Try the following: <ul style="list-style-type: none"> <li>● Login with a different account.</li> <li>● Contact a network administrator to have the password validated again.</li> </ul>





Screen	Message	Action
Save	Specified user needs to renew their password for this network folder.	Try the following: <ul style="list-style-type: none"><li>● Login with a different account.</li><li>● Contact a network administrator to have the password changed.</li></ul>
	Access to network folder was refused. The specified account is currently locked out.	Contact a network administrator to have the account unlocked.
	Access to network folder was refused. Login is not possible at this time.	Try the following: <ul style="list-style-type: none"><li>● Try again when login is possible.</li><li>● Contact a network administrator to have the time setting changed.</li></ul>
	Error: network folder could not be accessed.	Contact a network administrator to check whether the network folder can store data.
	When the file format is [MTIFF], the maximum file size for the total scanned data is 2GB. If the size of the scanned data exceeds 2GB, no MTIFF files can be created.	Try the following: <ul style="list-style-type: none"><li>● Delete scanned pages from Scan Viewer until the total file size of the scanned data is less than 2GB.</li><li>● Increase the compression level and try scanning again.</li></ul>
File Server Authentication	User name or password may be incorrect.	Try the following: <ul style="list-style-type: none"><li>● Directly enter a valid user name and password.</li><li>● Check that the proxy server is operating properly.</li><li>● Contact an administrator to check that the IP address settings, FTP server network folder, or proxy server settings are correct.</li></ul> <a href="#">"8.3 Network Connection Troubleshooting" (page 456)</a>
	Specified user is no longer able to login to this network folder.	Try the following: <ul style="list-style-type: none"><li>● Login with a different account.</li><li>● Contact a network administrator to have the account validated.</li></ul>

Screen	Message	Action
File Server Authentication	Specified password is no longer valid for this network folder.	Try the following: <ul style="list-style-type: none"> <li>● Login with a different account.</li> <li>● Contact a network administrator to have the password validated again.</li> </ul>
	Specified user needs to renew their password for this network folder.	Try the following: <ul style="list-style-type: none"> <li>● Login with a different account.</li> <li>● Contact a network administrator to have the password changed.</li> </ul>
	Access to network folder was refused. The specified account is currently locked out.	Contact a network administrator to have the account unlocked.
	Access to network folder was refused. Login is not possible at this time.	Try the following: <ul style="list-style-type: none"> <li>● Try again when login is possible.</li> <li>● Contact a network administrator to have the time setting changed.</li> </ul>
	Error: network folder could not be accessed.	Contact a network administrator to check whether the network folder can store data.

Screen	Message	Action
Scan to SharePoint	Network path is too long.	Set a folder and file URL path that does not exceed 260 characters.
	Properties of file saved to SharePoint could not be manipulated.	Check the file status and the properties and access permission settings of the specified site, and try again.
	<p>File saved to SharePoint could not be accessed.</p> <p>Check the following, and fix as necessary:</p> <ul style="list-style-type: none"> <li>● Is the SharePoint server running short of free space?</li> </ul> <p>If problem persists, the administrator should contact the FUJITSU scanner dealer or an authorized FUJITSU scanner service provider for help.</p>	<p>Check the following, and fix as necessary:</p> <ul style="list-style-type: none"> <li>● Is the SharePoint server running short of free space?</li> <li>● Is the SharePoint Server working properly?</li> <li>● Contact a server administrator to find out if an access permit has been set.</li> </ul> <p>If the problem persists, the administrator should contact the FUJITSU scanner dealer or an authorized FUJITSU scanner service provider for help.</p>



Screen	Message	Action
Scan to SharePoint	Specified SharePoint folder not found.	Check that the specified folder exists.
	Specified SharePoint library or folder not found.	Check that the specified library or folder exists.
	<p>Specified SharePoint site not found.</p> <p>Check the following, and fix as necessary:</p> <ul style="list-style-type: none"> <li>● Is the specified SharePoint site connectible to?</li> <li>● If the SharePoint Server sign in screen appears, are the specified authentication settings correct?</li> </ul> <p>If problem persists, the administrator should contact the FUJITSU scanner dealer or an authorized FUJITSU scanner service provider for help.</p>	<p>Check the following, and fix as necessary:</p> <ul style="list-style-type: none"> <li>● Is the specified SharePoint site connectible to?</li> <li>● If the SharePoint Server sign in screen appears, are the specified authentication settings correct?</li> <li>● Can scan data be saved in the specified SharePoint folder?</li> </ul> <p>If problem persists, the administrator should contact the FUJITSU scanner dealer or an authorized FUJITSU scanner service provider for help.</p>
	Specified SharePoint site authentication failed.	Check the user name and password to be used for the site sign in. Also, check that the date/time and timezone of the SharePoint server, server for authentication, and the scanner coincide. Then, try again.
<p>Specified SharePoint site cannot be accessed.</p> <p>Check the following, and fix as necessary:</p> <ul style="list-style-type: none"> <li>● Is the specified SharePoint site connectible to?</li> <li>● If the SharePoint Server sign in screen appears, are the specified authentication settings correct?</li> </ul> <p>If problem persists, the administrator should contact the FUJITSU scanner dealer or an authorized FUJITSU scanner service provider for help.</p>	<p>Check the following, and fix as necessary:</p> <ul style="list-style-type: none"> <li>● Is the specified SharePoint site connectible to?</li> <li>● If the SharePoint Server sign in screen appears, are the specified authentication settings correct?</li> </ul> <p>If problem persists, the administrator should contact the FUJITSU scanner dealer or an authorized FUJITSU scanner service provider for help.</p>	

Screen	Message	Action
Scan to SharePoint	Specified SharePoint site access permission refused.	Check the access permission of the site. Check that the date/time and timezone of the SharePoint server, server for authentication, and the scanner coincide.
Startup Scanner	Application could not be started. System restored to last known good state. Contact a system administrator.	System or user settings were restored at system restart. The administrator should check the restored system or user settings.
Scan Viewer	Scan not possible. Number of scan pages exceeds the maximum ( <i>XXX</i> pages).	Finish all operations (sending mail or fax, printing, saving to network folders), and try again.
	All scanned pages are blank. Check the documents. "Blank Page Skip" is set to "Auto", so all scanned pages were cleared.	Turn the "Blank Page Skip" option "Off", and try again. <a href="#">"6.9.15 Blank Page Skip" (page 395)</a>
Job Menu	Notification e-mail could not be sent to the administrator.	Contact an administrator to check if sending e-mail is possible.
	Job Menu could not be displayed. Check the Job Menu settings.	Contact an administrator to check the job settings.
	"Save as:" file name contains invalid characters (:*?"<> ), or is set to a reserved string (CON, PRN, AUX, CLOCK\$, NUL, COM0, ..., COM9, LPT0, ..., LPT9). Re-enter the file name and try again.	The following characters cannot be used. : * ? " < >   CON PRN AUX CLOCK\$ NUL COM0 - COM9 LPT0 - LPT9 Enter a file name using valid characters.
	File name must be specified.	Enter a file name.



Screen	Message	Action
Others	Cannot connect to the LDAP server.	<p>Try the following:</p> <ul style="list-style-type: none"> <li>● The network settings may not be valid. Contact a system administrator to have the network settings checked. <a href="#">"8.3 Network Connection Troubleshooting" (page 456)</a></li> <li>● The server may not be working. Contact a system administrator to have the server status checked.</li> <li>● If using SSL communication when connection to the LDAP server, contact an administrator to check if the server certificate, issued from a root certification authority, is installed on the LDAP server.</li> <li>● Enter a valid user name and password.</li> </ul>
	Cannot connect to the LDAP server. Check that the LDAP access settings are correct and that the LDAP server is running and accessible.	<p>Try the following:</p> <ul style="list-style-type: none"> <li>● The network settings may not be valid. Contact a system administrator to have the network settings checked. <a href="#">"8.3 Network Connection Troubleshooting" (page 456)</a></li> <li>● The server may not be working. Contact a system administrator to have the server status checked.</li> <li>● If using SSL communication when connection to the LDAP server, contact an administrator to check if the server certificate, issued from a root certification authority, is installed on the LDAP server.</li> <li>● Enter a valid user name and password.</li> </ul>

Screen	Message	Action
Others	LDAP server response error.	Try the following: <ul style="list-style-type: none"> <li>● Contact a system administrator to check whether the LDAP server is available.</li> <li>● Enter a valid user name and password.</li> </ul>
	LDAP server access failed. Check that the LDAP access settings and LDAP server settings are correct.	Try the following: <ul style="list-style-type: none"> <li>● Contact a system administrator to check whether the LDAP server is available.</li> <li>● Enter a valid user name and password.</li> </ul>
	LDAP server access failed. Check that the LDAP access, LDAP server, Authorized User (DN), Password and Search Base settings are correct.	Try the following: <ul style="list-style-type: none"> <li>● Contact a system administrator to check whether the LDAP server is available.</li> <li>● Enter a valid user name and password.</li> </ul>
	The system date/time has been reset. Check and correct the "Date/Time" setting.	Check and correct the "Date/Time" setting.
	An error has occurred. Try turning the power off and back on again. The administrator should contact the FUJITSU scanner dealer or an authorized FUJITSU scanner service provider for help. [alphanumeric eight digits]	Try the following: <ul style="list-style-type: none"> <li>● If the scanner does not restart automatically, press the [Shutdown] button on the "Login" screen to turn the power off, and turn the power back on again to restart the scanner.</li> <li>● If the error status persists after the scanner is restarted, press the [Shutdown] button on the "Login" screen, disconnect the AC cable from the scanner to turn the power off, wait for at least 10 seconds, then reconnect the AC cable and try turning the power back on again. If the error status persists, contact your FUJITSU scanner dealer or an authorized FUJITSU scanner service provider.</li> </ul>

Screen	Message	Action
Others	<p>An error has occurred. The system must be restarted. Any buffered jobs will be canceled. If problem persists, the administrator should contact a FUJITSU scanner dealer or an authorized FUJITSU scanner service provider for help.</p> <p>[alphanumeric eight digits]</p>	<p>If the problem persists, the administrator should contact a FUJITSU scanner dealer or an authorized FUJITSU scanner service provider.</p>
	<p>An error has occurred. The system must be restarted. Any buffered jobs will be canceled. After restarting the system, if the same error occurs, it may be due to a scanner failure. In this case, remove any documents that have been fed into the scanner, disconnect and reattach the power cord, and restart the system again. If problem persists, the administrator should contact a FUJITSU scanner dealer or an authorized FUJITSU scanner service provider for help.</p> <p>[alphanumeric eight digits]</p>	<p>If the problem persists, the administrator should contact a FUJITSU scanner dealer or an authorized FUJITSU scanner service provider.</p>
	<p>An error has occurred. Try turning the power off and back on again. If the problem reoccurs after restarting, try disconnecting the scanner power cord, reattaching it, and restarting again. If the problem still persists, the administrator should contact the FUJITSU scanner dealer or an authorized FUJITSU scanner service provider for help.</p> <p>[alphanumeric eight digits]</p>	<p>Turn the scanner power off. After the power turns off, disconnect the AC cable from the scanner. Wait for at least 10 seconds, then reconnect the AC cable and turn the power back on again. If the error status persists, contact your FUJITSU scanner dealer or an authorized FUJITSU scanner service provider.</p>



---


## E.2.2 System Log Messages

System log messages which may appear during user operations can be arranged into the following three categories:

- Information
- Warning
- Error

### ■ Information

Code	Message	Action
01080101	Pick roller cleaned.	No action required.
01091000	Language setting changed to <i>XXXX</i> .	No action required.
010D0001	User name <i>XXXX</i> logged in.	No action required.
010D0002	User name <i>XXXX</i> logged out.	No action required.
01121001	Scanner started up.	No action required.
01121002	Scanner resumed from standby mode.	No action required.
01131001	Scanner will be shutdown.	No action required.
01131002	Scanner entered standby mode.	No action required.
03080001	Scanner firmware has been updated. Scanner firmware version: <i>XXXX</i>	No action required.
05050000	Add-in module loaded successfully.	No action required.

Code	Message	Action
05050001	Add-in module operation started.	<p>No action is required. However, the finish status of the Add-in module will also be displayed later on.</p> <div data-bbox="919 427 1402 607" style="border: 1px solid black; padding: 5px;">  </div> <ol style="list-style-type: none"> <li>1. "1. Operation started" message <ul style="list-style-type: none"> <li>● 05050001</li> </ul> </li> <li>2. "2. Operation finished" message <p>The finish status of the Add-in module is displayed, and one of the following message codes is output.</p> <ul style="list-style-type: none"> <li>● 05050002</li> <li>● 05050003</li> <li>● 05050004</li> <li>● 15050002</li> </ul> </li> </ol> <p>After the "1. Operation started" message is displayed, if the "2. Operation finished" message is not displayed, control is not returned from the Add-in module to the scanner. Contact an Add-in module administrator.</p>
05050002	Add-in module operation finished successfully.	No action required.
05050003	Add-in module operation was canceled.	No action required.
05050004	Add-in module operation finished automatically.	No action required.
05050005	Add-in module passed self-authentication.	No action required.
05050006	Add-in module failed self-authentication.	No action required.
010902001	System time was synchronized using the backup NTP server.	No action required.
010902002	New system time has been acquired from the file server.	No action required.

Code	Message	Action
010902003	New system time has been acquired from the Central Admin server.	No action required.

## ■ Warning

Code	Message	Action
110C0010	Password contains invalid characters. Re-enter the password, and try again.	Enter a password and try again.
15050001	Add-in module could not be loaded.	Contact a system administrator.
15050002	Add-in module operation error.	Contact a system administrator.
83070001	Pad assy needs replacing. Contact a system administrator.	To have the pad assy replaced, contact a system administrator. The system administrator should open the top cover and replace the pad assy. <a href="#">"7.6.3 Replacing the Pad Assy" (page 439)</a>
83070002	Pick roller needs replacing. Contact a system administrator.	To have the pick roller replaced, contact a system administrator. The system administrator should open the top cover and replace the pick roller. <a href="#">"7.6.4 Replacing the Pick Roller" (page 440)</a>

## ■ Error

Code	Message	Action
100B0001	Network is busy. Try again later.	Wait for a while, and try again.
11030003	Cannot find the network printer path.	Try the following: <ul style="list-style-type: none"> <li>● Contact a network administrator to check server status.</li> <li>● Check that the spooler is operating properly.</li> </ul>
11040003	Cannot find the network folder path.	Contact a network administrator to check server status.

Code	Message	Action
11040005	Insufficient free space in the designated network folder.	Ensure the free space requirements are met, and try again.
11080001	Number of user data stores has reached the maximum allowed. New users may not login until the old user data stores are deleted.	To have the user data store cleared, contact a system administrator. Clearing the user data store is not an undoable action. <a href="#">"Clearing the User Data Store" (page 170)</a>
11090001	Application could not be started. System restored to last known good state. Contact a system administrator.	System or user settings were restored at system restart. Contact a system administrator. The administrator should check the restored system or user settings.
110B0001	Search has timed out. Contact a system administrator.	Contact a system administrator to check the time of the search timeout. <a href="#">"4.7.8 Setting the Login LDAP Server" (page 100)</a>
110B0002	Not connected to the network.	Check that the system network is functioning normally by performing a ping test from another machine in the network, other than from a machine in the same server as network printer. If the system network is not operating properly, refer to <a href="#">"Failure to connect to a server using its IP address" (page 461)</a> for further solutions.
110B0004	LDAP server is busy.	Try the following: <ul style="list-style-type: none"> <li>● Contact a system administrator to have the network settings checked. <a href="#">"8.3 Network Connection Troubleshooting" (page 456)</a></li> <li>● Contact a system administrator to have the server status checked.</li> </ul>
110B0100	LDAP server response error.	Try the following: <ul style="list-style-type: none"> <li>● Contact a system administrator to check whether the LDAP server is available.</li> <li>● Enter a valid user name and password.</li> </ul>
110B0101	LDAP server access failed. Check that the LDAP access settings and LDAP server settings are correct.	Try the following: <ul style="list-style-type: none"> <li>● Contact a system administrator to check whether the LDAP server is available.</li> <li>● Enter a valid user name and password.</li> </ul>

Code	Message	Action
110B0102	LDAP server access failed. Check that the LDAP access, LDAP server, Authorized User (DN), Password and Search Base settings are correct.	Try the following: <ul style="list-style-type: none"> <li>● Contact a system administrator to check whether the LDAP server is available.</li> <li>● Enter a valid user name and password.</li> </ul>
110D0001	Login failed. Check the user name and password, and try again.	Try the following: <ul style="list-style-type: none"> <li>● Enter a user name and password.</li> <li>● Enter a valid user name and password.</li> <li>● Contact a system administrator and have them check that the LDAP server is set.</li> <li>● Contact a system administrator to have the server status checked.</li> <li>● Contact a system administrator to check if the password has expired.</li> <li>● Login is not possible if the Active Directory account option is "User must change password at next logon". Contact an administrator to set a password, and then try logging in.</li> </ul>
110D000E	LDAP authorized user (DN), password and/or search base settings are invalid.	Try the following: <ul style="list-style-type: none"> <li>● Enter a correct authorized user (DN) and password.</li> <li>● Enter a valid authorized user (DN) and password.</li> <li>● Contact a system administrator and have them check that the LDAP server is set.</li> <li>● Contact a system administrator to have the server status checked.</li> <li>● Contact a system administrator to check if the password has expired.</li> </ul>



Code	Message	Action
110D0002	Cannot connect to the LDAP server.	<p>Try the following:</p> <ul style="list-style-type: none"> <li>● The network settings may not be valid. Contact a system administrator to have the network settings checked. <a href="#">"8.3 Network Connection Troubleshooting" (page 456)</a></li> <li>● The server may not be working. Contact a system administrator to have the server status checked.</li> <li>● If using SSL communication when connecting to the LDAP server, contact an administrator to check if the server certificate, issued from a root certification authority, is installed on the LDAP server.</li> <li>● Enter a valid user name and password.</li> </ul>
110D000F	Cannot connect to the LDAP server. Check that the LDAP access settings are correct and that the LDAP server is running and accessible.	<p>Try the following:</p> <ul style="list-style-type: none"> <li>● The network settings may not be valid. Contact a system administrator to have the network settings checked. <a href="#">"8.3 Network Connection Troubleshooting" (page 456)</a></li> <li>● The server may not be working. Contact a system administrator to have the server status checked.</li> <li>● If using SSL communication when connecting to the LDAP server, contact an administrator to check if the server certificate, issued from a root certification authority, is installed on the LDAP server.</li> <li>● Enter a valid user name and password.</li> </ul>
110D0004	Access to network folder was refused.	Contact a server administrator to find out if an access permit has been set.
110D0005	Number of network path connections has reached the maximum allowed. No more may be specified.	Close unneeded network connections, then try specifying the desired network path again.
110D0006	Invalid LDAP Search Base format.	Contact a system administrator to have the LDAP search base format corrected. <a href="#">"4.7.8 Setting the Login LDAP Server" (page 100)</a>

Code	Message	Action
110D0007	Current login (LDAP account) has become invalid.	Contact a system administrator to have the login account validated.
110D0008	The file to be overwritten may be in use elsewhere.	Check that the file to be overwritten is closed, and try again.
110D0009	Specified password is no longer valid for this network folder.	Try the following: <ul style="list-style-type: none"> <li>● Login with a different account.</li> <li>● Contact a network administrator to have the password validated again.</li> </ul>
110D000A	Specified user needs to renew their password for this network folder.	Try the following: <ul style="list-style-type: none"> <li>● Login with a different account.</li> <li>● Contact a network administrator to have the password changed.</li> </ul>
110D000B	Specified user is no longer able to login to this network folder.	Try the following: <ul style="list-style-type: none"> <li>● Login a with different account.</li> <li>● Contact a network administrator to have the account validated.</li> </ul>
110D000C	Access to network folder was refused. The specified account is currently locked out.	Contact a network administrator to have the account unlocked.
110D000D	Access to network folder was refused. Login is not possible at this time.	Try the following: <ul style="list-style-type: none"> <li>● Try again when login is possible.</li> <li>● Contact a network administrator to have the time setting changed.</li> </ul>
110D0044	Access to network printer was refused.	Contact a server administrator to find out if an access permit has been set.
110D0049	Specified password is no longer valid for this network printer.	Try the following: <ul style="list-style-type: none"> <li>● Login a with different account.</li> <li>● Contact a network administrator to have the account validated again.</li> </ul>
110D004A	Specified user needs to renew their password for this network printer.	Try the following: <ul style="list-style-type: none"> <li>● Login a with different account.</li> <li>● Contact a network administrator to have the password changed.</li> </ul>
110D004B	Specified user is no longer able to login to this network printer.	Try the following: <ul style="list-style-type: none"> <li>● Login a with different account.</li> <li>● Contact a network administrator to have the account validated.</li> </ul>

Code	Message	Action
110D004C	Access to network printer was refused. The specified account is currently locked out.	Contact a network administrator to have the account unlocked.
110D004D	Access to network printer was refused. Login is not possible at this time.	Try the following: <ul style="list-style-type: none"> <li>● Try again when login is possible.</li> <li>● Contact a network administrator to have the time setting changed.</li> </ul>
110D004E	Could not connect to the network printer.	Try the following: <ul style="list-style-type: none"> <li>● Check that the LAN cable is connected properly to the scanner and print server.</li> <li>● Contact a network administrator to check that the print server is working properly.</li> <li>● Check that the print server spooler is operating properly.</li> <li>● Contact a network administrator to find out if an access permit has been set.</li> <li>● Contact a system administrator to check that the scanner IP address and network printer settings are correct.</li> </ul> <a href="#">"8.3 Network Connection Troubleshooting" (page 456)</a>
110D0100	Error: network folder could not be accessed.	Contact a network administrator to check whether the network folder can store data.
110D0140	Error: network printer could not be accessed.	Contact a network administrator to check whether the network printer can be accessed.
110E0001	Notification e-mail could not be sent to the administrator.	Contact an administrator to check if sending e-mail is possible.
11150001	Corrupted system log file was deleted.	System log file was deleted because the scanner was turned off during operations. No action required.
11150002	Corrupted user log file was deleted.	User log file was deleted because the scanner was turned off during operations. No action required.



Code	Message	Action
12010001	Scanned data size exceeded maximum size allowed for e-mail attachments.	<p>Try the following:</p> <ul style="list-style-type: none"> <li>● Reduce the number of pages to be scanned and send the e-mail in separate parts.</li> <li>● Select a higher compression level and try again.</li> </ul> <p><a href="#">"6.9.9 Compression" (page 387)</a></p> <p>If the problem persists, contact a system administrator to check the "Maximum Attachment Size" setting.</p> <p><a href="#">"4.7.11 Setting the e-Mail Server (SMTP Server)" (page 116)</a></p>
12010002	Could not connect to server when sending e-mail.	<p>Try the following:</p> <ul style="list-style-type: none"> <li>● Check that the LAN cable of the scanner and SMTP server is connected properly.</li> <li>● Contact a system administrator to check that the scanner IP address and SMTP server settings are correct.</li> </ul> <p><a href="#">"8.3 Network Connection Troubleshooting" (page 456)</a></p> <ul style="list-style-type: none"> <li>● Contact a system administrator to check that the SMTP server is working properly.</li> </ul>
12010005	e-Mail size exceeded maximum e-mail size allowed by the SMTP server.	Contact a system administrator to check the maximum e-mail size allowed by the SMTP server.
12010006	SMTP server connection was lost while sending e-mail.	<p>Try the following:</p> <ul style="list-style-type: none"> <li>● Check that the LAN cable of the scanner and SMTP server is connected properly.</li> <li>● Contact a system administrator to check that the scanner IP address and SMTP server settings are correct.</li> </ul> <p><a href="#">"8.3 Network Connection Troubleshooting" (page 456)</a></p> <ul style="list-style-type: none"> <li>● Contact a system administrator to check that the SMTP server is working properly.</li> <li>● Contact a system administrator to check the maximum e-mail size allowed by the SMTP server.</li> </ul>

Code	Message	Action
12010100	Error: e-mail could not be sent.	<p>Try the following:</p> <ul style="list-style-type: none"> <li>● A message returned from the server is attached after the message displayed on the left. Contact a server administrator to deal with the error.</li> <li>● If the [e-Mail address of user] option button is selected for [To] and/or [From], an error will occur during the job process in the following cases: <ul style="list-style-type: none"> <li>● If the currently logged in user does not have an e-mail address</li> <li>● If the currently logged in user is using the guest account</li> </ul> </li> </ul> <p>In this case, specify a user with a registered e-mail address and perform the job sequence.</p>
12020001	Scanned data size exceeded maximum size allowed for sending by fax.	<p>Try the following:</p> <ul style="list-style-type: none"> <li>● Reduce the number of pages to be scanned and send the fax in separate parts.</li> <li>● Select a higher compression level, and try again.</li> </ul> <p><a href="#">"6.9.9 Compression" (page 387)</a></p> <p>If the problem persists, contact a system administrator to check the "Maximum Attachment Size" setting.</p> <p><a href="#">"4.7.11 Setting the e-Mail Server (SMTP Server)" (page 116)</a></p>
12020002	Could not connect to server when sending fax.	<p>Try the following:</p> <ul style="list-style-type: none"> <li>● Check that the LAN cable of the scanner and SMTP server is connected properly.</li> <li>● Contact a system administrator to check that the scanner IP address, SMTP server and fax server settings are correct.</li> </ul> <p><a href="#">"8.3 Network Connection Troubleshooting" (page 456)</a></p> <ul style="list-style-type: none"> <li>● Contact a system administrator to check that the SMTP and fax servers are working properly.</li> </ul>

Code	Message	Action
12020005	Fax size exceeded maximum fax size allowed by the SMTP server.	Contact a system administrator to check the "Maximum Attachment Size" setting. <a href="#">"4.7.11 Setting the e-Mail Server (SMTP Server)" (page 116)</a>
12020006	SMTP server connection was lost while sending fax data.	<p>Try the following:</p> <ul style="list-style-type: none"> <li>● Check that the LAN cable of the scanner and SMTP server is connected properly.</li> <li>● Contact a system administrator to check that the scanner IP address and SMTP server settings are correct. <a href="#">"8.3 Network Connection Troubleshooting" (page 456)</a></li> <li>● Contact a system administrator to check that the SMTP server is working properly.</li> <li>● Contact a system administrator to check the maximum e-mail size allowed by the SMTP server.</li> </ul>
12020100	Error: fax could not be sent.	<p>Try the following:</p> <ul style="list-style-type: none"> <li>● A message returned from the server is attached. Contact a server administrator to deal with the error.</li> <li>● If the [e-Mail address of user] option button is selected for "Notification To (Sender's e-Mail Address)", an error will occur when a job sequence is performed in the following cases: <ul style="list-style-type: none"> <li>● If the currently logged in user does not have an e-mail address</li> <li>● If logged in with the guest account</li> </ul> </li> </ul> <p>In this case, specify a user with a registered e-mail address and perform the job sequence.</p>



Code	Message	Action
12030001	Cannot find the network printer path.	Try the following: <ul style="list-style-type: none"> <li>● Check that the LAN cable of the scanner and print server is connected properly.</li> <li>● Contact a network administrator to check that the print server is working properly.</li> <li>● Check that the spooler is operating properly.</li> <li>● Contact a system administrator to check that the scanner IP address and network printer settings are correct.</li> </ul> <a href="#">"8.3 Network Connection Troubleshooting" (page 456)</a>
12030002	Access to network printer was refused.	Contact a server administrator to find out if an access permit has been set.
12030005	Network is busy. Try again later.	Wait for a while, and try again.
12030006	User name or password may be incorrect.	Re-enter the user name and password.
12030007	Not connected to the network.	Check that the system network is functioning normally by performing a ping test from another machine in the network, other than from a machine in the same server as network printer. If the system network is not operating correctly, refer to <a href="#">"Failure to connect to a server using its IP address" (page 461)</a> for further solutions.
1203000A	Number of network path connections has reached the maximum allowed. No more may be specified.	Close unneeded network connections, then try specifying the desired network path again.
1203000C	Specified user is no longer able to login to this network printer.	Try the following: <ul style="list-style-type: none"> <li>● Login a with different account.</li> <li>● Contact a network administrator to have the account validated.</li> </ul>
1203000D	Specified password is no longer valid for this network printer.	Try the following: <ul style="list-style-type: none"> <li>● Login a with different account.</li> <li>● Contact a network administrator to have the password validated again.</li> </ul>



Code	Message	Action
1203000E	Specified user needs to renew their password for this network printer.	Try the following: <ul style="list-style-type: none"><li>● Login a with different account.</li><li>● Contact a network administrator to have the password changed.</li></ul>
1203000F	Access to network printer was refused. The specified account is currently locked out.	Contact a network administrator to have the account unlocked.
12030010	Access to network printer was refused. Login is not possible at this time.	Try the following: <ul style="list-style-type: none"><li>● Try again when login is possible.</li><li>● Contact a network administrator to have the time setting changed.</li></ul>
12030011	Could not connect to the network printer.	Try the following: <ul style="list-style-type: none"><li>● Check that the LAN cable is connected properly to the scanner and print server.</li><li>● Contact a network administrator to check that the print server is working properly.</li><li>● Check that the print server spooler is operating properly.</li><li>● Contact a network administrator to find out if an access permit has been set.</li><li>● Contact a system administrator to check that the scanner IP address and network printer settings are correct.</li></ul> <a href="#">"8.3 Network Connection Troubleshooting" (page 456)</a>
12030100	Error: could not print.	Try the following: <ul style="list-style-type: none"><li>● Check that the LAN cable of the scanner and file server is connected properly.</li><li>● Contact a system administrator to check that the scanner IP address and registered network printer path settings are correct.</li><li>● Check the network printer authority privileges.</li></ul>

Code	Message	Action
12040001	Cannot find the network folder path.	<p>Try the following:</p> <ul style="list-style-type: none"> <li>● Check that the LAN cable of the scanner and file server is connected properly.</li> <li>● Check that the file server is working properly.</li> <li>● Contact a system administrator to check that the scanner IP address and network folder settings are correct.</li> </ul> <p><a href="#">"8.3 Network Connection Troubleshooting" (page 456)</a></p> <ul style="list-style-type: none"> <li>● When creating a folder, if the name of the folder to be created is already used by a file in the target network folder for saving, it cannot be created. Change the name of the file, or change the file name settings.</li> </ul> <p>For saving to the FTP server network folder, try the following:</p> <ul style="list-style-type: none"> <li>● Contact a system administrator to check whether or not read or write access to the FTP server network folder is permitted for the currently logged in user or authenticated user.</li> <li>● Check if the file attribute has been set as hidden.</li> <li>● Check that the target file to be overwritten is not used, and try again.</li> </ul>
12040002	Access to network folder was refused.	<p>Try the following:</p> <ul style="list-style-type: none"> <li>● Contact a system administrator to check whether or not access to the network folder is permitted for the currently logged in user or authenticated user.</li> <li>● Check if the file attribute has been set as hidden.</li> </ul>
12040003	File already existed, so data could not be saved.	To overwrite the existing file, on the "Save" screen, set "Overwrite old files?" as "Yes", and try again.
12040005	Network is busy. Try again later.	Try again later.



Code	Message	Action
12040006	User name or password may be incorrect.	Try the following: <ul style="list-style-type: none"><li>● Re-enter the user name and password.</li><li>● Check that the proxy server is operating properly.</li><li>● Contact an administrator to check that the IP address settings, FTP server network folder, or proxy server settings are correct.</li></ul> <a href="#">"8.3 Network Connection Troubleshooting" (page 456)</a>
12040007	Not connected to the network.	Check that the system network is functioning normally by performing a ping test from another machine in the network, other than the server with network folder. If the system network is not operating correctly, refer to <a href="#">"Failure to connect to a server using its IP address" (page 461)</a> for further solutions.
12040009	Insufficient free space in the designated network folder.	Ensure the free space requirements are met, and try again.
1204000A	Number of network path connections has reached the maximum allowed. No more may be specified.	Close unneeded network connections, then try specifying the desired network path again.
1204000B	File targeted for overwriting may already be in use.	Check that the file to be overwritten is closed, and try again.
1204000C	Specified user is no longer able to login to this network folder.	Try the following: <ul style="list-style-type: none"><li>● Login with a different account.</li><li>● Contact a network administrator to have the account validated.</li></ul>
1204000D	Specified password is no longer valid for this network folder.	Try the following: <ul style="list-style-type: none"><li>● Login with a different account.</li><li>● Contact a network administrator to have the password validated again.</li></ul>
1204000E	Specified user needs to renew their password for this network folder.	Try the following: <ul style="list-style-type: none"><li>● Login with a different account.</li><li>● Contact a network administrator to have the password changed.</li></ul>

Code	Message	Action
12040100	Error: network folder access was refused.	<p>Try the following:</p> <ul style="list-style-type: none"> <li>● Contact a network administrator to check whether the network folder is ready for use.</li> <li>● For the MTIFF format, the file size for the scanned data may not exceed 2GB. Try adjusting the scan parameters to decrease the size of the file.</li> <li>● Check that the file name format and number of characters of the file name are allowed for the file server.</li> </ul> <p>For saving to the FTP server network folder, try the following:</p> <ul style="list-style-type: none"> <li>● Check that the LAN cable is connected properly to the scanner and FTP server.</li> <li>● Contact a network administrator to check that the FTP server is working properly.</li> <li>● Contact a system administrator to check that the scanner IP address setting and FTP server network folder path are correct.</li> </ul> <p><a href="#">"8.3 Network Connection Troubleshooting" (page 456)</a></p> <ul style="list-style-type: none"> <li>● Ensure the free space requirements are met, and try again.</li> <li>● Close unneeded network connections, and try specifying the network path again.</li> </ul>
1204000F	Access to network folder was refused. The specified account is currently locked out.	Contact a network administrator to have the account unlocked.
12040010	Access to network folder was refused. Login is not possible at this time.	<p>Try the following:</p> <ul style="list-style-type: none"> <li>● Try again when login is possible.</li> <li>● Contact a network administrator to have the time setting changed.</li> </ul>



Code	Message	Action
12040011	"Save as:" file name contains invalid characters (:*?"<> ), or is set to a reserved string (CON, PRN, AUX, CLOCK\$, NUL, COM0, ..., COM9, LPT0, ..., LPT9). Re-enter the file name and try again.	The following characters and reserved strings cannot be used. : * ? " < >   CON PRN AUX CLOCK\$ NUL COM0 ... COM9 LPT0 ... LPT9 Re-enter the file name using only valid characters.
12050001	Properties of file saved to SharePoint could not be manipulated.	Check the file status and the properties and access permission settings of the specified site, and try again.
12050002	File saved to SharePoint could not be accessed.  Check the following, and fix as necessary: <ul style="list-style-type: none"> <li>● Is the SharePoint server running short of free space?</li> </ul> If problem persists, the administrator should contact the FUJITSU scanner dealer or an authorized FUJITSU scanner service provider for help.	Check the following, and fix as necessary: <ul style="list-style-type: none"> <li>● Is the SharePoint server running short of free space?</li> <li>● Is the SharePoint Server working properly?</li> <li>● Contact a server administrator to find out if an access permit has been set.</li> </ul> If problem persists, the administrator should contact the FUJITSU scanner dealer or an authorized FUJITSU scanner service provider for help.
12050003	File saved to SharePoint could not be overwritten.	Check the write access of the specified site and the file status, and try again.
12050004	SharePoint sub-folder could not be created.	Check the write access of the specified site and the file status, and try again.
12050005	File size exceeds the SharePoint folder's file size limit.	Check the permitted file size, and try again.
12050006	Specified SharePoint folder not found.	Check that the specified folder exists.
12050007	Specified SharePoint library or folder not found.	Check that the specified library or folder exists.



Code	Message	Action
12050008	<p>Specified SharePoint site not found.</p> <p>Check the following, and fix as necessary:</p> <ul style="list-style-type: none"> <li>● Is the specified SharePoint site connectible to?</li> <li>● If the SharePoint Server sign in screen appears, are the specified authentication settings correct?</li> </ul> <p>If problem persists, the administrator should contact the FUJITSU scanner dealer or an authorized FUJITSU scanner service provider for help.</p>	<p>Check the following, and fix as necessary:</p> <ul style="list-style-type: none"> <li>● Is the specified SharePoint site connectible to?</li> <li>● If the SharePoint Server sign in screen appears, are the specified authentication settings correct?</li> <li>● Can scan data be saved in the specified SharePoint folder?</li> </ul> <p>If problem persists, the administrator should contact the FUJITSU scanner dealer or an authorized FUJITSU scanner service provider for help.</p>
1205000A	Specified SharePoint file is already in use.	Check whether the specified file is being used, and try again.
1205000B	Specified SharePoint site authentication failed.	Check the user name and password to be used for the site sign in, and try again.
1205000C	<p>Specified SharePoint site cannot be accessed.</p> <p>Check the following, and fix as necessary:</p> <ul style="list-style-type: none"> <li>● Is the specified SharePoint site connectible to?</li> <li>● If the SharePoint Server sign in screen appears, are the specified authentication settings correct?</li> </ul> <p>If problem persists, the administrator should contact the FUJITSU scanner dealer or an authorized FUJITSU scanner service provider for help.</p>	<p>Check the following, and fix as necessary:</p> <ul style="list-style-type: none"> <li>● Is the specified SharePoint site connectible to?</li> <li>● If the SharePoint Server sign in screen appears, are the specified authentication settings correct?</li> </ul> <p>If problem persists, the administrator should contact the FUJITSU scanner dealer or an authorized FUJITSU scanner service provider for help.</p>
1205000D	Specified SharePoint site access permission refused.	Check the access permission of the site.

Code	Message	Action
12050015	<p>Scan to SharePoint file transfer error has occurred.</p> <p>Check the following, and fix as necessary:</p> <ul style="list-style-type: none"> <li>● Is the specified SharePoint site connectible to?</li> <li>● If the SharePoint Server sign in screen appears, are the specified authentication settings correct?</li> </ul> <p>If problem persists, the administrator should contact the FUJITSU scanner dealer or an authorized FUJITSU scanner service provider for help.</p>	<p>Check the following, and fix as necessary:</p> <ul style="list-style-type: none"> <li>● Is the specified SharePoint site connectible to?</li> <li>● If the SharePoint Server sign in screen appears, are the specified authentication settings correct?</li> <li>● Can scan data be saved in the specified SharePoint folder?</li> </ul> <p>If problem persists, the administrator should contact the FUJITSU scanner dealer or an authorized FUJITSU scanner service provider for help.</p>
12050016	File already exists. Choose a different name or change the overwrite permission setting.	Change the file name, or select [Yes] to overwrite the file with the same name.
12050018	Specified file type is not permitted for the selected SharePoint site.	Specify a file type that is permitted for the selected SharePoint site, and try again.
12050100	SharePoint access error occurred.	Try again. If the problem persists, contact your FUJITSU scanner dealer or an authorized FUJITSU scanner service provider.
12130001	Error: Scan&Buffer process could not output data for the scheduled jobs.	Try again.



Code	Message	Action
13060001	Scanner initialization has failed. Try turning the power off and back on again. The administrator should contact the FUJITSU scanner dealer or an authorized FUJITSU scanner service provider for help	Try the following: <ul style="list-style-type: none"> <li>● Check that the cables are connected to the scanner properly.</li> <li>● If the scanner does not restart automatically, press the [Shutdown] button on the "Login" screen to turn the power off, and turn the power back on again to restart the scanner.</li> <li>● If the error status persists after the scanner is restarted, press the [Shutdown] button on the "Login" screen, disconnect the AC cable and try turning the power back on again. If the error status persists, contact your FUJITSU scanner dealer or an authorized FUJITSU scanner service provider.</li> </ul>
1306001A		
1306001D		
1306002C	Insufficient memory. Try turning the power off and back on again. If problem persists, the administrator should contact the FUJITSU scanner dealer or an authorized FUJITSU scanner service provider for help.	System might be unstable. Shutdown and press the startup button to restart the scanner. If the error status persists, contact your FUJITSU scanner dealer or an authorized FUJITSU scanner service provider.
1314002C	Insufficient memory. Try turning the power off and back on again. If problem persists, the administrator should contact the FUJITSU scanner dealer or an authorized FUJITSU scanner service provider for help.	Reduce the size of the scan data or set a lower resolution level, and try again.
13061001	Scan error occurred.	Shutdown and press the startup button to restart the scanner. If the error status persists, contact your FUJITSU scanner dealer or an authorized FUJITSU scanner service provider.
13061002	File name: XXXX	
13061003	Error code: XXXX	

Code	Message	Action
13080001	Scanner firmware update failed. The administrator should contact the FUJITSU scanner dealer or an authorized FUJITSU scanner service provider for help. Scanner firmware version: XXXX	Contact your FUJITSU scanner dealer or an authorized FUJITSU scanner service provider.
83070006	Scanner hardware failure. The administrator should contact the FUJITSU scanner dealer or an authorized FUJITSU scanner service provider for help.	Shutdown and press the startup button to restart the scanner.
83070007		If the problem persists, contact your FUJITSU scanner dealer or an authorized FUJITSU scanner service provider.
83070008		
8307000C		
84000001	An error has occurred. Try turning the power off and back on again. If problem persists, the administrator should contact the FUJITSU scanner dealer or an authorized FUJITSU scanner service provider for help. [alphanumeric eight digits]	<p>Try the following:</p> <ul style="list-style-type: none"> <li>● If the scanner does not restart automatically, press the [Shutdown] button on the "Login" screen to turn the power off, and turn the power back on again to restart the scanner.</li> <li>● If the error status persists after the scanner is restarted, press the [Shutdown] button on the "Login" screen, disconnect the AC cable from the scanner to turn the power off, wait for at least 10 seconds, then reconnect the AC cable and try turning the power back on again. If the error status persists, contact your FUJITSU scanner dealer or an authorized FUJITSU scanner service provider.</li> </ul>
84000002	An error has occurred. The system must be restarted. Any buffered jobs will be canceled. If problem persists, the administrator should contact a FUJITSU scanner dealer or an authorized FUJITSU scanner service provider for help. [alphanumeric eight digits]	If the problem persists, the administrator should contact a FUJITSU scanner dealer or an authorized FUJITSU scanner service provider.



Code	Message	Action
84000003	<p>An error has occurred. The system must be restarted. Any buffered jobs will be canceled. After restarting the system, if the same error occurs, it may be due to a scanner failure. In this case, remove any documents that have been fed into the scanner, disconnect and reattach the power cord, and restart the system again. If problem persists, the administrator should contact a FUJITSU scanner dealer or an authorized FUJITSU scanner service provider for help.</p> <p>[alphanumeric eight digits]</p>	<p>If the problem persists, the administrator should contact a FUJITSU scanner dealer or an authorized FUJITSU scanner service provider.</p>
84000004	<p>An error has occurred. Try turning the power off and back on again. If the problem reoccurs after restarting, try disconnecting the scanner power cord, reattaching it, and restarting again. If the problem still persists, the administrator should contact the FUJITSU scanner dealer or an authorized FUJITSU scanner service provider for help.</p> <p>[alphanumeric eight digits]</p>	<p>Turn the scanner power off. After the power turns off, disconnect the AC cable from the scanner. Wait for at least 10 seconds, then reconnect the AC cable and turn the power back on again. If the problem persists, contact your FUJITSU scanner dealer or an authorized FUJITSU scanner service provider.</p>

## E.2.3 User Log

Code	Message	Action
00000000	-----	No action required.
12010001	Scanned data size exceeded maximum size allowed for e-mail attachments.	<p>Try the following:</p> <ul style="list-style-type: none"> <li>● Reduce the number of pages to be scanned and send the e-mail in separate parts.</li> <li>● Select a higher compression level and try again.</li> </ul> <p><a href="#">"6.9.9 Compression" (page 387)</a></p> <p>If the problem persists, contact a system administrator to check the "Maximum Attachment Size" setting.</p> <p><a href="#">"4.7.11 Setting the e-Mail Server (SMTP Server)" (page 116)</a></p>
12010002	Could not connect to server when sending e-mail.	<p>Try the following:</p> <ul style="list-style-type: none"> <li>● Check that the LAN cable of the scanner and SMTP server is connected properly.</li> <li>● Contact a system administrator to check that the scanner IP address and SMTP server settings are correct.</li> </ul> <p><a href="#">"8.3 Network Connection Troubleshooting" (page 456)</a></p> <ul style="list-style-type: none"> <li>● Contact a system administrator to check that the SMTP server is working properly.</li> </ul>
12010005	e-Mail size exceeded maximum e-mail size allowed by the SMTP server.	Contact a system administrator to check the maximum e-mail size allowed by the SMTP server.

Code	Message	Action
12010006	SMTP server connection was lost while sending e-mail.	<p>Try the following:</p> <ul style="list-style-type: none"> <li>● Check that the LAN cable of the scanner and SMTP server is connected properly.</li> <li>● Contact a system administrator to check that the scanner IP address and SMTP server settings are correct. <a href="#">"8.3 Network Connection Troubleshooting" (page 456)</a></li> <li>● Contact a system administrator to check that the SMTP server is working properly.</li> <li>● Contact a system administrator to check the maximum e-mail size allowed by the SMTP server.</li> </ul>
12010100	Error: e-mail could not be sent.	<p>Try the following:</p> <ul style="list-style-type: none"> <li>● A message returned from the server is attached after the message displayed on the left. Contact a server administrator to deal with the error.</li> <li>● If the [e-Mail address of user] option button is selected for [To] and/or [From], an error will occur during the job process in the following cases: <ul style="list-style-type: none"> <li>● If the currently logged in user does not have an e-mail address</li> <li>● If the currently logged in user is using the guest account</li> </ul> </li> </ul> <p>In this case, specify a user with a registered e-mail address and perform the job sequence.</p>
12020001	Scanned data size exceeded maximum size allowed for sending by fax.	<p>Try the following:</p> <ul style="list-style-type: none"> <li>● Reduce the number of pages to be scanned and send the fax in separate parts.</li> <li>● Select a higher compression level, and try again. <a href="#">"6.9.9 Compression" (page 387)</a></li> </ul> <p>If the problem persists, contact a system administrator to check the "Maximum Attachment Size" setting. <a href="#">"4.7.11 Setting the e-Mail Server (SMTP Server)" (page 116)</a></p>



Code	Message	Action
12020002	Could not connect to server when sending fax.	<p>Try the following:</p> <ul style="list-style-type: none"> <li>● Check that the LAN cable of the scanner and SMTP server is connected properly.</li> <li>● Contact a system administrator to check that the scanner IP address, SMTP server and fax server settings are correct.</li> </ul> <p><a href="#">"8.3 Network Connection Troubleshooting" (page 456)</a></p> <ul style="list-style-type: none"> <li>● Contact a system administrator to check that the SMTP and fax servers are working properly.</li> </ul>
12020005	Fax size exceeded maximum fax size allowed by the SMTP server.	<p>Contact a system administrator to check the "Maximum Attachment Size" setting.</p> <p><a href="#">"4.7.11 Setting the e-Mail Server (SMTP Server)" (page 116)</a></p>
12020006	SMTP server connection was lost while sending fax data.	<p>Try the following:</p> <ul style="list-style-type: none"> <li>● Check that the LAN cable of the scanner and SMTP server is connected properly.</li> <li>● Contact a system administrator to check that the scanner IP address and SMTP server settings are correct.</li> </ul> <p><a href="#">"8.3 Network Connection Troubleshooting" (page 456)</a></p> <ul style="list-style-type: none"> <li>● Contact a system administrator to check that the SMTP server is working properly.</li> <li>● Contact a system administrator to check the maximum e-mail size allowed by the SMTP server.</li> </ul>



Code	Message	Action
12020100	Error: fax could not be sent.	<p>Try the following:</p> <ul style="list-style-type: none"> <li>● A message returned from the server is attached. Contact a server administrator to deal with the error.</li> <li>● If the [e-Mail address of user] option button is selected for "Notification To (Sender's e-Mail Address)", an error will occur when a job sequence is performed in the following cases: <ul style="list-style-type: none"> <li>● If the currently logged in user does not have an e-mail address</li> <li>● If logged in with the guest account</li> </ul> </li> </ul> <p>In this case, specify a user with a registered e-mail address and perform the job sequence.</p>
12030001	Cannot find the network printer path.	<p>Try the following:</p> <ul style="list-style-type: none"> <li>● Check that the LAN cable of the scanner and the print server are connected properly.</li> <li>● Contact a system administrator to check that the print server is working properly.</li> <li>● Check that the spooler is operating correctly.</li> <li>● Contact a system administrator to check that the scanner IP address and SMTP server settings are correct.</li> </ul> <p><a href="#">"8.3 Network Connection Troubleshooting" (page 456)</a></p>
12030002	Access to network printer was refused.	Contact a network administrator to find out if an access permit has been set.
12030005	Network is busy. Try again later.	Wait for a few minutes, and try again.
12030006	User name or password may be incorrect.	Enter the user name and password correctly.

Code	Message	Action
12030007	Not connected to the network.	Check that the system network is functioning normally by performing a ping test from another machine in the network, other than the server with network folder. If the system network is not operating correctly, refer to <a href="#">"Failure to connect to a server using its IP address" (page 461)</a> for further solutions.
1203000A	Number of network path connections has reached the maximum allowed. No more may be specified.	Close unneeded network connections, then try specifying the desired network path again.
1203000C	Specified user is no longer able to login to this network printer.	Try the following: <ul style="list-style-type: none"> <li>● Login with a different account.</li> <li>● Contact a network administrator to have the account for the network printer validated.</li> </ul>
1203000D	Specified password is no longer valid for this network printer.	Try the following: <ul style="list-style-type: none"> <li>● Login with a different account.</li> <li>● Contact a network administrator to have the password validated again.</li> </ul>
1203000E	Specified user needs to renew their password for this network printer.	Try the following: <ul style="list-style-type: none"> <li>● Login with a different account.</li> <li>● Contact a network administrator to have the password for the network printer changed.</li> </ul>
1203000F	Access to network printer was refused. The specified account is currently locked out.	Contact a network administrator to have the account for the network printer unlocked.
12030010	Access to network printer was refused. Login is not possible at this time.	Try the following: <ul style="list-style-type: none"> <li>● Try again when login is possible.</li> <li>● Contact a network administrator to have the time setting changed.</li> </ul>

Code	Message	Action
12030011	Could not connect to the network printer.	<p>Try the following:</p> <ul style="list-style-type: none"> <li>● Check that the LAN cable is connected properly to the scanner and print server.</li> <li>● Contact a network administrator to check that the print server is working properly.</li> <li>● Check that the print server spooler is operating properly.</li> <li>● Contact a network administrator to find out if an access permit has been set.</li> <li>● Contact a system administrator to check that the scanner IP address and network printer settings are correct.</li> </ul> <p><a href="#">"8.3 Network Connection Troubleshooting" (page 456)</a></p>
12030100	Error: could not print.	<p>Try the following:</p> <ul style="list-style-type: none"> <li>● Check that the LAN cable of the scanner and file server is connected properly.</li> <li>● Contact a system administrator to check that the scanner IP address and registered network printer path settings are correct.</li> <li>● Check the network printer authority privileges.</li> </ul>



Code	Message	Action
12040001	Cannot find the network folder path.	<p>Try the following:</p> <ul style="list-style-type: none"><li>● Check that the LAN cable of the scanner and file server is connected properly.</li><li>● Check that the file server is working properly.</li><li>● Contact a system administrator to check that the scanner IP address and network folder settings are correct.</li></ul> <p><a href="#">"8.3 Network Connection Troubleshooting" (page 456)</a></p> <ul style="list-style-type: none"><li>● When creating a folder, if the name of the folder to be created is already used by a file in the save location network folder, it cannot be created. Change the name of the file, or change the file name settings.</li></ul> <p>For saving to the FTP server network folder, try the following:</p> <ul style="list-style-type: none"><li>● Contact a system administrator to check whether or not read or write access to the FTP server network folder is permitted for the currently logged in user or authenticated user.</li><li>● Check if the file attribute has been set as hidden.</li><li>● Check that the target file to be overwritten is not used, and try again.</li></ul>
12040002	Access to network folder was refused.	<p>Try the following:</p> <ul style="list-style-type: none"><li>● Contact a system administrator to check whether or not access to the network folder is permitted for the currently logged in user or authenticated user.</li><li>● Check if the file attribute has been set as hidden.</li></ul>
12040003	File already existed, so data could not be saved.	<p>To overwrite the existing file, on the "Save" screen, set "Overwrite old files?" as "Yes", and try again.</p>
12040005	Network is busy. Try again later.	<p>Try again later.</p>

Code	Message	Action
12040006	User name or password may be incorrect.	<p>Try the following:</p> <ul style="list-style-type: none"> <li>● Re-enter the user name and password.</li> <li>● Check that the proxy server is operating properly.</li> <li>● Contact an administrator to check that the IP address settings, FTP server network folder, or proxy server settings are correct.</li> </ul> <p><a href="#">"8.3 Network Connection Troubleshooting" (page 456)</a></p>
12040007	Not connected to the network.	<p>Check that the system network is functioning normally by performing a ping test from another machine in the network, other than the server with network folder. If the system network is not operating correctly, refer to <a href="#">"Failure to connect to a server using its IP address" (page 461)</a> for further solutions.</p>
12040009	Insufficient free space in the designated network folder.	<p>Ensure the free space requirements are met, and try again.</p>
1204000A	Number of network path connections has reached the maximum allowed. No more may be specified.	<p>Close unneeded network connections, then try specifying the desired network path again.</p>
1204000B	File targeted for overwriting may already be in use.	<p>Check that the file to be overwritten is closed, and try again.</p>
1204000C	Specified user is no longer able to login to this network folder.	<p>Try the following:</p> <ul style="list-style-type: none"> <li>● Login with a different account.</li> <li>● Contact a network administrator to have the account validated.</li> </ul>
1204000D	Specified password is no longer valid for this network folder.	<p>Try the following:</p> <ul style="list-style-type: none"> <li>● Login with a different account.</li> <li>● Contact a network administrator to have the password validated again.</li> </ul>
1204000E	Specified user needs to renew their password for this network folder.	<p>Try the following:</p> <ul style="list-style-type: none"> <li>● Login with a different account.</li> <li>● Contact a network administrator to have the password changed.</li> </ul>

Code	Message	Action
1204000F	Access to network folder was refused. The specified account is currently locked out.	Contact a network administrator to have the account unlocked.
12040010	Access to network folder was refused. Login is not possible at this time.	Try the following: <ul style="list-style-type: none"> <li>● Try again when login is possible.</li> <li>● Contact a network administrator to have the time setting changed.</li> </ul>
12040011	"Save as:" file name contains invalid characters (:*?"<> ), or is set to a reserved string (CON, PRN, AUX, CLOCK\$, NUL, COM0, ..., COM9, LPT0, ..., LPT9). Re-enter the file name and try again.	Do not use the following symbols or character strings: : * ? " < >   CON PRN AUX CLOCK\$ NUL COM0 ... COM9 LPT0 ... LPT9 Re-enter the file name using only valid characters.



Code	Message	Action
12040100	Error: network folder access was refused.	<p>Try the following:</p> <ul style="list-style-type: none"> <li>● Contact a network administrator to check whether the network folder is ready for use.</li> <li>● For the MTIFF format, the file size for the scanned data may not exceed 2GB. Try adjusting the scan parameters to decrease the size of the file.</li> <li>● Check that the file name format and number of characters of the file name are allowed for the file server.</li> </ul> <p>For saving to the FTP server network folder, try the following:</p> <ul style="list-style-type: none"> <li>● Check that the LAN cable is connected properly to the scanner and FTP server.</li> <li>● Contact a network administrator to check that the FTP server is working properly.</li> <li>● Contact a system administrator to check that the scanner IP address setting and FTP server network folder path are correct.</li> </ul> <p><a href="#">"8.3 Network Connection Troubleshooting" (page 456)</a></p> <ul style="list-style-type: none"> <li>● Ensure the free space requirements are met, and try again.</li> <li>● Close unneeded network connections, and try specifying the network path again.</li> </ul>
12050001	Properties of file saved to SharePoint could not be manipulated.	Check the file status and the properties and access permission settings of the specified site, and try again.



Code	Message	Action
12050002	<p>File saved to SharePoint could not be accessed.</p> <p>Check the following, and fix as necessary:</p> <ul style="list-style-type: none"> <li>● Is the SharePoint server running short of free space?</li> </ul> <p>If problem persists, the administrator should contact the FUJITSU scanner dealer or an authorized FUJITSU scanner service provider for help.</p>	<p>Check the following, and fix as necessary:</p> <ul style="list-style-type: none"> <li>● Is the SharePoint server running short of free space?</li> <li>● Is the SharePoint Server working properly?</li> <li>● Contact a server administrator to find out if an access permit has been set.</li> </ul> <p>If problem persists, the administrator should contact the FUJITSU scanner dealer or an authorized FUJITSU scanner service provider for help.</p>
12050003	File saved to SharePoint could not be overwritten.	Check the write access of the specified site and the file status, and try again.
12050004	SharePoint sub-folder could not be created.	Check the write access of the specified site and the file status, and try again.
12050005	File size exceeds the SharePoint folder's file size limit.	Check the permitted file size, and try again.
12050006	Specified SharePoint folder not found.	Check that the specified folder exists.
12050007	Specified SharePoint library or folder not found.	Check that the specified library or folder exists.
12050008	<p>Specified SharePoint site not found.</p> <p>Check the following, and fix as necessary:</p> <ul style="list-style-type: none"> <li>● Is the specified SharePoint site connectible to?</li> <li>● If the SharePoint Server sign in screen appears, are the specified authentication settings correct?</li> </ul> <p>If problem persists, the administrator should contact the FUJITSU scanner dealer or an authorized FUJITSU scanner service provider for help.</p>	<p>Check the following, and fix as necessary:</p> <ul style="list-style-type: none"> <li>● Is the specified SharePoint site connectible to?</li> <li>● If the SharePoint Server sign in screen appears, are the specified authentication settings correct?</li> <li>● Can scan data be saved in the specified SharePoint folder?</li> </ul> <p>If problem persists, the administrator should contact the FUJITSU scanner dealer or an authorized FUJITSU scanner service provider for help.</p>
1205000A	Specified SharePoint file is already in use.	Check whether the specified file is being used, and try again.

Code	Message	Action
1205000B	Specified SharePoint site authentication failed.	Check the user name and password to be used for the site sign in, and try again.
1205000C	<p>Specified SharePoint site cannot be accessed.</p> <p>Check the following, and fix as necessary:</p> <ul style="list-style-type: none"> <li>● Is the specified SharePoint site connectible to?</li> <li>● If the SharePoint Server sign in screen appears, are the specified authentication settings correct?</li> </ul> <p>If problem persists, the administrator should contact the FUJITSU scanner dealer or an authorized FUJITSU scanner service provider for help.</p>	<p>Check the following, and fix as necessary:</p> <ul style="list-style-type: none"> <li>● Is the specified SharePoint site connectible to?</li> <li>● If the SharePoint Server sign in screen appears, are the specified authentication settings correct?</li> </ul> <p>If problem persists, the administrator should contact the FUJITSU scanner dealer or an authorized FUJITSU scanner service provider for help.</p>
1205000D	Specified SharePoint site access permission refused.	Check the access permission of the site.
12050015	<p>Scan to SharePoint file transfer error has occurred.</p> <p>Check the following, and fix as necessary:</p> <ul style="list-style-type: none"> <li>● Is the specified SharePoint site connectible to?</li> <li>● Is the SharePoint server running short of free space?</li> </ul> <p>If problem persists, the administrator should contact the FUJITSU scanner dealer or an authorized FUJITSU scanner service provider for help.</p>	<p>Check the following, and fix as necessary:</p> <ul style="list-style-type: none"> <li>● Is the specified SharePoint site connectible to?</li> <li>● Is the SharePoint server running short of free space?</li> <li>● Can scan data be saved in the specified SharePoint folder?</li> </ul> <p>If problem persists, the administrator should contact the FUJITSU scanner dealer or an authorized FUJITSU scanner service provider for help.</p>
12050016	File already exists. Choose a different name or change the overwrite permission setting.	Change the file name, or select [Yes] to overwrite the file with the same name.
12050018	Specified file type is not permitted for the selected SharePoint site.	Specify a file type that is permitted for the selected SharePoint site, and try again.

<b>Code</b>	<b>Message</b>	<b>Action</b>
12050100	SharePoint access error occurred.	Try the same operation again. If the problem persists, contact your FUJITSU scanner dealer or an authorized FUJITSU scanner service provider.
F4B30000	An error has occurred. Try turning the power off and back on again. The administrator should contact the FUJITSU scanner dealer or an authorized FUJITSU scanner service provider for help. [alphanumeric eight digits]	Shutdown and press the startup button to restart the scanner. If the error status persists, contact your FUJITSU scanner dealer or an authorized FUJITSU scanner service provider.
F4CA0000		
F4EF0000		
F2010002		
F2020002		
F2040002		

**E**

## E.3 Central Admin Messages

The following messages may appear during central admin operations.

### E.3.1 Central Admin Console Messages

Screen	Message	Action
Connect	Check the port number setting.	Enter a port number.
	Check the target server setting.	Enter a target server.
	Connection error.	Check the connection origin and port number, and try again.
	Language setting is different to that used by the Central Admin server.	Set the same language setting for the Central Admin server and Central Admin console operating systems.
Central Admin Console	fi Network Scanner Admin Tool could not be started. Check that it has been installed.	Check that the Admin Tool has been installed correctly.
Error	Output was interrupted before it could finish, and the results cannot be displayed. Return to the previous screen, and try again.	Try again.
System Error	Cannot connect to the database. The server may be overloaded. Contact the administrator if this error persists. ( <i>Error code</i> )	Try the following: <ul style="list-style-type: none"> <li>● Try again.</li> <li>● Restart the Central Admin Server.</li> </ul>
	Internal error has occurred. ( <i>Error type</i> )	Try the following with reference to the contents of the error details. <ul style="list-style-type: none"> <li>● Disconnect and re-login to the Central Admin console.</li> <li>● Close and restart the Central Admin console.</li> <li>● Restart the Central Admin server.</li> <li>● Check the amount of available free disk space</li> </ul>



Screen	Message	Action
Edit Scanner Details	Scanner details cannot be found. This scanner may have already been deleted.	Check the Central Admin server scanner configuration.
	Scanner registration limit has been reached.	Delete scanner configuration from the Central Admin server for scanners which are no longer needed, and try again.
	This scanner name or MAC address is already registered.	Delete scanner configuration information from the Central Admin server for scanners which are no longer needed, and try again. The MAC address may have been changed in the maintenance process. In this case, after deleting the relevant scanner configuration, restart the scanner.
	Scanner name must be specified.	Enter a scanner name.
	Scanner name contains invalid characters.	Re-enter the scanner name using only specified valid characters.
	Invalid IP address format.	Re-enter the IP address in the valid format.
	Invalid MAC address format.	Re-enter the MAC address in the valid format.
	Settings Group name contains a reserved string.	Enter a valid settings group name.
	Add-in Group name contains a reserved string.	Enter a valid Add-in group name.
Duplicate scanner name or MAC address.	Ensure that there are no duplications in scanner configuration files.	
Scanner Details	No more WakeOnLAN packets may be sent at this time. Wait, then try again.	Wait for a few minutes, and try again.

Screen	Message	Action
System Updates	File format is not valid.	Specify a valid file.
	Specified file does not exist or is empty.	Specify a valid update file. The error may also occur if the authority to access the file does not exist.
	A date/time within one month from now must be specified.	Specify a valid update call date/time.
	A date/time within one month from now must be specified.	Enter a valid date/time.
	File must be specified.	Specify a file, and try again.
	The same or a newer system update has already been uploaded.	No action required.
	The same Add-in install module has already been uploaded.	No action required. However, to upload the same version of the Add-in install module again, first cancel the currently uploaded file.
Scanner Settings/ Job Mode Settings	Cannot open the Setting window. It may be being accessed by another user.	Another user may be editing job mode settings or scanner configuration settings. Wait the other user to finish the operation, and try again.
Import Scanner Settings	Specified scanner settings file could not be found or could not be uploaded.	Try the following: <ul style="list-style-type: none"> <li>● Check the scanner settings to be imported.</li> <li>● Try importing again.</li> <li>● Check that a network error did not occur while processing the import, and that the status of the network is "transmitting".</li> </ul>
	Scanner settings could not be imported. Specified file contains unsupported data.	The system versions of the import target scanner and import source scanner are incompatible. Update the target scanner's system software. <a href="#">"4.10.3 Updating the Scanner's System Software" (page 175)</a>

Screen	Message	Action
Import Scanner Settings	Scanner settings could not be imported. The language of the scanner settings file must be the same as the current language setting.	Change the language setting back to the language at the time of backup, and try restoring the user data again.
Central Admin Server Settings	Invalid Central Admin Console port number.	Enter a valid Central Admin Console port number.
	Invalid scanner communication port number.	Enter a valid scanner communication port number.
	Invalid WakeOnLAN port number.	Enter a valid Wake-On-LAN port number.
	LDAP server must be specified.	Specify an LDAP server.
	Invalid LDAP server address.	Enter a valid LDAP server address.
	Specified port number is already being used.	Specify a free port number.
iScanner Central Admin	Could not get data from the server. Status code: (XXXXXX)	<p>Some of the status codes are as follows. Errors 12007 or 12029 may appear immediately after resuming from standby mode.</p> <ul style="list-style-type: none"> <li>● -1: Timeout occurred waiting for a response from the server</li> <li>● 500: SQL server instance is not running</li> <li>● 503: Application pool is not running</li> <li>● 12007: Network error</li> <li>● 12029: Cannot communicate with Web site (AmConsole)</li> <li>● 12031: Network error</li> </ul>



---

## E.3.2 System Log Messages

System log messages which may appear during central admin operations can be arranged into the following three categories:

- Information
- Warning
- Error

System log messages are shown in the scanner system log.

### ■ Information

Code	Message	Action
0B020001	Scanner registered by Central Admin server.	No action required.
0B020020	Add-in updated.	
0B020021	Scanner settings updated.	
0B020022	System updated.	
0B020023	User roaming data updated.	
0B020024	Job mode settings updated.	
0B020005	User roaming data uploaded.	
0B020006	Update process halted by login.	
0B020013	Central Admin server setting changed.	
0B020014	Update started by the Update Scheduler.	
0B020015	Update completed by the Update Scheduler.	

### ■ Warning

Code	Message	Action
6B020003	Request received from invalid server.	The scanner received an invalid access request. If the problem persists, contact the network administrator.



Code	Message	Action
6B020004	Network error occurred while contacting Central Admin server.	Refer to Code " <a href="#">7B020001</a> " (page 590). The Central Admin Server will be contacted again when the scanner is re-started, resumed from standby mode, or when the user logs out.
6B020005	Audit log upload failed.	Refer to Code " <a href="#">7B020001</a> " (page 590). The operating status notification will be sent to the Central Admin server at the next scanner startup, power off, login, logout, restart or resume from standby mode.
6B020006	Operating status notification could not be sent to the Central Admin server.	
6B020007	Error notification could not be sent to the Central Admin server. (xxxx)	Refer to Code " <a href="#">7B020001</a> " (page 590). An error notification could not be sent to the Central Admin server. The error code is shown in "xxxx".

**E**

## ■ Error

Code	Message	Action
7B020001	Scanner registration by Central Admin server failed.	<ul style="list-style-type: none"><li>● For Central Admin Server Check that the scanner is registered on the Central Admin Console "Scanner List" screen.</li><li>● For Scanner Enter the address of the Central Admin Server on the "Ping" screen on the [Network Settings] tab, and check whether or not there is a response from the Central Admin Server. If there is no response from the Central Admin Server, check whether or not DHCP is enabled on the "IP Address" screen on the [Network Settings] tab. If DHCP is disabled, check that the IP Address, Subnet Mask, Default Gateway settings are correct. Check also that the network between the scanner and the Central Admin Server is connected correctly. Also check that the scanner's server-side status is "Registered" on the "Central Admin Server" screen on the [Network Settings] tab. If the scanner's server-side status is "Unregistered", check the address and the port number of the Central Admin Server, and register the scanner on the Central Admin Server.</li></ul>

Code	Message	Action
7B020050	Add-in update failed.	<p>Refer to Error Code "<a href="#">7B020001</a>" (<a href="#">page 590</a>).</p> <p>Update is not complete.</p> <p>If the "Status Details" window in Central Admin Console displays "Error" status for the scanner, clear the error.</p> <p>Update process will be run again by logout.</p>
7B020051	System update failed.	
7B020038	Scanner settings could not be applied.	
7B020039	Some scanner settings could not be applied.	<p>When the scanner settings were applied, some settings may have failed to be applied. Using the Admin Tool, check the contents of the system error log, and try again.</p> <p>For more details about running the update process, refer to the action for error "<a href="#">7B020038</a>" (<a href="#">page 591</a>).</p>

Code	Message	Action
7B020060	User Roaming Data download failed.	<p>Refer to Error Code <a href="#">"7B020001" (page 590)</a>.</p> <p>The latest user roaming data may not be used because the user roaming data download failed. To use the latest user roaming data, deal with errors and try to login again.</p> <p>If the user roaming data download fails and the error persists, new user roaming data is not uploaded to the Central Admin Server, even if the user data in the scanner is changed or the scanner is logged out.</p> <p>If both "Roaming Mode" and "Job Mode" are set as "On" on the "Central Admin Server" screen of the [Network Settings] tab, new job mode settings may also not be downloaded.</p> <p>To use the latest user roaming data, it must be downloaded from the Central Admin Server. After dealing with the error, re-login using the Central Admin Console and try again.</p>
7B020061	Job Mode Settings download failed.	<p>Refer to Error Code <a href="#">"7B020001" (page 590)</a>.</p> <p>Job mode settings cannot be downloaded because the job mode settings have not been updated. To use the job mode settings, they must be downloaded from the Central Admin Server. After dealing with the error, re-login using Central Admin Console and try again.</p>

Code	Message	Action
7B020023	New user data could not be uploaded to the server's User Roaming store.	Refer to Error Code " <a href="#">7B020001</a> " (page 590). User roaming data cannot be updated because the new user data has not be uploaded to the Central Admin Server.
7B020035	Network error occurred while contacting Central Admin server.	Refer to Error Code " <a href="#">7B020001</a> " (page 590). The new user roaming data and job mode settings cannot be used. To use the user roaming data and job mode settings, they must be downloaded from the Central Admin Server. After dealing with the error, re-login using Central Admin Console and try again.
7B020036	Network error occurred while contacting Central Admin server.	Refer to Error Code " <a href="#">7B020001</a> " (page 590). The applied status was not notified to the Central Admin Server. The applied status will be notified to the Central Admin Server the next time the scanner is restarted, resumed from standby mode, or when the user logs out.
7B020011	Inventory Information acquisition failed.	Try the following: <ul style="list-style-type: none"> <li>● Check that physical network connection to the DHCP server is functioning correctly.</li> <li>● Check the DHCP server. The server may not be operating normally, or the DHCP settings (restricted number of leases or MAC address validation) may be causing invalid IP addresses to be assigned.</li> </ul> <p>If there are no problems with the items described above, contact your FUJITSU scanner dealer or an authorized FUJITSU scanner service provider.</p>



Code	Message	Action
7B020025	Contact with Central Admin server failed.	An error occurred. Contact your FUJITSU scanner dealer or an authorized FUJITSU scanner service provider.
7B020026	Contact with Central Admin server failed.	
7B020064	Scanner registration by Central Admin server failed.	Refer to Error Code " <a href="#">7B020001</a> " (page 590).
7B020065	Operating status notification function could not be started.	An error occurred. Contact your FUJITSU scanner dealer or an authorized FUJITSU scanner service provider.
7B020066	Error notification function fatal error.	An error occurred. Contact your FUJITSU scanner dealer or an authorized FUJITSU scanner service provider.

## E.3.3 Event Log

### ■ System Event Log

The system event log shows a list of all system events.

- Log Type: Application
- Event source: iScanner Central Admin

Code	Message	Action
11001	iScanner Central Admin server started up.	No action required.
11002	iScanner Central Admin server shut down.	
11901	Service started successfully.	
11902	Service stopped successfully.	
12001	Default setting is being used in place of invalid value. Parameter: XXXX Invalid value: XXXX Default value: XXXX	
12002	Tried to exceed the scanner registration limit.	Delete unneeded scanner configuration.
12003	Tried to exceed the user roaming data registration limit.	Delete any unneeded user roaming data.
12902	Schedule notification failed. Retrying. (XXXX)	No action required.
13001	Error has occurred. Type: Error Type Details: Error Details	Check the error details and other event logs.
13002	Inhospitable execution environment – process cannot continue. Details: Error Details	Check the error details and other event logs.
13003	Database could not be accessed. Details: Error Details	Check the database operating status.
13004	Schedule could not be set. Details: Error Details	Restart the iScanner Central Admin service.
13005	Settings used for communication between the Central Admin Server and Central Admin Console could not be changed. Details: Error Details	Restart the iScanner Central Admin service.

E

<b>Code</b>	<b>Message</b>	<b>Action</b>
13901	Scheduler could not be started. (XXXX)	Restart the iScanner Central Admin service.
13902	Schedule notification failed. (XXXX)	Check the operating status of the Web site using IIS Manager. If the operating system of the Central Admin Server is either Windows Server 2003 or Windows Server 2008, check the operating status of the Web site "AmService" and the application pool "AmService". If the operation system of the Central Admin Server is Windows 2000 Server, check the operating status of the Web site "AmService".
13903	Schedule (XXXX) expired and was deleted. [XXXX] events	The release schedules for seven or more days ago were deleted. Check the status of updates to the scanner, and issue any necessary update calls to scanners with "Pending" status.
13904	Error has occurred. (XXXX)	Restart the iScanner Central Admin service.



## ■ Central Admin Console Event Log

This displays the Central Admin Console event list. For message error details, only text up to the maximum character limit (256 characters) will be shown.

Code	Message	Action
0A011001	New system update <i>System_version</i> has been released. [Scanner Notification Schedule: <i>Date/time</i> ]	No action required. This indicates whether or not the [Scanner Notification Schedule: <i>Date/time</i> ], [ ] is shown.
0A011002	New Add-in install <i>Add-in_name</i> [ <i>Add-in_group</i> ] has been released. [Scanner Notification Schedule: <i>Date/time</i> ]	
0A011003	New scanner settings <i>Settings_group</i> have been released. [Scanner Notification Schedule: <i>Date/time</i> ]	
0A011004	Notifying target scanners of system update <i>System_version</i> .	No action required.
0A011005	Target scanners notified of system update <i>System_version</i> .	
0A011006	Notifying target scanners of Add-in install <i>Add-in_name</i> [ <i>Add-in_group</i> ].	
0A011007	Target scanners notified of Add-in install <i>Add-in_name</i> [ <i>Add-in_group</i> ].	
0A011008	Notifying target scanners of scanner settings <i>Settings_group</i> .	
0A011009	Target scanners notified of scanner settings <i>Settings_group</i> .	
0A011010	New Job Mode Settings released.	
0A011011	User roaming data uploaded to server. User: <i>XXXX</i>	
0A011012	Update call for system update <i>System_version</i> was canceled.	
0A011013	Update call for Add-in install <i>Add-in_name</i> [ <i>Add-in_group</i> ] was canceled.	

E

<b>Code</b>	<b>Message</b>	<b>Action</b>
0A011014	Update call for scanner settings <i>Settings_group</i> was canceled.	No action required.
0A011015	System update <i>System_version</i> release has been canceled.	
0A011016	Add-in module <i>Add-in_name</i> [ <i>Add-in_group</i> ] release has been canceled.	
0A011017	System settings <i>Settings_group</i> release has been canceled.	
0A011018	Job Mode Settings release has been canceled.	
0A021101	System update successfully applied.	
0A021102	Add-in install successfully applied.	
0A021103	Scanner settings successfully applied.	
0A021104	Scanner inventory has been updated.	
0A021105	Scanner has been registered.	
0A021106	Update call has been sent to scanner.	
0A021107	Wake-On-LAN magic packet sent to scanner.	
0A021108	Update cannot be applied immediately, because the scanner is being used, or for some other reason. It will be applied as soon as it is possible.	
0A021109	User roaming data uploaded to server. User: <i>XXXX</i>	
6A022101	Illegal access attempt. Scanner name: <i>XXXX</i> MAC address: <i>XXXX</i> IP address: <i>XXXX</i>	No action required. When registering from the scanner, if the its scanner configuration is not added to the Central Admin Server, and the [Automatically add new scanners to the Central Admin configuration when they are discovered.] checkbox in the "Central Admin Server Settings" window is not selected, this message appears.



Code	Message	Action
6A012002	Duplicate scanner name. Scanner name: <i>XXXX</i> MAC address: <i>XXXX</i> IP address: <i>XXXX</i>	Change the scanner name or delete unneeded scanner data, and try again. This error may occur when the MAC address is changed in the maintenance process. In this case, delete scanner configuration data, and re-start the scanner.
6A012003	Tried to exceed the scanner registration limit.	Delete any unneeded scanner configuration data.
6A012004	Tried to exceed the user roaming data registration limit.	Delete any unneeded user roaming data.
7A013001	System update <i>System_version</i> could not be released. Details: <i>XXXX</i>	Ensure that there is enough free disk space available. Check that there are no errors in the event viewer.
7A013002	Add-in install <i>Add-in_name</i> [ <i>Add-in_group</i> ] could not be released. Details: <i>XXXX</i>	
7A013003	Scanner settings <i>XXXX</i> could not be released. Details: <i>XXXX</i>	
7A013004	Job Mode Settings could not be released. Details: <i>XXXX</i>	
7A013005	Update call for system update <i>System_version</i> failed. Details: <i>XXXX</i>	Check the network status.
7A013006	Update call for Add-in install <i>Add-in_name</i> [ <i>Add-in_group</i> ] failed. Details: <i>XXXX</i>	
7A013007	Update call for scanner settings <i>Settings_group</i> failed. Details: <i>XXXX</i>	
7A013008	Error notification e-mail could not be sent. Details: <i>XXXX</i>	Check whether the SMTP server set for the "Error Notification Settings" on the "Central Admin Server Settings" screen and its network connection are working properly.

---

<b>Code</b>	<b>Message</b>	<b>Action</b>
7A023101	System update could not be applied. Details: <i>XXXX</i>	Refer to the system log for the scanner.
7A023102	Add-in install could not be applied. Details: <i>XXXX</i>	
7A023103	Scanner settings could not be applied. Details: <i>XXXX</i>	

## E.3.4 Backup/Restore Command Messages

Backup/restore command messages which may appear during central admin operations can be arranged into the following two categories:

- Information
- Error

Backup/restore command messages will be shown on the command prompt.

### ■ Information

Code	Message	Action
0A040001	Starting backup.	No action required.
0A040002	Finishing backup.	
0A040003	Starting restore.	
0A040004	Finishing restore.	

### ■ Error

Code	Message	Action
7A040010	iScanner Central Admin is not installed.	Central Admin Server software is not installed. Try again in a Central Admin Server that has been correctly installed.
7A040011	Backup folder has not been specified.	The backup file name is not specified in the parameters of the backup command and restore command. Specify the backup file, and try again.
7A040012	Backup folder does not exist.	Specify the backup folder that was specified with the backup command, and try again. Or, check the read privilege for the specified backup folder.
7A040013	Backup folder contents are invalid.	The backup folder specified in the parameter for the restore command is not a backup folder for Central Admin. Specify the Central Admin backup folder and try again.

E

Code	Message	Action
7A040014	Backup file already exists.	A file or folder exists in the backup folder. Specify an empty folder. If a folder which does not exist is specified, it will be created.
7A040015	Backup folder specification is invalid.	This error message is output in the following cases. After checking the error, run the command again. <ul style="list-style-type: none"> <li>● The backup folder specified in the parameter for the restore command does not have write access.</li> <li>● The specified backup folder name already exists as a file.</li> <li>● The backup file full path is longer than 128 bytes.</li> </ul>
7A040016	Server is busy. Try again later.	This message appears if the backup/restore command is executed during an update call on the Central Admin Server. Wait until the update call is finished, and try again.
7A040017	Backup failed.	If this message appears with auxiliary code [7A041012], free disk space may be insufficient. Ensure that there is enough free disk space available, and try again. If this message appears with auxiliary code [7A041015], it is possible that the database file used in the Central Admin Server is being used with a software other than the Central Admin Server software. Stop using the database file and try again. If this message appears without auxiliary code, the contents of the problem are shown in the following format. ... Problem details ... If this message appears frequently with auxiliary code other than those mentioned above, contact your FUJITSU scanner dealer or an authorized FUJITSU scanner service provider.



Code	Message	Action
7A040018	Restore failed.	<p>If this message appears with auxiliary code [7A041013], free disk space may be insufficient. Ensure that there is enough free disk space available, and try again.</p> <p>If this message appears with auxiliary code [7A041008], a file in the restoration folder may be in use. Check that the file is not in use, and try again.</p> <p>If this message appears with auxiliary code [7A041015], it is possible that the database file used in the Central Admin Server is being used with a software other than the Central Admin Server software. Stop using the database file and try again.</p> <p>If this message appears without auxiliary code, the contents of the problem are shown in the following format.</p> <p>...</p> <p>Problem details</p> <p>...</p> <p>If this message appears frequently with auxiliary code other than those mentioned above, contact your FUJITSU scanner dealer or an authorized FUJITSU scanner service provider.</p>
7A040019	Backup or restore is already running.	Try again, after finishing the backup or restoration.
7A040020	Port number (XXXX) is already in use.	Port number (XXXX) is already in use by another application. Change the settings of the application using XXXX, and try restoring again.
7A040021	Backup folder is not empty.	<p>A file or folder exists in the backup folder. Specify an empty folder.</p> <p>If a folder which does not exist is specified, it will be created.</p>

---

Code	Message	Action
7A040023	Restoration from this version of backup file is not possible.	The backup file saved by executing the AmBackup.exe command in the Central Admin Server of the previous version cannot be restored with the AmRestore.exe command in the Central Admin Server of new version. Refer to <a href="#">"5.17.4 Migrating Data to an Updated Version of the Central Admin Server Software"</a> (page 295), and try backing up again.



## E.3.5 Audit Log Export Command Messages

Code	Message	Action
7A050010	iScanner Central Admin is not installed. Error message details: <i>XXXXXXXXXX</i>	Check whether or not the Central Admin Server is installed correctly. Check whether the command is being executed with administrative privileges for the computer.
7A050012	Audit log export failed. Error code details: <i>XXXXXXXXXX</i> Error message details: <i>XXXXXXXXXX</i>	<p>Confirm the error message, and try the following:</p> <ul style="list-style-type: none"> <li>● Check that there is enough free disk space in the destination (export-to) folder.</li> <li>● Check that the destination (export-to) folder is specified correctly.</li> <li>● Check that the destination (export-to) folder, the destination (export-from) folder, and log file have write access.</li> <li>● Check that there is not a file of the same file name without write access in the destination (export-to) folder.</li> <li>● Check that the audit log that failed to be exported is not being used in another application.</li> </ul>
7A050014	Command is already running.	Try again after the command execution is completed.
7A050015	Error has occurred. Error message details: <i>XXXXXXXXXX</i>	An unexpected error occurred. Contact your FUJITSU scanner dealer or an authorized FUJITSU scanner service provider.
7A050016	Length of specified folder path exceeds the maximum allowed.	The copy destination folder path length specified in the command line exceeds 180 bytes. Specify a copy destination folder path that is no longer than 180 bytes.



# *Appendix F*

---

## **Compatibility with Different Versions**

This appendix explains the compatibility with different versions of scanner systems and the Central Admin Server software.



<b>F.1 Backing Up/Restoring User Data and Scanner Settings.....</b>	<b>608</b>
<b>F.2 Updating System Settings from the Central Admin Server .....</b>	<b>609</b>
<b>F.3 Functional Compatibility between the Scanner and Central Admin Server..</b>	<b>610</b>
<b>F.4 Backing Up/Restoring Data between Different Versions of the Central Admin Server Software.....</b>	<b>611</b>

---

## F.1 Backing Up/Restoring User Data and Scanner Settings

The following shows the compatibility between different versions of the scanner system version, regarding backup and restoration of user data and scanner settings.

- User data

Scanner Version for Backup	Scanner Version for Restoration	Compatibility
is001 02.01.xx.xxxx or later	is001 02.01.xx.xxxx or later	Yes
is001 02.01.xx.xxxx or later	is001 01.04.xx.xxxx or earlier	Yes (*1)
is001 01.04.xx.xxxx or earlier	is001 02.01.xx.xxxx or later	Yes (*2)

- System settings

Scanner Version for Backup	Scanner Version for Restoration	Compatibility
is001 02.01.xx.xxxx or later	is001 02.01.xx.xxxx or later	Yes
is001 02.01.xx.xxxx or later	is001 01.04.xx.xxxx or earlier	No
is001 01.04.xx.xxxx or earlier	is001 02.01.xx.xxxx or later	Yes (*2)

(\*1): Functions supported within the range of "is001 01.04.xx.xxxx or earlier" can be restored.

(\*2): Default values are used for setting items added in "is001 02.01.xx.xxxx or later".

---

## F.2 Updating System Settings from the Central Admin Server

The following shows the compatibility of system setting updates between different versions of the Central Admin Server and the scanner system version.

The version of the Central Admin Server software can be checked on the Central Admin Console login screen.

Central Admin Server Version	Scanner System Version	Compatibility
2.4.x or later	is001 02.01.xx.xxxx or later	Yes
2.4.x or later	is001 01.04.xx.xxxx or earlier	Yes (*1)
2.3.x or earlier	is001 02.01.xx.xxxx or later	Yes (*2)

(\*1): System settings within the range of "is001 01.04.xx.xxxx or earlier" can be updated.

(\*2): Default values are used for setting items added in "is001 02.01.xx.xxxx or later".

---

## F.3 Functional Compatibility between the Scanner and Central Admin Server

The following shows the functional compatibility between different versions of the scanner system and the Central Admin Server.

The version of the Central Admin Server software can be checked on the Central Admin Console login screen.

Central Admin Server Version	Scanner System Version	Compatibility
2.4.x or later	is001 02.01.xx.xxxx or later	Yes
2.4.x or later	is001 01.04.xx.xxxx or earlier	Yes (*1)
2.3.x or earlier	is001 02.01.xx.xxxx or later	Yes (*2)

(\*1): Can be connected and used within the range supported by the scanner.

(\*2): Can be connected and used within the range supported by the Central Admin Server.

---

## F.4 Backing Up/Restoring Data between Different Versions of the Central Admin Server Software

The following shows the compatibility between different versions of the Central Admin Server software for backing up or restoring data.

The version of the Central Admin Server software can be checked in the Central Admin Console "Login" window.

Central Admin Server Software Version for Data Backup	Central Admin Server Software Version for Data Restoration	Compatibility
2.4.x or later	2.4.x or later	Yes
2.4.x or later	2.3.x or earlier	No
2.3.x or earlier	2.4.x or later	Yes (*1) (*2)

- (\*1): When Central Admin Server settings are restored from a previous version of the Central Admin Server, default values are set for items newly added in that of later version.
- (\*2): To back up data, use the "AmBackup.exe" command from version 2.4.x of the Central Admin Server. For how to execute the command, refer to ["5.17.4 Migrating Data to an Updated Version of the Central Admin Server Software"](#) (page 295).





# *Appendix G*

---

## **Glossary**

Admin

User



---

## **A4 size**

A standard international paper size. (210 × 297mm / approximately 8.27 × 11.7inches)

## **A5 size**

A standard international paper size. (148 × 210mm / approximately 5.83 × 8.27inches)

## **A6 size**

A standard international paper size. (105 × 148mm / approximately 4.13 × 5.83inches)

## **ADF (Automatic Document Feeder)**

A unit that allows the user to scan a number of pages consecutively.

Documents are transported from the ADF paper chute past the scanning area to the output tray. Actual scanning is performed by the CCD sensors inside of this unit.

## **B5 size**

A standard international paper size. (182 × 257mm / approximately 7.17 × 10.12inches)

## **B6 size**

A standard international paper size. (128 × 182mm / approximately 5.04 × 7.17inches)

## **Brightness**

Refers to the brightness level of the scanned images.

## **Business card size**

A standard paper size. (51 × 89mm)

Portrait orientation is used for this scanner.

## **Canadian DOC Regulations**

A standard issued by Industry Canada, a department of the Canadian government, which sets out the technical requirements relative to the radiated and conducted radio noise emissions from digital apparatus.

---

## Carrier Sheet

A Carrier Sheet is a plastic sheet specifically used for loading non-standard documents onto the scanner.

## Default settings

The settings installed at time of factory shipping.

## Duplex scan mode

A scan mode where both sides of each document sheet are scanned. See also "Simplex scan mode".

## dpi (dots per inch)

Dots per inch. Number of dots lined along one inch. The measurement of resolution normally used for scanners and printers. Higher dpi means better resolution.

## Executive size

A standard international paper size. (184.2 × 266.7mm / approximately 7.25 × 10.5inches)

## FCC

Acronym for "The Federal Communications Commission", an independent United States government agency which is in charge of regulating interstate and international communications via radio, television, wire, satellite and cable. The Part 15 of the FCC regulations mentioned in this manual is designed to prevent harmful interferences on radio communication of radio receivers and other devices which radiate radio frequency energy, and provides for the certification of radio receivers. It also provides the certification of low power transmitters and the operation of certificated transmitters without a license.

## Feed roller

Rollers that feed documents through the ADF.

## Idler roller

Rollers that feed documents through the ADF.

## Interface

The connection that allows communication from the computer to the scanner.

---

## **Landscape orientation**

A document with its long side horizontal and its short side vertical. See also "Portrait orientation".

## **LDAP (Lightweight Directory Access Protocol)**

A protocol for accessing a directory database over a TCP/IP network.

## **Legal size**

A standard international paper size. (215.9 × 355.6mm / 8.5 × 14inches)

## **Letter size**

A standard North American paper size. (215.9 × 279.4mm / 8.5 × 11inches)

## **MMR**

ITU-T (CCITT) T.6 compression.

A compression method used when the color mode is black and white.

## **Multifeed detection**

A scanner function which detects accidental feeding of multiple sheets into the ADF.

## **Noise**

Isolated white (black) dots appearing on black (white) areas of an image.

## **Pad assy (PAD ASSY)**

A collection of rubber pads and metal leaf springs that is used to help separate a single document sheet from a batch in the ADF paper chute for feeding into the ADF.

## **Paper jam**

A warning that appears when a document sheet is jammed in the document feed path, or document feeding is interrupted by a slipping sheet.

## **Pick roller**

A roller that picks the next document sheet out of the ADF paper chute and the ADF.

---

## **Portrait orientation**

A document with its long side vertical and its short side horizontal.  
See also "Landscape orientation".

## **Postcard size**

A standard paper size. (100 × 148mm / approximately 3.94 × 5.83inches)  
Portrait orientation is used for this scanner.

## **Resolution**

A measure of the fineness of details or grain of images. The customary metric of resolution is dpi (dots per inch). For any given image, the higher the resolution, the more dots or pixels that can be used, and the greater the resulting fineness of detail that can be expressed.

## **Simplex scan mode**

A scan mode where only one side of each document sheet is scanned. See also "Duplex scan mode".

## **Ultrasonic sensor**

A type of sensor that uses ultrasonic sound waves, in this case to detect document multifeeds by recognizing differences in how the sound penetrates single versus multiple sheets.



# Index

---

## A

AC adaptor connector .....	5
Add-in module .....	177
adding	
a contact to the e-mail address book .....	324
a contact to the fax number list .....	335
a job group .....	210
a job menu .....	203
a job sequence .....	185
ADF .....	6
ADF paper chute .....	5
ADF release button .....	5
admin password .....	71
Admin Tool .....	47, 52
administrator login .....	44
administrator .....	31, 37, 53, 223
administrator login .....	42
administrator screen messages .....	503
administrator screens	
via the Admin Tool .....	40
via the touch panel .....	38
alert notification .....	149
AmBackup.exe .....	291
AmExportLog .....	287
AmRestore.exe .....	293, 294
area not to be perforated .....	483
auto logout .....	66

## B

background removal .....	394
--------------------------	-----

## backing up

data between different versions of the	
Central Admin Server software .....	611
system settings .....	172
the user data store .....	167
user data and scanner settings .....	608
black & white .....	373
blank page skip .....	395
brightness .....	390

## C

carbonless paper .....	480
care .....	423
carrier sheet .....	372, 435, 437
Central Admin Console	
main window .....	263
Central Admin Console window .....	224, 227
central admin settings	
backing up .....	291
maintaining .....	291
restoring .....	293
certificate management .....	84
changing	
a file name	
(for save/e-mail attachment) .....	419
the admin password .....	71
checking	
the number of sheets to be scanned .....	420
the user log .....	410
Cleaner F1 .....	424

cleaning	424
frequency	425
the ADF	426
the carrier sheet	435
the keyboard	434
the LCD touch panel	433
cleaning paper	424
cleaning wipe	424
clearing	
the system log	164
the user data store	170
the user logs	161
cloning	
a job menu	208
a job sequence	197
color mode	373
common buttons and indicators	304
compatibility with different versions	607
compression	380, 387
contrast	391
converting scanned data into a searchable PDF	382
CSV format	161, 164, 171
custom	367

## D

date/time	64
default	367
deleting	
a contact from the fax number list	338
a job group	215
a job menu	209
a job sequence	198
a scanned page	409
device specifications	498

DHCP server	18
document loading capacity	482
downloading	
the system log	164
the system settings	171
the user logs	161
dropout color	393
duplex	351

## E

edge cropping	400
editing	
a contact in the fax number list	337
a job group	215
a job menu	208
a job sequence	197
an e-mail target in the e-mail address book	327
e-mail	314
e-mail address book	319, 324, 327, 329
e-mail LDAP server	108
exporting audit logs	286

## F

fax number list	332, 335, 338
fax number maximum contacts	335
fax server	18, 118
features	2
feed rollers	425, 430
file format	380, 381
of audit logs	289
file server	17
filtering job sequence	198
firewall	239
folder alias	135, 137



folder list .....	352
FTP path .....	138
FTP server .....	17
Functional Compatibility between the Scanner and Central Admin Server .....	610

## G

glass scanner windows .....	6, 431
glossary .....	613
grayscale .....	373

## I

idler rollers .....	425, 431
installing	
add-in .....	268
an add-in module .....	177
the Admin Tool .....	47
the Central Admin Console .....	236
the Central Admin Server software .....	231
IP address .....	86

## J

job menu .....	308
job progress .....	415
job report .....	416
job setting quick user guide .....	183

## K

keyboard .....	5, 29, 434
----------------	------------

## L

LAN connector .....	5
LCD touch panel .....	5, 28, 433
LDAP list .....	199, 218, 320
LDAP server .....	312

location .....	63
login .....	311
via the Admin Tool .....	53
via the Central Admin Console .....	241
via the touch panel .....	42
logout .....	38
long page .....	376

## M

main menu .....	306
maintenance .....	165
managing	
certificates .....	84
the system log .....	162
materials	
cleaning .....	424
maximum document loading capacity .....	482
menu mode .....	306, 309
menu tab .....	38
migrating data to an updated version of the Central Admin Server software .....	295
monitoring and maintaining the iScanner Network .....	263
multifeed detection .....	78, 399
multi-function main menu .....	217
my list .....	327

## N

network folder .....	133
network folder details .....	144
network path .....	136
network printer alias .....	126, 128, 136
network settings .....	86, 93
network tree .....	124
NTP server .....	18

---

<b>O</b>	
obtaining technical support .....	180
offset .....	81
operation logs .....	159
operation messages .....	501
operations .....	7, 31, 297
output tray .....	5

<b>P</b>	
pad assy .....	6, 425, 429, 436, 439
page orientation .....	396
paper quality .....	479
paper requirements .....	479
paper size .....	374, 376, 478
paper type .....	479
paper weight .....	479
part name .....	4
part to clean .....	425
PDF password .....	380, 385
pick roller .....	6, 425, 431, 436, 440
ping .....	150
plastic cards .....	481
port number list .....	20
positioning .....	349
pre-settings	
for using Central Admin Console .....	231
print .....	339
print server .....	18
printer details .....	131
printer list .....	339
processing a job .....	413
proxy server .....	98

<b>Q</b>	
quick guide	
Central Admin Console .....	229

<b>R</b>	
region/timezone .....	63
registering	
a network folder .....	133, 136
a network printer .....	124, 127
regular user .....	297
removing	
a network folder .....	143
a network printer .....	130
renaming	
a network folder .....	141
a network printer .....	129
replacement cycle .....	436, 437
replacing	
parts .....	436
the pad assy .....	439
the pick roller .....	440
report to administrator .....	416
required scanner function settings .....	33
resetting the usage counter .....	157
resolution .....	378
restoring	
data between different versions of the	
Central Admin Server software .....	611
the user data store .....	169
user data and scanner settings .....	608
rotating a scanned page .....	407

<b>S</b>	
SAM account name .....	107
save .....	352

saving	
the scanned data in a SharePoint	
server	357
to a network folder	352
scaling	344
SCAN button	5
scan mode	379
scan settings	365, 380
scan test	445
Scan to SharePoint	357
scan viewer	402, 405
scanner specifications	499
search string	333
searchable PDF	380, 382
selecting	
a fax number	332
an e-mail target	319
semi-transparent documents	480
send fax	332
sending	
by e-mail	314
by fax	330
setting	
a file name format (e-mail)	76
a file name format (save)	72
a job group	210
a job item	189
a job menu	203
a job sequence	185
job features	181
scanner configuration	254
scanning performance	81
the Central Admin Server	244
the date/time	64, 66
the destination for alert notifications	149
the DNS server	93
the e-mail server	116
the fax server	118
the information output level	179
the job mode	275
the language	62
the LDAP search parameters	111
the multideed detection method	78
the network folders	132
the NTP server	96
the proxy server	98
the region/timezone	63
the scan options	365
the SharePoint folders	145
the time to standby mode	66
the WINS server	95
SharePoint server	17
sharpness	392
sheet guide	6
side guides	5
simplex	351
SMTP server	17, 116
specifications	487, 493, 497
standby	26
standby mode	67
startup button	5, 26, 312
system log	162
system settings	56
system settings file	171
system status	154
<b>T</b>	
text recognition language	384
top cover	5
touch panel	38

---

turning the power on/off .....24

## U

ultrasonic sensors ..... 425, 431

uninstalling

    an Add-in module .....178

updating

    scanner system settings .....271

    system settings from the Central Admin

        Server .....609

    the scanner's system software .....175

URL .....47

usage status ..... 156, 157

user data store .....170

user log ..... 159, 410

user log summary .....159

user principal name .....107

## V

viewing

    a scanned page .....406

    event log .....284

    the detailed settings for a job menu .....209

    the scanners operating status .....281

    the status of consumable parts .....156

    the status of installed options .....155

    the system log details .....162

    the system status .....154

    the update status lists .....278

    the user log details .....159

## W

WINS server .....18

wood containing paper .....480

---

## **fi-6010N Network Scanner**

### **Operator's Guide**

**P3PC-2802-02ENZ0**

Date of issuance: January, 2010  
Issuance responsibility: PFU LIMITED

- 
- The contents of this manual are subject to change without notice.
  - PFU LIMITED is not liable whatsoever for any damages resulting from the use of this scanner and procedures described in this manual, profit loss due to defects, and any claims by a third party.
  - Copying of the contents of this manual in whole or in part and copying of the scanner application is forbidden under the copyright law.