MPUIQ-SRL MODULE
Quick Installation Guide

VERTIV™

The MPUIQ-SRL module is one part of the Avocent® MergePoint Unity™ KVM over IP and serial console switch system.

1. **Turn on your switch**
Connect the power supply to an appropriate AC wall outlet and turn on your switch.

2. **Connecting an MPUIQ-SRL module to a serial device**
Attach the MPUIQ-SRL module CAT5 connector to the serial device.

3. **Connecting an MPUIQ-SRL module to a serial device using an adaptor (optional)**
Attach the MPUIQ-SRL module to an RJ45 to 9-pin female adaptor. Attach the adaptor to the serial port of the serial device.

4. **Connecting an MPUIQ-SRL module to the switch**
Plug one end of a user-supplied CAT5 cable (4-pair, up to 100 ft/30 m) into an available numbered port on the rear of the MergePoint Unity switch. Plug the other end into the RJ45 connector of the MPUIQ-SRL module.

5. **Connecting an MPUIQ-SRL module to the power supply via an expander**
Connect the power supply to the power connector on your MPUIQ-SRL module. You can also use the cable expander to power up to four MPUIQ-SRL modules from a single power supply.

6. **Connecting an MPUIQ-SRL module to a USB to barrel power cord (optional)**
Attach the power end of a USB to barrel power cord to the power connector on your

MPUIQ-SRL Module Standard Configuration

Avocent® MergePoint Unity™ switch

Serial device

MPUIQ-SRL module

Power supply

Expander

Serial device

MPUIQ-SRL module. Plug the other end into the USB port on your serial device.

NOTE: You cannot use the expander with the USB to barrel power cord.

7. **Turning on your system**
If using the power supply, connect the MPUIQ-SRL module power supply to an appropriate AC wall outlet. Turn on your serial device.

USA Notification

NOTE: *Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.*

NOTE: *This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.*

Canadian Notification

This Class A digital apparatus complies with the Canadian ICES-003.
Cet appareil numérique de la classe A est conforme à la norme NMB-003 du Canada.

Japanese Notification

この装置は、情報処理装置等電波障害自主規制協議会（ＶＣＣＩ）の基準に基づくクラスA 情報技術装置です。この装置を家庭環境で使用すると電波妨害を引き起こすことがあります。この場合には使用者が適切な対策を講ずるよう要求されることがあります。

Korean Notification

기종별	사용자 안내문
A급 기기 (업무용 정보통신기기)	이기기는 업무용으로 전자파적합등록을 한 기기이오니 판매자 또는 사용자는 이 점을 주의하시기 바라며 만약 잘못 판매 구입 하였을 때에는 가정용으로 교환하시기 바랍니다.

European Union

WARNING: *This is a class A product. In a domestic environment this product may cause radio interference in which case the user may be required to take adequate measures.*

Safety, EMC and Environmental Approvals and Markings

Safety certifications and EMC certifications for this product are obtained under one or more of the following designations: CMN (Certification Model Number), MPN (Manufacturer's Part Number) or Sales Level Model designation. Designations that are referenced in the EMC and/or safety reports and certificates are printed on the label applied to this product.
For use with Listed Information Technology Equipment (I.T.E.).

AVO-CMN1000-002(A)
AVOCENT CORP.
RIP/CMN:1000-002